How to read oil container label:

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is added to some oil containers to help you select the oil you should use.



## Cooling system

Capacity (Reference)	<ul> <li>≥ 2.5 L 4-cylinder (A25A-FKS) engine</li> <li>7.3 qt. (6.9 L, 6.1 Imp. qt.)</li> <li>≥ 3.5 L V6 (2GR-FKS) engine</li> <li>9.1 qt. (8.6 L, 7.6 Imp. qt.)</li> </ul>
Coolant type	Use either of the following:

## Ignition system

Spark plug	
Make	▶ 2.5 L 4-cylinder (A25A-FKS) engine
	DENSO FC16HR-Q8
	▶ 3.5 L V6 (2GR-FKS) engine
	DENSO FK20HBR8
Gap	0.031 in. (0.8 mm)



## NOTICE

## ■Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust spark plug gap.