
MAINT REQD Maintenance required reminder light P. 423



or

High engine coolant temperature warning light (the rightmost segment of the engine coolant temperature display flashes) P. 421

*1: The light comes on in yellow to indicate a malfunction.

^{*2:} The light flashes in yellow to indicate a malfunction. The light flashes quickly in green to indicate that the steering lock has not been released.