■ Door lock (→P. 147, 156, 559)

Function	Default setting	Customized setting	1	2
Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step.	_	0
Automatic door lock	Shift position linked door lock-ing operation	Off	0	0
		Speed linked door locking operation		
Automatic door unlock	Shift position linked door unlocking opera- tion	Off	0	0
		Driver's door linked door unlocking oper- ation		
Locking/unlocking of the trunk when all doors are locked/unlocked*	On	Off	_	0

^{*:} Vehicles with a smart key system

■ Smart key system* and wireless remote control (→P. 147, 156, 161)

Function	Default setting	Customized setting	1	2
Operation buzzer volume	5	Off to 7	0	0
Operation signal (Emergency flashers)	On	Off	0	0
Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	60 seconds	Off	0	О
		30 seconds		
		120 seconds		
Open door warning buzzer	On	Off	_	0

^{*:} If equipped