■ HUD (Head-up display) (if equipped) (→P. 128)

Press o to enable/disable the head-up display.

Item	Settings	Details
HUD	On	Select to enable/disable the
	Off	head-up display.

Item	Settings	Details
HUD Brightness/Position		 Select to adjust the brightness/ position of the head-up display. Press the ⟨/⟩ switch to adjust the display brightness. Press the ∧/∨ switch to adjust the display position.
HUD Driving sup- port	Tachometer set- tings	Select to change the display between the following:
	Navigation system (if equipped)	Select to enable/disable head-up display content.
	Driving Assist	
	Compass (if equipped)	
Rotation		Select to adjust the angle of the head-up display.
		Press the 〈 / > switch to adjust the display angle.