■ 🏂 PCS (Pre-Collision System) (→P. 254)

The following pre-collision system settings can be changed:

Item	Settings	Details
PCS	On	Select to enable/disable the pre-
	Off	collision system.
Warning sensitivity	Early	
	Middle	Select to change the warning timing.
	Late	···· 9 ·

■ RCC (Dynamic Radar Cruise Control) (→P. 290, 306)

Item	Settings	Details
Curve speed reduction	Strong Weak Off	Select to change the vehicle speed reduction strength.

■ BSM (Blind Spot Monitor) function (if equipped) (→P. 330)

Item	Settings	Details
BSM	On	Select to enable/disable the
	Off	Blind Spot Monitor function.

■ RCTA (Rear Cross Traffic Alert) function (if equipped) (→P. 345)

Item	Settings	Details
RCTA	On	Select to enable/disable the Rear
	Off	Cross Traffic Alert function.

■ RCD (Rear Camera Detection) function (if equipped) (→P. 354)

Item	Settings	Details
RCD	On	Select to enable/disable the rear
	Off	camera detection.