AVTools v3.1.0 — Release Notes

Revit 2025, 2026 and 2027 · J. Stevens BIM Acoustics, LLC

v3.1.0 adds **Revit 2027**, **F1 help** on every ribbon button, and a set of fixes from testing v3.0.0 with EASE 5. One installer covers Revit 2025, 2026 and 2027.

Revit 2027 and the ribbon

- **Revit 2027.** System Designer, SpecTool and Room Exchange now run in Revit 2027 as well as 2025 and 2026, from the same installer.
- **F1 help.** Hover over any button on the BIM Acoustics tab and press F1 to open its help page on bimacoustics.net.
- **Two panels. AV Tools** holds System Designer and SpecTool; **Utilities** holds Room Exchange, Lucius and License Manager. The empty Acoustics Tools panel is gone.

Room Exchange

- **Include loudspeakers.** A tick box beside **Export to** adds the System Designer loudspeakers in the ticked rooms to the export, and shows how many the model holds. It is remembered for the next export.
- **EASE 5 loudspeaker targets.** EASE 5 cannot import loudspeakers from a drawing, so each one is written as a small target face on the `AVTOOLS-SPEAKER-TARGETS` layer. A ceiling loudspeaker's target now lies flat one inch under the ceiling, inside the room, so it can be picked in plan; the text labels that EASE 5 rejected are gone.
- **A note before an EASE 5 export with loudspeakers.** EASE 5 imports the targets as surfaces and warns that they sit on the ceiling face. Room Exchange says so first: **Continue** exports with the targets, **Exclude loudspeakers** exports the room only. Place an EASE loudspeaker at each target, then delete the `AVTOOLS-SPEAKER-TARGETS` selection set before calculating.
- **.NET check.** The separate program that builds the EASE model runs on the .NET installed in Windows. For Revit 2025 and 2026 it now needs the .NET 8 Desktop Runtime 8.0.32 or later, as Autodesk requires App Store add-ins to run on a .NET release with the current security fixes. If the PC's .NET is older, Room Exchange shows what is installed and what is needed, with a link to Microsoft's download page, or builds the model inside Revit instead.

System Designer

- **Iso-map.** Coverage is sampled on a grid no coarser than a quarter of the loudspeaker spacing, so each loudspeaker gets its own contour instead of contours that merge and split. Checked against EASE 5 at

the same listener height.

- **Drawing a room's iso-map in a second view** no longer stops with "The type name JSBA_DFM_... is already in use".
- **Messages** from System Designer open in front of its window instead of behind it, where they could leave the window blank until they were found.
- **Tag families.** The "JSBA Circuit ID Tag w Tap" family is no longer installed; use "JSBA Circuit ID Tag w Watts".

Lucius

- **Transcript opt-in is off unless you turn it on.** The first time you open Lucius you are asked once, with No as the default.
- **Share anonymous transcripts** tick box in the Lucius window, kept in step with the one on the About tab.

Security

- System.IO.Packaging updated to 8.0.1.
- Room Exchange's separate program requires .NET 8.0.32 or later (Revit 2025 and 2026).
- An unused component (Microsoft.Bcl.HashCode 6.0.0) is no longer installed.
- Every AVTools program file (DLL and EXE) in the installer is signed by J. Stevens BIM Acoustics LLC.

Installing

Installing v3.1.0 replaces v3.0.0 and earlier. Project state, license activation, settings and EULA acceptance carry forward. Close Revit before installing. Lucius and SpecTool need an internet connection; everything else, Room Exchange included, works offline once your license is activated. Room Exchange's DWG export for EASE 5 still needs AutoCAD on the same machine.