## 2 All Settings Menu

- 2.1 All Settings Menu Order 2.2 Navigation of All Settings 2.3 VIZIO Test (Hidden) Menu

	Settings Menu Requirement	Notes
1	TV settings are either adjusted from All Settings menu on the TV using the IR remote or from the SmartCast Mobile app.	All settings, also known as the sidebar.
2	When SmartCast Mobile app is used to adjust settings, the order is the same as in the All Settings menu displayed on the TV.	Differences are only as required for settings as per limitation of the app.
3	When a system setting is changed using SmartCast Mobile app, a notification displays confirming the change has been completed with exception that changes to most parental control settings do NOT display a notification on the TV.	
4	When SmartCast Mobile app is used to adjust the value of a slider, the adjustment is also annunciated on the TV with a slider (no notification in this case).	
5	When the MENU or gear key is first pressed, the header for the menu is All Settings.	
6	The default selected setting is the top setting (Picture) if no selection previously made. Thereafter All Settings launches with the last used setting selected.	
7	All Settings Timeout and Dismissal:	1 minute timeout does not apply:
Durii Ante • A INPU • key no d • F • S	idebar is dismissed.  ng one 1 minute timer, if another key press the restart the 1 minute timer.  enna Scan complete then 1 minute timer starts.  key press that displays another UI takes down the sidebar including:  T, PIC, MIC, HOME, partner keys  dismisses Quick and deep links to Picture mode.	puring antenna scan. Pystem Info (system info timeout after 5 hinutes). Idden menu on-customer facing ODM/SOC menus including actory menus alk Back voicing C notifications and closed captions do not take own TV settings.
8	If a setting, option or name exceeds the maximum of 15 characters for input name or 24 characters for TV name or does not fit then ellipses used to indicate the name is incomplete.	
9	If Loki has not received values from DTV service the first time leave setting blank (not a 0).	This applies to Quick menu and All settings.

## 2.1 All Settings Menu Order

	Sub menu	Definition
1	Picture	Configures the picture settings.
2	Audio	Configures the audio settings.
3	HDMI & Gaming	Configures HDMI, CEC and gaming settings.
4	Network	Configures and tests the network connection for the TV.
5	Bluetooth and Remote	Configures Bluetooth Headphones, game controllers and the Voice remote.
6	Antenna Channels	Configures the tuner.
7	Accessibility	Configures closed captions, video description, talk back and zoom mode for all models with SmartCast TV.

8	System	Configures menu language, time and timers, TV and input names, power mode, parental controls including the System PIN, store demo. Includes access to System Information and reset to defaults.
9	Support	Provides support including access to the support code, reboot TV, and check for updates. Includes a QR code for the user manual.
10	Privacy and Legal	Configures viewing data and DAI settings. Displays the VIZIO privacy policy and the License List.

## 2.2 Navigation of All Settings

	Definition	Notes
1	A highlighted setting can be changed in two ways	
2	A press of the LEFT/RIGHT keys toggles the options displayed right of the setting in the the sidebar menu.	Setting is immediately changed.
3	A press of UP/DOWN navigates up and down in a menu.	
• A	press of Up at top setting wraps to bottom setting. Examples:	
Pictu	re in All Settings wraps to Privacy & Legal Central re header in Picture menu wraps to Picture Mode Edit??? press of Down at bottom setting wraps to top setting. Examples:	
Priva	acy & Legal Central in All Settings wraps to Picture	
4	Alternatively, a press of OK key opens the specific setting.	For example, in Picture menu,
<ul><li>O</li><li>T</li><li>A</li><li>T</li><li>T</li></ul>	ptions displayed in the menu below. he first option is selected & highlighted. press of the UP or DOWN key highlights the next option above or below. o change to the highlighted setting press OK key. he setting menu closes and the originating menu reopens with the setting and new ption highlighted.  •	Picture mode is highlighted  press of OK key opens the Picture Mode options menu current picture mode option highlighted A press of the DOWN key highlights the next picture mode. A press of OK switches to the highlighted option Returns to the Picture menu with Picture mode highlighted.
5	If a carat is displayed the corresponding arrow navigates:	For example,
	ight carat for a setting, then right arrow opens the menu for the setting	Picture highlighted with left carat, left arrow returns to main menu with Picture highlighted. Advanced settings highlighted with right carat, right arrow opens Advanced Settings submenu Input Name highlighted with right carat, right arrow opens the Input Name with soft keyboard.
6	Under specific conditions, if a setting is noted as "not available", then the setting cannot be selected or used. The setting is grayed out and not sent to the SmartCast app until the condition is relieved.	Gray out is not used in SmartCast mobile (setting is not displayed).  Gray out is not used in Set and Forget settings (e.g. Digital Audio under TV Channels).

## 2.3 VIZIO Test (Hidden) Menu

	Menu	Definition
1	VIZIO Test menu AKA Hidden menu	Access to functions intended for use by engineering.

- To access the VIZIO Test menu, press
- Press MENU or gear iconPress LEFTPress RIGHTPress PLAY or UP