



# INTRODUCTION TO COMSOL Multiphysics

# Introduction to COMSOL Multiphysics

© 1998–2016 COMSOL

Protected by U.S. Patents listed on [www.comsol.com/patents](http://www.comsol.com/patents), and U.S. Patents 7,519,518; 7,596,474; 7,623,991; 8,457,932; 8,954,302; 9,098,106; 9,146,652; and 9,323,503. Patents pending.

This Documentation and the Programs described herein are furnished under the COMSOL Software License Agreement ([www.comsol.com/comsol-license-agreement](http://www.comsol.com/comsol-license-agreement)) and may be used or copied only under the terms of the license agreement.

COMSOL, the COMSOL logo, COMSOL Multiphysics, Capture the Concept, COMSOL Desktop, LiveLink, and COMSOL Server are either registered trademarks or trademarks of COMSOL AB. All other trademarks are the property of their respective owners, and COMSOL AB and its subsidiaries and products are not affiliated with, endorsed by, sponsored by, or supported by those trademark owners. For a list of such trademark owners, see [www.comsol.com/trademarks](http://www.comsol.com/trademarks).

Version: COMSOL 5.2a

## Contact Information

Visit the Contact COMSOL page at [www.comsol.com/contact](http://www.comsol.com/contact) to submit general inquiries, contact Technical Support, or search for an address and phone number. You can also visit the Worldwide Sales Offices page at [www.comsol.com/contact/offices](http://www.comsol.com/contact/offices) for address and contact information.

If you need to contact Support, an online request form is located at the COMSOL Access page at [www.comsol.com/support/case](http://www.comsol.com/support/case). Other useful links include:

- Support Center: [www.comsol.com/support](http://www.comsol.com/support)
- Product Download: [www.comsol.com/product-download](http://www.comsol.com/product-download)
- Product Updates: [www.comsol.com/support/updates](http://www.comsol.com/support/updates)
- COMSOL Blog: [www.comsol.com/blogs](http://www.comsol.com/blogs)
- Discussion Forum: [www.comsol.com/community](http://www.comsol.com/community)
- Events: [www.comsol.com/events](http://www.comsol.com/events)
- COMSOL Video Gallery: [www.comsol.com/video](http://www.comsol.com/video)
- Support Knowledge Base: [www.comsol.com/support/knowledgebase](http://www.comsol.com/support/knowledgebase)

Part number: CM010004

# Contents

---

Introduction .....	5
COMSOL Desktop® .....	6
Example 1: Structural Analysis of a Wrench.....	30
Model Wizard.....	30
Geometry .....	32
Materials .....	35
Global Definitions.....	36
Physics and Boundary Conditions .....	38
Mesh .....	41
Study .....	42
Results .....	42
Convergence Analysis .....	45
Example 2: The Busbar — A Multiphysics Model .....	52
Model Wizard.....	54
Global Definitions.....	56
Auto Completion and Find for Parameters and Variables .	57
Geometry .....	59
Materials .....	62
Physics and Boundary Conditions .....	68
Mesh .....	75
Study .....	77
Results .....	77

Building an Application .....	86
Advanced Topics.....	97
Parameters, Functions, Variables, and Couplings .....	97
Material Properties and Material Libraries.....	101
Adding Meshes.....	103
Adding Physics .....	105
Parametric Sweeps.....	127
Parallel Computing.....	139
COMSOL Multiphysics Client-Server .....	143
Appendix A — Building a Geometry .....	145
Appendix B — Keyboard and Mouse Shortcuts .....	161
Appendix C — Language Elements and Reserved Names .	165
Appendix D — File Formats .....	179
Appendix E — Connecting with LiveLink™ Add-Ons.....	185

## Introduction

---

Read this book if you are new to COMSOL Multiphysics®. It provides an overview of the COMSOL® environment with examples that show you how to use the COMSOL Desktop® user interface and the Model Builder. It also provides a quick introduction to creating applications using the Application Builder.

If you have not yet installed the software, install it now according to the instructions at [www.comsol.com/product-download](http://www.comsol.com/product-download).

In addition to this book, an extensive documentation set is available after installation. Tutorials can be found throughout the COMSOL website, including in the Video Gallery at [www.comsol.com/videos](http://www.comsol.com/videos) and on the COMSOL Blog at [www.comsol.com/blogs](http://www.comsol.com/blogs).

# COMSOL Desktop®


**QUICK ACCESS TOOLBAR** — Use these buttons for access to functionality such as file open/save, undo/redo, copy/paste, and delete.

**APPLICATION BUILDER** — Click this button to switch to the Application Builder and start building an application

**MODEL BUILDER TOOLBAR**

**MODEL TREE** — The model tree gives an overview of the model and all of the functionality and operations needed for building and solving a model as well as processing the results.


**RIBBON** — The ribbon tabs have buttons and drop-down lists for controlling all steps of the modeling process.



**MODEL BUILDER** — The Model Builder window with its model tree and the associated toolbar buttons gives you an overview of the model. The modeling process can be controlled from context-sensitive menus accessed by right-clicking a node.

**SETTINGS WINDOW** — Click any node in the model tree to see its associated Settings window displayed next to the Model Builder.

## GRAPHICS WINDOW TOOLBAR



The screenshot on the previous pages is what you will see when you first start modeling in COMSOL Multiphysics using the Model Builder. The COMSOL Desktop® user interface provides a complete and integrated environment for physics modeling and simulation as well as application design, providing you with the tools necessary to build a user-friendly interface for your models. You can customize the desktop to your own needs. The windows can be resized, moved, docked, and detached. Any changes you make to the layout will be saved when you close the session and available again the next time you open COMSOL Multiphysics. As you build your model, additional windows and widgets will be added. (See page 24 for an example of a more developed desktop.) Among the available windows and user interface components are the following:

### **Quick Access Toolbar**

The Quick Access Toolbar gives access to functionality such as **Open**, **Save**, **Undo**, **Redo**, **Copy**, **Paste**, and **Delete**. You can customize its content from the **Customize Quick Access Toolbar** list (the downward-facing arrow to the right of the toolbar).


### **Ribbon**

The ribbon at the top of the desktop gives access to commands used to complete most modeling tasks. The ribbon is only available in the Windows® version of the COMSOL Desktop environment and is replaced by menus and toolbars in the OS X and Linux® versions. Click the **Application Builder** button to switch from the Model Builder to the Application Builder and start building an application based on your model.

### **Settings Window**

This is the main window for entering all of the specifications of the model, including the dimensions of the geometry, properties of the materials, boundary conditions and initial conditions, and any other information that the solver will

need to carry out the simulation. The picture below shows the **Settings** window for the **Geometry** node.



## Plot Windows

These are the windows for graphical output. In addition to the **Graphics** window, **Plot** windows are used for visualizing results. Several **Plot** windows can be used to show multiple results simultaneously. A special case is the **Convergence Plot** window, an automatically generated **Plot** window that displays a graphical indication of the convergence of the solution process while a model is running.

## Information Windows

These are the windows for nongraphical information. They include:

- **Messages:** Various information about the current COMSOL Multiphysics session is displayed in this window.
- **Progress:** Progress information from the solver in addition to stop buttons.
- **Log:** Information from the solver, such as the number of degrees of freedom, solution time, and solver iteration data.

- **Table:** Numerical data in table format as defined in the **Results** node.
- **External Process:** Provides a control panel for cluster, cloud, and batch jobs.

## Other Windows

- **Add Material** and the **Material Browser:** Access the material property libraries. The **Material Browser** enables editing of material properties.
- **Selection List:** A list of geometry objects, domains, boundaries, edges, and points that are currently available for selection.

The **Windows** drop-down list in the **Home** tab of the ribbon gives you access to all COMSOL Desktop windows. (On OS X and Linux®, you will find this in the **Windows** menu.)

## Progress Bar with Cancel Button

The **Progress Bar** with a button for canceling the current computation, if any, is located in the lower right-hand corner of the COMSOL Desktop interface.

## Dynamic Help

The **Help** window provides context-dependent help texts about windows and model tree nodes. If you have the **Help** window open in your desktop (by typing F1, for example), you will get dynamic help (in English only) when you click a node or a window. From the **Help** window, you can search for other topics, such as menu items.

## The Model Builder and the Application Builder

---

The two main components of the COMSOL Desktop environment are the Model Builder and the Application Builder.

The Model Builder is the tool where you define the model and its components, such as how to solve it, the analysis of results, and creating reports. You do that by building a model tree. The model tree reflects the underlying data structure, the model object, which stores the state of the model including settings for geometry, mesh, physics, boundary conditions, studies, solvers, postprocessing, and visualizations.

The Application Builder allows you to quickly create an application with a specialized user interface that is easy to use. An application is typically based on a model created with the Model Builder. The Application Builder provides two important tools for creating applications: The Form editor and the Method editor. In addition, an application can have a menu bar or a ribbon. The Form editor

includes drag-and-drop capabilities to easily access and include user interface components, such as input fields, graphics windows, and buttons. The Method editor is a programming environment that, for example, allows you to modify the model represented by the model object data structure. You can also use the Method editor to add user interface logic and auxiliary functionality to an application. The Java® programming language is used to write code in the Method editor, which means that all Java® syntax and Java® libraries can be used.

This book, *Introduction to COMSOL Multiphysics*, gives a detailed introduction to using the Model Builder and a quick introduction to the Application Builder. For detailed information on how to use the Application Builder, including the Form editor and the Method editor, see *Introduction to Application Builder*.

## Running Applications and COMSOL Server

---

The Application Builder is included in the Windows® version of COMSOL Multiphysics. With a COMSOL Multiphysics license, applications can be run from the COMSOL Desktop environment. Although applications cannot be built with the OS X or Linux® versions of the software, applications can still be run with COMSOL Multiphysics on those platforms.


With a COMSOL Server license, applications can be run in major web browsers on a variety of operating systems and hardware platforms. In addition, you can run applications by connecting to COMSOL Server with an easy-to-install COMSOL Client for Windows®.

The COMSOL Client for Windows® allows a user to run applications that require a LiveLink™ product for CAD (this functionality is not available when running applications with a web browser).

Running applications in a web browser does not require any installation and no web browser plug-ins are needed. Running an application in a web browser supports interactive graphics in 1D, 2D, and 3D. In a web browser, graphics rendering in 3D are based on WebGL™ technology, which comes included with all major web browsers.


To create an application based on your model, click the **Application Builder** button, accessible from the **Home** tab in the ribbon.

For more information on creating COMSOL applications, refer to the section “Building an Application” on page 86 and the book *Introduction to Application Builder*.



## Preferences

Preferences are settings that affect the modeling environment. Most are persistent between modeling sessions, but some are saved with the model. You access the preferences from the **File** menu by selecting **Preferences**.




In the **Preferences** window, you can change settings such as graphics rendering, the number of displayed digits for results, the maximum number of CPU cores used for computations, or paths to user-defined application libraries. Take a moment to browse your current settings to familiarize yourself with the different options.

There are three graphics rendering options available: **OpenGL®**, **DirectX®**, and **Software Rendering**. The **DirectX®** option is not available in OS X or Linux®, but is available in Windows® if you choose to install the DirectX® runtime libraries during installation. If your computer does not have a dedicated graphics card, you may have to switch to **Software Rendering** for slower but fully functional graphics. A list of recommended graphics cards can be found at:

[www.comsol.com/system-requirements](http://www.comsol.com/system-requirements)

## Creating a New Model


You can set up a model guided by the **Model Wizard** or start from a **Blank Model** as shown in the figure below.



### CREATING A MODEL GUIDED BY THE MODEL WIZARD


The Model Wizard will guide you in setting up the space dimension, physics, and study type in a few steps:

- 1 Start by selecting the space dimension for your model component: **3D**, **2D Axisymmetric**, **2D**, **1D Axisymmetric**, or **0D**.




- 2 Now, add one or more physics interfaces. These are organized in a number of physics branches in order to make them easy to locate. These branches do not directly correspond to products. When products are added to your COMSOL

Multiphysics installation, one or more branches will be populated with additional physics interfaces.



- 3** Select the Study type that represents the solver or set of solvers that will be used for the computation.



Finally, click **Done**. The desktop is now displayed with the model tree configured according to the choices you made in the Model Wizard.

## CREATING A BLANK MODEL

The **Blank Model** option will open the COMSOL Desktop interface without any **Component** or **Study**. You can right-click the model tree to add a **Component** of a certain space dimension, physics interface, or **Study**.

## The Ribbon and Quick Access Toolbar

The ribbon tabs in the COMSOL Desktop environment reflect the modeling workflow and give an overview of the functionality available for each modeling step, including building simulation applications from your models.



The **Home** tab contains buttons for the most common operations for making changes to a model, running simulations, and for building and testing applications. Examples include changing model parameters for a parameterized


geometry, reviewing material properties and physics, building the mesh, running a study, and visualizing the simulation results.

There are standard tabs for each of the main steps in the modeling process. These are ordered from left to right according to the workflow: **Definitions**, **Geometry**, **Materials**, **Physics**, **Mesh**, **Study**, and **Results**.

Contextual tabs are shown only if and when they are needed, such as the **3D Plot Group** tab, which is shown when the corresponding plot group is added or when the node is selected in the model tree.



Modal tabs are used for very specific operations, when other operations in the ribbon may become temporarily irrelevant. An example is the **Work Plane** modal tab. When working with work planes, other tabs are not shown, since they do not present relevant operations.



## THE RIBBON VS. THE MODEL BUILDER


The ribbon gives quick access to available commands and complements the model tree in the **Model Builder** window. Most of the functionality accessed from the ribbon is also accessible from contextual menus by right-clicking nodes in the model tree. Certain operations are only available from the ribbon, such as selecting which desktop window to display. In the COMSOL Desktop interface for OS X and Linux®, this functionality is available from toolbars, which replace the ribbon on these platforms. There are also operations that are only available from the model tree, such as reordering and disabling nodes.

## THE QUICK ACCESS TOOLBAR

The **Quick Access Toolbar** contains a set of commands that are independent of the ribbon tab that is currently displayed. You can customize the **Quick Access Toolbar** and add most commands available in the **File** menu, including commands for undoing and redoing recent actions, as well as for copying, pasting, duplicating, and deleting nodes in the model tree. You can also choose to position the **Quick Access Toolbar** above or below the ribbon.

## OS X AND LINUX®

In the COMSOL Desktop environment for OS X and Linux®, the ribbon is replaced by a set of menus and toolbars.



The instructions in this book are based on the Windows® version of the COMSOL Desktop environment. However, running COMSOL Multiphysics and the COMSOL Desktop environment in OS X and Linux® is very similar, keeping in mind that the ribbon user interface components can instead be found in the corresponding menus and toolbars.

## The Model Builder and the Model Tree

Using the Model Builder, you build a model by starting with the default model tree, adding nodes, and editing the node settings.


All of the nodes in the default model tree are top-level parent nodes. You can right-click on them to see a list of child nodes, or subnodes, that you can add beneath them. This is the means by which nodes are added to the tree.

When you click on a child node, you will see its node settings in the **Settings** window. It is here that you can edit node settings.

It is worth noting that if you have the **Help** window open, which is achieved either by selecting **Help** from the **File** menu or by pressing the function key F1, then you will also get dynamic help (in English only) when you click on a node.

## THE ROOT, GLOBAL DEFINITIONS, AND RESULTS NODES

A model tree always has a root node (initially labeled `Untitled.mph`), a **Global Definitions** node, and a **Results** node. The label on the root node is the name of the multiphysics model file, or MPH file, to which the model is saved. The root node has settings for author name, default unit system, and more.




The **Global Definitions** node has a **Materials**

subnode by default. The **Global Definitions** node is where you define parameters, variables, functions, and couplings that can be used throughout the model tree. They can be used, for example, to define the values and functional dependencies of material properties, forces, geometry, and other relevant features. The **Global**

**Definitions** node itself has no settings, but its child nodes have plenty of them. The **Materials** subnode stores material properties that can be referenced in the **Component** nodes of a model.

The **Results** node is where you access the solution after performing a simulation and where you find tools for processing the data. The **Results** node initially has five subnodes:


- **Data Sets**, which contains a list of solutions you can work with.
- **Derived Values**, which defines values to be derived from the solution using a number of postprocessing tools.
- **Tables**, which is a convenient destination for the **Derived Values** or for **Results** generated by probes that monitor the solution in real-time while the simulation is running.
- **Export**, which defines numerical data, images, and animations to be exported to files.
- **Reports**, which contains automatically generated or custom reports about the model in HTML or Microsoft® Word format.



To these five default subnodes, you may also add more **Plot Group** subnodes that define graphs to be displayed in the **Graphics** window or in **Plot** windows. Some of these may be created automatically, depending on the type of simulations you are performing, but you may include additional figures by right-clicking on the **Results** node and choosing from the list of plot types.

## THE COMPONENT AND STUDY NODES

In addition to the three nodes just described, there are two additional top-level node types: **Component** nodes and **Study** nodes. These are usually created by the Model Wizard when you create a new model. After using the Model Wizard to specify what type of physics you are modeling and what type of **Study** (e.g., steady-state, time-dependent, frequency-domain, or eigenfrequency analysis) you will carry out, the Model Wizard automatically creates one node of each type and shows you their contents.




It is also possible to add more **Component** and **Study** nodes as you develop the model. A model can contain multiple **Component** and **Study** nodes and it would be confusing if they all had the same name. Therefore, these types of nodes can be renamed to be descriptive of their individual purposes.

If a model has multiple **Component** nodes, they can be coupled to form a more sophisticated sequence of simulation steps.


Note that each **Study** node may carry out a different type of computation, so each one has a separate **Compute** button = .

To be more specific, suppose that you build a model that simulates a coil assembly that is made up of two parts, a coil and a coil housing. You can create two **Component** nodes, one that models the coil and the other the coil housing. You can then rename each of the nodes with the name of the object. Similarly, you can also create two **Study** nodes, the first simulating the stationary or steady-state behavior of the assembly, and the second simulating the frequency response. You can rename these two nodes to be **Stationary** and **Frequency Domain**. When the model is complete, save it to a file named **Coil Assembly.mph**. At that point, the model tree in the Model Builder looks like the figure below.

In this figure, the root node is named **Coil Assembly.mph**, indicating the file in which the model is saved. The **Global Definitions** node and the **Results** node each have their default name. Additionally, there are two **Component** nodes and two **Study** nodes with the names chosen in the previous paragraph.



Keyboard Shortcuts



## PARAMETERS, VARIABLES, AND SCOPE

### Global Parameters


Global parameters are user-defined constant scalars that are usable throughout the model. That is to say, they are “global” in nature. Important uses are:

- Parameterizing geometric dimensions.
- Specifying mesh element sizes.
- Defining parametric sweeps (simulations that are repeated for a variety of different values of a parameter such as a frequency or load).

A global parameter expression can contain numbers, global parameters, built-in constants, built-in functions with global parameter expressions as arguments, and unary and binary operators. For a list of available operators, see “Appendix C — Language Elements and Reserved Names” on page 165. Because these expressions are evaluated before a simulation begins, global parameters may not depend on the time variable  $t$ . Likewise, they may not depend on spatial variables like  $x$ ,  $y$ , or  $z$ , nor on the dependent variables for which your equations are solving.


It is important to know that the names of parameters are case sensitive.

You define global parameters in the **Parameters** node in the model tree under **Global Definitions**.



## Results Parameters


For greater flexibility, it is possible to define parameters that are only used in the **Results** node. Using these parameters does not require resolving the model.



Result parameters may depend on other result parameters but not on global parameters.

## Variables

Variables have associated **Variables** nodes in the model tree and can be defined either in the **Global Definitions** node or in the **Definitions** subnode of any **Component** node.



Naturally, the choice of where to define the variable depends on whether you want it to be global (that is, usable throughout the model tree) or locally defined within a single **Component** node. Like a parameter expression, a variable expression may contain numbers, parameters, built-in constants, and unary and binary operators. However, it may also contain variables like  $t$ ,  $x$ ,  $y$ , or  $z$ ; functions with variable expressions as arguments; and dependent variables that you are solving for in addition to their space and time derivatives.

## Variables Used in Applications


Model parameters and variables can be used in applications. For example, you can let the user of an application change the value of a parameter. In addition, variables to be used in applications can be defined in the Application Builder, in the application tree under the **Declarations** node.

## Scope

The “scope” of a parameter or variable is a statement about where it may be used in an expression. All global parameters are defined in the **Global Definitions** node of the model tree as a **Parameters** subnode. This means that they are global in scope and can be used throughout the model tree.

A variable may also be defined in the Global Definitions node, as a **Variables** subnode, and have global scope, but they are subject to other limitations. For example, variables may not be used in **Geometry**, **Mesh**, or **Study** nodes (with the one exception that a variable may be used in an expression that determines when the simulation should stop).

A variable that is instead defined, under the **Definitions** subnode of a **Component** node has local scope and is intended for use in that particular **Component** (but, again, not in the **Geometry** or **Mesh** nodes). They may be used, for example, to specify material properties in the **Materials** subnode of a **Component** or to specify boundary conditions or interactions. It is sometimes valuable to limit the scope of the variable to only a certain part of the geometry, such as certain boundaries. For that purpose, provisions are available in the settings for a variable to select whether to apply the definition either to the entire geometry of the **Component** or only to a **Domain**, **Boundary**, **Edge**, or **Point**.



The figure at left shows the definition of two variables, `q_pin` and `R`, for which the scope is limited to just two boundaries identified by numbers 15 and 19.

Such a group of numbers is called a **Selection** and can be named and then referenced elsewhere in a model. This can be useful, for example, when defining material properties or boundary conditions that will use the variable at certain boundaries but not elsewhere. To give a name to the **Selection**, click the **Create Selection** button ( ) to the right of the **Selection** list.

Although the variables defined in the **Variables** node under the **Component > Definitions** subnode are intended to have local scope, they can still be accessed outside of the **Component**

node in the model tree by being sufficiently specific about their identity. This is

done by using a “dot-notation” where the variable name is preceded by the name of the **Component** node in which it is defined and they are joined by a “dot”. In other words, if a variable named `foo` is defined in a **Component** node named `MyModel1`, then this variable may be accessed outside of the Component node by using `MyModel1.foo`. This can be useful, for example, when you want to use the variable to make plots in the **Results** node. Variables defined under the **Declarations** node in the Application Builder are available globally in form objects and methods but cannot be used in the Model Builder.

## Built-In Constants, Variables, and Functions

---


COMSOL Multiphysics comes with many built-in constants, variables, and functions. They have reserved names that cannot be redefined by the user. If you use a reserved name for a user-defined variable, parameter, or function, the text you enter will turn orange (a warning) or red (an error) and you will get a tooltip message if you select the text string.

Some important examples are:

- Mathematical constants such as `pi` (3.14...) or the imaginary unit `i` or `j`
- Physical constants such as `g_const` (acceleration of gravity), `c_const` (speed of light), or `R_const` (universal gas constant)
- The time variable, `t`
- First- and second-order derivatives of the dependent variables (the solution) whose names are derived from the spatial coordinate names and dependent variable names (which are user-defined variables)
- Mathematical functions such as `cos`, `sin`, `exp`, `log`, `log10`, and `sqr`


See “Appendix C — Language Elements and Reserved Names” on page 165 for more information.

The following spread shows an example of a customized desktop with additional windows.



## GRAPHICS WINDOW


**DYNAMIC HELP** — Continuously updated with online access to the Knowledge Base and Application Gallery. The Help window enables easy browsing with extended search functionality.



## The Application Libraries

The Application Libraries are collections of MPH files containing tutorial models and runnable applications with accompanying documentation. Tutorial models show how to use the Model Builder and have documentation that includes theoretical background and step-by-step instructions. Runnable applications have instructions on how to use the application. You can readily inspect and edit all tutorial models and applications to make them your own. Each physics-based add-on module comes with its own application library with examples specific to its applications and physics area. You can use the step-by-step instructions and the MPH files as a template for your own modeling.

To open the **Application Libraries** window, select **Application Libraries**  from the **Windows** menu on the **Home** toolbar or from the **File** menu . Then, search by application name or browse under a module folder name.




Click **Open** , **Run Application** , or **Open PDF Document** . Alternatively, select **Help > Documentation** from the **File** menu to search by application name or browse by module. Note that the **Run Application** option is only available for MPH files that are runnable applications.

The MPH files in the Application Libraries can have two formats — Full MPH files or Compact MPH files:

- Full MPH files, including all meshes and solutions. In the Application Libraries window, these appear with the  icon. If the MPH file size exceeds 25MB, a tip with the text “Large file” and the file size appears when you position the cursor at the model’s node in the Application Libraries tree.
- Compact MPH files, with all settings for the model but without built meshes and solution data to save space on the DVD or download image. Some MPH files have no solutions for other reasons such that the computation time is short and the results are easily regenerated. You can open these to study the settings and to mesh and re-solve. It is also possible to download the full versions — with meshes and solutions — of most of these when you update your Application Libraries. These appear in the Application Libraries window with the  icon. If you position the cursor at a compact file in the Application Libraries window, a **No solutions stored** message appears. If a full MPH file is available for download, the corresponding node’s context menu includes a **Download File with Solutions**  option.


The Application Libraries are updated on a regular basis by COMSOL. To check all available updates, click **Update COMSOL Application Libraries**  at the top of the **Application Libraries** window. You can also find this option from the **File > Help** menu (Windows® users) or from the **Help** menu (OS X and Linux® users). This connects you to the COMSOL website, where you can access new applications and the latest updates.



If your computer has an Internet connection, then you can click the **Application Gallery** button to get access to a wide range of additional examples from the COMSOL website.

## Workflow and Sequence of Operations

In the **Model Builder** window, every step of the modeling process, from defining global variables to the final report of results, is displayed in the model tree.



From top to bottom, the model tree defines an orderly sequence of operations.

In the following branches of the model tree, the node order makes a difference and you can change the sequence of operations by moving the subnodes up or down the model tree:

- **Geometry**
- **Materials**
- **Physics**
- **Mesh**

- **Study**
- **Plot Groups**

In the **Component > Definitions** branch of the tree, the ordering of the following node types also makes a difference:

- **Perfectly Matched Layer**
- **Infinite Elements**

Nodes may be reordered by these methods:

- Drag-and-drop
- Right-clicking the node and selecting **Move Up** or **Move Down**
- Pressing Ctrl + Up arrow or Ctrl + Down arrow

In other branches, the ordering of nodes is not significant with respect to the sequence of operations, but some nodes can be reordered for readability. Child nodes to **Global Definitions** is one such example.

You can view the sequence of operations presented as program code statements by saving the model as a **Model File for MATLAB®** or as a **Model File for Java®** after having selected **Compact History** in the **File** menu. Note that the model history keeps a complete record of the changes you make to a model as you build it. As such, it includes all of your corrections, including changes to parameters and boundary conditions and modifications of solver methods. Compacting this history removes all of the overridden changes and leaves a clean copy of the most recent form of the model steps. In the Application Builder, you can use the **Record a New Method** option to view and edit program code statements in the Method editor.

As you work with the COMSOL Desktop interface and the Model Builder, you will grow to appreciate the organized and streamlined approach. However, any description of a user interface is inadequate until you try it for yourself. In the next chapters, you are invited to work through two examples to familiarize yourself with the software.

## Example 1: Structural Analysis of a Wrench

---

This simple example requires none of the add-on products to COMSOL Multiphysics®. For more fully-featured structural mechanics models, see the Structural Mechanics Module application library.

At some point in your life, it is likely that you have tightened a bolt using a wrench. This exercise takes you through a structural mechanics model that analyzes this basic task from the perspective of the structural integrity of the wrench subjected to a worst-case loading.

The wrench is, of course, made from steel, a ductile material. If the applied torque is too high, the tool will be permanently deformed due to the steel's elastoplastic behavior when pushed beyond its yield stress level. To analyze whether the wrench handle is appropriately dimensioned, you will check if the mechanical stress level is within the yield stress limit.


This tutorial gives a quick introduction to the Model Builder workflow. It starts with opening the Model Wizard and adding a physics option for solid mechanics. Then a geometry is imported and steel is selected as the material. You then explore the other key steps in creating a model by defining a parameter and boundary condition for the load; selecting geometric entities in the Graphics window; defining the Mesh and Study; and finally, examining the results numerically and through visualization.

If you prefer to practice with a more advanced model, read this section to familiarize yourself with some of the key features, and then go to the tutorial “Example 2: The Busbar — A Multiphysics Model” on page 52.

### Model Wizard


---

- To start the software, double-click the COMSOL Multiphysics icon on the desktop, which will take you to



the New window with two options for creating a new model: **Model Wizard** or **Blank Model**.


If you select **Blank Model**, you can right-click the root node in the model tree to manually add a **Component** and a **Study**. For this tutorial, click the **Model Wizard** button.



If the COMSOL Desktop user interface is already open, you can start the Model Wizard by selecting **New** from the **File** menu. Choose the **Model Wizard**.


The Model Wizard will guide you through the first steps of setting up a model. The next window lets you select the dimension of the modeling space.

- 2 In the **Select Space Dimension** window, select 3D.



- 3 In **Select Physics**, select **Structural Mechanics > Solid Mechanics (solid)**. Click **Add**.

Without add-on modules, **Solid Mechanics** is the only physics interface available in the **Structural Mechanics** folder. In the picture to the right, the **Structural Mechanics** folder is shown as it appears when all add-on modules are available.




Click **Study**  to continue.

- 4 Click **Stationary**  under **Preset Studies**. Click **Done**  once you have finished.

Preset studies have solver and equation settings adapted to the selected physics, which is, in this example, **Solid Mechanics**. A **Stationary** study is used in this case — there are no time-varying loads or material properties.

Any selection from the **Custom Studies** branch  requires manual settings.



4

## Geometry

---


This tutorial uses a geometry that was previously created and stored in the COMSOL native CAD format, **.mphbin**. To learn how to build your own geometry, see “Appendix A — Building a Geometry” on page 145.

### File Locations

The location of the application library that contains the file used in this exercise varies based on the software installation and operating system. In Windows®, the file path will be similar to:


C:\Program Files\COMSOL\COMSOL52a\Multiphysics\applications.

- 1** In the Model Builder window, under **Component 1**, right-click **Geometry 1**  and select **Import** .



As an alternative, you can use the ribbon and click **Import**  from the **Geometry** tab.


- 2** In the **Settings** window for **Import**, from the **Source** list, select **COMSOL Multiphysics file**.



- 3** Click **Browse** and locate the file `wrench.mphbin` in the application library folder of the COMSOL installation folder. Its default location in Windows® is

`C:\Program Files\COMSOL\COMSOL52a\Multiphysics\applications\COMSOL_Multiphysics\Structural_Mechanics\wrench.mphbin`  
Double-click to add or click **Open**.

- 4 Click **Import** to display the geometry in the **Graphics** window.



- 5 Click the wrench geometry in the **Graphics** window and then experiment with moving it around. As you point to or click the geometry, it changes color. Click the **Zoom In** , **Zoom Out** , **Go to Default 3D View** , **Zoom Extents** , and **Transparency** buttons on the **Graphics** window toolbar to see what happens to the geometry:

- To rotate, click and drag anywhere in the **Graphics** window.
- To move, right-click and drag.
- To zoom in and out, click the mouse scroll wheel, continue holding it, and drag.
- To get back to the original position, click the **Go to Default 3D View** button on the toolbar.

Also see “Appendix B — Keyboard and Mouse Shortcuts” on page 161 for additional information.

The imported model has two parts, or domains, corresponding to the bolt and the wrench. In this exercise, the focus will be on analyzing the stress in the wrench.


## Materials

The **Materials** node  stores the material properties for all physics and all domains in a **Component** node. Use the same generic steel material for both the bolt and tool. Here is how to choose it in the Model Builder.

### 1 Open the Add Materials window.

You can open the Add Materials window in either of these two ways:


- Right-click **Component 1 > Materials**  in the **Model Builder** and select **Add Material** 
- From the ribbon, select the **Home** tab and then click **Add Material**.



### 2 In the Add Material window, click to expand the **Built-In** folder. Scroll down to find **Structural steel**, right-click, and select **Add to Component 1**.

### 3 Examine the **Material Contents** section in the **Settings** window for **Material** to see the properties that are available. Properties with green check marks are used by the physics in the simulation.

### 4 Close the Add Material window.



3

Material Contents				
Property	Name	Value	Unit	Property group
<input checked="" type="checkbox"/> Density	rho	7850[kg/m^3]	kg/m <sup>3</sup>	Basic
<input checked="" type="checkbox"/> Young's modulus	E	200e9[Pa]	Pa	Young's modulus and Poisson's ratio
<input checked="" type="checkbox"/> Poisson's ratio	nu	0.33	1	Young's modulus and Poisson's ratio
Relative permeability	mur	1	1	Basic
Heat capacity at constant pressure	Cp	475[J/(kg*K)]	J/(kg*K)	Basic
Thermal conductivity	k	44.5[W/(m*K)]	W/(m-K)	Basic
Electrical conductivity	sigma	4.032e6[S/m]	S/m	Basic
Relative permittivity	epsilon0	1	1	Basic
Coefficient of thermal expansion	alpha	12.3e-6[1/K]	1/K	Basic
Murnaghan third-order elastic moduli	l	-3.0e11[Pa]	N/m <sup>2</sup>	Murnaghan
Murnaghan third-order elastic moduli	m	-6.2e11[Pa]	N/m <sup>2</sup>	Murnaghan
Murnaghan third-order elastic moduli	n	-7.2e11[Pa]	N/m <sup>2</sup>	Murnaghan

!


Also see the busbar tutorial sections “Materials” on page 62 and “Customizing Materials” on page 101 to learn more about working with materials.

## Global Definitions

You will now define a global parameter specifying the load applied to the wrench.

### Parameters

- In the **Model Builder**, right-click **Global Definitions**  and choose **Parameters** .



- Go to the **Settings** window for **Parameters**. In the **Parameters** table, enter these settings:

- In the **Name** column or field, enter F.
- In the **Expression** column or field, enter 150[N]. The square-bracket notation is used to associate a physical unit to a numerical value; in this case, the unit of force in Newtons. The **Value** column is automatically updated based on the expression entered once you leave the field or press Return.
- In the **Description** column or field, enter Applied force.

Parameters			
Name	Expression	Value	Description
F	150[N]	150.00 N	Applied force

2

- ! If you have a **Parameters** table with more than one entry, you can sort the table with respect to a particular column by clicking on the corresponding header.

The sections “Global Definitions” on page 56 and “Parameters, Functions, Variables, and Couplings” on page 97 show you more about working with parameters.

So far, you have added the physics and study, imported a geometry, added the material, and defined one parameter. The **Model Builder** node sequence should now match the figure to the right. The default feature nodes under **Solid Mechanics** are indicated by a **D** in the upper-left corner of the node icon .


The default nodes for **Solid Mechanics** are: **Linear Elastic Material**, **Free**, and **Initial Values**.

The node **Linear Elastic Material** is the default material model for the **Solid Mechanics** interface. The node **Free** is a boundary condition that allows all boundaries to move freely without a constraint or load. The node **Initial Values** is used for specifying initial displacement and velocity values for a nonlinear or transient analysis (not applicable in this case).

The default physics nodes cannot be removed. Instead, you specify physics settings that deviate from that of the default nodes by adding additional nodes. These additional nodes can override or contribute to the settings of the default nodes as well as other nodes. For more information, see “Override and Contribution: Exclusive and Contributing Nodes” on page 112.

At any time, you can save your model and then open it later in exactly the state in which it was saved.

- 3 From the File Menu, select **File > Save As**. Browse to a folder where you have write permissions, and save the file as `wrench.mph`.




## Physics and Boundary Conditions

With the geometry and materials defined, you are now ready to set the boundary conditions.


- In the **Model Builder**, right-click **Solid Mechanics (solid)**  and select **Fixed Constraint** .

This boundary condition constrains the displacement of each point on a boundary surface to be zero in all directions.

You can also use the ribbon and select, from the **Physics** tab, **Boundaries > Fixed Constraint**.




- In the **Graphics** window, rotate the geometry by clicking anywhere in the window and then dragging the wrench into the position shown. Click on the exposed front surface of the partially modeled bolt. The boundary turns blue indicating that it has been selected. The **Boundary number** in the **Selection** list should be **35**.



- Click the **Go to Default 3D View** button  on the **Graphics** toolbar to restore the geometry to the default view.




- 4 In the **Model Builder**, right-click **Solid Mechanics (solid)** and select **Boundary Load**. A **Boundary Load** node is added to the **Model Builder** sequence.




- 5 In the **Graphics** window, click the **Zoom Box** button on the toolbar and drag the mouse to select the square region shown in the figure to the right. Release the mouse button to zoom in on the selected region.

5




- 6 Select the top socket face (boundary ) by clicking the boundary to highlight it in blue and add it to the **Selection** list.

6



In the **Settings** window for **Boundary Load**, under **Force**, select **Total force** as the **Load type** and enter  $-F$  in the text field for the  $z$  component. The negative sign indicates the negative  $z$  direction




(downward). With these settings, the load of 150 N will be distributed uniformly across the selected surface.

Note that to simplify the modeling process, the mechanical contact between the bolt and the wrench is approximated with a material interface boundary condition. Such an internal boundary condition is automatically defined and guarantees continuity in normal stress and displacement across a material interface. A more detailed analysis including mechanical contact can be done with the Structural Mechanics Module.

## SELECTING BOUNDARIES AND OTHER GEOMETRIC ENTITIES

When a boundary is unselected, its color is typically gray, the exception being when you use the material **Appearance** setting available in **Materials**; See page 67. To select a boundary, first hover over it. This highlights the boundary in red, assuming the boundary was previously unselected. Now, click to select the boundary by using the left mouse button. The boundary now turns blue. Its boundary number will appear in the **Selection** list in the **Settings** window of the corresponding boundary condition. Once a boundary is selected and you hover over it again, the boundary turns green. If you click a boundary highlighted in green, the boundary is deselected and now turns gray again. The same technique for selecting and deselecting is applicable to geometry objects, domains, boundaries, edges, and points.

The figure below shows the different selection states for a boundary.




To select internal surfaces that are hidden behind the one closest to you, use one of the following methods to cycle through the boundaries at the mouse pointer: roll the mouse scroll wheel, use the keyboard up and down arrows, or use two-finger drag on a touchpad.

## Mesh


The mesh settings determine the resolution of the finite element mesh used to discretize the model. The finite element method divides the model into small elements of geometrically simple shapes, in this case tetrahedrons. In each tetrahedron, a set of polynomial functions is used to approximate the structural displacement field — how much the object deforms in each of the three coordinate directions.

In this example, because the geometry contains small edges and faces, you will define a slightly finer mesh than the default setting suggests. This will better resolve the variations of the stress field and give a more accurate result. Refining the mesh size to improve computational accuracy always involves some sacrifice in speed and typically requires increased memory usage.

- 1 In the **Model Builder**, under **Component 1**, click **Mesh**  . In the **Settings** window for **Mesh**, under **Mesh Settings**, select **Fine** from the **Element size** list.



- 2 Click the **Build All** button  in the **Settings** window or on the **Mesh** toolbar.
- 3 After a few seconds, the mesh is displayed in the **Graphics** window. Rotate the wrench to take a look at the element size distribution.




## Study

---

In the beginning of setting up the model, you selected a **Stationary** study, which implies that a stationary solver will be used. For this to be applicable, the assumption is that the load, deformation, and stress do not vary in time. To start the solver:

- Right-click **Study 1** and select **Compute** = (or press F8).

After a few seconds of computation time, the default plot is displayed in the **Graphics** window. You can find other useful information about the computation in the **Messages** and **Log** windows; Click the **Messages** and **Log** tabs under the **Graphics** window to see the kind of information available to you. The **Messages** window can also be opened from the **Windows** drop-down list in the **Home** tab of the ribbon.



```
Messages Progress Log


Stationary Solver 1 in Study 1/Solution 1 (sol1) started at 13-May-2016 17:36:24.
Linear solver
Number of degrees of freedom solved for: 108483.
Symmetric matrices found.
Scales for dependent variables:
Displacement field (Material) (comp1.u): 1
Orthonormal null-space function used.
Iter SolEst Damping Stepsize #Res #Jac #Sol LinErr LinRes
  1   0.85  1.000000    0.85   1   1   1  5e-007 2.3e-009
Stationary Solver 1 in Study 1/Solution 1 (sol1): Solution time: 5 s
                                                Physical memory: 1.77 GB
                                                Virtual memory: 2.1 GB
=====
```

## Results


---

The von Mises stress is displayed in the **Graphics** window in a default Surface plot with the displacement visualized using a Deformation subnode. Change the default unit ( $\text{N}/\text{m}^2$ ) to the more suitable MPa as shown in the following steps.

- 1** In the **Model Builder**, expand the **Results > Stress (solid)** node, then click **Surface 1**.




- 2** In the **Settings** window under **Expression**, from the **Unit** list, select **MPa** (or type MPa in the field).



- 3** Click the **Plot** button on the toolbar of the **Settings** window for the **Surface** plot and then click the **Go to Default 3D View** button on the **Graphics window** toolbar.


The von Mises stress distribution is shown in the bolt and wrench under an applied vertical load.




For a typical steel used for tools like a wrench, the yield stress is about 600 MPa, which means that we are getting close to plastic deformation for our 150 N load (which corresponds to about 34 pounds force). You may also be interested in a safety margin of, say, a factor of three. To quickly assess which parts of the wrench

are at risk of plastic deformation, you can plot an inequality expression such as `solid.mises>200[MPa]`.

- Right-click the **Results** node  and add a **3D Plot Group** .




- Right-click the **3D Plot Group**  and select **Surface** .



- In the **Settings** window for **Surface**, click the **Replace Expression** button  and select **Model > Component1 > Solid Mechanics > Stress > solid.mises-von Mises stress** by double-clicking. When you know the variable name beforehand, you can also directly enter `solid.mises` in the **Expression** field. Now edit this expression to:  
`solid.mises>200[MPa]`.


This is a boolean expression that evaluates to either 1 for true or 0 for false. In areas where the expression evaluates to 1, the safety margin is exceeded.

- Click the **Plot** button .



- 5** In the **Model Builder**, click **3D Plot Group 2**. Press F2 and in the **Rename 3D Plot Group** dialog box, enter Safety Margin. Click **OK**.

The resulting plot shows that the stress in the bolt is high, but the focus of this exercise is on the wrench. If you wished to comfortably certify the wrench for a 150 N load with a factor-of-three safety margin, you would need to change the handle design somewhat, such as by making it wider.



You may have noticed that the manufacturer, for various reasons, has chosen an asymmetric design for the wrench. Because of that, the stress field may be different if the wrench is flipped around. Try now, on your own, to apply the same force in the other direction and visualize the maximum von Mises stress to see if there is any difference.


## Convergence Analysis

To check the accuracy of the computed maximum von Mises stress in the wrench, you can now continue with a mesh convergence analysis. Do that by using a finer mesh and therefore a higher number of degrees of freedom (DOFs).

- ! This section illustrates some more in-depth functionality and the steps below could be skipped at a first reading. In order to run the convergence analysis below, a computer with at least 4GB of memory (RAM) is recommended.

## EVALUATING THE MAXIMUM VON MISES STRESS


- To study the maximum von Mises stress in the wrench, in the **Results** section of the model tree, right-click the **Derived Values** 8.85  
8-12 node and select **Maximum > Volume Maximum** MAX.
- In the **Settings** window for **Volume Maximum**, under **Selection**, choose **Manual** and select the wrench, domain 1, by clicking on the wrench in the **Graphics** window. We will only consider values in the wrench domain and neglect those in the bolt.
- In the first row of the **Expressions** table, in the **Expression** column, type `solid.mises`. To find the expression for the von Mises stress, you can also click the **Replace Expression** button .
- In the **Expressions table**, type MPa as the **Unit**.



- In the **Settings** window for **Volume Maximum**, click **Evaluate** to evaluate the maximum stress. The result will be displayed in a Table window and will be approximately 522 MPa.
- To see where the maximum value is attained, you can use a **Max/Min Volume** plot. Right-click the **Results** node  and add a **3D Plot Group** .

Messages	Progress	Log	Table 1
	8.85 8-12	AUTO 8-1	850 8-3
von Mises stress (MPa)			0.85
522.04			 

- 7 Right-click the **3D Plot Group 3** node  and select **More Plots > Max/Min Volume** .
- 8 In the **Settings** window for **Max/Min Volume**, in the **Expression** text field, type `solid.mises`.
- 9 In the **Settings** window under **Expression**, from the **Unit** list, select **MPa** (or enter **MPa** in the field).
- 10 Click the **Plot** button . This type of plot simultaneously shows the location of the maximum and minimum values and also their coordinate location in the table below.



## PARAMETERIZING THE MESH

We will now define a parametric sweep for successively refining the mesh size while solving and then finally plot the maximum von Mises stress vs. mesh size. First, we define the parameters that will be used for controlling the mesh density.

- 1 In the **Model Builder**, click **Parameters**  under **Global Definitions** .
- 2 Go to the **Settings** window for **Parameters**. In the **Parameters** table (or under the table in the fields), enter these settings:
  - In the **Name** column or field, enter `hd`. This parameter will be used in the parametric sweep to control the element size.
  - In the **Expression** column or field, enter `1`.
  - In the **Description** column or field, enter `Element size divider`.

- 3** Now, enter another parameter with **Name** **h0**, **Expression** **0.01**, and **Description** **Starting element size**. This parameter will be used to define the element size at the start of the parametric sweep.

Settings				
Parameters				
Parameters				
» Name	Expression	Value	Description	
F	150[N]	150.00 N	Applied force	
hd	1	1.0000	Element size divider	
h0	0.01	0.010000	Starting element size	

- 4** In the **Model Builder**, under **Component I**, click **Mesh I** . In the **Settings** window for **Mesh**, select **User-controlled mesh** from the **Sequence type** list.

- 5** Under **Mesh I**, click the **Size** node .

- 6** In the **Settings** window for **Size**, under **Element Size**, click the **Custom** button.

Under **Element Size Parameters**, enter:

- $h0/hd$  in the **Maximum element size** field.
- $h0/(4*hd)$  in the **Minimum element size** field.
- 1.3 in the Maximum element growth rate field.
- 0.1 in the Curvature factor field.
- 0.2 in the Resolution of narrow regions field.

▼ Element Size Parameters

Maximum element size:  
h0/hd m

Minimum element size:  
h0/(4\*hd) m

Maximum element growth rate:  
1.3

Curvature factor:  
0.1


Resolution of narrow regions:  
0.2

See page 75 for more information on the element size parameters.

## PARAMETRIC SWEEP AND SOLVER SETTINGS

As a next step, add a parametric sweep for the parameter **hd**.

- 1** In the **Model Builder**, right-click **Study 1** and select **Parametric Sweep** . A **Parametric Sweep** node is added to the **Model Builder** sequence.
- 2** In the **Settings** window for **Parametric Sweep**, under the table in the **Study Settings** section, click the **Add** button . From the **Parameter names** list in the table, select **hd**.



- 3** Enter a range of **Parameter values** to sweep for. Click the **Range**  button and enter the values in the **Range** dialog box. In the **Start** field, enter 1. In the **Step** field, enter 1, and in the **Stop** field, enter 6. Click **Replace**. The **Parameter value list** will now display `range(1,1,6)`.

The settings above make sure that as the sweep progresses, the value of the parameter `hd` increases and the maximum and minimum element sizes decrease.


See page 127 for more information on defining parametric sweeps.

For the highest value of `hd`, the number of DOFs will exceed one million. Therefore, we will switch to a more memory-efficient iterative solver.

- 4** Under **Study 1 > Solver Configurations > Solution 1**, expand the **Stationary Solver 1** node, right-click **Stationary Solver 1** , and select **Iterative** .
- The **Iterative** solver option typically reduces memory usage but can require physics-specific tailoring of the solver settings for efficient computations.
- 5** Under **General** in the **Settings** window for **Iterative**, change the **Solver** to **Conjugate Gradients**.
- 6** In the same **Settings** window for **Iterative**, set **Preconditioning** to **Right**. (This is a low-level solver option, which in this case will suppress a warning message that would otherwise appear. However, this setting does not affect the resulting solution. Preconditioning is a mathematical transformation used to prepare the finite element equation system for using the iterative solver.)
- 7** Right-click the **Iterative 1** node  and select **Multigrid** .
- 8** In the **Settings** window for the **Multigrid 1** node, change the **Solver** to **Smoothed aggregation AMG**.
- 9** Click the **Study 1** node and select **Compute =**, either in the **Settings** window or by right-clicking the node. You can also click **Compute** in the ribbon **Home** or **Study** tab. The computation time will be a few minutes (depending on the computer hardware) and memory usage will be about 4GB.

## RESULTS ANALYSIS

As a final step, analyze the results from the parametric sweep by displaying the maximum von Mises stress in a table.




- 1 In the Model Builder under **Results > Derived Values**, select the **Volume Maximum** node .

The solutions from the parametric sweep are stored in a new **Data Set** named **Study 1/Parametric Solutions 1**. Now, change the **Volume Maximum** settings accordingly:

- 2 In the **Settings** window for **Volume Maximum**, change the **Data set** to **Study 1/Parametric Solutions 1**.
- 3 Click the arrow next to the **Evaluate** button at the top of the **Settings** window for **Volume Maximum** and select to evaluate in a **New Table**. This evaluation may take 20 seconds or so.
- 4 To plot the results in the **Table**, click the **Table Graph**  button at the top of the **Table** window.

hd	ppr(solid.mises) (MPa)
1.0000	391.20
2.0000	404.04
3.0000	429.50
4.0000	375.53
5.0000	375.32
6.0000	375.23



It is more interesting to plot the maximum value vs. the number of DOFs. This is possible by using the built-in variable `numberofdofs`.


- 5 Right-click the **Derived Values** node  and select **Global Evaluation** .
- 6 In the **Settings** window for **Global Evaluation**, change the **Data set** to **Study 1/Parametric Solutions 1**.
- 7 In the **Expressions** field, enter `numberofdofs`.
- 8 In the **Settings** window for **Global Evaluation**, click the arrow next to the **Evaluate** button and select the option to evaluate in **Table 2**. This displays the DOF values for each parameter next to the previously evaluated data.

This convergence analysis shows that the computed value of the maximum von Mises stress in the wrench handle will increase from the original 391 MPa, for a mesh with about 52,000 DOFs, to 375 MPa for a mesh with about 1,000,000

DOFs. It also shows that 500,000 DOFs essentially gives the same accuracy as 1,000,000 DOFs; See the table below.

DEGREES OF FREEDOM	COMPUTED MAX VON MISES STRESS (MPA)
52,269	391.2
155,097	404.0
281,886	429.5
516,930	375.5
775,968	375.3
1,027,374	375.2

The figure below shows the associated **Table Graph** and **Table Graph Settings** window.



Note that depending on the version of COMSOL Multiphysics that you are running, the above values may vary slightly due to variations in the number of elements generated by the meshing algorithm.

This concludes the wrench tutorial.

## Example 2: The Busbar — A Multiphysics Model


---

### *Electrical Heating in a Busbar*

This tutorial demonstrates the concept of multiphysics modeling in COMSOL Multiphysics using the Model Builder. You will learn how to use one of the many preconfigured multiphysics combinations as well as subsequently add the effects of physics phenomena not initially included in the analysis. At the end, you will have built a truly multiphysics model.

The model that you are about to create analyzes a busbar designed to conduct a high amount of direct current in an industrial setting (see picture below). The current conducted in the busbar, from bolt 1 to bolts 2a and 2b, produces heat due to the resistive losses, a phenomenon referred to as Joule heating. The busbar is made of copper, while the bolts are made of a titanium alloy. Busbar bolts are usually made of steel, but in this example, we will assume a highly corrosive environment. Therefore, a titanium alloy was chosen.

Under normal operational conditions, the currents are predominantly conducted through the copper. This example, however, illustrates the effects of an unwanted electrical loading of the busbar through the bolts. The fact that there are different materials is important because titanium has a lower electrical conductivity than copper and will be subjected to a higher current density.



The goal of your simulation is to precisely calculate how much the busbar heats up. Once you have captured the basic multiphysics phenomena, you will have the chance to investigate thermal expansion that generates structural stresses and strains in the busbar and the effects of cooling by an air stream.

The Joule heating effect is described by conservation laws for electric current and energy. Once solved for, the two conservation laws give the temperature and electric field, respectively. All surfaces, except the bolt contact surfaces, are cooled by natural convection in the air surrounding the busbar. You can assume that the exposed parts of the bolt do not contribute to the cooling or heating of the device. The electric potential at the upper-right vertical bolt surface is 20 mV and the potential at the two horizontal surfaces of the lower bolts is 0 V. This corresponds to a relatively high and potentially unsafe loading of this type of busbar. More advanced boundary conditions for electromagnetics analysis are available with the AC/DC Module, such as the capability to give the total current on a boundary.

## ***Busbar Model Overview***

More in-depth and advanced topics included in this tutorial are used to show you some of the many options available in COMSOL Multiphysics. The following topics are covered:

- “Parameters, Functions, Variables, and Couplings” on page 97, where you learn how to define functions and component couplings.
- “Material Properties and Material Libraries” on page 101 shows you how to customize a material and add it to your own material library.
- “Adding Meshes” on page 103 gives you the opportunity to add and define two different meshes and compare them in the Graphics window.
- “Adding Physics” on page 105 explores the multiphysics capabilities by adding solid mechanics and laminar flow to the busbar model.
- “Parametric Sweeps” on page 127 shows you how to vary the width of the busbar using a parameter and then solve for a range of parameter values. The result is a plot of the average temperature as a function of the width.
- “Parallel Computing” on page 139, gives you an overview of how to solve on clusters.
- “COMSOL Multiphysics Client-Server” on page 143, gives you an introduction to using the COMSOL Multiphysics client-server mode of operation.

## Model Wizard

- 1 To open the software, double-click the COMSOL Multiphysics icon on the desktop.



When the software opens, click the **Model Wizard** button. You can also start the Model Wizard at any time by selecting **New** from the **File** menu. Then, choose **Model Wizard**.

1



- 2 In the **Select Space Dimension** window, click **3D**.




- 3 In the **Select Physics** window, expand the **Heat Transfer > Electromagnetic Heating** folder. Then, right-click **Joule Heating** and choose **Add Physics**. Click the **Study** button.

You can also double-click or click the **Add** button to add physics.

(Another way to add physics is to open the **Add Physics** window by right-clicking the **Component** node in the Model Builder and selecting **Add Physics**.)

Note that you may have fewer items in your physics list depending on the add-on modules installed. The figure on the right is shown for the case where all add-on modules are installed.

Select Physics



- 4 In the **Select Study** window, click to select the **Stationary** study type.

Click the **Done** button.


Choosing a stationary study means that we are solving for the steady-state temperature of the busbar when it has reached thermal equilibrium with its surroundings.

A preconfigured **Study** has solver and equation settings adapted to the selected combination of physics interface; in this example, **Joule Heating**.


Any selection from the **Custom Studies** branch may require manual tuning.

Note that you may have fewer study types in your study list depending on the installed add-on modules.

## Select Study



The **Joule Heating** multiphysics interface consists of two physics interfaces, **Electric Currents** and **Heat Transfer in Solids**, together with the multiphysics couplings that appear in the Multiphysics branch: **Electromagnetic Heat Source** and **Temperature Coupling**. (The **Boundary Electromagnetic Heat Source** is for modeling thin shells and is not used in this example.) This method of mixing physics interfaces for multiphysics purposes is very flexible and makes it possible to fully use the capabilities of the participating physics interfaces.



## Global Definitions

To save time, it is recommended that you load the geometry from a file. In that case, you can skip to “Geometry” on page 59.

If, on the other hand, you want to draw the geometry yourself, the **Global Definitions** node is where you define the parameters. First, complete steps 1 through 3 below to define the parameter list for the model. Then, follow step 4 and skip to the section “Appendix A — Building a Geometry” on page 145.


The **Global Definitions** node  in the Model Builder stores **Parameters**, **Variables**, and **Functions** with a global scope. The model tree can hold several model components simultaneously, and the definitions with a global scope are made available for all components. In this particular example,

there is only one **Component** node in which the parameters are used. If you wish to limit the scope to this single component, you could define, for example, **Variables** and **Functions** in the **Definitions** subnode, available directly under the corresponding **Component** node. However, no **Parameters** can be defined here because **Parameters** that are defined under **Global Definitions** are always global.

Since you will run a parametric study of the geometry later in this example, define the geometry using parameters from the start. In this step, enter parameters for the length of the lower part of the busbar,  $L$ ; the radius of the titanium bolts,  $rad\_1$ ; the thickness of the busbar,  $tbb$ ; and the width of the device,  $wbb$ .

You will also add the parameters that control the mesh,  $mh$ ; a heat transfer coefficient for cooling by natural convection,  $htc$ ; and a value for the voltage across the busbar,  $Vtot$ .

- 1 Right-click **Global Definitions**  and choose **Parameters** . In the **Parameters** table, click the first row under **Name** and enter  $L$ .
- 2 Click the first row under **Expression** and enter the value of  $L$ ,  $9[\text{cm}]$ . You can enter the unit inside the square brackets.
- 3 Continue adding the other parameters:  $rad\_1$ ,  $tbb$ ,  $wbb$ ,  $mh$ ,  $htc$ , and  $Vtot$  according to the **Parameters** list below. It is a good idea to enter descriptions for



variables in case you want to share the model with others and for your own future reference.

Parameters			
Name	Expression	Value	Description
L	9[cm]	0.09 m	Length
rad_1	6[mm]	0.006 m	Bolt radius
tbb	5[mm]	0.005 m	Thickness
wbb	5[cm]	0.05 m	Width
mh	6[mm]	0.006 m	Maximum element size
htc	5[W/m^2/K]	5 W/(m^2·K)	Heat transfer coefficient
Vtot	20[mV]	0.02 V	Applied voltage

Click the **Save** button on the Quick Access Toolbar and name the model `busbar.mph` or use the corresponding **File** menu option. Then, go to “Appendix A — Building a Geometry” on page 145.

## Auto Completion and Find for Parameters and Variables


---

The model tree contains a large number of parameters and variables. To make it easier to find them, you can use auto completion and find tools as described below.

### AUTO COMPLETION

You can use **Ctrl+Space** for auto completion of parameter and variable names. For example, in the **Parameters** table, click an empty **Expression** field and then press


Ctrl+Space, you will get a list of parameters and variables, as shown in the figure below.



This functionality is also available for other edit fields in the Model Builder.

## FIND

To find parameters and variables in the model tree, you can click the **Find** button in the **Quick Access Toolbar** or use the keyboard shortcut Ctrl+F. This opens the **Find** window.



The results of the search are displayed in the **Find Results** window, as shown in the figure below.

The screenshot shows a software interface with a top navigation bar containing 'Messages', 'Progress', 'Log', and 'Find Results'. The 'Find Results' tab is selected, indicated by a blue border. Below the navigation bar, a message says 'C "current": 9 matches'. A table lists nine items, each with a 'Node' column, a 'Type' column, and a 'Text' column. The items are:


Node	Type	Text
Electric Currents (ec) {ec}	Node	Electric Currents
Electric Currents (ec) {ec}	Node	Electric Currents
Current Conservation 1 {cucn1}	Node	Current Conservation 1
Current Conservation 1 {cucn1}	Node	Current Conservation
Electromagnetic Heat Source 1 {emh1} {emh1}	Setting	Electric Currents (ec) {ec}
Boundary Electromagnetic Heat Source 1 {bemh1} {bemh1}	Setting	Electric Currents (ec) {ec}
Temperature Coupling 1 {tc1} {tc1}	Setting	Electric Currents (ec) {ec}
Current Density (pg4)	Node	Current Density
Surface 1 {surf1}	Setting	Current density norm

You can double-click any of the rows in this window to open the corresponding **Settings** window.

## Geometry

This section describes how the geometry can be opened from the Application Libraries. The physics, study, parameters, and geometry are included with the model file you are about to open.

- | Select **Application Libraries**  from the **Windows** drop down menu in the **Home** tab.



- 2** In the **Application Libraries** tree under **COMSOL Multiphysics > Multiphysics**, select **busbar geom**.

To open the file, you can:

- Double-click the name
- Right-click and select an option from the menu
- Click one of the buttons under the tree



You can select **No** if prompted to save **Untitled.mph**.

The geometry in this file is parameterized. In the next few steps, we will experiment with different values for the width parameter, **wbb**.

- 3** Under **Global Definitions**  , click the **Parameters** node .


In the Settings window for **Parameters**, click in the **Expression** column for the **wbb** parameter and enter **10[cm]** to change the value of the busbar width.

- 4** In the **Model Builder**, under **Component 1 > Geometry 1**, click the **Form Union** node  and then the **Build All** button in the




Name	Expression	Value
L	9[cm]	0.09 m
rad_1	6[mm]	0.006 m
tbb	5[mm]	0.005 m
wbb	10[cm]	0.1 m
mh	6[mm]	0.006 m
htc	5[W/m^2/K]	5 W/(m <sup>2</sup> ·K)
Vtot	20[mV]	0.02 V

**Settings** window ■ to rerun the geometry sequence. You can also use the ribbon and click **Build All** from the **Geometry** group in the **Home** tab.



- 5 In the **Graphics** toolbar, click the **Zoom Extents** button to see the wider busbar in the **Graphics** window.



- 6** Experiment with the geometry in the **Graphics** window:
- To rotate the busbar, click and drag the pointer anywhere in the **Graphics** window.
  - To move it, right-click and drag.
  - To zoom in and out, click the scroll wheel, continue holding it, and drag.
  - To get back to the original position, click the **Go to Default 3D View** button 



**6**

- 7** Return to the **Parameters** table and change the value of wbb back to 5[cm].
- 8** In the **Model Builder**, click the **Form Union** node  and then click the **Build All** button  to rerun the geometry sequence.
- 9** On the **Graphics** toolbar, click the **Zoom Extents** button .
- 10** If you built the geometry yourself, you are already using the `busbar.mph` file, but if you opened the file from the Application Libraries, select **Save As** from the **File** menu and rename the model `busbar.mph`.

**7**

Parameters		
Name	Expression	Value
L	9[cm]	0.09 m
rad_1	6[mm]	0.006 m
tbb	5[mm]	0.005 m
wbb	<b>5[cm]</b>	0.05 m
mh	6[mm]	0.006 m
htc	5[W/m^2/K]	5 W/(m <sup>2</sup> .K)
Vtot	20[mV]	0.02 V

After creating or importing the geometry, it is time to define the materials.


## Materials

---

The **Materials** node  stores the material properties for all physics and geometrical domains in a **Component** node. The busbar is made of copper and the bolts are made of a titanium alloy. Both of these materials are available from the **Built-In** material database.


- In the **Model Builder**, right-click **Component 1 > Materials**  and select **Add Material** .
- By default, the window will open at the right-hand side of the desktop. You can move the window by clicking on the window title and then

dragging it to a new location. While dragging the window, you will be presented with several options for docking.




- ! The **Materials** node will show a red × in the lower-left corner if you try to solve without first defining a material, which we will go over in the next few steps.

- 2 In the **Add Material** window, expand the **Built-In** materials folder and locate **Copper**. Right-click **Copper** and select **Add to Component 1**. Alternatively, you can double-click. A **Copper** node is added to the **Model Builder**.
- 3 In the **Add Material** window, scroll to **Titanium beta-21S** in the **Built-In** material folder list. Right-click and select **Add to Component 1**.



- 4 In the **Model Builder**, collapse the **Geometry 1** node to get an overview of the model.



- 5 Under the **Materials** node, click **Copper** .



- 6 In the **Settings** window for **Material**, examine the **Material Contents** section.

"	Property	Name	Value	Unit	Property group
<input checked="" type="checkbox"/>	Electrical conductivity	sigma	5.998e7[S/m]	S/m	Basic
<input checked="" type="checkbox"/>	Heat capacity at constant pressure	Cp	385[J/(kg*K)]	J/(kg*K)	Basic
<input checked="" type="checkbox"/>	Relative permittivity	epsilon0r	1	1	Basic
<input checked="" type="checkbox"/>	Density	rho	8960[kg/m^3]	kg/m³	Basic
<input checked="" type="checkbox"/>	Thermal conductivity	k	400[W/(m*K)]	W/(m*K)	Basic
	Relative permeability	mur	1	1	Basic
	Coefficient of thermal expansion	alpha	17e-6[1/K]	1/K	Basic
	Young's modulus	E	110e9[Pa]	Pa	Young's modulus and Poisson's ratio
	Poisson's ratio	nu	0.35	1	Young's modulus and Poisson's ratio
	Reference resistivity	rho0	1.72e-8[ohm...]	Ω·m	Linearized resistivity
	Resistivity temperature coefficient	alpha	0.0039[1/K]	1/K	Linearized resistivity
	Reference temperature	Tref	298[K]	K	Linearized resistivity


The **Material Contents** section has useful information about the material property usage of a model. Properties that are both required by the physics and available from the material are marked with a green check mark . Properties required by the physics but missing in the material are marked with a warning sign . A property that is available but not used in the model is unmarked.



The **Coefficient of thermal expansion** in the table above is not used, but will be needed later when heat-induced stresses and strains are added to the model.

Because the copper material is added first, by default, all parts have copper material assigned. In the next step, you will assign titanium properties to the bolts, which override the copper material assignment for those parts.


- 7 In the **Model Builder**, click **Titanium beta-21S**.





- 8 Select **All Domains** from the **Selection** list and then click domain 1 in the list. Now remove domain 1 from the selection list.

To remove a domain from the selection list (or any geometric entity, such as boundaries, edges, or points), you can use either of these two methods:

- Click domain 1 in the selection list found in the **Settings** window for **Material**. Then, click the **Remove from Selection** button — or press Delete on your keyboard.
- Alternatively, in the **Graphics** window, click domain 1 to remove it from the selection list.




- 8 The domains 2, 3, 4, 5, 6, and 7 are highlighted in blue.






To render the copper components in the actual color of the material, open the **Preferences** window from the **File** menu. Then, on the **Graphics and Plot Windows** page, select the **Show material color and texture** check box. This will also enable material-true rendering of other materials.

- 9 In the **Settings** window for **Material**, be sure to inspect the **Material Contents** section for the titanium material. All of the properties used by the physics should have a green check mark .



9

- 10 Close the **Add Material** window either by clicking the icon in the upper-right corner or by clicking the **Add Material** toggle button  in the **Materials** group of the ribbon **Home** tab.




10

## Physics and Boundary Conditions

Next, you will inspect the physics domain settings and set the boundary conditions for the heat transfer problem and the conduction of the electric current.

In the **Model Builder** window, examine the default physics nodes of the multiphysics interface for **Joule Heating**. First, collapse the **Materials** node. Then, click the arrows next to the **Electric Currents** , **Heat Transfer in Solids** , and **Multiphysics**  nodes to expand them.



The **D** in the upper-left corner of a node's icon () means it is a default node.

The equations that are being solved are displayed in the Equation section of the Settings windows of the respective physics nodes.

The default equation form is inherited from the study added in the Model Wizard. For the **Joule Heating** multiphysics interface, the equations are for the temperature and electric potential.

-  To always display the equations in the **Settings** windows, click the **Show** button () on the **Model Builder** toolbar and select **Equation Sections** so that a check mark appears next to it.

The **Heat Transfer in Solids** and **Electric Currents** nodes have the settings for heat conduction and current conduction, respectively.

Under the **Electric Currents** node, the **Current Conservation** node represents the conservation of electric current at the domain level and the **Electric Insulation** node contains the default boundary condition for **Electric Currents**.

Under the **Heat Transfer in Solids** node, the domain level **Heat Transfer in Solids** node represents the


conservation of heat and the **Thermal**

**Insulation** node contains the default

boundary condition for **Heat Transfer in Solids**. The heat source for the Joule heating effect is set in the **Electromagnetic Heat Source** node under the **Multiphysics** node. The **Initial Values** node, found in both the **Electric Currents** and **Heat Transfer in Solids** interfaces, contains initial guesses for the nonlinear solver for stationary problems and initial conditions for time-dependent problems.

Now, define the boundary conditions.


- Right-click the **Heat Transfer in Solids** node . In the second section of the context menu — the boundary section — select **Heat Flux**.



- 2** In the **Settings** window for **Heat Flux**, select **All boundaries** from the **Selection** list.


Assume that the circular bolt boundaries are neither heated nor cooled by the surroundings.

In the next step, you will remove the selection of these boundaries from the heat flux selection list, which leaves them with the default **Thermal Insulation** boundary condition for the **Heat Transfer in Solids** interface.




- 3** Rotate the busbar to view the back. Move the mouse pointer over one of the circular titanium bolt surfaces to highlight it in green. Click the bolt surface to remove this boundary selection from the **Selection** list. Repeat this step to remove the other two circular bolt surfaces from the selection list. Boundaries 8, 15, and 43 are removed.

**3** Cross-check: Boundaries 8, 15, and 43 are removed from the Selection list.



- 4** In the **Settings** window for **Heat Flux** under **Heat Flux**, click the **Convective heat flux** button. Enter **htc** in the **Heat transfer coefficient** field,  $h$ .


This parameter was either entered in the **Parameter** table in “Global Definitions” on page 56 or imported with the geometry.




**!** More advanced boundary conditions for heat transfer analysis are available with the Heat Transfer Module. Examples include the capability to give the total deposited power on a boundary or to set boundary conditions for common natural convection scenarios such as for a horizontal or vertical wall.

Continue by setting the boundary conditions for the electric current according to the following steps:

- 5** In the **Model Builder**, right-click the **Electric Currents** node . In the second section of the context menu — the boundary section — select **Electric Potential**. An **Electric Potential** node is added to the model tree.




- 6 Move the mouse pointer over the circular face of the single titanium bolt to highlight it and then click to add it (boundary 43) to the **Selection** list.



6


- 7 In the **Settings** window for **Electric Potential**, enter  $V_{tot}$  in the **Electric potential** field.

The last step is to set the surfaces of the two remaining bolts to ground.



7

- 8 In the **Model Builder**, right-click the **Electric Currents** node . In the boundary section of the context menu, select **Ground**. A **Ground** node is added to the model tree. The model tree node sequence should now match this figure.




8

- 9 In the **Graphics** window, click one of the remaining bolts to add it to the **Selection** list.

9

Cross-check: Boundaries 8 and 15.



Repeat this step to add the last bolt. Boundaries 8 and 15 are added to the selection list for the **Ground** boundary condition.

- 10 On the **Graphics** toolbar, click the **Go to Default 3D View** button .

Graphics




10

! More advanced boundary conditions for electromagnetics analysis are available with the AC/DC Module, such as the capability to give the total current on a boundary.


## COMBINING PHYSICS INTERFACES MANUALLY

As an alternative to using the preconfigured **Joule Heating** multiphysics interface, you can manually combine the **Electric Currents** and **Heat Transfer in Solids** interfaces. For example, you can start by setting up and solving the model for

**Electric Currents** and then subsequently add **Heat Transfer in Solids**. In that case, you right-click the **Multiphysics** node to add the required multiphysics couplings.




As an alternative, you can click the **Add Multiphysics** button in the ribbon and select a suggested multiphysics coupling in the **Add Multiphysics** window.




## Mesh

The simplest way to mesh is to create an unstructured tetrahedral mesh, which is perfect for the busbar model. Alternatively, you can create several meshing sequences, as shown in “Adding Meshes” on page 103.

- 💡 A physics-controlled mesh is created by default. In most cases, it is possible to skip to the **Study** node and just solve the model. For this exercise, the settings are investigated in order to parameterize the mesh settings.
- 1 In the **Model Builder**, click the **Mesh 1** node . In the **Settings** window for **Mesh**, select **User-controlled mesh** from the **Sequence type** list.
  - 2 Under **Mesh 1**, click the **Size** node .



- 3 In the **Settings** window for **Size**, in the **Element Size** section, click the **Custom** button.  
Under **Element Size Parameters**, enter:
  - **mh** in the **Maximum element size** field. Note that **mh** is 6 mm —



the value entered earlier as a global parameter. By using the parameter `mh`, element sizes are limited by this value.

- `mh - mh/3` in the **Minimum element size** field. The **Minimum element size** is slightly smaller than the maximum size.
- 0.2 in the **Curvature factor** field. The **Curvature factor** determines the number of elements on curved boundaries; A lower value gives a finer mesh.


The other two parameters are left unchanged.

**The Maximum element growth rate** determines how fast the elements should grow from small to large over a domain. The larger this value is, the larger the growth rate. A value of 1 does not give any growth.

**For Resolution of narrow regions**, a higher value will generally result in a finer mesh.

The asterisk (\*) that displays in the upper-right corner of the **Size** node  indicates that the node is being edited.

- 4 Click the **Build All** button  in the **Settings** window for **Size** to create the mesh, as in this figure:




You can also click **Build Mesh** in the **Home** tab of the ribbon.

## Study

To run a simulation, in the **Model Builder**, right-click **Study 1** and choose **Compute =**. You can also press F8 or click **Compute** in the ribbon **Home** tab.


The **Study** node automatically defines a solution sequence for the simulation based on the selected physics and study type. In this case, the simulation only takes a few seconds to solve. During the solution process, two **Convergence** plots are generated and are available from tabs next to the **Graphics** window. These plots show the convergence progress of the different solver algorithms engaged by the **Study**.




## Results

By default, in the **Results** node, three plot groups are generated: a **Multislice** plot of the **Electric Potential**, a **Surface** plot of the **Temperature**, and a plot named **Isothermal Contours** containing an **Isosurface** plot of the temperature.

Click **Results > Temperature** to view the **Temperature** plot in the **Graphics** window. The temperature difference in the device is less than 10 K due to the high thermal conductivity of copper and titanium. The temperature variations are largest in the top bolt, which conducts double the amount of current compared to the two lower bolts. The temperature is substantially higher than the ambient temperature of 293 K.



- 1 Click and drag the image in the **Graphics** window to rotate and view the back of the busbar.




- 2 In the **Graphics** toolbar, click the **Go to Default 3D View** button .


You can now manually set the color table range to visualize the temperature difference in the copper part.

- 3 In the model tree, expand the **Results > Temperature** node  and click the **Surface** node .


- 4 In the **Settings** window for **Surface**, click **Range** to expand the section. Select the **Manual color range** check box and enter 323 in the **Maximum** field (replace the default). Click the **Plot** button  in the **Settings** window for **Surface**.



- 5 On the **Graphics** toolbar, click the **Zoom Extents** button  to view the updated plot.



- 6 Click and drag in the **Graphics** window to rotate the busbar and view the back.




The temperature distribution is laterally symmetric with a vertical mirror plane running between the two lower titanium bolts and cutting through the center of the upper bolt. In this case, the model does not require much computing power and you can model the entire geometry. For more complex models, you can consider using symmetries to reduce the computational requirements.

Select **Go to Default 3D View** on the toolbar in the **Graphics** window ↕.



Then, generate a **Surface** plot that shows the current density in the device.

- In the **Model Builder**, right-click **Results** 📈 and add a **3D Plot Group** 📃. Right-click **3D Plot Group 4** 📃 and add a **Surface** node 📈.



- 2** In the **Settings** window for **Surface** under **Expression**, click the **Replace Expression** button . Go to **Model > Component 1 > Electric Currents > Currents and charge > ec.normJ - Current density norm** and double-click or press Enter to select.


**ec.normJ** is the variable for the magnitude, or absolute value, of the current density vector. You can also type **ec.normJ** in the **Expression** field when you know the variable name.



- 3** Click the **Plot** button .


The plot that displays in the **Graphics** window is almost uniform in color due to the high current density at the contact edges with the bolts. The next step is to manually change the color table range to visualize the current density distribution.

- 4** In the Settings window for **Surface** under **Range**, select the **Manual color range** check box. Enter **1e6** in the **Maximum** field and replace the default.




**5** Click the **Plot** button .

The resulting plot shows that the current takes the shortest path in the 90-degree bend in the busbar. Notice that the edges of the busbar outside of the bolts are hardly carrying any current.



**6** Click and drag the busbar in the **Graphics** window to view the back. Continue rotating the image to see the high current density around the contact surfaces of each of the bolts.




When you are done, click the **Go to Default 3D View** button  on the **Graphics** toolbar.

## GETTING THE MAXIMUM AND MINIMUM TEMPERATURE


You can easily obtain the maximum and minimum temperature values in the busbar, including their locations.

- Right-click **Results > Temperature** and select **More Plots > Max/Min Volume**.




- In the **Settings** window for **Max/Min Volume** under **Expression**, click the **Replace Expression** button . Go to **Mode I > Component I > Heat Transfer in Solids > Temperature > T - Temperature** and double-click or press Enter to select. You

can also search for Temperature in the search field above the tree of postprocessing variables. Click **Plot**.




The maximum and minimum values are plotted in the **Graphics** window and their locations and values are displayed in the **Maximum and minimum values** table.



As an alternative to the method of plotting the maximum and minimum values described above, you can use the **Derived Values** node for a pure numerical output.

- 3 In the **Results** section of the model tree, right-click the **Derived Values**  node and select **Maximum > Volume Maximum** .
- 4 In the **Settings** window for **Volume Maximum**, under **Selection**, choose **All domains**.
- 5 In the first row of the **Expression** table, enter **T** (unless it is automatically filled out) for the temperature and click **Evaluate** at the top of the **Settings** window.



The resulting maximum temperature is shown in **Table 1**.

Table 1
       
Temperature (K)
330.69

5

As a next step, you will create a model thumbnail image.

## CREATING MODEL IMAGES FROM PLOTS

With any solution, you can create an image to display when browsing for model files. After generating a plot, in the **Model Builder** under **Results**, click the corresponding plot node. Then click the root node (the first node in the model tree). In the **Settings** window for the root node under **Thumbnail**, click **Set from Graphics Window**.

There are two other ways to create images from a plot. One is to click the **Image Snapshot** button  in the **Graphics** window toolbar to directly create an

image. You can also add an **Image** node  to the **Export** node to create an image file. Right-click the plot group of interest and then select **Add Image to Export**.

- ! Make sure to save the model at this stage. This version of the model, `busbar.mph`, is reused and renamed during the next set of tutorials.

## Building an Application


---

This section gives a brief introduction to creating an application based on the Busbar model. The application will have a specialized user interface dedicated to interact with the busbar model and include input fields for the length, width, and applied voltage. The outputs will be the maximum temperature and a temperature plot.


You will learn how to use the New Form wizard to quickly create an application. The New Form wizard is used to create a form with user interface components called form objects. The wizard gives quick access to a subset of all of the form objects available for creating applications with the Application Builder. In this example, you will learn how to use the wizard to add input fields, numerical output, graphics, and buttons. For detailed information on building applications, see the book *Introduction to Application Builder*.

### CREATING A NEW FORM

- I To switch from the Model Builder to the Application Builder, click the **Application Builder** button in the leftmost part of the **Home** tab in the ribbon.




- 2 To create a new form, click the **New Form** button in the ribbon.



2


The wizard window appears.



2


It consists of three tabs for **Inputs/outputs**, **Graphics**, and **Buttons**. In the **Inputs/outputs** tab, you can double-click the nodes in the tree to make these available in the user interface of the application. For this application, we will select a few of the parameters as input fields and the maximum temperature as output.

- 3 Double-click each of the parameters: **Length (L)**, **Width (wbb)**, and **Applied voltage (Vtot)**. Also, double-click the **Volume Maximum** under **Derived Values**.




The **Preview** section to the right displays the user interface layout.

- 4 Click the **Graphics** tab in the wizard and double-click the **Temperature** plot. A graphics object placeholder appears in the **Preview** area.




- 5 Click the **Buttons** tab in the wizard and double-click **Compute Study 1**. A button now appears in the **Preview** area beneath the graphics object.




- 6 Finally, click **OK** to accept the settings and close the wizard.

After closing the New Form wizard, the Form editor is opened. The Form editor allows you to drag-and-drop form objects and add new ones




- 7 You can, for example, rearrange the user interface by dragging the graphics object to the right of the input fields and the button directly under the input

fields, as shown in the figure below. Blue guidelines will aid you in aligning the objects.




You can make the graphics object larger by dragging the blue handles.

- 8 You can test the application by clicking **Test Application** in the ribbon.




This creates a run-time copy of the application and lets you quickly try different designs during the process of developing an application.




- 9 Now, try a different **Length** value and click **Compute**.

## ADDING A BUTTON


You may wish to preview the geometry before starting the computation. This can easily be done by adding a button. There are two ways to add button. Either use the **Insert Object** menu in the ribbon, as shown in the figure below, or use the **Editor Tools** window. In this example, you will use the latter.




- | First, make sure the **Editor Tools** window is visible by selecting the corresponding button in the ribbon.



- 2 In the **Editor Tools** tree, right-click the **Geometry** node and select **Button**.




- 3 Drag the **Plot Geometry** button to the left of the **Compute** button.



Behind each button is a command sequence that controls the action taken when it is pressed. The command sequence is defined in the **Settings** window of the button and you can open the **Settings** window (if not already opened) by double-clicking the button.

- 4** Double-click the **Plot Geometry** button to see its **Settings** window. Command sequences appear below the tree in the section **Choose Commands to Run**.




4

In this case, the command sequence for the **Plot Geometry** has one command for plotting the geometry. The input argument contains information on which graphics window to send the geometry plot, in this case, the graphics object **graphics1**.

To automatically adjust the axis settings, you can add a **Zoom Extents** command.


- 5** In the **Choose Commands to Run** section, locate the **Zoom Extents** command under **GUI Commands > Graphics Commands**. Double click to add it to the command sequence.
- 6** Now, create the input argument to the **Zoom Extents** command. Click the white field next to **Zoom extents** and click the **Edit Argument** button.




6

6

- 7 This opens a dialog box with possible input arguments. Select **graphics1** under **form1**.



- 8 The command sequence is now complete.




- 9 To make sure the new **Plot Geometry** button works, you can test the application again by clicking **Test Application** in the ribbon.


## METHODS

To perform a more advanced operation than what is possible to do with a command sequence, you can use the Method editor to write code that defines the actions to be taken when the user clicks a button, selects a menu item, etc. An easy way to get started with the Method editor is to convert an existing command sequence into a method.


- | 1 Locate or open the **Settings** window for the **Plot Geometry** button again. Click the **Convert to New Method** button below the command sequence.



- | 2 To open the method in the Method editor, click the **Go to Method** button below the command sequence.



The Method editor now opens with the code for **method1** corresponding to the **Plot Geometry** and the **Zoom Extents** commands in the previous command sequence.




The Application Builder has several tools for automatically generating code. In addition to converting a command sequence to a method, you can, for example, click **Record Code** in the ribbon.



This will generate code for each operation performed in the COMSOL Desktop windows. Click **Stop Recording** in the ribbon to stop recording and go back to the Method editor.

To learn more about using the Form editor and the Method editor, see the book *Introduction to Application Builder*.

This completes the busbar example. To switch back to the Model Builder, click the **Model Builder** button in the ribbon.



The next sections are designed to deepen your understanding of the steps implemented so far, and to extend your simulation to include additional effects like thermal expansion and fluid flow. These additional topics begin on the following pages:

- “Parameters, Functions, Variables, and Couplings” on page 97
- “Material Properties and Material Libraries” on page 101
- “Adding Meshes” on page 103
- “Adding Physics” on page 105
- “Parametric Sweeps” on page 127
- “Parallel Computing” on page 139
- “COMSOL Multiphysics Client-Server” on page 143
- “Appendix A — Building a Geometry” on page 145

# Advanced Topics

---

## Parameters, Functions, Variables, and Couplings

---

This section explores working with parameters, functions, variables, and component couplings.

The **Global Definitions** and **Component > Definitions** nodes contain functionality that helps you to prepare model inputs and component couplings and organize simulations. You have already used the functionality for adding parameters to organize model inputs in “Global Definitions” on page 56.


Functions, available as both **Global Definitions** and **Component > Definitions**, contain a set of predefined function templates that can be useful when setting up multiphysics simulations. For example, the **Step** function template can create a smooth step function for defining different types of spatial or temporal transitions.

To illustrate using functions, assume that you want to add a time-dependent study to the busbar model, where an electric potential is applied across the busbar that goes from 0 V to 20 mV in 0.5 seconds. For this purpose, you could use a step function to be multiplied with the parameter *Vtot*. In this section, you will add a step function to the model that goes smoothly from 0 to 1 in 0.5 seconds to find out how functions can be defined and verified.


### DEFINING FUNCTIONS

For this section, you can continue working with the same model file created in the previous section. Locate and open the file *busbar.mph* if it is not already open on the desktop.

- 1 Right-click the **Global Definitions** node  and select **Functions > Step** .




- 2 In the **Settings** window for **Step**, enter 0.25 in the **Location** field to set the location of the middle of the step, where it has the value of 0.5.




- 3 Click **Smoothing** to expand the section and enter 0.5 in the **Size of transition zone** field to set the width of the smoothing interval. Keep the default **Number of continuous derivatives** at 2.
- 4 Click the **Plot** button  in the **Settings** window for **Step**.

If your plot matches the one below, this confirms that you have defined the function correctly.




You can also add comments and rename the function to make it more descriptive.

- 5 Right-click the **Step 1** node in the **Model Builder** and select **Properties** .




- 6 In the **Properties** window, enter any information you want. Right-click the **Properties** tab and select **Close** when you are finished.



For the purpose of this exercise, assume that you want to introduce a second component to represent an electric device connected to the busbar through the titanium bolts.

First, rename **Component 1** to specify that it represents the busbar.


- 1 Right-click the **Component 1** node and select **Rename** (or press F2).
- 2 In the **Rename Component** window, enter Busbar. Click **OK** and save the model.



## DEFINING COMPONENT COUPLINGS AND PROBES

Right-click the **Definitions** node under **Busbar (comp1)** to introduce a component coupling that computes the integral of any **Busbar (comp1)** variable at the bolt boundaries facing the electric device. You can use such a coupling, for example, to define a variable in a **Variables** node under the **Global Definitions** node that calculates the total current. This variable is then globally accessible and could, for example, form a boundary condition for the current that is fed to an electric device modeled as a second component.

The **Component Couplings** in **Definitions** have a wide range of uses. The **Average** , **Maximum** , and **Minimum** couplings have applications in generating results as well as in



boundary conditions, sources, sinks, properties, or any other contribution to the model equations. The **Probes**  are for monitoring the solution progress. For instance, you can follow the solution at a critical point during a time-dependent simulation or for each parameter value in a parametric study.

You can find an example of using the average operator in “Parametric Sweeps” on page 127. Also see “Functions” on page 171 for a list of available functions.



To learn more about working with definitions, in the **Model Builder**, click the **Definitions**  or **Global Definitions**  node and press F1 to open the **Help** window . This window displays helpful information about the selected item in the desktop and provides links to the documentation. It could take up to a minute for the window to load the first time it is activated, but will load quickly the next time it is opened.

## Material Properties and Material Libraries

---

You have already used the functionality in the **Materials** node to access the properties of copper and titanium in the busbar model. In the **Materials** node, you are also able to define your own materials and save them in your material library. You can also add material properties to existing materials. In cases where you define properties that are functions of other variables, typically temperature, the plot functionality helps you to verify the property functions in the range of interest. You can also load Excel® spreadsheets and define interpolation functions for material properties using LiveLink™ for Excel®.


The Material Library add-on contains over 2500 materials with tens of thousands of temperature-dependent property functions. In addition, many of the add-on products include material libraries relevant to their application areas.

First, investigate how to add properties to an existing material. Assume that you want to add bulk modulus and shear modulus to the copper properties.

### CUSTOMIZING MATERIALS

Let us keep working on the busbar.

- | In the **Model Builder**, under **Materials**, click **Copper** .




- 2** In the **Settings** window for **Material**, click to expand the **Material Properties** section, which contains a list of all of the definable properties.

Expand the **Solid Mechanics > Linear Elastic Material** section. Right-click **Bulk Modulus and Shear Modulus** and select **+ Add to Material**.

This lets you define the bulk modulus and shear modulus for the copper in your model.

- 3** In the **Copper** node, locate the **Material Contents** section. **Bulk modulus** and **Shear modulus** rows are now available in the table. The warning sign indicates that the values are not yet defined. To define the values, click the **Value** column. In the **Bulk modulus** row, enter **140e9** and in the **Shear modulus** row, enter **46e9**.




**3**

Property	Name	Value	Unit	Property group
Bulk modulus	K	140e9	N/m <sup>2</sup>	Bulk modulus and shear mod...
Shear modulus	G	46e9	N/m <sup>2</sup>	Bulk modulus and shear mod...
Electrical conductivity	sigma	5.998e7[S...]	S/m	Basic
Heat capacity at constant pressure	Cp	385[J/(kg*...]	J/(kg·K)	Basic
Relative permittivity	epsilon0r	1	1	Basic
Density	rho	8700[kg/m...]	kg/m <sup>3</sup>	Basic
Thermal conductivity	k	400[W/(m...]	W/(m·K)	Basic
Relative permeability	mur	1	1	Basic
Coefficient of thermal expansion	alpha	17e-6[1/K]	1/K	Basic
Young's modulus	E	110e9[Pa]	Pa	Young's modulus and Poisson...
Poisson's ratio	nu	0.35	1	Young's modulus and Poisson...
Reference resistivity	rho0	1.72e-8[ohm m]	ohm m	Linearized resistivity

By adding these material properties, you have changed the **Copper** material. You can save this information in your own material library, but not in the read-only Solid Mechanics materials library.

- 4** In the **Model Builder**, right-click **Copper** and select **Add to User-Defined Library**



To see this library, click the **Browse Materials** in the **Materials** tab in the ribbon.


## Adding Meshes

A model component can contain different mesh sequences for generating meshes with different settings. A mesh sequence is an ordered set of instructions for generating a mesh. Mesh sequences can be accessed by the study steps. In a study, you can select which mesh you would like to use in a particular simulation.

In the busbar model, a second mesh node is now added to create a mesh that is refined in the areas around the bolts and the bend.


### ADDING A MESH

- 1 Open the model `busbar.mph` that was created earlier.
- 2 In order to keep this model in a separate file for later use, select **File > Save As** and rename the model `busbar_I.mph`.
- 3 To add a second mesh node, right-click the **Component 1** node  and select **Add Mesh** .




By adding another **Mesh** node, a **Meshes** parent node is created that contains both **Mesh 1** and **Mesh 2**.

- 4 Click the **Mesh 2** node. In the Settings window for **Mesh** under **Mesh Settings**, select **User-controlled mesh** as the **Sequence type**.  
A **Size** and **Free Tetrahedral** node are now available under **Mesh 2**.



- 5 In the **Model Builder**, under **Mesh 2**, click **Size**



The asterisk in the upper-right corner of a node icon indicates that the node is being edited.

- 6 In the **Settings** window for **Size**, under **Element Size**, click the **Custom** button.


- 7 Under **Element Size Parameters**, enter:

- mh/2 in the **Maximum element size** field, where mh is 6 mm — the mesh control parameter defined previously.
- mh/2-mh/6 in the **Minimum element size** field.
- 0.2 in the **Curvature factor** field.

- 8 Click **Build All** . Save the file as **busbar\_I.mph**.

Compare **Mesh 1** and **Mesh 2** by clicking the **Mesh** nodes. The mesh is updated in the **Graphics** window. An alternative to creating multiple meshes in this way is to

run a parametric sweep of the parameter for the maximum mesh size,  $m_h$ , that was defined in the section “Global Definitions” on page 56.



## Adding Physics

The distinguishing characteristics of COMSOL Multiphysics, particularly adaptability and compatibility, are prominently displayed when you add physics to an existing model. In this section, you will experience the ease with which this seemingly difficult task is performed. By following these directions, you can add structural mechanics and fluid flow to the busbar model.

### STRUCTURAL MECHANICS


After completing the busbar Joule heating simulation, we know that there is a temperature rise in the busbar. What kind of mechanical stress is induced by thermal expansion? To answer this question, let us expand the model to include the physics associated with structural mechanics.

- ! To complete these steps, either the Structural Mechanics Module or the MEMS Module (which enhances the core Solid Mechanics interface) is required.

If you want to add cooling by fluid flow, or do not have the Structural Mechanics Module or MEMS Module, read this section and then go to “Cool by Adding Fluid Flow” on page 114.

**1** Open the model `busbar.mph` that was created earlier. From the main menu, select **File > Save As** and rename the model `busbar_II.mph`.


**2** In the **Model Builder**, right-click the **Component 1** node  and select **Add Physics** .



**3** In the **Add Physics** window, under **Structural Mechanics**, select **Solid Mechanics** .

To add this interface, you can right-click and select **Add to Component** or click the **+ Add to Component** button at the top of the window.


**4** Close the **Add Physics** window and save the file.



 When adding additional physics, you need to make sure that materials included in the **Materials** node have all of the required properties for the selected physics. In this example, all properties are already available for copper and titanium.

You can start by adding the effect of thermal expansion to the structural analysis.


- 5 In the **Model Builder**, right-click the **Multiphysics** node  and select **Thermal Expansion** .
- A **Thermal Expansion** node is added to the model tree.
- You can also use the ribbon and select, from the **Physics** tab, **Multiphysics > Thermal Expansion**.




- 6 In the **Settings** window for **Thermal Expansion**, from the **Selection** list, select **All domains**. This will enable thermal expansion in the copper as well as in the titanium bolts.

The **Thermal Expansion Properties** section of this window shows information about the **Coefficient of thermal expansion** and the **Strain reference temperature** (there are also some more advanced settings.) The **Coefficient of thermal expansion** takes its value from the **Materials** node. The **Strain reference temperature** has a default value of 293.15 K (room temperature) and defines the temperature for which there is no thermal expansion. The **Coupled Interfaces** section at the bottom of the **Settings** windows shows which two physics interfaces define the physics for heat transfer and solid mechanics. This is useful in the case where there is more than one physics interface for heat transfer or solid mechanics in the model component. Keep all default settings in this window.

Next, constrain the busbar at the position of the titanium bolts.




- In the model tree, right-click **Solid Mechanics** and from the boundary level, select **Fixed Constraint**. A node with the same name is added to the tree.
- Click the **Fixed Constraint** node. In the **Graphics** window, rotate the busbar to view the back. Click the circular surface of one of the bolts to add it to the **Selection** list.
- Repeat this procedure for the remaining bolts to add boundaries 8, 15, and 43.



! For easier management of multiple boundary selections, you can group boundaries into a user-defined selection. Once you have selected boundaries 8, 15, and 43, click the **Create Selection** button and give it a name such as **Bolt top surfaces**.



This selection is then added as a node under **Component I > Definitions** and is accessible from the **Selection** list in the **Settings** window for all types of boundary conditions. You can use this technique to group domains, boundaries, edges, and points.




Next, we update the **Study** node to take the added physics into account.


## SOLVING FOR JOULE HEATING AND THERMAL EXPANSION

The Joule heating effect is independent of the stresses and strains in the busbar, assuming temperature invariant materials, small deformations, and ignoring the effects of electric contact pressure. This means that you can run the simulation using the temperature as merely an input to the structural analysis. In other words, the extended multiphysics problem is weakly coupled. As such, you can solve it in two separate study steps to save computation time — one for Joule heating and a second one for structural analysis. In a more advanced analysis, you can include all of the aforementioned effects.

- For this example, you can skip these steps and just click **Compute**. However, the following technique can be useful for saving computational time and memory resources, especially for larger simulations.
- 1 In the **Model Builder**, right-click **Study 1** and select **Study Steps > Stationary > Stationary** to add a second stationary study step.




- When adding study steps, you need to manually connect the correct physics with the correct study step. We start by disabling the structural analysis from the first step.
- 2 Under **Study 1**, click the **Step 1: Stationary** node.
- 3 In the **Settings** window for **Stationary**, locate the **Physics and Variables Selection**.
- 4 In the **Solid Mechanics (solid)** row under **Solve for**, click to change the check mark  to an  to remove **Solid Mechanics** from **Study Step 1**.  
In the **Multiphysics** section, keep all of the default settings.




Now, repeat these steps to remove **Electric Currents (ec)** and **Heat Transfer in Solids (ht)** from the second study step.

- 5 Under **Study 1**, click **Step 2: Stationary 2**.



- 6 Under Physics and Variables Selection**, in the **Electric Currents (ec)** and **Heat Transfer in Solids (ht)** rows, click to change the check mark  to an  to remove Joule heating from **Step 2: Stationary 2.**



- 7 Right-click the Study 1 node** and select **Compute** = (or press F8 or click **Compute** in the ribbon) to solve.




Save the file as **busbar\_II.mph**, which now includes the **Solid Mechanics** interface and the additional study step.


## RESULTING DEFORMATION

Now that a physics interface has been added, additional plots for **Solid Mechanics** need to be added manually. First, a displacement plot.

- I Under **Results > 3D Plot Group 4**, click the **Surface 1** node .



- 2 In the **Settings** window for **Surface** in the **Expression** section, click the **Replace Expression** button .




From the context menu, select **Model > Component 1 > Solid Mechanics > Displacement > solid\_disp - Total displacement**.

You can also enter `solid_disp` in the **Expression** field.

Now, change to a more suitable unit. In the **Settings** window under **Expression**, from the **Unit** list, select **mm** (or type **mm** in the field).

- 3 Click **Range** to expand that section. Click to clear the **Manual color range** check box.




The local displacement due to thermal expansion is displayed as a surface plot. Next, we will add information about the busbar deformation.

- 4 In the **Model Builder**, under **Results > 3D Plot Group 4**, right-click the **Surface 1** node  and add a **Deformation** node . The plot automatically updates in the **Graphics** window. Click the **Go to Default 3D View** button  so your view appears similar to the plot shown below.



The deformations shown in the figure are highly amplified to make the very small distortions that actually take place more visible.



4

- 5 Save the `busbar_II.mph` file, which now includes a **Surface** plot with a **Deformation**.



You can also plot the von Mises and principal stresses to assess the structural integrity of the busbar and the bolts.


## OVERRIDE AND CONTRIBUTION: EXCLUSIVE AND CONTRIBUTING NODES

The model tree nodes for a physics interface are traversed in a downward sequence starting from the top. Depending on the selection, a node can totally or partially override, or shadow, a node that comes earlier in the sequence. There are two types of physics interface nodes: exclusive and contributing. How the nodes are treated depends on the type.


A constraint boundary condition is a typical example of an exclusive node.

Examples of constraint boundary conditions include **Electric Potential** or **Fixed Constraint**. In the case of **Electric Currents**, for example, if there are two or more **Electric Potential** nodes for the same boundary, then the last **Electric Potential** node in the sequence will override the settings of the other nodes. The **Ground** node is also an exclusive node and will similarly override the boundary conditions specified by any previous node.

The figure below shows the **Override and Contribution** section in the **Settings** window for **Electric Potential**. The **Overrides** list indicates that this boundary condition takes precedence over the default **Electric Insulation** boundary condition.



A flux boundary condition, such as one specifying a heat flux, is a typical example of a contributing node. You can stack several heat flux boundary conditions and they will all contribute to the total heat flux. The figure below shows an example where a **Heat Flux 2** boundary condition overrides the default **Thermal Insulation** boundary condition and contributes to the heat flux together with **Heat Flux 1**.



In the model tree, the override and contribution relationships are indicated by a red arrow and an orange circle, respectively.


## COOL BY ADDING FLUID FLOW

After analyzing the heat generated in the busbar and possibly the induced thermal expansion, you might want to investigate ways of cooling the busbar by letting air flow over its surfaces. These steps do not require any additional modules, as the model only includes Joule heating without the previous thermal expansion analysis.

! If you have the CFD Module, the **Non-Isothermal Flow** multiphysics interface is available. If you have the Heat Transfer Module, the **Conjugate Heat Transfer** multiphysics interface is available. Either one of these two interfaces automatically defines coupled heat transfer in solids and fluids including laminar or turbulent flow, whereas in this example, this is done manually and with limited functionality.

Adding fluid flow to the Joule heating model creates a new multiphysics coupling. To simulate the flow domain, you need to create an air box around the busbar for the external flow. You can do this manually by altering the geometry from your first model or by opening an Application Library file. To save time, open a file with the box already created.


After loading the geometry, you will learn how to simulate air flow according to this figure:



## DEFINING INLET VELOCITY

Start by loading the geometry and adding a new parameter for the inlet flow velocity.

- If you have just reopened the software, close the **New** window that opens automatically by clicking the **Cancel** button .
- Click the **Home** tab, and from the **Windows** menu select **Application Libraries**  . Navigate to **COMSOL Multiphysics > Multiphysics > busbar box**. (You can also open the Application Libraries directly from the **File** menu.)  
Double-click to open the file, which contains the geometry in addition to the physics modeling steps completed through the end of the section “Customizing Materials” on page 101.



- Under **Global Definitions**, click the **Parameters** node .
- In the **Settings** window for **Parameters**, click the empty row just below the **Vtot** row. In the **Name** column, enter **Vin**. Enter **1e-1[m/s]** in the **Expression** column and a description of your choice in the **Description** column, such as **Inlet velocity**.


Name	Expression	Value	Description
L	9[cm]	0.09 m	Length
rad_1	6[mm]	0.006 m	Bolt radius
tbb	5[mm]	0.005 m	Thickness
wbb	5[cm]	0.05 m	Width
mh	6[mm]	0.006 m	Maximum element size
htc	5[W/m^2/K]	5 W/(m^2.K)	Heat transfer coefficient
Vtot	20[mV]	0.02 V	Applied voltage
Vin	1e-1[m/s]	0.1 m/s	Inlet velocity

- Select **File > Save As** and save the model with a new name, **busbar\_box\_I.mph**.




## ADDING AIR

The next step is to add the material properties of air.

- 1 From the **Home** tab, select **Add Material**  (or right-click the **Materials** node and select **Add Material**.)
- 2 In the **Add Material** window, expand the **Built-In** node. Right-click **Air** and select **Add to Component 1**. Close the **Add Material** window.
- 3 In the **Model Builder** under **Materials**, click the **Air** node .



- 4 On the **Graphics** window toolbar, click **Zoom Extents** .
- 5 In the **Graphics** window, click the air box (domain 1) to add it to the **Selection** list, which changes the color to blue. This step assigns the air material properties to the air box.




## ADDING FLUID FLOW

Now, add the physics of fluid flow.

- 1 In the model tree, right-click **Component 1**  and select **Add Physics** .

- 2 In the **Add Physics** window under **Fluid Flow > Single-Phase Flow**, right-click **Laminar Flow**  and select **+ Add to Component**.

**Laminar Flow** will appear under **Component 1** in the model tree. Close the **Add Physics** window.




- 3 In the **Graphics** toolbar, click the **Transparency** button . In addition, click the **Wireframe Rendering** button . These two settings make it easier to see inside the box. Toggle these on and off as needed during the modeling process to control the type of rendering used.


Now that you have added fluid flow to the model, you need to remove the air domain (domain 1) from the **Electric Currents (ec)** interface (assuming that the air has no electric conductivity and hence no currents) and then couple the heat transfer part of the **Joule Heating** multiphysics interface to the fluid flow.

- 4 In the model tree, select the **Electric Currents (ec)** node . In the **Graphics** window, move the mouse pointer over the air domain and click to remove it from the selection list. At this point, only the busbar should be selected and highlighted in blue.

4




- 5 In the **Model Builder**, right-click **Heat Transfer in Solids (ht)**. In the first section of the context menu, the domain level , select **Fluid**.



- 6 In the **Graphics** window, click the air domain (domain 1) to add it to the **Selection** list.


Now, couple the fluid flow and heat transfer phenomena.

6



- 7 In the **Settings** window for **Fluid** in the section **Model Inputs**, select **Velocity field (spf)** from the **Velocity field** list. Then, select **Absolute pressure (spf)** from the **Absolute pressure** list.


This identifies the flow field and pressure from the **Laminar Flow** interface and couples it to heat transfer.



Now, define the boundary conditions by specifying the inlet and outlet for the heat transfer in the fluid domain.

- 8 In the **Model Builder**, right-click **Heat Transfer in Solids** . In the second section of the context menu, the boundary section , select **Temperature**.

A **Temperature** node is added to the model tree.




- 9 In the **Graphics** window, click the inlet boundary, boundary number 2, to add it to the **Selection** list.


This sets the inlet temperature to 293.15 K, the default setting.

The graphics should look like the image to the right. (It may look slightly different depending on whether you have **Transparency** and **Wireframe Rendering** on or off.)

Continue by defining the outlet.




- 10 In the **Model Builder**, right-click **Heat Transfer in Solids** . At the boundary level, select **Outflow**. An **Outflow** node is added to the model tree.




- II In the **Graphics** window, click the outlet boundary, boundary number 5, to add it to the **Selection** list. Use the mouse scroll wheel to scroll in and highlight the boundary before selecting it, or use the up and down arrow keyboard buttons.

II




- ! The settings for the busbar, the bolts, and the **Electric Potential I** and **Ground I** boundaries have retained the correct selection, even though you added the box geometry for the air domain. To confirm this, in the model tree under **Electric Currents**, click the **Electric Potential I** and the **Ground I** nodes to verify that they have the correct boundary selection.



Next, continue with the flow settings. You need to indicate that fluid flow only takes place in the fluid domain and then set the inlet, outlet, and symmetry

conditions. Do this by first removing all domains from the selection and then adding the air domain.

- In the model tree, click the **Laminar Flow** node . In the **Settings** window for **Laminar Flow**, click the **Clear Selection** button .




- In the **Graphics** window, click the air box (domain 1) to add it to the **Selection**.

 It is good practice to verify that the **Air** material under the **Materials** node has all of the properties that this multiphysics combination requires. In the model tree under **Materials**, click **Air**. In the Settings window for **Material** under **Material Contents**, verify that there are no missing properties, which are marked with a warning sign . The section “Materials” on page 62 has more information.

- ! Materials
  - Materials
  - Copper (mat1)
  - Titanium beta-21S (mat2)
  - Air (mat3)


Now, we continue with the boundaries.

- In the **Model Builder**, right-click **Laminar Flow**  and at the boundary level, select **Inlet**. An **Inlet** node  is added to the model tree.



- 4 In the **Graphics** window, click the inlet (boundary 2) to add it to the **Selection** list.

4




- 5 In the **Settings** window for **Inlet** under **Velocity** in the  $U_0$  field, enter  $V_{in}$  to set the **Normal inflow velocity**.



- 6 Right-click **Laminar Flow** and at the boundary level, select **Outlet** . In the **Graphics** window, click the outlet (boundary 5) to add it to the **Selection** list. Use the mouse scroll wheel or keyboard arrows to scroll in and highlight the boundary before selecting it.

The last step is to add symmetry boundaries. For simplicity, assume that the flow just outside of the faces of the channel is similar to the flow just inside these faces. This assumption can be correctly expressed by the symmetry condition.


6



- 7 Right-click **Laminar Flow** and select **Symmetry**. A **Symmetry** node is added to the sequence.

- 8** In the **Graphics** window, click each of the blue faces in the figure below (boundaries 1, 3, 4, and 48) to add all of them to the **Selection** list. You may need to use the mouse scroll wheel or rotate the geometry to select all of them.


Save the `busbar_box_I.mph` file, which now includes the **Air** material and **Laminar Flow** interface settings.



8

When you know the boundary numbers, you can click the **Paste Selection** button and enter the information. In this example, enter `1,3,4,48` in the **Paste Selection** window.

Click **OK** and the boundaries are automatically added to the **Selection** list.




## COARSENING THE MESH

To get a quick solution, we will change the mesh slightly and make it coarser. The current mesh settings would take a relatively long time to solve, and you can always refine it later.


- I** In the **Model Builder**, expand the **Mesh 1** node and click the **Size** node .



- 2 In the **Settings** window for **Size** under **Element Size**, click the **Predefined** button and ensure that **Normal** is selected.



- 3 Click the **Build All** button . The geometry displays with a mesh in the **Graphics** window (you may need to turn **Transparency** off to see the picture below.)




You can assume that the flow velocity is large enough to neglect the influence of the temperature increase in the flow field.

It follows that you can solve for the flow field first and then solve for the temperature using the results from the flow field as input. This is implemented with a study sequence.

## SOLVING FOR FLUID FLOW AND JOULE HEATING


When the flow field is solved before the temperature field, it yields a weakly coupled multiphysics problem. The study sequence described in this section automatically solves such a weak, or one-directional, coupling.

- 1 In the model tree, right-click **Study 1** and select **Study Steps > Stationary > Stationary** to add a second stationary study step to the **Model Builder**.




Next, the correct physics needs to be connected with the correct study step. Start by disabling the **Electric Currents (ec)** and **Heat Transfer in Solids (ht)** interfaces associated with Joule heating from the first step.

- 2 Under **Study 1**, click **Step 1: Stationary** .




- 3 In the **Settings** window for **Stationary**, locate the **Physics and Variables Selection** section. In both the **Electric Currents (ec)** and the **Heat Transfer in Solids (ht)** rows, click to change the check mark to an in the **Solve for** column, removing the Joule heating effect from **Step 1**.

- 4 Repeat the step. Under **Study 1**, click **Step 2: Stationary 2** . Under **Physics and Variables Selection**, in the **Laminar Flow (spf)** row, click in the **Solve for** column to change the check mark  to an .




- 5 Right-click the **Study 1** node and select **Compute =** (or press F8 or click **Compute** in the ribbon). This will now automatically create a new solver sequence that solves for laminar flow and then Joule heating.



- 6 After the solution is complete, select the **Temperature (ht)** plot under the **Results** node in the **Model Builder**. If you do not already have transparency on, click the **Transparency** button on the **Graphics** toolbar to visualize the temperature field

inside the box. To zoom, middle-click and hold down the mouse button (or scroll wheel) while dragging the mouse.



The **Temperature Surface** plot that displays in the **Graphics** window shows the temperature in the busbar and in the surrounding box. You can also see that the temperature field is not smooth due to the relatively coarse mesh. A good strategy to get a smoother solution would be to refine the mesh to estimate the accuracy.

- 7 At this point, save the `busbar_box_I.mph` file so you can return to it at any time. The next steps use the original `busbar.mph` file.

## Parametric Sweeps

---


### Sweeping a Geometric Parameter

It is often useful to generate multiple instances of a design with the objective of meeting specific constraints. In the previous busbar example, a design goal might be to lower the operating temperature or decrease the current density. We will demonstrate the former. Since the current density depends on the geometry of the busbar, varying the width, `wbb`, should change the current density and, in turn, have some impact on the operating temperature. Let us run a parametric sweep on `wbb` to study this change.


## ADDING A PARAMETRIC SWEEP

- From the **File** menu, open the model file **busbar.mph**. If you did not save the model, you can also open it from the Application Libraries: **File > Application Libraries > COMSOL Multiphysics > Multiphysics > busbar**.

In the **Model Builder**, right-click **Study 1** and select **Parametric Sweep**. A **Parametric Sweep** node is added to the **Model Builder** sequence.




- In the **Settings** window for **Parametric Sweep**, under the empty parameter table, click the **Add** button **+**. From the **Parameter names** list in the table, select **wbb**.



The **Sweep type** is used to control parametric sweeps with multiple parameters. You select between sweeping for **All combinations** of the given parameters or a subset of **Specified combinations**.

- 3** Enter a range of parameter values to sweep the width of the busbar from 5 cm to 10 cm in 1 cm increments. There are different ways to enter this information:
- Copy and paste or enter `range(0.05,0.01,0.1)` into the **Parameter value list** field.
  - Click the **Parameter value list** field and then click the **Range**  button and enter the values in the **Range** dialog box. In the **Start** field, enter `5e-2`. In the **Step** field, enter `1e-2`, and in the **Stop** field, enter `1e-1`. Click **Replace**.
  - In any of the methods, you can also use length units to override the default SI unit system using meters. Instead of `5e-2`, you can enter `5[cm]`; similarly, `1[cm]` instead of `1e-2` and `10[cm]` instead of `1e-1`. You can also change the default unit system from the **Settings** window of the root node in the model tree.



**3**


Study Settings

Sweep type: Specified combinations


Parameter name	Parameter value list	Parameter unit
wbb (Width)	range(0.05,0.01,0.1)	

Next, define an **Average** component coupling that can be used later to calculate the average temperature in the busbar.

- 4 Under **Component 1**, right-click **Definitions** and select **Component Couplings > Average**.



- 5 In the **Settings** window for **Average**, select **All domains** from the **Selection** list.





This creates an operator called `aveop1`. This operator is now available to calculate the average of any quantity defined on the selected domains. Later, we use this tool to calculate the average temperature, but it can also be used to calculate average electric potential, current density, and so forth.

- Select **File > Save As** to save the model with the new name, **busbar\_III.mph**.
- Right-click **Study 1** and select **Compute =** to run the sweep or click **Compute** in the **Home** tab.


## PARAMETRIC SWEEP RESULTS

Click the **Temperature (ht) 1** node located under **Results** in the model tree.

The plot that displays in the **Graphics** window shows the temperature in the wider busbar using the last parameter value,  $wbb=0.1[m]$  ( $10[cm]$ ). Select **Zoom Extents** from the **Graphics** window toolbar so that you can see the entire plot. The resulting plot is rather uniform in color, so we need to change the maximum color range.





- | Under the **Temperature (ht) 1** node, click the **Surface** node




- 2 In the **Settings** window for **Surface**, click **Range** to expand the section. Select the **Manual color range** check box. Enter 309.4 in the **Maximum** field (replace the default).

- 3 The **Temperature (ht)** 1 plot is updated in the **Graphics** window for  $wbb=0.1[m]$  ( $10[cm]$ ).



Compare the wider busbar plot to the temperature for  $wbb=0.05[m]$  ( $5[cm]$ ). For this purpose, you can reuse one of the previously defined plot groups.



- 1 In the **Model Builder**, click the first **Temperature (ht)** node .



- 2** In the **Settings** window for **3D Plot Group**, select **Study 1/Parametric Solutions 1** from the **Data set** list. This data set contains the results from the parametric sweep.

- 3** In the **Parameter value** list, select **0.05** (which represents  $wbb=5\text{ cm}$ ). Click the **Plot** button . Click the **Zoom Extents** button on the **Graphics window** toolbar.

The **Temperature (ht)** plot is updated for  $wbb=0.05[\text{m}] (5[\text{cm}])$ . Note that if you have updated the color range for this plot already, your plot should look similar to the one below. If not, follow the subsequent steps.



Like the wider busbar, the plot may be quite uniform in color, so change the maximum color range.


- 1** Under the first **Temperature (ht)** node, click the **Surface** node .
- 2** In the Settings window for **Surface**, click **Range** to expand the section (if it is not already expanded). Select the **Manual color range** check box.

- 3 Enter 323 in the **Maximum** field (replace the default) to plot wbb at 5 cm. The **Temperature (ht)** plot is updated in the **Graphics** window for  $wbb=0.05[m]$  ( $5[cm]$ ). Click the first and second **Temperature** plot nodes to compare the plots in the **Graphics** window. The maximum temperature decreases from 331 K to 318 K as the width of the busbar increases from 5 cm to 10 cm.


## ADDING MORE PLOTS

To further analyze these results, you can plot the average temperature for each width.


- | Right-click **Results**  and add a **ID Plot Group** .



- 2 In the **Settings** window for **ID Plot Group**, select **Study 1/Parametric Solutions 1** from the **Data set** list.




- 3 In the **Model Builder**, right-click **ID Plot Group 8** and add a **Global** node.




- 4 In the **Settings** window for **Global** under **y-Axis Data**, click the first row in the **Expressions** column and enter `aveop1(T)`. This is the operator that we defined on page 130 for later use. You use a similar syntax to calculate the average of other quantities.


You can also use autocompletion by using **Ctrl+Space** after clicking the first row.



To use a coupling operator without solving, you can select the option **Update Solution** that is available by right-clicking a **Study** node.



- 5 Click to expand the **Legends** section. Select the **Expression** check box.  
This adds a legend at the top-right corner of the graph.
- 6 Click the **Plot** button  and save the **busbar\_III.mph** model with these additional plots that use the parametric sweep results.




In the plot, the average temperature decreases as the width increases.

## PARAMETERS IN RESULTS

For greater flexibility, it is possible to define parameters that are only used in the **Results** node. Using these parameters does not require resolving the model. The following example shows how you can animate over a **Parameter** defined under **Results**.

- 1 Right-click the **Results** node and select **Parameters**.



- 2 Define a parameter, `iso_level`, with **Expression** `309.5[K]`.

This screenshot shows the Model Builder and Settings windows. In the Model Builder, under the 'Parameters (param)' node, a new parameter 'iso\_level' is defined with the expression '309.5[K]'. In the Settings window, the 'Parameters' section shows a table:


Name	Expression	Value	Description
iso_level	309.5[K]	309.5 K	Isosurface level

A blue circle labeled '2' is placed over the Settings window.


- 3 For the **Isothermal Contours (ht)** 1 plot group, in the **Settings** window for the **Isosurface** plot, change the **Entry method** to **Levels**. For the **Levels** expression field, type `iso_level`.

This screenshot shows the Model Builder and Settings windows. In the Model Builder, the 'Isothermal Contours (ht) 1' node is selected. In the Settings window, for the 'Isosurface (iso1)' plot, the 'Entry method' is set to 'Levels' and the 'Levels' expression field contains 'iso\_level'. A blue circle labeled '3' is placed over the Settings window.

- 4 In the same **Settings** window, click **Plot**.



- 5** Generate an **Animation** by either selecting the **Player** option in the **Animation** menu of the **Isothermal Contours (ht)** 1 tab in the ribbon, or right-click the Export node and select **Animation > Player**.



- 6** In the **Settings** window for **Animation**, change the **Sequence type** to **Result parameter** and select the **iso\_level** parameter. Type **309.25** for **Start** and **309.75** for **Stop**. Click the **Play** button in the **Graphics** toolbar or the **Show Frame** button in the **Settings** window for the **Animation**. To get a smoother animation, change the **Number of frames** to a higher number; for example, **50**.


The subject of parametric sweeps raises the question of parallel computing; it would be efficient if all parameters were solved simultaneously.

## Parallel Computing

COMSOL Multiphysics and COMSOL Server support most forms of parallel computing, including shared memory parallelism for multicore processors and high-performance computing (HPC) for clusters and clouds. All COMSOL


licenses are multicore enabled. For cluster or cloud computing, including parallelized sweeps, a Floating Network License (FNL) is needed.

You can use clusters or clouds with one of two options: either for **Cluster Sweep** or for **Cluster Computing**. If you have a Floating Network License, these two options are available by right-clicking the **Study** node. However, you first need to enable **Advanced Study Options** by clicking the **Show** button  on the **Model Builder** toolbar and selecting **Advanced Study Options**.



## CLUSTER SWEEP

The **Cluster Sweep** option is used for solving several models in parallel where each model has a different set of parameters. This can be seen as a generalization of **Parametric Sweep**. Right-click the **Study** node to add a **Cluster Sweep** node.



The **Study Settings** for **Cluster Sweep** are similar to that of **Parametric Sweep**, but additional settings are required for the cluster or cloud being used. The picture above shows how the top of the **Settings** window for **Cluster Sweep** would look for


the same sweep as defined in “Parametric Sweeps” on page 127. To run a cluster sweep in this case, you would first remove the **Parametric Sweep** node.

## CLUSTER COMPUTING

You can also utilize a cluster or cloud to solve a single large model using distributed memory. For maximum performance, the COMSOL software cluster implementation can utilize shared-memory multicore processing on each node in combination with the message passing interface (MPI) based distributed memory model. This is also known as hybrid parallelism and brings a major performance boost by making the most out of the computational power available.

Right-click the **Study** node to add a **Cluster Computing** node. A **Cluster Computing** node cannot be used in combination with a **Cluster Sweep**. You will be asked if you want to remove the **Cluster Sweep** before proceeding. Select **Yes**.

The **Settings** window for **Cluster Computing**, shown below, helps to manage the simulation with settings for the cluster or cloud.



You choose the type of cluster job you want to perform from the **Cluster type** list. COMSOL Multiphysics and COMSOL Server support General, Windows® Compute Cluster Server (WCCS) 2003, Windows® HPC Server (HPCS) 2008/2012, Open Grid Scheduler/ Grid Engine (OGS/GE), SLURM, or Not distributed. The **General** option is a multipurpose option for Linux® clusters. Additional cluster and scheduler settings, such as **Prepend command** and **Postpend command**, are available in the **Preferences** window available from the **File** menu.

To learn more about running in parallel, see the *Reference Manual*.

## COMSOL Multiphysics Client-Server

---

When using COMSOL Multiphysics with a Floating Network License (FNL), it is possible to use a client-server mode of operation to access remote computing resources for solving large models, while still using the graphics card on a local machine to display graphics. (This mode of operation should not be confused with the COMSOL Server product for use with COMSOL applications.)

Using the COMSOL Multiphysics client-server mode can have some significant advantages, since engineering and scientific computing problems involve working with large amounts of data — anywhere from megabytes to gigabytes of data are commonly generated during a simulation. To generate and store this data, you may want to use computers with fast processors, large amounts of Random Access Memory (RAM), and a large hard drive. To visualize large data sets, it is important to have a high-end graphics card on your local computer.

Under ideal conditions, you would always be working on a high-end computer with more than enough memory and processing power for all of the simulation steps. But if this is not the case and you need to solve larger models, you may instead access a shared computing resource across a network.

At any time while using COMSOL Multiphysics, it is possible to connect to a remote computing resource via the client-server mode of operation. This is a two-step process. First, log onto the remote system and invoke the COMSOL Multiphysics server, which will start the COMSOL Multiphysics server process and open a network connection. Second, on the local machine, simply enter the network connection information into an open session of COMSOL Multiphysics. The software then transparently streams the model data and results back and forth over the network and uses the remote computing resource for all computations.


There are several ways to start a COMSOL Multiphysics server session. In Windows® 7, you can, for example, start a server session from the start menu under **COMSOL Multiphysics 5.2a > Client-Server**. In Windows® 10, you can start a server session from the **COMSOL Launchers** option from the Windows start menu. In Linux®, you can use the `comsol mphserver` command. The server and client sessions can be run on different operating systems. For example, the server can run in Linux® and the client session in Windows®.

The first time you start a COMSOL Multiphysics server on a computer, you are asked for a username and password that are associated with the client-server mode


of operation and stored for future connections. The figure below shows the command window for starting a server session in Windows.

```
COMSOL Multiphysics Server
Username: paul
Password: 
Confirm password: 
Port number 2036 was busy, using 2038 instead
COMSOL Multiphysics Server started listening on port 2038
Use the console command 'close' to exit the program
```

The figure below shows how to connect to a server session from the COMSOL Desktop user interface. To connect, from the **File** menu, select **COMSOL Multiphysics Server > Connect to Server**.



You are now prompted for the username and password that you gave the first time you started a server session.



For more information on running the COMSOL Multiphysics client-server, see the *Reference Manual*.

## Appendix A — Building a Geometry

---

This section details how to create the busbar geometry using the built-in geometry tools in COMSOL Multiphysics. The step-by-step instructions take you through the construction of the geometry using the parameters set up in the **Global Definitions** section. Using parameterized dimensions helps to produce *what-if* analyses and geometric parametric sweeps.


As an alternative to building the geometry using the tools available in COMSOL Multiphysics, you can import a geometry created with a CAD package. The optional CAD Import Module and Design Module support many CAD file formats. Moreover, several add-on products are available that provide bidirectional interfaces to common CAD software packages. See “Appendix E — Connecting with LiveLink™ Add-Ons” on page 185 for a list. Note that the Design Module, in addition to the features available in the CAD Import Module, adds 3D functionality for loft, fillet, chamfer, midsurface, and thicken.

If you have not done so already, start with “Example 2: The Busbar — A Multiphysics Model” on page 52. Follow the steps in the section “Model Wizard” on page 30 to add the physics and study and then follow the steps under **Global Definitions** to add the parameters. Return to this section to learn about geometry modeling. The first step in the geometry sequence is to draw the profile of the busbar.

- 1 Under **Component 1**, right-click **Geometry 1** and select **Work Plane** .
- In the **Settings** window for **Work Plane**:
- Select **xz-plane** from the **Plane** list (the last option in the list).
  - Click the **Show Work Plane** button on the **Settings** window for **Work Plane** toolbar.

Continue by editing the axis and grid settings in **Work Plane 1**.

- 2 In the **Model Builder**, expand the **View 2** node and click **Axis** .



- 3 In the **Settings** window for **Axis**:

Under **Axis**:



- In the **x minimum** and **y minimum** fields, enter **-0.01**.
- In the **x maximum** and **y maximum** fields, enter **0.11**.

Under **Grid**:

- Select the **Manual Spacing** check box.
- In the **x spacing** and **y spacing** fields, enter **5e-3**.

- 4 Click the **Update** button on the toolbar.


Note that the values you type will automatically adjust slightly after you click **Update** to adapt to the screen aspect ratio.



You can use interactive drawing to create a geometry using the drawing tools from the **Work Plane** tab in the ribbon while pointing and clicking in the **Graphics** window.



Work Plane Tab



Geometry Primitives

You can also right-click the **Plane Geometry** node under **Work Plane I** to add geometry objects to the geometry sequence.


In the next few steps, we create a profile of the busbar.

- 5 In the **Model Builder** under **Work Plane I**, right-click **Plane Geometry** and select **Rectangle** .

In the **Settings** window for **Rectangle** under **Size**, enter:

- $L+2*tbb$  in the **Width** field.
- $0.1[m]$  in the **Height** field.

Click the **Build Selected** button .



- 6** Create a second rectangle. Under **Work Plane 1**, right-click **Plane Geometry** and select **Rectangle** .

Under **Size**, enter:

- $L+tbb$  in the **Width** field
- $0.1[m]-tbb$  in the **Height** field.

Under **Position**, enter:

- $tbb$  in the **yw** field.


Click the **Build Selected** button .

Use the Boolean **Difference** operation to subtract the second rectangle from the first one.

- 7** Under **Work Plane 1**, right-click **Plane Geometry** and select **Booleans and Partitions > Difference** .
- In the **Graphics** window, click **r1** (the larger of the two rectangles) to add it to the **Objects to add** list in the **Settings** window for **Difference**.



To help select the geometry, you can display geometry labels in the **Graphics** window. In the **Model Builder** under **Geometry 1 > WorkPlane 1**, click the **View 2** node. Go to the **Settings** window for **View** and select the **Show geometry labels** check box.





- 8 Click the **Difference** node. In the **Settings** window for **Difference**, click the **Active selection** button to the left of the **Objects to subtract** list. Select the smaller rectangle, r2, by using the mouse scroll wheel or arrow keys to cycle through the overlapping rectangles to first highlight it and then click on it to select it.


Click **Build Selected** .

Another way to select r2 in the **Graphics** window is to use the **Selection List** feature. Go to the **Home** tab in the ribbon and select **Windows > Selection List**. In the **Selection List**, click to highlight r2 (solid). Then, right-click r2 (solid) in the list and select **Add to Selection** to add it to the **Objects to subtract** list. Right-click on the **Selection List** window title and select **Close**.

After building the selected geometry, you should have a backward-facing, L-shaped profile. Continue by rounding the corners of the L-shaped profile.



- 9 Under **Work Plane 1**, right-click **Plane Geometry**  and select **Fillet** .
- Select point 3 (in the inner-right corner) to add it to the **Vertices to fillet** list. There are different ways to add points:
- In the **Graphics** window, click point 3 to add it to the **Vertices to fillet** list.
  - From the **Home** tab, select **Windows > Selection List**. In the **Selection List** window, click 3. The corresponding point is highlighted in the **Graphics** window. Click the **Add to Selection** button  in the **Settings** window for **Fillet** or right-click in the **Selection List**.




- 10 Enter tbb in the **Radius** field. Click **Build Selected** .

This creates a fillet at the inner corner.


- 11 For the outer corner, right-click **Plane Geometry**  and select **Fillet** .

- 12 In the **Graphics** window, click point 6, the outer corner, to add it to the **Vertices to fillet** list.

- 13 Enter  $2*tbb$  in the **Radius** field. Click **Build Selected** .




The result should match this figure:




Next, extrude the work plane to create the 3D busbar geometry.

- In the **Model Builder**, right-click **Work Plane 1** and select **Extrude**. In the Settings window for **Extrude**, enter wbb in the **Distances from Plane** table (replace the default) to extrude to the width of the profile.



The table allows you to enter several values in order to create sandwich structures with different materials. In this case, only one extruded layer is needed.


- 2 Click **Build Selected** and then click the **Zoom Extents** button on the **Graphics** toolbar. Click the **Save** button and name the model **busbar.mph** (if you have not already done so).



2


Next, create the titanium bolts by extruding two circles drawn in two work planes.

- 3 In the **Model Builder**, right-click **Geometry 1** and add a **Work Plane** . A **Work Plane 2** node is added. In the **Settings** window for **Work Plane**, under **Plane Definition**, select **Face parallel** as the **Plane type**.



- 4 In the **Graphics** window, click face 8, as shown in the figure below, to add it to the **Planar face** list in the Settings window for **Work Plane**.

Face 8 is now highlighted in blue and the work plane is positioned on top of the face.




- 5 Click the **Show Work Plane** button to draw the first circle representing the position of the first bolt. Click the **Zoom Extents** button on the **Graphics** toolbar.

- 6 Under **Work Plane 2**, right-click **Plane Geometry** and select **Circle** .

In the Settings window for **Circle**:

- Under **Size and Shape**, in the **Radius** field, enter `rad_1`.
- Under **Position**, leave the default **xw** and **yw** coordinates (0, 0).

Click **Build Selected** .




6


6

Continue creating the bolt by adding an extrude operation.

- In the **Model Builder**, right-click **Work Plane 2** and select **Extrude** . In the Settings window for **Extrude**, in the first row of the **Distances from Plane** table, enter  $-2*tbb$  to extrude the circle.




- Click the **Build Selected** button to create the cylindrical part of the titanium bolt that runs through the busbar.



Draw the two remaining bolts.

- 3 Right-click **Geometry**  and select **Work Plane** . A **Work Plane 3** node is added. In the **Settings** window for **Work Plane**, for **Work Plane 3**, select **Face parallel** as the **Plane type**.
- 4 In the **Graphics** window, click face 4, as shown in the figure, to add it to the **Planar face** list in the **Settings** window for **Work Plane**.



- 5 Click the **Show Work Plane** button  on the **Settings** window for **Work Plane** and the **Zoom Extents** button  on the **Graphics** toolbar to get a better view of the geometry.


To parameterize the position of the two remaining bolts, add the circles that form the cross sections of the bolts.

**6** Under **Work Plane 3**, right-click **Plane Geometry**  and select **Circle** .

In the **Settings** window for **Circle**:

- Under **Size and Shape**, enter `rad_1` in the **Radius** field.
- Under **Position**, enter `-L/2+1.5[cm]` in the **xw** field and `-wbb/4` in the **yw** field.

Click **Build Selected** .




**7** Copy the circle that you just created to generate the third bolt in the busbar.

**7** Under **Work Plane 3**, right-click **Plane Geometry**  and select **Transforms > Copy** .


**8** In the **Graphics** window, click the circle `c1` to select and add the circle to the **Input objects** list in the **Settings** window for **Copy**.

**9** In the **Settings** window for **Copy** under **Displacement**, enter `wbb/2` in the **yw** field.




**10** Click **Build Selected**  and click the **Zoom Extents** button  on the **Graphics** toolbar.

Your geometry, as shown in the work plane, should match this figure so far.




Continue by extruding the circles.

- In the **Model Builder**, right-click **Work Plane 3** and select **Extrude** . In the **Settings** window for **Extrude**, in the first row of the **Distances from Plane** table, enter  $-2*tbb$  (replace the default). Click **Build All Objects** .



The geometry and geometry sequence should match the figures below. Click the **Save** button and name the model **busbar.mph**.




## Creating Parts and Using the Part Libraries

---


After setting up the busbar or other geometry model, it is convenient to be able to save it for future use, avoiding unnecessary work. In the steps you have just completed, the geometry was stored directly in the COMSOL model file that will also be used to set up the complete busbar model. Instead, you can also create a reusable and parameterized part that can serve as a building block of a more complex COMSOL model geometry, which is stored in a separate file accessible through the Part Libraries.

While building the busbar geometry, you were using features from the **Geometry** and **Workplane** tabs. A **Parts** menu is located in the **Other** group in these tabs.



Through the **Parts** menu, you can choose to create or load a part, or add a part to the model geometry by selecting one from the Part Libraries. Several Part Libraries are already provided with the software by default. When new parts are created, they are added under a part's parent node in the **Global Definitions** section of the model tree.

The figure below shows an **Internal Helical Gear** part from the part library of the Multibody Dynamics Module. The part comes with 18 **Input Parameters** that control the dimensions.



For additional information on working with parts and the Part Libraries, see the *Reference Manual*.

**!** To continue with the busbar tutorial, return to the section “Materials” on page 62.

## Appendix B — Keyboard and Mouse Shortcuts

---

SHORTCUT (WINDOWS, LINUX)	SHORTCUT (OS X)	ACTION
F1	F1	Display help for the selected node or window
Ctrl+F1	Command+F1	Open the COMSOL Documentation front page in an external window
F2	F2	Rename the selected node, file, or folder
F3	F3	Disable selected nodes
F4	F4	Enable selected nodes
F5	F5	Update the Data Sets Solutions with respect to any new Global Definitions and Definitions without re-solving the model
F6	F6	Build the preceding node in the geometry branch
F7	F7	Build the selected node in the geometry and mesh branches, compute the selected study step, or compute the selected node in the solver sequence
F8	F8	Build the geometry, build the mesh, compute the entire solver sequence, update results data, or update the plot
Del	Del	Delete selected nodes
Left arrow (Windows); Shift + Left arrow (Linux)	Left arrow	Collapse a branch in the model tree
Right arrow (Windows); Shift + Right arrow (Linux)	Right arrow	Expand a branch in the model tree
Up arrow	Up arrow	Move to the node above in the model tree
Down arrow	Down arrow	Move to the node below in the model tree
Alt+left arrow	Ctrl+left arrow	Move to the previously selected node in the model tree

SHORTCUT (WINDOWS, LINUX)	SHORTCUT (OS X)	ACTION
Alt+Right arrow	Ctrl+Right arrow	Move to the next selected node in the model tree
Ctrl+A	Command+A	Select all domains, boundaries, edges, or points; Select all cells in a table
Ctrl+C	Command+C	Copy text in fields
Ctrl+D	Command+D	Clear the selection of domains, boundaries, edges, or points
Ctrl+Shift+D	Command+Shift+D	Duplicate the selected node in the model tree
Ctrl+F	Command+F	Find a search string
Ctrl+N	Command+N	New model
Ctrl+O	Command+O	Open a model file
Ctrl+P	Command+P	Print the contents of the plot window
Ctrl+S	Command+S	Save a model file
Ctrl+V	Command+V	Paste copied text
Ctrl+Y	Ctrl+Shift+Z	Redo the last undone operation
Ctrl+Z	Command+Z	Undo the last operation
Ctrl+Up arrow	Command+Up arrow	Move a definitions node, geometry node, physics node (except default nodes), material node, mesh node, study step node, or results node up one step
Ctrl+Down arrow	Command+Down arrow	Move a definitions node, geometry node, physics node (except default nodes), material node, mesh node, study step node, or results node down one step
Ctrl+Tab	Ctrl+Tab	Switch focus to the next window on the desktop
Ctrl+Shift+Tab	Ctrl+Shift+Tab	Switch focus to the previous window on the desktop
Ctrl+Alt+A	Not available	Go to Application Builder
Ctrl+Alt+M	Not available	Go to Model Builder
Ctrl+Alt+Left arrow	Command+Alt+Left arrow	Switch focus to the Model Builder window

SHORTCUT (WINDOWS, LINUX)	SHORTCUT (OS X)	ACTION
Ctrl+Alt+Right arrow	Command+Alt+Right arrow	Switch focus to the Settings window.
Ctrl+Alt+Up arrow	Command+Alt+Up arrow	Switch focus to the previous section in the Settings window.
Ctrl+Alt+Down arrow	Command+Alt+Down arrow	Switch focus to the next section in the Settings window.
Shift+F10 or (Windows only) Menu key	Ctrl+F10	Open the context menu.
Ctrl+Space	Ctrl+Space	Open list of predefined quantities for insertion in Expression fields.
Left-click and hold down the mouse button while dragging the mouse.	Same as for Windows; only available for two-button mouse.	Rotate the scene around the axes parallel to the screen's x- and y-axes with the origin at the scene rotation point.
Right-click and hold down the mouse button while dragging the mouse.	Same as for Windows; only available for two-button mouse.	Move the visible frame on the image plane in any direction.
Middle-click and hold down the mouse button while dragging the mouse.	Same as for Windows; only available for two-button mouse.	The scene is zoomed in/out around the mouse position where the action started.
Press Ctrl and left-click. While holding down the key and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Tilt and pan the camera by rotating about the x- and y-axes in the image plane.
Press Ctrl and right-click. While holding down the key and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Move the camera in the plane parallel to the image plane.
Press Ctrl and middle-click. While holding down the key and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Move the camera into and away from the object (dolly in/out).
Press Ctrl+Alt and left-click. While holding down the keys and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Rotate the camera around the axis.
Press Alt and left-click. While holding down the key and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Rotate the camera about its axis between the camera and the scene rotation point (roll direction).

SHORTCUT (WINDOWS, LINUX)	SHORTCUT (OS X)	ACTION
Press Alt and right-click. While holding down the key and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Move the scene in the plane orthogonal to the axis between the camera and the scene rotation point.
Press Alt and middle-click. While holding down the key and button, drag the mouse.	Same as for Windows; only available for two-button mouse.	Move the camera along the axis between the camera and the scene rotation point.

## Appendix C — Language Elements and Reserved Names

---

Building a model tree in COMSOL Multiphysics is equivalent to graphically programming a sequence of operations. Using the Record Code functionality in the Application Builder or saving as a model file for MATLAB® or Java® outputs the sequence of operations as a list of traditional programming statements. In this section, we will give an overview of the following element categories as defined by the underlying COMSOL language:

- Constants
- Variables
- Functions
- Operators
- Expressions

These language elements are built-in or user-defined. Operators cannot be user-defined. Expressions are always user-defined.

### ABOUT RESERVED NAMES

Built-in elements have reserved names, names that cannot be redefined by the user. If you try to use a reserved name for a user-defined variable, parameter, or function, the text where you enter the name will turn orange and you will get a tooltip error message if you select the text string. Reserved function names are reserved only for function names, which means that such names can be used for variable and parameter names and vice versa. In the following pages, we list the most commonly used built-in elements and hence those reserved names. A more exhaustive list of built-in elements can be found in the *Programming Reference Manual* and the *Application Programming Guide*.

### VARIABLES USED IN APPLICATIONS

Model parameters and variables can be used in applications. For example, you can let the user of an application change the value of a parameter. In addition, variables to be used in applications can be defined in the Application Builder under the **Declarations** node. Such variables are available globally in form objects and methods but cannot be used in the Model Builder.

## Constants and Parameters

---

There are three different types of constants accessible from the Model Builder: built-in mathematical and numerical constants, built-in physical constants, and parameters. Parameters are user-defined constants, which can vary over parameter sweeps. Constants are scalar valued. The tables below list the built-in mathematical and numerical constants as well as built-in physical constants. Constants and parameters can have units.

### BUILT-IN MATHEMATICAL AND NUMERICAL CONSTANTS

DESCRIPTION	NAME	VALUE
Floating point relative accuracy for double floating point numbers, also known as machine epsilon	eps	$2^{-52}$ ( $\sim 2.2204 \cdot 10^{-16}$ )
The imaginary unit	i, j	i, $\sqrt{-1}$
Infinity, $\infty$	inf, Inf	A value larger than what can be handled with floating point representation
Not-a-number	Nan, nan	An undefined or unrepresentable value, such as the result of 0/0 or inf/inf
$\pi$	pi	3.141592653589793

## BUILT-IN PHYSICAL CONSTANTS

DESCRIPTION	NAME	VALUE
Acceleration of gravity	g_const	9.80665[m/s^2]
Avogadro constant	N_A_const	6.02214129e23[1/mol]
Boltzmann constant	k_B_const	1.3806488e-23[J/K]
Characteristic impedance of vacuum (impedance of free space)	Z0_const	376.73031346177066[ohm]
Electron mass	me_const	9.10938291e-31[kg]
Elementary charge	e_const	1.602176565e-19[C]
Faraday constant	F_const	96485.3365[C/mol]
Fine-structure constant	alpha_const	7.2973525698e-3
Gravitational constant	G_const	6.67384e-11[m^3/(kg*s^2)]
Molar volume of ideal gas (at 273.15 K and 1 atm)	V_m_const	2.2413968e-2[m^3/mol]
Neutron mass	mn_const	1.674927351e-27[kg]
Permeability of vacuum (magnetic constant)	mu0_const	4*pi*1e-7[H/m]
Permittivity of vacuum (electric constant)	epsilon0_const	8.85418781700001e-12[F/m]
Planck's constant	h_const	6.62606957e-34[J*s]
Planck's constant over 2 pi	hbar_const	1.05457172533629e-34[J*s]
Proton mass	mp_const	1.672621777e-27[kg]
Speed of light in vacuum	c_const	299792458[m/s]
Stefan-Boltzmann constant	sigma_const	5.670373e-8[W/(m^2*K^4)]
Universal gas constant	R_const	8.3144621[J/(mol*K)]
Wien displacement law constant	b_const	2.8977721e-3[m*K]

## PARAMETERS

Parameters are user-defined constant scalars in the **Global Definitions** branch in the model tree. Example uses are:

- Parameterizing geometric dimensions
- Parameterizing mesh element sizes

- Defining parameters to be used in parametric sweeps

A parameter can be defined as an expression in terms of numbers, parameters, built-in constants, and built-in functions of parameters and built-in constants. Parameters should be assigned a unit, using [ ], unless they are dimensionless.

## Variables

---

There are two types of variables used in the Model Builder: built-in and user-defined. Variables can be scalars or fields. Variables can have units.

Note: Spatial coordinate variables and dependent variables are user-defined variables of special interest. These variables have default names based on the space dimension of the geometry and the physics interface, respectively. As a result of the names chosen for these variables, a list of built-in variables will be created by COMSOL Multiphysics: the first- and second-order derivatives with respect to space and time.

## BUILT-IN VARIABLES

NAME	DESCRIPTION	TYPE
<b>curv</b>	The curvature of a boundary in 2D	Field
<b>curv1, curv2</b>	The principal curvature components of a boundary in 3D	Field
<b>dom</b>	The domain number for a domain, boundary, edge, or point	Field
<b>dvol</b>	Volume scale factor variable; This is the determinant of the Jacobian matrix for the mapping from local (element) coordinates to global coordinates.	Field
<b>freq</b>	Frequency	Global variable
<b>h</b>	Mesh element size (length of the longest edge of the element)	Field
<b>lambda</b>	Eigenvalue	Global variable
<b>linearizedelem</b>	Elements forced to be linear	Field
<b>numberofdofs</b>	Number of degrees of freedom	Global variable
<b>meshtype</b>	Mesh type index for the mesh element; This is the number of edges in the element.	Field
<b>meshelement</b>	Mesh element number	Field
<b>meshvol</b>	Volume of the (linearized) element	Field
<b>nx,ny,nz</b>	Normal component for boundaries	Field
<b>phase</b>	Phase angle	Global variable
<b>qual</b>	Mesh quality	Field
<b>realdetjac</b>	The determinant of the Jacobian matrix for the mapping from a straight mesh element to the possibly curved element used when solving. Use this variable to measure the difference in shape between a curved element and the corresponding straight element.	Field

<code>realdetjacmin</code>	A scalar field variable for each element defined as the minimum value of the <code>reldetjac</code> variable for the corresponding element. A <code>reldetjacmin</code> value less than zero for an element means that the element is wrapped inside-out; that is, the element is an inverted mesh element.	Field
<code>s, s1, s2</code>	Curve and surface parameterization variables	Field
<code>t</code>	Time	Global variable
<code>tcurv<sub>x</sub>, tcurv<sub>y</sub>, tcurv<sub>1x</sub>, curv<sub>1y</sub>, tcurv<sub>1z</sub>, tcurv<sub>2x</sub>, tcurv<sub>2y</sub>, tcurv<sub>2z</sub></code>	Tangential directions for the corresponding curvature variables	Field
<code>tx, ty, t1x, t1y, t1z, t2x, t2y, t2z</code>	Tangent vector components corresponding to the curve and surface parameterizations	Field
<code>qual</code>	A mesh quality measure between 0 (poor quality) and 1 (perfect quality)	Field

## USER-DEFINED VARIABLES THAT GENERATE BUILT-IN VARIABLES

DEFAULT NAME	DESCRIPTION	TYPE
<code>x, y, z</code>	Spatial coordinates (Cartesian)	Field
<code>r, phi, z</code>	Spatial coordinates (Cylindrical)	Field
<code>u, T, etc.</code>	Dependent variables (Solution)	Field

Example: `T` is the name for the temperature in a 2D, time-dependent heat transfer model; `x` and `y` are the spatial coordinate names. In this case, the following built-in variables will be generated: `T, Tx, Ty, Txx, Txy, Tyx, Tyy, Tt, Txt, Tyt, Txxt, Txyt, Tyxt, Tytt, Ttt, Txtt, Tytt, Txxtt, Txytt, Tyxtt, and Tytt`. Here, `Tx` corresponds to the partial derivative of the temperature `T` with respect to `x` and `Ttt` corresponds to the second-order time derivative of `T`, and so on. If the spatial coordinate variables have other names — for example, `psi` and `chi` — then `Txy` would be `Tpsichi`, and `Txt` would be `Tpsit`. (The time variable `t` is built-in; the user cannot change its name.)

## Functions

---

In the Model Builder, there are two types of functions: built-in and user-defined. Functions can be scalar valued or field valued depending on the input argument(s). Some functions can have units for both input and output arguments.

### BUILT-IN MATHEMATICAL FUNCTIONS

These functions do not have units for their input or output arguments.

NAME	DESCRIPTION	SYNTAX EXAMPLE
<b>abs</b>	Absolute value	<code>abs(x)</code>
<b>acos</b>	Inverse cosine (in radians)	<code>acos(x)</code>
<b>acosh</b>	Inverse hyperbolic cosine	<code>acosh(x)</code>
<b>acot</b>	Inverse cotangent (in radians)	<code>acot(x)</code>
<b>acoth</b>	Inverse hyperbolic cotangent	<code>acoth(x)</code>
<b>acsc</b>	Inverse cosecant (in radians)	<code>acsc(x)</code>
<b>acsch</b>	Inverse hyperbolic cosecant	<code>acsch(x)</code>
<b>arg</b>	Phase angle (in radians)	<code>arg(x)</code>
<b>asec</b>	Inverse secant (in radians)	<code>asec(x)</code>
<b>asech</b>	Inverse hyperbolic secant	<code>asech(x)</code>
<b>asin</b>	Inverse sine (in radians)	<code>asin(x)</code>
<b>asinh</b>	Inverse hyperbolic sine	<code>asinh(x)</code>
<b>atan</b>	Inverse tangent (in radians)	<code>atan(x)</code>
<b>atan2</b>	Four-quadrant inverse tangent (in radians)	<code>atan2(y,x)</code>
<b>atanh</b>	Inverse hyperbolic tangent	<code>atanh(x)</code>
<b>besselj</b>	Bessel function of the first kind	<code>besselj(a,x)</code>
<b>bessely</b>	Bessel function of the second kind	<code>bessely(a,x)</code>
<b>besseli</b>	Modified Bessel function of the first kind	<code>besseli(a,x)</code>
<b>besselk</b>	Modified Bessel function of the second kind	<code>besselk(a,x)</code>
<b>ceil</b>	Nearest following integer	<code>ceil(x)</code>
<b>conj</b>	Complex conjugate	<code>conj(x)</code>
<b>cos</b>	Cosine	<code>cos(x)</code>
<b>cosh</b>	Hyperbolic cosine	<code>cosh(x)</code>
<b>cot</b>	Cotangent	<code>cot(x)</code>
<b>coth</b>	Hyperbolic cotangent	<code>coth(x)</code>

NAME	DESCRIPTION	SYNTAX EXAMPLE
csc	Cosecant	csc(x)
csch	Hyperbolic cosecant	csch(x)
erf	Error function	erf(x)
exp	Exponential	exp(x)
floor	Nearest previous integer	floor(x)
gamma	Gamma function	gamma(x)
imag	Imaginary part	imag(u)
log	Natural logarithm	log(x)
log10	Base-10 logarithm	log10(x)
log2	Base-2 logarithm	log2(x)
max	Maximum of two arguments	max(a,b)
min	Minimum of two arguments	min(a,b)
mod	Modulo operator	mod(a,b)
psi	Psi function and its derivatives	psi(x,k)
range	Create a range of numbers	range(a,step,b)
real	Real part	real(u)
round	Round to closest integer	round(x)
sec	Secant	sec(x)
sech	Hyperbolic secant	sech(x)
sign	Signum function	sign(u)
sin	Sine	sin(x)
sinh	Hyperbolic sine	sinh(x)
sqrt	Square root	sqrt(x)
tan	Tangent	tan(x)
tanh	Hyperbolic tangent	tanh(x)

## BUILT-IN OPERATOR FUNCTIONS

These built-in functions behave differently than the built-in mathematical functions. They may not belong in an introductory text but are listed to complete the list of reserved names. For more information, see the *Reference Manual*.

NAME	NAME	NAME	NAME
adj	dtang	mean	timeavg
at	emetric	noenv	timeint

NAME	NAME	NAME	NAME
atlocal	env	nojac	timemax
attimemax	error	noxd	timemin
attimemin	fsens	pd	treatasconst
atxd	fsensimag	ppr	tryCatch
atonly	if	pprint	uflux
ballavg	integrate	prev	up
ballint	isdefined	reacf	var
bdf		realdot	with
bndenv	isinf	residual	withsol
centroid	islinear	scope.ati	
circavg	isnan	sens	
circint	jacdepends	setconst	
circumcenter	lindev	setind	
d	linper	setval	
depends	linpoint	shapeorder	
dest	linsol	side	
dflux	lintotal	sphavg	
diskavg	lintotalavg	sphint	
diskint	lintotalpeak	subst	
down	lintotalrms	sum	
dtang	linzero	test	

## USER-DEFINED FUNCTIONS

A user-defined function can be defined in the model tree under the **Global Definitions** node or, for each **Component**, under the **Definitions** node. Select a

template from the **Functions** menu and enter settings to define the name and detailed shape of the function.

TEMPLATE NAME	ARGUMENTS AND DEFINITION	SYNTAX EXAMPLE
Analytic	<p>The function name is its identifier; for example, <b>an1</b>.</p> <p>The function is a mathematical expression of its arguments.</p> <p>Example: Given the arguments <b>x</b> and <b>y</b>, its definition is <math>\sin(x) * \cos(y)</math>.</p> <p>The function has an arbitrary number of arguments.</p>	<p>The name of the function with comma-separated arguments within parentheses. For example:</p> <p><b>an1(x,y)</b></p>
Elevation	<p>The function name is its identifier; for example, <b>elev1</b>.</p> <p>Used to import geospatial elevation data from digital elevation models and map the elevation data to a function of <b>x</b> and <b>y</b>. A DEM file contains elevation data for a portion of the earth's surface. The resulting function behaves essentially like a grid-based interpolation function.</p>	<p>The name of the function with comma-separated arguments within parentheses. For example:</p> <p><b>elev1(x,y)</b></p>
Gaussian Pulse	<p>The function name is its identifier; for example, <b>gp1</b>.</p> <p>The Gaussian pulse function defines a bell-shaped curve according to the expression</p> $y(x) = \frac{1}{\sigma\sqrt{2\pi}} e^{\frac{-(x-x_0)^2}{2\sigma^2}}$ <p>It is defined by the mean parameter, <math>x_0</math>, and the standard deviation, <math>\sigma</math>.</p> <p>The function has one argument.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><b>gp1(x)</b></p>

TEMPLATE NAME	ARGUMENTS AND DEFINITION	SYNTAX EXAMPLE
Image	<p>The function name is its identifier; for example, <code>im1</code>.</p> <p>Used to import an image (in BMP, JPEG, PNG, or GIF format) and map the image's RGB data to a scalar (single channel) function output value. By default the function's output uses the mapping <math>(R+G+B)/3</math>.</p>	<p>The name of the function with comma-separated arguments within parentheses. For example:</p> <p><code>im1(x,y)</code></p>
Interpolation	<p>The function name is its identifier; for example, <code>int1</code>.</p> <p>An interpolation function is defined by a table or file containing the values of the function in discrete points.</p> <p>The file formats are the following: spreadsheet, grid, or sectionwise.</p> <p>The function has one to three arguments.</p>	<p>The name of the function with comma-separated arguments within parentheses. For example:</p> <p><code>int1(x,y,z)</code></p>
Piecewise	<p>The function name is its identifier; for example, <code>pw1</code>.</p> <p>A piecewise function is created by splicing together several functions, each defined on one interval. Define the argument, extrapolation and smoothing methods, and the functions and their intervals.</p> <p>This function has one argument with different definitions on different intervals, which must not overlap or have any holes between them.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><code>pw1(x)</code></p>
Ramp	<p>The function name is its identifier; for example, <code>rm1</code>.</p> <p>A ramp function is a linear increase with a user-defined slope that begins at some specified time.</p> <p>The function has one argument. It can also be smoothed.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><code>rm1(x)</code></p>

TEMPLATE NAME	ARGUMENTS AND DEFINITION	SYNTAX EXAMPLE
Random	<p>The function name is its identifier; for example, <b>rn1</b>.</p> <p>A random function generates white noise with uniform or normal distribution and has one or more arguments to simulate white noise.</p> <p>The function has arbitrary number of arguments.</p>	<p>The name of the function with comma-separated arguments within parentheses. For example:</p> <p><b>rn1(x,y)</b></p> <p>The arguments x and y are used as random seeds for the random function.</p>
Rectangle	<p>The function name is its identifier; for example, <b>rect1</b>.</p> <p>A rectangle function is <b>1</b> in an interval and <b>0</b> everywhere else.</p> <p>The function has one argument.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><b>rect1(x)</b></p>
Step	<p>The function name is its identifier; for example, <b>step1</b>.</p> <p>A step function is a sharp transition from <b>0</b> to some other value (amplitude) at some location.</p> <p>The function has one argument. It can also be smoothed.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><b>step1(x)</b></p>
Switch	<p>The function name is its identifier; for example, <b>sw1</b>.</p> <p>A switch is used to switch between global functions during a solver sweep. You add the functions as subnodes under the Switch node. The switch for functions acts essentially as a switch statement in a programming language; that is, it dynamically chooses one of its underlying branches depending on a parameter that can be controlled from the solvers using a Function Sweep study. You can also add a Switch node under Materials and then use a Material Sweep to sweep over a discrete set of materials.</p>	Switch is a container node for functions.

TEMPLATE NAME	ARGUMENTS AND DEFINITION	SYNTAX EXAMPLE
Triangle	<p>The function name is its identifier; for example, <b>tri1</b>.</p> <p>A triangle function is a linear increase and linear decline within an interval and <b>0</b> everywhere else.</p> <p>The function has one argument. It can also be smoothed.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><b>tri1(x)</b></p>
Waveform	<p>The function name is its identifier; for example, <b>wv1</b>.</p> <p>A waveform function is a periodic function with one of several characteristic shapes: sawtooth, sine, square, or triangle.</p> <p>The function has one argument. It can also be smoothed.</p>	<p>The name of the function with a single argument within parentheses. For example:</p> <p><b>wv1(x)</b></p>
External (Global Definitions only)	<p>An external function defines an interface to one or more functions written in the C language (which can be a wrapper function interfacing source code written in, for example, Fortran). Such an external function can be used, for example, to interface a user-created shared library. Note that the extension of a shared library file depends on the platform: .dll (Windows), .so (Linux), or .dylib (OS X).</p>	<p>The name of the function and the appropriate number of arguments within parentheses. For example:</p> <p><b>myextfunc(a,b)</b></p>
MATLAB® (Global Definitions only)	<p>A MATLAB® function interfaces one or more functions written in the MATLAB® language. Such functions can be used as any other function defined in COMSOL Multipysics provided LiveLink™ for MATLAB® and MATLAB® are installed. (MATLAB® functions are evaluated by MATLAB® at runtime.)</p>	<p>The name of the function and the appropriate number of arguments within parentheses. For example:</p> <p><b>mymatlabfunc(a,b)</b></p>

## Unary and Binary Operators

---

In the Model Builder, the following table contains the unary and binary operators that can be used in expressions.

PRECEDENCE LEVEL	SYMBOL	DESCRIPTION
1	( ) { } .	Grouping, Lists, Scope
2	$^$	Power
3	! - +	Unary: Logical NOT, Minus, Plus
4	[ ]	Unit
5	* /	Multiplication, Division
6	+ -	Binary: Addition, Subtraction
7	< <= > >=	Comparisons: Less-Than, Less-Than or Equal, More-Than, More-Than or Equal
8	== !=	Comparisons: Equal, Not Equal
9	&&	Logical AND
10		Logical OR
11	,	Element Separator in Lists

## Expressions

---

### PARAMETERS

A parameter expression can contain: numbers, parameters, built-in constants, built-in functions of parameter expressions, and unary and binary operators. Parameters can have units.

### VARIABLES

A variable expression can contain: numbers, parameters, constants, variables, functions of variable expressions, and unary and binary operators. Variables can have units.

### FUNCTIONS

A function definition can contain: input arguments, numbers, parameters, constants, functions of parameter expressions, including input arguments, unary and binary operators.

## Appendix D — File Formats

---

### COMSOL File Formats

---

The COMSOL Model MPH file type, with the extension `.mph`, is the default file type containing the entire model tree and application tree from the Model Builder and Application Builder, respectively. The file contains both binary and text data. The mesh and solution data is stored as binary data, while all other information is stored as plain text.

The COMSOL binary and text file types, with the extension `.mphbin` and `.mphtxt`, respectively, contain either geometry objects or mesh objects that can be imported directly to the **Geometry** or **Mesh** nodes in the model tree.

The Physics Builder file type, with the extension `.mphphb`, contains one or more user-defined physics interfaces that you can access from the Model Builder. See the *Physics Builder Manual* for more information.

See “Supported External File Formats” for more information about all the other formats supported by COMSOL Multiphysics.

FILE TYPE	EXTENSION	READ	WRITE
COMSOL Model and Application	<code>.mph</code>	Yes	Yes
Binary Data	<code>.mphbin</code>	Yes	Yes
Text Data	<code>.mphtxt</code>	Yes	Yes
Physics Builder	<code>.mphphb</code>	Yes	Yes

### Supported External File Formats

---

#### CAD

The CAD Import Module and Design Module allow for import of a range of industry-standard CAD file types. Additional file types are available through the bidirectional functionality of the LiveLink products for CAD as well as with the File Import for CATIA® V5 add-on.

The DXF (2D), VRML (3D), and STL (3D) file types are available for import with COMSOL Multiphysics and do not require any add-on products. Unless noted

otherwise in the table below, import of the listed file types is available on all supported versions of Linux®, Mac OS X, and Windows® operating systems.

FILE TYPE	EXTENSION	READ	WRITE
AutoCAD® <sup>1,2,3</sup>	.dwg	Yes	Yes <sup>9</sup>
Inventor® <sup>1,2,3</sup>	.ipt,.iam	Yes	Yes <sup>9</sup>
NX® <sup>1,4</sup>	.prt	Yes	No
PTC® Creo® Parametric™ <sup>1,3</sup>	.prt , .asm	Yes	Yes <sup>9</sup>
PTC® Pro/ENGINEER® <sup>1,3</sup>	.prt , .asm	Yes	Yes <sup>9</sup>
Revit® Architecture <sup>3,5</sup>	.rvt	Yes <sup>9</sup>	Yes <sup>9</sup>
Solid Edge® <sup>3,6</sup>	.par , .asm	Yes <sup>9</sup>	Yes <sup>9</sup>
SOLIDWORKS® <sup>1,2,3</sup>	.sldprt , .sldasm	Yes	Yes <sup>9</sup>
DXF (3D <sup>1,2</sup> and 2D)	.dxf	Yes	Yes <sup>10</sup>
Parasolid® <sup>1</sup>	.x_t , .xmt_txt , .x_b , .xmt_bin	Yes	Yes
ACIS® <sup>1</sup>	.sat , .sab , .asat , .asab	Yes	Yes
STEP <sup>1</sup>	.step , .stp	Yes	No
IGES <sup>1</sup>	.iges , .igs	Yes	No
CATIA® V5 <sup>2,7</sup>	.CATPart , .CATProduct	Yes	No
VRML, v1 <sup>8</sup>	.vrml , .wrl	Yes	No
STL <sup>8</sup>	.stl	Yes	Yes

<sup>1</sup>Requires one of the LiveLink™ products for AutoCAD®, Revit®, PTC® Creo® Parametric™, Inventor®, PTC® Pro/ENGINEER®, Solid Edge®, SOLIDWORKS®, CAD Import Module, or Design Module

<sup>2</sup>Import supported on Windows® operating systems only

<sup>3</sup>Synchronization of files between COMSOL Multiphysics and a linked CAD program supported on Windows® 7, 8, and 8.1 operating systems only

<sup>4</sup>Import supported on Windows® and Linux operating systems only

<sup>5</sup>Requires LiveLink™ for Revit®

<sup>6</sup>Requires LiveLink™ for Solid Edge®

<sup>7</sup>Requires the CAD Import Module (or the Design Module or one of the LiveLink™ products for AutoCAD®, PTC® Creo® Parametric™, Inventor®, PTC Pro/ENGINEER®, Solid Edge®, or SOLIDWORKS®) and the File Import for CATIA® V5

<sup>8</sup>Limited to a single geometric domain

<sup>9</sup>From/To file using linked CAD package, provided the original CAD geometry is created in the CAD package

<sup>10</sup>Writing to file is supported for 2D geometry only

## ECAD

The ECAD Import Module allows for import of 2D layout files with automatic conversion to 3D CAD models. The Touchstone file type is used for exporting S-parameters, impedance, and admittance values from simultaneous port and frequency sweeps. The SPICE Circuit Netlist file type is converted at import to a series of lumped circuit element nodes under an **Electrical Circuit** node.

FILE TYPE	EXTENSION	READ	WRITE
NETEX-G <sup>1</sup>	.asc	Yes	No
ODB++ <sup>1</sup>	.zip,.tar,.tgz,.tar.gz	Yes	No
ODB++(X) <sup>1</sup>	.xml	Yes	No
GDS <sup>1</sup>	.gds	Yes	No
Touchstone <sup>2</sup>	.s2p,.s3p,.s4p,...	No	Yes
SPICE Circuit Netlist <sup>3</sup>	.cir	Yes	No

<sup>1</sup>Requires the ECAD Import Module

<sup>2</sup>Requires one of the AC/DC Module, RF Module, MEMS Module, or Wave Optics Module

<sup>3</sup>Requires one of the AC/DC Module, RF Module, MEMS Module, Plasma Module, or Semiconductor Module

## MATERIAL DATABASES

The Chemical Reaction Engineering Module and the Plasma Module can read CHEMKIN® files to simulate complex chemical reactions in the gas phase. The Plasma Module can read LXCAT files for sets of electron impact collision cross sections.

FILE TYPE	EXTENSION	READ	WRITE
CHEMKIN® <sup>1</sup>	.dat,.txt,.inp <sup>3</sup>	Yes	No
CAPE-OPEN <sup>1</sup> (direct connection)	n/a	n/a	n/a
LXCAT file <sup>2</sup>	.lxcat,.txt	Yes	No

<sup>1</sup>Requires the Chemical Reaction Engineering Module or the Plasma Module. The Plasma Module only supports thermodynamic and transport data.

<sup>2</sup>Requires the Plasma Module

<sup>3</sup>Any extension is allowed; These are the most common extensions

## MESH

The NASTRAN® Bulk Data file types are used to import a volumetric mesh. The VRML and STL file types are used to import a triangular surface mesh and cannot be used for creating a volumetric mesh. If imported as a geometry, VRML and

STL files can be used as a basis for creating a volumetric mesh for a single geometric domain.

FILE TYPE	EXTENSION	READ	WRITE
NASTRAN® Bulk Data	.nas,.bdf,.nastran,.dat	Yes	Yes
STL	.stl	Yes	Yes
VRML, v1	.vrml,.wr1	Yes	No
VTK	.vtu	No	Yes

## IMAGES AND MOVIES

Results visualization can be exported to a number of common image file types; See the table below. Images can also be read and used as interpolation functions for physics modeling. Animations can be exported to one of the Animated GIF, Adobe® Flash®, and AVI file types.

FILE TYPE	EXTENSION	READ	WRITE
Adobe® Flash®	.swf	No	Yes
Animated GIF	.gif	No	Yes
AVI <sup>1</sup>	.avi	No	Yes
BMP	.bmp	Yes	Yes
EPS (1D graphs only)	.eps	No	Yes
GIF	.gif	Yes	Yes
JPEG	.jpg,.jpeg	Yes	Yes
MP4 <sup>2</sup>	.mp4	Yes	No
OGV <sup>2</sup>	.ogv	Yes	No
PNG	.png	Yes	Yes
TIFF	.tif,.tiff	No	Yes
WEBM <sup>2</sup>	.webm	Yes	No

<sup>1</sup> Available for Windows® only

<sup>2</sup> Available in the Application Builder; for Windows® only, in the video form object

## PROGRAMMING LANGUAGES AND SPREADSHEET

Model files for Java® are editable files with the extension .java that contain sequences of COMSOL commands as Java® code. Edit the files in a text editor to add additional commands. You can compile these Java® files into Java® Class files with the extension .class and run them as separate applications. Program code used in model files for Java® is essentially identical to that of the Method editor in

the Application Builder. However, the Method editor comes with an integrated Java® compiler.

Model files for MATLAB® are editable script files (M files), similar to the model files for Java®, for use with MATLAB®. These model files, which have the extension .m, contain a sequence of COMSOL commands as a MATLAB® M file. You can run the model files in MATLAB® like any other M file scripts. It is also possible to edit the files in a text editor to include additional COMSOL commands or general MATLAB® commands. Running model files in the M file format requires LiveLink™ for MATLAB®.

With a license for LiveLink™ for Excel®, you can save models on the Visual Basic for Applications (VBA) format for use with Excel®.

Complied C-code can be linked with a model or application in several ways including the External Material and External Function interfaces in the Model Builder and as the External Library interface in the Application Builder.

FILE TYPE	EXTENSION	READ	WRITE
MATLAB®: Model file for MATLAB®	.m	No	Yes
MATLAB®: Function <sup>1</sup>	.m	Yes	No
Java®: Archive file	.jar <sup>6</sup>	Yes	No
Java®: Compiled model file for Java®	.class	Yes	No
Java®: Model file for Java®	.java	No	Yes
C: Function	.dll <sup>3</sup> , .so <sup>4</sup> , .dylib <sup>5</sup>	Yes	No
Excel® <sup>2</sup>	.xlsx, .vba	Yes	Yes

<sup>1</sup> Requires LiveLink™ for MATLAB®

<sup>2</sup> Requires LiveLink™ for Excel®, available for Windows® only

<sup>3</sup> Available for Windows® only

<sup>4</sup> Available for Linux® only

<sup>5</sup> Available for OS X only

<sup>6</sup> Can be linked to a method in an application using the Application Builder

## NUMERICAL AND INTERPOLATION DATA FORMATS

The grid, sectionwise, and spreadsheet file types can be read for defining interpolation functions. The sectionwise and spreadsheet file types can furthermore be read and used for defining interpolation curves and written for exporting results. In addition, tables can be copy-pasted on spreadsheet format. Parameters and variables can be imported and exported to the plain text, comma-separated values, or data file types.

The continuous and discrete color table text file types are used for user-defined color tables for results visualization.

Digital elevation model (DEM) files can be read and used as a parametric surface for defining a geometry.

FILE TYPE	EXTENSION	READ	WRITE
Copy and paste spreadsheet format	n/a	Yes	Yes
Excel® spreadsheet <sup>1</sup>	.xlsx	Yes	Yes
Table	.txt,.csv,.dat	Yes	Yes
Grid	.txt	Yes	Yes
Sectionwise	.txt,.csv,.dat	Yes	Yes
Spreadsheet	.txt,.csv,.dat	Yes	Yes
Parameters	.txt,.csv,.dat	Yes	Yes
Variables	.txt,.csv,.dat	Yes	Yes
Continuous and Discrete color table	.txt	Yes	No
Point data for Cut Point data sets	.txt	Yes	No
DEM	.dem	Yes	No
VTK	.vtu	No	Yes

<sup>1</sup>Requires LiveLink™ for Excel®, available for Windows® only

## Appendix E — Connecting with LiveLink™ Add-Ons

---

The following table shows the options to start COMSOL and the different linked partner software using the LiveLink add-ons.

COMSOL® Software	Can Start COMSOL from Partner Software	Can Start Partner Software from COMSOL	Can Connect Running Sessions
LiveLink™ for Excel®	Yes <sup>1</sup>	Yes <sup>2</sup>	No
LiveLink™ for MATLAB®	Yes <sup>3</sup>	Yes <sup>4</sup>	Yes <sup>5</sup>
LiveLink™ for AutoCad®	No	No	Yes
LiveLink™ for Revit®	No	No	Yes
LiveLink™ for PTC®Creo® Parametric™	No	No	Yes
LiveLink™ for Inventor®			
- Bidirectional Mode	No	No	Yes
- One Window Mode	Yes	No	No
LiveLink™ for PTC® Pro/ENGINEER®	No	No	Yes
LiveLink™ for Solid Edge®	No	No	Yes
LiveLink™ for SOLIDWORKS®			
- Bidirectional Mode	No	No	Yes
- One Window Mode	Yes	No	No

<sup>1</sup>When you open a model from Excel®, a model window starts and a link is established automatically. The model window is an output window that displays geometry, mesh, and results.

<sup>2</sup>A model that includes a table reference to an Excel® spreadsheet automatically starts an Excel® process in the background when the model is run in the COMSOL Desktop environment.

- <sup>3</sup>You can start a COMSOL Multiphysics server from a MATLAB® session using the **system** command and then connect to it using **mphstart** in the MATLAB® command prompt.
- <sup>4</sup>The “COMSOL with MATLAB®” desktop shortcut starts a COMSOL Multiphysics server and MATLAB®, then connects them automatically. When you run a COMSOL Multiphysics model in the COMSOL Desktop interface that includes a MATLAB® function (Global Definitions > Functions), a MATLAB® engine and connection is started automatically.
- <sup>5</sup>You can connect a MATLAB® session to a running COMSOL Multiphysics server using the command **mphstart** in the MATLAB® command prompt.

# Index

---

- A** AC/DC Module 53, 73  
accuracy  
convergence analysis 45  
Add Material window  
busbar model 63  
opening 35, 62  
Add Multiphysics  
button 74  
window 74  
add-on modules  
AC/DC Module 53, 71, 73  
Application Libraries 26  
CAD Import Module 145, 179  
CFD Module 114  
Chemical Reaction Engineering Module 181  
Design Module 145, 179  
ECAD Import Module 181  
MEMS Module 106  
physics list 31, 54  
physics list, and 54  
Plasma Module 181  
Structural Mechanics Module 30, 40  
study types 55  
advanced study options 140  
advanced topics 97  
analysis  
convergence 45  
example, parametric sweep 49  
animation 18, 139  
application 11, 86  
Application Builder 6, 8, 10, 11, 21, 86, 165  
Application Gallery 27  
Application Libraries  
examples 26  
file types 27  
MPH files 26  
Application Libraries window 27  
Application Library update 27  
autocompletion  
parameter and variable names 135  
parameters and variables 57  
average temperature 130
- B** blank model, creating 13, 15  
boundaries 70  
adding to selection 72  
variables scope 22  
boundary condition 68  
automatically defined 40  
boundary load 39  
busbar, setting 68  
electric current 68, 71  
fixed constraint 38  
free 37  
ground, electrical 73  
heat transfer 68  
insulating 70  
material interface 40  
settings window 8  
boundary load 39  
boundary section  
context menu 69  
boundary selection, busbar model 70  
Build All button  
geometry 60  
meshes 41, 76  
built-in  
constants, functions, and variables 23  
materials 35, 62  
variables 81

- button object 89
- C** CAD Import Module 145, 179  
Cancel button 10, 25  
CFD Module 114  
chamfer 145  
Chemical Reaction Engineering Module 181  
cloud computing 139  
Cluster Computing node 140  
Cluster Sweep node 140  
command sequence 92  
Compact MPH files 27  
component coupling 130  
Component node, adding materials 63  
computing studies 49  
COMSOL Client 11  
COMSOL Desktop environment  
customizing 23  
on Linux 17  
on OS X 17  
overview 6  
COMSOL Multiphysics 11  
native CAD format 33  
opening 30  
COMSOL Server 11  
constants  
mathematical and physical types 23  
context menu  
domain and boundary sections 69  
contextual tab 16  
contributing node 113  
convergence analysis 45, 50  
Convergence plot 9, 77  
cooling  
air stream 52  
natural convection 56  
coupling operator 130  
Create Selection button 108  
custom studies 55
- customized desktop 23
- D** data sets, defined 18  
default feature 68  
Definitions node 29  
degrees of freedom 45, 50  
derivatives 23  
Derived Values  
defined 18  
Global Evaluation 50  
Volume Maximum 46, 50, 85  
Design Module 145, 179  
DirectX 12  
discretize 41  
documentation, models 26  
domain level 69  
domain section  
context menu 69  
domains  
materials 66  
remove from selection 66  
variables scope 22  
dynamic help 10, 25
- E** ECAD Import Module 181  
edges  
variables scope 22  
Editor Templates window 91  
eigenfrequency analysis 18  
Electric Currents interface  
defining boundary conditions 69  
multiphysics 55, 73  
overview 68  
electric potential 53  
physics node 71  
voltage drop, parameter 56  
electrical heating 52  
equation  
built-in 68  
user-defined 44

- evaluating  
volume maximum 46, 83, 85  
von Mises stress 46
- example  
advanced, electrical heating 52  
basic, structural mechanics 30
- Excel® 183, 185
- exclusive node 112
- Export node 18
- exporting images 85
- expressions  
Boolean 44  
manual entry 47, 56  
replacing 44, 81, 83  
units, specifying 46  
user-defined 44
- External Process window 10
- F** fillet 145  
find  
parameters and variables 58
- finite element  
mesh 41  
preconditioning 49  
tetrahedrons 41
- Fixed Constraint node 38
- Floating Network License 140
- Form editor 10, 89  
form objects 86  
form union, geometry 60  
frequency response 19  
frequency-domain study 18
- Full MPH files 27
- functions  
advanced topics 97  
built-in 23  
mathematical 23  
scope 56
- Functions node 56
- G** geometric dimensions  
parameters, and 20, 159  
parametric sweep 56
- geometry  
building 56  
CAD format 32  
importing 32  
in Application Libraries 59  
loading from file 56, 59  
parameterized 20, 56, 60, 159  
settings window 8
- Geometry node 28
- Global Definitions node 17, 20  
functions 56  
parameters 56  
scope 22, 56  
variables 21
- global parameters 20, 36, 47, 56  
expression 20
- graphics  
rendering and hardware 12
- graphics object 88, 90
- Graphics toolbar  
default view button 38, 43, 73, 82  
image snapshot button 85  
zoom extents button 61, 79
- Graphics window 7, 9, 25  
geometry, and 34  
plot 42  
rotate geometry 38, 78, 80  
selecting boundary 38, 39, 73  
toolbar 7  
using 34, 62  
zoom box 39
- Ground, boundary condition 72
- H** Heat Transfer in Solids interface  
defining boundary conditions 69  
multiphysics 55, 73  
overview 68

Heat Transfer Module 114  
Help window 10  
opening 17  
high performance computing 139  
Home tab 15  
HPC 139  
hybrid parallelism 141

**I** Image Snapshot button 85  
images, creating thumbnails 85  
importing geometry 32, 33  
infinite elements 29  
information windows 7, 9, 25  
initial conditions 8  
Initial Values node  
Electric Currents interface 69  
Heat Transfer in Solids interface 69  
Solid Mechanics interface 37  
input fields 87  
Input Parameters  
for part 160  
Insert Object menu 91  
Isosurface plot 77, 137  
iterative solver  
multigrid 49  
preconditioning 49

**J** Java file 29, 182  
Joule heating  
equations 68  
multiphysics coupling 73  
multiphysics interface 54

**L** Laminar Flow interface 117  
Linux version 17  
LiveLink™ add-ons 185  
loft 145  
Log window 9, 42

**M** M file 29, 183  
Material Browser  
defined 10  
material contents section 35, 64  
material interface  
mechanical contact 40  
materials  
appearance, color and texture 67  
copper 52  
domains, assigning 65  
model tree 28  
settings window 8  
steel 35, 43  
titanium alloy 52  
Materials node 35, 62  
mathematical constants and functions  
23  
MATLAB® 183  
Max/Min Volume plot 46  
Maximum and minimum values table 84  
MEMS Module  
thermal expansion, and 106  
mesh  
convergence analysis, and 45  
density 47  
finite element 41  
model tree, and 28  
parameterizing 47, 75  
physics-controlled, default 75  
refining 47  
settings 41  
unstructured tetrahedral 75  
user-controlled 48, 75  
mesh element size  
parameters, defining 20, 75  
settings 41  
message passing interface 141  
Messages window 9, 42  
method 94  
Method editor 10, 94  
midsurface 145  
modal tab 16

Model Builder 6, 86  
defined 10  
example 28  
expanding sections 68  
geometry import 33  
node sequence example 37  
the ribbon, and 16  
toolbar 6  
window 24  
model history 29  
model tree 6, 24  
building 17  
defined 56  
example 28  
geometry 28  
Global Definitions node 17, 36, 56  
Materials node 28, 35  
Model Builder 10  
nodes 17  
Results node 18  
ribbon 16  
root node 17  
Study node 18, 29  
Model Wizard  
adding physics 18, 31, 54  
Component node, and 18  
creating a new model 13  
custom studies 32, 55  
opening 31, 54  
preset studies 32, 55  
space dimension 31, 54  
study 18, 55  
models  
defining 10  
discretization 41  
documentation 26  
saving 62  
structural mechanics 30  
symmetry 80

workflow 28  
MPH file 179  
full and compact 27  
saving 62, 86  
MPHBIN file 179  
MPHPHB file 179  
MPHTXT file 179  
MPI 141  
multicore processors 139  
multiphysics models 52  
Multiphysics node 68, 69, 74, 107  
multiphysics phenomena 52  
Multislice plot 77

**N** New Form wizard 86  
no solutions stored, message 27  
nodes 17  
default feature 37  
reordering 29

**O** OpenGL 12  
OS X version 17  
Override and Contribution 37, 113

**P** parallel computing 139  
parameters 20, 88  
defining 47, 56  
editing 60  
expression 20, 47  
global 20  
meshes, and 47  
name 47  
range of values 49  
results 21, 136  
scope 56  
using, referencing 71  
Parameters node 56, 97  
parametric study 56  
parametric sweep 20  
example 48  
meshes, and 47

range, defining 49  
part 159  
    Input Parameters 160  
Part Libraries 159  
perfectly matched layer (PML) 29  
physics  
    adding 54  
    boundary conditions 68  
    electromagnetic heating 54  
    heat transfer 54  
    Joule heating 52, 68  
    laminar flow 117  
    model tree 28  
physics interface 13  
    Electric Currents 55  
    Heat Transfer in Solids 55  
    Joule Heating 54  
    Laminar Flow 117  
    Solid Mechanics 31  
Plasma Module 181  
player 139  
plot group 18  
    3D, adding 44  
Plot window 24  
plots  
    expression, user-defined 44  
    max/min volume 46  
    model tree 29  
    regenerating 47  
    surface 42, 44  
    windows 9  
points, variables scope 22  
polynomial functions 41  
preconditioning 49  
preferences 12  
preset studies 55  
principal stress 112  
program code  
    model file for Java 29  
model M-file 29  
progress bar 10, 25  
Progress window 9  
**Q** Quick Access Toolbar 6, 8, 16, 24  
**R** Record Code 96  
renaming plot groups 45  
rendering options 12  
reports, defined 18  
reserved name 23  
resolution of curvature, mesh 76  
results  
    color table range 78, 81  
    derived values 46, 50, 85  
    displaying 42  
    parameters 21, 136  
    surface settings, modify 78  
    units, changing 42  
Results node  
    3D plot group 46, 80  
    busbar defaults 77  
    subnodes 18  
    surface node, adding 80  
ribbon 6, 24  
    Add Material 35, 67, 116  
    Build All 61  
    Build Mesh 76  
    Compute 49, 110, 126  
    defined 8, 15  
    example 6  
    importing geometry 33  
    Model Builder 16  
    Physics tab 38, 107  
    Windows 10, 42, 149  
    Work Plane 147  
root node  
    default units 129  
    defined 17  
    model thumbnails 85

- Model Wizard 31
  - running simulations 77
  - s** saving files 62, 86
  - scope
    - global definitions 56
    - parameters and variables 22
    - parameters and variables, defined 20
    - variable name 23
  - search
    - parameters and variables 58
  - Select Study window 15
  - selecting
    - multiple boundaries 108
    - selecting internal surfaces 40
  - Selection 108
  - Selection List window 10, 149
  - selection of geometry objects, domains, boundaries, edges, and points 40
  - Settings window 6, 8, 17, 24
  - shared memory parallelism 139
  - simulation, running 77
  - software rendering 12
  - Solid Mechanics interface 31
    - add-on modules 106
  - solvers
    - configurations 49
    - iterative 48, 49
    - stationary 42, 49
    - using 42
  - space dimension 13
  - Stationary study 32, 42
  - steady-state study 18
  - structural analysis 30
  - structural displacement field 41
  - structural mechanics
    - design 45
    - plastic deformation 43
    - stresses and strains 52, 65
  - von Mises stress 42
- Structural Mechanics Module
    - application library 30
    - mechanical contact 40
    - thermal expansion 106
  - studies
    - computing solutions 49, 77
    - defining 42
    - example, multigrid iterative 49
    - example, stationary 42
    - model tree 29
    - preset 55
    - types 18
  - Study node 18
    - solution sequence 77
  - Surface plot
    - busbar results 77
    - color table range 81
    - deformation 42
    - electrical current density 80
    - replace expression 81
    - settings 44
    - updating 79, 81
  - T** table
    - Maximum and minimum 84
  - Table window 10
    - graph plot 50
    - wrench results 46
  - Tables node 18
    - tables, evaluating 50
  - temperature 77, 126
  - temperature, average 130
  - Test Application 90
  - tetrahedron, polynomial functions 41
  - thermal expansion 52, 65
  - thicken 145
  - thumbnail image 85
  - time-dependent study 18
  - torque, applied 30

- U** unit, changing 42, 111
  - update COMSOL Application Libraries 27
- user interface
  - COMSOL Desktop 6
  - overview 6
- user-controlled mesh 48
- V** variables
  - advanced topics 97
  - built-in 23
  - example, built-in 50
  - expression 21
  - scope 56
  - scope, limit 22
- Variables node 21, 56
- visualization 9
  - color table 78, 81
- Volume Maximum, evaluating 46, 83, 85
- von Mises stress 42, 112
- W** Windows list 42, 149
  - wizard
    - New Form 86
  - workflow 26
- Y** yield stress 30, 43
- Z** zoom 127
  - Zoom Extents command 93