

LOAD CALCULATOR PRO - QUICKSTART

This is a field-first, one-page quick guide for first-time users.

What this tool does

'Load Calculator Pro' estimates:

- running load (kW and kVA)
- peak starting kVA (largest motor start logic)
- recommended generator size (kVA)
- fuel runtime estimate (gallons-based)

Use it for planning and rapid field checks. It is not a final engineering design tool.

Open and run

1. Open 'index.html' in a modern browser.
2. No internet or server is required.
3. All save/autosave data stays in the current browser on the current device.

Fast workflow (recommended)

1. Enter quantities and review row kW/PF values.
2. Use 'Sort' and 'Search' to focus the list.
3. Review side cards:
 - total running kW and kVA
 - peak starting kVA
 - recommended generator size (kVA)
 - capacity status and runtime
4. Enter:
 - 'Actual generator size' (kVA)
 - 'Fuel tank capacity' (Gallons)
 - 'Consumption (per kW)' (Gal/hr per kW)
5. Print or save/export as needed.

Scenarios and files

- 'Save Scenario': save current worksheet as a named scenario.
- 'Load/Delete/Clear all': manage saved scenarios in this browser.
- 'Export to file': choose JSON (backup/re-import) or CSV (human-readable report).
- 'Import from file': load a JSON scenario file.

If imported data has issues, the tool sanitizes values and reports import issues.

Autosave (toolbar)

- 'Clear Autosaved State': removes worksheet recovery state only.
- 'Last autosaved': shows latest autosave timestamp.
- Named saved scenarios are **not** deleted by clearing autosave state.

Reset buttons

- 'Reset Quantities': clears quantities and removes custom rows.
- 'Reset Worksheet': full reset to defaults for quantities, kW/PF, custom rows, and side inputs.

Both actions ask for confirmation before applying.

Important usage notes

- Main totals are all-items values.
- Filtered subtotals appear when search is active.
- Final generator selection must satisfy both running and peak-start requirements.

Safety/disclaimer

This calculator is a simplified estimator for planning support. Final electrical sizing must be