

HOVIS Lite **Assembly** Manual "Parts List"

HOVIS Lite **Assembly** Manual "Parts List"















X4 DRB-0006 Dummy Servo (BH/M 2.6X8.0 Bolt attached)



X4 DRB-0001 Front / Back



X4 DRB-0002



X4 DRB-0003



X40 DRB-0004 Universal Plate



X8 DRB-0005 Ankle Plate



X6 DRB-0008 U1-type Bracke



X8 DRB-0009 U2-type Bracket



X6 DRB-0010 U3-type Bracke



X8 DRB-0011 U4-type Brack



X 1 DRB-0007 Battery Case & Holder



X1 DRC-005T



DRL-0728 7.4V Li-Po Bat







X70 DRJ-0001 L-type Joint (Single Nut)



X10 DRJ-0002 L-type Joint (Double Nut)



X40 DRJ-0003 (Hole only)



X10 DRJ-0004 I-type Joint (10.9mm, Hole only)



×60 DRJ-0006 I-type Joint (12.5mm, Double Nut)



X20 DRJ-0007 (16.0mm, Hole only)



X20 DRJ-0008 V-type Joint (12,0mm, Single Nut)



X20 DRJ-0009 V-type Joint (12,0mm, Double Nut)



X20 DRJ-0010



X20 DRJ-0011



X4 DCW-0001 Wheel (White, @



DRQ-0001 AC Adaptor



DRI-0002 Serial Cable (DSUB 9Pin - 3P Audio Jack)



X DRI-0003
USB to Serial Gender



X DRI-0004



DRI-0005



X 1 DRI-0008 PSD Sensor



X DRI-0007 ZigBee (Option





1:1 SCALE









⟨○⟩ **×10 DRA-0052** Nut (M3)





| DRA-0064 | Bolt (PH/T 2 0XF

1 DRA-0054
Rolf (PH/M 2 0X13)



DRA-0056 Bolt (PH/M 2.0X4





















