Kai's Wi-Fi Plane

Keel dart · cut-and-fold · one sheet

Print on CARD STOCK, at 100%
("Actual size", not "Fit to page")

- solid line = CUT
- dashed = FOLD (in number order)
- dotted = skewer spine, inside the keel
- boxes = where parts go (real size)

▲ NOSE

This bar must be 5 cm.
Check with a ruler. If it isn't, reprint at 100% before you cut.

Before cutting: lay the skewer on the MOTOR STICK and mark both motor spots + the centre on it.

① **fold in half, printed side OUTSIDE**
② **fold each wing back out flat**
③ **bend the back flaps up 2 mm**

LEFT motor

RIGHT motor

centre ↓

MOTOR STICK (skewer, 16 cm)

USB ↑
XIAO
pins up

DRIVER
pins up
OUT →

BAT ↕

BAT ↕

BALANCE

BALANCE
10 cm from the nose

motor wires run along the skewer to the DRIVER

ANTENNA

KEEL: folds UNDER, no parts here

SPINE: skewer inside the keel

LEFT WING

(this printed side is the TOP)

RIGHT WING

②
keel

②
keel

✂ cut the 4 short slits

③ bend UP 2 mm

①

③ bend UP 2 mm