



Produced by
Psion Teklogix Ltd

Record User Guide

RECORD

You can use the Record program to make sound recordings and create alarm sounds. You can record sounds and play back from any point in the sound.



Displaying on-line help

To display on-line help, select the [Help on Record](#) option from the [Tools](#) menu.

Recording a sound

When you open the Record program you can begin to record right away. Simply place the machine so that the microphone is near the sound source and tap the [REC](#) button or press Enter.

Tap the [STOP](#) button, or press Esc to stop recording.

Note: The microphone is located to the right-hand side of the netpad on the bottom edge (see the 'Getting Started' document).



- To record some more, tap [REC](#) or press Enter again. New sound is added to the end of the existing recording.
- To start a new file, select the [Create new file](#) command from the [File](#) menu. Type in the name before you begin recording.
- To save your file under a different name, tap the [Save as](#) button on the Toolbar or select the command from the [File](#) menu.
- To replace the ending of an existing recording, use the pen to drag the bar to the point where you want to begin recording (or select the [Go to time](#) button or the command from the [Play](#) menu and specify a start point in minutes and seconds), then select the [Record & replace](#) command from the [Record](#) menu.
- To erase the whole of the current recording, tap the [Erase](#) button on the Toolbar or select the [Erase all](#) command from the [Record](#) menu.

The maximum recording length depends on the amount of disk space available. While recording, a 'Time remaining' indicator shows how much more sound you could record if you wanted to use the available space. Record will not allow you to completely fill the disk, and will always leave 100K free so that you can use other programs.

Note: If an alarm is due to ring while you are recording or playing a sound, you may hear warning "ticks" and the alarm will be postponed until you finish the current action.

Playing sounds

To play back the entire sound file, tap the [PLAY](#) button, press the Spacebar, or select the command on the [Play](#) menu.

Note: The loudspeaker is located at the back of the machine (see the 'Getting Started' document).

- To play back only part of a sound, use the pen to drag the cursor to the point where you want to begin playing (or select the [Go to time](#) command from the [Play](#) menu and enter the start position in minutes and seconds), then press [PLAY](#). Playback begins from the selected point. To pause playback, press [PLAY](#) again.
- To adjust the volume, use the pen to move the volume fader to one of the volume settings, or set it to [Min](#) to turn off the sound completely.
- To play back a sound recording several times in succession, tap the [Repeat](#) button on the Toolbar or select the [Repeat sound](#) command from the [Tools](#) menu and set the number of occurrences as appropriate.

File sizes and compression

Digital sound recordings can be very large. In order to save disk space, a compression process is applied to Record files as they are being recorded.

To save even more disk space:

- Use the [Compress sound](#) command on the [Tools](#) menu and select ADPCM (4 minutes per Mbyte) before starting to record the sound. This approximately halves the amount of space required. Search and skip functions may take slightly longer if a file is ADPCM compressed.

