TECHNICAL INFORMATION

Telegram Listing

GLS621

SICK
Sensor Intelligence.

Described product

GLS621

Manufacturer

SICK AG
Erwin-Sick-Str. 1
79183 Waldkirch
Germany

Production location

Legal information

This work is protected by copyright. Any rights derived from the copyright shall be reserved for SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Any modification, abridgment or translation of this document is prohibited without the express written permission of SICK AG.

The trademarks stated in this document are the property of their respective owner.

© SICK AG. All rights reserved.

Original document

This document is an original document of SICK AG.

Information on the Telegram Listing

NOTE
Telegrams that are not described in this document for the device should not be implemented as they may either be incompetible or cause undesired effects.

Most parameter changes require certain user levels. Additionally, commands may change during the product lifecycle and development process with a new firmware.

If commands do not seem to work, please verify that your device version supports this functionality, that the minimum required user level has been selected and check on updates of this documentation.

This document is based on the following firmware version (or newer):

- V4.14.0.21

ASCII Telegram structure

The ASCII commands are written in plaintext. The string consists of two parts: the framing and the data part.

The framing indicates with <STX> and <ETX> the start and stop of each telegram.

The data part comprises the actual command with letters and characters (plaintext), parameter values either in decimal (special indicator required) or in hexadecimal (example: a frequency of 25 Hz = +2500 (decimal) = 09C4 (Hex)) and fixed hexadecimal values with a specific, intrinsic meaning.

NOTE
Leading zeros are deleted in ASCII. Therefore a space is always required between all command parts and parameter parts.

NOTE
The device will confirm parameter values always in hexadecimal code, regardless of the code sent.

Table 1: Example: ASCII telegram

ASCII	<STX>	sMN{SPC}SetAccessMode{SPC}3{SPC}F4724744	<ETX>
	Start	Data	Stop

This is again an example telegram for setting the user level “Authorized Client”. As only fixed hexadecimal parameter values are needed, the option to use parameter values in decimal code with special indicator cannot be applied here:

- Framing = <STX> = telegram start
- Data:
  - sMN = start of Sopas command (and blank)
  - SetAccessMode = the actual command for setting the user level (and blank)
  - 3 = fixed Hex value meaning user level “Authorized Client” (and blank)
  - F4 72 47 44 = fixed Hex value, serving as password for the selected user level “Authorized Client”
- Framing = <ETX> = telegram stop

Table Of Contents

1. General . . . 1
1.1. Introduction . . . 1
1.2. User Level . . . 1
1.3. Methods . . . 1
1.4. Events . . . 1
1.5. Datatypes . . . 1
2. Interfaces . . . 3
2.1. Interface Block: S_Standard . . . 3
2.1.1. Group: V100 . . . 3
2.1.1.1. Variable: LocationName . . . 3
2.1.1.2. Method: SetAccessMode . . . 4
2.1.1.3. Method: NotifyMode . . . 5
2.1.1.4. Method: GetAccessMode . . . 6
2.1.1.5. Method: Run . . . 7
2.1.1.6. Method: GetDescription . . . 8
2.1.2. Group: V200 . . . 11
2.1.2.1. Method: GetChallenge . . . 11
2.1.2.2. Method: SetUserLevel . . . 12
2.1.2.3. Method: ChangePassword . . . 13
2.1.3. Group: Optional . . . 15
2.1.3.1. Method: SetPassword . . . 15
2.1.3.2. Method: CheckPassword . . . 16
2.1.4. Group: fileMethods . . . 18
2.1.4.1. Method: GenOpenFile . . . 18
2.1.4.2. Method: GenCloseFile . . . 19
2.1.4.3. Method: GenReadFile . . . 20
2.1.4.4. Method: GenWriteFile . . . 22
2.1.4.5. Method: GetFileSyncValue . . . 24
2.1.4.6. Method: GetFileSize . . . 25
2.2. Interface Block: GeneralCfgBase . . . 27
2.2.1. Group: EEprom . . . 27
2.2.1.1. Method: ReadEeprom . . . 27
2.2.1.2. Method: WriteEeprom . . . 28
2.2.2. Group: SystemControl . . . 30
2.2.2.1. Variable: SCTimeFormat . . . 30
2.2.2.2. Variable: SCUserInterfaceVariant . . . 31
2.2.2.3. Method: SoftReset . . . 33

© SICK AG - Germany - All rights reserved

2.2.2.4. Method: RebootDevice . . . 34
2.2.2.5. Method: LoadFactoryDefaults . . . 35
2.2.2.6. Method: LoadApplicationDefaults . . . 36
2.2.2.7. Method: SetPasswordDefaults . . . 37
2.2.2.8. Method: SelfTest . . . 38
2.2.3. Group: FirmwareDownload2nd . . . 39
2.2.3.1. Method: Start2ndStageLoader . . . 39
2.2.3.2. Method: LogWrite . . . 40
2.2.3.3. Method: LogEnd . . . 41
2.2.3.4. Method: LogInfo . . . 42
2.2.3.5. Method: LogErase . . . 43
2.2.3.6. Method: StartMemCardUpdate . . . 45
2.3. Interface Block: DiagBase . . . 46
2.3.1. Group: DeviceInformationBase . . . 46
2.3.1.1. Variable: LastMaintenance . . . 46
2.3.1.2. Variable: NextMaintenance . . . 47
2.3.1.3. Method: SetLastUser . . . 49
2.4. Interface Block: TestBase . . . 51
2.4.1. Group: TestErrorSetting . . . 51
2.4.1.1. Method: SetTestErrorInfo . . . 51
2.4.1.2. Method: SetTestErrorWarning . . . 52
2.4.1.3. Method: SetTestErrorError . . . 53
2.4.1.4. Method: SetTestErrorFatalError . . . 54
2.5. Interface Block: FirstStageLdr . . . 55
2.5.1. Group: FirmwareDownload . . . 55
2.5.1.1. Method: SystemConfigData . . . 55
2.5.1.2. Method: ProgramConfigData . . . 56
2.5.1.3. Method: ProgramData . . . 58
2.5.1.4. Method: ExecuteDownload . . . 60
2.5.1.5. Method: StatusDownload . . . 61
2.5.1.6. Method: FinishDownload . . . 63
2.5.1.7. Method: AbortDownload . . . 64
2.6. Interface Block: GeneralCfgIOBase . . . 66
2.6.1. Group: DigitalOutputsBase . . . 66
2.6.1.1. Variable: Out1FuncEvCndExt . . . 66
2.6.1.2. Variable: Out1OffFunc . . . 67
2.6.1.3. Variable: Out1OffFuncEvCndExt . . . 69
2.6.1.4. Variable: Out1Logic . . . 70
2.6.1.5. Variable: Out1DurTime . . . 72
2.6.1.6. Variable: Out1DurTrack . . . 73
2.6.1.7. Variable: Out1Control . . . 74
2.6.1.8. Variable: Out2FuncEvCndExt . . . 76

© SICK AG - Germany - All rights reserved

2.6.1.9. Variable: Out2OffFunc . . . 77
2.6.1.10. Variable: Out2OffFuncEvCndExt . . . 79
2.6.1.11. Variable: Out2Logic . . . 80
2.6.1.12. Variable: Out2DurTime . . . 82
2.6.1.13. Variable: Out2DurTrack . . . 83
2.6.1.14. Variable: Out2Control . . . 84
2.6.1.15. Variable: Out2Func . . . 86
2.6.1.16. Variable: Out1Func . . . 87
2.6.1.17. Method: SetOutput . . . 89
2.6.2. Group: DigitalInputsBase . . . 91
2.6.2.1. Variable: Sensor1Sensitivity . . . 91
2.6.2.2. Variable: Sensor1Logic . . . 92
2.6.2.3. Variable: Sensor1DebounceTime . . . 94
2.6.2.4. Variable: Sensor1DebounceTrack . . . 95
2.6.2.5. Variable: Sensor1Control . . . 96
2.6.2.6. Variable: Sensor2Sensitivity . . . 98
2.6.2.7. Variable: Sensor2Logic . . . 99
2.6.2.8. Variable: Sensor2DebounceTime . . . 100
2.6.2.9. Variable: Sensor2DebounceTrack . . . 102
2.6.2.10. Variable: Sensor2Control . . . 103
2.6.2.11. Method: ReadInput . . . 104
2.7. Interface Block: CdfSensorShared . . . 106
2.7.1. Group: CdfBasicMethods . . . 106
2.7.1.1. Method: CdfProfinetEeWriteOnlyIntern . . . 106
2.7.1.2. Method: CdfProfinetResetToFactory . . . 107
2.7.2. Group: CdfStaticProfinetConfig . . . 109
2.7.2.1. Variable: CdfPnDeviceId . . . 109
2.7.2.2. Variable: CdfPnDeviceType . . . 110
2.7.2.3. Variable: CdfPnSwRevision . . . 112
2.7.2.4. Variable: CdfPnHwRevision . . . 113
2.7.2.5. Variable: CdfPnProfileId . . . 115
2.7.2.6. Variable: CdfPnProfileSpecificType . . . 116
2.7.2.7. Variable: CdfEthMac . . . 118
2.7.2.8. Variable: CdfEthMacP1 . . . 119
2.7.2.9. Variable: CdfEthMacP2 . . . 121
2.7.2.10. Variable: CdfOrderIdFamily . . . 122
2.7.2.11. Variable: CdfOrderIdDevice . . . 124
2.7.2.12. Variable: CdfIsDeviceFamily . . . 125
2.7.3. Group: CdfProfinetStatus . . . 127
2.7.3.1. Variable: CdfProfinetBusStatus . . . 127
2.7.3.2. Variable: CdfProfinetStackErrorCode . . . 128
2.7.4. Group: CdfProfinetControlAndInformationFlags . . . 130

© SICK AG - Germany - All rights reserved

2.7.4.1. Variable: CdfProfinetMasterAvailable . . . 130
2.7.4.2. Variable: CdfProfinetStationNameStoringRemanent . . . 131
2.7.4.3. Variable: CdfProfinetIpSettingsStoringRemanent . . . 133
2.7.4.4. Variable: CdfProfinetConfigApply . . . 135
2.7.4.5. Variable: CdfProfinetConfigChanged . . . 136
2.7.4.6. Variable: CdfProfinetS7CompatibilityMode . . . 138
2.7.4.7. Method: CdfProfinetApplyButton . . . 140
2.8. Interface Block: CdfSensorConfigShared . . . 142
2.8.1. Group: CdfProfinetConfig . . . 142
2.8.1.1. Variable: CdfProfinetStationName . . . 142
2.8.1.2. Variable: CdfProfinetIpAddress . . . 143
2.8.1.3. Variable: CdfProfinetIpMask . . . 145
2.8.1.4. Variable: CdfProfinetIpGateway . . . 146
2.8.1.5. Variable: CdfProfinetImFunction . . . 148
2.8.1.6. Variable: CdfProfinetImLocation . . . 149
2.8.1.7. Variable: CdfProfinetImDate . . . 151
2.8.1.8. Variable: CdfProfinetImDescriptor . . . 152
2.8.1.9. Variable: CdfProfinetImSignature . . . 154
2.8.2. Group: CdfProfinetConfigPDEV . . . 156
2.8.2.1. Variable: CdfPnPdevMagic . . . 156
2.8.2.2. Variable: CdfPnPdevCrc . . . 157
2.8.2.3. Variable: CdfPnPdevRawData . . . 159
2.9. Interface Block: ExtDeviceShared . . . 161
2.9.1. Group: ControlAndInformationFlags . . . 161
2.9.1.1. Variable: ExtDeviceLoadFactoryDefaults . . . 161
2.9.1.2. Variable: ExtDeviceWriteEeprom . . . 163
2.10. Interface Block: GeneralCfgIOLector6xx . . . 165
2.10.1. Group: DigitalOutputsLector6xx . . . 165
2.10.1.1. Variable: Out3FuncEvCndExt . . . 165
2.10.1.2. Variable: Out3OffFunc . . . 166
2.10.1.3. Variable: Out3OffFuncEvCndExt . . . 168
2.10.1.4. Variable: Out3Logic . . . 169
2.10.1.5. Variable: Out3DurTime . . . 171
2.10.1.6. Variable: Out3DurTrack . . . 172
2.10.1.7. Variable: Out3Control . . . 173
2.10.1.8. Variable: Out4FuncEvCndExt . . . 175
2.10.1.9. Variable: Out4OffFunc . . . 176
2.10.1.10. Variable: Out4OffFuncEvCndExt . . . 178
2.10.1.11. Variable: Out4Logic . . . 179
2.10.1.12. Variable: Out4DurTime . . . 181
2.10.1.13. Variable: Out4DurTrack . . . 182
2.10.1.14. Variable: Out4Control . . . 183

© SICK AG - Germany - All rights reserved

2.10.1.15. Variable: Out1Mode . . . 185
2.10.1.16. Variable: Out2Mode . . . 186
2.10.1.17. Variable: Out3Mode . . . 187
2.10.1.18. Variable: Out4Mode . . . 189
2.10.1.19. Variable: Out1ScopingEnabled . . . 190
2.10.1.20. Variable: Out1ScopingExtraDelay . . . 191
2.10.1.21. Variable: Out2ScopingEnabled . . . 193
2.10.1.22. Variable: Out2ScopingExtraDelay . . . 194
2.10.1.23. Variable: ResetOutOnTrigger . . . 195
2.10.1.24. Variable: Out4Func . . . 197
2.10.1.25. Variable: Out3Func . . . 198
2.10.1.26. Method: StartModeDigIoCondition1 . . . 200
2.10.1.27. Method: StopModeDigIoCondition1 . . . 201
2.10.1.28. Method: StartModeDigIoCondition2 . . . 202
2.10.1.29. Method: StopModeDigIoCondition2 . . . 203
2.10.1.30. Method: StartModeDigIoCondition3 . . . 204
2.10.1.31. Method: StopModeDigIoCondition3 . . . 205
2.10.1.32. Method: StartModeDigIoCondition4 . . . 206
2.10.1.33. Method: StopModeDigIoCondition4 . . . 207
2.11. Interface Block: GeneralCfgExtIOBase . . . 208
2.11.1. Group: ExternalOutputsBase . . . 208
2.11.1.1. Variable: ExtOut1Func . . . 208
2.11.1.2. Variable: ExtOut1FuncEvCndExt . . . 209
2.11.1.3. Variable: ExtOut1OffFunc . . . 211
2.11.1.4. Variable: ExtOut1OffFuncEvCndExt . . . 212
2.11.1.5. Variable: ExtOut1Logic . . . 214
2.11.1.6. Variable: ExtOut1DurTime . . . 215
2.11.1.7. Variable: ExtOut1DurTrack . . . 216
2.11.1.8. Variable: ExtOut1Control . . . 218
2.11.1.9. Variable: ExtOut2Func . . . 219
2.11.1.10. Variable: ExtOut2FuncEvCndExt . . . 221
2.11.1.11. Variable: ExtOut2OffFunc . . . 222
2.11.1.12. Variable: ExtOut2OffFuncEvCndExt . . . 224
2.11.1.13. Variable: ExtOut2Logic . . . 225
2.11.1.14. Variable: ExtOut2DurTime . . . 227
2.11.1.15. Variable: ExtOut2DurTrack . . . 228
2.11.1.16. Variable: ExtOut2Control . . . 229
2.11.1.17. Method: SetExtOutput . . . 231
2.11.2. Group: ExternalInputsBase . . . 233
2.11.2.1. Variable: ExtSensor1Sensitivity . . . 233
2.11.2.2. Variable: ExtSensor1Logic . . . 234
2.11.2.3. Variable: ExtSensor1DebounceTime . . . 236

© SICK AG - Germany - All rights reserved

2.11.2.4. Variable: ExtSensor1DebounceTrack . . . 237
2.11.2.5. Variable: ExtSensor1Control . . . 239
2.11.2.6. Variable: ExtSensor2Sensitivity . . . 240
2.11.2.7. Variable: ExtSensor2Logic . . . 242
2.11.2.8. Variable: ExtSensor2DebounceTime . . . 243
2.11.2.9. Variable: ExtSensor2DebounceTrack . . . 244
2.11.2.10. Variable: ExtSensor2Control . . . 246
2.11.2.11. Method: ReadExtInput . . . 247
2.12. Interface Block: GeneralCfgDecoding1DBase . . . 249
2.12.1. Group: Decoding1DGeneral . . . 249
2.12.1.1. Variable: CodeContrast1D . . . 249
2.12.1.2. Variable: CodeBackground1D . . . 250
2.12.2. Group: Decoding1DBase . . . 252
2.12.2.1. Variable: CBARMultiRead . . . 252
2.12.2.2. Variable: CBARStaStoIdent . . . 253
2.12.2.3. Variable: CBARStaStoTransmit . . . 255
2.12.2.4. Variable: CBARCheckDigitTest . . . 256
2.12.2.5. Variable: CBARLengthMode . . . 258
2.12.2.6. Variable: CBARFixLenList . . . 259
2.12.2.7. Variable: CBARIntLenList . . . 261
2.12.2.8. Variable: CBARTransmitCheckDigit . . . 262
2.12.2.9. Variable: C39MultiRead . . . 264
2.12.2.10. Variable: C39StaStoTransmit . . . 265
2.12.2.11. Variable: C39FullASCII . . . 266
2.12.2.12. Variable: C39HexASCIIOutput . . . 268
2.12.2.13. Variable: C39CheckDigitTest . . . 269
2.12.2.14. Variable: C39LengthMode . . . 270
2.12.2.15. Variable: C39FixLenList . . . 272
2.12.2.16. Variable: C39IntLenList . . . 273
2.12.2.17. Variable: C39Code32Conversion . . . 275
2.12.2.18. Variable: C39TransmitCheckDigit . . . 276
2.12.2.19. Variable: C39ClassRestriction . . . 278
2.12.2.20. Variable: UPCEANMultiRead . . . 279
2.12.2.21. Variable: UPCEANAddOnMode . . . 280
2.12.2.22. Variable: UPCEANAddOnLength . . . 282
2.12.2.23. Variable: UPCEExtended . . . 283
2.12.2.24. Variable: EANUPCTransmitCheckDigit . . . 285
2.12.2.25. Variable: UPCENumSystem . . . 286
2.12.2.26. Variable: UPCEANStopCharacterValidation . . . 287
2.12.2.27. Variable: UPCEANStartCharacterValidation . . . 289
2.12.2.28. Variable: C25ILMultiReadL1 . . . 290
2.12.2.29. Variable: C25ILMultiReadL2 . . . 291

© SICK AG - Germany - All rights reserved

2.12.2.30. Variable: C25ILMultiReadL3 . . . 293
2.12.2.31. Variable: C25ILMultiReadL4 . . . 294
2.12.2.32. Variable: C25ILMultiReadL5 . . . 295
2.12.2.33. Variable: C25ILCheckDigitTestL1 . . . 297
2.12.2.34. Variable: C25ILCheckDigitTestL2 . . . 298
2.12.2.35. Variable: C25ILCheckDigitTestL3 . . . 300
2.12.2.36. Variable: C25ILCheckDigitTestL4 . . . 301
2.12.2.37. Variable: C25ILCheckDigitTestL5 . . . 303
2.12.2.38. Variable: C25ILLengthMode . . . 304
2.12.2.39. Variable: C25ILFixLenList . . . 306
2.12.2.40. Variable: C25ILIntLenList . . . 307
2.12.2.41. Variable: C25ILClassRestriction . . . 309
2.12.2.42. Variable: C25ILTransmitCheckDigit . . . 310
2.12.2.43. Variable: C25ILStopCharacterValidation . . . 311
2.12.2.44. Variable: C25ILStartCharacterValidation . . . 313
2.12.2.45. Variable: C25ILSingleErrorCorrection . . . 314
2.12.2.46. Variable: C25ILQuietZoneVerification . . . 315
2.12.2.47. Variable: C93MultiRead . . . 317
2.12.2.48. Variable: C93LengthMode . . . 318
2.12.2.49. Variable: C93FixLenList . . . 319
2.12.2.50. Variable: C93IntLenList . . . 321
2.12.2.51. Variable: C93HexASCIIOutput . . . 322
2.12.2.52. Variable: C128MultiRead . . . 324
2.12.2.53. Variable: C128CheckDigitTestL1 . . . 325
2.12.2.54. Variable: C128CheckDigitTestL2 . . . 327
2.12.2.55. Variable: C128CheckDigitTestL3 . . . 328
2.12.2.56. Variable: C128CheckDigitTestL4 . . . 330
2.12.2.57. Variable: C128CheckDigitTestL5 . . . 331
2.12.2.58. Variable: C128LengthMode . . . 333
2.12.2.59. Variable: C128FixLenList . . . 334
2.12.2.60. Variable: C128IntLenList . . . 336
2.12.2.61. Variable: C128HexASCIIOutput . . . 337
2.12.2.62. Variable: C128StopCharacterValidation . . . 339
2.12.2.63. Variable: C128StartCharacterValidation . . . 340
2.12.2.64. Variable: C128SingleErrorCorrection . . . 341
2.12.2.65. Variable: EAN128FirstFC1Val . . . 343
2.12.2.66. Variable: EAN128InsideFC1Val . . . 344
2.12.2.67. Variable: PharmaActive . . . 346
2.12.2.68. Variable: PharmMultiRead . . . 347
2.12.2.69. Variable: PharmModuleWidthMode . . . 348
2.12.2.70. Variable: PharmModuleWidthUserDefined . . . 350
2.12.2.71. Variable: PharmLengthMode . . . 351

© SICK AG - Germany - All rights reserved

2.12.2.72. Variable: PharmLength . . . 353
2.12.2.73. Variable: PharmReverse . . . 354
2.12.2.74. Variable: PharmCheckBarGapActive . . . 355
2.12.2.75. Variable: PharmBarSizeMin . . . 357
2.12.2.76. Variable: PharmBarSizeMax . . . 358
2.12.2.77. Variable: PharmGapSizeMin . . . 360
2.12.2.78. Variable: PharmGapSizeMax . . . 361
2.12.2.79. Variable: PharmLimitTolSize . . . 363
2.12.2.80. Variable: Pharm2DigitsEnable . . . 364
2.12.2.81. Variable: PharmQuietzoneCheckEnable . . . 366
2.12.2.82. Variable: PharmAddQuietZoneFact . . . 367
2.12.2.83. Variable: PharmDensityQuietZone . . . 368
2.12.2.84. Variable: PharmMinPercUndisturbedQuietZoneScans . . . 370
2.12.2.85. Variable: PharmDecimalOutput . . . 371
2.12.2.86. Variable: EnableSMARTDecoder . . . 373
2.12.2.87. Variable: ExtendedSegmentation . . . 374
2.12.2.88. Variable: UPCAActive . . . 376
2.12.2.89. Variable: EAN128Active . . . 377
2.12.2.90. Variable: C25ILActive . . . 378
2.12.2.91. Variable: C39Active . . . 380
2.12.2.92. Variable: EAN8Active . . . 381
2.12.2.93. Variable: UPCEANActive . . . 382
2.12.2.94. Variable: C93Active . . . 384
2.12.2.95. Variable: UPCEActive . . . 385
2.12.2.96. Variable: CBARActive . . . 386
2.12.2.97. Variable: EAN13Active . . . 388
2.12.2.98. Variable: C128Active . . . 389
2.12.2.99. Variable: C128FamiliyActive . . . 390
2.12.3. Group: Decoding1DPostCodes . . . 392
2.12.3.1. Variable: PostCodeActive . . . 392
2.12.3.2. Variable: PostCodesDependentSymbology . . . 393
2.12.3.3. Variable: PostCodeDPI . . . 395
2.12.3.4. Variable: PostCodesOrientation . . . 396
2.12.3.5. Variable: PostCodeKixLengthMode . . . 398
2.12.3.6. Variable: PostCodeKixFixLenList . . . 399
2.12.3.7. Variable: PostCodeKixIntLenList . . . 401
2.12.3.8. Variable: PostCodeRMMailmarkActive . . . 402
2.12.3.9. Variable: PostCodeRMMailmarkLengthMode . . . 404
2.12.3.10. Variable: PostCodeRMMailmarkFixLenList . . . 405
2.12.3.11. Variable: PostCodeRMMailmarkIntLenList . . . 407
2.12.3.12. Variable: PostCodeRMRM4SCCActive . . . 408
2.12.3.13. Variable: PostCodeRMRM4SCCLengthMode . . . 410

© SICK AG - Germany - All rights reserved

2.12.3.14. Variable: PostCodeRMRM4SCCFixLenList 411
2.12.3.15. Variable: PostCodeRMRM4SCCIntLenList 413
2.12.3.16. Variable: PostCodeRMInfomailActive 414
2.12.3.17. Variable: PostCodeRMInfomailLengthMode 416
2.12.3.18. Variable: PostCodeRMInfomailFixLenList 417
2.12.3.19. Variable: PostCodeRMInfomailIntLenList 419
2.12.3.20. Variable: PostCodeRMPostSingaporeActive 420
2.12.3.21. Variable: PostCodeRMPostSingaporeLengthMode 422
2.12.3.22. Variable: PostCodeRMPostSingaporeFixLenList 423
2.12.3.23. Variable: PostCodeRMPostSingaporeIntLenList 425
2.12.3.24. Variable: PostCodePostJapanLengthMode 426
2.12.3.25. Variable: PostCodePostJapanFixLenList 428
2.12.3.26. Variable: PostCodePostJapanIntLenList 429
2.12.3.27. Variable: PostCodePostAustraliaLengthMode 431
2.12.3.28. Variable: PostCodePostAustraliaFixLenList 432
2.12.3.29. Variable: PostCodePostAustraliaIntLenList 434
2.12.3.30. Variable: PostCodePostAustraliaAllowZeroFCC 435
2.12.3.31. Variable: PostCodeUSPPostNetActive 437
2.12.3.32. Variable: PostCodeUSPPostNetAllowBnBFields 438
2.12.3.33. Variable: PostCodeUSPPlanetActive 439
2.12.3.34. Variable: PostCodeUSPLengthMode 441
2.12.3.35. Variable: PostCodeUSPFixLenList 442
2.12.3.36. Variable: PostCodeUSPIntLenList 444
2.12.3.37. Variable: PostCodeUSPUPUActive 445
2.12.3.38. Variable: PostCodeUSPUPULengthMode 447
2.12.3.39. Variable: PostCodeUSPUPUFixLenList 448
2.12.3.40. Variable: PostCodeUSPUPUIntLenList 450
2.12.3.41. Variable: PostCodeUSPUsps4StateActive 451
2.12.3.42. Variable: PostCodeUSPUsps4StateLengthMode 453
2.12.3.43. Variable: PostCodeUSPUsps4StateFixLenList 454
2.12.3.44. Variable: PostCodeUSPUsps4StateIntLenList 456
2.12.3.45. Variable: PostCodePostSwedenLengthMode 457
2.12.3.46. Variable: PostCodePostSwedenFixLenList 459
2.12.3.47. Variable: PostCodePostSwedenIntLenList 460
2.12.3.48. Variable: PostCodeRawBarOutput2StateActive 462
2.12.3.49. Variable: PostCodeRawBarOutput2StateLengthMode 463
2.12.3.50. Variable: PostCodeRawBarOutput2StateFixLenList 465
2.12.3.51. Variable: PostCodeRawBarOutput2StateIntLenList 466
2.12.3.52. Variable: PostCodeRawBarOutput4StateActive 468
2.12.3.53. Variable: PostCodeRawBarOutput4StateLengthMode 469
2.12.3.54. Variable: PostCodeRawBarOutput4StateFixLenList 471
2.12.3.55. Variable: PostCodeRawBarOutput4StateIntLenList 472

© SICK AG - Germany - All rights reserved

2.12.4. Group: DecodingPostCodes 474
2.12.4.1. Variable: SwiftPostCodeRMMailmarkActive 474
2.12.4.2. Variable: SwiftPostCodeRMRM4SCCActive 475
2.12.4.3. Variable: SwiftPostCodeRMInfomailActive 477
2.12.4.4. Variable: SwiftPostCodeUSPPostNetActive 478
2.12.4.5. Variable: SwiftPostCodeUSPPlanetActive 479
2.12.4.6. Variable: SwiftPostCodeUSPUPUActive 481
2.12.4.7. Variable: SwiftPostCodeUSPUsps4StateActive 482
2.12.5. Group: Decoding1DPlessey 484
2.12.5.1. Variable: PlesseyActive 484
2.12.5.2. Variable: PlesseyMultiRead 485
2.12.5.3. Variable: PlesseyTransmitCheckDigit 487
2.12.5.4. Variable: PlesseyLengthMode 488
2.12.5.5. Variable: PlesseyFixLenList 489
2.12.5.6. Variable: PlesseyIntLenList 491
2.12.6. Group: Decoding1DMSIPlessey 493
2.12.6.1. Variable: MSIPlesseyActive 493
2.12.6.2. Variable: MSIPlesseyMultiRead 494
2.12.6.3. Variable: MSIPlesseyCheckDigitTest 496
2.12.6.4. Variable: MSIPlesseyTransmitCheckDigit 497
2.12.6.5. Variable: MSIPlesseyLengthMode 498
2.12.6.6. Variable: MSIPlesseyFixLenList 500
2.12.6.7. Variable: MSIPlesseyIntLenList 501
2.12.7. Group: Decoding1DTelepen 503
2.12.7.1. Variable: TelepenActive 503
2.12.7.2. Variable: TelepenMultiRead 504
2.12.7.3. Variable: TelepenMode 506
2.12.7.4. Variable: TelepenTransmitCheckDigit 507
2.12.7.5. Variable: TelepenLengthMode 509
2.12.7.6. Variable: TelepenFixLenList 510
2.12.7.7. Variable: TelepenIntLenList 512
2.12.8. Group: Decoding1DGS1DataBar 514
2.12.8.1. Variable: GS1DataBarActive 514
2.12.8.2. Variable: GS114Enabled 515
2.12.8.3. Variable: GS1ExpandedEnabled 517
2.12.8.4. Variable: GS1LimitedEnabled 518
2.12.8.5. Variable: GS1DataBarStackedCodesActive 519
2.12.8.6. Variable: GS1MultiRead 521
2.12.8.7. Variable: GS12DComponentMode 522
2.12.8.8. Variable: GS1HexASCIIOutput 523
2.12.8.9. Variable: GS1EmulationEnabled 525
2.12.8.10. Variable: GS1FixLenList 526

© SICK AG - Germany - All rights reserved

2.12.8.11. Variable: GS1IntLenList . . . 528
2.12.8.12. Variable: GS1Min3AdjacentSegments . . . 529
2.12.8.13. Variable: GS1ModuleWidthTolerance . . . 531
2.12.8.14. Variable: GS1NorcaOutputVerifier . . . 532
2.12.8.15. Variable: GS1NorcaIssueUndecodableSymbols . . . 534
2.12.9. Group: Decoding1DVerifier . . . 536
2.12.9.1. Variable: Code1DVerISO15416 . . . 536
2.13. Interface Block: GeneralCfgDecoding2DBase . . . 538
2.13.1. Group: Decoding2DGeneral . . . 538
2.13.1.1. Variable: CodeContrast2D . . . 538
2.13.1.2. Variable: MinModuleSize2DMM . . . 539
2.13.1.3. Variable: CodeBackground2D . . . 541
2.13.1.4. Variable: MaxModuleSize2DMM . . . 542
2.13.2. Group: DecodingDataMatrix . . . 544
2.13.2.1. Variable: DataMatrixErrorCorr . . . 544
2.13.2.2. Variable: DataMatrixDilateFilterSize . . . 545
2.13.2.3. Variable: DataMatrixErodeFilterSize . . . 547
2.13.2.4. Variable: DataMatrixDilateErodeWith2ndValue . . . 548
2.13.2.5. Variable: DataMatrixWeakBitsEnabled . . . 550
2.13.2.6. Variable: DataMatrixPositiveDifferenceAllowed . . . 551
2.13.2.7. Variable: DataMatrixNegativeDifferenceAllowed . . . 552
2.13.2.8. Variable: DataMatrixNumWeakBitErrorBitsAllowed . . . 554
2.13.2.9. Variable: DataMatrixWeakBitTreshhold . . . 555
2.13.2.10. Variable: DataMatrixTolerateErrorsInLPattern . . . 556
2.13.2.11. Variable: DataMatrixTolerateErrorsInTimingPattern . . . 558
2.13.2.12. Variable: DataMatrixEnableSpeedOptimization . . . 559
2.13.2.13. Variable: DataMatrixCheckSimpleLPatterns . . . 560
2.13.2.14. Variable: DataMatrixTolerateLPatternDeformation . . . 562
2.13.2.15. Variable: DataMatrixEnablePCBSpeedUp . . . 563
2.13.2.16. Variable: DataMatrixEnableTextSpeedUp . . . 564
2.13.2.17. Variable: DataMatrixRedundantCodes . . . 566
2.13.2.18. Variable: DataMatrixEnableNewSeg . . . 567
2.13.2.19. Variable: DataMatrixNewSegAllowSingleTiles . . . 569
2.13.2.20. Variable: DataMatrixFPGASpeedup . . . 570
2.13.2.21. Variable: DataMatrixMinModuleSize100 . . . 572
2.13.2.22. Variable: DataMatrixFormatMode . . . 573
2.13.2.23. Variable: DataMatrixGS1FirstCharReplacement . . . 575
2.13.2.24. Variable: DataMatrixGS1SeparatorCharReplacement . . . 576
2.13.2.25. Variable: DataMatrixGS1AIMarking . . . 578
2.13.2.26. Variable: DataMatrixVerISO16022 . . . 579
2.13.2.27. Variable: DataMatrixVerISO15415 . . . 580
2.13.2.28. Variable: DataMatrixFullRescan . . . 582

© SICK AG - Germany - All rights reserved

2.13.2.29. Variable: DataMatrixRescanTPattern . . . 583
2.13.2.30. Variable: DataMatrixDefectCorrection . . . 584
2.13.2.31. Variable: DataMatrixGeoEstimation . . . 586
2.13.2.32. Variable: DataMatrixConstructiveGrid . . . 587
2.13.2.33. Variable: DataMatrixFilterSamplePoints . . . 588
2.13.2.34. Variable: DataMatrixExcludeCodeAreas . . . 590
2.13.2.35. Variable: DataMatrixDotActive . . . 591
2.13.2.36. Variable: DataMatrixDotPolarity . . . 592
2.13.2.37. Variable: DataMatrixDotIntegralBlobSearch . . . 594
2.13.2.38. Variable: DataMatrixDotBlobSensitivity . . . 595
2.13.2.39. Variable: DataMatrixDotFilterBlobSearch . . . 596
2.13.2.40. Variable: DataMatrixDotDiameter . . . 598
2.13.2.41. Variable: DataMatrixDotSymbolGeometry . . . 599
2.13.2.42. Variable: DataMatrixLengthMode . . . 600
2.13.2.43. Variable: DataMatrixActive . . . 602
2.13.2.44. Variable: DataMatrixFixLenList . . . 603
2.13.2.45. Variable: DataMatrixAggressivityLevel . . . 607
2.13.2.46. Variable: DataMatrixAllowRect . . . 608
2.13.3. Group: DecodingPDF417 . . . 610
2.13.3.1. Variable: PDF417Active . . . 610
2.13.3.2. Variable: PDF417Truncated . . . 611
2.13.3.3. Variable: PDF417DecodingLevel . . . 613
2.13.4. Group: DecodingMaxiCode . . . 615
2.13.4.1. Variable: MaxiCodeActive . . . 615
2.13.4.2. Variable: MaxiCodePrimaryMessage . . . 616
2.13.4.3. Variable: MaxiCodeVerifierEnable . . . 618
2.13.4.4. Variable: MaxiCodeMode2Active . . . 619
2.13.4.5. Variable: MaxiCodeMode6Active . . . 620
2.13.4.6. Variable: MaxiCodeMode4Active . . . 622
2.13.4.7. Variable: MaxiCodeMode5Active . . . 623
2.13.4.8. Variable: MaxiCodeMode3Active . . . 624
2.13.5. Group: DecodingQRCode . . . 626
2.13.5.1. Variable: QRCodeActive . . . 626
2.13.5.2. Variable: QRMode . . . 627
2.13.5.3. Variable: QRLengthMode . . . 629
2.13.5.4. Variable: QRFixLenList . . . 630
2.13.5.5. Variable: QRVerISO18004 . . . 633
2.13.5.6. Variable: QRDecodingLevel . . . 634
2.13.5.7. Variable: QRFormatMode . . . 636
2.13.5.8. Variable: QRGS1FirstCharReplacement . . . 637
2.13.5.9. Variable: QRGS1SeparatorCharReplacement . . . 638
2.13.5.10. Variable: QRGS1AIMarking . . . 640

© SICK AG - Germany - All rights reserved

2.13.6. Group: VerificationAimDpm . . . 642
2.13.6.1. Variable: AimDpmActive . . . 642
2.13.6.2. Variable: AimDpmCalibratedGain . . . 643
2.13.6.3. Variable: AimDpmCalibratedMaxReflectance . . . 645
2.13.6.4. Variable: AimDpmCalibratedMeanReflectance . . . 646
2.13.6.5. Method: StartAimDpmCalib . . . 648
2.13.6.6. Method: CancelAimDpmCalib . . . 649
2.13.6.7. Method: FinishAimDpmCalib . . . 650
2.13.7. Group: DPMGeneral . . . 651
2.13.7.1. Variable: DPMCodeTypeChoice . . . 651
2.13.8. Group: DPMDataMatrix . . . 653
2.13.8.1. Variable: DPMDataMatrixActive . . . 653
2.13.8.2. Variable: DPMDataMatrixDecodingLevel . . . 654
2.13.8.3. Variable: DPMDataMatrixTimeout . . . 656
2.13.8.4. Variable: DPMDataMatrixNumCodes . . . 657
2.13.8.5. Variable: DPMDataMatrixFixedNumCodes . . . 658
2.13.8.6. Variable: DPMDataMatrixMinCellSize . . . 660
2.13.8.7. Variable: DPMDataMatrixMaxCellSize . . . 661
2.13.8.8. Variable: DPMDataMatrixMinNumRows . . . 662
2.13.8.9. Variable: DPMDataMatrixMaxNumRows . . . 664
2.13.8.10. Variable: DPMDataMatrixMinNumCols . . . 666
2.13.8.11. Variable: DPMDataMatrixMaxNumCols . . . 668
2.13.8.12. Variable: DPMDataMatrixAllowRectangular . . . 670
2.13.8.13. Variable: DPMDataMatrixGeometricDistortion . . . 672
2.13.8.14. Variable: DPMDataMatrixCodeDirection . . . 673
2.13.8.15. Variable: DPMDataMatrixCodeContrast . . . 675
2.13.8.16. Variable: DPMDataMatrixCodeBackground . . . 676
2.13.8.17. Variable: DPMDataMatrixSmallCells . . . 678
2.13.8.18. Variable: DPMDataMatrixMaxSkew . . . 679
2.13.8.19. Variable: DPMDataMatrixMinGapRow . . . 680
2.13.8.20. Variable: DPMDataMatrixMaxGapRow . . . 682
2.13.8.21. Variable: DPMDataMatrixMinGapCol . . . 683
2.13.8.22. Variable: DPMDataMatrixMaxGapCol . . . 685
2.13.8.23. Variable: DPMDataMatrixFinderPatternTolerance . . . 686
2.13.8.24. Variable: DPMDataMatrixContrastTolerance . . . 688
2.13.9. Group: DPMQR . . . 690
2.13.9.1. Variable: DPMQRModelType . . . 690
2.13.9.2. Variable: DPMQRVersionMin . . . 691
2.13.9.3. Variable: DPMQRVersionMax . . . 694
2.13.10. Group: DotCodeTobacco . . . 697
2.13.10.1. Variable: DotCodeTobaccoActive . . . 697
2.13.10.2. Variable: DotCodeTobaccoOrientation . . . 698

© SICK AG - Germany - All rights reserved

2.13.10.3. Variable: DotCodeTobaccoDotDiameter . . . 700
2.13.10.4. Variable: DotCodeTobaccoWidth . . . 701
2.13.10.5. Variable: DotCodeTobaccoHeight . . . 702
2.13.10.6. Variable: DotCodeTobaccoBlurWindow . . . 704
2.13.10.7. Variable: DotCodeTobaccoSauvolaWindow . . . 705
2.13.10.8. Variable: DotCodeTobaccoSauvolaK . . . 706
2.13.10.9. Variable: DotCodeTobaccoSauvolaR . . . 708
2.13.10.10. Variable: DotCodeTobaccoCloseDiagonal . . . 709
2.13.10.11. Variable: DotCodeTobaccoCloseX . . . 710
2.13.10.12. Variable: DotCodeTobaccoCloseY . . . 712
2.13.10.13. Variable: DotCodeTobaccoDeviationLengthX . . . 713
2.13.10.14. Variable: DotCodeTobaccoDeviationLengthY . . . 714
2.14. Interface Block: GeneralCfgOCR . . . 716
2.14.1. Group: OCRGeneral . . . 716
2.14.1.1. Variable: OCRActive . . . 716
2.14.1.2. Variable: OCRRegionReferenceMode . . . 717
2.14.1.3. Variable: OCRRegion . . . 719
2.14.1.4. Variable: OCRReferenceCodeRegion . . . 720
2.14.1.5. Variable: OCRReferencePatternRegion . . . 722
2.14.1.6. Variable: OCRReferencePatternExclusionRegions . . . 723
2.14.1.7. Variable: OCRPreprocessMode . . . 724
2.14.1.8. Variable: OCRRegionFinderDoTraining . . . 726
2.14.1.9. Variable: OCRShowScores . . . 727
2.14.1.10. Variable: OCRDiagLevel . . . 729
2.14.1.11. Method: OCRPushParams . . . 730
2.14.1.12. Method: OCRPopParams . . . 731
2.14.1.13. Method: RequestOCRInformation . . . 732
2.14.2. Group: OCR3 . . . 734
2.14.2.1. Variable: OCR3AbortTime_ms . . . 734
2.14.2.2. Variable: OCR3UseFullReader . . . 735
2.14.2.3. Variable: OCR3DoRowFind . . . 737
2.14.2.4. Variable: OCR3NumRows . . . 738
2.14.2.5. Variable: OCR3DoTraining . . . 739
2.14.2.6. Variable: OCR3DontUseHW . . . 741
2.14.2.7. Variable: OCR3DoDeslant . . . 742
2.14.2.8. Variable: OCR3SlantAngleInDegrees . . . 744
2.14.2.9. Variable: OCR3FieldingMode . . . 745
2.14.2.10. Variable: OCR3Classifier . . . 746
2.14.2.11. Variable: OCR3UseAlternateScore . . . 748
2.14.2.12. Variable: OCR3SubstituteCharacter . . . 749
2.14.2.13. Variable: OCR3UseIdealCharacter . . . 750
2.14.2.14. Variable: OCR3IdealCharacterIndices . . . 752

© SICK AG - Germany - All rights reserved

2.14.2.15. Variable: OCR3RowConfigArray . . . 753
2.14.2.16. Variable: OCR3EdgeWidth . . . 755
2.14.2.17. Variable: OCR3NumBlocks . . . 757
2.14.2.18. Variable: OCR3ThresholdGain . . . 758
2.14.2.19. Variable: OCR3ThresholdOffset . . . 760
2.14.2.20. Variable: OCR3RowConfigExArray . . . 761
2.14.2.21. Method: OCR3DeleteFont . . . 766
2.14.2.22. Method: OCR3SetFielding . . . 767
2.14.2.23. Method: OCR3OCVInput . . . 768
2.14.2.24. Method: OCR3GetCharInfo . . . 769
2.14.2.25. Method: OCR3DeleteChar . . . 771
2.14.2.26. Method: OCR3ResetCharStatistics . . . 772
2.14.2.27. Event: OCR3CharStatistics . . . 773
2.15. Interface Block: GeneralCfgObjAdminBase . . . 774
2.15.1. Group: TrackingBase . . . 774
2.15.1.1. Variable: TrackingMode . . . 774
2.15.1.2. Variable: TrackingTimeOut . . . 775
2.15.1.3. Variable: ObjectReleasePoint . . . 777
2.15.1.4. Variable: UseReleaseDelayTime . . . 778
2.15.1.5. Variable: ReleaseDelayTime . . . 779
2.15.1.6. Variable: LabelAssTol . . . 781
2.15.1.7. Variable: LabelAssMax . . . 782
2.15.1.8. Variable: LabelAssFix . . . 783
2.15.1.9. Variable: AssignmentMode . . . 785
2.15.1.10. Variable: MinTolerance3D . . . 786
2.15.1.11. Variable: MaxTolerance3D . . . 787
2.15.1.12. Variable: StartOfAssignment . . . 789
2.15.2. Group: OutputTimingBase . . . 791
2.15.2.1. Variable: OutputTimingControl . . . 791
2.15.2.2. Variable: OPSendPointTracking . . . 792
2.15.2.3. Variable: OPCondASAPenum . . . 794
2.15.2.4. Variable: OPCondASAPstruct . . . 795
2.15.2.5. Variable: OutputSendingPointReference . . . 797
2.15.2.6. Variable: OutputSendingPointDistance . . . 798
2.15.2.7. Variable: OutputSendingPointTime . . . 799
2.15.2.8. Variable: OutputDelayTime . . . 801
2.15.2.9. Variable: OutputDelayTrack . . . 802
2.15.2.10. Variable: TimeoutTime . . . 803
2.15.2.11. Variable: TimeoutTrack . . . 805
2.15.2.12. Variable: ASAPLabelTimoutTrack . . . 806
2.15.2.13. Variable: ASAPConditionTimoutTrack . . . 807
2.15.2.14. Variable: CodeFilterDepth . . . 809

© SICK AG - Germany - All rights reserved

2.15.2.15. Variable: LabelTimoutTimeActive . . . 810
2.15.2.16. Variable: LabelTimoutTime . . . 811
2.15.2.17. Variable: LabelTimoutTrack . . . 813
2.15.2.18. Variable: SlaveTimeoutTime . . . 814
2.15.2.19. Variable: SlaveTimeoutTrack . . . 815
2.15.2.20. Variable: OPSendPointNonTracking . . . 817
2.15.2.21. Variable: ASAPConditionTimoutTime . . . 818
2.15.2.22. Variable: ASAPLabelTimoutTime . . . 819
2.15.2.23. Variable: OutputOutputMode . . . 821
2.15.3. Group: OutputFormattingBase . . . 823
2.15.3.1. Variable: HeartbeatString . . . 823
2.15.3.2. Variable: OFEmbodimentMode . . . 824
2.15.3.3. Variable: OFTemplateString1Maximized . . . 826
2.15.3.4. Variable: OFTemplateString2Maximized . . . 827
2.15.3.5. Variable: OFTemplateStringFixString1 . . . 828
2.15.3.6. Variable: OFTemplateStringFixString2 . . . 830
2.15.3.7. Variable: OFTemplateStringFixString3 . . . 831
2.15.3.8. Variable: OFTemplateString1 . . . 832
2.15.3.9. Variable: OFTemplateString2 . . . 834
2.15.4. Group: OutputFormattingScript . . . 836
2.15.4.1. Variable: OFUsageMode2 . . . 836
2.15.5. Group: SorterFilterBase . . . 838
2.15.5.1. Variable: SFStructure1 . . . 838
2.15.5.2. Variable: SFStructure2 . . . 839
2.15.5.3. Variable: SFParameter . . . 841
2.15.6. Group: EvalConditions . . . 843
2.15.6.1. Variable: EVMainGoodReadStruct . . . 843
2.15.6.2. Variable: EVMinNbrCodes . . . 844
2.15.6.3. Variable: EVCheckMinNbr . . . 846
2.15.6.4. Variable: EVMaxNbrCodes . . . 847
2.15.6.5. Variable: EVCheckMaxNbr . . . 849
2.15.6.6. Variable: EVUserDefCondtionNames . . . 850
2.15.6.7. Variable: EVCondtionDiag . . . 852
2.15.6.8. Variable: EVRebootOnNoreadEnable . . . 854
2.15.6.9. Variable: EVRebootOnNoreadCntr . . . 855
2.15.6.10. Variable: EVCondtions . . . 857
2.15.6.11. Variable: EVCondtionNames . . . 859
2.15.6.12. Method: EVSetMatchCode . . . 860
2.15.6.13. Method: mSetMatch . . . 861
2.15.6.14. Method: mGetMatch . . . 863
2.15.7. Group: CodePosCompare . . . 865
2.15.7.1. Variable: CPUseComparison . . . 865

© SICK AG - Germany - All rights reserved

2.15.7.2. Variable: CPCodeDistance . . . 866
2.15.7.3. Variable: CPCompareDeviceID . . . 868
2.16. Interface Block: ExtDataString . . . 870
2.16.1. Group: ExternalDataInput . . . 870
2.16.1.1. Variable: ExtDataStringDefault . . . 870
2.17. Interface Block: GeneralCfgCAN1Base . . . 872
2.17.1. Group: CAN1BusBase . . . 872
2.17.1.1. Variable: CAN1Baudrate . . . 872
2.17.1.2. Variable: CAN1Format . . . 873
2.17.1.3. Variable: CAN1DigOutputPdoId . . . 875
2.17.1.4. Variable: CAN1DigOutputPdoEna . . . 876
2.17.1.5. Variable: CAN1DigInputPdoId . . . 878
2.17.1.6. Variable: CAN1DigInputMask . . . 879
2.17.1.7. Variable: CAN1HBEna . . . 881
2.17.1.8. Variable: CAN1HBInterval . . . 882
2.17.1.9. Variable: CAN1RetrHB . . . 883
2.17.1.10. Variable: CAN1UsrIOEna . . . 885
2.17.1.11. Variable: CAN1UserInpPdoId . . . 886
2.17.1.12. Variable: CAN1UserInpByteNum . . . 888
2.17.1.13. Variable: CAN1UserOutpPdoId . . . 889
2.17.1.14. Variable: CAN1UserOutpByteNum . . . 890
2.17.1.15. Variable: CAN1TimeStampMode . . . 892
2.17.1.16. Variable: CAN1TimeStampPeriod . . . 893
2.17.1.17. Variable: CAN1Mode . . . 895
2.17.2. Group: CAN1BusCANopen . . . 897
2.17.2.1. Variable: CAN1ProdHbTime . . . 897
2.17.2.2. Variable: CAN1ReadResultEnable . . . 898
2.17.2.3. Variable: CAN1SendMode . . . 900
2.17.2.4. Variable: CAN1_ReadResultTimeout . . . 901
2.17.2.5. Variable: CAN1AutoSdoRelease . . . 903
2.17.2.6. Variable: CAN1PdoNum . . . 904
2.17.2.7. Variable: CAN1PdoID . . . 906
2.17.2.8. Variable: CAN1PdoTrmType . . . 907
2.17.2.9. Variable: CAN1PdoInhibitTime . . . 909
2.17.2.10. Variable: CAN1PdoEventTime . . . 910
2.17.2.11. Variable: CAN1DiagEnable . . . 911
2.17.2.12. Variable: CAN1_DiagDataTimeout . . . 913
2.17.2.13. Variable: CAN1CmdRespEnable . . . 914
2.17.2.14. Variable: CAN1_CmdResponseTimeout . . . 916
2.17.2.15. Variable: CAN1EmcyID . . . 917
2.17.2.16. Variable: CAN1EmcyInhibitTime . . . 919
2.17.3. Group: CAN1BusTPDO . . . 921

© SICK AG - Germany - All rights reserved

2.17.3.1. Variable: C1_TPDO1_MapNum . . . 921
2.17.3.2. Variable: C1_TPDO1_MapObjs . . . 922
2.17.3.3. Variable: C1_TPDO1_PreConnSet . . . 925
2.17.3.4. Variable: C1_TPDO1_CobId . . . 926
2.17.3.5. Variable: C1_TPDO1_TrmType . . . 928
2.17.3.6. Variable: C1_TPDO1_InhibtTime . . . 929
2.17.3.7. Variable: C1_TPDO1_EventTime . . . 930
2.17.3.8. Variable: C1_TPDO2_MapNum . . . 932
2.17.3.9. Variable: C1_TPDO2_MapObjs . . . 933
2.17.3.10. Variable: C1_TPDO2_PreConnSet . . . 936
2.17.3.11. Variable: C1_TPDO2_CobId . . . 937
2.17.3.12. Variable: C1_TPDO2_TrmType . . . 938
2.17.3.13. Variable: C1_TPDO2_InhibtTime . . . 940
2.17.3.14. Variable: C1_TPDO2_EventTime . . . 941
2.17.3.15. Variable: C1_TPDO3_MapNum . . . 942
2.17.3.16. Variable: C1_TPDO3_MapObjs . . . 944
2.17.3.17. Variable: C1_TPDO3_PreConnSet . . . 946
2.17.3.18. Variable: C1_TPDO3_CobId . . . 948
2.17.3.19. Variable: C1_TPDO3_TrmType . . . 949
2.17.3.20. Variable: C1_TPDO3_InhibtTime . . . 950
2.17.3.21. Variable: C1_TPDO3_EventTime . . . 952
2.17.3.22. Variable: C1_TPDO4_MapNum . . . 953
2.17.3.23. Variable: C1_TPDO4_MapObjs . . . 954
2.17.3.24. Variable: C1_TPDO4_PreConnSet . . . 957
2.17.3.25. Variable: C1_TPDO4_CobId . . . 958
2.17.3.26. Variable: C1_TPDO4_TrmType . . . 960
2.17.3.27. Variable: C1_TPDO4_InhibtTime . . . 961
2.17.3.28. Variable: C1_TPDO4_EventTime . . . 962
2.17.4. Group: CAN1BusRPDO . . . 964
2.17.4.1. Variable: C1_RPDO1_MapNum . . . 964
2.17.4.2. Variable: C1_RPDO1_MapObjs . . . 965
2.17.4.3. Variable: C1_RPDO1_PreConnSet . . . 968
2.17.4.4. Variable: C1_RPDO1_CobId . . . 969
2.17.4.5. Variable: C1_RPDO1_TrmType . . . 971
2.17.4.6. Variable: C1_RPDO2_MapNum . . . 972
2.17.4.7. Variable: C1_RPDO2_MapObjs . . . 973
2.17.4.8. Variable: C1_RPDO2_PreConnSet . . . 976
2.17.4.9. Variable: C1_RPDO2_CobId . . . 977
2.17.4.10. Variable: C1_RPDO2_TrmType . . . 979
2.17.4.11. Variable: C1_RPDO3_MapNum . . . 980
2.17.4.12. Variable: C1_RPDO3_MapObjs . . . 981
2.17.4.13. Variable: C1_RPDO3_PreConnSet . . . 984

© SICK AG - Germany - All rights reserved

2.17.4.14. Variable: C1_RPDO3_CobId . . . 985
2.17.4.15. Variable: C1_RPDO3_TrmType . . . 987
2.17.4.16. Variable: C1_RPDO4_MapNum . . . 988
2.17.4.17. Variable: C1_RPDO4_MapObjs . . . 989
2.17.4.18. Variable: C1_RPDO4_PreConnSet . . . 992
2.17.4.19. Variable: C1_RPDO4_CobId . . . 993
2.17.4.20. Variable: C1_RPDO4_TrmType . . . 995
2.18. Interface Block: GeneralCfgSerialBase . . . 997
2.18.1. Group: SerialBase . . . 997
2.18.1.1. Variable: SerHostProtocol . . . 997
2.18.1.2. Variable: SerHostMultiplex . . . 998
2.18.1.3. Variable: SerHostBaudrate . . . 1000
2.18.1.4. Variable: SerHostStopbits . . . 1001
2.18.1.5. Variable: SerHostParity . . . 1003
2.18.1.6. Variable: SerHostHardware . . . 1004
2.18.1.7. Variable: SerHostEnHB . . . 1006
2.18.1.8. Variable: SerHostHBInterval . . . 1007
2.18.1.9. Variable: SerHostRetrHB . . . 1008
2.18.1.10. Variable: SerAuxProtocol . . . 1010
2.18.1.11. Variable: SerAuxBaudrate . . . 1011
2.18.1.12. Variable: SerAuxStopbits . . . 1013
2.18.1.13. Variable: SerAuxParity . . . 1014
2.18.1.14. Variable: SerAuxHardware . . . 1016
2.18.1.15. Variable: SerAuxEnHB . . . 1017
2.18.1.16. Variable: SerAuxHBInterval . . . 1019
2.18.1.17. Variable: SerAuxRetrHB . . . 1020
2.19. Interface Block: GeneralCfgEthernetBase . . . 1022
2.19.1. Group: EthernetBase . . . 1022
2.19.1.1. Variable: EtherIPAddress . . . 1022
2.19.1.2. Variable: EtherIPGateAddress . . . 1023
2.19.1.3. Variable: EtherIPMask . . . 1025
2.19.1.4. Variable: EtherIPSpeedDuplex . . . 1026
2.19.1.5. Variable: EtherHostProtocol . . . 1028
2.19.1.6. Variable: EtherHostFTPProtocol . . . 1029
2.19.1.7. Variable: EtherHostFTPUsername . . . 1031
2.19.1.8. Variable: EtherHostFTPPassword . . . 1032
2.19.1.9. Variable: EtherHostFTPUploadPath . . . 1033
2.19.1.10. Variable: EtherHostMultiplex . . . 1035
2.19.1.11. Variable: EtherHostServerClient . . . 1036
2.19.1.12. Variable: EtherHostIPPort . . . 1037
2.19.1.13. Variable: EtherHostIPServerAddress . . . 1039
2.19.1.14. Variable: EtherHostCoLaDialect . . . 1040

© SICK AG - Germany - All rights reserved

2.19.1.15. Variable: EtherHostEnHB . . . 1042
2.19.1.16. Variable: EtherHostHBInterval . . . 1043
2.19.1.17. Variable: EtherHostRetrHB . . . 1044
2.19.1.18. Variable: EtherAuxProtocol . . . 1046
2.19.1.19. Variable: EtherAuxIPPort . . . 1047
2.19.1.20. Variable: EtherRDTServerClient . . . 1049
2.19.1.21. Variable: EtherRDT_ID . . . 1050
2.19.1.22. Variable: EtherRDTIPPort . . . 1051
2.19.1.23. Variable: EtherRDTIPServerAddress . . . 1053
2.19.1.24. Variable: EtherMonOutputFormat1 . . . 1054
2.19.1.25. Variable: EtherMonOutputFormat2 . . . 1056
2.19.1.26. Variable: EtherMonSerAux . . . 1057
2.19.1.27. Variable: EtherMonSerHost . . . 1058
2.19.1.28. Variable: EtherMonSerAux2 . . . 1060
2.19.1.29. Variable: EtherMonSerHost2 . . . 1061
2.19.1.30. Variable: EtherMonCAN1 . . . 1062
2.19.1.31. Variable: EtherMonCAN2 . . . 1064
2.19.1.32. Variable: EtherAddressingMode . . . 1065
2.19.1.33. Variable: EtherDHCPFallback . . . 1067
2.19.1.34. Variable: EtherUpdateNeeded . . . 1068
2.19.1.35. Variable: EtherUDPIPPort . . . 1069
2.19.1.36. Variable: EtherUDPCoLaDialect . . . 1071
2.19.1.37. Method: EthernetPing . . . 1072
2.19.1.38. Method: EthernetUpdate . . . 1073
2.19.2. Group: FTPServer . . . 1075
2.19.2.1. Variable: FTPSrvEnabled . . . 1075
2.19.2.2. Variable: FTPSrvUsrPassword . . . 1076
2.19.2.3. Variable: FTPSrvUsrName . . . 1078
2.19.2.4. Variable: FTPSrvPort . . . 1079
2.19.2.5. Variable: FTPRootPath . . . 1080
2.20. Interface Block: GeneralCfgEthernet1Base . . . 1082
2.20.1. Group: Ethernet1Base . . . 1082
2.20.1.1. Variable: Ether1IPAddress . . . 1082
2.20.1.2. Variable: Ether1IPGateAddress . . . 1083
2.20.1.3. Variable: Ether1IPMask . . . 1085
2.20.1.4. Variable: Ether1IPSpeedDuplex . . . 1086
2.20.1.5. Variable: Ether1DHCPFallback . . . 1088
2.20.1.6. Variable: Ether1AddressingMode . . . 1089
2.20.1.7. Variable: Ether1AuxProtocol . . . 1090
2.20.1.8. Variable: Ether1AuxIPPort . . . 1092
2.21. Interface Block: GeneralCfgTrigCtrlBase . . . 1094
2.21.1. Group: TrigCtrlBase . . . 1094

© SICK AG - Germany - All rights reserved

2.21.1.1. Variable: TrigControl . . . 1094
2.21.1.2. Variable: TrigStartDelayTime . . . 1095
2.21.1.3. Variable: TrigStartDelayTrack . . . 1097
2.21.1.4. Variable: TrigStopTimerTime . . . 1098
2.21.1.5. Variable: TrigStopTimerTrack . . . 1099
2.21.1.6. Variable: TrigStopDelayTime . . . 1101
2.21.1.7. Variable: TrigStopDelayTrack . . . 1102
2.21.1.8. Variable: TrigAutoCyclePulseTime . . . 1103
2.21.1.9. Variable: TrigAutoCyclePauseTime . . . 1105
2.21.1.10. Variable: TrigAutoCyclePulseTrack . . . 1106
2.21.1.11. Variable: TrigAutoCyclePauseTrack . . . 1108
2.21.1.12. Variable: TrigCANSource . . . 1109
2.21.1.13. Variable: TrigDistribute . . . 1111
2.21.1.14. Variable: TrigExpansionTime . . . 1112
2.21.1.15. Variable: TrigExpansionTrack . . . 1113
2.21.1.16. Variable: TrigPreExpansionTime . . . 1115
2.21.1.17. Variable: TrigPreExpansionTrack . . . 1116
2.21.1.18. Variable: ObjTrigSource . . . 1117
2.21.1.19. Variable: MaxIndexValue . . . 1119
2.21.1.20. Variable: InvalidIndex . . . 1120
2.21.1.21. Method: ReadingGateOn . . . 1121
2.21.1.22. Method: ReadingGateOff . . . 1122
2.21.1.23. Method: ReadingGateOnDiag . . . 1123
2.21.1.24. Method: ReadingGateOffDiag . . . 1124
2.21.1.25. Method: DoDiagReading . . . 1125
2.21.1.26. Method: StartDiagReading . . . 1127
2.21.1.27. Method: EndDiagReading . . . 1128
2.22. Interface Block: GeneralCfgFileSystem2Base . . . 1129
2.22.1. Group: FileSystem2Base . . . 1129
2.22.1.1. Method: FileSystemAccess . . . 1129
2.23. Interface Block: GeneralCfgNetworkBase . . . 1131
2.23.1. Group: NetworkBase . . . 1131
2.23.1.1. Variable: NetDeviceID . . . 1131
2.23.1.2. Variable: NetMasterSlave . . . 1132
2.23.1.3. Variable: NetworkAssignment . . . 1134
2.23.1.4. Variable: NetSlaveList . . . 1135
2.23.1.5. Variable: NetMultiplexerAssignment . . . 1137
2.23.1.6. Variable: NetServerList . . . 1138
2.23.1.7. Variable: NetMonAssignment1 . . . 1139
2.23.1.8. Variable: NetMonDevList1 . . . 1141
2.23.1.9. Variable: NetMonAssignment2 . . . 1142
2.23.1.10. Variable: NetMonDevList2 . . . 1143

© SICK AG - Germany - All rights reserved

2.23.1.11. Variable: NetMonTimeout . . . 1145
2.24. Interface Block: GeneralCfgRDT400Base . . . 1147
2.24.1. Group: RDT400ConfigBase . . . 1147
2.24.1.1. Variable: RDTCTCond1Enum . . . 1147
2.24.1.2. Variable: RDTCTCond1Struct . . . 1148
2.24.1.3. Variable: RDTCTCond2Enum . . . 1150
2.24.1.4. Variable: RDTCTCond2Struct . . . 1151
2.24.1.5. Variable: RDTCTCond3Enum . . . 1152
2.24.1.6. Variable: RDTCTCond3Struct . . . 1154
2.24.1.7. Variable: RDTSendTraces . . . 1155
2.24.1.8. Variable: RDTSendCommTraces . . . 1156
2.24.1.9. Variable: RDTEnableErrors . . . 1158
2.24.1.10. Variable: RDTVMSSendTraces . . . 1159
2.24.1.11. Variable: RDTVMSSendCommTraces . . . 1161
2.24.1.12. Variable: RDTVMSEnableErrors . . . 1162
2.25. Interface Block: GeneralCfgCDFpublic . . . 1164
2.25.1. Group: CDF_Config . . . 1164
2.25.1.1. Variable: CDF_FramingHeaderInputSelect_1 . . . 1164
2.25.1.2. Variable: CDF_FramingHeaderInputSelect_2 . . . 1165
2.25.1.3. Variable: CDF_PhysOutputSelect_1 . . . 1167
2.25.1.4. Variable: CDF_PhysOutputSelect_2 . . . 1168
2.25.1.5. Variable: CDF_PhysInDebounceTime_1 . . . 1170
2.25.1.6. Variable: CDF_PhysInDebounceTime_2 . . . 1171
2.25.2. Group: CDF_IoPublic . . . 1173
2.25.2.1. Variable: CDF_PlcLogicalInputState_FH . . . 1173
2.25.2.2. Variable: CDF_PlcLogicalInputState_Map . . . 1174
2.25.2.3. Variable: CDF_SensorPhysicalOutputState . . . 1176
2.25.3. Group: CDF_ProfinetPublic . . . 1178
2.25.3.1. Variable: CdfSyncStationNameToLocationName . . . 1178
2.25.3.2. Variable: CdfCm_CDF600HS . . . 1179
2.25.3.3. Method: CdfUpDatePnConfig . . . 1181
2.26. Interface Block: System . . . 1182
2.26.1. Group: Time . . . 1182
2.26.1.1. Variable: TimeSource . . . 1182
2.26.1.2. Variable: TimeServerIPAddress . . . 1183
2.26.1.3. Variable: TimeServerIPPort . . . 1185
2.26.1.4. Variable: TimeServerIface . . . 1186
2.26.1.5. Variable: TimeZoneOffset . . . 1187
2.26.1.6. Method: GetTime . . . 1189
2.26.1.7. Method: SetTime . . . 1190
2.26.1.8. Method: ConnectTimeServer . . . 1191
2.26.2. Group: GUI . . . 1192

© SICK AG - Germany - All rights reserved

2.26.2.1. Variable: SYUIMode . . . 1192
2.26.3. Group: SDCard . . . 1194
2.26.3.1. Method: UmountSdCard . . . 1194
2.26.3.2. Method: CheckSdCard . . . 1195
2.26.3.3. Method: RepairSdCard . . . 1196
2.27. Interface Block: Calib . . . 1197
2.27.1. Group: HallSensorCalib . . . 1197
2.27.1.1. Method: StartContinuousHallSensorMeasurement . . . 1197
2.27.1.2. Method: StopHallSensorMeasurements . . . 1198
2.27.1.3. Method: StartHallSensorSingleshotMeasurement . . . 1199
2.28. Interface Block: GeneralCfgReadingStatisticBase . . . 1200
2.28.1. Group: ReadingStatisticConfigBase . . . 1200
2.28.1.1. Variable: ReadingStatisticEnabled . . . 1200
2.28.1.2. Variable: RSCTCond1Enum . . . 1201
2.28.1.3. Variable: RSCTCond1Struct . . . 1203
2.28.1.4. Variable: RSCTCond1Name . . . 1204
2.28.1.5. Variable: RSCTCond2Enum . . . 1206
2.28.1.6. Variable: RSCTCond2Struct . . . 1207
2.28.1.7. Variable: RSCTCond2Name . . . 1209
2.28.1.8. Variable: RSCTCond3Enum . . . 1210
2.28.1.9. Variable: RSCTCond3Struct . . . 1212
2.28.1.10. Variable: RSCTCond3Name . . . 1213
2.28.1.11. Method: RSClearStat . . . 1215
2.28.2. Group: ReadingStatisticFileView . . . 1216
2.28.2.1. Variable: RSRefreshRunning . . . 1216
2.28.2.2. Variable: RSRefreshTrigger . . . 1217
2.29. Interface Block: GeneralCfg . . . 1219
2.29.1. Group: DigitalOutputsEnhancements . . . 1219
2.29.1.1. Variable: Out1FuncTeachInMatchCodeEnh . . . 1219
2.29.1.2. Variable: Out2FuncTeachInMatchCodeEnh . . . 1221
2.29.1.3. Variable: Out3FuncTeachInMatchCodeEnh . . . 1222
2.29.1.4. Variable: Out4FuncTeachInMatchCodeEnh . . . 1224
2.29.1.5. Variable: ExtOut1FuncTeachInMatchCodeEnh . . . 1226
2.29.1.6. Variable: ExtOut2FuncTeachInMatchCodeEnh . . . 1227
2.29.2. Group: Serial . . . 1230
2.29.2.1. Variable: SerHostCustomProtNb . . . 1230
2.29.3. Group: Ethernet . . . 1232
2.29.3.1. Variable: EtherHostCustomProtNb . . . 1232
2.29.4. Group: FTP . . . 1234
2.29.4.1. Variable: FTPClientActive . . . 1234
2.29.4.2. Variable: FTPServerIPAddress . . . 1235
2.29.4.3. Variable: FTPServerIPPort . . . 1237

© SICK AG - Germany - All rights reserved

2.29.4.4. Variable: FTPHostname . . . 1238
2.29.4.5. Variable: FTPEthIface . . . 1239
2.29.4.6. Variable: FTPProtocol . . . 1241
2.29.4.7. Variable: FTPAuthenticationMethod . . . 1242
2.29.4.8. Variable: FTPUsername . . . 1243
2.29.4.9. Variable: FTPPassword . . . 1245
2.29.4.10. Variable: FTPPathPrivateKey . . . 1246
2.29.4.11. Variable: FTPUploadPath . . . 1247
2.29.4.12. Variable: FTPDevUpload . . . 1249
2.29.5. Group: FTPArchiv . . . 1251
2.29.5.1. Variable: FTPArchivUsername . . . 1251
2.29.5.2. Variable: FTPArchibPassword . . . 1252
2.29.5.3. Variable: FTPArchiveIPPort . . . 1254
2.29.5.4. Variable: FTPArchiveSendBufferSize . . . 1255
2.29.5.5. Variable: FTPArchiveMaxClients . . . 1256
2.29.5.6. Variable: FTPArchiveClientTimeout . . . 1258
2.29.5.7. Variable: FTPArchiveSLocalFileTimeout . . . 1259
2.29.5.8. Variable: FTPArchiveMaxNumObjects . . . 1260
2.29.6. Group: SVP . . . 1262
2.29.6.1. Variable: SVPActive . . . 1262
2.29.6.2. Variable: SVPAppSrvIPAddress . . . 1263
2.29.6.3. Variable: SVPAppSrvIPPort . . . 1265
2.29.6.4. Variable: SVPAppSrvIface . . . 1266
2.29.6.5. Variable: SVPImageTransfer . . . 1267
2.29.6.6. Variable: SVPImgSrvIPAddress . . . 1269
2.29.6.7. Variable: SVPImgSrvIPPort . . . 1270
2.29.6.8. Variable: SVPImgSrvIface . . . 1272
2.29.6.9. Variable: SVPImgSrvUsername . . . 1273
2.29.6.10. Variable: SVPImgSrvPassword . . . 1274
2.29.6.11. Variable: SVPOutputFormat . . . 1276
2.29.6.12. Variable: SVPSendOnlyErrors . . . 1277
2.29.7. Group: HTTP . . . 1279
2.29.7.1. Variable: HTWebserverEnabled . . . 1279
2.29.8. Group: Gateway . . . 1281
2.29.8.1. Variable: GatewaySerAux . . . 1281
2.29.8.2. Variable: GatewaySerHost . . . 1282
2.29.8.3. Variable: GatewayPBDevIDIsPBAdress . . . 1284
2.29.8.4. Variable: GatewayPBAddress . . . 1285
2.29.8.5. Variable: GatewayPBOpMode . . . 1287
2.29.8.6. Variable: GatewayDNAddress . . . 1288
2.29.8.7. Variable: GatewayDNDevIDIsDNAdress . . . 1290
2.29.8.8. Variable: GatewayDNOpMode . . . 1291

© SICK AG - Germany - All rights reserved

2.29.8.9. Variable: GatewayDNBaudrate . . . 1293
2.29.8.10. Variable: GatewayDNInputDataLength . . . 1294
2.29.8.11. Variable: GatewayDNOutputDataLength . . . 1296
2.29.9. Group: Profibus . . . 1298
2.29.9.1. Variable: CdfProfiCmMode . . . 1298
2.29.9.2. Variable: CdfSelectDataFormat . . . 1299
2.29.9.3. Variable: CdfCanMultiplexSend . . . 1301
2.29.9.4. Variable: Usage_CdfProfibusFhOut1 . . . 1302
2.29.9.5. Variable: Usage_CdfProfibusFhOut2 . . . 1304
2.29.9.6. Variable: Usage_CdfProfibusFhIn1 . . . 1305
2.29.9.7. Variable: Usage_CdfProfibusFhIn2 . . . 1307
2.29.10. Group: Ethercat . . . 1309
2.29.10.1. Variable: CdfEcatCmMode . . . 1309
2.29.11. Group: EthernetIP . . . 1311
2.29.11.1. Variable: EIPAct . . . 1311
2.29.11.2. Variable: EIPMode . . . 1312
2.29.11.3. Variable: EIPMultiplex . . . 1313
2.29.11.4. Variable: EIPDataFormat . . . 1315
2.29.11.5. Variable: EIPControlBitsPlcOutMask . . . 1316
2.29.11.6. Variable: EIPHBEna . . . 1317
2.29.11.7. Variable: EIPHBInterval . . . 1319
2.29.11.8. Variable: EIPRetrHB . . . 1320
2.29.11.9. Variable: EIPAssemblySizeOutput . . . 1321
2.29.11.10. Variable: EIPAssemblySizeInput . . . 1323
2.29.11.11. Variable: EIPTxBufferSize . . . 1324
2.29.12. Group: ModbusTcp . . . 1326
2.29.12.1. Variable: ModbusTcpMode . . . 1326
2.29.12.2. Variable: ModbusAddress . . . 1327
2.29.13. Group: Profinet1Port . . . 1329
2.29.13.1. Variable: PN1PortActive . . . 1329
2.29.13.2. Variable: PNAutoDetect . . . 1330
2.29.13.3. Variable: PNAutoDetectTO . . . 1331
2.29.14. Group: ExternalParameters . . . 1333
2.29.14.1. Variable: UseExtParams . . . 1333
2.29.15. Group: EthernetInterface1 . . . 1335
2.29.15.1. Variable: Ether1Enable . . . 1335
2.29.15.2. Variable: EIPInterface . . . 1336
2.29.15.3. Variable: Ether1AuxInputHandling . . . 1338
2.29.16. Group: SystemControlLector65x . . . 1340
2.29.16.1. Method: LoadApplicationDefaultsSystemSlave . . . 1340
2.29.17. Group: CDPMethods . . . 1341
2.29.17.1. Method: Method_4 . . . 1341

© SICK AG - Germany - All rights reserved

2.29.18. Group: Script 1342
2.29.18.1. Variable: EnableActiveScript 1342
2.29.18.2. Method: ScriptCommand 1343
2.29.19. Group: NetworkAddressTranslation 1345
2.29.19.1. Variable: IpAddressChoiceForImageTransmission 1345
2.29.19.2. Variable: TcpPortChoiceForImageTransmission 1346
2.29.19.3. Variable: ManualBlobIpAddress 1348
2.29.19.4. Variable: ManualBlobTcpPort 1349
2.30. Interface Block: CdpApiBlock 1351
2.30.1. Group: CdpApiVariables 1351
2.30.1.1. Variable: cdpFbCommStatusReg 1351
2.30.1.2. Variable: cdpCmdReg 1352
2.30.1.3. Variable: cdpResStatusReg 1354
2.30.1.4. Variable: cdpEndianCheck 1355
2.30.2. Group: CdpApiTracerVariables 1357
2.30.2.1. Variable: cdpApiTracerMode 1357
2.30.2.2. Variable: cdpApiTracerCommProc 1358
2.30.2.3. Variable: cdpApiTracerEnabled 1360
2.30.2.4. Variable: cdpApiTracerMaxRecords 1361
2.30.2.5. Variable: cdpApiTracerCycleThresholdUpperUs 1362
2.30.2.6. Variable: cdpApiTracerCycleThresholdLowerUs 1364
2.30.3. Group: CdpApiEvents 1366
2.30.3.1. Event: cdpApiErrorEvent 1366
2.30.3.2. Event: cdpApiWarningEvent 1366
2.30.3.3. Event: cdpApiRstToFactorySettingsEvent 1367
2.30.4. Group: CDPApiMethodes 1368
2.30.4.1. Method: cdpApiStoreParams 1368
2.30.4.2. Method: cdpApiUpDateDiagExt 1369
2.30.5. Group: CDPApiTracerMethodes 1370
2.30.5.1. Method: cdpApiRequestTracepointInfo 1370
2.30.5.2. Method: cdpApiTracerSetTPProp 1372
2.31. Interface Block: Profinet_Address_FBParam 1374
2.31.1. Group: Profinet_Address_ParamData_grp 1374
2.31.1.1. Variable: cdpPnioStationName 1374
2.31.1.2. Variable: cdpPnioIpAddressType 1375
2.31.1.3. Variable: cdpPnioIpAddress 1377
2.31.1.4. Variable: cdpPnioSubNetMaskAddr 1378
2.31.1.5. Variable: cdpPnioGateWayAddr 1380
2.31.1.6. Variable: cdpPnioPLCSetNameRemanent 1381
2.31.1.7. Variable: cdpPnioPLCSetAddrRemanent 1383
2.31.2. Group: Profinet_Address_VolatileData_grp 1385
2.31.2.1. Variable: cdpPnioDHCP_Support 1385

© SICK AG - Germany - All rights reserved

2.31.2.2. Variable: cdpPnioDHCP_Status . . . 1386
2.31.3. Group: Profinet_Address_ApplData_grp . . . 1388
2.31.3.1. Variable: cdpPnioSyncStationNameToLocationName . . . 1388
2.31.3.2. Method: cdpPnioUpDatePnConfig . . . 1389
2.32. Interface Block: Profinet_DeviceInfoFBParam . . . 1391
2.32.1. Group: Profinet_DeviceInfo_ParamData_grp . . . 1391
2.32.1.1. Variable: cdpPnioIMTagLocation . . . 1391
2.32.1.2. Variable: cdpPnioIMTagFunction . . . 1392
2.32.1.3. Variable: cdpPnioIMDate . . . 1394
2.32.1.4. Variable: cdpPnioIMDescriptor . . . 1395
2.32.1.5. Variable: cdpPnioIMSignature . . . 1396
2.32.1.6. Variable: cdpPnioEpMAnnotation . . . 1398
2.32.1.7. Variable: cdpPnioEpMOrderID . . . 1399
2.32.1.8. Variable: cdpPnioAlarmsSupported . . . 1400
2.33. Interface Block: Profinet_Diagnosis . . . 1402
2.33.1. Group: Profinet_Diagnosis_grp . . . 1402
2.33.1.1. Variable: cdpPnioStateApplication . . . 1402
2.33.1.2. Variable: cdpPnioStateCommunication . . . 1403
2.33.1.3. Variable: cdpPnioStateDeviceSummaryDiagnosis . . . 1405
2.33.1.4. Variable: cdpPnioLedStateBF . . . 1406
2.33.1.5. Variable: cdpPnioLedStateSF . . . 1408
2.33.1.6. Variable: cdpPnioStateCommunicationFSM . . . 1409
2.33.1.7. Variable: cdpPnioMibSysDesc . . . 1410
2.33.1.8. Variable: cdpPnioMibSysUpTime . . . 1412
2.33.1.9. Variable: cdpPnioMibSysContact . . . 1413
2.33.2. Group: Profinet_Diagnosis_Mib1_grp . . . 1415
2.33.2.1. Variable: cdpPnioMib1_ifNumber . . . 1415
2.33.2.2. Variable: cdpPnioMib1_ifSpeed . . . 1416
2.33.2.3. Variable: cdpPnioMib1_ifPhysAddress . . . 1418
2.33.2.4. Variable: cdpPnioMib1_ifOperStatus . . . 1419
2.33.2.5. Variable: cdpPnioMib1_ifLastChange . . . 1421
2.33.2.6. Variable: cdpPnioMib1_ifInOctets . . . 1422
2.33.2.7. Variable: cdpPnioMib1_ifInUcastPkts . . . 1423
2.33.2.8. Variable: cdpPnioMib1_ifInNUcastPkts . . . 1425
2.33.2.9. Variable: cdpPnioMib1_ifInDiscards . . . 1426
2.33.2.10. Variable: cdpPnioMib1_ifInErrors . . . 1427
2.33.2.11. Variable: cdpPnioMib1_ifOutOctets . . . 1429
2.33.2.12. Variable: cdpPnioMib1_ifOutUcastPkts . . . 1430
2.33.2.13. Variable: cdpPnioMib1_ifOutNUcastPkts . . . 1431
2.33.2.14. Variable: cdpPnioMib1_ifOutDiscards . . . 1433
2.33.2.15. Variable: cdpPnioMib1_ifOutErrors . . . 1434
2.33.3. Group: Profinet_Diagnosis_Mib1_optional_grp . . . 1436

© SICK AG - Germany - All rights reserved

2.33.3.1. Variable: cdpPnioMib1_ipInReceives . . . 1436
2.33.3.2. Variable: cdpPnioMib1_ipInHdrErrors . . . 1437
2.33.3.3. Variable: cdpPnioMib1_ipInAddrErrors . . . 1439
2.33.3.4. Variable: cdpPnioMib1_ipInDiscards . . . 1440
2.33.3.5. Variable: cdpPnioMib1_ipOutRequests . . . 1441
2.33.3.6. Variable: cdpPnioMib1_ipOutDiscards . . . 1443
2.33.3.7. Variable: cdpPnioMib1_udpInDatagrams . . . 1444
2.33.3.8. Variable: cdpPnioMib1_udpNoPorts . . . 1445
2.33.3.9. Variable: cdpPnioMib1_udpInErrors . . . 1447
2.33.3.10. Variable: cdpPnioMib1_udpOutDatagrams . . . 1448
2.33.3.11. Variable: cdpPnioMib1_tcpInSegs . . . 1449
2.33.3.12. Variable: cdpPnioMib1_tcpOutSegs . . . 1451
2.33.3.13. Variable: cdpPnioMib1_tcpRetransSegs . . . 1452
2.33.3.14. Variable: cdpPnioMib1_tcpInErrs . . . 1453
2.33.3.15. Variable: cdpPnioMib1_tcpOutRsts . . . 1455
2.33.4. Group: Profinet_Diagnosis_Mib2_grp . . . 1457
2.33.4.1. Variable: cdpPnioMib2_ifNumber . . . 1457
2.33.4.2. Variable: cdpPnioMib2_ifSpeed . . . 1458
2.33.4.3. Variable: cdpPnioMib2_ifPhysAddress . . . 1460
2.33.4.4. Variable: cdpPnioMib2_ifOperStatus . . . 1461
2.33.4.5. Variable: cdpPnioMib2_ifLastChange . . . 1463
2.33.4.6. Variable: cdpPnioMib2_ifInOctets . . . 1464
2.33.4.7. Variable: cdpPnioMib2_ifInUcastPkts . . . 1465
2.33.4.8. Variable: cdpPnioMib2_ifInNUcastPkts . . . 1467
2.33.4.9. Variable: cdpPnioMib2_ifInDiscards . . . 1468
2.33.4.10. Variable: cdpPnioMib2_ifInErrors . . . 1469
2.33.4.11. Variable: cdpPnioMib2_ifOutOctets . . . 1471
2.33.4.12. Variable: cdpPnioMib2_ifOutUcastPkts . . . 1472
2.33.4.13. Variable: cdpPnioMib2_ifOutNUcastPkts . . . 1473
2.33.4.14. Variable: cdpPnioMib2_ifOutDiscards . . . 1475
2.33.4.15. Variable: cdpPnioMib2_ifOutErrors . . . 1476
2.33.5. Group: Profinet_Diagnosis_Mib2_Optional_grp . . . 1478
2.33.5.1. Variable: cdpPnioMib2_ipInReceives . . . 1478
2.33.5.2. Variable: cdpPnioMib2_ipInHdrErrors . . . 1479
2.33.5.3. Variable: cdpPnioMib2_ipInAddrErrors . . . 1481
2.33.5.4. Variable: cdpPnioMib2_ipInDiscards . . . 1482
2.33.5.5. Variable: cdpPnioMib2_ipOutRequests . . . 1483
2.33.5.6. Variable: cdpPnioMib2_ipOutDiscards . . . 1485
2.33.5.7. Variable: cdpPnioMib2_udpInDatagrams . . . 1486
2.33.5.8. Variable: cdpPnioMib2_udpNoPorts . . . 1487
2.33.5.9. Variable: cdpPnioMib2_udpInErrors . . . 1489
2.33.5.10. Variable: cdpPnioMib2_udpOutDatagrams . . . 1490

© SICK AG - Germany - All rights reserved

2.33.5.11. Variable: cdpPnioMib2_tcpInSegs . . . 1491
2.33.5.12. Variable: cdpPnioMib2_tcpOutSegs . . . 1493
2.33.5.13. Variable: cdpPnioMib2_tcpRetransSegs . . . 1494
2.33.5.14. Variable: cdpPnioMib2_tcpInErrs . . . 1495
2.33.5.15. Variable: cdpPnioMib2_tcpOutRsts . . . 1497
2.33.6. Group: Profinet_Diagnosis_Mib3_grp . . . 1499
2.33.6.1. Variable: cdpPnioMib3_ifNumber . . . 1499
2.33.6.2. Variable: cdpPnioMib3_ifSpeed . . . 1500
2.33.6.3. Variable: cdpPnioMib3_ifPhysAddress . . . 1502
2.33.6.4. Variable: cdpPnioMib3_ifOperStatus . . . 1503
2.33.6.5. Variable: cdpPnioMib3_ifLastChange . . . 1505
2.33.6.6. Variable: cdpPnioMib3_ifInOctets . . . 1506
2.33.6.7. Variable: cdpPnioMib3_ifInUcastPkts . . . 1507
2.33.6.8. Variable: cdpPnioMib3_ifInNUcastPkts . . . 1509
2.33.6.9. Variable: cdpPnioMib3_ifInDiscards . . . 1510
2.33.6.10. Variable: cdpPnioMib3_ifInErrors . . . 1511
2.33.6.11. Variable: cdpPnioMib3_ifOutOctets . . . 1513
2.33.6.12. Variable: cdpPnioMib3_ifOutUcastPkts . . . 1514
2.33.6.13. Variable: cdpPnioMib3_ifOutNUcastPkts . . . 1515
2.33.6.14. Variable: cdpPnioMib3_ifOutDiscards . . . 1517
2.33.6.15. Variable: cdpPnioMib3_ifOutErrors . . . 1518
2.33.7. Group: Profinet_Diagnosis_Mib3_Optional_grp . . . 1520
2.33.7.1. Variable: cdpPnioMib3_ipInReceives . . . 1520
2.33.7.2. Variable: cdpPnioMib3_ipInHdrErrors . . . 1521
2.33.7.3. Variable: cdpPnioMib3_ipInAddrErrors . . . 1523
2.33.7.4. Variable: cdpPnioMib3_ipInDiscards . . . 1524
2.33.7.5. Variable: cdpPnioMib3_ipOutRequests . . . 1525
2.33.7.6. Variable: cdpPnioMib3_ipOutDiscards . . . 1527
2.33.7.7. Variable: cdpPnioMib3_udpInDatagrams . . . 1528
2.33.7.8. Variable: cdpPnioMib3_udpNoPorts . . . 1529
2.33.7.9. Variable: cdpPnioMib3_udpInErrors . . . 1531
2.33.7.10. Variable: cdpPnioMib3_udpOutDatagrams . . . 1532
2.33.7.11. Variable: cdpPnioMib3_tcpInSegs . . . 1533
2.33.7.12. Variable: cdpPnioMib3_tcpOutSegs . . . 1535
2.33.7.13. Variable: cdpPnioMib3_tcpRetransSegs . . . 1536
2.33.7.14. Variable: cdpPnioMib3_tcpInErrs . . . 1537
2.33.7.15. Variable: cdpPnioMib3_tcpOutRsts . . . 1539
2.34. Interface Block: ConfirmedMsgControl . . . 1541
2.34.1. Group: ConfirmMsgCtrlBitsIn . . . 1541
2.34.1.1. Variable: cdpCmCtrlBitsIn . . . 1541
2.34.2. Group: ConfirmMsgCtrlBitsOut . . . 1543
2.34.2.1. Variable: cdpCmCtrlBitsOut . . . 1543

© SICK AG - Germany - All rights reserved

2.34.3. Group: ConfirmMsgStatus . . . 1545
2.34.3.1. Variable: cdpCmStatus . . . 1545
2.34.4. Group: ConfirmMsgConfig . . . 1547
2.34.4.1. Variable: cdpCmConfig . . . 1547
2.34.4.2. Variable: cdpCmInFrameLength . . . 1548
2.34.4.3. Variable: cdpCmOutFrameLength . . . 1550
2.34.4.4. Variable: cdpCmProtocolVariant . . . 1551
2.34.5. Group: ConfirmMsgInput . . . 1553
2.34.5.1. Variable: cdpCmInMsgLength . . . 1553
2.34.6. Group: ConfirmMsgOutput . . . 1555
2.34.6.1. Variable: cdpCmOutMsg . . . 1555
2.35. Interface Block: ConfirmMsgFrames . . . 1557
2.35.1. Group: ConfirmMsgInputFrame . . . 1557
2.35.1.1. Variable: cdpCmInternalDataIn . . . 1557
2.35.2. Group: ConfirmMsgOutputFrame . . . 1559
2.35.2.1. Variable: cdpCmInternalDataOut . . . 1559
2.36. Interface Block: DigIORegisters . . . 1561
2.36.1. Group: DigIORegisters . . . 1561
2.36.1.1. Variable: cdpDigIoReg0 . . . 1561
2.37. Interface Block: GeneralCfgApp . . . 1563
2.37.1. Group: System . . . 1563
2.37.1.1. Variable: SYParaPasswordGuarded . . . 1563
2.37.1.2. Variable: SYNoQuickstart . . . 1564
2.37.2. Group: Camera . . . 1566
2.37.2.1. Variable: UseFrameRate . . . 1566
2.37.2.2. Variable: ImgAcqMode . . . 1567
2.37.2.3. Variable: ImgAcqBurstModeNumImages . . . 1569
2.37.2.4. Variable: UseNumFramesInQueue . . . 1570
2.37.2.5. Variable: NumFramesInQueue . . . 1571
2.37.2.6. Variable: Brightness . . . 1573
2.37.2.7. Variable: Contrast . . . 1574
2.37.2.8. Variable: GammaCorrectionTurningPoint10bit . . . 1575
2.37.2.9. Variable: NoiseReductionFilter . . . 1577
2.37.2.10. Variable: MorphologicalFilter . . . 1578
2.37.2.11. Variable: InternalIlluminationMode . . . 1579
2.37.2.12. Variable: InternalIlluminationColor . . . 1581
2.37.2.13. Variable: ExternalIlluminationMode . . . 1582
2.37.2.14. Variable: ExternalLightConnectorMode . . . 1584
2.37.2.15. Variable: AimingLaser . . . 1586
2.37.2.16. Variable: LedTimeout . . . 1587
2.37.2.17. Variable: ImageAcqROI . . . 1589
2.37.2.18. Variable: ImageResolution . . . 1591

© SICK AG - Germany - All rights reserved

2.37.2.19. Variable: ImageVerticalFlip . . . 1592
2.37.2.20. Variable: ImageMirroring . . . 1593
2.37.2.21. Variable: UseCCDToWorldTransformMatrix . . . 1595
2.37.2.22. Variable: AutoAdjustGain . . . 1596
2.37.2.23. Variable: AutoAdjustRegion . . . 1597
2.37.2.24. Variable: AutoAdjustGainRangeMin . . . 1599
2.37.2.25. Variable: AutoAdjustGainRangeMax . . . 1601
2.37.2.26. Variable: ImageBinningMode . . . 1602
2.37.2.27. Variable: LedTimeoutEnabled . . . 1603
2.37.2.28. Variable: ReadingDistanceInput . . . 1605
2.37.2.29. Variable: FocusPosition . . . 1606
2.37.2.30. Variable: FrameRate . . . 1608
2.37.2.31. Variable: ShutterTime . . . 1609
2.37.2.32. Method: GetCurrentFrameRate . . . 1611
2.37.3. Group: Camera65x . . . 1612
2.37.3.1. Variable: FlashFrequencyControlLevel . . . 1612
2.37.3.2. Variable: PanoramaHoodActive . . . 1613
2.37.3.3. Variable: PanoramaHoodImageOverlapping . . . 1615
2.37.3.4. Variable: IlluSyncEnable . . . 1616
2.37.3.5. Variable: IlluSyncDevDelayMs . . . 1617
2.37.3.6. Variable: IlluOffDelayEnable . . . 1619
2.37.3.7. Variable: IlluOffDelayTime . . . 1620
2.37.3.8. Variable: CCDToWorldTransformMatrix . . . 1621
2.37.3.9. Variable: CalibratedMmPerPix . . . 1623
2.37.3.10. Variable: FlashFrequencyControlEnable . . . 1625
2.37.3.11. Event: FlashDutyCycleViolation . . . 1626
2.37.4. Group: Lector61xIllumination . . . 1627
2.37.4.1. Variable: L61xIlluminationLEDStates1 . . . 1627
2.37.4.2. Variable: L61xIlluminationIntensity . . . 1629
2.37.5. Group: DeShading . . . 1631
2.37.5.1. Variable: DeShadingActive . . . 1631
2.37.5.2. Variable: DeShadingIlluminationNonUniformity . . . 1632
2.37.5.3. Variable: RotateDeShadingMetric . . . 1634
2.37.6. Group: FocusControlCfg . . . 1636
2.37.6.1. Variable: FocusControlMode . . . 1636
2.37.6.2. Variable: FocusControlSource . . . 1637
2.37.6.3. Variable: FocusControlBehavior . . . 1639
2.37.6.4. Variable: FocusControlTimerTime . . . 1640
2.37.6.5. Variable: FocusControlTimerTrack . . . 1641
2.37.6.6. Variable: FocusControlActive . . . 1643
2.37.6.7. Variable: FocusControlDistances . . . 1644
2.37.6.8. Variable: FocusControlSensorInput . . . 1646

© SICK AG - Germany - All rights reserved

2.37.6.9. Variable: FocusControlFocusDelayTime . . . 1647
2.37.6.10. Variable: FocusControlFocusDelayTrack . . . 1649
2.37.6.11. Variable: FocusControlPreExpansionTime . . . 1650
2.37.6.12. Variable: FocusControlPreExpansionTrack . . . 1651
2.37.6.13. Variable: FocusControlPostExpansionTime . . . 1653
2.37.6.14. Variable: FocusControlPostExpansionTrack . . . 1654
2.37.6.15. Variable: FocusControlMLGZDistDeviceBeamLow . . . 1655
2.37.6.16. Variable: FocusControlMLGZDistBeams . . . 1657
2.37.6.17. Variable: FocusControlMLGIsMLGMaster . . . 1658
2.37.6.18. Variable: FocusControlMLGNodeID . . . 1660
2.37.6.19. Variable: FocusControlMLGIsUpsideDown . . . 1661
2.37.6.20. Variable: FocusControlLTRNodeID . . . 1662
2.37.6.21. Variable: FocusControlLTRHysteresis . . . 1664
2.37.6.22. Variable: FocusControlLTRXOffset . . . 1665
2.37.6.23. Variable: FocusControlLTRPostExpation . . . 1666
2.37.6.24. Variable: FocusControlLTRManualOffset . . . 1668
2.37.6.25. Variable: FocusControlLTRUsFrontRearFocus . . . 1669
2.37.6.26. Method: SwitchDynRdCfgTableIndex . . . 1670
2.37.6.27. Method: SwitchDynRdCfgDistance . . . 1671
2.37.6.28. Method: MLGTeachIn . . . 1673
2.37.7. Group: CodeImageSegmentation . . . 1674
2.37.7.1. Variable: SharpnessMeasuring . . . 1674
2.37.7.2. Variable: ContrastSpreading . . . 1675
2.37.7.3. Variable: ScanDensity1D . . . 1677
2.37.7.4. Variable: MaxCodesPerRegion1D . . . 1678
2.37.7.5. Variable: NORCAVerification . . . 1680
2.37.7.6. Variable: DottedPostalCodes . . . 1681
2.37.7.7. Variable: CodeTrackingDirection . . . 1682
2.37.7.8. Variable: OptimizeTireReading . . . 1684
2.37.7.9. Variable: ShortBarHeight . . . 1685
2.37.7.10. Variable: MaxNum1DCodesEnabled . . . 1687
2.37.7.11. Variable: MaxNum1DCodes . . . 1688
2.37.7.12. Variable: MaxNumDMxCodes . . . 1689
2.37.7.13. Variable: MaxNumQRCodes . . . 1691
2.37.7.14. Variable: MaxNumMaxiCodesEnabled . . . 1692
2.37.7.15. Variable: MaxNumMaxiCodes . . . 1693
2.37.7.16. Variable: WoodTexture . . . 1695
2.37.7.17. Variable: LogisticsFalsePositiveFilter . . . 1696
2.37.7.18. Variable: MaxNumQRCodesEnabled . . . 1697
2.37.7.19. Variable: MaxNumDMxCodesEnabled . . . 1699
2.37.7.20. Variable: CodeModuleSize2D . . . 1700
2.37.8. Group: Digimarc . . . 1702

© SICK AG - Germany - All rights reserved

2.37.8.1. Variable: DigimarcActive . . . 1702
2.37.8.2. Variable: DigimarcExpectedModuleSize . . . 1703
2.37.8.3. Variable: DigimarcBlockSpacing . . . 1705
2.37.8.4. Variable: DigimarcPerspectiveCorrection . . . 1706
2.37.8.5. Variable: DigimarcTilt . . . 1707
2.37.8.6. Variable: DigimarcBearing . . . 1709
2.37.8.7. Variable: DigimarcMaxBlocksToReadActive . . . 1710
2.37.8.8. Variable: DigimarcMaxBlocksToRead . . . 1712
2.37.8.9. Variable: DigimarcGiftCard . . . 1713
2.37.9. Group: OpticsInterchangeableLens . . . 1715
2.37.9.1. Variable: InterchangeableLensfNumber . . . 1715
2.37.9.2. Variable: InterchangeableLensfStr . . . 1716
2.37.9.3. Variable: InterchangeableLensType . . . 1718
2.37.9.4. Variable: InterchangeableLensTransmission . . . 1719
2.37.10. Group: ImageDiagnosis . . . 1721
2.37.10.1. Variable: ImgDiagStoreCondition . . . 1721
2.37.10.2. Variable: ImgDiagStoreConditionExt . . . 1722
2.37.10.3. Variable: ImgDiagImageSelection . . . 1724
2.37.10.4. Variable: ImgDiagPathDevice . . . 1725
2.37.10.5. Variable: ImgDiagPathDeviceName . . . 1727
2.37.10.6. Variable: ImgDiagPathDate . . . 1728
2.37.10.7. Variable: ImgDiagPathHour . . . 1729
2.37.10.8. Variable: ImgDiagPathGoodReadNoRead . . . 1731
2.37.10.9. Variable: ImgDiagFileGoodReadNoRead . . . 1732
2.37.10.10. Variable: ImgDiagFileName . . . 1734
2.37.10.11. Variable: ImgDiagFileSystemInfo . . . 1735
2.37.10.12. Variable: ImgDiagFileTimestamp . . . 1736
2.37.10.13. Variable: ImgDiagSDCardFileCycleMethod . . . 1738
2.37.10.14. Variable: ImgDiagSDCardFileCycleModulo . . . 1739
2.37.10.15. Variable: ImgDiagSopasFileCycleMethod . . . 1741
2.37.10.16. Variable: ImgDiagSopasFileCycleModulo . . . 1742
2.37.10.17. Variable: ImgDiagFTPFileCycleMethod . . . 1744
2.37.10.18. Variable: ImgDiagFTPFileCycleModulo . . . 1745
2.37.10.19. Variable: ImgDiagSaveToSDCard . . . 1747
2.37.10.20. Variable: ImgDiagSaveToSDCard2 . . . 1748
2.37.10.21. Variable: ImgDiagSendFTP . . . 1750
2.37.10.22. Variable: ImgDiagSendFTPLegacyStyle . . . 1751
2.37.10.23. Variable: ImgDiagSendFTP2 . . . 1753
2.37.10.24. Variable: ImgDiagFTPArchiv . . . 1754
2.37.10.25. Variable: ImgDiagFTPArchiv2 . . . 1756
2.37.10.26. Variable: ImgDiagSendSopas . . . 1757
2.37.10.27. Variable: ImgDiagSendSopas2 . . . 1759

© SICK AG - Germany - All rights reserved

2.37.10.28. Method: GetImagesFromSD . . . 1760
2.37.10.29. Method: GetImagesFromRam . . . 1761
2.37.10.30. Method: CancelImageUpload . . . 1762
2.37.10.31. Method: DeleteImagesFromSD . . . 1763
2.37.10.32. Method: DeleteImagesFromRam . . . 1764
2.37.10.33. Method: CancelImageDeletion . . . 1765
2.37.10.34. Event: ImgBlobTransfer . . . 1766
2.37.10.35. Event: ImageUploadStatus . . . 1766
2.37.10.36. Event: ImageDeleteStatus . . . 1767
2.37.11. Group: ImageDiagnosis65x . . . 1768
2.37.11.1. Variable: ImgDiagStoreCondition2 . . . 1768
2.37.11.2. Variable: ImgDiagStoreConditionExt2 . . . 1769
2.37.11.3. Variable: ImgDiagImageSelection2 . . . 1771
2.37.11.4. Variable: ImgDiagJpegCompressionEnabled . . . 1772
2.37.11.5. Variable: VisualDecoProfiling . . . 1774
2.37.11.6. Variable: ImgDiagJpegCompressionQuality . . . 1775
2.37.11.7. Variable: ImgDiagImageOutReduction . . . 1776
2.37.11.8. Variable: ImgDiagMinConveyingPathMM . . . 1778
2.37.11.9. Variable: ImgDiagContinuousModCnt . . . 1779
2.37.11.10. Variable: ImgDiagNameTemplateString . . . 1781
2.37.12. Group: LogfileDiagnosis . . . 1783
2.37.12.1. Variable: LogfCtrlSourceSerialHostActive . . . 1783
2.37.12.2. Variable: LogfCtrlSourceSerialAuxActive . . . 1784
2.37.12.3. Variable: LogfCtrlSourceEthernetHostActive . . . 1786
2.37.12.4. Variable: LogfCtrlSourceEthernetAuxActive . . . 1787
2.37.12.5. Variable: LogfCtrlRamMaxStorageSpaceMB . . . 1789
2.37.12.6. Variable: LogfCtrlDestinationSDCardActive . . . 1790
2.37.12.7. Variable: LogfCtrlSDCardMaxStorageSpaceMB . . . 1792
2.37.12.8. Variable: LogfCtrlDiagPathDevice . . . 1793
2.37.12.9. Variable: LogfCtrlDiagPathDeviceName . . . 1795
2.37.12.10. Variable: LogfCtrlDiagPathDate . . . 1796
2.37.12.11. Variable: LogfCtrlDiagPathHour . . . 1797
2.37.12.12. Variable: LogfCtrlDiagFileName . . . 1799
2.37.12.13. Variable: LogfCtrlDiagFormatTimestamp . . . 1800
2.37.12.14. Method: LogfCtrlStartLogging . . . 1801
2.37.12.15. Method: LogfCtrlStopLogging . . . 1802
2.37.13. Group: Position . . . 1804
2.37.13.1. Variable: ScannerPosBeta . . . 1804
2.37.13.2. Variable: ScannerPosGamma . . . 1805
2.37.13.3. Variable: ScannerPosXCoord . . . 1807
2.37.13.4. Variable: ScannerPosYCoord . . . 1808
2.37.13.5. Variable: ScannerHRPosBeta . . . 1809

© SICK AG - Germany - All rights reserved

2.37.13.6. Variable: ScannerHRPosGamma . . . 1811
2.37.13.7. Variable: ScannerHRPosXCoord . . . 1812
2.37.13.8. Variable: ScannerHRPosYCoord . . . 1813
2.37.13.9. Variable: PositionDeshadingActive . . . 1815
2.37.13.10. Variable: PositionXOffset . . . 1816
2.37.13.11. Variable: PositionYOffset . . . 1817
2.37.13.12. Variable: PositionZOffset . . . 1819
2.37.13.13. Variable: ScannerHRPosZCoord . . . 1820
2.37.13.14. Variable: ScannerPosZCoord . . . 1821
2.37.13.15. Variable: ScannerHRPosAlpha . . . 1823
2.37.13.16. Variable: ScannerPosAlpha . . . 1824
2.37.14. Group: ExpanderPositionLector65x . . . 1826
2.37.14.1. Variable: ExpanderScannerPosAlpha . . . 1826
2.37.14.2. Variable: ExpanderScannerPosBeta . . . 1827
2.37.14.3. Variable: ExpanderScannerPosGamma . . . 1829
2.37.14.4. Variable: ExpanderScannerPosXCoord . . . 1830
2.37.14.5. Variable: ExpanderScannerPosYCoord . . . 1832
2.37.14.6. Variable: ExpanderScannerPosZCoord . . . 1833
2.37.14.7. Variable: ExpanderScannerHRPosAlpha . . . 1835
2.37.14.8. Variable: ExpanderScannerHRPosBeta . . . 1836
2.37.14.9. Variable: ExpanderScannerHRPosGamma . . . 1838
2.37.14.10. Variable: ExpanderScannerHRPosXCoord . . . 1839
2.37.14.11. Variable: ExpanderScannerHRPosYCoord . . . 1841
2.37.14.12. Variable: ExpanderScannerHRPosZCoord . . . 1842
2.37.15. Group: Reading . . . 1844
2.37.15.1. Variable: RCReadingAreaLimY1 . . . 1844
2.37.15.2. Variable: RCReadingAreaLimY2 . . . 1845
2.37.15.3. Variable: RCReadingAreaLimZ1 . . . 1847
2.37.15.4. Variable: RCReadingAreaLimZ2 . . . 1848
2.37.15.5. Method: DoMatchCodeTeachIn . . . 1849
2.37.16. Group: Reading65x . . . 1851
2.37.16.1. Variable: CalcTriggerPreExpand . . . 1851
2.37.16.2. Variable: CalcTriggerPostExpand . . . 1852
2.37.17. Group: AutoSetup . . . 1854
2.37.17.1. Variable: ASParameter . . . 1854
2.37.17.2. Variable: ASCodeRegion . . . 1857
2.37.17.3. Variable: ASManualCodeRegion . . . 1859
2.37.17.4. Variable: ASDatamatrixPrio . . . 1861
2.37.17.5. Variable: ASAllowTeachPixToMM . . . 1862
2.37.17.6. Variable: ASUseDPMRoi . . . 1864
2.37.17.7. Variable: ASUserDefinedDPMRoi . . . 1865
2.37.17.8. Variable: ASWriteTarget . . . 1867

© SICK AG - Germany - All rights reserved

2.37.17.9. Variable: ASConveyorSpeed . . . 1868
2.37.17.10. Variable: ASCellSize . . . 1870
2.37.17.11. Method: StartAutoSetup . . . 1871
2.37.17.12. Method: CancelAutoSetup . . . 1872
2.37.17.13. Method: FinishAutoSetup . . . 1873
2.37.17.14. Method: ASCalculateShutterTime . . . 1874
2.37.17.15. Event: ASAllOperationsFinished . . . 1875
2.37.18. Group: AutoSetupLector65x . . . 1876
2.37.18.1. Variable: PoseEstimationXOrigin . . . 1876
2.37.18.2. Variable: PoseEstimationYOrigin . . . 1877
2.37.18.3. Variable: PoseEstimationZOrigin . . . 1879
2.37.18.4. Variable: PoseEstimationTargetOrientation . . . 1880
2.37.18.5. Variable: PoseEstimationFeedback . . . 1881
2.37.18.6. Variable: PoseEstimationProcessFeedback . . . 1884
2.37.18.7. Variable: PoseEstimationFinish . . . 1886
2.37.18.8. Variable: NodalPoseAlphaOpti . . . 1887
2.37.18.9. Variable: NodalPoseBetaOpti . . . 1888
2.37.18.10. Variable: NodalPoseGammaOpti . . . 1890
2.37.18.11. Variable: NodalPoseXCoordOffset . . . 1891
2.37.18.12. Variable: NodalPoseYCoordOffset . . . 1893
2.37.18.13. Variable: NodalPoseZCoordOffset . . . 1894
2.37.18.14. Variable: ExpNodalPoseAlphaOpti . . . 1896
2.37.18.15. Variable: ExpNodalPoseBetaOpti . . . 1897
2.37.18.16. Variable: ExpNodalPoseGammaOpti . . . 1899
2.37.18.17. Variable: ExpNodalPoseXCoordOffset . . . 1900
2.37.18.18. Variable: ExpNodalPoseYCoordOffset . . . 1902
2.37.18.19. Variable: ExpNodalPoseZCoordOffset . . . 1903
2.37.18.20. Method: StartPoseEstimation . . . 1905
2.37.18.21. Method: StartPoseEstimationPanoramaHood1of2 . . . 1906
2.37.18.22. Method: StartPoseEstimationPanoramaHood2of2 . . . 1907
2.37.18.23. Method: CancelPoseEstimation . . . 1908
2.37.18.24. Method: FinishPoseEstimation . . . 1909
2.37.19. Group: DemoMode . . . 1910
2.37.19.1. Variable: DemoModeROI . . . 1910
2.37.19.2. Variable: DemoModePDF417 . . . 1912
2.37.19.3. Variable: DemoModeMaxiCode . . . 1913
2.37.19.4. Variable: DemoModeDPMDataMatrix . . . 1914
2.37.19.5. Method: StartDemoMode . . . 1916
2.37.19.6. Method: CancelDemoMode . . . 1917
2.37.19.7. Method: FinishDemoMode . . . 1918
2.37.20. Group: Increment . . . 1919
2.37.20.1. Variable: IncrSource . . . 1919

© SICK AG - Germany - All rights reserved

2.37.20.2. Variable: IncrDistance . . . 1920
2.37.20.3. Variable: IncrFixVelocity . . . 1922
2.37.20.4. Variable: IncrDistribute . . . 1923
2.37.20.5. Method: SetIncrement . . . 1924
2.37.20.6. Method: GetIncrement . . . 1925
2.37.20.7. Method: GetIncrementMM . . . 1926
2.37.21. Group: TriggerControl . . . 1928
2.37.21.1. Variable: TrigStopCondition1Ext . . . 1928
2.37.21.2. Variable: TrigStopCondition2Ext . . . 1929
2.37.21.3. Variable: TrigStopCondition3Ext . . . 1931
2.37.21.4. Variable: TriggerEcho . . . 1932
2.37.21.5. Variable: UserDefTriggerStartCmd . . . 1934
2.37.21.6. Variable: UserDefTriggerStopCmd . . . 1935
2.37.21.7. Variable: TrigStartCondition . . . 1936
2.37.21.8. Variable: TrigStopCondition2 . . . 1938
2.37.21.9. Variable: TrigStopCondition1 . . . 1939
2.37.21.10. Variable: TrigStopCondition3 . . . 1941
2.37.21.11. Method: DoReadingGateDiag . . . 1942
2.37.21.12. Method: SetDeviceIdle . . . 1943
2.37.21.13. Method: StartPercentageEvaluation . . . 1944
2.37.21.14. Method: StopPercentageEvaluation . . . 1945
2.37.22. Group: DecodingGeneral . . . 1947
2.37.22.1. Variable: DecodingTimeOutput . . . 1947
2.37.22.2. Variable: EnableNciiForEveryNoReadImage . . . 1948
2.37.22.3. Variable: CodeDirection . . . 1950
2.37.23. Group: Decoding1DExtensions . . . 1952
2.37.23.1. Variable: EnableLineFeedMode . . . 1952
2.37.23.2. Variable: LineFeedModeHorizontalScans . . . 1953
2.37.23.3. Variable: LineFeedModeNumScansInImage . . . 1955
2.37.23.4. Variable: OptimizeBad1DDecoding . . . 1956
2.37.23.5. Variable: Emphasize1D . . . 1958
2.37.23.6. Variable: Scanning1DRegionMode . . . 1959
2.37.23.7. Variable: SizeFilter1DCodes . . . 1960
2.37.23.8. Variable: CodeAtBorder1D . . . 1962
2.37.23.9. Variable: SuperResolutionActive . . . 1964
2.37.23.10. Variable: UPCEANAddonMatchingStrategy . . . 1965
2.37.23.11. Variable: Decoding1DLevel . . . 1966
2.37.24. Group: Decoding2DExtensions . . . 1968
2.37.24.1. Variable: GlsCodeSelection . . . 1968
2.37.24.2. Variable: MultiCodeGridModuleSize . . . 1969
2.37.24.3. Variable: MCMountingAngleAlphaCompensationActive . . . 1971
2.37.24.4. Variable: GLSIncreaseAngleStability . . . 1972

© SICK AG - Germany - All rights reserved

2.37.24.5. Variable: MultiCodeCenterOffsetEnabled . . . 1974
2.37.25. Group: DecodingAztec . . . 1976
2.37.25.1. Variable: AztecActive . . . 1976
2.37.25.2. Variable: AztecLengthMode . . . 1977
2.37.25.3. Variable: AztecFixLenList . . . 1979
2.37.25.4. Variable: AztecMode . . . 1982
2.37.26. Group: MatchTeachIn . . . 1984
2.37.26.1. Variable: MTIGeneralSettings . . . 1984
2.37.26.2. Variable: MTIChannelSettings1 . . . 1986
2.37.26.3. Variable: MTIChannelStopSettings1 . . . 1988
2.37.26.4. Variable: MTIChannel1Condition . . . 1989
2.37.26.5. Variable: MTIChannelSettings2 . . . 1991
2.37.26.6. Variable: MTIChannelStopSettings2 . . . 1993
2.37.26.7. Variable: MTIChannel2Condition . . . 1994
2.37.27. Group: HMI . . . 1996
2.37.27.1. Variable: HMIAllowMatchCodeTeachIn . . . 1996
2.37.27.2. Variable: HMIAutoSetupChangeFocus . . . 1997
2.37.27.3. Variable: HMIAutoSetupChangeImage . . . 1999
2.37.27.4. Variable: HMIAutoSetupChangeCode . . . 2000
2.37.27.5. Variable: HMIButtonMode . . . 2002
2.37.28. Group: Beeper . . . 2004
2.37.28.1. Variable: BeeperFuncExt . . . 2004
2.37.28.2. Variable: BeeperLoudness . . . 2005
2.37.28.3. Variable: BeeperFunc . . . 2007
2.37.29. Group: GoodReadLed . . . 2009
2.37.29.1. Variable: GoodReadLedFuncExt . . . 2009
2.37.29.2. Variable: GoodReadLedDuration . . . 2010
2.37.29.3. Variable: IlluminationForFeedback . . . 2012
2.37.29.4. Variable: GoodReadLedFunc . . . 2013
2.37.30. Group: FeedbackLedRed . . . 2015
2.37.30.1. Variable: FeedbackLedRedFunc . . . 2015
2.37.30.2. Variable: FeedbackLedRedFuncExt . . . 2016
2.37.30.3. Variable: FeedbackLedRedDuration . . . 2018
2.37.31. Group: ApplicationCounters . . . 2020
2.37.31.1. Variable: APCCounterCondition01 . . . 2020
2.37.31.2. Variable: APCCounterConditionStruct01 . . . 2021
2.37.31.3. Variable: APCCounterDBTagStruct01 . . . 2023
2.37.31.4. Variable: APCIsPermanent01 . . . 2024
2.37.31.5. Variable: APCCounterCondition02 . . . 2026
2.37.31.6. Variable: APCCounterConditionStruct02 . . . 2027
2.37.31.7. Variable: APCCounterDBTagStruct02 . . . 2029
2.37.31.8. Variable: APCIsPermanent02 . . . 2030

© SICK AG - Germany - All rights reserved

2.37.31.9. Variable: APCCounterCondition03 . . . 2032
2.37.31.10. Variable: APCCounterConditionStruct03 . . . 2033
2.37.31.11. Variable: APCCounterDBTagStruct03 . . . 2035
2.37.31.12. Variable: APCIsPermanent03 . . . 2036
2.37.31.13. Variable: APCCounterCondition04 . . . 2038
2.37.31.14. Variable: APCCounterConditionStruct04 . . . 2039
2.37.31.15. Variable: APCCounterDBTagStruct04 . . . 2041
2.37.31.16. Variable: APCIsPermanent04 . . . 2042
2.37.31.17. Variable: APCCounterCondition05 . . . 2044
2.37.31.18. Variable: APCCounterConditionStruct05 . . . 2045
2.37.31.19. Variable: APCCounterDBTagStruct05 . . . 2047
2.37.31.20. Variable: APCIsPermanent05 . . . 2048
2.37.31.21. Variable: APCCounterCondition06 . . . 2050
2.37.31.22. Variable: APCCounterConditionStruct06 . . . 2051
2.37.31.23. Variable: APCCounterDBTagStruct06 . . . 2053
2.37.31.24. Variable: APCIsPermanent06 . . . 2054
2.37.31.25. Variable: APCCounterCondition07 . . . 2056
2.37.31.26. Variable: APCCounterConditionStruct07 . . . 2057
2.37.31.27. Variable: APCCounterDBTagStruct07 . . . 2059
2.37.31.28. Variable: APCIsPermanent07 . . . 2060
2.37.31.29. Variable: APCCounterCondition08 . . . 2062
2.37.31.30. Variable: APCCounterConditionStruct08 . . . 2063
2.37.31.31. Variable: APCCounterDBTagStruct08 . . . 2065
2.37.31.32. Variable: APCIsPermanent08 . . . 2066
2.37.31.33. Variable: APCCounterCondition09 . . . 2068
2.37.31.34. Variable: APCCounterConditionStruct09 . . . 2069
2.37.31.35. Variable: APCCounterDBTagStruct09 . . . 2071
2.37.31.36. Variable: APCIsPermanent09 . . . 2072
2.37.31.37. Variable: APCCounterCondition10 . . . 2074
2.37.31.38. Variable: APCCounterConditionStruct10 . . . 2075
2.37.31.39. Variable: APCCounterDBTagStruct10 . . . 2077
2.37.31.40. Variable: APCIsPermanent10 . . . 2078
2.37.31.41. Method: ResetAppCounter . . . 2080
2.37.31.42. Method: StoreAppCounter . . . 2081
2.37.32. Group: ParameterSwitching . . . 2082
2.37.32.1. Variable: ParameterSwitchingMode . . . 2082
2.37.32.2. Variable: APSRetries . . . 2083
2.37.32.3. Variable: EPSSource . . . 2085
2.37.32.4. Variable: DpsFocusPositions . . . 2086
2.37.32.5. Variable: DpsFocusPositionsExt . . . 2088
2.37.32.6. Variable: DpsFocusPostSwitchDelayMs . . . 2089
2.37.32.7. Variable: ParameterSets . . . 2091

© SICK AG - Germany - All rights reserved

2.37.32.8. Variable: ParameterSetsExt . . . 2092
2.37.32.9. Variable: ParameterSetsIlluminationColor . . . 2093
2.37.32.10. Variable: ParameterSetsIlluminationColorExt . . . 2095
2.37.32.11. Variable: ParameterSetsDPMDMXString . . . 2096
2.37.32.12. Variable: ParameterSetsDPMDMXStringExt . . . 2097
2.37.32.13. Variable: ParameterSetsDPMDMXPrettyString . . . 2099
2.37.32.14. Variable: ParameterSetsDPMDMXPrettyStringExt . . . 2100
2.37.32.15. Variable: ParameterSetsL61xIlluminationLEDStates1 . . . 2102
2.37.32.16. Variable: ParameterSetsL61xIlluminationLEDStates1Ext . . . 2103
2.37.32.17. Variable: ParameterSetsL61xIlluminationIntensity . . . 2104
2.37.32.18. Variable: ParameterSetsL61xIlluminationIntensityExt . . . 2106
2.37.32.19. Variable: ParameterSetEnabled . . . 2107
2.37.32.20. Variable: ParameterSetEnabledExt . . . 2109
2.37.32.21. Method: ActivateEPSSet . . . 2110
2.37.33. Group: CollectionOfData . . . 2112
2.37.33.1. Variable: LabelPosTolerance . . . 2112
2.37.33.2. Variable: ImageQueueTimeoutMM . . . 2113
2.37.33.3. Variable: ImageQueueTimeoutMS . . . 2115
2.37.33.4. Variable: EnableImageQueueTimeout . . . 2116
2.37.33.5. Variable: EnableSkipImageByQueueSize . . . 2117
2.37.33.6. Variable: EnableOptimizeObjCap . . . 2119
2.37.33.7. Variable: SkipImgQueueFillLevel1 . . . 2120
2.37.33.8. Variable: SkipImageByQueueSize1 . . . 2121
2.37.33.9. Variable: SkipImgQueueFillLevel2 . . . 2123
2.37.33.10. Variable: SkipImageByQueueSize2 . . . 2124
2.37.33.11. Variable: SkipImgQueueFillLevel3 . . . 2125
2.37.33.12. Variable: SkipImageByQueueSize3 . . . 2127
2.37.33.13. Variable: SkipImgQueueFillLevel4 . . . 2128
2.37.33.14. Variable: SkipImageByQueueSize4 . . . 2130
2.37.33.15. Variable: SkipImgQueueFillLevel5 . . . 2131
2.37.33.16. Variable: SkipImageByQueueSize5 . . . 2133
2.37.33.17. Variable: SkipImgQueueFillLevel6 . . . 2134
2.37.33.18. Variable: CodePositionByImageMultipleEnable . . . 2136
2.37.33.19. Variable: CodeMultiImageToleranceFactor . . . 2137
2.37.33.20. Variable: EnableSystemOptimizingParameter . . . 2138
2.37.34. Group: Profinet . . . 2140
2.37.34.1. Variable: cdpPnioSelectDataFormat . . . 2140
2.37.35. Group: PresentationMode . . . 2142
2.37.35.1. Variable: PMSensitivityThreshold . . . 2142
2.37.35.2. Variable: PMReTrigPause . . . 2143
2.37.35.3. Variable: PMMovDectTimeout . . . 2145
2.37.35.4. Variable: PMSleepTriggerTime . . . 2146

© SICK AG - Germany - All rights reserved

2.37.35.5. Variable: PMRepetitiveContentFilteringEnabled . . . 2148
2.37.35.6. Variable: PMRepetitiveContentFilteringNumObjects . . . 2149
2.37.35.7. Variable: PMRepetitiveContentFilteringMaxAge . . . 2151
2.37.35.8. Variable: PMSleepModeEnabled . . . 2152
2.37.36. Group: ExternalDataInputHandling . . . 2154
2.37.36.1. Variable: SerHostInputHandling . . . 2154
2.37.36.2. Variable: SerAuxInputHandling . . . 2155
2.37.36.3. Variable: EtherHostInputHandling . . . 2157
2.37.36.4. Variable: EtherAuxInputHandling . . . 2158
2.37.36.5. Variable: ED_DataForwardDestination . . . 2160
2.37.36.6. Variable: ED_DataForwardFrameRxHeader . . . 2161
2.37.36.7. Variable: ED_DataForwardFrameRxTerminator . . . 2163
2.37.36.8. Variable: ED_DataForwardFrameTxHeader . . . 2164
2.37.36.9. Variable: ED_DataForwardFrameTxTerminator . . . 2166
2.37.36.10. Variable: ED_AuxReadResultBarcodeType . . . 2167
2.37.36.11. Variable: ED_AuxReadResultFrameRxHeader . . . 2169
2.37.36.12. Variable: ED_AuxReadResultFrameRxTerminator . . . 2170
2.37.36.13. Variable: ED_DataStringAcqDefault . . . 2172
2.37.36.14. Variable: ED_DataStringAcqFrameRxHeader . . . 2173
2.37.36.15. Variable: ED_DataStringAcqFrameRxTerminator . . . 2174
2.37.37. Group: ScriptParameters . . . 2176
2.37.37.1. Variable: ScriptParam01 . . . 2176
2.37.37.2. Variable: ScriptParam02 . . . 2177
2.37.37.3. Variable: ScriptParam03 . . . 2179
2.37.37.4. Variable: ScriptParam04 . . . 2180
2.37.37.5. Variable: ScriptParam05 . . . 2181
2.37.37.6. Variable: ScriptParam06 . . . 2183
2.37.37.7. Variable: ScriptParam07 . . . 2184
2.37.37.8. Variable: ScriptParam08 . . . 2185
2.37.37.9. Variable: ScriptParam09 . . . 2187
2.37.37.10. Variable: ScriptParam10 . . . 2188
2.37.37.11. Variable: ScriptParam11 . . . 2189
2.37.37.12. Variable: ScriptParam12 . . . 2191
2.37.37.13. Variable: ScriptParam13 . . . 2192
2.37.37.14. Variable: ScriptParam14 . . . 2193
2.37.37.15. Variable: ScriptParam15 . . . 2195
2.37.37.16. Variable: ScriptParam16 . . . 2196
2.37.37.17. Variable: ScriptParam17 . . . 2197
2.37.37.18. Variable: ScriptParam18 . . . 2199
2.37.37.19. Variable: ScriptParam19 . . . 2200
2.37.37.20. Variable: ScriptParam20 . . . 2201
2.37.38. Group: BackwardMode . . . 2203

© SICK AG - Germany - All rights reserved

2.37.38.1. Variable: BWDEnableMode 2203
2.37.38.2. Variable: BWDDistanceBwdTrigger 2204
2.37.38.3. Variable: BWDBeltWidth 2206
2.37.38.4. Variable: BWDCalcTriggerPreExpand 2207
2.37.38.5. Variable: BWDCalcTriggerPostExpand 2208
2.37.38.6. Variable: BWDFocusPosition 2210
2.37.38.7. Variable: BWDRCReadingAreaLimY1 2211
2.37.38.8. Variable: BWDRCReadingAreaLimY2 2213
2.37.38.9. Variable: BWDDistMeasSourceVMSNodeID 2214
2.37.38.10. Variable: BWDScannerPosAlpha 2216
2.37.38.11. Variable: BWDScannerPosBeta 2217
2.37.38.12. Variable: BWDScannerPosGamma 2218
2.37.38.13. Variable: BWDScannerPosXCoord 2220
2.37.38.14. Variable: BWDScannerPosYCoord 2221
2.37.38.15. Variable: BWDScannerPosAlphaPanorama 2223
2.37.38.16. Variable: BWDScannerPosBetaPanorama 2224
2.37.38.17. Variable: BWDScannerPosGammaPanorama 2226
2.37.38.18. Variable: BWDScannerPosXCoordPanorama 2227
2.37.38.19. Variable: BWDScannerPosYCoordPanorama 2229
2.37.38.20. Method: BWDCopyParam 2230
2.37.39. Group: ProfileCodes 2232
2.37.39.1. Variable: ProfileCodesSharedKey 2232
2.37.39.2. Variable: ProfileCodesForwardingEnabled 2233
2.37.40. Group: HostImageProcessing 2235
2.37.40.1. Variable: PMShippEnabled 2235
2.37.40.2. Variable: ShippSnapPreDelayMs 2236
2.37.40.3. Variable: ShippSnapHostTimeoutMs 2238
2.37.40.4. Variable: ShippSnapBurstLength 2239
2.37.40.5. Variable: ShippPrepSteadyTimeMs 2241
2.37.40.6. Variable: ShippPrepSteadyCount 2242
2.37.40.7. Variable: ShippPrepPostWaitMs 2244
2.37.40.8. Variable: ShippPrepModeActive 2245
2.37.40.9. Variable: ShippSnapModeActive 2246
2.37.40.10. Variable: ShippInhibitLoggingInPresentation 2248
2.37.40.11. Variable: ShippForceResultOutput 2249
2.37.40.12. Variable: ShippBeepDurationShort 2251
2.37.40.13. Variable: ShippBeepDurationLong 2252
2.37.40.14. Variable: ShippPrepTimeout 2253
2.37.40.15. Method: ShippSnapStart 2255
2.37.40.16. Method: ShippSnapPositiveFeedback 2256
2.37.40.17. Method: ShippSnapNegativeFeedback 2257
2.37.40.18. Method: ShippPrepStart 2258

© SICK AG - Germany - All rights reserved

2.37.40.19. Method: ShippPrepStop . . . 2259
2.37.41. Group: CodeMotionTracker . . . 2260
2.37.41.1. Variable: CodeMotionSteadyThreshold . . . 2260
2.37.41.2. Variable: CodeMotionTrackingEnabled . . . 2261
2.37.42. Group: StandbyMode . . . 2263
2.37.42.1. Variable: StandbyModeActive . . . 2263
2.37.43. Group: LaetusGroup . . . 2265
2.37.43.1. Variable: LaetusSerialNumber . . . 2265
2.37.43.2. Variable: LaetusDeviceName . . . 2266
2.38. Interface Block: Diag . . . 2268
2.38.1. Group: DeviceInformation . . . 2268
2.38.1.1. Variable: HasFieldbusConfigChanged . . . 2268
2.38.1.2. Method: GetEffectiveImageSize . . . 2269
2.38.1.3. Method: BootupCDF . . . 2270
2.38.2. Group: FirmwareInformation . . . 2272
2.38.2.1. Variable: OSDescription . . . 2272
2.38.3. Group: AnalogEvents . . . 2274
2.38.3.1. Variable: eConveyorSpeed . . . 2274
2.38.4. Group: Visualisation . . . 2276
2.38.4.1. Variable: BarcodeState . . . 2276
2.38.4.2. Method: ResetStatisticDisplay . . . 2277
2.38.5. Group: CodeDiag . . . 2279
2.38.5.1. Method: mTestCode . . . 2279
2.38.6. Group: DevModeDiag . . . 2281
2.38.6.1. Method: mGetDevModsRunning . . . 2281
2.38.6.2. Method: mGetDevModsPending . . . 2282
2.38.7. Group: LiveImage . . . 2283
2.38.7.1. Method: StartLiveImageMode . . . 2283
2.38.7.2. Method: StopLiveImageMode . . . 2284
2.38.8. Group: StaticImageCtrl . . . 2285
2.38.8.1. Variable: StaticImageSource . . . 2285
2.38.8.2. Variable: StaticImageMode . . . 2286
2.38.8.3. Variable: StaticImagePaused . . . 2288
2.38.8.4. Method: StaticImageStart . . . 2289
2.38.8.5. Method: StaticImageStop . . . 2290
2.38.8.6. Method: StaticImageAcquire . . . 2291
2.38.8.7. Method: StaticImageProcess . . . 2292
2.39. Interface Block: EventMonitor . . . 2293
2.39.1. Group: EventMonitor . . . 2293
2.39.1.1. Variable: EVCheckEvtAct . . . 2293
2.40. Interface Block: Fieldbus . . . 2295
2.40.1. Group: Fieldbus . . . 2295

© SICK AG - Germany - All rights reserved

2.40.1.1. Variable: ControlBitsPlcOut . . . 2295
2.40.2. Group: EthernetIPResult . . . 2297
2.40.2.1. Variable: EIPControlBitsPlcOut . . . 2297
2.40.3. Group: ProfibusCommand . . . 2299
2.40.3.1. Variable: vPBSizeFilter1DCodes . . . 2299
2.40.3.2. Variable: vPBSuperResolutionActive . . . 2301
2.40.3.3. Variable: vPBGeneral2dCodeSettingRealValue . . . 2302
2.40.3.4. Variable: vPBIllumAndAcquisitionSettings . . . 2304
2.40.3.5. Variable: vPBEndOfParam . . . 2307
2.40.3.6. Variable: vPBCommandX20 . . . 2308
2.40.3.7. Variable: vPBCommandX30 . . . 2309
2.40.3.8. Variable: vPBCommandX50 . . . 2311
2.40.3.9. Variable: vPBCommandX100 . . . 2312
2.40.3.10. Variable: vPBCommandX200 . . . 2313
2.40.3.11. Method: ExecutePBCmd . . . 2315
2.40.3.12. Method: vCdfUpDatePnConfig . . . 2316
2.40.4. Group: VirtualModbus . . . 2318
2.40.4.1. Variable: ModbusCommandWord . . . 2318
2.40.4.2. Variable: ModbusResultBuf . . . 2319
2.40.4.3. Variable: ModbusResultChangeCtr . . . 2321
2.40.5. Group: DummyGroupForVirtualMemRef_FBParamEEprom . . . 2323
2.40.5.1. Variable: Dummy_FBParamEEprom_Type . . . 2323
2.41. Interface Block: BlobTransfer . . . 2325
2.41.1. Group: CommonBlobConfig . . . 2325
2.41.1.1. Variable: BlobFragmentSize . . . 2325
2.41.1.2. Method: BlobServerGetStatistics . . . 2326
2.41.1.3. Method: BlobServerResetLocalStatistics . . . 2329
2.41.2. Group: BlobClientConfig . . . 2331
2.41.2.1. Variable: BlobTcpPort . . . 2331
2.41.2.2. Method: GetBlobClientConfig . . . 2332
2.42. Interface Block: Lector6xxHardware . . . 2335
2.42.1. Group: Optics . . . 2335
2.42.1.1. Variable: ESys . . . 2335
2.42.2. Group: FocusCtrl6xx . . . 2337
2.42.2.1. Method: GetFocusPositionIs . . . 2337
2.42.2.2. Method: GetMotorPosMinMax . . . 2338
2.42.2.3. Method: SetMotorPosAbsolute . . . 2339
2.42.2.4. Method: SetMotorPosRelative . . . 2340
2.42.2.5. Method: GetMotorRotationAngle . . . 2341
2.42.2.6. Method: GetMMPerPixel . . . 2342
2.42.2.7. Method: GetMotorPos . . . 2344
2.42.2.8. Method: DisableLiquidLensOutput . . . 2345

© SICK AG - Germany - All rights reserved

2.42.3. Group: FPGA . . . 2346
2.42.3.1. Method: DumpIOMUX . . . 2346
2.42.3.2. Method: ExecFpgaDeveloperCommand . . . 2347
2.42.4. Group: DebugMisc . . . 2349
2.42.4.1. Method: TracingStop . . . 2349
2.42.5. Group: Imager . . . 2350
2.42.5.1. Variable: GeneralImgOutActive . . . 2350
2.42.5.2. Method: RequestFrameStatistics . . . 2351
2.42.5.3. Method: CuckooImageLoad . . . 2354
2.42.5.4. Method: CuckooImageClear . . . 2355
2.42.6. Group: OutputHardware2 . . . 2356
2.42.6.1. Method: MAX14820ReadRegisters . . . 2356
2.42.6.2. Method: MAX14820WriteRegisters . . . 2357
2.42.7. Group: Temperature . . . 2358
2.42.7.1. Method: TemperatureGetValues . . . 2358
2.42.8. Group: ToFSensorMeasurement . . . 2361
2.42.8.1. Variable: ToFDisabledForCompliance . . . 2361
2.42.8.2. Method: ToFSingleshotStart . . . 2362
2.42.8.3. Method: ToFContinuousMeasurementStart . . . 2363
2.42.8.4. Method: ToFStopAllMeasurements . . . 2364
2.43. Interface Block: CDF600_Types . . . 2365
2.43.1. Group: _CDF_SystemPublic . . . 2365
2.43.1.1. Method: CDF_ReadParameterSetSegment . . . 2365
2.43.1.2. Method: CDF_WriteParameterSetSegment . . . 2366
2.43.1.3. Method: CDF_FlashParameterFile . . . 2368
2.43.1.4. Method: CDF_EraseParameterFile . . . 2369
3. User Types . . . 2371
3.1. Type: CidVersion . . . 2371
3.2. Type: OCRRegionPrimitive . . . 2372
3.3. Type: ErrTimeType . . . 2373
3.4. Type: ErrStructType . . . 2373
3.5. Type: SETEM_Binary . . . 2374
3.6. Type: SETEM_Analog . . . 2374
3.7. Type: SETEM_String . . . 2375
3.8. Type: SETEditExtendibleEnum . . . 2375
3.9. Type: SETEditExtendibleEnumSize6 . . . 2376
3.10. Type: eUsePredConnSetType . . . 2376
3.11. Type: ProfinetFixed . . . 2376
3.12. Type: Asci127_t . . . 2377
3.13. Type: Asci127AndObject_t . . . 2381
3.14. Type: Asci127AndCode_t . . . 2385
3.15. Type: Temperature . . . 2389

© SICK AG - Germany - All rights reserved

3.16. Type: TempSensArray_t . . . 2390
3.17. Type: DPSSet . . . 2390
3.18. Type: DPSColorType . . . 2391
3.19. Type: DPSIllu61xLedStates . . . 2392
3.20. Type: E_USER_LEVEL_TYPE . . . 2392
4. Error Codes . . . 2393
4.1. Error Level . . . 2393
4.2. LECTOR65x . . . 2393
4.2.1. FOCUS . . . 2393
4.2.2. IMG_SENSOR_ACQ_DRIVER . . . 2393
4.2.3. OUTPUTS . . . 2394
4.2.4. MAIN . . . 2394
4.2.5. IMAGEOUTPUT . . . 2395
4.2.6. TEMPERATURE_OBSERVER . . . 2395
4.2.7. MLG . . . 2395
4.3. LECTOR6xx . . . 2396
4.3.1. EXTERNAL_DEVICES . . . 2396
4.3.2. IMG_ACQ_CTRL . . . 2396
4.3.3. DEVICE_MODE . . . 2397
4.3.4. AUTO_SETUP . . . 2398
4.3.5. BLOB_SERVER . . . 2398
4.3.6. IMAGE_LOGGING_UPLOAD . . . 2398
4.3.7. OS . . . 2399
4.3.8. FILESYSTEM_LECTOR . . . 2399
4.3.9. TIME_CONTROL . . . 2399
4.3.10. ETHERNETIP . . . 2400
4.3.11. SVP . . . 2400
4.3.12. NETINTERFACE_LOGGING_UPLOAD . . . 2400
4.3.13. FPGA . . . 2401
4.3.14. PROFINET . . . 2401
4.4. BASE . . . 2401
4.4.1. GENERAL . . . 2401
4.4.2. TESTERRORS . . . 2402
4.4.3. CSAD_CSFD . . . 2402
4.5. CAN1 . . . 2403
4.5.1. CAN1_GENERAL . . . 2403
4.6. NETWORK . . . 2404
4.6.1. NETWORK_GENERAL . . . 2404
4.6.2. NETWORK_MONITOR . . . 2404
4.7. FILESYSTEM . . . 2405
4.7.1. FILESYSTEM_GENERAL . . . 2405
4.8. ETHERNET . . . 2405

© SICK AG - Germany - All rights reserved

4.8.1. ETHERNET_GENERAL 2405
4.9. ObjAdmin 2406
4.9.1. OBJECT_ADMIN 2406
4.10. TriggerCtrl 2406
4.10.1. TRIGGER_CTRL 2406
Index 2407

© SICK AG - Germany - All rights reserved

© SICK AG - Germany - All rights reserved

1. General

1.1. Introduction

This document describes the functional interfaces of the GLS621 device, 4.14.0.21R. The GLS621 device is a SOPAS device. SOPAS devices have Variables, Methods and Events. Variables can always be read and in some cases be written by user.

1.2. User Level

Whether a Variable can be written by user depends on the least user level. Defined user levels are:

ID	Name
0	Always (Run)
1	Operator
2	Maintenance
3	AuthorizedClient
4	Service

Table 1: User Levels

1.3. Methods

Methods can be invoked by using certain parameters. The method will return with a structure of one or more return values. If a Method can be invoked depends as well on the least user level (see above).

1.4. Events

Events can be registered and will then be fired by the device to the registered client. Most Events have parameters which are the data coming with the Event.

1.5. Datatypes

All items of the interface have certain data elements. These are the Variables itself, the parameters of Methods and Events and the return values of the Methods.

The structure of the data elements can be one of the following BasicType(s), Structures or Arrays.

Basic Type

Name	Description	Range of values
Bool	boolean	True(1), False(0)
USInt	unsigned short (8 bit)	(0..255)
UInt	unsigned int (16 bit)	(0..65535)
UDInt	unsigned double int (32 bit)	(0..4294967295)
SInt	signed short (8 bit)	(-128..127)
Int	signed int (16 bit)	(-32768..32767)
DInt	signed double int (32 bit)	(-2147483648..2147483647)
LInt	signed long int (64 bit)	(-9223372036854775808..9223372036854775807)
Real	IEEE-754 single precision (32 bit) (float)	See specification in IEEE-754
LReal	IEEE-754 single precision (64 bit) (double)	See specification in IEEE-754

© SICK AG - Germany - All rights reserved

Name	Description	Range of values
Enum8	short enumeration (8 bit)	certain values defined in a list of choises (0-255)
Enum16	short enumeration (16 bit)	certain values defined in a list of choises (0-65535)
String	array of visible characters (array of 8 bit)	a character = an USInt with values between 0x20..0xFF
FlexString	array of visible characters with preeding current length (UInt lenght) (array of 8 bit)	See description of String and FlexArray
Byte	bitset definition (8 bit). Detailed specification of bits UInt1..UInt16 = UInt (1..16 bit) Int1..Int16 = Int (1..16 bit) Enum1..Enum16 = Enum16 (1..16 bit) Bool = Bool (1 bit)	value is transfered as an array of USInt. See "XByte Serialisation" document for further details on bit ordering
Word	bitset definition (16 bit), see description of Byte	value is transfered as an array of USInt see "XByte Serialisation" document for further details on bit ordering.
DWord	bitset definition (32 bit), see description of Byte	value is transfered as an array of USInt see "XByte Serialisation" document for further details on bit ordering.
LWord	bitset definition (64 bit), see description of Byte	value is transfered as an array of USInt see "XByte Serialisation" document for further details on bit ordering.
XByte	bitset definition (8,16,24,32,... bit) see description of Byte	value is transfered as an array of USInt see "XByte Serialisation" document for further details on bit ordering.

Table 2: Basic Datatypes

Struct

A structure is a sequence of further types. These types can be of a BasicType, Structs again or an Array.

Array

An Array is a repetition of a type. The length of the array is defined with each Array. The types can be of a BasicType, a Struct or an Array again (n- dimensional).

Flex Array

A FlexArray is a repetition of a type with a variable length. The maximum length of the array is defined with each FlexArray. The current length of the FlexArray is transferred as a UInt preceeding the Array itself. The types can be of a BasicType, a Struct or an Array again (n- dimensional).

© SICK AG - Germany - All rights reserved

2. Interfaces

2.1. Interface Block: S_Standard

2.1.1. Group: V100

2.1.1.1. Variable: LocationName

The following section contains a detailed description of the variable LocationName.

Variable Overview

Variable Name	Description
LocationName	Location of Device (set by user)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	2 (fixed)
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..240
Initialisation	not defined

Variable Telegram Syntax

Read Variable:				
`sRN LocationName`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LocationName	String	12	Location of Device (set by user)

Read Variable Response:				
`sRA LocationName <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LocationName	String	12	Location of Device (set by user)
Variable Data	data	FlexString	240	

Write Variable:				
`sWN LocationName <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LocationName	String	12	Location of Device (set by user)
Variable Data	data	FlexString	240	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LocationName				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LocationName	String	12	Location of Device (set by user)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LocationName[ETX]
Read Variable Response:	[STX]sRA LocationName B not defined[ETX]
Write Variable:	[STX]sWN LocationName B not defined[ETX]
Write Variable Response:	[STX]sWA LocationName[ETX]

2.1.1.2. Method: SetAccessMode

The following section contains a detailed description of the method SetAccessMode.

Method Overview

Method Name	Description
SetAccessMode	Change operation mode returns True, if successful

Sopas Index	0 (fixed)
Invocation Access	Always

Parameters		
NewMode		
	SInt	
	Value Range	-128..127
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
Password		hash value
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Return Values		
success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN SetAccessMode <NewMode> <Password>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	SetAccessMode	String	13	Change operation mode returns True, if successful
Parameter 1	NewMode	SInt	1	
Parameter 2	Password	UDInt	4	hash value

Method Return Value:				
`sAN SetAccessMode <success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	SetAccessMode	String	13	Change operation mode returns True, if successful
Return Value 1	success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN SetAccessMode 0 0[ETX]`
Method Return Value:	`[STX]sAN SetAccessMode 0[ETX]`

2.1.1.3. Method: NotifyMode

The following section contains a detailed description of the method NotifyMode.

Method Overview

Method Name	**Description**
NotifyMode	Decoupling login from sensor mode. This function will be called before and after something is written

Sopas Index	3
Invocation Access	Always

Parameters				
NewMode				
	Enum8			
		Value	Name	Description
		0	ENDWRITE	
		1	BEGINWRITE	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN NotifyMode <NewMode>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	NotifyMode	String	10	Decoupling login from sensor mode. This function will be called before and after something is written
Parameter 1	NewMode	Enum8	1	

Method Return Value:				
`sAN NotifyMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	NotifyMode	String	10	Decoupling login from sensor mode. This function will be called before and after something is written

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN NotifyMode 0[ETX]`
Method Return Value:	`[STX]sAN NotifyMode[ETX]`

2.1.1.4. Method: GetAccessMode

The following section contains a detailed description of the method GetAccessMode.

Method Overview

Method Name	Description
GetAccessMode	returns actual operation mode

Sopas Index	1 (fixed)
Invocation Access	Always

Return Values		
opmode		
	SInt	
	Value Range	-128..127
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN GetAccessMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetAccessMode	String	13	returns actual operation mode

Method Return Value:				
`sAN GetAccessMode <opmode>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetAccessMode	String	13	returns actual operation mode
Return Value 1	opmode	SInt	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetAccessMode[ETX]`
Method Return Value:	`[STX]sAN GetAccessMode 0[ETX]`

2.1.1.5. Method: Run

The following section contains a detailed description of the method Run.

Method Overview

Method Name	Description
Run	Change operation mode to "Run"

Sopas Index	2 (fixed)
Invocation Access	Always

Return Values		
success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN Run				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	Run	String	3	Change operation mode to "Run"

Method Return Value:				
sAN Run <success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	Run	String	3	Change operation mode to "Run"
Return Value 1	success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN Run[ETX]
Method Return Value:	[STX]sAN Run 0[ETX]

2.1.1.6. Method: GetDescription

The following section contains a detailed description of the method GetDescription.

Method Overview

Method Name
GetDescription

Sopas Index	4 (fixed)
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Parameters			
eType			
	Enum8		
	Default Value	CID	
	Value	Name	Description
	1	CID	
	2	ShortUDD	
	3	PMD	
	4	Jar	
	5	CidPMD	
	6	Eip2PMD	
	7	ChInfo	
	8	AVC	
	9	Profibus	
	10	Profibus2	
	11	CanOpen	
	12	EcatPMD	
	13	Profibus3	
uiSegmentNumber			
	UInt		
	Value Range	0..65535	
	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	

Return Values			
eState			
	Enum8		
	Value	Name	Description
	0	TypeNotSupported	
	1	SegmentOutOfRange	
	2	FirstSegment	
	3	NormalSegment	
	4	LastSegment	
uiSegmentNumber			
	UInt		
	Value Range	0..65535	
	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	
aByteStream			
	Array		
	Length	0..256	
	USInt		
	Value Range	0..255	
	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN GetDescription <eType> <uiSegmentNumber>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetDescription	String	14	
Parameter 1	eType	Enum8	1	
Parameter 2	uiSegmentNumber	UInt	2	

Method Return Value:				
`sAN GetDescription <eState> <uiSegmentNumber> <aByteStream>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetDescription	String	14	
Return Value 1	eState	Enum8	1	
Return Value 2	uiSegmentNumber	UInt	2	
Return Value 3	aByteStream	Array	256	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetDescription 1 0[ETX]`
Method Return Value:	`[STX]sAN GetDescription 0 0 0[ETX]`

© SICK AG - Germany - All rights reserved

2.1.2. Group: V200

2.1.2.1. Method: GetChallenge

The following section contains a detailed description of the method GetChallenge.

Method Overview

Method Name
GetChallenge

Sopas Index	6
Invocation Access	Always

Return Values			
result			
	Enum8		
	Value	Name	Description
	0	SUCCESS	
	1	INVALID_CLIENT	
	2	NOT_ACCEPTED	
challenge			
	Array		
	Length	16	
	USInt		
	Value Range	0..255	
	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	

Method Telegram Syntax

Method Invocation:
`sMN GetChallenge`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetChallenge	String	12	

Method Return Value:
`sAN GetChallenge <result> <challenge>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetChallenge	String	12	
Return Value 1	result	Enum8	1	
Return Value 2	challenge	Array	16	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetChallenge[ETX]`
Method Return Value:	`[STX]sAN GetChallenge 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0[ETX]`

2.1.2.2. Method: SetUserLevel

The following section contains a detailed description of the method SetUserLevel.

Method Overview

Method Name
SetUserLevel

Sopas Index	7
Invocation Access	Always

Parameters			
challengeResponse			
	Array		
	Length		32
		USInt	
		Value Range	0..255
		Initialisation	
		Physical Unit	
		Physical Unit Factor	0.0
userLevel			
	UserType		
	E_USER_LEVEL_TYPE		See the chapter "User Types" for details.

Return Values				
result				
	Enum8			
		Value	Name	Description
		0	SUCCESS	
		1	INVALID_CLIENT	
		2	NOT_ACCEPTED	
		3	UNKNOWN_CHALLENGE	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN SetUserLevel <challengeResponse> <userLevel>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	SetUserLevel	String	12	
Parameter 1	challengeResponse	Array	32	
Parameter 2	userLevel	E_USER_LEVEL_TYPE	0	

Method Return Value:				
`sAN SetUserLevel <result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	SetUserLevel	String	12	
Return Value 1	result	Enum8	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN SetUserLevel[ETX]`
Method Return Value:	`[STX]sAN SetUserLevel 0[ETX]`

2.1.2.3. Method: ChangePassword

The following section contains a detailed description of the method ChangePassword.

Method Overview

Method Name
ChangePassword

Sopas Index	8
Invocation Access	Always

Parameters			
encryptedMessage			
	Array		
	Length		0..1024
		USInt	
		Value Range	0..255
		Initialisation	
		Physical Unit	
		Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Parameters		
userLevel		
	UserType	
	E_USER_LEVEL_TYPE	See the chapter "User Types" for details.

Return Values			
result			
	Enum8		
	Value	Name	Description
	0	SUCCESS	
	1	INVALID_CLIENT	
	2	NOT_ACCEPTED	
	4	PWD_NOT_CHANGABLE	

Method Telegram Syntax

Method Invocation:

```
sMN ChangePassword <encryptedMessage> <userLevel>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ChangePassword	String	14	
Parameter 1	encryptedMessage	Array	1024	
Parameter 2	userLevel	E_USER_LEVEL_TYPE	0	

Method Return Value:

```
sAN ChangePassword <result>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ChangePassword	String	14	
Return Value 1	result	Enum8	1	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN ChangePassword[ETX]`
Method Return Value:	`[STX]sAN ChangePassword 0[ETX]`

© SICK AG - Germany - All rights reserved

2.1.3. Group: Optional

2.1.3.1. Method: SetPassword

The following section contains a detailed description of the method SetPassword.

Method Overview

Method Name
SetPassword

Sopas Index	9
Invocation Access	Always

Parameters		
siUserLevel		
	SInt	
	Value Range	-128..127
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
udiNewPassword		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Return Values		
bSuccess		
	Bool	
	Value Range	False, True
	Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN SetPassword <siUserLevel> <udiNewPassword>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	SetPassword	String	11	
Parameter 1	siUserLevel	SInt	1	
Parameter 2	udiNewPassword	UDInt	4	

Method Return Value:				
`sAN SetPassword <bSuccess>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	SetPassword	String	11	

© SICK AG - Germany - All rights reserved

Method Return Value:				
sAN SetPassword <bSuccess>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Return Value 1	bSuccess	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN SetPassword 0 0[ETX]
Method Return Value:	[STX]sAN SetPassword 0[ETX]

2.1.3.2. Method: CheckPassword

The following section contains a detailed description of the method CheckPassword.

Method Overview

Method Name
CheckPassword

Sopas Index	5 (fixed)
Invocation Access	Always

Parameters	
siUserLevel	
SInt	
Value Range	-128..127
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
udiPassword	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
bSuccess	
Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN CheckPassword <siUserLevel> <udiPassword>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	CheckPassword	String	13	
Parameter 1	siUserLevel	SInt	1	
Parameter 2	udiPassword	UDInt	4	

Method Return Value:				
`sAN CheckPassword <bSuccess>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	CheckPassword	String	13	
Return Value 1	bSuccess	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN CheckPassword 0 0[ETX]`
Method Return Value:	`[STX]sAN CheckPassword 0[ETX]`

© SICK AG - Germany - All rights reserved

2.1.4. Group: fileMethods

2.1.4.1. Method: GenOpenFile

The following section contains a detailed description of the method GenOpenFile.

Method Overview

Method Name	Description
GenOpenFile	Open selected file

Communication Name	OpenFile
Sopas Index	10 (fixed)
Invocation Access	Always

Parameters		
Name		
	FlexString	
	Length	0..256
	Initialisation	
Mode		
	FlexString	
	Length	0..5
	Initialisation	

Return Values		
State		
	Int	
	Value Range	-32768..32767
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
FileHandle		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN OpenFile <Name> <Mode>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	OpenFile	String	8	Open selected file
Parameter 1	Name	FlexString	256	
Parameter 2	Mode	FlexString	5	

Method Return Value:				
`sAN OpenFile <State> <FileHandle>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	OpenFile	String	8	Open selected file
Return Value 1	State	Int	2	
Return Value 2	FileHandle	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN OpenFile 0 0[ETX]`
Method Return Value:	`[STX]sAN OpenFile 0 0[ETX]`

2.1.4.2. Method: GenCloseFile

The following section contains a detailed description of the method GenCloseFile.

Method Overview

Method Name	Description
GenCloseFile	Close selected file

Communication Name	CloseFile
Sopas Index	11 (fixed)
Invocation Access	Always

Parameters	
FileHandle	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
State	
Int	
Value Range	-32768..32767
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN CloseFile <FileHandle>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	CloseFile	String	9	Close selected file
Parameter 1	FileHandle	UDInt	4	

Method Return Value:				
`sAN CloseFile <State>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	CloseFile	String	9	Close selected file
Return Value 1	State	Int	2	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN CloseFile 0[ETX]`
Method Return Value:	`[STX]sAN CloseFile 0[ETX]`

2.1.4.3. Method: GenReadFile

The following section contains a detailed description of the method GenReadFile.

Method Overview

Method Name	Description
GenReadFile	Read selected file

Communication Name	ReadFile
Sopas Index	13 (fixed)
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Parameters		
FileHandle		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
SequenceNumber		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Return Values			
State			
	Int		
	Value Range		-32768..32767
	Initialisation		
	Physical Unit		
	Physical Unit Factor		0.0
Data			
	Array		
	Length		0..256
		USInt	
		Value Range	0..255
		Initialisation	
		Physical Unit	
		Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN ReadFile <FileHandle> <SequenceNumber>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ReadFile	String	8	Read selected file
Parameter 1	FileHandle	UDInt	4	
Parameter 2	SequenceNumber	UDInt	4	

Method Return Value:

```
sAN ReadFile <State> <Data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ReadFile	String	8	Read selected file
Return Value 1	State	Int	2	
Return Value 2	Data	Array	256	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ReadFile 0 0[ETX]`
Method Return Value:	`[STX]sAN ReadFile 0 0[ETX]`

2.1.4.4. Method: GenWriteFile

The following section contains a detailed description of the method GenWriteFile.

Method Overview

Method Name	**Description**
GenWriteFile	Write selected file

Communication Name	WriteFile
Sopas Index	14 (fixed)
Invocation Access	Always

Parameters		
FileHandle		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
Data		
	Array	
	Length	0..256
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
SequenceNumber		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
State	
Int	
Value Range	-32768..32767
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN WriteFile <FileHandle> <Data> <SequenceNumber>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	WriteFile	String	9	Write selected file
Parameter 1	FileHandle	UDInt	4	
Parameter 2	Data	Array	256	
Parameter 3	SequenceNumber	UDInt	4	

Method Return Value:

```
sAN WriteFile <State>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	WriteFile	String	9	Write selected file
Return Value 1	State	Int	2	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN WriteFile 0 0 0[ETX]`
Method Return Value:	`[STX]sAN WriteFile 0[ETX]`

© SICK AG - Germany - All rights reserved

2.1.4.5. Method: GetFileSyncValue

The following section contains a detailed description of the method GetFileSyncValue.

Method Overview

Method Name	Description
GetFileSyncValue	get Sync Value for file

Sopas Index	15 (fixed)
Invocation Access	Always

Parameters	
Name	
FlexString	
Length	0..256
Initialisation	

Return Values	
HashValue	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN GetFileSyncValue <Name>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetFileSyncValue	String	16	get Sync Value for file
Parameter 1	Name	FlexString	256	

Method Return Value:

```
sAN GetFileSyncValue <HashValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetFileSyncValue	String	16	get Sync Value for file
Return Value 1	HashValue	UDInt	4	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetFileSyncValue 0[ETX]`
Method Return Value:	`[STX]sAN GetFileSyncValue 0[ETX]`

2.1.4.6. Method: GetFileSize

The following section contains a detailed description of the method GetFileSize.

Method Overview

Method Name	Description
GetFileSize	get file size

Sopas Index	16 (fixed)
Invocation Access	Always

Parameters	
State	
Int	
Value Range	-32768..32767
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
FileHandle	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
FileSize	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN GetFileSize <State> <FileHandle>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetFileSize	String	11	get file size
Parameter 1	State	Int	2	
Parameter 2	FileHandle	UDInt	4	

Method Return Value:				
`sAN GetFileSize <FileSize>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetFileSize	String	11	get file size
Return Value 1	FileSize	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetFileSize 0 0[ETX]`
Method Return Value:	`[STX]sAN GetFileSize 0[ETX]`

© SICK AG - Germany - All rights reserved

2.2. Interface Block: GeneralCfgBase

2.2.1. Group: EEprom

2.2.1.1. Method: ReadEeprom

The following section contains a detailed description of the method ReadEeprom.

Method Overview

Method Name	Description
ReadEeprom	Method reads all permanent parameters from the ParamEEprom into the mirror

Communication Name	mEEreadall
Sopas Index	12
Invocation Access	AuthorizedClient, Service

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mEEreadall
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEEreadall	String	10	Method reads all permanent parameters from the ParamEEprom into the mirror

Method Return Value:

```
sAN mEEreadall <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEEreadall	String	10	Method reads all permanent parameters from the ParamEEprom into the mirror
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEEreadall[ETX]`
Method Return Value:	`[STX]sAN mEEreadall 0[ETX]`

2.2.1.2. Method: WriteEeprom

The following section contains a detailed description of the method WriteEeprom.

Method Overview

Method Name	Description
WriteEeprom	Method writes all permanent parameters from the SOPAS mirror to the ParamEEprom

Communication Name	mEEwriteall
Sopas Index	17
Invocation Access	AuthorizedClient, Service

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN mEEwriteall`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEEwriteall	String	11	Method writes all permanent parameters from the SOPAS mirror to the ParamEEprom

Method Return Value:				
`sAN mEEwriteall <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEEwriteall	String	11	Method writes all permanent parameters from the SOPAS mirror to the ParamEEprom
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEEwriteall[ETX]`
Method Return Value:	`[STX]sAN mEEwriteall 0[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2. Group: SystemControl

2.2.2.1. Variable: SCTimeFormat

The following section contains a detailed description of the variable SCTimeFormat.

Variable Overview

Variable Name	Description
SCTimeFormat	Defines the time format

Communication Name	SCtimeformat
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	13
Read-Access	AuthorizedClient, Service
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	OpHours	
	1	RealTime	

Variable Telegram Syntax

Read Variable:				
`sRN SCtimeformat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SCtimeformat	String	12	Defines the time format

Read Variable Response:				
`sRA SCtimeformat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SCtimeformat	String	12	Defines the time format
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SCtimeformat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SCtimeformat	String	12	Defines the time format
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SCtimeformat				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SCtimeformat	String	12	Defines the time format

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SCtimeformat[ETX]
Read Variable Response:	[STX]sRA SCtimeformat 0[ETX]
Write Variable:	[STX]sWN SCtimeformat 0[ETX]
Write Variable Response:	[STX]sWA SCtimeformat[ETX]

2.2.2.2. Variable: SCUserInterfaceVariant

The following section contains a detailed description of the variable SCUserInterfaceVariant.

Variable Overview

Variable Name	Description
SCUserInterfaceVariant	Defines which kind of User interface has been used for parametrization. Variable may be set by the OnDeviceAdded-Hook

Communication Name	SCUIVers
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	15
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_SOPAS_ET_STANDARD	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SCUIVers`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SCUIVers	String	8	Defines which kind of User interface has been used for parametrization. Variable may be set by the OnDeviceAdded-Hook

Read Variable Response:				
`sRA SCUIVers <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SCUIVers	String	8	Defines which kind of User interface has been used for parametrization. Variable may be set by the OnDeviceAdded-Hook
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SCUIVers <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SCUIVers	String	8	Defines which kind of User interface has been used for parametrization. Variable may be set by the OnDeviceAdded-Hook
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SCUIVers`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SCUIVers	String	8	Defines which kind of User interface has been used for parametrization. Variable may be set by the OnDeviceAdded-Hook

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SCUIVers[ETX]`
Read Variable Response:	`[STX]sRA SCUIVers 0[ETX]`
Write Variable:	`[STX]sWN SCUIVers 0[ETX]`
Write Variable Response:	`[STX]sWA SCUIVers[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2.3. Method: SoftReset

The following section contains a detailed description of the method SoftReset.

Method Overview

Method Name	Description
SoftReset	Method executes a software reset on the device

Communication Name	mSCsoftreset
Sopas Index	20
Invocation Access	AuthorizedClient, Service

Parameters	
ProcessorNbr	
UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mSCsoftreset <ProcessorNbr>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCsoftreset	String	12	Method executes a software reset on the device
Parameter 1	ProcessorNbr	UInt	2	

Method Return Value:

```
sAN mSCsoftreset
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCsoftreset	String	12	Method executes a software reset on the device

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mSCsoftreset 0[ETX]`
Method Return Value:	`[STX]sAN mSCsoftreset[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2.4. Method: RebootDevice

The following section contains a detailed description of the method RebootDevice.

Method Overview

Method Name	Description
RebootDevice	Method shuts the device down but saves the parameter before shutdown ist executed

Communication Name	mSCreboot
Sopas Index	21
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mSCreboot`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCreboot	String	9	Method shuts the device down but saves the parameter before shutdown ist executed

Method Return Value:				
`sAN mSCreboot`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCreboot	String	9	Method shuts the device down but saves the parameter before shutdown ist executed

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCreboot[ETX]`
Method Return Value:	`[STX]sAN mSCreboot[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2.5. Method: LoadFactoryDefaults

The following section contains a detailed description of the method LoadFactoryDefaults.

Method Overview

Method Name	Description
LoadFactoryDefaults	The method resets all variables to their default value.

Communication Name	mSCloadfacdef
Sopas Index	22
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mSCloadfacdef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCloadfacdef	String	13	The method resets all variables to their default value.

Method Return Value:				
`sAN mSCloadfacdef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCloadfacdef	String	13	The method resets all variables to their default value.

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCloadfacdef[ETX]`
Method Return Value:	`[STX]sAN mSCloadfacdef[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2.6. Method: LoadApplicationDefaults

The following section contains a detailed description of the method LoadApplicationDefaults.

Method Overview

Method Name	Description
LoadApplicationDefaults	The method resets all application relevant variables to their default value

Communication Name	mSCloadappdef
Sopas Index	23
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mSCloadappdef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCloadappdef	String	13	The method resets all application relevant variables to their default value

Method Return Value:				
`sAN mSCloadappdef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCloadappdef	String	13	The method resets all application relevant variables to their default value

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCloadappdef[ETX]`
Method Return Value:	`[STX]sAN mSCloadappdef[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2.7. Method: SetPasswordDefaults

The following section contains a detailed description of the method SetPasswordDefaults.

Method Overview

Method Name	Description
SetPasswordDefaults	Sets the password defaults.

Communication Name	mSCsetpwdef
Sopas Index	25
Invocation Access	Service

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN mSCsetpwdef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCsetpwdef	String	11	Sets the password defaults.

Method Return Value:				
`sAN mSCsetpwdef <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCsetpwdef	String	11	Sets the password defaults.
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCsetpwdef[ETX]`
Method Return Value:	`[STX]sAN mSCsetpwdef 0[ETX]`

© SICK AG - Germany - All rights reserved

2.2.2.8. Method: SelfTest

The following section contains a detailed description of the method SelfTest.

Method Overview

Method Name	Description
SelfTest	The method forces the device to execute a self test. Return value 0 means self test was successful

Communication Name	mSCselftest
Sopas Index	26
Invocation Access	Always

Return Values		
ErrorCode		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mSCselftest`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCselftest	String	11	The method forces the device to execute a self test. Return value 0 means self test was successful

Method Return Value:				
`sAN mSCselftest <ErrorCode>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCselftest	String	11	The method forces the device to execute a self test. Return value 0 means self test was successful
Return Value 1	ErrorCode	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCselftest[ETX]`
Method Return Value:	`[STX]sAN mSCselftest 0[ETX]`

© SICK AG - Germany - All rights reserved

2.2.3. Group: FirmwareDownload2nd

2.2.3.1. Method: Start2ndStageLoader

The following section contains a detailed description of the method Start2ndStageLoader.

Method Overview

Method Name	Description
Start2ndStageLoader	Method starts the second-stage loader and publishes for which processor the following the following data are intended

Communication Name	mFDsrt2ndstgldr
Sopas Index	27
Invocation Access	Service

Parameters	
Parameter	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mFDsrt2ndstgldr <Parameter>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDsrt2ndstgldr	String	15	Method starts the second-stage loader and publishes for which processor the following the following data are intended
Parameter 1	Parameter	DInt	4	

Method Return Value:

```
sAN mFDsrt2ndstgldr <Handle>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDsrt2ndstgldr	String	15	Method starts the second-stage loader and publishes for which processor the following the following data are intended
Return Value 1	Handle	DInt	4	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDsrt2ndstgldr 0[ETX]`
Method Return Value:	`[STX]sAN mFDsrt2ndstgldr 0[ETX]`

2.2.3.2. Method: LogWrite

The following section contains a detailed description of the method LogWrite.

Method Overview

Method Name	Description
LogWrite	Transfer logging data

Communication Name	mFDlogwrite
Sopas Index	28
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
LogData	
FlexString	
Length	0..256
Initialisation	

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mFDlogwrite <Handle> <LogData>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDlogwrite	String	11	Transfer logging data
Parameter 1	Handle	DInt	4	
Parameter 2	LogData	FlexString	256	

Method Return Value:				
sAN mFDlogwrite <Result>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDlogwrite	String	11	Transfer logging data
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mFDlogwrite 0 0[ETX]
Method Return Value:	[STX]sAN mFDlogwrite 0[ETX]

2.2.3.3. Method: LogEnd

The following section contains a detailed description of the method LogEnd.

Method Overview

Method Name	Description
LogEnd	Ends logging data

Communication Name	mFDlogend
Sopas Index	29
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFDlogend <Handle>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDlogend	String	9	Ends logging data
Parameter 1	Handle	DInt	4	

Method Return Value:				
`sAN mFDlogend <Result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDlogend	String	9	Ends logging data
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDlogend 0[ETX]`
Method Return Value:	`[STX]sAN mFDlogend 0[ETX]`

2.2.3.4. Method: LogInfo

The following section contains a detailed description of the method LogInfo.

Method Overview

Method Name	Description
LogInfo	Informs about free logging space

Communication Name	mFDloginfo
Sopas Index	30
Invocation Access	Service

© SICK AG - Germany - All rights reserved

Return Values	
Size	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFDloginfo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDloginfo	String	10	Informs about free logging space

Method Return Value:				
`sAN mFDloginfo <Size>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDloginfo	String	10	Informs about free logging space
Return Value 1	Size	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDloginfo[ETX]`
Method Return Value:	`[STX]sAN mFDloginfo 0[ETX]`

2.2.3.5. Method: LogErase

The following section contains a detailed description of the method LogErase.

Method Overview

Method Name	Description
LogErase	Deletes the log fle

Communication Name	mFDlogerase
Sopas Index	31
Invocation Access	Service

© SICK AG - Germany - All rights reserved

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mFDlogerase <Handle>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDlogerase	String	11	Deletes the log fle
Parameter 1	Handle	DInt	4	

Method Return Value:

```
sAN mFDlogerase <Result>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDlogerase	String	11	Deletes the log fle
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mFDlogerase 0[ETX]`
Method Return Value:	`[STX]sAN mFDlogerase 0[ETX]`

© SICK AG - Germany - All rights reserved

2.2.3.6. Method: StartMemCardUpdate

The following section contains a detailed description of the method StartMemCardUpdate.

Method Overview

Method Name	Description
StartMemCardUpdate	Starts the firmware update from a memory card.

Communication Name	mFDstrMCupdt
Sopas Index	32
Invocation Access	Service

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFDstrMCupdt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDstrMCupdt	String	12	Starts the firmware update from a memory card.

Method Return Value:				
`sAN mFDstrMCupdt <Result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDstrMCupdt	String	12	Starts the firmware update from a memory card.
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDstrMCupdt[ETX]`
Method Return Value:	`[STX]sAN mFDstrMCupdt 0[ETX]`

© SICK AG - Germany - All rights reserved

2.3. Interface Block: DiagBase

2.3.1. Group: DeviceInformationBase

2.3.1.1. Variable: LastMaintenance

The following section contains a detailed description of the variable LastMaintenance.

Variable Overview

Variable Name	Description
LastMaintenance	Date of last maintenance

Communication Name	DIlstmt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	32
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	DD.MM.YYYY

Variable Telegram Syntax

Read Variable:

```
sRN DIlstmt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIlstmt	String	7	Date of last maintenance

Read Variable Response:

```
sRA DIlstmt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIlstmt	String	7	Date of last maintenance
Variable Data	data	FlexString	10	

Write Variable:

```
sWN DIlstmt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIlstmt	String	7	Date of last maintenance
Variable Data	data	FlexString	10	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIlstmt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIlstmt	String	7	Date of last maintenance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIlstmt[ETX]
Read Variable Response:	[STX]sRA DIlstmt A DD.MM.YYYY[ETX]
Write Variable:	[STX]sWN DIlstmt A DD.MM.YYYY[ETX]
Write Variable Response:	[STX]sWA DIlstmt[ETX]

2.3.1.2. Variable: NextMaintenance

The following section contains a detailed description of the variable NextMaintenance.

Variable Overview

Variable Name	Description
NextMaintenance	Date of Next maintenance

Communication Name	DInxtmt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	33
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	10
Initialisation	DD.MM.YYYY

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DInxtmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DInxtmt	String	7	Date of Next maintenance

Read Variable Response:				
`sRA DInxtmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DInxtmt	String	7	Date of Next maintenance
Variable Data	data	String	10	

Write Variable:				
`sWN DInxtmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DInxtmt	String	7	Date of Next maintenance
Variable Data	data	String	10	

Write Variable Response:				
`sWA DInxtmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DInxtmt	String	7	Date of Next maintenance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DInxtmt[ETX]`
Read Variable Response:	`[STX]sRA DInxtmt DD.MM.YYYY[ETX]`
Write Variable:	`[STX]sWN DInxtmt DD.MM.YYYY[ETX]`
Write Variable Response:	`[STX]sWA DInxtmt[ETX]`

© SICK AG - Germany - All rights reserved

2.3.1.3. Method: SetLastUser

The following section contains a detailed description of the method SetLastUser.

Method Overview

Method Name	Description
SetLastUser	Method defines the last user and last date parameters

Communication Name	mDIsetlast
Sopas Index	35
Invocation Access	AuthorizedClient, Service

Parameters	
LastUser	
FlexString	
Length	0..18
Initialisation	
LastParaDate	
FlexString	
Length	0..10
Initialisation	
LastParaTime	
FlexString	
Length	0..5
Initialisation	

Method Telegram Syntax

Method Invocation:

```
sMN mDIsetlast <LastUser> <LastParaDate> <LastParaTime>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIsetlast	String	10	Method defines the last user and last date parameters
Parameter 1	LastUser	FlexString	18	
Parameter 2	LastParaDate	FlexString	10	
Parameter 3	LastParaTime	FlexString	5	

Method Return Value:

```
sAN mDIsetlast
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIsetlast	String	10	Method defines the last user and last date parameters

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIsetlast 0 0 0[ETX]`
Method Return Value:	`[STX]sAN mDIsetlast[ETX]`

© SICK AG - Germany - All rights reserved

2.4. Interface Block: TestBase

2.4.1. Group: TestErrorSetting

2.4.1.1. Method: SetTestErrorInfo

The following section contains a detailed description of the method SetTestErrorInfo.

Method Overview

Method Name	Description
SetTestErrorInfo	Sets and resets test errors of different levels

Communication Name	mTSetErrInfo
Sopas Index	36
Invocation Access	Service

Parameters	
SetOrReset	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mTSetErrInfo <SetOrReset>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTSetErrInfo	String	12	Sets and resets test errors of different levels
Parameter 1	SetOrReset	Bool	1	

Method Return Value:

```
sAN mTSetErrInfo
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTSetErrInfo	String	12	Sets and resets test errors of different levels

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mTSetErrInfo 0[ETX]`
Method Return Value:	`[STX]sAN mTSetErrInfo[ETX]`

© SICK AG - Germany - All rights reserved

2.4.1.2. Method: SetTestErrorWarning

The following section contains a detailed description of the method SetTestErrorWarning.

Method Overview

Method Name	Description
SetTestErrorWarning	Sets and resets test errors of different levels

Communication Name	mTSetErrWarn
Sopas Index	37
Invocation Access	Service

Parameters	
SetOrReset	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mTSetErrWarn <SetOrReset>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTSetErrWarn	String	12	Sets and resets test errors of different levels
Parameter 1	SetOrReset	Bool	1	

Method Return Value:

```
sAN mTSetErrWarn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTSetErrWarn	String	12	Sets and resets test errors of different levels

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mTSetErrWarn 0[ETX]`
Method Return Value:	`[STX]sAN mTSetErrWarn[ETX]`

© SICK AG - Germany - All rights reserved

2.4.1.3. Method: SetTestErrorError

The following section contains a detailed description of the method SetTestErrorError.

Method Overview

Method Name	Description
SetTestErrorError	Sets and resets test errors of different levels

Communication Name	mTSetErrErr
Sopas Index	38
Invocation Access	Service

Parameters	
SetOrReset	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mTSetErrErr <SetOrReset>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTSetErrErr	String	11	Sets and resets test errors of different levels
Parameter 1	SetOrReset	Bool	1	

Method Return Value:

```
sAN mTSetErrErr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTSetErrErr	String	11	Sets and resets test errors of different levels

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mTSetErrErr 0[ETX]`
Method Return Value:	`[STX]sAN mTSetErrErr[ETX]`

© SICK AG - Germany - All rights reserved

2.4.1.4. Method: SetTestErrorFatalError

The following section contains a detailed description of the method SetTestErrorFatalError.

Method Overview

Method Name	Description
SetTestErrorFatalError	Sets and resets test errors of different levels

Communication Name	mTSetErrFatal
Sopas Index	39
Invocation Access	Service

Parameters	
SetOrReset	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mTSetErrFatal <SetOrReset>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTSetErrFatal	String	13	Sets and resets test errors of different levels
Parameter 1	SetOrReset	Bool	1	

Method Return Value:

```
sAN mTSetErrFatal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTSetErrFatal	String	13	Sets and resets test errors of different levels

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mTSetErrFatal 0[ETX]`
Method Return Value:	`[STX]sAN mTSetErrFatal[ETX]`

© SICK AG - Germany - All rights reserved

2.5. Interface Block: FirstStageLdr

2.5.1. Group: FirmwareDownload

2.5.1.1. Method: SystemConfigData

The following section contains a detailed description of the method SystemConfigData.

Method Overview

Method Name	Description
SystemConfigData	Method transfers the relevant data of the system header

Communication Name	mFDsyscfgdata
Sopas Index	40
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Identifier	
FlexString	
Length	0..64
Initialisation	
Data	
FlexString	
Length	0..256
Initialisation	

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mFDsyscfgdata <Handle> <Identifier> <Data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDsyscfgdata	String	13	Method transfers the relevant data of the system header
Parameter 1	Handle	DInt	4	
Parameter 2	Identifier	FlexString	64	
Parameter 3	Data	FlexString	256	

Method Return Value:				
sAN mFDsyscfgdata <Result>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDsyscfgdata	String	13	Method transfers the relevant data of the system header
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mFDsyscfgdata 0 0 0[ETX]
Method Return Value:	[STX]sAN mFDsyscfgdata 0[ETX]

2.5.1.2. Method: ProgramConfigData

The following section contains a detailed description of the method ProgramConfigData.

Method Overview

Method Name	Description
ProgramConfigData	Method transfers the relevant data of the program header

Communication Name	mFDprgcfgdata
Sopas Index	41
Invocation Access	Service

Parameters		
Handle		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Parameters	
Device	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Identifier	
FlexString	
Length	0..64
Initialisation	
Data	
FlexString	
Length	0..256
Initialisation	

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mFDprgcfgdata <Handle> <Device> <Identifier> <Data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDprgcfgdata	String	13	Method transfers the relevant data of the program header
Parameter 1	Handle	DInt	4	
Parameter 2	Device	DInt	4	
Parameter 3	Identifier	FlexString	64	
Parameter 4	Data	FlexString	256	

Method Return Value:

```
sAN mFDprgcfgdata <Result>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDprgcfgdata	String	13	Method transfers the relevant data of the program header
Return Value 1	Result	DInt	4	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDprgcfgdata 0 0 0 0[ETX]`
Method Return Value:	`[STX]sAN mFDprgcfgdata 0[ETX]`

2.5.1.3. Method: ProgramData

The following section contains a detailed description of the method ProgramData.

Method Overview

Method Name	**Description**
ProgramData	Method transfers the program data

Communication Name	mFDprgdata
Sopas Index	42
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Device	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
BlockSize	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Data	
FlexString	
Length	0..1025
Initialisation	

© SICK AG - Germany - All rights reserved

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mFDprgdata <Handle> <Device> <BlockSize> <Data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDprgdata	String	10	Method transfers the program data
Parameter 1	Handle	DInt	4	
Parameter 2	Device	DInt	4	
Parameter 3	BlockSize	DInt	4	
Parameter 4	Data	FlexString	1025	

Method Return Value:

```
sAN mFDprgdata <Result>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDprgdata	String	10	Method transfers the program data
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mFDprgdata 0 0 0 0[ETX]`
Method Return Value:	`[STX]sAN mFDprgdata 0[ETX]`

© SICK AG - Germany - All rights reserved

2.5.1.4. Method: ExecuteDownload

The following section contains a detailed description of the method ExecuteDownload.

Method Overview

Method Name	Description
ExecuteDownload	Method directs the device to execute the download

Communication Name	mFDexedwnld
Sopas Index	43
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Device	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mFDexedwnld <Handle> <Device>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDexedwnld	String	11	Method directs the device to execute the download
Parameter 1	Handle	DInt	4	
Parameter 2	Device	DInt	4	

Method Return Value:				
`sAN mFDexedwnld <Result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDexedwnld	String	11	Method directs the device to execute the download
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDexedwnld 0 0[ETX]`
Method Return Value:	`[STX]sAN mFDexedwnld 0[ETX]`

2.5.1.5. Method: StatusDownload

The following section contains a detailed description of the method StatusDownload.

Method Overview

Method Name	Description
StatusDownload	Method informs the progress of the download process

Communication Name	mFDstadwnld
Sopas Index	44
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Parameters	
Device	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Status	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mFDstadwnld <Handle> <Device>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDstadwnld	String	11	Method informs the progress of the download process
Parameter 1	Handle	DInt	4	
Parameter 2	Device	DInt	4	

Method Return Value:

```
sAN mFDstadwnld <Status>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDstadwnld	String	11	Method informs the progress of the download process
Return Value 1	Status	DInt	4	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mFDstadwnld 0 0[ETX]`
Method Return Value:	`[STX]sAN mFDstadwnld 0[ETX]`

© SICK AG - Germany - All rights reserved

2.5.1.6. Method: FinishDownload

The following section contains a detailed description of the method FinishDownload.

Method Overview

Method Name	Description
FinishDownload	Finishes the download process

Communication Name	mFDfindwnld
Sopas Index	45
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Device	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mFDfindwnld <Handle> <Device>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDfindwnld	String	11	Finishes the download process
Parameter 1	Handle	DInt	4	
Parameter 2	Device	DInt	4	

Method Return Value:				
`sAN mFDfindwnld <Result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDfindwnld	String	11	Finishes the download process
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDfindwnld 0 0[ETX]`
Method Return Value:	`[STX]sAN mFDfindwnld 0[ETX]`

2.5.1.7. Method: AbortDownload

The following section contains a detailed description of the method AbortDownload.

Method Overview

Method Name	Description
AbortDownload	Aborts the download process

Communication Name	mFDabrtdwnld
Sopas Index	46
Invocation Access	Service

Parameters	
Handle	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Parameters	
Device	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Result	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFDabrtdwnld <Handle> <Device>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFDabrtdwnld	String	12	Aborts the download process
Parameter 1	Handle	DInt	4	
Parameter 2	Device	DInt	4	

Method Return Value:				
`sAN mFDabrtdwnld <Result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFDabrtdwnld	String	12	Aborts the download process
Return Value 1	Result	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFDabrtdwnld 0 0[ETX]`
Method Return Value:	`[STX]sAN mFDabrtdwnld 0[ETX]`

© SICK AG - Germany - All rights reserved

2.6. Interface Block: GeneralCfgIOBase

2.6.1. Group: DigitalOutputsBase

2.6.1.1. Variable: Out1FuncEvCndExt

The following section contains a detailed description of the variable Out1FuncEvCndExt.

Variable Overview

Variable Name	Description
Out1FuncEvCndExt	Function of Output 1, EvalCond extension

Communication Name	DO1FncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	39
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..18
	Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO1FncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1FncEvExt	String	11	Function of Output 1, EvalCond extension

Read Variable Response:

```
sRA DO1FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1FncEvExt	String	11	Function of Output 1, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO1FncEvExt <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1FncEvExt	String	11	Function of Output 1, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA DO1FncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1FncEvExt	String	11	Function of Output 1, EvalCond extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO1FncEvExt[ETX]
Read Variable Response:	[STX]sRA DO1FncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO1FncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO1FncEvExt[ETX]

2.6.1.2. Variable: Out1OffFunc

The following section contains a detailed description of the variable Out1OffFunc.

Variable Overview

Variable Name	Description
Out1OffFunc	Off-Function for output 1

Communication Name	DO1OffFnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	40
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIMER_TRACKING	
	1	TX_NEXT_READING_GATE	
	2	TX_COMMAND	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_TEACH1_START	
	6	TX_TEACH2_START	

Variable Telegram Syntax

Read Variable:				
`sRN DO1OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1OffFnc	String	9	Off-Function for output 1

Read Variable Response:				
`sRA DO1OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1OffFnc	String	9	Off-Function for output 1
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO1OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1OffFnc	String	9	Off-Function for output 1
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO1OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1OffFnc	String	9	Off-Function for output 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1OffFnc[ETX]`
Read Variable Response:	`[STX]sRA DO1OffFnc 0[ETX]`
Write Variable:	`[STX]sWN DO1OffFnc 0[ETX]`
Write Variable Response:	`[STX]sWA DO1OffFnc[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.3. Variable: Out1OffFuncEvCndExt

The following section contains a detailed description of the variable Out1OffFuncEvCndExt.

Variable Overview

Variable Name	Description
Out1OffFuncEvCndExt	Extension of List for EvCnd

Communication Name	DO1OffFncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	41
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..18
	Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO1OffFncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1OffFncEvExt	String	14	Extension of List for EvCnd

Read Variable Response:

```
sRA DO1OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO1OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DO1OffFncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1OffFncEvExt	String	14	Extension of List for EvCnd

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO1OffFncEvExt[ETX]
Read Variable Response:	[STX]sRA DO1OffFncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO1OffFncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO1OffFncEvExt[ETX]

2.6.1.4. Variable: Out1Logic

The following section contains a detailed description of the variable Out1Logic.

Variable Overview

Variable Name	Description
Out1Logic	True if Output 1 Function is inverted

Communication Name	DO1Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	42
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1Logic	String	8	True if Output 1 Function is inverted

Read Variable Response:				
`sRA DO1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1Logic	String	8	True if Output 1 Function is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1Logic	String	8	True if Output 1 Function is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1Logic	String	8	True if Output 1 Function is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1Logic[ETX]`
Read Variable Response:	`[STX]sRA DO1Logic 0[ETX]`
Write Variable:	`[STX]sWN DO1Logic 0[ETX]`
Write Variable Response:	`[STX]sWA DO1Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.5. Variable: Out1DurTime

The following section contains a detailed description of the variable Out1DurTime.

Variable Overview

Variable Name	Description
Out1DurTime	Duration of Output 1 if time controlled

Communication Name	DO1DurTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	43
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	10..10000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO1DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1DurTm	String	8	Duration of Output 1 if time controlled

Read Variable Response:

```
sRA DO1DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1DurTm	String	8	Duration of Output 1 if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN DO1DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1DurTm	String	8	Duration of Output 1 if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DO1DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1DurTm	String	8	Duration of Output 1 if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1DurTm[ETX]`
Read Variable Response:	`[STX]sRA DO1DurTm 64[ETX]`
Write Variable:	`[STX]sWN DO1DurTm 64[ETX]`
Write Variable Response:	`[STX]sWA DO1DurTm[ETX]`

2.6.1.6. Variable: Out1DurTrack

The following section contains a detailed description of the variable Out1DurTrack.

Variable Overview

Variable Name	Description
Out1DurTrack	Duration of Output 1 if track controlled

Communication Name	Do1DurTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	44
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN Do1DurTrk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	Do1DurTrk	String	9	Duration of Output 1 if track controlled

Read Variable Response:

`sRA Do1DurTrk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	Do1DurTrk	String	9	Duration of Output 1 if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN Do1DurTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	Do1DurTrk	String	9	Duration of Output 1 if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA Do1DurTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	Do1DurTrk	String	9	Duration of Output 1 if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN Do1DurTrk[ETX]
Read Variable Response:	[STX]sRA Do1DurTrk 64[ETX]
Write Variable:	[STX]sWN Do1DurTrk 64[ETX]
Write Variable Response:	[STX]sWA Do1DurTrk[ETX]

2.6.1.7. Variable: Out1Control

The following section contains a detailed description of the variable Out1Control.

Variable Overview

Variable Name	Description
Out1Control	Switch wether output 1 is time or track controlled

Communication Name	DO1Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	45
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO1Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1Control	String	10	Switch wether output 1 is time or track controlled

Read Variable Response:				
`sRA DO1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1Control	String	10	Switch wether output 1 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1Control	String	10	Switch wether output 1 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO1Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1Control	String	10	Switch wether output 1 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1Control[ETX]`
Read Variable Response:	`[STX]sRA DO1Control 0[ETX]`
Write Variable:	`[STX]sWN DO1Control 0[ETX]`
Write Variable Response:	`[STX]sWA DO1Control[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.8. Variable: Out2FuncEvCndExt

The following section contains a detailed description of the variable Out2FuncEvCndExt.

Variable Overview

Variable Name	Description
Out2FuncEvCndExt	Function of Output 2, EvalCond extension

Communication Name	DO2FncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	47
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO2FncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2FncEvExt	String	11	Function of Output 2, EvalCond extension

Read Variable Response:

```
sRA DO2FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2FncEvExt	String	11	Function of Output 2, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO2FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2FncEvExt	String	11	Function of Output 2, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DO2FncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2FncEvExt	String	11	Function of Output 2, EvalCond extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO2FncEvExt[ETX]
Read Variable Response:	[STX]sRA DO2FncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO2FncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO2FncEvExt[ETX]

2.6.1.9. Variable: Out2OffFunc

The following section contains a detailed description of the variable Out2OffFunc.

Variable Overview

Variable Name	Description
Out2OffFunc	Off-Function for output 2

Communication Name	DO2OffFnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	48
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIMER_TRACKING	
	1	TX_NEXT_READING_GATE	
	2	TX_COMMAND	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_TEACH1_START	
	6	TX_TEACH2_START	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO2OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2OffFnc	String	9	Off-Function for output 2

Read Variable Response:				
`sRA DO2OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2OffFnc	String	9	Off-Function for output 2
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO2OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2OffFnc	String	9	Off-Function for output 2
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO2OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2OffFnc	String	9	Off-Function for output 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO2OffFnc[ETX]`
Read Variable Response:	`[STX]sRA DO2OffFnc 0[ETX]`
Write Variable:	`[STX]sWN DO2OffFnc 0[ETX]`
Write Variable Response:	`[STX]sWA DO2OffFnc[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.10. Variable: Out2OffFuncEvCndExt

The following section contains a detailed description of the variable Out2OffFuncEvCndExt.

Variable Overview

Variable Name	Description
Out2OffFuncEvCndExt	Extension of List for EvCnd

Communication Name	DO2OffFncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	49
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO2OffFncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2OffFncEvExt	String	14	Extension of List for EvCnd

Read Variable Response:

```
sRA DO2OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO2OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DO2OffFncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2OffFncEvExt	String	14	Extension of List for EvCnd

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO2OffFncEvExt[ETX]
Read Variable Response:	[STX]sRA DO2OffFncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO2OffFncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO2OffFncEvExt[ETX]

2.6.1.11. Variable: Out2Logic

The following section contains a detailed description of the variable Out2Logic.

Variable Overview

Variable Name	Description
Out2Logic	True if Output 2 Function is inverted

Communication Name	DO2Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	50
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2Logic	String	8	True if Output 2 Function is inverted

Read Variable Response:				
`sRA DO2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2Logic	String	8	True if Output 2 Function is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2Logic	String	8	True if Output 2 Function is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2Logic	String	8	True if Output 2 Function is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO2Logic[ETX]`
Read Variable Response:	`[STX]sRA DO2Logic 0[ETX]`
Write Variable:	`[STX]sWN DO2Logic 0[ETX]`
Write Variable Response:	`[STX]sWA DO2Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.12. Variable: Out2DurTime

The following section contains a detailed description of the variable Out2DurTime.

Variable Overview

Variable Name	Description
Out2DurTime	Duration of Output 2 if time controlled

Communication Name	DO2DurTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	51
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	10..10000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO2DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2DurTm	String	8	Duration of Output 2 if time controlled

Read Variable Response:

```
sRA DO2DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2DurTm	String	8	Duration of Output 2 if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN DO2DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2DurTm	String	8	Duration of Output 2 if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DO2DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2DurTm	String	8	Duration of Output 2 if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO2DurTm[ETX]`
Read Variable Response:	`[STX]sRA DO2DurTm 64[ETX]`
Write Variable:	`[STX]sWN DO2DurTm 64[ETX]`
Write Variable Response:	`[STX]sWA DO2DurTm[ETX]`

2.6.1.13. Variable: Out2DurTrack

The following section contains a detailed description of the variable Out2DurTrack.

Variable Overview

Variable Name	Description
Out2DurTrack	Duration of Output 2 if track controlled

Communication Name	DO2DurTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	52
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO2DurTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2DurTrk	String	9	Duration of Output 2 if track controlled

Read Variable Response:

```
sRA DO2DurTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2DurTrk	String	9	Duration of Output 2 if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO2DurTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2DurTrk	String	9	Duration of Output 2 if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DO2DurTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2DurTrk	String	9	Duration of Output 2 if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO2DurTrk[ETX]
Read Variable Response:	[STX]sRA DO2DurTrk 64[ETX]
Write Variable:	[STX]sWN DO2DurTrk 64[ETX]
Write Variable Response:	[STX]sWA DO2DurTrk[ETX]

2.6.1.14. Variable: Out2Control

The following section contains a detailed description of the variable Out2Control.

Variable Overview

Variable Name	Description
Out2Control	Switch wether output 2 is time or track controlled

Communication Name	DO2Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	53
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO2Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2Control	String	10	Switch wether output 2 is time or track controlled

Read Variable Response:				
`sRA DO2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2Control	String	10	Switch wether output 2 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2Control	String	10	Switch wether output 2 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO2Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2Control	String	10	Switch wether output 2 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO2Control[ETX]`
Read Variable Response:	`[STX]sRA DO2Control 0[ETX]`
Write Variable:	`[STX]sWN DO2Control 0[ETX]`
Write Variable Response:	`[STX]sWA DO2Control[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.15. Variable: Out2Func

The following section contains a detailed description of the variable Out2Func.

Variable Overview

Variable Name	Description
Out2Func	Function of Output 2

Communication Name	DO2Fnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	46
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		3	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	2	TX_DEVICE_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	10	TX_EXTERNAL_ILLUMINATION	
	11	TX_PM_FEEDBACK	
	12	TX_MODE_DIGIO_CONDITION1	
	13	TX_MODE_DIGIO_CONDITION2	
	14	TX_MODE_DIGIO_CONDITION3	
	15	TX_MODE_DIGIO_CONDITION4	

Variable Telegram Syntax

Read Variable:

```
sRN DO2Fnc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2Fnc	String	6	Function of Output 2

Read Variable Response:

```
sRA DO2Fnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2Fnc	String	6	Function of Output 2
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DO2Fnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2Fnc	String	6	Function of Output 2

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO2Fnc <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DO2Fnc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2Fnc	String	6	Function of Output 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO2Fnc[ETX]
Read Variable Response:	[STX]sRA DO2Fnc 3[ETX]
Write Variable:	[STX]sWN DO2Fnc 3[ETX]
Write Variable Response:	[STX]sWA DO2Fnc[ETX]

2.6.1.16. Variable: Out1Func

The following section contains a detailed description of the variable Out1Func.

Variable Overview

Variable Name	Description
Out1Func	Function of Output 1

Communication Name	DO1Fnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	38
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		2	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	2	TX_DEVICE_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	10	TX_PM_FEEDBACK	
	11	TX_MODE_DIGIO_CONDITION1	
	12	TX_MODE_DIGIO_CONDITION2	
	13	TX_MODE_DIGIO_CONDITION3	
	14	TX_MODE_DIGIO_CONDITION4	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO1Fnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1Fnc	String	6	Function of Output 1

Read Variable Response:				
`sRA DO1Fnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1Fnc	String	6	Function of Output 1
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO1Fnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1Fnc	String	6	Function of Output 1
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO1Fnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1Fnc	String	6	Function of Output 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1Fnc[ETX]`
Read Variable Response:	`[STX]sRA DO1Fnc 2[ETX]`
Write Variable:	`[STX]sWN DO1Fnc 2[ETX]`
Write Variable Response:	`[STX]sWA DO1Fnc[ETX]`

© SICK AG - Germany - All rights reserved

2.6.1.17. Method: SetOutput

The following section contains a detailed description of the method SetOutput.

Method Overview

Method Name	Description
SetOutput	sets the specified output

Communication Name	mDOSetOutput
Sopas Index	47
Invocation Access	Always

Parameters	
Output	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Value	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mDOSetOutput <Output> <Value>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDOSetOutput	String	12	sets the specified output
Parameter 1	Output	USInt	1	
Parameter 2	Value	USInt	1	

Method Return Value:

```
sAN mDOSetOutput <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDOSetOutput	String	12	sets the specified output
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDOSetOutput 0 0[ETX]`
Method Return Value:	`[STX]sAN mDOSetOutput 0[ETX]`

© SICK AG - Germany - All rights reserved

2.6.2. Group: DigitalInputsBase

2.6.2.1. Variable: Sensor1Sensitivity

The following section contains a detailed description of the variable Sensor1Sensitivity.

Variable Overview

Variable Name	Description
Sensor1Sensitivity	Sensitivity of sensor 1

Communication Name	DI1Sens
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	54
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_EDGE	
	1	TX_LEVEL	

Variable Telegram Syntax

Read Variable:

```
sRN DI1Sens
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI1Sens	String	7	Sensitivity of sensor 1

Read Variable Response:

```
sRA DI1Sens <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI1Sens	String	7	Sensitivity of sensor 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DI1Sens <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI1Sens	String	7	Sensitivity of sensor 1
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DI1Sens				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI1Sens	String	7	Sensitivity of sensor 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DI1Sens[ETX]
Read Variable Response:	[STX]sRA DI1Sens 0[ETX]
Write Variable:	[STX]sWN DI1Sens 0[ETX]
Write Variable Response:	[STX]sWA DI1Sens[ETX]

2.6.2.2. Variable: Sensor1Logic

The following section contains a detailed description of the variable Sensor1Logic.

Variable Overview

Variable Name	Description
Sensor1Logic	Sensor 1 is inverted

Communication Name	DI1Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	55
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DI1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI1Logic	String	8	Sensor 1 is inverted

Read Variable Response:				
`sRA DI1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI1Logic	String	8	Sensor 1 is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DI1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI1Logic	String	8	Sensor 1 is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DI1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI1Logic	String	8	Sensor 1 is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DI1Logic[ETX]`
Read Variable Response:	`[STX]sRA DI1Logic 0[ETX]`
Write Variable:	`[STX]sWN DI1Logic 0[ETX]`
Write Variable Response:	`[STX]sWA DI1Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.6.2.3. Variable: Sensor1DebounceTime

The following section contains a detailed description of the variable Sensor1DebounceTime.

Variable Overview

Variable Name	Description
Sensor1DebounceTime	Time controlled Debounce value of sensor 1

Communication Name	DI1DebTim
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	56
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DI1DebTim
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI1DebTim	String	9	Time controlled Debounce value of sensor 1

Read Variable Response:

```
sRA DI1DebTim <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI1DebTim	String	9	Time controlled Debounce value of sensor 1
Variable Data	data	UInt	2	

Write Variable:

```
sWN DI1DebTim <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI1DebTim	String	9	Time controlled Debounce value of sensor 1
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DI1DebTim
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI1DebTim	String	9	Time controlled Debounce value of sensor 1

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DI1DebTim[ETX]`
Read Variable Response:	`[STX]sRA DI1DebTim A[ETX]`
Write Variable:	`[STX]sWN DI1DebTim A[ETX]`
Write Variable Response:	`[STX]sWA DI1DebTim[ETX]`

2.6.2.4. Variable: Sensor1DebounceTrack

The following section contains a detailed description of the variable Sensor1DebounceTrack.

Variable Overview

Variable Name	Description
Sensor1DebounceTrack	Track controlled Debounce value of sensor 1

Communication Name	DI1DebTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	57
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	10
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DI1DebTrk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI1DebTrk	String	9	Track controlled Debounce value of sensor 1

Read Variable Response:

`sRA DI1DebTrk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI1DebTrk	String	9	Track controlled Debounce value of sensor 1
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DI1DebTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI1DebTrk	String	9	Track controlled Debounce value of sensor 1
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DI1DebTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI1DebTrk	String	9	Track controlled Debounce value of sensor 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DI1DebTrk[ETX]
Read Variable Response:	[STX]sRA DI1DebTrk A[ETX]
Write Variable:	[STX]sWN DI1DebTrk A[ETX]
Write Variable Response:	[STX]sWA DI1DebTrk[ETX]

2.6.2.5. Variable: Sensor1Control

The following section contains a detailed description of the variable Sensor1Control.

Variable Overview

Variable Name	Description
Sensor1Control	Switch wether sensor 1 is time or track controlled

Communication Name	DI1Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	58
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DI1Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI1Control	String	10	Switch wether sensor 1 is time or track controlled

Read Variable Response:				
`sRA DI1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI1Control	String	10	Switch wether sensor 1 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DI1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI1Control	String	10	Switch wether sensor 1 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DI1Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI1Control	String	10	Switch wether sensor 1 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DI1Control[ETX]`
Read Variable Response:	`[STX]sRA DI1Control 0[ETX]`
Write Variable:	`[STX]sWN DI1Control 0[ETX]`
Write Variable Response:	`[STX]sWA DI1Control[ETX]`

© SICK AG - Germany - All rights reserved

2.6.2.6. Variable: Sensor2Sensitivity

The following section contains a detailed description of the variable Sensor2Sensitivity.

Variable Overview

Variable Name	Description
Sensor2Sensitivity	Sensitivity of sensor 2

Communication Name	DI2Sens
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	59
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_EDGE	
	1	TX_LEVEL	

Variable Telegram Syntax

Read Variable:				
`sRN DI2Sens`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI2Sens	String	7	Sensitivity of sensor 2

Read Variable Response:				
`sRA DI2Sens <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI2Sens	String	7	Sensitivity of sensor 2
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DI2Sens <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI2Sens	String	7	Sensitivity of sensor 2
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DI2Sens`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI2Sens	String	7	Sensitivity of sensor 2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DI2Sens[ETX]`
Read Variable Response:	`[STX]sRA DI2Sens 0[ETX]`
Write Variable:	`[STX]sWN DI2Sens 0[ETX]`
Write Variable Response:	`[STX]sWA DI2Sens[ETX]`

2.6.2.7. Variable: Sensor2Logic

The following section contains a detailed description of the variable Sensor2Logic.

Variable Overview

Variable Name	Description
Sensor2Logic	Sensor 2 is inverted

Communication Name	DI2Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	60
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

Variable Telegram Syntax

Read Variable:				
`sRN DI2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI2Logic	String	8	Sensor 2 is inverted

Read Variable Response:				
`sRA DI2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI2Logic	String	8	Sensor 2 is inverted
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DI2Logic <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI2Logic	String	8	Sensor 2 is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DI2Logic				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI2Logic	String	8	Sensor 2 is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DI2Logic[ETX]
Read Variable Response:	[STX]sRA DI2Logic 0[ETX]
Write Variable:	[STX]sWN DI2Logic 0[ETX]
Write Variable Response:	[STX]sWA DI2Logic[ETX]

2.6.2.8. Variable: Sensor2DebounceTime

The following section contains a detailed description of the variable Sensor2DebounceTime.

Variable Overview

Variable Name	Description
Sensor2DebounceTime	Time controlled Debounce value of sensor 2

Communication Name	DI2DebTim
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	61
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DI2DebTim`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI2DebTim	String	9	Time controlled Debounce value of sensor 2

Read Variable Response:				
`sRA DI2DebTim <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI2DebTim	String	9	Time controlled Debounce value of sensor 2
Variable Data	data	UInt	2	

Write Variable:				
`sWN DI2DebTim <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI2DebTim	String	9	Time controlled Debounce value of sensor 2
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DI2DebTim`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI2DebTim	String	9	Time controlled Debounce value of sensor 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DI2DebTim[ETX]`
Read Variable Response:	`[STX]sRA DI2DebTim A[ETX]`
Write Variable:	`[STX]sWN DI2DebTim A[ETX]`
Write Variable Response:	`[STX]sWA DI2DebTim[ETX]`

© SICK AG - Germany - All rights reserved

2.6.2.9. Variable: Sensor2DebounceTrack

The following section contains a detailed description of the variable Sensor2DebounceTrack.

Variable Overview

Variable Name	Description
Sensor2DebounceTrack	Track controlled Debounce value of sensor 2

Communication Name	DI2DebTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	62
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	10
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DI2DebTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI2DebTrk	String	9	Track controlled Debounce value of sensor 2

Read Variable Response:

```
sRA DI2DebTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI2DebTrk	String	9	Track controlled Debounce value of sensor 2
Variable Data	data	UInt	2	

Write Variable:

```
sWN DI2DebTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI2DebTrk	String	9	Track controlled Debounce value of sensor 2
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DI2DebTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI2DebTrk	String	9	Track controlled Debounce value of sensor 2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DI2DebTrk[ETX]`
Read Variable Response:	`[STX]sRA DI2DebTrk A[ETX]`
Write Variable:	`[STX]sWN DI2DebTrk A[ETX]`
Write Variable Response:	`[STX]sWA DI2DebTrk[ETX]`

2.6.2.10. Variable: Sensor2Control

The following section contains a detailed description of the variable Sensor2Control.

Variable Overview

Variable Name	Description
Sensor2Control	Switch wether sensor 2 is time or track controlled

Communication Name	DI2Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	63
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

Variable Telegram Syntax

Read Variable:				
`sRN DI2Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DI2Control	String	10	Switch wether sensor 2 is time or track controlled

Read Variable Response:				
`sRA DI2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DI2Control	String	10	Switch wether sensor 2 is time or track controlled
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DI2Control <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DI2Control	String	10	Switch wether sensor 2 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DI2Control				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DI2Control	String	10	Switch wether sensor 2 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DI2Control[ETX]
Read Variable Response:	[STX]sRA DI2Control 0[ETX]
Write Variable:	[STX]sWN DI2Control 0[ETX]
Write Variable Response:	[STX]sWA DI2Control[ETX]

2.6.2.11. Method: ReadInput

The following section contains a detailed description of the method ReadInput.

Method Overview

Method Name	Description
ReadInput	reads the specified input state

Communication Name	mDIReadInput
Sopas Index	48
Invocation Access	Always

Parameters	
Input	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
Value	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:
`sMN mDIReadInput <Input>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIReadInput	String	12	reads the specified input state
Parameter 1	Input	USInt	1	

Method Return Value:
`sAN mDIReadInput <Value>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIReadInput	String	12	reads the specified input state
Return Value 1	Value	USInt	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIReadInput 0[ETX]`
Method Return Value:	`[STX]sAN mDIReadInput 0[ETX]`

© SICK AG - Germany - All rights reserved

2.7. Interface Block: CdfSensorShared

2.7.1. Group: CdfBasicMethods

2.7.1.1. Method: CdfProfinetEeWriteOnlyIntern

The following section contains a detailed description of the method CdfProfinetEeWriteOnlyIntern.

Method Overview

Method Name	Description
CdfProfinetEeWriteOnlyIntern	Parameter are only stored in internal Flash (no cloning) used from CDF to store parameters in sensor without cloning

Communication Name	CdfPnEeWrInt
Sopas Index	49
Invocation Access	Always

Return Values	
success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN CdfPnEeWrInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	CdfPnEeWrInt	String	12	Parameter are only stored in internal Flash (no cloning) used from CDF to store parameters in sensor without cloning

Method Return Value:

```
sAN CdfPnEeWrInt <success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	CdfPnEeWrInt	String	12	Parameter are only stored in internal Flash (no cloning) used from CDF to store parameters in sensor without cloning
Return Value 1	success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN CdfPnEeWrInt[ETX]`
Method Return Value:	`[STX]sAN CdfPnEeWrInt 0[ETX]`

2.7.1.2. Method: CdfProfinetResetToFactory

The following section contains a detailed description of the method CdfProfinetResetToFactory.

Method Overview

Method Name	Description
CdfProfinetResetToFactory	Set the all parameter in this CID to their default values. These values are stored permanently.

Communication Name	CdfPnResetFactory
Sopas Index	50
Invocation Access	Always

Return Values	
success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN CdfPnResetFactory`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	CdfPnResetFactory	String	17	Set the all parameter in this CID to their default values. These values are stored permanently.

Method Return Value:				
`sAN CdfPnResetFactory <success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	CdfPnResetFactory	String	17	Set the all parameter in this CID to their default values. These values are stored permanently.
Return Value 1	success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN CdfPnResetFactory[ETX]`
Method Return Value:	`[STX]sAN CdfPnResetFactory 0[ETX]`

© SICK AG - Germany - All rights reserved

2.7.2. Group: CdfStaticProfinetConfig

2.7.2.1. Variable: CdfPnDeviceId

The following section contains a detailed description of the variable CdfPnDeviceId.

Variable Overview

Variable Name	Description
CdfPnDeviceId	GSD Device ID

Communication Name	CdfPnDevId
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	64
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	0x5301
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnDevId
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnDevId	String	10	GSD Device ID

Read Variable Response:

```
sRA CdfPnDevId <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnDevId	String	10	GSD Device ID
Variable Data	data	UInt	2	

Write Variable:

```
sWN CdfPnDevId <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnDevId	String	10	GSD Device ID
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnDevId				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnDevId	String	10	GSD Device ID

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnDevId[ETX]
Read Variable Response:	[STX]sRA CdfPnDevId 5301[ETX]
Write Variable:	[STX]sWN CdfPnDevId 5301[ETX]
Write Variable Response:	[STX]sWA CdfPnDevId[ETX]

2.7.2.2. Variable: CdfPnDeviceType

The following section contains a detailed description of the variable CdfPnDeviceType.

Variable Overview

Variable Name	Description
CdfPnDeviceType	GSD Device Type

Communication Name	CdfPnDevTyp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	65
Read-Access	Always
Write-Access	Always

FlexString	
Length	0..25
Initialisation	LECTOR62x

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnDevTyp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnDevTyp	String	11	GSD Device Type

Read Variable Response:				
`sRA CdfPnDevTyp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnDevTyp	String	11	GSD Device Type
Variable Data	data	FlexString	25	

Write Variable:				
`sWN CdfPnDevTyp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnDevTyp	String	11	GSD Device Type
Variable Data	data	FlexString	25	

Write Variable Response:				
`sWA CdfPnDevTyp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnDevTyp	String	11	GSD Device Type

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnDevTyp[ETX]`
Read Variable Response:	`[STX]sRA CdfPnDevTyp 9 LECTOR62x[ETX]`
Write Variable:	`[STX]sWN CdfPnDevTyp 9 LECTOR62x[ETX]`
Write Variable Response:	`[STX]sWA CdfPnDevTyp[ETX]`

© SICK AG - Germany - All rights reserved

2.7.2.3. Variable: CdfPnSwRevision

The following section contains a detailed description of the variable CdfPnSwRevision.

Variable Overview

Variable Name	Description
CdfPnSwRevision	GSD SW Revision (stack version) Software revision, format is {prefix}{function}.{bugfix}.{change}, e.g. V0.1.2 prefix: 'V', 'R', 'P', 'U', 'T' function, bugfix, change: 0x00-0xff e.g.: {'V', 0x31, 0x32, 0x33} displayed as V1.2.3

Communication Name	CdfPnSwRev
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	66
Read-Access	Always
Write-Access	Always

UserType	
ProfinetFixed	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnSwRev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnSwRev	String	10	GSD SW Revision (stack version) Software revision, format is {prefix}{function}.{bugfix}.{change}, e.g. V0.1.2 prefix: 'V', 'R', 'P', 'U', 'T' function, bugfix, change: 0x00-0xff e.g.: {'V', 0x31, 0x32, 0x33} displayed as V1.2.3

Read Variable Response:				
`sRA CdfPnSwRev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnSwRev	String	10	GSD SW Revision (stack version) Software revision, format is {prefix}{function}.{bugfix}.{change}, e.g. V0.1.2 prefix: 'V', 'R', 'P', 'U', 'T' function, bugfix, change: 0x00-0xff e.g.: {'V', 0x31, 0x32, 0x33} displayed as V1.2.3
Variable Data	data	ProfinetFixed	4	

Write Variable:				
`sWN CdfPnSwRev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnSwRev	String	10	GSD SW Revision (stack version) Software revision, format is {prefix}{function}.{bugfix}.{change}, e.g. V0.1.2 prefix: 'V', 'R', 'P', 'U', 'T' function, bugfix, change: 0x00-0xff e.g.: {'V', 0x31, 0x32, 0x33} displayed as V1.2.3

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CdfPnSwRev <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	ProfinetFixed	4	

Write Variable Response:				
sWA CdfPnSwRev				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnSwRev	String	10	GSD SW Revision (stack version) Software revision, format is {prefix}{function}.{bugfix}.{change}, e.g. V0.1.2 prefix: 'V', 'R', 'P', 'U', 'T' function, bugfix, change: 0x00-0xff e.g.: {'V', 0x31, 0x32, 0x33} displayed as V1.2.3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnSwRev[ETX]
Read Variable Response:	[STX]sRA CdfPnSwRev V 2 0 0[ETX]
Write Variable:	[STX]sWN CdfPnSwRev V 2 0 0[ETX]
Write Variable Response:	[STX]sWA CdfPnSwRev[ETX]

2.7.2.4. Variable: CdfPnHwRevision

The following section contains a detailed description of the variable CdfPnHwRevision.

Variable Overview

Variable Name	Description
CdfPnHwRevision	GSD HW Revision (HW interface version)

Communication Name	CdfPnHwRev
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	67
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnHwRev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnHwRev	String	10	GSD HW Revision (HW interface version)

Read Variable Response:				
`sRA CdfPnHwRev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnHwRev	String	10	GSD HW Revision (HW interface version)
Variable Data	data	UInt	2	

Write Variable:				
`sWN CdfPnHwRev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnHwRev	String	10	GSD HW Revision (HW interface version)
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CdfPnHwRev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnHwRev	String	10	GSD HW Revision (HW interface version)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnHwRev[ETX]`
Read Variable Response:	`[STX]sRA CdfPnHwRev 1[ETX]`
Write Variable:	`[STX]sWN CdfPnHwRev 1[ETX]`
Write Variable Response:	`[STX]sWA CdfPnHwRev[ETX]`

© SICK AG - Germany - All rights reserved

2.7.2.5. Variable: CdfPnProfileId

The following section contains a detailed description of the variable CdfPnProfileId.

Variable Overview

Variable Name	Description
CdfPnProfileId	GSD parameter see http://www.profibus.com/IM/Profile_ID_Table.xml

Communication Name	CdfPnProfId
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	68
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	0x0000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnProfId`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnProfId	String	11	GSD parameter see http://www.profibus.com/IM/Profile_ID_Table.xml

Read Variable Response:				
`sRA CdfPnProfId <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnProfId	String	11	GSD parameter see http://www.profibus.com/IM/Profile_ID_Table.xml
Variable Data	data	UInt	2	

Write Variable:				
`sWN CdfPnProfId <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnProfId	String	11	GSD parameter see http://www.profibus.com/IM/Profile_ID_Table.xml
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CdfPnProfId`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnProfId				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPnProfId	String	11	GSD parameter see http://www.profibus.com/IM/Profile_ID_Table.xml

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnProfId[ETX]
Read Variable Response:	[STX]sRA CdfPnProfId 0[ETX]
Write Variable:	[STX]sWN CdfPnProfId 0[ETX]
Write Variable Response:	[STX]sWA CdfPnProfId[ETX]

2.7.2.6. Variable: CdfPnProfileSpecificType

The following section contains a detailed description of the variable CdfPnProfileSpecificType.

Variable Overview

Variable Name	Description
CdfPnProfileSpecificType	GSD profile type

Communication Name	CdfPnProfSpTyp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	69
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	0x0003
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnProfSpTyp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnProfSpTyp	String	14	GSD profile type

Read Variable Response:				
`sRA CdfPnProfSpTyp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnProfSpTyp	String	14	GSD profile type
Variable Data	data	UInt	2	

Write Variable:				
`sWN CdfPnProfSpTyp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnProfSpTyp	String	14	GSD profile type
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CdfPnProfSpTyp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnProfSpTyp	String	14	GSD profile type

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnProfSpTyp[ETX]`
Read Variable Response:	`[STX]sRA CdfPnProfSpTyp 3[ETX]`
Write Variable:	`[STX]sWN CdfPnProfSpTyp 3[ETX]`
Write Variable Response:	`[STX]sWA CdfPnProfSpTyp[ETX]`

© SICK AG - Germany - All rights reserved

2.7.2.7. Variable: CdfEthMac

The following section contains a detailed description of the variable CdfEthMac.

Variable Overview

Variable Name	Description
CdfEthMac	CDF device MAC

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	70
Read-Access	Always
Write-Access	Always

Array	
Length	6
Default Value	{0x00,0x06,0x77,0x00,0x00,0x00}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfEthMac
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfEthMac	String	9	CDF device MAC

Read Variable Response:

```
sRA CdfEthMac <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfEthMac	String	9	CDF device MAC
Variable Data	data	Array	6	

Write Variable:

```
sWN CdfEthMac <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfEthMac	String	9	CDF device MAC
Variable Data	data	Array	6	

Write Variable Response:

```
sWA CdfEthMac
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfEthMac				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfEthMac	String	9	CDF device MAC

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfEthMac[ETX]
Read Variable Response:	[STX]sRA CdfEthMac 0 6 77 0 0 0[ETX]
Write Variable:	[STX]sWN CdfEthMac 0 6 77 0 0 0[ETX]
Write Variable Response:	[STX]sWA CdfEthMac[ETX]

2.7.2.8. Variable: CdfEthMacP1

The following section contains a detailed description of the variable CdfEthMacP1.

Variable Overview

Variable Name	Description
CdfEthMacP1	CDF port1 MAC (PN)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	71
Read-Access	Always
Write-Access	Always

Array		
Length		6
Default Value		{0x00,0x06,0x77,0x00,0x00,0x01}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfEthMacP1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfEthMacP1	String	11	CDF port1 MAC (PN)

Read Variable Response:				
`sRA CdfEthMacP1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfEthMacP1	String	11	CDF port1 MAC (PN)
Variable Data	data	Array	6	

Write Variable:				
`sWN CdfEthMacP1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfEthMacP1	String	11	CDF port1 MAC (PN)
Variable Data	data	Array	6	

Write Variable Response:				
`sWA CdfEthMacP1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfEthMacP1	String	11	CDF port1 MAC (PN)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfEthMacP1[ETX]`
Read Variable Response:	`[STX]sRA CdfEthMacP1 0 6 77 0 0 1[ETX]`
Write Variable:	`[STX]sWN CdfEthMacP1 0 6 77 0 0 1[ETX]`
Write Variable Response:	`[STX]sWA CdfEthMacP1[ETX]`

© SICK AG - Germany - All rights reserved

2.7.2.9. Variable: CdfEthMacP2

The following section contains a detailed description of the variable CdfEthMacP2.

Variable Overview

Variable Name	Description
CdfEthMacP2	CDF port2 MAC (PN)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	72
Read-Access	Always
Write-Access	Always

Array	
Length	6
Default Value	{0x00,0x06,0x77,0x00,0x00,0x02}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfEthMacP2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfEthMacP2	String	11	CDF port2 MAC (PN)

Read Variable Response:

```
sRA CdfEthMacP2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfEthMacP2	String	11	CDF port2 MAC (PN)
Variable Data	data	Array	6	

Write Variable:

```
sWN CdfEthMacP2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfEthMacP2	String	11	CDF port2 MAC (PN)
Variable Data	data	Array	6	

Write Variable Response:

```
sWA CdfEthMacP2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfEthMacP2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfEthMacP2	String	11	CDF port2 MAC (PN)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfEthMacP2[ETX]
Read Variable Response:	[STX]sRA CdfEthMacP2 0 6 77 0 0 2[ETX]
Write Variable:	[STX]sWN CdfEthMacP2 0 6 77 0 0 2[ETX]
Write Variable Response:	[STX]sWA CdfEthMacP2[ETX]

2.7.2.10. Variable: CdfOrderIdFamily

The following section contains a detailed description of the variable CdfOrderIdFamily.

Variable Overview

Variable Name	Description
CdfOrderIdFamily	CDF Device orderId as written in the GSD. This value may be empty or a placeholder.

Communication Name	CdfOrdIdFam
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	73
Read-Access	Always
Write-Access	Always

FlexString	
Length	0..20
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfOrdIdFam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfOrdIdFam	String	11	CDF Device orderId as written in the GSD. This value may be empty or a placeholder.

Read Variable Response:				
`sRA CdfOrdIdFam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfOrdIdFam	String	11	CDF Device orderId as written in the GSD. This value may be empty or a placeholder.
Variable Data	data	FlexString	20	

Write Variable:				
`sWN CdfOrdIdFam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfOrdIdFam	String	11	CDF Device orderId as written in the GSD. This value may be empty or a placeholder.
Variable Data	data	FlexString	20	

Write Variable Response:				
`sWA CdfOrdIdFam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfOrdIdFam	String	11	CDF Device orderId as written in the GSD. This value may be empty or a placeholder.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfOrdIdFam[ETX]`
Read Variable Response:	`[STX]sRA CdfOrdIdFam 0[ETX]`
Write Variable:	`[STX]sWN CdfOrdIdFam 0[ETX]`
Write Variable Response:	`[STX]sWA CdfOrdIdFam[ETX]`

© SICK AG - Germany - All rights reserved

2.7.2.11. Variable: CdfOrderIdDevice

The following section contains a detailed description of the variable CdfOrderIdDevice.

Variable Overview

Variable Name	Description
CdfOrderIdDevice	CDF Real device orderId, in case there is no or only a placeholder value in the GSD

Communication Name	CdfOrdIdDev
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	74
Read-Access	Always
Write-Access	Always

String	
Length	7
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN CdfOrdIdDev
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfOrdIdDev	String	11	CDF Real device orderId, in case there is no or only a placeholder value in the GSD

Read Variable Response:

```
sRA CdfOrdIdDev <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfOrdIdDev	String	11	CDF Real device orderId, in case there is no or only a placeholder value in the GSD
Variable Data	data	String	7	

Write Variable:

```
sWN CdfOrdIdDev <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfOrdIdDev	String	11	CDF Real device orderId, in case there is no or only a placeholder value in the GSD
Variable Data	data	String	7	

Write Variable Response:

```
sWA CdfOrdIdDev
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfOrdIdDev	String	11	CDF Real device orderId, in case there is no or only a placeholder value in the GSD

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfOrdIdDev[ETX]`
Read Variable Response:	`[STX]sRA CdfOrdIdDev ·····[ETX]`
Write Variable:	`[STX]sWN CdfOrdIdDev ·····[ETX]`
Write Variable Response:	`[STX]sWA CdfOrdIdDev[ETX]`

2.7.2.12. Variable: CdfIsDeviceFamily

The following section contains a detailed description of the variable CdfIsDeviceFamily.

Variable Overview

Variable Name	Description
CdfIsDeviceFamily	If OrderNumber in GSDML is empty (string), because the GSDML is for a device family, then set value static to TRUE! Otherwise to FALSE.

Communication Name	CdfIsDevFam
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	75
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN CdfIsDevFam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfIsDevFam	String	11	If OrderNumber in GSDML is empty (string), because the GSDML is for a device family, then set value static to TRUE! Otherwise to FALSE.

Read Variable Response:				
`sRA CdfIsDevFam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfIsDevFam	String	11	If OrderNumber in GSDML is empty (string), because the GSDML is for a device family, then set value static to TRUE! Otherwise to FALSE.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN CdfIsDevFam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfIsDevFam	String	11	If OrderNumber in GSDML is empty (string), because the GSDML is for a device family, then set value static to TRUE! Otherwise to FALSE.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CdfIsDevFam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfIsDevFam	String	11	If OrderNumber in GSDML is empty (string), because the GSDML is for a device family, then set value static to TRUE! Otherwise to FALSE.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfIsDevFam[ETX]`
Read Variable Response:	`[STX]sRA CdfIsDevFam 1[ETX]`
Write Variable:	`[STX]sWN CdfIsDevFam 1[ETX]`
Write Variable Response:	`[STX]sWA CdfIsDevFam[ETX]`

© SICK AG - Germany - All rights reserved

2.7.3. Group: CdfProfinetStatus

2.7.3.1. Variable: CdfProfinetBusStatus

The following section contains a detailed description of the variable CdfProfinetBusStatus.

Variable Overview

Variable Name	Description
CdfProfinetBusStatus	Profinet bus status.

Communication Name	CdfPnBusStatus
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	76
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		BOOTUP	
	Value	Name	Description
	1	BOOTUP	
	2	NO_CONNECTED	
	3	DATA_EXCHANGE	
	4	PRM_FAULT	
	5	CFG_FAULT	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnBusStatus
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnBusStatus	String	14	Profinet bus status.

Read Variable Response:

```
sRA CdfPnBusStatus <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnBusStatus	String	14	Profinet bus status.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CdfPnBusStatus <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnBusStatus	String	14	Profinet bus status.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnBusStatus				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnBusStatus	String	14	Profinet bus status.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnBusStatus[ETX]
Read Variable Response:	[STX]sRA CdfPnBusStatus 1[ETX]
Write Variable:	[STX]sWN CdfPnBusStatus 1[ETX]
Write Variable Response:	[STX]sWA CdfPnBusStatus[ETX]

2.7.3.2. Variable: CdfProfinetStackErrorCode

The following section contains a detailed description of the variable CdfProfinetStackErrorCode.

Variable Overview

Variable Name	Description
CdfProfinetStackErrorCode	Error codes (32 bit) that are defined in Profinet stack of Hilscher.

Communication Name	CdfPnErrCode
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	77
Read-Access	Always
Write-Access	Always

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnErrCode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnErrCode	String	12	Error codes (32 bit) that are defined in Profinet stack of Hilscher.

Read Variable Response:				
`sRA CdfPnErrCode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnErrCode	String	12	Error codes (32 bit) that are defined in Profinet stack of Hilscher.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN CdfPnErrCode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnErrCode	String	12	Error codes (32 bit) that are defined in Profinet stack of Hilscher.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA CdfPnErrCode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnErrCode	String	12	Error codes (32 bit) that are defined in Profinet stack of Hilscher.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnErrCode[ETX]`
Read Variable Response:	`[STX]sRA CdfPnErrCode 0[ETX]`
Write Variable:	`[STX]sWN CdfPnErrCode 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPnErrCode[ETX]`

© SICK AG - Germany - All rights reserved

2.7.4. Group: CdfProfinetControlAndInformationFlags

2.7.4.1. Variable: CdfProfinetMasterAvailable

The following section contains a detailed description of the variable CdfProfinetMasterAvailable.

Variable Overview

Variable Name	Description
CdfProfinetMasterAvailable	If value is False then there is an active Master-PLC in the current network. Therefore the variables (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) may not be changed. Otherwise it is allowed.

Communication Name	CdfPnMasterAvailable
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	78
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnMasterAvailable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnMasterAvailable	String	20	If value is False then there is an active Master-PLC in the current network. Therefore the variables (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) may not be changed. Otherwise it is allowed.

Read Variable Response:

```
sRA CdfPnMasterAvailable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnMasterAvailable	String	20	If value is False then there is an active Master-PLC in the current network. Therefore the variables (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) may not be changed. Otherwise it is allowed.
Variable Data	data	Bool	1	

Write Variable:

```
sWN CdfPnMasterAvailable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN CdfPnMasterAvailable <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPnMasterAvailable	String	20	If value is False then there is an active Master-PLC in the current network. Therefore the variables (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) may not be changed. Otherwise it is allowed.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CdfPnMasterAvailable`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnMasterAvailable	String	20	If value is False then there is an active Master-PLC in the current network. Therefore the variables (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) may not be changed. Otherwise it is allowed.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnMasterAvailable[ETX]`
Read Variable Response:	`[STX]sRA CdfPnMasterAvailable 0[ETX]`
Write Variable:	`[STX]sWN CdfPnMasterAvailable 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPnMasterAvailable[ETX]`

2.7.4.2. Variable: CdfProfinetStationNameStoringRemanent

The following section contains a detailed description of the variable CdfProfinetStationNameStoringRemanent.

Variable Overview

Variable Name	Description
CdfProfinetStationNameStoringRemanent	If value is True then the StationName is stored permanently and will be displayed. Otherwise the StationName is not stored with empty string ("") and the real used StationName is still displayed. At start up is checked if value is False. Then the StationName is overwrite with value "" (before the PN stack is initialized).

Communication Name	CdfPnStationNameRemanent
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	79
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnStationNameRemanent`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnStationNameRemanent	String	24	If value is True then the StationName is stored permanently and will be displayed. Otherwise the StationName is not stored with empty string ("") and the real used StationName is still displayed. At start up is checked if value is False. Then the StationName is overwrite with value "" (before the PN stack is initialized).

Read Variable Response:				
`sRA CdfPnStationNameRemanent <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnStationNameRemanent	String	24	If value is True then the StationName is stored permanently and will be displayed. Otherwise the StationName is not stored with empty string ("") and the real used StationName is still displayed. At start up is checked if value is False. Then the StationName is overwrite with value "" (before the PN stack is initialized).
Variable Data	data	Bool	1	

Write Variable:				
`sWN CdfPnStationNameRemanent <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnStationNameRemanent	String	24	If value is True then the StationName is stored permanently and will be displayed. Otherwise the StationName is not stored with empty string ("") and the real used StationName is still displayed. At start up is checked if value is False. Then the StationName is overwrite with value "" (before the PN stack is initialized).
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CdfPnStationNameRemanent`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnStationNameRemanent	String	24	If value is True then the StationName is stored permanently and will be displayed. Otherwise the StationName is not stored with empty string ("") and the real used StationName is still displayed. At start up is checked if value is False. Then the StationName is overwrite with value "" (before the PN stack is initialized).

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnStationNameRemanent[ETX]`
Read Variable Response:	`[STX]sRA CdfPnStationNameRemanent 1[ETX]`
Write Variable:	`[STX]sWN CdfPnStationNameRemanent 1[ETX]`
Write Variable Response:	`[STX]sWA CdfPnStationNameRemanent[ETX]`

2.7.4.3. Variable: CdfProfinetIpSettingsStoringRemanent

The following section contains a detailed description of the variable CdfProfinetIpSettingsStoringRemanent.

Variable Overview

Variable Name	Description
CdfProfinetIpSettingsStoringRemanent	If value is True then the IP settings (CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) are stored permanently and will be displayed. Otherwise the IP settings are not stored with 0.0.0.0 and the real used IP settings are still displayed. At start up is checked if value is False. Then the IP settings are overwrite with value 0.0.0.0 (before the PN stack is initialized).

Communication Name	CdfPnIpRemanent
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	80
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnIpRemanent`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnIpRemanent	String	15	If value is True then the IP settings (CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) are stored permanently and will be displayed. Otherwise the IP settings are not stored with 0.0.0.0 and the real used IP settings are still displayed. At start up is checked if value is False. Then the IP settings are overwrite with value 0.0.0.0 (before the PN stack is initialized).

© SICK AG - Germany - All rights reserved

Read Variable Response:				
`sRA CdfPnIpRemanent <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnIpRemanent	String	15	If value is True then the IP settings (CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) are stored permanently and will be displayed. Otherwise the IP settings are not stored with 0.0.0.0 and the real used IP settings are still displayed. At start up is checked if value is False. Then the IP settings are overwrite with value 0.0.0.0 (before the PN stack is initialized).
Variable Data	data	Bool	1	

Write Variable:				
`sWN CdfPnIpRemanent <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnIpRemanent	String	15	If value is True then the IP settings (CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) are stored permanently and will be displayed. Otherwise the IP settings are not stored with 0.0.0.0 and the real used IP settings are still displayed. At start up is checked if value is False. Then the IP settings are overwrite with value 0.0.0.0 (before the PN stack is initialized).
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CdfPnIpRemanent`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnIpRemanent	String	15	If value is True then the IP settings (CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) are stored permanently and will be displayed. Otherwise the IP settings are not stored with 0.0.0.0 and the real used IP settings are still displayed. At start up is checked if value is False. Then the IP settings are overwrite with value 0.0.0.0 (before the PN stack is initialized).

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnIpRemanent[ETX]`
Read Variable Response:	`[STX]sRA CdfPnIpRemanent 1[ETX]`
Write Variable:	`[STX]sWN CdfPnIpRemanent 1[ETX]`
Write Variable Response:	`[STX]sWA CdfPnIpRemanent[ETX]`

© SICK AG - Germany - All rights reserved

2.7.4.4. Variable: CdfProfinetConfigApply

The following section contains a detailed description of the variable CdfProfinetConfigApply.

Variable Overview

Variable Name	Description
CdfProfinetConfigApply	Only used for sensor in Proxy-Mode. If value is True then the IP settings (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) can be set via a button in SOPAS-ET. CDF600 must initialized its Profinet stack.

Communication Name	CdfPncfgApply
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	81
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CdfPncfgApply
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPncfgApply	String	13	Only used for sensor in Proxy-Mode. If value is True then the IP settings (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) can be set via a button in SOPAS-ET. CDF600 must initialized its Profinet stack.

Read Variable Response:

```
sRA CdfPncfgApply <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPncfgApply	String	13	Only used for sensor in Proxy-Mode. If value is True then the IP settings (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) can be set via a button in SOPAS-ET. CDF600 must initialized its Profinet stack.
Variable Data	data	Bool	1	

Write Variable:

```
sWN CdfPncfgApply <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPncfgApply	String	13	Only used for sensor in Proxy-Mode. If value is True then the IP settings (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) can be set via a button in SOPAS-ET. CDF600 must initialized its Profinet stack.

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CdfPncfgApply <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CdfPncfgApply				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPncfgApply	String	13	Only used for sensor in Proxy-Mode. If value is True then the IP settings (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway) can be set via a button in SOPAS-ET. CDF600 must initialized its Profinet stack.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPncfgApply[ETX]
Read Variable Response:	[STX]sRA CdfPncfgApply 0[ETX]
Write Variable:	[STX]sWN CdfPncfgApply 0[ETX]
Write Variable Response:	[STX]sWA CdfPncfgApply[ETX]

2.7.4.5. Variable: CdfProfinetConfigChanged

The following section contains a detailed description of the variable CdfProfinetConfigChanged.

Variable Overview

Variable Name	Description
CdfProfinetConfigChanged	CdfProfinetConfigApply will be enabled if one of following IP settings are changed: (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway.

Communication Name	CdfPncfgChanged
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	82
Read-Access	Always
Write-Access	Always

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPncfgChanged`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPncfgChanged	String	15	CdfProfinetConfigApply will be enabled if one of following IP settings are changed: (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway.

Read Variable Response:				
`sRA CdfPncfgChanged <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPncfgChanged	String	15	CdfProfinetConfigApply will be enabled if one of following IP settings are changed: (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway.
Variable Data	data	USInt	1	

Write Variable:				
`sWN CdfPncfgChanged <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPncfgChanged	String	15	CdfProfinetConfigApply will be enabled if one of following IP settings are changed: (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway.
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA CdfPncfgChanged`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPncfgChanged	String	15	CdfProfinetConfigApply will be enabled if one of following IP settings are changed: (CdfProfinetStationName, CdfProfinetIpAddress, CdfProfinetIpMask and CdfProfinetIpGateway.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPncfgChanged[ETX]`
Read Variable Response:	`[STX]sRA CdfPncfgChanged 0[ETX]`
Write Variable:	`[STX]sWN CdfPncfgChanged 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPncfgChanged[ETX]`

© SICK AG - Germany - All rights reserved

2.7.4.6. Variable: CdfProfinetS7CompatibilityMode

The following section contains a detailed description of the variable CdfProfinetS7CompatibilityMode.

Variable Overview

Variable Name	Description
CdfProfinetS7CompatibilityMode	Only use if OrderID in GSDML is an empty string. If value is FALSE then the device working as certificated Profinet device (certified by ComDec). So the OrderNumber of EPM, I+M (and MIB -> depend on PN stack) is an empty string. So the S7-Topology-Scan works, but the Inventory-Management of some customers that use I+M, doesn't work! If value is TRUE then the device working in a compatibility mode that support both, S7-Topology-Scan and Inventory-Management. For this case, the OrderNumber for EPM (And MIB) is set to an empty string and for I+M is using the real OrderId (1Mio no).

Communication Name	CdfPnS7CompMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	83
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnS7CompMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnS7CompMode	String	15	Only use if OrderID in GSDML is an empty string. If value is FALSE then the device working as certificated Profinet device (certified by ComDec). So the OrderNumber of EPM, I+M (and MIB -> depend on PN stack) is an empty string. So the S7-Topology-Scan works, but the Inventory-Management of some customers that use I+M, doesn't work! If value is TRUE then the device working in a compatibility mode that support both, S7-Topology-Scan and Inventory-Management. For this case, the OrderNumber for EPM (And MIB) is set to an empty string and for I+M is using the real OrderId (1Mio no).

Read Variable Response:

```
sRA CdfPnS7CompMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge

© SICK AG - Germany - All rights reserved

Read Variable Response:				
`sRA CdfPnS7CompMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPnS7CompMode	String	15	Only use if OrderID in GSDML is an empty string. If value is FALSE then the device working as certificated Profinet device (certified by ComDec). So the OrderNumber of EPM, I+M (and MIB -> depend on PN stack) is an empty string. So the S7-Topology-Scan works, but the Inventory-Management of some customers that use I+M, doesn't work! If value is TRUE then the device working in a compatibility mode that support both, S7-Topology-Scan and Inventory-Management. For this case, the OrderNumber for EPM (And MIB) is set to an empty string and for I+M is using the real OrderId (1Mio no).
Variable Data	data	Bool	1	

Write Variable:				
`sWN CdfPnS7CompMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnS7CompMode	String	15	Only use if OrderID in GSDML is an empty string. If value is FALSE then the device working as certificated Profinet device (certified by ComDec). So the OrderNumber of EPM, I+M (and MIB -> depend on PN stack) is an empty string. So the S7-Topology-Scan works, but the Inventory-Management of some customers that use I+M, doesn't work! If value is TRUE then the device working in a compatibility mode that support both, S7-Topology-Scan and Inventory-Management. For this case, the OrderNumber for EPM (And MIB) is set to an empty string and for I+M is using the real OrderId (1Mio no).
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CdfPnS7CompMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnS7CompMode	String	15	Only use if OrderID in GSDML is an empty string. If value is FALSE then the device working as certificated Profinet device (certified by ComDec). So the OrderNumber of EPM, I+M (and MIB -> depend on PN stack) is an empty string. So the S7-Topology-Scan works, but the Inventory-Management of some customers that use I+M, doesn't work! If value is TRUE then the device working in a compatibility mode that support both, S7-Topology-Scan and Inventory-Management. For this case, the OrderNumber for EPM (And MIB) is set to an empty string and for I+M is using the real OrderId (1Mio no).

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnS7CompMode[ETX]`
Read Variable Response:	`[STX]sRA CdfPnS7CompMode 0[ETX]`
Write Variable:	`[STX]sWN CdfPnS7CompMode 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPnS7CompMode[ETX]`

2.7.4.7. Method: CdfProfinetApplyButton

The following section contains a detailed description of the method CdfProfinetApplyButton.

Method Overview

Method Name	Description
CdfProfinetApplyButton	Method for the Apply button in SOPAS-ET. If button is pressed then the CdfProfinetConfigApply is set to True and then False again.

Communication Name	CdfPnApplyButton
Sopas Index	51
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN CdfPnApplyButton`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	CdfPnApplyButton	String	16	Method for the Apply button in SOPAS-ET. If button is pressed then the CdfProfinetConfigApply is set to True and then False again.

Method Return Value:				
`sAN CdfPnApplyButton`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	CdfPnApplyButton	String	16	Method for the Apply button in SOPAS-ET. If button is pressed then the CdfProfinetConfigApply is set to True and then False again.

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN CdfPnApplyButton[ETX]`
Method Return Value:	`[STX]sAN CdfPnApplyButton[ETX]`

© SICK AG - Germany - All rights reserved

2.8. Interface Block: CdfSensorConfigShared

2.8.1. Group: CdfProfinetConfig

2.8.1.1. Variable: CdfProfinetStationName

The following section contains a detailed description of the variable CdfProfinetStationName.

Variable Overview

Variable Name	Description
CdfProfinetStationName	PROFINET parameter StationName/DeviceName; use DNS format. CDF uses location name from sensor for PN configuration Note: parameter length will be adapted to max. length in real sensor locaton name (64 byte)

Communication Name	CdfPnStationName
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	84
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..240
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnStationName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnStationName	String	16	PROFINET parameter StationName/DeviceName; use DNS format. CDF uses location name from sensor for PN configuration Note: parameter length will be adapted to max. length in real sensor locaton name (64 byte)

Read Variable Response:

```
sRA CdfPnStationName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnStationName	String	16	PROFINET parameter StationName/DeviceName; use DNS format. CDF uses location name from sensor for PN configuration Note: parameter length will be adapted to max. length in real sensor locaton name (64 byte)
Variable Data	data	FlexString	240	

Write Variable:

```
sWN CdfPnStationName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN CdfPnStationName <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPnStationName	String	16	PROFINET parameter StationName/DeviceName; use DNS format. CDF uses location name from sensor for PN configuration Note: parameter length will be adapted to max. length in real sensor locaton name (64 byte)
Variable Data	data	FlexString	240	

Write Variable Response:				
`sWA CdfPnStationName`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnStationName	String	16	PROFINET parameter StationName/DeviceName; use DNS format. CDF uses location name from sensor for PN configuration Note: parameter length will be adapted to max. length in real sensor locaton name (64 byte)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnStationName[ETX]`
Read Variable Response:	`[STX]sRA CdfPnStationName 0[ETX]`
Write Variable:	`[STX]sWN CdfPnStationName 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPnStationName[ETX]`

2.8.1.2. Variable: CdfProfinetIpAddress

The following section contains a detailed description of the variable CdfProfinetIpAddress.

Variable Overview

Variable Name	Description
CdfProfinetIpAddress	CDF IP address

Communication Name	CdfPnIpAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	85
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Array		
Length		4
Default Value		{192,168,0,123}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnIpAddr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnIpAddr	String	11	CDF IP address

Read Variable Response:

```
sRA CdfPnIpAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnIpAddr	String	11	CDF IP address
Variable Data	data	Array	4	

Write Variable:

```
sWN CdfPnIpAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnIpAddr	String	11	CDF IP address
Variable Data	data	Array	4	

Write Variable Response:

```
sWA CdfPnIpAddr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnIpAddr	String	11	CDF IP address

Variable Telegram Examples

Example: Default Values

Variable telegram examples with data set to default values.

Read Variable:	`[STX]sRN CdfPnIpAddr[ETX]`
Read Variable Response:	`[STX]sRA CdfPnIpAddr C0 A8 0 7B[ETX]`
Write Variable:	`[STX]sWN CdfPnIpAddr C0 A8 0 7B[ETX]`
Write Variable Response:	`[STX]sWA CdfPnIpAddr[ETX]`

© SICK AG - Germany - All rights reserved

2.8.1.3. Variable: CdfProfinetIpMask

The following section contains a detailed description of the variable CdfProfinetIpMask.

Variable Overview

Variable Name	Description
CdfProfinetIpMask	CDF IP mask

Communication Name	CdfPnIpMask
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	86
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{255,255,255,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnIpMask
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnIpMask	String	11	CDF IP mask

Read Variable Response:

```
sRA CdfPnIpMask <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnIpMask	String	11	CDF IP mask
Variable Data	data	Array	4	

Write Variable:

```
sWN CdfPnIpMask <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnIpMask	String	11	CDF IP mask
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnIpMask				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnIpMask	String	11	CDF IP mask

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnIpMask[ETX]
Read Variable Response:	[STX]sRA CdfPnIpMask FF FF FF 0[ETX]
Write Variable:	[STX]sWN CdfPnIpMask FF FF FF 0[ETX]
Write Variable Response:	[STX]sWA CdfPnIpMask[ETX]

2.8.1.4. Variable: CdfProfinetIpGateway

The following section contains a detailed description of the variable CdfProfinetIpGateway.

Variable Overview

Variable Name	Description
CdfProfinetIpGateway	CDF IP gateway

Communication Name	CdfPnImGw
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	87
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnImGw`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnImGw	String	9	CDF IP gateway

Read Variable Response:				
`sRA CdfPnImGw <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnImGw	String	9	CDF IP gateway
Variable Data	data	Array	4	

Write Variable:				
`sWN CdfPnImGw <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnImGw	String	9	CDF IP gateway
Variable Data	data	Array	4	

Write Variable Response:				
`sWA CdfPnImGw`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnImGw	String	9	CDF IP gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnImGw[ETX]`
Read Variable Response:	`[STX]sRA CdfPnImGw 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN CdfPnImGw 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPnImGw[ETX]`

© SICK AG - Germany - All rights reserved

2.8.1.5. Variable: CdfProfinetImFunction

The following section contains a detailed description of the variable CdfProfinetImFunction.

Variable Overview

Variable Name	Description
CdfProfinetImFunction	PROFINET parameter IM_Function; fill with blanks to length

Communication Name	CdfPnImFun
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	88
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnImFun
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnImFun	String	10	PROFINET parameter IM_Function; fill with blanks to length

Read Variable Response:

```
sRA CdfPnImFun <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnImFun	String	10	PROFINET parameter IM_Function; fill with blanks to length
Variable Data	data	FlexString	32	

Write Variable:

```
sWN CdfPnImFun <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnImFun	String	10	PROFINET parameter IM_Function; fill with blanks to length
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA CdfPnImFun
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnImFun				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPnImFun	String	10	PROFINET parameter IM_Function; fill with blanks to length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnImFun[ETX]
Read Variable Response:	[STX]sRA CdfPnImFun 20 [ETX]
Write Variable:	[STX]sWN CdfPnImFun 20 [ETX]
Write Variable Response:	[STX]sWA CdfPnImFun[ETX]

2.8.1.6. Variable: CdfProfinetImLocation

The following section contains a detailed description of the variable CdfProfinetImLocation.

Variable Overview

Variable Name	Description
CdfProfinetImLocation	PROFINET parameter IM_Location; fill with blanks to length

Communication Name	CdfPnImLoc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	89
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

FlexString	
Length	0..22
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnImLoc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnImLoc	String	10	PROFINET parameter IM_Location; fill with blanks to length

Read Variable Response:				
`sRA CdfPnImLoc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnImLoc	String	10	PROFINET parameter IM_Location; fill with blanks to length
Variable Data	data	FlexString	22	

Write Variable:				
`sWN CdfPnImLoc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnImLoc	String	10	PROFINET parameter IM_Location; fill with blanks to length
Variable Data	data	FlexString	22	

Write Variable Response:				
`sWA CdfPnImLoc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnImLoc	String	10	PROFINET parameter IM_Location; fill with blanks to length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnImLoc[ETX]`
Read Variable Response:	`[STX]sRA CdfPnImLoc 16 [ETX]`
Write Variable:	`[STX]sWN CdfPnImLoc 16 [ETX]`
Write Variable Response:	`[STX]sWA CdfPnImLoc[ETX]`

© SICK AG - Germany - All rights reserved

2.8.1.7. Variable: CdfProfinetImDate

The following section contains a detailed description of the variable CdfProfinetImDate.

Variable Overview

Variable Name	Description
CdfProfinetImDate	PROFINET parameter IM_Date; date in ISO8601 notation; fill with blanks to length

Communication Name	CdfPnImDate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	90
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

FlexString	
Length	0..16
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnImDate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnImDate	String	11	PROFINET parameter IM_Date; date in ISO8601 notation; fill with blanks to length

Read Variable Response:

```
sRA CdfPnImDate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnImDate	String	11	PROFINET parameter IM_Date; date in ISO8601 notation; fill with blanks to length
Variable Data	data	FlexString	16	

Write Variable:

```
sWN CdfPnImDate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnImDate	String	11	PROFINET parameter IM_Date; date in ISO8601 notation; fill with blanks to length
Variable Data	data	FlexString	16	

Write Variable Response:

```
sWA CdfPnImDate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnImDate				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPnImDate	String	11	PROFINET parameter IM_Date; date in ISO8601 notation; fill with blanks to length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnImDate[ETX]
Read Variable Response:	[STX]sRA CdfPnImDate 10 [ETX]
Write Variable:	[STX]sWN CdfPnImDate 10 [ETX]
Write Variable Response:	[STX]sWA CdfPnImDate[ETX]

2.8.1.8. Variable: CdfProfinetImDescriptor

The following section contains a detailed description of the variable CdfProfinetImDescriptor.

Variable Overview

Variable Name	Description
CdfProfinetImDescriptor	PROFINET parameter IM_Descriptor: fill with blanks to length

Communication Name	CdfPnImDsc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	91
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

FlexString	
Length	0..54
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnImDsc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnImDsc	String	10	PROFINET parameter IM_Descriptor: fill with blanks to length

Read Variable Response:				
`sRA CdfPnImDsc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnImDsc	String	10	PROFINET parameter IM_Descriptor: fill with blanks to length
Variable Data	data	FlexString	54	

Write Variable:				
`sWN CdfPnImDsc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnImDsc	String	10	PROFINET parameter IM_Descriptor: fill with blanks to length
Variable Data	data	FlexString	54	

Write Variable Response:				
`sWA CdfPnImDsc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnImDsc	String	10	PROFINET parameter IM_Descriptor: fill with blanks to length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnImDsc[ETX]`
Read Variable Response:	`[STX]sRA CdfPnImDsc 36 [ETX]`
Write Variable:	`[STX]sWN CdfPnImDsc 36 [ETX]`
Write Variable Response:	`[STX]sWA CdfPnImDsc[ETX]`

© SICK AG - Germany - All rights reserved

2.8.1.9. Variable: CdfProfinetImSignature

The following section contains a detailed description of the variable CdfProfinetImSignature.

Variable Overview

Variable Name	Description
CdfProfinetImSignature	[imported] PROFINET parameter IM_Signature: fill with zero to length

Communication Name	CdfPnImSign
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	92
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

Array	
Length	54
Default Value	{0,0,0,

Write Variable Response:				
sWA CdfPnImSign				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnImSign	String	11	[imported] PROFINET parameter IM_Signature: fill with zero to length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnImSign[ETX]
Read Variable Response:	[STX]sRA CdfPnImSign 0 0 0

2.8.2. Group: CdfProfinetConfigPDEV

2.8.2.1. Variable: CdfPnPdevMagic

The following section contains a detailed description of the variable CdfPnPdevMagic.

Variable Overview

Variable Name	Description
CdfPnPdevMagic	Magic flag for Profinet PDEV. Value for valid PDEV data is "0x600dfeed".

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	93
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnPdevMagic
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnPdevMagic	String	14	Magic flag for Profinet PDEV. Value for valid PDEV data is "0x600dfeed".

Read Variable Response:

```
sRA CdfPnPdevMagic <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnPdevMagic	String	14	Magic flag for Profinet PDEV. Value for valid PDEV data is "0x600dfeed".
Variable Data	data	UDInt	4	

Write Variable:

```
sWN CdfPnPdevMagic <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnPdevMagic	String	14	Magic flag for Profinet PDEV. Value for valid PDEV data is "0x600dfeed".
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnPdevMagic				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnPdevMagic	String	14	Magic flag for Profinet PDEV. Value for valid PDEV data is "0x600dfeed".

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnPdevMagic[ETX]
Read Variable Response:	[STX]sRA CdfPnPdevMagic 0[ETX]
Write Variable:	[STX]sWN CdfPnPdevMagic 0[ETX]
Write Variable Response:	[STX]sWA CdfPnPdevMagic[ETX]

2.8.2.2. Variable: CdfPnPdevCrc

The following section contains a detailed description of the variable CdfPnPdevCrc.

Variable Overview

Variable Name	Description
CdfPnPdevCrc	CRC32 for Profinet PDEV data.

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	94
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPnPdevCrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnPdevCrc	String	12	CRC32 for Profinet PDEV data.

Read Variable Response:				
`sRA CdfPnPdevCrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnPdevCrc	String	12	CRC32 for Profinet PDEV data.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN CdfPnPdevCrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnPdevCrc	String	12	CRC32 for Profinet PDEV data.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA CdfPnPdevCrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnPdevCrc	String	12	CRC32 for Profinet PDEV data.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPnPdevCrc[ETX]`
Read Variable Response:	`[STX]sRA CdfPnPdevCrc 0[ETX]`
Write Variable:	`[STX]sWN CdfPnPdevCrc 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPnPdevCrc[ETX]`

© SICK AG - Germany - All rights reserved

2.8.2.3. Variable: CdfPnPdevRawData

The following section contains a detailed description of the variable CdfPnPdevRawData.

Variable Overview

Variable Name	Description
CdfPnPdevRawData	Profinet PhysicalDEVice needs unstructured EEPROM area for PDEV records. NOTE: Check mem size!

Communication Name	CdfPnPdev
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	95
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

Array	
Length	0..8192
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfPnPdev
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPnPdev	String	9	Profinet PhysicalDEVice needs unstructured EEPROM area for PDEV records. NOTE: Check mem size!

Read Variable Response:

```
sRA CdfPnPdev <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPnPdev	String	9	Profinet PhysicalDEVice needs unstructured EEPROM area for PDEV records. NOTE: Check mem size!
Variable Data	data	Array	8192	

Write Variable:

```
sWN CdfPnPdev <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPnPdev	String	9	Profinet PhysicalDEVice needs unstructured EEPROM area for PDEV records. NOTE: Check mem size!
Variable Data	data	Array	8192	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfPnPdev				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPnPdev	String	9	Profinet PhysicalDEVice needs unstructured EEPROM area for PDEV records. NOTE: Check mem size!

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPnPdev[ETX]
Read Variable Response:	[STX]sRA CdfPnPdev 0[ETX]
Write Variable:	[STX]sWN CdfPnPdev 0[ETX]
Write Variable Response:	[STX]sWA CdfPnPdev[ETX]

© SICK AG - Germany - All rights reserved

2.9. Interface Block: ExtDeviceShared

2.9.1. Group: ControlAndInformationFlags

2.9.1.1. Variable: ExtDeviceLoadFactoryDefaults

The following section contains a detailed description of the variable ExtDeviceLoadFactoryDefaults.

Variable Overview

Variable Name	Description
ExtDeviceLoadFactoryDefaults	Status: INVALID: Default value. External device can use this state, when ResetFactoryDefaults is occured and then lose this status, because minimum one paramter has been changed. BEGIN: Reset-button in SOPAS-ET is clicked. Before the parameters are reset, the sensor set this state to BEGIN. END: If all parameters are reset then the sensor set this state to END.

Communication Name	ExtDevFacDflt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	96
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		INVALID	
	Value	Name	Description
	0	INVALID	
	1	BEGIN	
	2	END	

Variable Telegram Syntax

Read Variable:

```
sRN ExtDevFacDflt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExtDevFacDflt	String	13	Status: INVALID: Default value. External device can use this state, when ResetFactoryDefaults is occured and then lose this status, because minimum one paramter has been changed. BEGIN: Reset-button in SOPAS-ET is clicked. Before the parameters are reset, the sensor set this state to BEGIN. END: If all parameters are reset then the sensor set this state to END.

Read Variable Response:

```
sRA ExtDevFacDflt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExtDevFacDflt	String	13	Status: INVALID: Default value. External device can use this state, when ResetFactoryDefaults is occured and then lose this status, because minimum one paramter has been changed. BEGIN: Reset-button in SOPAS-ET is clicked. Before the parameters are reset, the sensor set this state to BEGIN. END: If all parameters are reset then the sensor set this state to END.

© SICK AG - Germany - All rights reserved

Read Variable Response:				
`sRA ExtDevFacDflt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Enum8	1	

Write Variable:				
`sWN ExtDevFacDflt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExtDevFacDflt	String	13	Status: INVALID: Default value. External device can use this state, when ResetFactoryDefaults is occured and then lose this status, because minimum one paramter has been changed. BEGIN: Reset-button in SOPAS-ET is clicked. Before the parameters are reset, the sensor set this state to BEGIN. END: If all parameters are reset then the sensor set this state to END.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA ExtDevFacDflt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExtDevFacDflt	String	13	Status: INVALID: Default value. External device can use this state, when ResetFactoryDefaults is occured and then lose this status, because minimum one paramter has been changed. BEGIN: Reset-button in SOPAS-ET is clicked. Before the parameters are reset, the sensor set this state to BEGIN. END: If all parameters are reset then the sensor set this state to END.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExtDevFacDflt[ETX]`
Read Variable Response:	`[STX]sRA ExtDevFacDflt 0[ETX]`
Write Variable:	`[STX]sWN ExtDevFacDflt 0[ETX]`
Write Variable Response:	`[STX]sWA ExtDevFacDflt[ETX]`

© SICK AG - Germany - All rights reserved

2.9.1.2. Variable: ExtDeviceWriteEeprom

The following section contains a detailed description of the variable ExtDeviceWriteEeprom.

Variable Overview

Variable Name	Description
ExtDeviceWriteEeprom	Kind of memory segment that parameters should be stored permanently.

Communication Name	ExtDevEEwrite
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	97
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		NONE	
	Value	Name	Description
	0	NONE	
	1	ALL	
	2	CALIB	
	3	APPLICATION	
	4	FIELDBUS	

Variable Telegram Syntax

Read Variable:

```
sRN ExtDevEEwrite
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExtDevEEwrite	String	13	Kind of memory segment that parameters should be stored permanently.

Read Variable Response:

```
sRA ExtDevEEwrite <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExtDevEEwrite	String	13	Kind of memory segment that parameters should be stored permanently.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN ExtDevEEwrite <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExtDevEEwrite	String	13	Kind of memory segment that parameters should be stored permanently.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExtDevEEwrite				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExtDevEEwrite	String	13	Kind of memory segment that parameters should be stored permanently.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExtDevEEwrite[ETX]
Read Variable Response:	[STX]sRA ExtDevEEwrite 0[ETX]
Write Variable:	[STX]sWN ExtDevEEwrite 0[ETX]
Write Variable Response:	[STX]sWA ExtDevEEwrite[ETX]

© SICK AG - Germany - All rights reserved

2.10. Interface Block: GeneralCfgIOLector6xx

2.10.1. Group: DigitalOutputsLector6xx

2.10.1.1. Variable: Out3FuncEvCndExt

The following section contains a detailed description of the variable Out3FuncEvCndExt.

Variable Overview

Variable Name	Description
Out3FuncEvCndExt	Function of Output 3, EvalCond extension

Communication Name	DO3FncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	99
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO3FncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3FncEvExt	String	11	Function of Output 3, EvalCond extension

Read Variable Response:

```
sRA DO3FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3FncEvExt	String	11	Function of Output 3, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO3FncEvExt <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3FncEvExt	String	11	Function of Output 3, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA DO3FncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3FncEvExt	String	11	Function of Output 3, EvalCond extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO3FncEvExt[ETX]
Read Variable Response:	[STX]sRA DO3FncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO3FncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO3FncEvExt[ETX]

2.10.1.2. Variable: Out3OffFunc

The following section contains a detailed description of the variable Out3OffFunc.

Variable Overview

Variable Name	Description
Out3OffFunc	Off-Function for output 3

Communication Name	DO3OffFnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	100
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIMER_TRACKING	
	1	TX_NEXT_READING_GATE	
	2	TX_COMMAND	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_TEACH1_START	
	6	TX_TEACH2_START	

Variable Telegram Syntax

Read Variable:				
`sRN DO3OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3OffFnc	String	9	Off-Function for output 3

Read Variable Response:				
`sRA DO3OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3OffFnc	String	9	Off-Function for output 3
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO3OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3OffFnc	String	9	Off-Function for output 3
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO3OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3OffFnc	String	9	Off-Function for output 3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3OffFnc[ETX]`
Read Variable Response:	`[STX]sRA DO3OffFnc 0[ETX]`
Write Variable:	`[STX]sWN DO3OffFnc 0[ETX]`
Write Variable Response:	`[STX]sWA DO3OffFnc[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.3. Variable: Out3OffFuncEvCndExt

The following section contains a detailed description of the variable Out3OffFuncEvCndExt.

Variable Overview

Variable Name	Description
Out3OffFuncEvCndExt	Extension of List for EvCnd Output 3

Communication Name	DO3OffFncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	101
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO3OffFncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3OffFncEvExt	String	14	Extension of List for EvCnd Output 3

Read Variable Response:

```
sRA DO3OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3OffFncEvExt	String	14	Extension of List for EvCnd Output 3
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO3OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3OffFncEvExt	String	14	Extension of List for EvCnd Output 3
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DO3OffFncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3OffFncEvExt	String	14	Extension of List for EvCnd Output 3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO3OffFncEvExt[ETX]
Read Variable Response:	[STX]sRA DO3OffFncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO3OffFncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO3OffFncEvExt[ETX]

2.10.1.4. Variable: Out3Logic

The following section contains a detailed description of the variable Out3Logic.

Variable Overview

Variable Name	Description
Out3Logic	True if Output 3 Function is inverted

Communication Name	DO3Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	102
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO3Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3Logic	String	8	True if Output 3 Function is inverted

Read Variable Response:				
`sRA DO3Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3Logic	String	8	True if Output 3 Function is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO3Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3Logic	String	8	True if Output 3 Function is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO3Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3Logic	String	8	True if Output 3 Function is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3Logic[ETX]`
Read Variable Response:	`[STX]sRA DO3Logic 0[ETX]`
Write Variable:	`[STX]sWN DO3Logic 0[ETX]`
Write Variable Response:	`[STX]sWA DO3Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.5. Variable: Out3DurTime

The following section contains a detailed description of the variable Out3DurTime.

Variable Overview

Variable Name	Description
Out3DurTime	Duration of Output 3 if time controlled

Communication Name	DO3DurTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	103
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	10..10000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO3DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3DurTm	String	8	Duration of Output 3 if time controlled

Read Variable Response:

```
sRA DO3DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3DurTm	String	8	Duration of Output 3 if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN DO3DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3DurTm	String	8	Duration of Output 3 if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DO3DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3DurTm	String	8	Duration of Output 3 if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3DurTm[ETX]`
Read Variable Response:	`[STX]sRA DO3DurTm 64[ETX]`
Write Variable:	`[STX]sWN DO3DurTm 64[ETX]`
Write Variable Response:	`[STX]sWA DO3DurTm[ETX]`

2.10.1.6. Variable: Out3DurTrack

The following section contains a detailed description of the variable Out3DurTrack.

Variable Overview

Variable Name	Description
Out3DurTrack	Duration of Output 3 if track controlled

Communication Name	Do3DurTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	104
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN Do3DurTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	Do3DurTrk	String	9	Duration of Output 3 if track controlled

Read Variable Response:

```
sRA Do3DurTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	Do3DurTrk	String	9	Duration of Output 3 if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN Do3DurTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	Do3DurTrk	String	9	Duration of Output 3 if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA Do3DurTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	Do3DurTrk	String	9	Duration of Output 3 if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN Do3DurTrk[ETX]
Read Variable Response:	[STX]sRA Do3DurTrk 64[ETX]
Write Variable:	[STX]sWN Do3DurTrk 64[ETX]
Write Variable Response:	[STX]sWA Do3DurTrk[ETX]

2.10.1.7. Variable: Out3Control

The following section contains a detailed description of the variable Out3Control.

Variable Overview

Variable Name	Description
Out3Control	Switch wether output 3 is time or track controlled

Communication Name	DO3Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	105
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO3Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3Control	String	10	Switch wether output 3 is time or track controlled

Read Variable Response:				
`sRA DO3Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3Control	String	10	Switch wether output 3 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO3Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3Control	String	10	Switch wether output 3 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO3Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3Control	String	10	Switch wether output 3 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3Control[ETX]`
Read Variable Response:	`[STX]sRA DO3Control 0[ETX]`
Write Variable:	`[STX]sWN DO3Control 0[ETX]`
Write Variable Response:	`[STX]sWA DO3Control[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.8. Variable: Out4FuncEvCndExt

The following section contains a detailed description of the variable Out4FuncEvCndExt.

Variable Overview

Variable Name	Description
Out4FuncEvCndExt	Function of Output 4, EvalCond extension

Communication Name	DO4FncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	107
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO4FncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4FncEvExt	String	11	Function of Output 4, EvalCond extension

Read Variable Response:

```
sRA DO4FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4FncEvExt	String	11	Function of Output 4, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO4FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4FncEvExt	String	11	Function of Output 4, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DO4FncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4FncEvExt	String	11	Function of Output 4, EvalCond extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO4FncEvExt[ETX]
Read Variable Response:	[STX]sRA DO4FncEvExt 0 0[ETX]
Write Variable:	[STX]sWN DO4FncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA DO4FncEvExt[ETX]

2.10.1.9. Variable: Out4OffFunc

The following section contains a detailed description of the variable Out4OffFunc.

Variable Overview

Variable Name	Description
Out4OffFunc	Off-Function for output 4

Communication Name	DO4OffFnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	108
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIMER_TRACKING	
	1	TX_NEXT_READING_GATE	
	2	TX_COMMAND	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_TEACH1_START	
	6	TX_TEACH2_START	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO4OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4OffFnc	String	9	Off-Function for output 4

Read Variable Response:				
`sRA DO4OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4OffFnc	String	9	Off-Function for output 4
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO4OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4OffFnc	String	9	Off-Function for output 4
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO4OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4OffFnc	String	9	Off-Function for output 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4OffFnc[ETX]`
Read Variable Response:	`[STX]sRA DO4OffFnc 0[ETX]`
Write Variable:	`[STX]sWN DO4OffFnc 0[ETX]`
Write Variable Response:	`[STX]sWA DO4OffFnc[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.10. Variable: Out4OffFuncEvCndExt

The following section contains a detailed description of the variable Out4OffFuncEvCndExt.

Variable Overview

Variable Name	Description
Out4OffFuncEvCndExt	Extension of List for EvCnd Output 4

Communication Name	DO4OffFncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	109
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO4OffFncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4OffFncEvExt	String	14	Extension of List for EvCnd Output 4

Read Variable Response:

```
sRA DO4OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4OffFncEvExt	String	14	Extension of List for EvCnd Output 4
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO4OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4OffFncEvExt	String	14	Extension of List for EvCnd Output 4
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DO4OffFncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4OffFncEvExt	String	14	Extension of List for EvCnd Output 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4OffFncEvExt[ETX]`
Read Variable Response:	`[STX]sRA DO4OffFncEvExt 0 0[ETX]`
Write Variable:	`[STX]sWN DO4OffFncEvExt 0 0[ETX]`
Write Variable Response:	`[STX]sWA DO4OffFncEvExt[ETX]`

2.10.1.11. Variable: Out4Logic

The following section contains a detailed description of the variable Out4Logic.

Variable Overview

Variable Name	Description
Out4Logic	True if Output 4 Function is inverted

Communication Name	DO4Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	110
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO4Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4Logic	String	8	True if Output 4 Function is inverted

Read Variable Response:				
`sRA DO4Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4Logic	String	8	True if Output 4 Function is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO4Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4Logic	String	8	True if Output 4 Function is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO4Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4Logic	String	8	True if Output 4 Function is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4Logic[ETX]`
Read Variable Response:	`[STX]sRA DO4Logic 0[ETX]`
Write Variable:	`[STX]sWN DO4Logic 0[ETX]`
Write Variable Response:	`[STX]sWA DO4Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.12. Variable: Out4DurTime

The following section contains a detailed description of the variable Out4DurTime.

Variable Overview

Variable Name	Description
Out4DurTime	Duration of Output 4 if time controlled

Communication Name	DO4DurTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	111
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	10..10000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO4DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4DurTm	String	8	Duration of Output 4 if time controlled

Read Variable Response:

```
sRA DO4DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4DurTm	String	8	Duration of Output 4 if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN DO4DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4DurTm	String	8	Duration of Output 4 if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DO4DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4DurTm	String	8	Duration of Output 4 if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4DurTm[ETX]`
Read Variable Response:	`[STX]sRA DO4DurTm 64[ETX]`
Write Variable:	`[STX]sWN DO4DurTm 64[ETX]`
Write Variable Response:	`[STX]sWA DO4DurTm[ETX]`

2.10.1.13. Variable: Out4DurTrack

The following section contains a detailed description of the variable Out4DurTrack.

Variable Overview

Variable Name	Description
Out4DurTrack	Duration of Output 4 if track controlled

Communication Name	DO4DurTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	112
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO4DurTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4DurTrk	String	9	Duration of Output 4 if track controlled

Read Variable Response:

```
sRA DO4DurTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4DurTrk	String	9	Duration of Output 4 if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO4DurTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4DurTrk	String	9	Duration of Output 4 if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DO4DurTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4DurTrk	String	9	Duration of Output 4 if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO4DurTrk[ETX]
Read Variable Response:	[STX]sRA DO4DurTrk 64[ETX]
Write Variable:	[STX]sWN DO4DurTrk 64[ETX]
Write Variable Response:	[STX]sWA DO4DurTrk[ETX]

2.10.1.14. Variable: Out4Control

The following section contains a detailed description of the variable Out4Control.

Variable Overview

Variable Name	Description
Out4Control	Switch wether output 4 is time or track controlled

Communication Name	DO4Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	113
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO4Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4Control	String	10	Switch wether output 4 is time or track controlled

Read Variable Response:				
`sRA DO4Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4Control	String	10	Switch wether output 4 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO4Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4Control	String	10	Switch wether output 4 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO4Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4Control	String	10	Switch wether output 4 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4Control[ETX]`
Read Variable Response:	`[STX]sRA DO4Control 0[ETX]`
Write Variable:	`[STX]sWN DO4Control 0[ETX]`
Write Variable Response:	`[STX]sWA DO4Control[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.15. Variable: Out1Mode

The following section contains a detailed description of the variable Out1Mode.

Variable Overview

Variable Name	Description
Out1Mode	Sets the modus (configuration) for Output 1

Communication Name	DO1Mode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	114
Storage	Variable is stored in ParamEEprom
Read-Access	Service
Write-Access	Service

Enum8			
Default Value		TX_HIGH_SIDE	
	Value	Name	Description
	1	TX_LOW_SIDE	
	2	TX_HIGH_SIDE	

Variable Telegram Syntax

Read Variable:

```
sRN DO1Mode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1Mode	String	7	Sets the modus (configuration) for Output 1

Read Variable Response:

```
sRA DO1Mode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1Mode	String	7	Sets the modus (configuration) for Output 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DO1Mode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1Mode	String	7	Sets the modus (configuration) for Output 1
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DO1Mode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1Mode	String	7	Sets the modus (configuration) for Output 1

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1Mode[ETX]`
Read Variable Response:	`[STX]sRA DO1Mode 2[ETX]`
Write Variable:	`[STX]sWN DO1Mode 2[ETX]`
Write Variable Response:	`[STX]sWA DO1Mode[ETX]`

2.10.1.16. Variable: Out2Mode

The following section contains a detailed description of the variable Out2Mode.

Variable Overview

Variable Name	Description
Out2Mode	Sets the modus (configuration) for Output 2

Communication Name	DO2Mode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	115
Storage	Variable is stored in ParamEEprom
Read-Access	Service
Write-Access	Service

Enum8			
Default Value		TX_HIGH_SIDE	
	Value	Name	Description
	1	TX_LOW_SIDE	
	2	TX_HIGH_SIDE	

Variable Telegram Syntax

Read Variable:				
`sRN DO2Mode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2Mode	String	7	Sets the modus (configuration) for Output 2

Read Variable Response:				
`sRA DO2Mode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2Mode	String	7	Sets the modus (configuration) for Output 2
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO2Mode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2Mode	String	7	Sets the modus (configuration) for Output 2
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DO2Mode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2Mode	String	7	Sets the modus (configuration) for Output 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO2Mode[ETX]
Read Variable Response:	[STX]sRA DO2Mode 2[ETX]
Write Variable:	[STX]sWN DO2Mode 2[ETX]
Write Variable Response:	[STX]sWA DO2Mode[ETX]

2.10.1.17. Variable: Out3Mode

The following section contains a detailed description of the variable Out3Mode.

Variable Overview

Variable Name	Description
Out3Mode	Sets the modus (configuration) for Output 3

Communication Name	DO3Mode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	116
Storage	Variable is stored in ParamEEprom
Read-Access	Service
Write-Access	Service

Enum8			
Default Value		TX_HIGH_SIDE	
	Value	Name	Description
	1	TX_LOW_SIDE	
	2	TX_HIGH_SIDE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO3Mode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3Mode	String	7	Sets the modus (configuration) for Output 3

Read Variable Response:				
`sRA DO3Mode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3Mode	String	7	Sets the modus (configuration) for Output 3
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO3Mode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3Mode	String	7	Sets the modus (configuration) for Output 3
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO3Mode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3Mode	String	7	Sets the modus (configuration) for Output 3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3Mode[ETX]`
Read Variable Response:	`[STX]sRA DO3Mode 2[ETX]`
Write Variable:	`[STX]sWN DO3Mode 2[ETX]`
Write Variable Response:	`[STX]sWA DO3Mode[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.18. Variable: Out4Mode

The following section contains a detailed description of the variable Out4Mode.

Variable Overview

Variable Name	Description
Out4Mode	Sets the modus (configuration) for Output 4

Communication Name	DO4Mode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	117
Storage	Variable is stored in ParamEEprom
Read-Access	Service
Write-Access	Service

Enum8			
Default Value		TX_HIGH_SIDE	
	Value	Name	Description
	1	TX_LOW_SIDE	
	2	TX_HIGH_SIDE	

Variable Telegram Syntax

Read Variable:				
`sRN DO4Mode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4Mode	String	7	Sets the modus (configuration) for Output 4

Read Variable Response:				
`sRA DO4Mode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4Mode	String	7	Sets the modus (configuration) for Output 4
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO4Mode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4Mode	String	7	Sets the modus (configuration) for Output 4
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO4Mode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4Mode	String	7	Sets the modus (configuration) for Output 4

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4Mode[ETX]`
Read Variable Response:	`[STX]sRA DO4Mode 2[ETX]`
Write Variable:	`[STX]sWN DO4Mode 2[ETX]`
Write Variable Response:	`[STX]sWA DO4Mode[ETX]`

2.10.1.19. Variable: Out1ScopingEnabled

The following section contains a detailed description of the variable Out1ScopingEnabled.

Variable Overview

Variable Name	Description
Out1ScopingEnabled	Enforce that DO is inactive when corresponding trigger DI is inactive

Communication Name	DO1Sc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	122
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

`sRN DO1Sc`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive

Read Variable Response:

`sRA DO1Sc <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO1Sc <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DO1Sc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO1Sc[ETX]
Read Variable Response:	[STX]sRA DO1Sc 0[ETX]
Write Variable:	[STX]sWN DO1Sc 0[ETX]
Write Variable Response:	[STX]sWA DO1Sc[ETX]

2.10.1.20. Variable: Out1ScopingExtraDelay

The following section contains a detailed description of the variable Out1ScopingExtraDelay.

Variable Overview

Variable Name	Description
Out1ScopingExtraDelay	Reject DO high-edges in the first ms of a trigger gate; duration of that

Communication Name	DO1ScD
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	123
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO1ScD`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that

Read Variable Response:				
`sRA DO1ScD <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that
Variable Data	data	UInt	2	

Write Variable:				
`sWN DO1ScD <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DO1ScD`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1ScD[ETX]`
Read Variable Response:	`[STX]sRA DO1ScD 0[ETX]`
Write Variable:	`[STX]sWN DO1ScD 0[ETX]`
Write Variable Response:	`[STX]sWA DO1ScD[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.21. Variable: Out2ScopingEnabled

The following section contains a detailed description of the variable Out2ScopingEnabled.

Variable Overview

Variable Name	Description
Out2ScopingEnabled	Enforce that DO is inactive when corresponding trigger DI is inactive

Communication Name	DO2Sc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	124
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DO2Sc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive

Read Variable Response:

```
sRA DO2Sc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive
Variable Data	data	Bool	1	

Write Variable:

```
sWN DO2Sc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DO2Sc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2Sc	String	5	Enforce that DO is inactive when corresponding trigger DI is inactive

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO2Sc[ETX]`
Read Variable Response:	`[STX]sRA DO2Sc 0[ETX]`
Write Variable:	`[STX]sWN DO2Sc 0[ETX]`
Write Variable Response:	`[STX]sWA DO2Sc[ETX]`

2.10.1.22. Variable: Out2ScopingExtraDelay

The following section contains a detailed description of the variable Out2ScopingExtraDelay.

Variable Overview

Variable Name	Description
Out2ScopingExtraDelay	Reject DO high-edges in the first ms of a trigger gate; duration of that

Communication Name	DO2ScD
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	125
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DO2ScD
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that

Read Variable Response:

```
sRA DO2ScD <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO2ScD <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DO2ScD				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2ScD	String	6	Reject DO high-edges in the first ms of a trigger gate; duration of that

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO2ScD[ETX]
Read Variable Response:	[STX]sRA DO2ScD 0[ETX]
Write Variable:	[STX]sWN DO2ScD 0[ETX]
Write Variable Response:	[STX]sWA DO2ScD[ETX]

2.10.1.23. Variable: ResetOutOnTrigger

The following section contains a detailed description of the variable ResetOutOnTrigger.

Variable Overview

Variable Name	Description
ResetOutOnTrigger	Resets all outputs on trigger signal

Communication Name	DOResOutTrig
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	126
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DOResOutTrig`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DOResOutTrig	String	12	Resets all outputs on trigger signal

Read Variable Response:				
`sRA DOResOutTrig <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DOResOutTrig	String	12	Resets all outputs on trigger signal
Variable Data	data	Bool	1	

Write Variable:				
`sWN DOResOutTrig <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DOResOutTrig	String	12	Resets all outputs on trigger signal
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DOResOutTrig`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DOResOutTrig	String	12	Resets all outputs on trigger signal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DOResOutTrig[ETX]`
Read Variable Response:	`[STX]sRA DOResOutTrig 0[ETX]`
Write Variable:	`[STX]sWN DOResOutTrig 0[ETX]`
Write Variable Response:	`[STX]sWA DOResOutTrig[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.24. Variable: Out4Func

The following section contains a detailed description of the variable Out4Func.

Variable Overview

Variable Name	Description
Out4Func	Function of Output 4

Communication Name	DO4Fnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	106
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	2	TX_DEVICE_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	9	TX_EXTERNAL_ILLUMINATION	
	10	TX_PM_FEEDBACK	
	11	TX_MODE_DIGIO_CONDITION1	
	12	TX_MODE_DIGIO_CONDITION2	
	13	TX_MODE_DIGIO_CONDITION3	
	14	TX_MODE_DIGIO_CONDITION4	

Variable Telegram Syntax

Read Variable:

```
sRN DO4Fnc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4Fnc	String	6	Function of Output 4

Read Variable Response:

```
sRA DO4Fnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4Fnc	String	6	Function of Output 4
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DO4Fnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4Fnc	String	6	Function of Output 4

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DO4Fnc <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DO4Fnc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4Fnc	String	6	Function of Output 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DO4Fnc[ETX]
Read Variable Response:	[STX]sRA DO4Fnc 0[ETX]
Write Variable:	[STX]sWN DO4Fnc 0[ETX]
Write Variable Response:	[STX]sWA DO4Fnc[ETX]

2.10.1.25. Variable: Out3Func

The following section contains a detailed description of the variable Out3Func.

Variable Overview

Variable Name	Description
Out3Func	Function of Output 3

Communication Name	DO3Fnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	98
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	2	TX_DEVICE_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	9	TX_PM_FEEDBACK	
	10	TX_MODE_DIGIO_CONDITION1	
	11	TX_MODE_DIGIO_CONDITION2	
	12	TX_MODE_DIGIO_CONDITION3	
	13	TX_MODE_DIGIO_CONDITION4	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO3Fnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3Fnc	String	6	Function of Output 3

Read Variable Response:				
`sRA DO3Fnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3Fnc	String	6	Function of Output 3
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DO3Fnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3Fnc	String	6	Function of Output 3
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DO3Fnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3Fnc	String	6	Function of Output 3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3Fnc[ETX]`
Read Variable Response:	`[STX]sRA DO3Fnc 0[ETX]`
Write Variable:	`[STX]sWN DO3Fnc 0[ETX]`
Write Variable Response:	`[STX]sWA DO3Fnc[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.26. Method: StartModeDigIoCondition1

The following section contains a detailed description of the method StartModeDigIoCondition1.

Method Overview

Method Name
StartModeDigIoCondition1

Communication Name	mStartModeDigIoCondition1
Sopas Index	52
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStartModeDigIoCondition1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStartModeDigIoCondition1	String	25	

Method Return Value:				
`sAN mStartModeDigIoCondition1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStartModeDigIoCondition1	String	25	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStartModeDigIoCondition1[ETX]`
Method Return Value:	`[STX]sAN mStartModeDigIoCondition1[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.27. Method: StopModeDigIoCondition1

The following section contains a detailed description of the method StopModeDigIoCondition1.

Method Overview

Method Name
StopModeDigIoCondition1

Communication Name	mStopModeDigIoCondition1
Sopas Index	53
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStopModeDigIoCondition1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStopModeDigIoCondition1	String	24	

Method Return Value:				
`sAN mStopModeDigIoCondition1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStopModeDigIoCondition1	String	24	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStopModeDigIoCondition1[ETX]`
Method Return Value:	`[STX]sAN mStopModeDigIoCondition1[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.28. Method: StartModeDigIoCondition2

The following section contains a detailed description of the method StartModeDigIoCondition2.

Method Overview

Method Name
StartModeDigIoCondition2

Communication Name	mStartModeDigIoCondition2
Sopas Index	54
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStartModeDigIoCondition2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStartModeDigIoCondition2	String	25	

Method Return Value:				
`sAN mStartModeDigIoCondition2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStartModeDigIoCondition2	String	25	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStartModeDigIoCondition2[ETX]`
Method Return Value:	`[STX]sAN mStartModeDigIoCondition2[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.29. Method: StopModeDigIoCondition2

The following section contains a detailed description of the method StopModeDigIoCondition2.

Method Overview

Method Name
StopModeDigIoCondition2

Communication Name	mStopModeDigIoCondition2
Sopas Index	55
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStopModeDigIoCondition2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStopModeDigIoCondition2	String	24	

Method Return Value:				
`sAN mStopModeDigIoCondition2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStopModeDigIoCondition2	String	24	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStopModeDigIoCondition2[ETX]`
Method Return Value:	`[STX]sAN mStopModeDigIoCondition2[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.30. Method: StartModeDigIoCondition3

The following section contains a detailed description of the method StartModeDigIoCondition3.

Method Overview

Method Name
StartModeDigIoCondition3

Communication Name	mStartModeDigIoCondition3
Sopas Index	56
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStartModeDigIoCondition3`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStartModeDigIoCondition3	String	25	

Method Return Value:				
`sAN mStartModeDigIoCondition3`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStartModeDigIoCondition3	String	25	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStartModeDigIoCondition3[ETX]`
Method Return Value:	`[STX]sAN mStartModeDigIoCondition3[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.31. Method: StopModeDigIoCondition3

The following section contains a detailed description of the method StopModeDigIoCondition3.

Method Overview

Method Name
StopModeDigIoCondition3

Communication Name	mStopModeDigIoCondition3
Sopas Index	57
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

```
sMN mStopModeDigIoCondition3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStopModeDigIoCondition3	String	24	

Method Return Value:

```
sAN mStopModeDigIoCondition3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStopModeDigIoCondition3	String	24	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mStopModeDigIoCondition3[ETX]`
Method Return Value:	`[STX]sAN mStopModeDigIoCondition3[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.32. Method: StartModeDigIoCondition4

The following section contains a detailed description of the method StartModeDigIoCondition4.

Method Overview

Method Name
StartModeDigIoCondition4

Communication Name	mStartModeDigIoCondition4
Sopas Index	58
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStartModeDigIoCondition4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStartModeDigIoCondition4	String	25	

Method Return Value:				
`sAN mStartModeDigIoCondition4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStartModeDigIoCondition4	String	25	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStartModeDigIoCondition4[ETX]`
Method Return Value:	`[STX]sAN mStartModeDigIoCondition4[ETX]`

© SICK AG - Germany - All rights reserved

2.10.1.33. Method: StopModeDigIoCondition4

The following section contains a detailed description of the method StopModeDigIoCondition4.

Method Overview

Method Name
StopModeDigIoCondition4

Communication Name	mStopModeDigIoCondition4
Sopas Index	59
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mStopModeDigIoCondition4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStopModeDigIoCondition4	String	24	

Method Return Value:				
`sAN mStopModeDigIoCondition4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStopModeDigIoCondition4	String	24	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStopModeDigIoCondition4[ETX]`
Method Return Value:	`[STX]sAN mStopModeDigIoCondition4[ETX]`

© SICK AG - Germany - All rights reserved

2.11. Interface Block: GeneralCfgExtIOBase

2.11.1. Group: ExternalOutputsBase

2.11.1.1. Variable: ExtOut1Func

The following section contains a detailed description of the variable ExtOut1Func.

Variable Overview

Variable Name	Description
ExtOut1Func	Function of external Output 1

Communication Name	EO1Fnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	127
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_COMMAND	
	2	TX_DEVICE_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_FIELDBUS	
	6	TX_TEACH1_SUCCESS	
	7	TX_TEACH1_FAIL	
	8	TX_TEACH2_SUCCESS	
	9	TX_TEACH2_FAIL	

Variable Telegram Syntax

Read Variable:

```
sRN EO1Fnc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1Fnc	String	6	Function of external Output 1

Read Variable Response:

```
sRA EO1Fnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1Fnc	String	6	Function of external Output 1
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EO1Fnc <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1Fnc	String	6	Function of external Output 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA EO1Fnc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1Fnc	String	6	Function of external Output 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EO1Fnc[ETX]
Read Variable Response:	[STX]sRA EO1Fnc 0[ETX]
Write Variable:	[STX]sWN EO1Fnc 0[ETX]
Write Variable Response:	[STX]sWA EO1Fnc[ETX]

2.11.1.2. Variable: ExtOut1FuncEvCndExt

The following section contains a detailed description of the variable ExtOut1FuncEvCndExt.

Variable Overview

Variable Name	Description
ExtOut1FuncEvCndExt	Function of external Output 1, EvalCond extension

Communication Name	EO1FncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	128
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO1FncEvExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1FncEvExt	String	11	Function of external Output 1, EvalCond extension

Read Variable Response:				
`sRA EO1FncEvExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1FncEvExt	String	11	Function of external Output 1, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN EO1FncEvExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1FncEvExt	String	11	Function of external Output 1, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA EO1FncEvExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1FncEvExt	String	11	Function of external Output 1, EvalCond extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO1FncEvExt[ETX]`
Read Variable Response:	`[STX]sRA EO1FncEvExt 0 0[ETX]`
Write Variable:	`[STX]sWN EO1FncEvExt 0 0[ETX]`
Write Variable Response:	`[STX]sWA EO1FncEvExt[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.3. Variable: ExtOut1OffFunc

The following section contains a detailed description of the variable ExtOut1OffFunc.

Variable Overview

Variable Name	Description
ExtOut1OffFunc	Off-Function for ext. out. 1

Communication Name	EO1OffFnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	129
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIMER_TRACKING	
	1	TX_NEXT_READING_GATE	
	2	TX_COMMAND	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_TEACH1_START	
	6	TX_TEACH2_START	

Variable Telegram Syntax

Read Variable:

```
sRN EO1OffFnc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1OffFnc	String	9	Off-Function for ext. out. 1

Read Variable Response:

```
sRA EO1OffFnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1OffFnc	String	9	Off-Function for ext. out. 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EO1OffFnc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1OffFnc	String	9	Off-Function for ext. out. 1
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EO1OffFnc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1OffFnc	String	9	Off-Function for ext. out. 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EO1OffFnc[ETX]
Read Variable Response:	[STX]sRA EO1OffFnc 0[ETX]
Write Variable:	[STX]sWN EO1OffFnc 0[ETX]
Write Variable Response:	[STX]sWA EO1OffFnc[ETX]

2.11.1.4. Variable: ExtOut1OffFuncEvCndExt

The following section contains a detailed description of the variable ExtOut1OffFuncEvCndExt.

Variable Overview

Variable Name	Description
ExtOut1OffFuncEvCndExt	Extension of List for EvCnd

Communication Name	EO1OffFncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	130
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO1OffFncEvExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1OffFncEvExt	String	14	Extension of List for EvCnd

Read Variable Response:				
`sRA EO1OffFncEvExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN EO1OffFncEvExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA EO1OffFncEvExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1OffFncEvExt	String	14	Extension of List for EvCnd

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO1OffFncEvExt[ETX]`
Read Variable Response:	`[STX]sRA EO1OffFncEvExt 0 0[ETX]`
Write Variable:	`[STX]sWN EO1OffFncEvExt 0 0[ETX]`
Write Variable Response:	`[STX]sWA EO1OffFncEvExt[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.5. Variable: ExtOut1Logic

The following section contains a detailed description of the variable ExtOut1Logic.

Variable Overview

Variable Name	Description
ExtOut1Logic	True if external Output 1 Function is inverted

Communication Name	EO1Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	131
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

Variable Telegram Syntax

Read Variable:				
`sRN EO1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1Logic	String	8	True if external Output 1 Function is inverted

Read Variable Response:				
`sRA EO1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1Logic	String	8	True if external Output 1 Function is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EO1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1Logic	String	8	True if external Output 1 Function is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EO1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1Logic	String	8	True if external Output 1 Function is inverted

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO1Logic[ETX]`
Read Variable Response:	`[STX]sRA EO1Logic 0[ETX]`
Write Variable:	`[STX]sWN EO1Logic 0[ETX]`
Write Variable Response:	`[STX]sWA EO1Logic[ETX]`

2.11.1.6. Variable: ExtOut1DurTime

The following section contains a detailed description of the variable ExtOut1DurTime.

Variable Overview

Variable Name	Description
ExtOut1DurTime	Duration of external Output 1 if time controlled

Communication Name	EO1DurTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	132
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	10..10000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN EO1DurTm`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1DurTm	String	8	Duration of external Output 1 if time controlled

Read Variable Response:

`sRA EO1DurTm <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1DurTm	String	8	Duration of external Output 1 if time controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN EO1DurTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1DurTm	String	8	Duration of external Output 1 if time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EO1DurTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1DurTm	String	8	Duration of external Output 1 if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO1DurTm[ETX]`
Read Variable Response:	`[STX]sRA EO1DurTm 64[ETX]`
Write Variable:	`[STX]sWN EO1DurTm 64[ETX]`
Write Variable Response:	`[STX]sWA EO1DurTm[ETX]`

2.11.1.7. Variable: ExtOut1DurTrack

The following section contains a detailed description of the variable ExtOut1DurTrack.

Variable Overview

Variable Name	Description
ExtOut1DurTrack	Duration of external Output 1 if track controlled

Communication Name	EO1DurTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	133
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO1DurTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1DurTrk	String	9	Duration of external Output 1 if track controlled

Read Variable Response:				
`sRA EO1DurTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1DurTrk	String	9	Duration of external Output 1 if track controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN EO1DurTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1DurTrk	String	9	Duration of external Output 1 if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EO1DurTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1DurTrk	String	9	Duration of external Output 1 if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO1DurTrk[ETX]`
Read Variable Response:	`[STX]sRA EO1DurTrk 64[ETX]`
Write Variable:	`[STX]sWN EO1DurTrk 64[ETX]`
Write Variable Response:	`[STX]sWA EO1DurTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.8. Variable: ExtOut1Control

The following section contains a detailed description of the variable ExtOut1Control.

Variable Overview

Variable Name	Description
ExtOut1Control	Switch wether external output 1 is time or track controlled

Communication Name	EO1Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	134
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

Variable Telegram Syntax

Read Variable:				
`sRN EO1Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO1Control	String	10	Switch wether external output 1 is time or track controlled

Read Variable Response:				
`sRA EO1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO1Control	String	10	Switch wether external output 1 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EO1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO1Control	String	10	Switch wether external output 1 is time or track controlled
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EO1Control				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO1Control	String	10	Switch wether external output 1 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EO1Control[ETX]
Read Variable Response:	[STX]sRA EO1Control 0[ETX]
Write Variable:	[STX]sWN EO1Control 0[ETX]
Write Variable Response:	[STX]sWA EO1Control[ETX]

2.11.1.9. Variable: ExtOut2Func

The following section contains a detailed description of the variable ExtOut2Func.

Variable Overview

Variable Name	Description
ExtOut2Func	Function of external Output 2

Communication Name	EO2Fnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	135
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_COMMAND	
	2	TX_DEVICE_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_FIELDBUS	
	6	TX_TEACH1_SUCCESS	
	7	TX_TEACH1_FAIL	
	8	TX_TEACH2_SUCCESS	
	9	TX_TEACH2_FAIL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO2Fnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2Fnc	String	6	Function of external Output 2

Read Variable Response:				
`sRA EO2Fnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2Fnc	String	6	Function of external Output 2
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EO2Fnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2Fnc	String	6	Function of external Output 2
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EO2Fnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2Fnc	String	6	Function of external Output 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO2Fnc[ETX]`
Read Variable Response:	`[STX]sRA EO2Fnc 0[ETX]`
Write Variable:	`[STX]sWN EO2Fnc 0[ETX]`
Write Variable Response:	`[STX]sWA EO2Fnc[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.10. Variable: ExtOut2FuncEvCndExt

The following section contains a detailed description of the variable ExtOut2FuncEvCndExt.

Variable Overview

Variable Name	Description
ExtOut2FuncEvCndExt	Function of external Output 2, EvalCond extension

Communication Name	EO2FncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	136
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN EO2FncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2FncEvExt	String	11	Function of external Output 2, EvalCond extension

Read Variable Response:

```
sRA EO2FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2FncEvExt	String	11	Function of external Output 2, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN EO2FncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2FncEvExt	String	11	Function of external Output 2, EvalCond extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EO2FncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2FncEvExt	String	11	Function of external Output 2, EvalCond extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EO2FncEvExt[ETX]
Read Variable Response:	[STX]sRA EO2FncEvExt 0 0[ETX]
Write Variable:	[STX]sWN EO2FncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA EO2FncEvExt[ETX]

2.11.1.11. Variable: ExtOut2OffFunc

The following section contains a detailed description of the variable ExtOut2OffFunc.

Variable Overview

Variable Name	Description
ExtOut2OffFunc	Off-Function for ext. out. 2

Communication Name	EO2OffFnc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	137
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIMER_TRACKING	
	1	TX_NEXT_READING_GATE	
	2	TX_COMMAND	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_TEACH1_START	
	6	TX_TEACH2_START	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO2OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2OffFnc	String	9	Off-Function for ext. out. 2

Read Variable Response:				
`sRA EO2OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2OffFnc	String	9	Off-Function for ext. out. 2
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EO2OffFnc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2OffFnc	String	9	Off-Function for ext. out. 2
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EO2OffFnc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2OffFnc	String	9	Off-Function for ext. out. 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO2OffFnc[ETX]`
Read Variable Response:	`[STX]sRA EO2OffFnc 0[ETX]`
Write Variable:	`[STX]sWN EO2OffFnc 0[ETX]`
Write Variable Response:	`[STX]sWA EO2OffFnc[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.12. Variable: ExtOut2OffFuncEvCndExt

The following section contains a detailed description of the variable ExtOut2OffFuncEvCndExt.

Variable Overview

Variable Name	Description
ExtOut2OffFuncEvCndExt	Extension of List for EvCnd

Communication Name	EO2OffFncEvExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	138
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..18
	Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN EO2OffFncEvExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2OffFncEvExt	String	14	Extension of List for EvCnd

Read Variable Response:

```
sRA EO2OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN EO2OffFncEvExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2OffFncEvExt	String	14	Extension of List for EvCnd
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EO2OffFncEvExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2OffFncEvExt	String	14	Extension of List for EvCnd

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EO2OffFncEvExt[ETX]
Read Variable Response:	[STX]sRA EO2OffFncEvExt 0 0[ETX]
Write Variable:	[STX]sWN EO2OffFncEvExt 0 0[ETX]
Write Variable Response:	[STX]sWA EO2OffFncEvExt[ETX]

2.11.1.13. Variable: ExtOut2Logic

The following section contains a detailed description of the variable ExtOut2Logic.

Variable Overview

Variable Name	Description
ExtOut2Logic	True if external Output 2 Function is inverted

Communication Name	EO2Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	139
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2Logic	String	8	True if external Output 2 Function is inverted

Read Variable Response:				
`sRA EO2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2Logic	String	8	True if external Output 2 Function is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EO2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2Logic	String	8	True if external Output 2 Function is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EO2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2Logic	String	8	True if external Output 2 Function is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO2Logic[ETX]`
Read Variable Response:	`[STX]sRA EO2Logic 0[ETX]`
Write Variable:	`[STX]sWN EO2Logic 0[ETX]`
Write Variable Response:	`[STX]sWA EO2Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.14. Variable: ExtOut2DurTime

The following section contains a detailed description of the variable ExtOut2DurTime.

Variable Overview

Variable Name	Description
ExtOut2DurTime	Duration of external Output 2 if time controlled

Communication Name	EO2DurTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	140
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	10..10000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EO2DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2DurTm	String	8	Duration of external Output 2 if time controlled

Read Variable Response:

```
sRA EO2DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2DurTm	String	8	Duration of external Output 2 if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN EO2DurTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2DurTm	String	8	Duration of external Output 2 if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA EO2DurTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2DurTm	String	8	Duration of external Output 2 if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO2DurTm[ETX]`
Read Variable Response:	`[STX]sRA EO2DurTm 64[ETX]`
Write Variable:	`[STX]sWN EO2DurTm 64[ETX]`
Write Variable Response:	`[STX]sWA EO2DurTm[ETX]`

2.11.1.15. Variable: ExtOut2DurTrack

The following section contains a detailed description of the variable ExtOut2DurTrack.

Variable Overview

Variable Name	Description
ExtOut2DurTrack	Duration of external Output 2 if track controlled

Communication Name	EO2DurTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	141
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN EO2DurTrk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2DurTrk	String	9	Duration of external Output 2 if track controlled

Read Variable Response:

`sRA EO2DurTrk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2DurTrk	String	9	Duration of external Output 2 if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EO2DurTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2DurTrk	String	9	Duration of external Output 2 if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA EO2DurTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2DurTrk	String	9	Duration of external Output 2 if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EO2DurTrk[ETX]
Read Variable Response:	[STX]sRA EO2DurTrk 64[ETX]
Write Variable:	[STX]sWN EO2DurTrk 64[ETX]
Write Variable Response:	[STX]sWA EO2DurTrk[ETX]

2.11.1.16. Variable: ExtOut2Control

The following section contains a detailed description of the variable ExtOut2Control.

Variable Overview

Variable Name	Description
ExtOut2Control	Switch wether external output 2 is time or track controlled

Communication Name	EO2Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	142
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EO2Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EO2Control	String	10	Switch wether external output 2 is time or track controlled

Read Variable Response:				
`sRA EO2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EO2Control	String	10	Switch wether external output 2 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EO2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EO2Control	String	10	Switch wether external output 2 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EO2Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EO2Control	String	10	Switch wether external output 2 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EO2Control[ETX]`
Read Variable Response:	`[STX]sRA EO2Control 0[ETX]`
Write Variable:	`[STX]sWN EO2Control 0[ETX]`
Write Variable Response:	`[STX]sWA EO2Control[ETX]`

© SICK AG - Germany - All rights reserved

2.11.1.17. Method: SetExtOutput

The following section contains a detailed description of the method SetExtOutput.

Method Overview

Method Name	Description
SetExtOutput	sets the specified external output

Communication Name	mEOSetOutput
Sopas Index	60
Invocation Access	Always

Parameters	
Output	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Value	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mEOSetOutput <Output> <Value>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEOSetOutput	String	12	sets the specified external output
Parameter 1	Output	USInt	1	
Parameter 2	Value	USInt	1	

Method Return Value:

```
sAN mEOSetOutput <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEOSetOutput	String	12	sets the specified external output
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEOSetOutput 0 0[ETX]`
Method Return Value:	`[STX]sAN mEOSetOutput 0[ETX]`

© SICK AG - Germany - All rights reserved

2.11.2. Group: ExternalInputsBase

2.11.2.1. Variable: ExtSensor1Sensitivity

The following section contains a detailed description of the variable ExtSensor1Sensitivity.

Variable Overview

Variable Name	Description
ExtSensor1Sensitivity	Sensitivity of external sensor 1

Communication Name	EI1Sens
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	143
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_EDGE	
	1	TX_LEVEL	

Variable Telegram Syntax

Read Variable:

```
sRN EI1Sens
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1Sens	String	7	Sensitivity of external sensor 1

Read Variable Response:

```
sRA EI1Sens <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1Sens	String	7	Sensitivity of external sensor 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EI1Sens <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1Sens	String	7	Sensitivity of external sensor 1
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EI1Sens				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1Sens	String	7	Sensitivity of external sensor 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1Sens[ETX]
Read Variable Response:	[STX]sRA EI1Sens 0[ETX]
Write Variable:	[STX]sWN EI1Sens 0[ETX]
Write Variable Response:	[STX]sWA EI1Sens[ETX]

2.11.2.2. Variable: ExtSensor1Logic

The following section contains a detailed description of the variable ExtSensor1Logic.

Variable Overview

Variable Name	Description
ExtSensor1Logic	External Sensor 1 is inverted

Communication Name	EI1Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	144
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1Logic	String	8	External Sensor 1 is inverted

Read Variable Response:				
`sRA EI1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1Logic	String	8	External Sensor 1 is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI1Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1Logic	String	8	External Sensor 1 is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EI1Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1Logic	String	8	External Sensor 1 is inverted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1Logic[ETX]`
Read Variable Response:	`[STX]sRA EI1Logic 0[ETX]`
Write Variable:	`[STX]sWN EI1Logic 0[ETX]`
Write Variable Response:	`[STX]sWA EI1Logic[ETX]`

© SICK AG - Germany - All rights reserved

2.11.2.3. Variable: ExtSensor1DebounceTime

The following section contains a detailed description of the variable ExtSensor1DebounceTime.

Variable Overview

Variable Name	Description
ExtSensor1DebounceTime	Time controlled Debounce value of external sensor 1

Communication Name	EI1DebTim
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	145
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..2000
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EI1DebTim
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1DebTim	String	9	Time controlled Debounce value of external sensor 1

Read Variable Response:

```
sRA EI1DebTim <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1DebTim	String	9	Time controlled Debounce value of external sensor 1
Variable Data	data	UInt	2	

Write Variable:

```
sWN EI1DebTim <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1DebTim	String	9	Time controlled Debounce value of external sensor 1
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EI1DebTim				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1DebTim	String	9	Time controlled Debounce value of external sensor 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1DebTim[ETX]
Read Variable Response:	[STX]sRA EI1DebTim A[ETX]
Write Variable:	[STX]sWN EI1DebTim A[ETX]
Write Variable Response:	[STX]sWA EI1DebTim[ETX]

2.11.2.4. Variable: ExtSensor1DebounceTrack

The following section contains a detailed description of the variable ExtSensor1DebounceTrack.

Variable Overview

Variable Name	Description
ExtSensor1DebounceTrack	Track controlled Debounce value of external sensor 1

Communication Name	EI1DebTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	146
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..2000
Initialisation	10
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI1DebTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1DebTrk	String	9	Track controlled Debounce value of external sensor 1

Read Variable Response:				
`sRA EI1DebTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1DebTrk	String	9	Track controlled Debounce value of external sensor 1
Variable Data	data	UInt	2	

Write Variable:				
`sWN EI1DebTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1DebTrk	String	9	Track controlled Debounce value of external sensor 1
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EI1DebTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1DebTrk	String	9	Track controlled Debounce value of external sensor 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1DebTrk[ETX]`
Read Variable Response:	`[STX]sRA EI1DebTrk A[ETX]`
Write Variable:	`[STX]sWN EI1DebTrk A[ETX]`
Write Variable Response:	`[STX]sWA EI1DebTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.11.2.5. Variable: ExtSensor1Control

The following section contains a detailed description of the variable ExtSensor1Control.

Variable Overview

Variable Name	Description
ExtSensor1Control	Switch wether external sensor 1 is time or track controlled

Communication Name	EI1Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	147
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

Variable Telegram Syntax

Read Variable:				
`sRN EI1Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1Control	String	10	Switch wether external sensor 1 is time or track controlled

Read Variable Response:				
`sRA EI1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1Control	String	10	Switch wether external sensor 1 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI1Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1Control	String	10	Switch wether external sensor 1 is time or track controlled
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EI1Control				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1Control	String	10	Switch wether external sensor 1 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1Control[ETX]
Read Variable Response:	[STX]sRA EI1Control 0[ETX]
Write Variable:	[STX]sWN EI1Control 0[ETX]
Write Variable Response:	[STX]sWA EI1Control[ETX]

2.11.2.6. Variable: ExtSensor2Sensitivity

The following section contains a detailed description of the variable ExtSensor2Sensitivity.

Variable Overview

Variable Name	Description
ExtSensor2Sensitivity	Sensitivity of external sensor 2

Communication Name	EI2Sens
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	148
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_EDGE	
	1	TX_LEVEL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI2Sens`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI2Sens	String	7	Sensitivity of external sensor 2

Read Variable Response:				
`sRA EI2Sens <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI2Sens	String	7	Sensitivity of external sensor 2
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI2Sens <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI2Sens	String	7	Sensitivity of external sensor 2
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EI2Sens`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI2Sens	String	7	Sensitivity of external sensor 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI2Sens[ETX]`
Read Variable Response:	`[STX]sRA EI2Sens 0[ETX]`
Write Variable:	`[STX]sWN EI2Sens 0[ETX]`
Write Variable Response:	`[STX]sWA EI2Sens[ETX]`

© SICK AG - Germany - All rights reserved

2.11.2.7. Variable: ExtSensor2Logic

The following section contains a detailed description of the variable ExtSensor2Logic.

Variable Overview

Variable Name	Description
ExtSensor2Logic	External Sensor 2 is inverted

Communication Name	EI2Logic
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	149
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ACTIVE_HIGH	
	1	TX_ACTIVE_LOW	

Variable Telegram Syntax

Read Variable:				
`sRN EI2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI2Logic	String	8	External Sensor 2 is inverted

Read Variable Response:				
`sRA EI2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI2Logic	String	8	External Sensor 2 is inverted
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI2Logic <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI2Logic	String	8	External Sensor 2 is inverted
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EI2Logic`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI2Logic	String	8	External Sensor 2 is inverted

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI2Logic[ETX]`
Read Variable Response:	`[STX]sRA EI2Logic 0[ETX]`
Write Variable:	`[STX]sWN EI2Logic 0[ETX]`
Write Variable Response:	`[STX]sWA EI2Logic[ETX]`

2.11.2.8. Variable: ExtSensor2DebounceTime

The following section contains a detailed description of the variable ExtSensor2DebounceTime.

Variable Overview

Variable Name	Description
ExtSensor2DebounceTime	Time controlled Debounce value of external sensor 2

Communication Name	EI2DebTim
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	150
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..2000
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN EI2DebTim`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI2DebTim	String	9	Time controlled Debounce value of external sensor 2

Read Variable Response:

`sRA EI2DebTim <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI2DebTim	String	9	Time controlled Debounce value of external sensor 2
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EI2DebTim <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI2DebTim	String	9	Time controlled Debounce value of external sensor 2
Variable Data	data	UInt	2	

Write Variable Response:				
sWA EI2DebTim				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI2DebTim	String	9	Time controlled Debounce value of external sensor 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI2DebTim[ETX]
Read Variable Response:	[STX]sRA EI2DebTim A[ETX]
Write Variable:	[STX]sWN EI2DebTim A[ETX]
Write Variable Response:	[STX]sWA EI2DebTim[ETX]

2.11.2.9. Variable: ExtSensor2DebounceTrack

The following section contains a detailed description of the variable ExtSensor2DebounceTrack.

Variable Overview

Variable Name	Description
ExtSensor2DebounceTrack	Track controlled Debounce value of external sensor 2

Communication Name	EI2DebTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	151
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..2000
Initialisation	10
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI2DebTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI2DebTrk	String	9	Track controlled Debounce value of external sensor 2

Read Variable Response:				
`sRA EI2DebTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI2DebTrk	String	9	Track controlled Debounce value of external sensor 2
Variable Data	data	UInt	2	

Write Variable:				
`sWN EI2DebTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI2DebTrk	String	9	Track controlled Debounce value of external sensor 2
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EI2DebTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI2DebTrk	String	9	Track controlled Debounce value of external sensor 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI2DebTrk[ETX]`
Read Variable Response:	`[STX]sRA EI2DebTrk A[ETX]`
Write Variable:	`[STX]sWN EI2DebTrk A[ETX]`
Write Variable Response:	`[STX]sWA EI2DebTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.11.2.10. Variable: ExtSensor2Control

The following section contains a detailed description of the variable ExtSensor2Control.

Variable Overview

Variable Name	Description
ExtSensor2Control	Switch wether external sensor 2 is time or track controlled

Communication Name	EI2Control
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	152
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

Variable Telegram Syntax

Read Variable:				
`sRN EI2Control`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI2Control	String	10	Switch wether external sensor 2 is time or track controlled

Read Variable Response:				
`sRA EI2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI2Control	String	10	Switch wether external sensor 2 is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI2Control <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI2Control	String	10	Switch wether external sensor 2 is time or track controlled
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EI2Control				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI2Control	String	10	Switch wether external sensor 2 is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI2Control[ETX]
Read Variable Response:	[STX]sRA EI2Control 0[ETX]
Write Variable:	[STX]sWN EI2Control 0[ETX]
Write Variable Response:	[STX]sWA EI2Control[ETX]

2.11.2.11. Method: ReadExtInput

The following section contains a detailed description of the method ReadExtInput.

Method Overview

Method Name	Description
ReadExtInput	reads the specified external input state

Communication Name	mEIReadInput
Sopas Index	61
Invocation Access	Always

Parameters		
Input		
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Return Values		
Value		
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mEIReadInput <Input>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEIReadInput	String	12	reads the specified external input state
Parameter 1	Input	USInt	1	

Method Return Value:				
`sAN mEIReadInput <Value>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEIReadInput	String	12	reads the specified external input state
Return Value 1	Value	USInt	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEIReadInput 0[ETX]`
Method Return Value:	`[STX]sAN mEIReadInput 0[ETX]`

© SICK AG - Germany - All rights reserved

2.12. Interface Block: GeneralCfgDecoding1DBase

2.12.1. Group: Decoding1DGeneral

2.12.1.1. Variable: CodeContrast1D

The following section contains a detailed description of the variable CodeContrast1D.

Variable Overview

Variable Name	Description
CodeContrast1D	Contrast in per cent that a barcode should have at least

Communication Name	DC1DContrast
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	153
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_CODE_CONTRAST_30	
	Value	Name	Description
	5	TX_CODE_CONTRAST_5	
	10	TX_CODE_CONTRAST_10	
	15	TX_CODE_CONTRAST_15	
	20	TX_CODE_CONTRAST_20	
	25	TX_CODE_CONTRAST_25	
	30	TX_CODE_CONTRAST_30	
	40	TX_CODE_CONTRAST_40	
	50	TX_CODE_CONTRAST_50	
	60	TX_CODE_CONTRAST_60	
	70	TX_CODE_CONTRAST_70	

Variable Telegram Syntax

Read Variable:

```
sRN DC1DContrast
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC1DContrast	String	12	Contrast in per cent that a barcode should have at least

Read Variable Response:

```
sRA DC1DContrast <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC1DContrast	String	12	Contrast in per cent that a barcode should have at least
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DC1DContrast <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC1DContrast	String	12	Contrast in per cent that a barcode should have at least
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DC1DContrast				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DC1DContrast	String	12	Contrast in per cent that a barcode should have at least

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DC1DContrast[ETX]
Read Variable Response:	[STX]sRA DC1DContrast 1E[ETX]
Write Variable:	[STX]sWN DC1DContrast 1E[ETX]
Write Variable Response:	[STX]sWA DC1DContrast[ETX]

2.12.1.2. Variable: CodeBackground1D

The following section contains a detailed description of the variable CodeBackground1D.

Variable Overview

Variable Name	Description
CodeBackground1D	Barcode background color

Communication Name	DC1DBackground
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	154
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_WHITE	
	Value	Name	Description
	0	TX_WHITE	
	1	TX_BLACK	
	2	TX_BOTH	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DC1DBackground`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC1DBackground	String	14	Barcode background color

Read Variable Response:				
`sRA DC1DBackground <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC1DBackground	String	14	Barcode background color
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DC1DBackground <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC1DBackground	String	14	Barcode background color
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DC1DBackground`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DC1DBackground	String	14	Barcode background color

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DC1DBackground[ETX]`
Read Variable Response:	`[STX]sRA DC1DBackground 0[ETX]`
Write Variable:	`[STX]sWN DC1DBackground 0[ETX]`
Write Variable Response:	`[STX]sWA DC1DBackground[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2. Group: Decoding1DBase

2.12.2.1. Variable: CBARMultiRead

The following section contains a detailed description of the variable CBARMultiRead.

Variable Overview

Variable Name	Description
CBARMultiRead	Multiread of Codabar

Communication Name	DCCBARMr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	156
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCCBARMr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARMr	String	8	Multiread of Codabar

Read Variable Response:

```
sRA DCCBARMr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARMr	String	8	Multiread of Codabar
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCCBARMr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARMr	String	8	Multiread of Codabar
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCCBARMr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARMr	String	8	Multiread of Codabar

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCCBARMr[ETX]
Read Variable Response:	[STX]sRA DCCBARMr 3[ETX]
Write Variable:	[STX]sWN DCCBARMr 3[ETX]
Write Variable Response:	[STX]sWA DCCBARMr[ETX]

2.12.2.2. Variable: CBARStaStoIdent

The following section contains a detailed description of the variable CBARStaStoIdent.

Variable Overview

Variable Name	Description
CBARStaStoIdent	Start/Stop identical Codabar

Communication Name	DCCBARStId
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	157
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCCBARStId`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARStId	String	10	Start/Stop identical Codabar

Read Variable Response:				
`sRA DCCBARStId <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARStId	String	10	Start/Stop identical Codabar
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCCBARStId <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARStId	String	10	Start/Stop identical Codabar
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCCBARStId`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARStId	String	10	Start/Stop identical Codabar

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCCBARStId[ETX]`
Read Variable Response:	`[STX]sRA DCCBARStId 0[ETX]`
Write Variable:	`[STX]sWN DCCBARStId 0[ETX]`
Write Variable Response:	`[STX]sWA DCCBARStId[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.3. Variable: CBARStaStoTransmit

The following section contains a detailed description of the variable CBARStaStoTransmit.

Variable Overview

Variable Name	Description
CBARStaStoTransmit	Start/Stop transmit Codabar

Communication Name	DCCBARStTx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	158
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCCBARStTx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARStTx	String	10	Start/Stop transmit Codabar

Read Variable Response:

```
sRA DCCBARStTx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARStTx	String	10	Start/Stop transmit Codabar
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCCBARStTx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARStTx	String	10	Start/Stop transmit Codabar
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCCBARStTx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARStTx	String	10	Start/Stop transmit Codabar

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCCBARStTx[ETX]`
Read Variable Response:	`[STX]sRA DCCBARStTx 0[ETX]`
Write Variable:	`[STX]sWN DCCBARStTx 0[ETX]`
Write Variable Response:	`[STX]sWA DCCBARStTx[ETX]`

2.12.2.4. Variable: CBARCheckDigitTest

The following section contains a detailed description of the variable CBARCheckDigitTest.

Variable Overview

Variable Name	Description
CBARCheckDigitTest	Check Digit Test for Codabar

Communication Name	DCCBARCdTst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	159
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_7DR	
	3	TX_Modulo_16	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCCBARCdTst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARCdTst	String	11	Check Digit Test for Codabar

Read Variable Response:				
`sRA DCCBARCdTst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARCdTst	String	11	Check Digit Test for Codabar
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCCBARCdTst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARCdTst	String	11	Check Digit Test for Codabar
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCCBARCdTst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARCdTst	String	11	Check Digit Test for Codabar

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCCBARCdTst[ETX]`
Read Variable Response:	`[STX]sRA DCCBARCdTst 0[ETX]`
Write Variable:	`[STX]sWN DCCBARCdTst 0[ETX]`
Write Variable Response:	`[STX]sWA DCCBARCdTst[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.5. Variable: CBARLengthMode

The following section contains a detailed description of the variable CBARLengthMode.

Variable Overview

Variable Name	Description
CBARLengthMode	Codelength mode of Codabar

Communication Name	DCCBARLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	160
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCCBARLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARLenMode	String	13	Codelength mode of Codabar

Read Variable Response:

```
sRA DCCBARLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARLenMode	String	13	Codelength mode of Codabar
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCCBARLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARLenMode	String	13	Codelength mode of Codabar
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCCBARLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCCBARLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCCBARLenMode	String	13	Codelength mode of Codabar

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCCBARLenMode[ETX]
Read Variable Response:	[STX]sRA DCCBARLenMode 0[ETX]
Write Variable:	[STX]sWN DCCBARLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCCBARLenMode[ETX]

2.12.2.6. Variable: CBARFixLenList

The following section contains a detailed description of the variable CBARFixLenList.

Variable Overview

Variable Name	Description
CBARFixLenList	List of fix code lengths

Communication Name	DCCBARFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	161
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCCBARFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARFixLen	String	12	List of fix code lengths

Read Variable Response:				
`sRA DCCBARFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARFixLen	String	12	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCCBARFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARFixLen	String	12	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCCBARFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARFixLen	String	12	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCCBARFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCCBARFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCCBARFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCCBARFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.7. Variable: CBARIntLenList

The following section contains a detailed description of the variable CBARIntLenList.

Variable Overview

Variable Name	Description
CBARIntLenList	List of interval code lengths

Communication Name	DCCBARIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	162
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCCBARIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARIntLen	String	12	List of interval code lengths

Read Variable Response:

```
sRA DCCBARIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARIntLen	String	12	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCCBARIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARIntLen	String	12	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCCBARIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARIntLen	String	12	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCCBARIntLen[ETX]
Read Variable Response:	[STX]sRA DCCBARIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCCBARIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCCBARIntLen[ETX]

2.12.2.8. Variable: CBARTransmitCheckDigit

The following section contains a detailed description of the variable CBARTransmitCheckDigit.

Variable Overview

Variable Name	Description
CBARTransmitCheckDigit	Transmit Check Digit for Codabar

Communication Name	DCCBARTrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	163
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCCBARTrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARTrCd	String	10	Transmit Check Digit for Codabar

Read Variable Response:				
`sRA DCCBARTrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARTrCd	String	10	Transmit Check Digit for Codabar
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCCBARTrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARTrCd	String	10	Transmit Check Digit for Codabar
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCCBARTrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARTrCd	String	10	Transmit Check Digit for Codabar

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCCBARTrCd[ETX]`
Read Variable Response:	`[STX]sRA DCCBARTrCd 1[ETX]`
Write Variable:	`[STX]sWN DCCBARTrCd 1[ETX]`
Write Variable Response:	`[STX]sWA DCCBARTrCd[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.9. Variable: C39MultiRead

The following section contains a detailed description of the variable C39MultiRead.

Variable Overview

Variable Name	Description
C39MultiRead	Multiread of Code 39

Communication Name	DCC39Mr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	165
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC39Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39Mr	String	7	Multiread of Code 39

Read Variable Response:

```
sRA DCC39Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39Mr	String	7	Multiread of Code 39
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCC39Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39Mr	String	7	Multiread of Code 39
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCC39Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39Mr	String	7	Multiread of Code 39

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39Mr[ETX]`
Read Variable Response:	`[STX]sRA DCC39Mr 3[ETX]`
Write Variable:	`[STX]sWN DCC39Mr 3[ETX]`
Write Variable Response:	`[STX]sWA DCC39Mr[ETX]`

2.12.2.10. Variable: C39StaStoTransmit

The following section contains a detailed description of the variable C39StaStoTransmit.

Variable Overview

Variable Name	Description
C39StaStoTransmit	Start/Stop transmit Code 39

Communication Name	DCC39StTx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	166
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCC39StTx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39StTx	String	9	Start/Stop transmit Code 39

Read Variable Response:				
`sRA DCC39StTx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39StTx	String	9	Start/Stop transmit Code 39
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC39StTx <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39StTx	String	9	Start/Stop transmit Code 39
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCC39StTx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39StTx	String	9	Start/Stop transmit Code 39

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC39StTx[ETX]
Read Variable Response:	[STX]sRA DCC39StTx 0[ETX]
Write Variable:	[STX]sWN DCC39StTx 0[ETX]
Write Variable Response:	[STX]sWA DCC39StTx[ETX]

2.12.2.11. Variable: C39FullASCII

The following section contains a detailed description of the variable C39FullASCII.

Variable Overview

Variable Name	Description
C39FullASCII	Start/Stop transmit Code 39

Communication Name	DCC39FullA
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	167
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC39FullA`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39FullA	String	10	Start/Stop transmit Code 39

Read Variable Response:				
`sRA DCC39FullA <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39FullA	String	10	Start/Stop transmit Code 39
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC39FullA <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39FullA	String	10	Start/Stop transmit Code 39
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC39FullA`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39FullA	String	10	Start/Stop transmit Code 39

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39FullA[ETX]`
Read Variable Response:	`[STX]sRA DCC39FullA 0[ETX]`
Write Variable:	`[STX]sWN DCC39FullA 0[ETX]`
Write Variable Response:	`[STX]sWA DCC39FullA[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.12. Variable: C39HexASCIIOutput

The following section contains a detailed description of the variable C39HexASCIIOutput.

Variable Overview

Variable Name	Description
C39HexASCIIOutput	Start/Stop transmit Code 39

Communication Name	DCC39HxAOut
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	168
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC39HxAOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39HxAOut	String	11	Start/Stop transmit Code 39

Read Variable Response:

```
sRA DCC39HxAOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39HxAOut	String	11	Start/Stop transmit Code 39
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCC39HxAOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39HxAOut	String	11	Start/Stop transmit Code 39
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCC39HxAOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39HxAOut	String	11	Start/Stop transmit Code 39

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39HxAOut[ETX]`
Read Variable Response:	`[STX]sRA DCC39HxAOut 0[ETX]`
Write Variable:	`[STX]sWN DCC39HxAOut 0[ETX]`
Write Variable Response:	`[STX]sWA DCC39HxAOut[ETX]`

2.12.2.13. Variable: C39CheckDigitTest

The following section contains a detailed description of the variable C39CheckDigitTest.

Variable Overview

Variable Name	Description
C39CheckDigitTest	Check Digit Test for Code 39

Communication Name	DCC39CdTst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	169
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_Modulo_43	

Variable Telegram Syntax

Read Variable:				
`sRN DCC39CdTst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39CdTst	String	10	Check Digit Test for Code 39

Read Variable Response:				
`sRA DCC39CdTst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39CdTst	String	10	Check Digit Test for Code 39
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC39CdTst <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39CdTst	String	10	Check Digit Test for Code 39
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCC39CdTst				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39CdTst	String	10	Check Digit Test for Code 39

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC39CdTst[ETX]
Read Variable Response:	[STX]sRA DCC39CdTst 0[ETX]
Write Variable:	[STX]sWN DCC39CdTst 0[ETX]
Write Variable Response:	[STX]sWA DCC39CdTst[ETX]

2.12.2.14. Variable: C39LengthMode

The following section contains a detailed description of the variable C39LengthMode.

Variable Overview

Variable Name	Description
C39LengthMode	Codelength mode of Code 39

Communication Name	DCC39LenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	170
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC39LenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39LenMode	String	12	Codelength mode of Code 39

Read Variable Response:				
`sRA DCC39LenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39LenMode	String	12	Codelength mode of Code 39
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC39LenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39LenMode	String	12	Codelength mode of Code 39
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCC39LenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39LenMode	String	12	Codelength mode of Code 39

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39LenMode[ETX]`
Read Variable Response:	`[STX]sRA DCC39LenMode 0[ETX]`
Write Variable:	`[STX]sWN DCC39LenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCC39LenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.15. Variable: C39FixLenList

The following section contains a detailed description of the variable C39FixLenList.

Variable Overview

Variable Name	Description
C39FixLenList	List of fix code lengths

Communication Name	DCC39FixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	171
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	5
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:
`sRN DCC39FixLen`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39FixLen	String	11	List of fix code lengths

Read Variable Response:
`sRA DCC39FixLen <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39FixLen	String	11	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:
`sWN DCC39FixLen <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39FixLen	String	11	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC39FixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39FixLen	String	11	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC39FixLen[ETX]
Read Variable Response:	[STX]sRA DCC39FixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCC39FixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCC39FixLen[ETX]

2.12.2.16. Variable: C39IntLenList

The following section contains a detailed description of the variable C39IntLenList.

Variable Overview

Variable Name	Description
C39IntLenList	List of interval code lengths

Communication Name	DCC39IntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	172
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC39IntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39IntLen	String	11	List of interval code lengths

Read Variable Response:				
`sRA DCC39IntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39IntLen	String	11	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCC39IntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39IntLen	String	11	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DCC39IntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39IntLen	String	11	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39IntLen[ETX]`
Read Variable Response:	`[STX]sRA DCC39IntLen 0 0[ETX]`
Write Variable:	`[STX]sWN DCC39IntLen 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCC39IntLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.17. Variable: C39Code32Conversion

The following section contains a detailed description of the variable C39Code32Conversion.

Variable Overview

Variable Name	Description
C39Code32Conversion	If activated the Code39 characters will be converted to Code32 content.

Communication Name	DCC39C32Conv
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	173
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC39C32Conv
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39C32Conv	String	12	If activated the Code39 characters will be converted to Code32 content.

Read Variable Response:

```
sRA DCC39C32Conv <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39C32Conv	String	12	If activated the Code39 characters will be converted to Code32 content.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCC39C32Conv <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39C32Conv	String	12	If activated the Code39 characters will be converted to Code32 content.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCC39C32Conv
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC39C32Conv				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCC39C32Conv	String	12	If activated the Code39 characters will be converted to Code32 content.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC39C32Conv[ETX]
Read Variable Response:	[STX]sRA DCC39C32Conv 0[ETX]
Write Variable:	[STX]sWN DCC39C32Conv 0[ETX]
Write Variable Response:	[STX]sWA DCC39C32Conv[ETX]

2.12.2.18. Variable: C39TransmitCheckDigit

The following section contains a detailed description of the variable C39TransmitCheckDigit.

Variable Overview

Variable Name	Description
C39TransmitCheckDigit	Transmit Check Digit for C39

Communication Name	DCC39TrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	174
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC39TrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39TrCd	String	9	Transmit Check Digit for C39

Read Variable Response:				
`sRA DCC39TrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39TrCd	String	9	Transmit Check Digit for C39
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC39TrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39TrCd	String	9	Transmit Check Digit for C39
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC39TrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39TrCd	String	9	Transmit Check Digit for C39

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39TrCd[ETX]`
Read Variable Response:	`[STX]sRA DCC39TrCd 1[ETX]`
Write Variable:	`[STX]sWN DCC39TrCd 1[ETX]`
Write Variable Response:	`[STX]sWA DCC39TrCd[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.19. Variable: C39ClassRestriction

The following section contains a detailed description of the variable C39ClassRestriction.

Variable Overview

Variable Name	Description
C39ClassRestriction	Classification restriction of Code 39

Communication Name	DCC39ClRs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	175
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	0
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC39ClRs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39ClRs	String	9	Classification restriction of Code 39

Read Variable Response:

```
sRA DCC39ClRs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39ClRs	String	9	Classification restriction of Code 39
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCC39ClRs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39ClRs	String	9	Classification restriction of Code 39
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCC39ClRs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39ClRs	String	9	Classification restriction of Code 39

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39ClRs[ETX]`
Read Variable Response:	`[STX]sRA DCC39ClRs 0[ETX]`
Write Variable:	`[STX]sWN DCC39ClRs 0[ETX]`
Write Variable Response:	`[STX]sWA DCC39ClRs[ETX]`

2.12.2.20. Variable: UPCEANMultiRead

The following section contains a detailed description of the variable UPCEANMultiRead.

Variable Overview

Variable Name	Description
UPCEANMultiRead	Multiread of UPC/EAN

Communication Name	DCUPCEANMr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	177
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCUPCEANMr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCEANMr	String	10	Multiread of UPC/EAN

Read Variable Response:

```
sRA DCUPCEANMr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCEANMr	String	10	Multiread of UPC/EAN
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCUPCEANMr <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCEANMr	String	10	Multiread of UPC/EAN
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DCUPCEANMr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCEANMr	String	10	Multiread of UPC/EAN

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCUPCEANMr[ETX]
Read Variable Response:	[STX]sRA DCUPCEANMr 3[ETX]
Write Variable:	[STX]sWN DCUPCEANMr 3[ETX]
Write Variable Response:	[STX]sWA DCUPCEANMr[ETX]

2.12.2.21. Variable: UPCEANAddOnMode

The following section contains a detailed description of the variable UPCEANAddOnMode.

Variable Overview

Variable Name	Description
UPCEANAddOnMode	Add-On mode

Communication Name	DCAddOnMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	178
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Active	
	2	TX_Required	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCAddOnMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCAddOnMode	String	11	Add-On mode

Read Variable Response:				
`sRA DCAddOnMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCAddOnMode	String	11	Add-On mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCAddOnMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCAddOnMode	String	11	Add-On mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCAddOnMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCAddOnMode	String	11	Add-On mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCAddOnMode[ETX]`
Read Variable Response:	`[STX]sRA DCAddOnMode 0[ETX]`
Write Variable:	`[STX]sWN DCAddOnMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCAddOnMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.22. Variable: UPCEANAddOnLength

The following section contains a detailed description of the variable UPCEANAddOnLength.

Variable Overview

Variable Name	Description
UPCEANAddOnLength	Add-On length

Communication Name	DCAddOnLength
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	179
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_2_Digits	
	1	TX_5_Digits	
	2	TX_2or5_Digits	

Variable Telegram Syntax

Read Variable:

```
sRN DCAddOnLength
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCAddOnLength	String	13	Add-On length

Read Variable Response:

```
sRA DCAddOnLength <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCAddOnLength	String	13	Add-On length
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCAddOnLength <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCAddOnLength	String	13	Add-On length
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCAddOnLength
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCAddOnLength				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCAddOnLength	String	13	Add-On length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCAddOnLength[ETX]
Read Variable Response:	[STX]sRA DCAddOnLength 0[ETX]
Write Variable:	[STX]sWN DCAddOnLength 0[ETX]
Write Variable Response:	[STX]sWA DCAddOnLength[ETX]

2.12.2.23. Variable: UPCEExtended

The following section contains a detailed description of the variable UPCEExtended.

Variable Overview

Variable Name	Description
UPCEExtended	Activates Extended UPC-E

Communication Name	DCUPCExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	182
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCUPCExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCExt	String	8	Activates Extended UPC-E

Read Variable Response:				
`sRA DCUPCExt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCExt	String	8	Activates Extended UPC-E
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCUPCExt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCExt	String	8	Activates Extended UPC-E
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCUPCExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCExt	String	8	Activates Extended UPC-E

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCUPCExt[ETX]`
Read Variable Response:	`[STX]sRA DCUPCExt 0[ETX]`
Write Variable:	`[STX]sWN DCUPCExt 0[ETX]`
Write Variable Response:	`[STX]sWA DCUPCExt[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.24. Variable: EANUPCTransmitCheckDigit

The following section contains a detailed description of the variable EANUPCTransmitCheckDigit.

Variable Overview

Variable Name	Description
EANUPCTransmitCheckDigit	Transmit Check Digit for EAN/UPC

Communication Name	DCEANUPCTrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	183
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCEANUPCTrCd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEANUPCTrCd	String	12	Transmit Check Digit for EAN/UPC

Read Variable Response:

```
sRA DCEANUPCTrCd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEANUPCTrCd	String	12	Transmit Check Digit for EAN/UPC
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCEANUPCTrCd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEANUPCTrCd	String	12	Transmit Check Digit for EAN/UPC
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCEANUPCTrCd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEANUPCTrCd	String	12	Transmit Check Digit for EAN/UPC

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCEANUPCTrCd[ETX]`
Read Variable Response:	`[STX]sRA DCEANUPCTrCd 1[ETX]`
Write Variable:	`[STX]sWN DCEANUPCTrCd 1[ETX]`
Write Variable Response:	`[STX]sWA DCEANUPCTrCd[ETX]`

2.12.2.25. Variable: UPCENumSystem

The following section contains a detailed description of the variable UPCENumSystem.

Variable Overview

Variable Name	Description
UPCENumSystem	Activates output of UPC-E number system

Communication Name	DCUPCNumSys
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	184
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCUPCNumSys`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCNumSys	String	11	Activates output of UPC-E number system

Read Variable Response:				
`sRA DCUPCNumSys <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCNumSys	String	11	Activates output of UPC-E number system
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCUPCNumSys <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCNumSys	String	11	Activates output of UPC-E number system
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCUPCNumSys				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCNumSys	String	11	Activates output of UPC-E number system

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCUPCNumSys[ETX]
Read Variable Response:	[STX]sRA DCUPCNumSys 0[ETX]
Write Variable:	[STX]sWN DCUPCNumSys 0[ETX]
Write Variable Response:	[STX]sWA DCUPCNumSys[ETX]

2.12.2.26. Variable: UPCEANStopCharacterValidation

The following section contains a detailed description of the variable UPCEANStopCharacterValidation.

Variable Overview

Variable Name	Description
UPCEANStopCharacterValidation	Enables / disables the stop character validation

Communication Name	DCUPCEANStopCharVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	187
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCUPCEANStopCharVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCEANStopCharVal	String	19	Enables / disables the stop character validation

Read Variable Response:				
`sRA DCUPCEANStopCharVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCEANStopCharVal	String	19	Enables / disables the stop character validation
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCUPCEANStopCharVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCEANStopCharVal	String	19	Enables / disables the stop character validation
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCUPCEANStopCharVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCEANStopCharVal	String	19	Enables / disables the stop character validation

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCUPCEANStopCharVal[ETX]`
Read Variable Response:	`[STX]sRA DCUPCEANStopCharVal 0[ETX]`
Write Variable:	`[STX]sWN DCUPCEANStopCharVal 0[ETX]`
Write Variable Response:	`[STX]sWA DCUPCEANStopCharVal[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.27. Variable: UPCEANStartCharacterValidation

The following section contains a detailed description of the variable UPCEANStartCharacterValidation.

Variable Overview

Variable Name	Description
UPCEANStartCharacterValidation	Enables / disables the start character validation

Communication Name	DCUPCEANStartCharVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	188
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCUPCEANStartCharVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCEANStartCharVal	String	20	Enables / disables the start character validation

Read Variable Response:

```
sRA DCUPCEANStartCharVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCEANStartCharVal	String	20	Enables / disables the start character validation
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCUPCEANStartCharVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCEANStartCharVal	String	20	Enables / disables the start character validation
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCUPCEANStartCharVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCEANStartCharVal	String	20	Enables / disables the start character validation

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCUPCEANStartCharVal[ETX]`
Read Variable Response:	`[STX]sRA DCUPCEANStartCharVal 0[ETX]`
Write Variable:	`[STX]sWN DCUPCEANStartCharVal 0[ETX]`
Write Variable Response:	`[STX]sWA DCUPCEANStartCharVal[ETX]`

2.12.2.28. Variable: C25ILMultiReadL1

The following section contains a detailed description of the variable C25ILMultiReadL1.

Variable Overview

Variable Name	Description
C25ILMultiReadL1	Multiread of 2/5 Interleaved Length 1

Communication Name	DCC25ILMrL1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	190
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DCC25ILMrL1`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILMrL1	String	11	Multiread of 2/5 Interleaved Length 1

Read Variable Response:

`sRA DCC25ILMrL1 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILMrL1	String	11	Multiread of 2/5 Interleaved Length 1
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC25ILMrL1 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILMrL1	String	11	Multiread of 2/5 Interleaved Length 1
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DCC25ILMrL1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILMrL1	String	11	Multiread of 2/5 Interleaved Length 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILMrL1[ETX]
Read Variable Response:	[STX]sRA DCC25ILMrL1 3[ETX]
Write Variable:	[STX]sWN DCC25ILMrL1 3[ETX]
Write Variable Response:	[STX]sWA DCC25ILMrL1[ETX]

2.12.2.29. Variable: C25ILMultiReadL2

The following section contains a detailed description of the variable C25ILMultiReadL2.

Variable Overview

Variable Name	Description
C25ILMultiReadL2	Multiread of 2/5 Interleaved Length 2

Communication Name	DCC25ILMrL2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	191
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILMrL2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILMrL2	String	11	Multiread of 2/5 Interleaved Length 2

Read Variable Response:				
`sRA DCC25ILMrL2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILMrL2	String	11	Multiread of 2/5 Interleaved Length 2
Variable Data	data	UInt	2	

Write Variable:				
`sWN DCC25ILMrL2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILMrL2	String	11	Multiread of 2/5 Interleaved Length 2
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DCC25ILMrL2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILMrL2	String	11	Multiread of 2/5 Interleaved Length 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILMrL2[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILMrL2 3[ETX]`
Write Variable:	`[STX]sWN DCC25ILMrL2 3[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILMrL2[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.30. Variable: C25ILMultiReadL3

The following section contains a detailed description of the variable C25ILMultiReadL3.

Variable Overview

Variable Name	Description
C25ILMultiReadL3	Multiread of 2/5 Interleaved Length 3

Communication Name	DCC25ILMrL3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	192
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILMrL3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILMrL3	String	11	Multiread of 2/5 Interleaved Length 3

Read Variable Response:

```
sRA DCC25ILMrL3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILMrL3	String	11	Multiread of 2/5 Interleaved Length 3
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCC25ILMrL3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILMrL3	String	11	Multiread of 2/5 Interleaved Length 3
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCC25ILMrL3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILMrL3	String	11	Multiread of 2/5 Interleaved Length 3

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILMrL3[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILMrL3 3[ETX]`
Write Variable:	`[STX]sWN DCC25ILMrL3 3[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILMrL3[ETX]`

2.12.2.31. Variable: C25ILMultiReadL4

The following section contains a detailed description of the variable C25ILMultiReadL4.

Variable Overview

Variable Name	Description
C25ILMultiReadL4	Multiread of 2/5 Interleaved Length 4

Communication Name	DCC25ILMrL4
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	193
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILMrL4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILMrL4	String	11	Multiread of 2/5 Interleaved Length 4

Read Variable Response:				
`sRA DCC25ILMrL4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILMrL4	String	11	Multiread of 2/5 Interleaved Length 4
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC25ILMrL4 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILMrL4	String	11	Multiread of 2/5 Interleaved Length 4
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DCC25ILMrL4				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILMrL4	String	11	Multiread of 2/5 Interleaved Length 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILMrL4[ETX]
Read Variable Response:	[STX]sRA DCC25ILMrL4 3[ETX]
Write Variable:	[STX]sWN DCC25ILMrL4 3[ETX]
Write Variable Response:	[STX]sWA DCC25ILMrL4[ETX]

2.12.2.32. Variable: C25ILMultiReadL5

The following section contains a detailed description of the variable C25ILMultiReadL5.

Variable Overview

Variable Name	Description
C25ILMultiReadL5	Multiread of 2/5 Interleaved Length 5

Communication Name	DCC25ILMrL5
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	194
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILMrL5`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILMrL5	String	11	Multiread of 2/5 Interleaved Length 5

Read Variable Response:				
`sRA DCC25ILMrL5 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILMrL5	String	11	Multiread of 2/5 Interleaved Length 5
Variable Data	data	UInt	2	

Write Variable:				
`sWN DCC25ILMrL5 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILMrL5	String	11	Multiread of 2/5 Interleaved Length 5
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DCC25ILMrL5`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILMrL5	String	11	Multiread of 2/5 Interleaved Length 5

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILMrL5[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILMrL5 3[ETX]`
Write Variable:	`[STX]sWN DCC25ILMrL5 3[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILMrL5[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.33. Variable: C25ILCheckDigitTestL1

The following section contains a detailed description of the variable C25ILCheckDigitTestL1.

Variable Overview

Variable Name	Description
C25ILCheckDigitTestL1	Check Digit Test for Code 25IL Length 1

Communication Name	DCC25ILCdTstL1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	195
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_1R18	
	3	TX_W49M10	
	5	TX_W12CSM10	
	6	TX_ModModulo_11	

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILCdTstL1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILCdTstL1	String	14	Check Digit Test for Code 25IL Length 1

Read Variable Response:

```
sRA DCC25ILCdTstL1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILCdTstL1	String	14	Check Digit Test for Code 25IL Length 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCC25ILCdTstL1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILCdTstL1	String	14	Check Digit Test for Code 25IL Length 1
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC25ILCdTstL1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILCdTstL1	String	14	Check Digit Test for Code 25IL Length 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILCdTstL1[ETX]
Read Variable Response:	[STX]sRA DCC25ILCdTstL1 0[ETX]
Write Variable:	[STX]sWN DCC25ILCdTstL1 0[ETX]
Write Variable Response:	[STX]sWA DCC25ILCdTstL1[ETX]

2.12.2.34. Variable: C25ILCheckDigitTestL2

The following section contains a detailed description of the variable C25ILCheckDigitTestL2.

Variable Overview

Variable Name	Description
C25ILCheckDigitTestL2	Check Digit Test for Code 25IL Length 2

Communication Name	DCC25ILCdTstL2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	196
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_1R18	
	3	TX_W49M10	
	5	TX_W12CSM10	
	6	TX_ModModulo_11	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN DCC25ILCdTstL2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILCdTstL2	String	14	Check Digit Test for Code 25IL Length 2

Read Variable Response:				
sRA DCC25ILCdTstL2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILCdTstL2	String	14	Check Digit Test for Code 25IL Length 2
Variable Data	data	Enum8	1	

Write Variable:				
sWN DCC25ILCdTstL2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILCdTstL2	String	14	Check Digit Test for Code 25IL Length 2
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCC25ILCdTstL2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILCdTstL2	String	14	Check Digit Test for Code 25IL Length 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILCdTstL2[ETX]
Read Variable Response:	[STX]sRA DCC25ILCdTstL2 0[ETX]
Write Variable:	[STX]sWN DCC25ILCdTstL2 0[ETX]
Write Variable Response:	[STX]sWA DCC25ILCdTstL2[ETX]

© SICK AG - Germany - All rights reserved

2.12.2.35. Variable: C25ILCheckDigitTestL3

The following section contains a detailed description of the variable C25ILCheckDigitTestL3.

Variable Overview

Variable Name	Description
C25ILCheckDigitTestL3	Check Digit Test for Code 25IL Length 3

Communication Name	DCC25ILCdTstL3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	197
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_1R18	
	3	TX_W49M10	
	5	TX_W12CSM10	
	6	TX_ModModulo_11	

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILCdTstL3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILCdTstL3	String	14	Check Digit Test for Code 25IL Length 3

Read Variable Response:

```
sRA DCC25ILCdTstL3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILCdTstL3	String	14	Check Digit Test for Code 25IL Length 3
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCC25ILCdTstL3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILCdTstL3	String	14	Check Digit Test for Code 25IL Length 3
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC25ILCdTstL3				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILCdTstL3	String	14	Check Digit Test for Code 25IL Length 3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILCdTstL3[ETX]
Read Variable Response:	[STX]sRA DCC25ILCdTstL3 0[ETX]
Write Variable:	[STX]sWN DCC25ILCdTstL3 0[ETX]
Write Variable Response:	[STX]sWA DCC25ILCdTstL3[ETX]

2.12.2.36. Variable: C25ILCheckDigitTestL4

The following section contains a detailed description of the variable C25ILCheckDigitTestL4.

Variable Overview

Variable Name	Description
C25ILCheckDigitTestL4	Check Digit Test for Code 25IL Length 4

Communication Name	DCC25ILCdTstL4
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	198
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_1R18	
	3	TX_W49M10	
	5	TX_W12CSM10	
	6	TX_ModModulo_11	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILCdTstL4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILCdTstL4	String	14	Check Digit Test for Code 25IL Length 4

Read Variable Response:				
`sRA DCC25ILCdTstL4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILCdTstL4	String	14	Check Digit Test for Code 25IL Length 4
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC25ILCdTstL4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILCdTstL4	String	14	Check Digit Test for Code 25IL Length 4
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCC25ILCdTstL4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILCdTstL4	String	14	Check Digit Test for Code 25IL Length 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILCdTstL4[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILCdTstL4 0[ETX]`
Write Variable:	`[STX]sWN DCC25ILCdTstL4 0[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILCdTstL4[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.37. Variable: C25ILCheckDigitTestL5

The following section contains a detailed description of the variable C25ILCheckDigitTestL5.

Variable Overview

Variable Name	Description
C25ILCheckDigitTestL5	Check Digit Test for Code 25IL Length 5

Communication Name	DCC25ILCdTstL5
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	199
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	
	2	TX_1R18	
	3	TX_W49M10	
	5	TX_W12CSM10	
	6	TX_ModModulo_11	

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILCdTstL5
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILCdTstL5	String	14	Check Digit Test for Code 25IL Length 5

Read Variable Response:

```
sRA DCC25ILCdTstL5 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILCdTstL5	String	14	Check Digit Test for Code 25IL Length 5
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCC25ILCdTstL5 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILCdTstL5	String	14	Check Digit Test for Code 25IL Length 5
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC25ILCdTstL5				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILCdTstL5	String	14	Check Digit Test for Code 25IL Length 5

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILCdTstL5[ETX]
Read Variable Response:	[STX]sRA DCC25ILCdTstL5 0[ETX]
Write Variable:	[STX]sWN DCC25ILCdTstL5 0[ETX]
Write Variable Response:	[STX]sWA DCC25ILCdTstL5[ETX]

2.12.2.38. Variable: C25ILLengthMode

The following section contains a detailed description of the variable C25ILLengthMode.

Variable Overview

Variable Name	Description
C25ILLengthMode	Codelength mode of Code 25IL

Communication Name	DCC25ILLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	200
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILLenMode	String	14	Codelength mode of Code 25IL

Read Variable Response:				
`sRA DCC25ILLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILLenMode	String	14	Codelength mode of Code 25IL
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC25ILLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILLenMode	String	14	Codelength mode of Code 25IL
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCC25ILLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILLenMode	String	14	Codelength mode of Code 25IL

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILLenMode 1[ETX]`
Write Variable:	`[STX]sWN DCC25ILLenMode 1[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.39. Variable: C25ILFixLenList

The following section contains a detailed description of the variable C25ILFixLenList.

Variable Overview

Variable Name	Description
C25ILFixLenList	List of fix code lengths

Communication Name	DCC25ILFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	201
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILFixLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILFixLen	String	13	List of fix code lengths

Read Variable Response:

```
sRA DCC25ILFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILFixLen	String	13	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:

```
sWN DCC25ILFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILFixLen	String	13	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC25ILFixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILFixLen	String	13	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILFixLen[ETX]
Read Variable Response:	[STX]sRA DCC25ILFixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCC25ILFixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCC25ILFixLen[ETX]

2.12.2.40. Variable: C25ILIntLenList

The following section contains a detailed description of the variable C25ILIntLenList.

Variable Overview

Variable Name	Description
C25ILIntLenList	List of interval code lengths

Communication Name	DCC25ILIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	202
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
Default Value		{4, 50}
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILIntLen	String	13	List of interval code lengths

Read Variable Response:				
`sRA DCC25ILIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILIntLen	String	13	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCC25ILIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILIntLen	String	13	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DCC25ILIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILIntLen	String	13	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILIntLen[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILIntLen 4 32[ETX]`
Write Variable:	`[STX]sWN DCC25ILIntLen 4 32[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILIntLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.41. Variable: C25ILClassRestriction

The following section contains a detailed description of the variable C25ILClassRestriction.

Variable Overview

Variable Name	Description
C25ILClassRestriction	Classification restriction of 2/5 Interleaved

Communication Name	DCC25ILClRs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	203
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	0
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILClRs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILClRs	String	11	Classification restriction of 2/5 Interleaved

Read Variable Response:

```
sRA DCC25ILClRs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILClRs	String	11	Classification restriction of 2/5 Interleaved
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCC25ILClRs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILClRs	String	11	Classification restriction of 2/5 Interleaved
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCC25ILClRs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILClRs	String	11	Classification restriction of 2/5 Interleaved

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILClRs[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILClRs 0[ETX]`
Write Variable:	`[STX]sWN DCC25ILClRs 0[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILClRs[ETX]`

2.12.2.42. Variable: C25ILTransmitCheckDigit

The following section contains a detailed description of the variable C25ILTransmitCheckDigit.

Variable Overview

Variable Name	Description
C25ILTransmitCheckDigit	Transmit Check Digit for 25IL

Communication Name	DCC25ILTrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	204
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILTrCd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILTrCd	String	11	Transmit Check Digit for 25IL

Read Variable Response:

```
sRA DCC25ILTrCd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILTrCd	String	11	Transmit Check Digit for 25IL
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DCC25ILTrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILTrCd	String	11	Transmit Check Digit for 25IL
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC25ILTrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILTrCd	String	11	Transmit Check Digit for 25IL

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILTrCd[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILTrCd 1[ETX]`
Write Variable:	`[STX]sWN DCC25ILTrCd 1[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILTrCd[ETX]`

2.12.2.43. Variable: C25ILStopCharacterValidation

The following section contains a detailed description of the variable C25ILStopCharacterValidation.

Variable Overview

Variable Name	Description
C25ILStopCharacterValidation	Enables / disables the stop character validation

Communication Name	DCC25ILStopCharVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	205
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILStopCharVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILStopCharVal	String	18	Enables / disables the stop character validation

Read Variable Response:				
`sRA DCC25ILStopCharVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILStopCharVal	String	18	Enables / disables the stop character validation
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC25ILStopCharVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILStopCharVal	String	18	Enables / disables the stop character validation
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC25ILStopCharVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILStopCharVal	String	18	Enables / disables the stop character validation

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILStopCharVal[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILStopCharVal 0[ETX]`
Write Variable:	`[STX]sWN DCC25ILStopCharVal 0[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILStopCharVal[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.44. Variable: C25ILStartCharacterValidation

The following section contains a detailed description of the variable C25ILStartCharacterValidation.

Variable Overview

Variable Name	Description
C25ILStartCharacterValidation	Enables / disables the start character validation

Communication Name	DCC25ILStartCharVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	206
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC25ILStartCharVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILStartCharVal	String	19	Enables / disables the start character validation

Read Variable Response:

```
sRA DCC25ILStartCharVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILStartCharVal	String	19	Enables / disables the start character validation
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCC25ILStartCharVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILStartCharVal	String	19	Enables / disables the start character validation
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCC25ILStartCharVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILStartCharVal	String	19	Enables / disables the start character validation

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILStartCharVal[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILStartCharVal 0[ETX]`
Write Variable:	`[STX]sWN DCC25ILStartCharVal 0[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILStartCharVal[ETX]`

2.12.2.45. Variable: C25ILSingleErrorCorrection

The following section contains a detailed description of the variable C25ILSingleErrorCorrection.

Variable Overview

Variable Name	Description
C25ILSingleErrorCorrection	Enables / disables the single error correction

Communication Name	DCC25ILSingErrCorr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	207
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILSingErrCorr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILSingErrCorr	String	18	Enables / disables the single error correction

Read Variable Response:				
`sRA DCC25ILSingErrCorr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILSingErrCorr	String	18	Enables / disables the single error correction
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC25ILSingErrCorr <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILSingErrCorr	String	18	Enables / disables the single error correction
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCC25ILSingErrCorr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILSingErrCorr	String	18	Enables / disables the single error correction

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC25ILSingErrCorr[ETX]
Read Variable Response:	[STX]sRA DCC25ILSingErrCorr 0[ETX]
Write Variable:	[STX]sWN DCC25ILSingErrCorr 0[ETX]
Write Variable Response:	[STX]sWA DCC25ILSingErrCorr[ETX]

2.12.2.46. Variable: C25ILQuietZoneVerification

The following section contains a detailed description of the variable C25ILQuietZoneVerification.

Variable Overview

Variable Name	Description
C25ILQuietZoneVerification	Enables / disables the quiet zone verification

Communication Name	DCC25ILQuietZnVer
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	208
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILQuietZnVer`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILQuietZnVer	String	17	Enables / disables the quiet zone verification

Read Variable Response:				
`sRA DCC25ILQuietZnVer <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILQuietZnVer	String	17	Enables / disables the quiet zone verification
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC25ILQuietZnVer <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILQuietZnVer	String	17	Enables / disables the quiet zone verification
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC25ILQuietZnVer`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILQuietZnVer	String	17	Enables / disables the quiet zone verification

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILQuietZnVer[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILQuietZnVer 0[ETX]`
Write Variable:	`[STX]sWN DCC25ILQuietZnVer 0[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILQuietZnVer[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.47. Variable: C93MultiRead

The following section contains a detailed description of the variable C93MultiRead.

Variable Overview

Variable Name	Description
C93MultiRead	Multiread of Code 93

Communication Name	DCC93Mr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	210
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC93Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC93Mr	String	7	Multiread of Code 93

Read Variable Response:

```
sRA DCC93Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC93Mr	String	7	Multiread of Code 93
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCC93Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC93Mr	String	7	Multiread of Code 93
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCC93Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC93Mr	String	7	Multiread of Code 93

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC93Mr[ETX]`
Read Variable Response:	`[STX]sRA DCC93Mr 3[ETX]`
Write Variable:	`[STX]sWN DCC93Mr 3[ETX]`
Write Variable Response:	`[STX]sWA DCC93Mr[ETX]`

2.12.2.48. Variable: C93LengthMode

The following section contains a detailed description of the variable C93LengthMode.

Variable Overview

Variable Name	Description
C93LengthMode	Codelength mode of Code93

Communication Name	DCC93LenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	211
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:				
`sRN DCC93LenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC93LenMode	String	12	Codelength mode of Code93

Read Variable Response:				
`sRA DCC93LenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC93LenMode	String	12	Codelength mode of Code93
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC93LenMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC93LenMode	String	12	Codelength mode of Code93
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCC93LenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC93LenMode	String	12	Codelength mode of Code93

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC93LenMode[ETX]
Read Variable Response:	[STX]sRA DCC93LenMode 0[ETX]
Write Variable:	[STX]sWN DCC93LenMode 0[ETX]
Write Variable Response:	[STX]sWA DCC93LenMode[ETX]

2.12.2.49. Variable: C93FixLenList

The following section contains a detailed description of the variable C93FixLenList.

Variable Overview

Variable Name	Description
C93FixLenList	List of fix code lengths

Communication Name	DCC93FixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	212
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC93FixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC93FixLen	String	11	List of fix code lengths

Read Variable Response:				
`sRA DCC93FixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC93FixLen	String	11	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCC93FixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC93FixLen	String	11	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCC93FixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC93FixLen	String	11	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC93FixLen[ETX]`
Read Variable Response:	`[STX]sRA DCC93FixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCC93FixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCC93FixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.50. Variable: C93IntLenList

The following section contains a detailed description of the variable C93IntLenList.

Variable Overview

Variable Name	Description
C93IntLenList	List of interval code lengths

Communication Name	DCC93IntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	213
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC93IntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC93IntLen	String	11	List of interval code lengths

Read Variable Response:

```
sRA DCC93IntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC93IntLen	String	11	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCC93IntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC93IntLen	String	11	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC93IntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC93IntLen	String	11	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC93IntLen[ETX]
Read Variable Response:	[STX]sRA DCC93IntLen 0 0[ETX]
Write Variable:	[STX]sWN DCC93IntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCC93IntLen[ETX]

2.12.2.51. Variable: C93HexASCIIOutput

The following section contains a detailed description of the variable C93HexASCIIOutput.

Variable Overview

Variable Name	Description
C93HexASCIIOutput	Hex ASCII Output of Code 93

Communication Name	DCC93HxAOut
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	214
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC93HxAOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC93HxAOut	String	11	Hex ASCII Output of Code 93

Read Variable Response:				
`sRA DCC93HxAOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC93HxAOut	String	11	Hex ASCII Output of Code 93
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC93HxAOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC93HxAOut	String	11	Hex ASCII Output of Code 93
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC93HxAOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC93HxAOut	String	11	Hex ASCII Output of Code 93

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC93HxAOut[ETX]`
Read Variable Response:	`[STX]sRA DCC93HxAOut 0[ETX]`
Write Variable:	`[STX]sWN DCC93HxAOut 0[ETX]`
Write Variable Response:	`[STX]sWA DCC93HxAOut[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.52. Variable: C128MultiRead

The following section contains a detailed description of the variable C128MultiRead.

Variable Overview

Variable Name	Description
C128MultiRead	Multiread of Code 128

Communication Name	DCC128Mr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	218
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCC128Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128Mr	String	8	Multiread of Code 128

Read Variable Response:

```
sRA DCC128Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128Mr	String	8	Multiread of Code 128
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCC128Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128Mr	String	8	Multiread of Code 128
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCC128Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128Mr	String	8	Multiread of Code 128

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128Mr[ETX]`
Read Variable Response:	`[STX]sRA DCC128Mr 3[ETX]`
Write Variable:	`[STX]sWN DCC128Mr 3[ETX]`
Write Variable Response:	`[STX]sWA DCC128Mr[ETX]`

2.12.2.53. Variable: C128CheckDigitTestL1

The following section contains a detailed description of the variable C128CheckDigitTestL1.

Variable Overview

Variable Name	Description
C128CheckDigitTestL1	Check Digit Test for Code128 Length 1

Communication Name	DCC128CdTstL1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	219
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_GROUND96	
	2	TX_SSCC18	
	3	TX_W8M11	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC128CdTstL1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128CdTstL1	String	13	Check Digit Test for Code128 Length 1

Read Variable Response:				
`sRA DCC128CdTstL1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128CdTstL1	String	13	Check Digit Test for Code128 Length 1
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC128CdTstL1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128CdTstL1	String	13	Check Digit Test for Code128 Length 1
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCC128CdTstL1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128CdTstL1	String	13	Check Digit Test for Code128 Length 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128CdTstL1[ETX]`
Read Variable Response:	`[STX]sRA DCC128CdTstL1 0[ETX]`
Write Variable:	`[STX]sWN DCC128CdTstL1 0[ETX]`
Write Variable Response:	`[STX]sWA DCC128CdTstL1[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.54. Variable: C128CheckDigitTestL2

The following section contains a detailed description of the variable C128CheckDigitTestL2.

Variable Overview

Variable Name	Description
C128CheckDigitTestL2	Check Digit Test for Code128 Length 2

Communication Name	DCC128CdTstL2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	220
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_GROUND96	
	2	TX_SSCC18	
	3	TX_W8M11	

Variable Telegram Syntax

Read Variable:				
`sRN DCC128CdTstL2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128CdTstL2	String	13	Check Digit Test for Code128 Length 2

Read Variable Response:				
`sRA DCC128CdTstL2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128CdTstL2	String	13	Check Digit Test for Code128 Length 2
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC128CdTstL2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128CdTstL2	String	13	Check Digit Test for Code128 Length 2
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC128CdTstL2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128CdTstL2	String	13	Check Digit Test for Code128 Length 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC128CdTstL2[ETX]
Read Variable Response:	[STX]sRA DCC128CdTstL2 0[ETX]
Write Variable:	[STX]sWN DCC128CdTstL2 0[ETX]
Write Variable Response:	[STX]sWA DCC128CdTstL2[ETX]

2.12.2.55. Variable: C128CheckDigitTestL3

The following section contains a detailed description of the variable C128CheckDigitTestL3.

Variable Overview

Variable Name	Description
C128CheckDigitTestL3	Check Digit Test for Code128 Length 3

Communication Name	DCC128CdTstL3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	221
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_GROUND96	
	2	TX_SSCC18	
	3	TX_W8M11	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC128CdTstL3`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128CdTstL3	String	13	Check Digit Test for Code128 Length 3

Read Variable Response:				
`sRA DCC128CdTstL3 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128CdTstL3	String	13	Check Digit Test for Code128 Length 3
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC128CdTstL3 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128CdTstL3	String	13	Check Digit Test for Code128 Length 3
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCC128CdTstL3`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128CdTstL3	String	13	Check Digit Test for Code128 Length 3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128CdTstL3[ETX]`
Read Variable Response:	`[STX]sRA DCC128CdTstL3 0[ETX]`
Write Variable:	`[STX]sWN DCC128CdTstL3 0[ETX]`
Write Variable Response:	`[STX]sWA DCC128CdTstL3[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.56. Variable: C128CheckDigitTestL4

The following section contains a detailed description of the variable C128CheckDigitTestL4.

Variable Overview

Variable Name	Description
C128CheckDigitTestL4	Check Digit Test for Code128 Length 4

Communication Name	DCC128CdTstL4
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	222
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_GROUND96	
	2	TX_SSCC18	
	3	TX_W8M11	

Variable Telegram Syntax

Read Variable:				
`sRN DCC128CdTstL4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128CdTstL4	String	13	Check Digit Test for Code128 Length 4

Read Variable Response:				
`sRA DCC128CdTstL4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128CdTstL4	String	13	Check Digit Test for Code128 Length 4
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC128CdTstL4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128CdTstL4	String	13	Check Digit Test for Code128 Length 4
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC128CdTstL4				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128CdTstL4	String	13	Check Digit Test for Code128 Length 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC128CdTstL4[ETX]
Read Variable Response:	[STX]sRA DCC128CdTstL4 0[ETX]
Write Variable:	[STX]sWN DCC128CdTstL4 0[ETX]
Write Variable Response:	[STX]sWA DCC128CdTstL4[ETX]

2.12.2.57. Variable: C128CheckDigitTestL5

The following section contains a detailed description of the variable C128CheckDigitTestL5.

Variable Overview

Variable Name	Description
C128CheckDigitTestL5	Check Digit Test for Code128 Length 5

Communication Name	DCC128CdTstL5
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	223
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_None	
	1	TX_GROUND96	
	2	TX_SSCC18	
	3	TX_W8M11	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC128CdTstL5`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128CdTstL5	String	13	Check Digit Test for Code128 Length 5

Read Variable Response:				
`sRA DCC128CdTstL5 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128CdTstL5	String	13	Check Digit Test for Code128 Length 5
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCC128CdTstL5 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128CdTstL5	String	13	Check Digit Test for Code128 Length 5
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCC128CdTstL5`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128CdTstL5	String	13	Check Digit Test for Code128 Length 5

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128CdTstL5[ETX]`
Read Variable Response:	`[STX]sRA DCC128CdTstL5 0[ETX]`
Write Variable:	`[STX]sWN DCC128CdTstL5 0[ETX]`
Write Variable Response:	`[STX]sWA DCC128CdTstL5[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.58. Variable: C128LengthMode

The following section contains a detailed description of the variable C128LengthMode.

Variable Overview

Variable Name	Description
C128LengthMode	Codelength mode of Code128

Communication Name	DCC128LenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	224
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCC128LenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128LenMode	String	13	Codelength mode of Code128

Read Variable Response:

```
sRA DCC128LenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128LenMode	String	13	Codelength mode of Code128
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCC128LenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128LenMode	String	13	Codelength mode of Code128
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCC128LenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC128LenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCC128LenMode	String	13	Codelength mode of Code128

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC128LenMode[ETX]
Read Variable Response:	[STX]sRA DCC128LenMode 0[ETX]
Write Variable:	[STX]sWN DCC128LenMode 0[ETX]
Write Variable Response:	[STX]sWA DCC128LenMode[ETX]

2.12.2.59. Variable: C128FixLenList

The following section contains a detailed description of the variable C128FixLenList.

Variable Overview

Variable Name	Description
C128FixLenList	List of fix code lengths

Communication Name	DCC128FixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	225
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC128FixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128FixLen	String	12	List of fix code lengths

Read Variable Response:				
`sRA DCC128FixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128FixLen	String	12	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCC128FixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128FixLen	String	12	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCC128FixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128FixLen	String	12	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128FixLen[ETX]`
Read Variable Response:	`[STX]sRA DCC128FixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCC128FixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCC128FixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.60. Variable: C128IntLenList

The following section contains a detailed description of the variable C128IntLenList.

Variable Overview

Variable Name	Description
C128IntLenList	List of interval code lengths

Communication Name	DCC128IntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	226
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCC128IntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128IntLen	String	12	List of interval code lengths

Read Variable Response:				
`sRA DCC128IntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128IntLen	String	12	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCC128IntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128IntLen	String	12	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCC128IntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128IntLen	String	12	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC128IntLen[ETX]
Read Variable Response:	[STX]sRA DCC128IntLen 0 0[ETX]
Write Variable:	[STX]sWN DCC128IntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCC128IntLen[ETX]

2.12.2.61. Variable: C128HexASCIIOutput

The following section contains a detailed description of the variable C128HexASCIIOutput.

Variable Overview

Variable Name	Description
C128HexASCIIOutput	Hex ASCII Output of Code 128

Communication Name	DCC128HxAOut
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	227
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC128HxAOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128HxAOut	String	12	Hex ASCII Output of Code 128

Read Variable Response:				
`sRA DCC128HxAOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128HxAOut	String	12	Hex ASCII Output of Code 128
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC128HxAOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128HxAOut	String	12	Hex ASCII Output of Code 128
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC128HxAOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128HxAOut	String	12	Hex ASCII Output of Code 128

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128HxAOut[ETX]`
Read Variable Response:	`[STX]sRA DCC128HxAOut 0[ETX]`
Write Variable:	`[STX]sWN DCC128HxAOut 0[ETX]`
Write Variable Response:	`[STX]sWA DCC128HxAOut[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.62. Variable: C128StopCharacterValidation

The following section contains a detailed description of the variable C128StopCharacterValidation.

Variable Overview

Variable Name	Description
C128StopCharacterValidation	Enables / disables the stop character validation

Communication Name	DCC128StopCharVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	228
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC128StopCharVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128StopCharVal	String	17	Enables / disables the stop character validation

Read Variable Response:

```
sRA DCC128StopCharVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128StopCharVal	String	17	Enables / disables the stop character validation
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCC128StopCharVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128StopCharVal	String	17	Enables / disables the stop character validation
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCC128StopCharVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128StopCharVal	String	17	Enables / disables the stop character validation

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128StopCharVal[ETX]`
Read Variable Response:	`[STX]sRA DCC128StopCharVal 0[ETX]`
Write Variable:	`[STX]sWN DCC128StopCharVal 0[ETX]`
Write Variable Response:	`[STX]sWA DCC128StopCharVal[ETX]`

2.12.2.63. Variable: C128StartCharacterValidation

The following section contains a detailed description of the variable C128StartCharacterValidation.

Variable Overview

Variable Name	Description
C128StartCharacterValidation	Enables / disables the start character validation

Communication Name	DCC128StartCharVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	229
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCC128StartCharVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128StartCharVal	String	18	Enables / disables the start character validation

Read Variable Response:				
`sRA DCC128StartCharVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128StartCharVal	String	18	Enables / disables the start character validation
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC128StartCharVal <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128StartCharVal	String	18	Enables / disables the start character validation
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCC128StartCharVal				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128StartCharVal	String	18	Enables / disables the start character validation

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC128StartCharVal[ETX]
Read Variable Response:	[STX]sRA DCC128StartCharVal 0[ETX]
Write Variable:	[STX]sWN DCC128StartCharVal 0[ETX]
Write Variable Response:	[STX]sWA DCC128StartCharVal[ETX]

2.12.2.64. Variable: C128SingleErrorCorrection

The following section contains a detailed description of the variable C128SingleErrorCorrection.

Variable Overview

Variable Name	Description
C128SingleErrorCorrection	Enables / disables the single error correction

Communication Name	DCC128SingErrCorr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	230
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC128SingErrCorr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128SingErrCorr	String	17	Enables / disables the single error correction

Read Variable Response:				
`sRA DCC128SingErrCorr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128SingErrCorr	String	17	Enables / disables the single error correction
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC128SingErrCorr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128SingErrCorr	String	17	Enables / disables the single error correction
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC128SingErrCorr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128SingErrCorr	String	17	Enables / disables the single error correction

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC128SingErrCorr[ETX]`
Read Variable Response:	`[STX]sRA DCC128SingErrCorr 1[ETX]`
Write Variable:	`[STX]sWN DCC128SingErrCorr 1[ETX]`
Write Variable Response:	`[STX]sWA DCC128SingErrCorr[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.65. Variable: EAN128FirstFC1Val

The following section contains a detailed description of the variable EAN128FirstFC1Val.

Variable Overview

Variable Name	Description
EAN128FirstFC1Val	FC1 replace values if FC1 on first position

Communication Name	DCEAN1281stFc1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	231
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		3
Default Value		{93,67,49}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCEAN1281stFc1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEAN1281stFc1	String	14	FC1 replace values if FC1 on first position

Read Variable Response:

```
sRA DCEAN1281stFc1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEAN1281stFc1	String	14	FC1 replace values if FC1 on first position
Variable Data	data	Array	3	

Write Variable:

```
sWN DCEAN1281stFc1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEAN1281stFc1	String	14	FC1 replace values if FC1 on first position
Variable Data	data	Array	3	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCEAN1281stFc1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEAN1281stFc1	String	14	FC1 replace values if FC1 on first position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCEAN1281stFc1[ETX]
Read Variable Response:	[STX]sRA DCEAN1281stFc1 5D 43 31[ETX]
Write Variable:	[STX]sWN DCEAN1281stFc1 5D 43 31[ETX]
Write Variable Response:	[STX]sWA DCEAN1281stFc1[ETX]

2.12.2.66. Variable: EAN128InsideFC1Val

The following section contains a detailed description of the variable EAN128InsideFC1Val.

Variable Overview

Variable Name	Description
EAN128InsideFC1Val	FC1 replace values if FC1 within code

Communication Name	DCEAN128InsFc1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	232
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		3
Default Value		{29,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCEAN128InsFc1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEAN128InsFc1	String	14	FC1 replace values if FC1 within code

Read Variable Response:				
`sRA DCEAN128InsFc1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEAN128InsFc1	String	14	FC1 replace values if FC1 within code
Variable Data	data	Array	3	

Write Variable:				
`sWN DCEAN128InsFc1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEAN128InsFc1	String	14	FC1 replace values if FC1 within code
Variable Data	data	Array	3	

Write Variable Response:				
`sWA DCEAN128InsFc1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEAN128InsFc1	String	14	FC1 replace values if FC1 within code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCEAN128InsFc1[ETX]`
Read Variable Response:	`[STX]sRA DCEAN128InsFc1 1D 0 0[ETX]`
Write Variable:	`[STX]sWN DCEAN128InsFc1 1D 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCEAN128InsFc1[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.67. Variable: PharmaActive

The following section contains a detailed description of the variable PharmaActive.

Variable Overview

Variable Name	Description
PharmaActive	Activates Pharma Decoder

Communication Name	DCPhrmAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	233
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmAct	String	9	Activates Pharma Decoder

Read Variable Response:

```
sRA DCPhrmAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmAct	String	9	Activates Pharma Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPhrmAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmAct	String	9	Activates Pharma Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPhrmAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmAct	String	9	Activates Pharma Decoder

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmAct[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmAct 0[ETX]`
Write Variable:	`[STX]sWN DCPhrmAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmAct[ETX]`

2.12.2.68. Variable: PharmMultiRead

The following section contains a detailed description of the variable PharmMultiRead.

Variable Overview

Variable Name	Description
PharmMultiRead	Multiread of Pharmacode

Communication Name	DCPhrmMr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	234
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmMr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmMr	String	8	Multiread of Pharmacode

Read Variable Response:

```
sRA DCPhrmMr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmMr	String	8	Multiread of Pharmacode
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPhrmMr <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmMr	String	8	Multiread of Pharmacode
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DCPhrmMr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmMr	String	8	Multiread of Pharmacode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmMr[ETX]
Read Variable Response:	[STX]sRA DCPhrmMr 3[ETX]
Write Variable:	[STX]sWN DCPhrmMr 3[ETX]
Write Variable Response:	[STX]sWA DCPhrmMr[ETX]

2.12.2.69. Variable: PharmModuleWidthMode

The following section contains a detailed description of the variable PharmModuleWidthMode.

Variable Overview

Variable Name	Description
PharmModuleWidthMode	Mode at which allowed module widths of pharma codes are handled

Communication Name	DCPhrmMdWdMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	235
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_AUTO	
	1	TX_USER_DEFINED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmMdWdMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmMdWdMd	String	12	Mode at which allowed module widths of pharma codes are handled

Read Variable Response:				
`sRA DCPhrmMdWdMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmMdWdMd	String	12	Mode at which allowed module widths of pharma codes are handled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPhrmMdWdMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmMdWdMd	String	12	Mode at which allowed module widths of pharma codes are handled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPhrmMdWdMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmMdWdMd	String	12	Mode at which allowed module widths of pharma codes are handled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmMdWdMd[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmMdWdMd 0[ETX]`
Write Variable:	`[STX]sWN DCPhrmMdWdMd 0[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmMdWdMd[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.70. Variable: PharmModuleWidthUserDefined

The following section contains a detailed description of the variable PharmModuleWidthUserDefined.

Variable Overview

Variable Name	Description
PharmModuleWidthUserDefined	Classification limit if PharmModuleWidthMode is user defined.

Communication Name	DCPhrmMdWdUs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	236
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.2..10.0
Initialisation	0.35
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmMdWdUs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmMdWdUs	String	12	Classification limit if PharmModuleWidthMode is user defined.

Read Variable Response:

```
sRA DCPhrmMdWdUs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmMdWdUs	String	12	Classification limit if PharmModuleWidthMode is user defined.
Variable Data	data	Real	4	

Write Variable:

```
sWN DCPhrmMdWdUs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmMdWdUs	String	12	Classification limit if PharmModuleWidthMode is user defined.
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPhrmMdWdUs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmMdWdUs	String	12	Classification limit if PharmModuleWidthMode is user defined.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmMdWdUs[ETX]
Read Variable Response:	[STX]sRA DCPhrmMdWdUs 3EB33333[ETX]
Write Variable:	[STX]sWN DCPhrmMdWdUs 3EB33333[ETX]
Write Variable Response:	[STX]sWA DCPhrmMdWdUs[ETX]

2.12.2.71. Variable: PharmLengthMode

The following section contains a detailed description of the variable PharmLengthMode.

Variable Overview

Variable Name	Description
PharmLengthMode	Codelength mode of Pharmacode

Communication Name	DCPhrmLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	237
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_Fix	
	Value	Name	Description
	0	TX_Free	
	1	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmLenMode	String	13	Codelength mode of Pharmacode

Read Variable Response:				
`sRA DCPhrmLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmLenMode	String	13	Codelength mode of Pharmacode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPhrmLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmLenMode	String	13	Codelength mode of Pharmacode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPhrmLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmLenMode	String	13	Codelength mode of Pharmacode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmLenMode 1[ETX]`
Write Variable:	`[STX]sWN DCPhrmLenMode 1[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.72. Variable: PharmLength

The following section contains a detailed description of the variable PharmLength.

Variable Overview

Variable Name	Description
PharmLength	Length of pharma code

Communication Name	DCPhrmLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	238
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	3..20
Initialisation	4
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmLen	String	9	Length of pharma code

Read Variable Response:

```
sRA DCPhrmLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmLen	String	9	Length of pharma code
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCPhrmLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmLen	String	9	Length of pharma code
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DCPhrmLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmLen	String	9	Length of pharma code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmLen[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmLen 4[ETX]`
Write Variable:	`[STX]sWN DCPhrmLen 4[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmLen[ETX]`

2.12.2.73. Variable: PharmReverse

The following section contains a detailed description of the variable PharmReverse.

Variable Overview

Variable Name	Description
PharmReverse	Reverse output of pharma code

Communication Name	DCPhrmRev
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	239
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmRev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmRev	String	9	Reverse output of pharma code

Read Variable Response:				
`sRA DCPhrmRev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmRev	String	9	Reverse output of pharma code
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPhrmRev <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmRev	String	9	Reverse output of pharma code
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCPhrmRev				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmRev	String	9	Reverse output of pharma code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmRev[ETX]
Read Variable Response:	[STX]sRA DCPhrmRev 0[ETX]
Write Variable:	[STX]sWN DCPhrmRev 0[ETX]
Write Variable Response:	[STX]sWA DCPhrmRev[ETX]

2.12.2.74. Variable: PharmCheckBarGapActive

The following section contains a detailed description of the variable PharmCheckBarGapActive.

Variable Overview

Variable Name	Description
PharmCheckBarGapActive	Activates check for bar/gap tolerances for pharma with niminal modul width

Communication Name	DCPhrmBGAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	240
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmBGAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmBGAct	String	11	Activates check for bar/gap tolerances for pharma with niminal modul width

Read Variable Response:				
`sRA DCPhrmBGAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmBGAct	String	11	Activates check for bar/gap tolerances for pharma with niminal modul width
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPhrmBGAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmBGAct	String	11	Activates check for bar/gap tolerances for pharma with niminal modul width
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPhrmBGAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmBGAct	String	11	Activates check for bar/gap tolerances for pharma with niminal modul width

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmBGAct[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmBGAct 0[ETX]`
Write Variable:	`[STX]sWN DCPhrmBGAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmBGAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.75. Variable: PharmBarSizeMin

The following section contains a detailed description of the variable PharmBarSizeMin.

Variable Overview

Variable Name	Description
PharmBarSizeMin	Minimal allowed bar size in % related to DCPhrmMdWdMd/Us

Communication Name	DCPhrmBSmin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	241
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..100
Initialisation	25
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmBSmin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmBSmin	String	11	Minimal allowed bar size in % related to DCPhrmMdWdMd/Us

Read Variable Response:

```
sRA DCPhrmBSmin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmBSmin	String	11	Minimal allowed bar size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCPhrmBSmin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmBSmin	String	11	Minimal allowed bar size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPhrmBSmin				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmBSmin	String	11	Minimal allowed bar size in % related to DCPhrmMdWdMd/Us

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmBSmin[ETX]
Read Variable Response:	[STX]sRA DCPhrmBSmin 19[ETX]
Write Variable:	[STX]sWN DCPhrmBSmin 19[ETX]
Write Variable Response:	[STX]sWA DCPhrmBSmin[ETX]

2.12.2.76. Variable: PharmBarSizeMax

The following section contains a detailed description of the variable PharmBarSizeMax.

Variable Overview

Variable Name	Description
PharmBarSizeMax	Maximal allowed bar size in % related to DCPhrmMdWdMd/Us

Communication Name	DCPhrmBSmax
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	242
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..600
Initialisation	400
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmBSmax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmBSmax	String	11	Maximal allowed bar size in % related to DCPhrmMdWdMd/Us

Read Variable Response:				
`sRA DCPhrmBSmax <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmBSmax	String	11	Maximal allowed bar size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCPhrmBSmax <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmBSmax	String	11	Maximal allowed bar size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCPhrmBSmax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmBSmax	String	11	Maximal allowed bar size in % related to DCPhrmMdWdMd/Us

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmBSmax[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmBSmax 190[ETX]`
Write Variable:	`[STX]sWN DCPhrmBSmax 190[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmBSmax[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.77. Variable: PharmGapSizeMin

The following section contains a detailed description of the variable PharmGapSizeMin.

Variable Overview

Variable Name	Description
PharmGapSizeMin	Minimal allowed gap size in % related to DCPhrmMdWdMd/Us

Communication Name	DCPhrmGSmin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	243
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..600
Initialisation	25
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmGSmin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmGSmin	String	11	Minimal allowed gap size in % related to DCPhrmMdWdMd/Us

Read Variable Response:

```
sRA DCPhrmGSmin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmGSmin	String	11	Minimal allowed gap size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCPhrmGSmin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmGSmin	String	11	Minimal allowed gap size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPhrmGSmin				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmGSmin	String	11	Minimal allowed gap size in % related to DCPhrmMdWdMd/Us

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmGSmin[ETX]
Read Variable Response:	[STX]sRA DCPhrmGSmin 19[ETX]
Write Variable:	[STX]sWN DCPhrmGSmin 19[ETX]
Write Variable Response:	[STX]sWA DCPhrmGSmin[ETX]

2.12.2.78. Variable: PharmGapSizeMax

The following section contains a detailed description of the variable PharmGapSizeMax.

Variable Overview

Variable Name	Description
PharmGapSizeMax	Maximal allowed gap size in % related to DCPhrmMdWdMd/Us

Communication Name	DCPhrmGSmax
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	244
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..600
Initialisation	400
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmGSmax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmGSmax	String	11	Maximal allowed gap size in % related to DCPhrmMdWdMd/Us

Read Variable Response:				
`sRA DCPhrmGSmax <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmGSmax	String	11	Maximal allowed gap size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCPhrmGSmax <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmGSmax	String	11	Maximal allowed gap size in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCPhrmGSmax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmGSmax	String	11	Maximal allowed gap size in % related to DCPhrmMdWdMd/Us

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmGSmax[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmGSmax 190[ETX]`
Write Variable:	`[STX]sWN DCPhrmGSmax 190[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmGSmax[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.79. Variable: PharmLimitTolSize

The following section contains a detailed description of the variable PharmLimitTolSize.

Variable Overview

Variable Name	Description
PharmLimitTolSize	Threshold tolerance in % related to DCPhrmMdWdMd/Us

Communication Name	DCPhrmLimTol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	245
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..500
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmLimTol
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmLimTol	String	12	Threshold tolerance in % related to DCPhrmMdWdMd/Us

Read Variable Response:

```
sRA DCPhrmLimTol <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmLimTol	String	12	Threshold tolerance in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCPhrmLimTol <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmLimTol	String	12	Threshold tolerance in % related to DCPhrmMdWdMd/Us
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPhrmLimTol				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmLimTol	String	12	Threshold tolerance in % related to DCPhrmMdWdMd/Us

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmLimTol[ETX]
Read Variable Response:	[STX]sRA DCPhrmLimTol 0[ETX]
Write Variable:	[STX]sWN DCPhrmLimTol 0[ETX]
Write Variable Response:	[STX]sWA DCPhrmLimTol[ETX]

2.12.2.80. Variable: Pharm2DigitsEnable

The following section contains a detailed description of the variable Pharm2DigitsEnable.

Variable Overview

Variable Name	Description
Pharm2DigitsEnable	Enables decoding of 2 digits pharmacodes

Communication Name	DCPhrm2Digits
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	246
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrm2Digits`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrm2Digits	String	13	Enables decoding of 2 digits pharmacodes

Read Variable Response:				
`sRA DCPhrm2Digits <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrm2Digits	String	13	Enables decoding of 2 digits pharmacodes
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPhrm2Digits <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrm2Digits	String	13	Enables decoding of 2 digits pharmacodes
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPhrm2Digits`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrm2Digits	String	13	Enables decoding of 2 digits pharmacodes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrm2Digits[ETX]`
Read Variable Response:	`[STX]sRA DCPhrm2Digits 0[ETX]`
Write Variable:	`[STX]sWN DCPhrm2Digits 0[ETX]`
Write Variable Response:	`[STX]sWA DCPhrm2Digits[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.81. Variable: PharmQuietzoneCheckEnable

The following section contains a detailed description of the variable PharmQuietzoneCheckEnable.

Variable Overview

Variable Name	Description
PharmQuietzoneCheckEnable	Activates check of the quiet zone arround the code

Communication Name	DCPhrmQZChck
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	247
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmQZChck
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmQZChck	String	12	Activates check of the quiet zone arround the code

Read Variable Response:

```
sRA DCPhrmQZChck <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmQZChck	String	12	Activates check of the quiet zone arround the code
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPhrmQZChck <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmQZChck	String	12	Activates check of the quiet zone arround the code
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPhrmQZChck
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmQZChck	String	12	Activates check of the quiet zone arround the code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmQZChck[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmQZChck 0[ETX]`
Write Variable:	`[STX]sWN DCPhrmQZChck 0[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmQZChck[ETX]`

2.12.2.82. Variable: PharmAddQuietZoneFact

The following section contains a detailed description of the variable PharmAddQuietZoneFact.

Variable Overview

Variable Name	Description
PharmAddQuietZoneFact	Require quiet zone arround code

Communication Name	DCPhrmAddQZFact
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	248
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	5..50
Initialisation	15
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DCPhrmAddQZFact`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmAddQZFact	String	15	Require quiet zone arround code

Read Variable Response:

`sRA DCPhrmAddQZFact <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmAddQZFact	String	15	Require quiet zone arround code
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPhrmAddQZFact <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmAddQZFact	String	15	Require quiet zone arround code
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCPhrmAddQZFact				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmAddQZFact	String	15	Require quiet zone arround code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmAddQZFact[ETX]
Read Variable Response:	[STX]sRA DCPhrmAddQZFact F[ETX]
Write Variable:	[STX]sWN DCPhrmAddQZFact F[ETX]
Write Variable Response:	[STX]sWA DCPhrmAddQZFact[ETX]

2.12.2.83. Variable: PharmDensityQuietZone

The following section contains a detailed description of the variable PharmDensityQuietZone.

Variable Overview

Variable Name	Description
PharmDensityQuietZone	???

Communication Name	DCPhrmQZDens
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	249
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..100
Initialisation	10
Physical Unit	%
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmQZDens`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmQZDens	String	12	???

Read Variable Response:				
`sRA DCPhrmQZDens <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmQZDens	String	12	???
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCPhrmQZDens <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmQZDens	String	12	???
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCPhrmQZDens`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmQZDens	String	12	???

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmQZDens[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmQZDens A[ETX]`
Write Variable:	`[STX]sWN DCPhrmQZDens A[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmQZDens[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.84. Variable: PharmMinPercUndisturbedQuietZoneScans

The following section contains a detailed description of the variable PharmMinPercUndisturbedQuietZoneScans.

Variable Overview

Variable Name	Description
PharmMinPercUndisturbedQuietZoneScans	Minimal percentage of undisturbed quiet zone scans

Communication Name	DCPhrmPercQZScans
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	250
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..100
Initialisation	100
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPhrmPercQZScans
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmPercQZScans	String	17	Minimal percentage of undisturbed quiet zone scans

Read Variable Response:

```
sRA DCPhrmPercQZScans <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmPercQZScans	String	17	Minimal percentage of undisturbed quiet zone scans
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCPhrmPercQZScans <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmPercQZScans	String	17	Minimal percentage of undisturbed quiet zone scans
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPhrmPercQZScans				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmPercQZScans	String	17	Minimal percentage of undisturbed quiet zone scans

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPhrmPercQZScans[ETX]
Read Variable Response:	[STX]sRA DCPhrmPercQZScans 64[ETX]
Write Variable:	[STX]sWN DCPhrmPercQZScans 64[ETX]
Write Variable Response:	[STX]sWA DCPhrmPercQZScans[ETX]

2.12.2.85. Variable: PharmDecimalOutput

The following section contains a detailed description of the variable PharmDecimalOutput.

Variable Overview

Variable Name	Description
PharmDecimalOutput	Activates decimal code content output

Communication Name	DCPhrmDecOut
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	251
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPhrmDecOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPhrmDecOut	String	12	Activates decimal code content output

Read Variable Response:				
`sRA DCPhrmDecOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPhrmDecOut	String	12	Activates decimal code content output
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPhrmDecOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPhrmDecOut	String	12	Activates decimal code content output
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPhrmDecOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPhrmDecOut	String	12	Activates decimal code content output

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPhrmDecOut[ETX]`
Read Variable Response:	`[STX]sRA DCPhrmDecOut 0[ETX]`
Write Variable:	`[STX]sWN DCPhrmDecOut 0[ETX]`
Write Variable Response:	`[STX]sWA DCPhrmDecOut[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.86. Variable: EnableSMARTDecoder

The following section contains a detailed description of the variable EnableSMARTDecoder.

Variable Overview

Variable Name	Description
EnableSMARTDecoder	Globlally enables the SMART decoders, on top of DecoderAlgorithm variable. When deselected, it is the same as DecoderAlgorithm=TX_StandardOnly. For usage in lower user levels (CLV)

Communication Name	DCEnaSMART
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	253
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCEnaSMART
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEnaSMART	String	10	Globlally enables the SMART decoders, on top of DecoderAlgorithm variable. When deselected, it is the same as DecoderAlgorithm=TX_StandardOnly. For usage in lower user levels (CLV)

Read Variable Response:

```
sRA DCEnaSMART <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEnaSMART	String	10	Globlally enables the SMART decoders, on top of DecoderAlgorithm variable. When deselected, it is the same as DecoderAlgorithm=TX_StandardOnly. For usage in lower user levels (CLV)
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCEnaSMART <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEnaSMART	String	10	Globlally enables the SMART decoders, on top of DecoderAlgorithm variable. When deselected, it is the same as DecoderAlgorithm=TX_StandardOnly. For usage in lower user levels (CLV)
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCEnaSMART				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEnaSMART	String	10	Globlally enables the SMART decoders, on top of DecoderAlgorithm variable. When deselected, it is the same as DecoderAlgorithm=TX_StandardOnly. For usage in lower user levels (CLV)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCEnaSMART[ETX]
Read Variable Response:	[STX]sRA DCEnaSMART 1[ETX]
Write Variable:	[STX]sWN DCEnaSMART 1[ETX]
Write Variable Response:	[STX]sWA DCEnaSMART[ETX]

2.12.2.87. Variable: ExtendedSegmentation

The following section contains a detailed description of the variable ExtendedSegmentation.

Variable Overview

Variable Name	Description
ExtendedSegmentation	Extended segmentation for decoders

Communication Name	D1DExtSeg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	255
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN D1DExtSeg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DExtSeg	String	9	Extended segmentation for decoders

Read Variable Response:				
`sRA D1DExtSeg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DExtSeg	String	9	Extended segmentation for decoders
Variable Data	data	Bool	1	

Write Variable:				
`sWN D1DExtSeg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DExtSeg	String	9	Extended segmentation for decoders
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA D1DExtSeg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DExtSeg	String	9	Extended segmentation for decoders

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D1DExtSeg[ETX]`
Read Variable Response:	`[STX]sRA D1DExtSeg 0[ETX]`
Write Variable:	`[STX]sWN D1DExtSeg 0[ETX]`
Write Variable Response:	`[STX]sWA D1DExtSeg[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.88. Variable: UPCAAActive

The following section contains a detailed description of the variable UPCAAActive.

Variable Overview

Variable Name	Description
UPCAAActive	Activates UPC-A

Communication Name	DCUPCAAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	180
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCUPCAAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCAAct	String	9	Activates UPC-A

Read Variable Response:

```
sRA DCUPCAAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCAAct	String	9	Activates UPC-A
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCUPCAAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCAAct	String	9	Activates UPC-A
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCUPCAAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCAAct	String	9	Activates UPC-A

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCUPCAAct[ETX]`
Read Variable Response:	`[STX]sRA DCUPCAAct 0[ETX]`
Write Variable:	`[STX]sWN DCUPCAAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCUPCAAct[ETX]`

2.12.2.89. Variable: EAN128Active

The following section contains a detailed description of the variable EAN128Active.

Variable Overview

Variable Name	Description
EAN128Active	Activates EAN 128

Communication Name	DCEAN128Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	217
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

`sRN DCEAN128Act`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEAN128Act	String	11	Activates EAN 128

Read Variable Response:

`sRA DCEAN128Act <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEAN128Act	String	11	Activates EAN 128
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCEAN128Act <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEAN128Act	String	11	Activates EAN 128
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCEAN128Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEAN128Act	String	11	Activates EAN 128

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCEAN128Act[ETX]
Read Variable Response:	[STX]sRA DCEAN128Act 0[ETX]
Write Variable:	[STX]sWN DCEAN128Act 0[ETX]
Write Variable Response:	[STX]sWA DCEAN128Act[ETX]

2.12.2.90. Variable: C25ILActive

The following section contains a detailed description of the variable C25ILActive.

Variable Overview

Variable Name	Description
C25ILActive	Activates 2/5 Interleaved Decoder

Communication Name	DCC25ILAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	189
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCC25ILAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC25ILAct	String	10	Activates 2/5 Interleaved Decoder

Read Variable Response:				
`sRA DCC25ILAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC25ILAct	String	10	Activates 2/5 Interleaved Decoder
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCC25ILAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC25ILAct	String	10	Activates 2/5 Interleaved Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCC25ILAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC25ILAct	String	10	Activates 2/5 Interleaved Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC25ILAct[ETX]`
Read Variable Response:	`[STX]sRA DCC25ILAct 0[ETX]`
Write Variable:	`[STX]sWN DCC25ILAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCC25ILAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.91. Variable: C39Active

The following section contains a detailed description of the variable C39Active.

Variable Overview

Variable Name	Description
C39Active	Activates Code 39 Decoder

Communication Name	DCC39Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	164
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC39Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC39Act	String	8	Activates Code 39 Decoder

Read Variable Response:

```
sRA DCC39Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC39Act	String	8	Activates Code 39 Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCC39Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC39Act	String	8	Activates Code 39 Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCC39Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC39Act	String	8	Activates Code 39 Decoder

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC39Act[ETX]`
Read Variable Response:	`[STX]sRA DCC39Act 0[ETX]`
Write Variable:	`[STX]sWN DCC39Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCC39Act[ETX]`

2.12.2.92. Variable: EAN8Active

The following section contains a detailed description of the variable EAN8Active.

Variable Overview

Variable Name	Description
EAN8Active	Activates EAN8

Communication Name	DCEAN8Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	185
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCEAN8Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEAN8Act	String	9	Activates EAN8

Read Variable Response:				
`sRA DCEAN8Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEAN8Act	String	9	Activates EAN8
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCEAN8Act <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEAN8Act	String	9	Activates EAN8
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCEAN8Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEAN8Act	String	9	Activates EAN8

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCEAN8Act[ETX]
Read Variable Response:	[STX]sRA DCEAN8Act 0[ETX]
Write Variable:	[STX]sWN DCEAN8Act 0[ETX]
Write Variable Response:	[STX]sWA DCEAN8Act[ETX]

2.12.2.93. Variable: UPCEANActive

The following section contains a detailed description of the variable UPCEANActive.

Variable Overview

Variable Name	Description
UPCEANActive	Activates UPC and EAN Decoder

Communication Name	DCUPCEANAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	176
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCUPCEANAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCEANAct	String	11	Activates UPC and EAN Decoder

Read Variable Response:				
`sRA DCUPCEANAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCEANAct	String	11	Activates UPC and EAN Decoder
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCUPCEANAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCEANAct	String	11	Activates UPC and EAN Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCUPCEANAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCEANAct	String	11	Activates UPC and EAN Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCUPCEANAct[ETX]`
Read Variable Response:	`[STX]sRA DCUPCEANAct 0[ETX]`
Write Variable:	`[STX]sWN DCUPCEANAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCUPCEANAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.94. Variable: C93Active

The following section contains a detailed description of the variable C93Active.

Variable Overview

Variable Name	Description
C93Active	Activates Code 93 Decoder

Communication Name	DCC93Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	209
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC93Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC93Act	String	8	Activates Code 93 Decoder

Read Variable Response:

```
sRA DCC93Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC93Act	String	8	Activates Code 93 Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCC93Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC93Act	String	8	Activates Code 93 Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCC93Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC93Act	String	8	Activates Code 93 Decoder

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCC93Act[ETX]`
Read Variable Response:	`[STX]sRA DCC93Act 0[ETX]`
Write Variable:	`[STX]sWN DCC93Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCC93Act[ETX]`

2.12.2.95. Variable: UPCEActive

The following section contains a detailed description of the variable UPCEActive.

Variable Overview

Variable Name	Description
UPCEActive	Activates UPC-E

Communication Name	DCUPCEAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	181
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCUPCEAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCUPCEAct	String	9	Activates UPC-E

Read Variable Response:

```
sRA DCUPCEAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCUPCEAct	String	9	Activates UPC-E
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCUPCEAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCUPCEAct	String	9	Activates UPC-E
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCUPCEAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCUPCEAct	String	9	Activates UPC-E

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCUPCEAct[ETX]
Read Variable Response:	[STX]sRA DCUPCEAct 0[ETX]
Write Variable:	[STX]sWN DCUPCEAct 0[ETX]
Write Variable Response:	[STX]sWA DCUPCEAct[ETX]

2.12.2.96. Variable: CBARActive

The following section contains a detailed description of the variable CBARActive.

Variable Overview

Variable Name	Description
CBARActive	Activates Codabar Decoder

Communication Name	DCCBARAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	155
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCCBARAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCCBARAct	String	9	Activates Codabar Decoder

Read Variable Response:				
`sRA DCCBARAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCCBARAct	String	9	Activates Codabar Decoder
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCCBARAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCCBARAct	String	9	Activates Codabar Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCCBARAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCCBARAct	String	9	Activates Codabar Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCCBARAct[ETX]`
Read Variable Response:	`[STX]sRA DCCBARAct 0[ETX]`
Write Variable:	`[STX]sWN DCCBARAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCCBARAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.2.97. Variable: EAN13Active

The following section contains a detailed description of the variable EAN13Active.

Variable Overview

Variable Name	Description
EAN13Active	Activates EAN13

Communication Name	DCEAN13Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	186
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCEAN13Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEAN13Act	String	10	Activates EAN13

Read Variable Response:

```
sRA DCEAN13Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEAN13Act	String	10	Activates EAN13
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCEAN13Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEAN13Act	String	10	Activates EAN13
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCEAN13Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEAN13Act	String	10	Activates EAN13

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCEAN13Act[ETX]`
Read Variable Response:	`[STX]sRA DCEAN13Act 0[ETX]`
Write Variable:	`[STX]sWN DCEAN13Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCEAN13Act[ETX]`

2.12.2.98. Variable: C128Active

The following section contains a detailed description of the variable C128Active.

Variable Overview

Variable Name	Description
C128Active	Activates Code 128 Decoder

Communication Name	DCC128Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	216
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCC128Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCC128Act	String	9	Activates Code 128 Decoder

Read Variable Response:

```
sRA DCC128Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCC128Act	String	9	Activates Code 128 Decoder
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCC128Act <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCC128Act	String	9	Activates Code 128 Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCC128Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCC128Act	String	9	Activates Code 128 Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCC128Act[ETX]
Read Variable Response:	[STX]sRA DCC128Act 0[ETX]
Write Variable:	[STX]sWN DCC128Act 0[ETX]
Write Variable Response:	[STX]sWA DCC128Act[ETX]

2.12.2.99. Variable: C128FamiliyActive

The following section contains a detailed description of the variable C128FamiliyActive.

Variable Overview

Variable Name	Description
C128FamiliyActive	Activates Family Code 128 Decoder

Communication Name	DCFam128Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	215
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCFam128Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCFam128Act	String	11	Activates Family Code 128 Decoder

Read Variable Response:				
`sRA DCFam128Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCFam128Act	String	11	Activates Family Code 128 Decoder
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCFam128Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCFam128Act	String	11	Activates Family Code 128 Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCFam128Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCFam128Act	String	11	Activates Family Code 128 Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCFam128Act[ETX]`
Read Variable Response:	`[STX]sRA DCFam128Act 0[ETX]`
Write Variable:	`[STX]sWN DCFam128Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCFam128Act[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3. Group: Decoding1DPostCodes

2.12.3.1. Variable: PostCodeActive

The following section contains a detailed description of the variable PostCodeActive.

Variable Overview

Variable Name	Description
PostCodeActive	Activates Post Code Decoder

Communication Name	DCPCAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	256
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCAct	String	7	Activates Post Code Decoder

Read Variable Response:

```
sRA DCPCAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCAct	String	7	Activates Post Code Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCAct	String	7	Activates Post Code Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCAct	String	7	Activates Post Code Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCAct[ETX]
Read Variable Response:	[STX]sRA DCPCAct 0[ETX]
Write Variable:	[STX]sWN DCPCAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCAct[ETX]

2.12.3.2. Variable: PostCodesDependentSymbology

The following section contains a detailed description of the variable PostCodesDependentSymbology.

Variable Overview

Variable Name	Description
PostCodesDependentSymbology	List of synbologies that can be enabled only exclusive

Communication Name	DCPCDepSym
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	257
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_UNITED_STATES_POSTAL	
	Value	Name	Description
	1	TX_UNITED_STATES_POSTAL	
	2	TX_AUSTRALIA_POST	
	4	TX_ROYAL_MAIL	
	5	TX_KIX	
	6	TX_SWEDEN_POST	
	7	TX_RAW_BAR_OUTPUT	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCDepSym`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCDepSym	String	10	List of synbologies that can be enabled only exclusive

Read Variable Response:				
`sRA DCPCDepSym <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCDepSym	String	10	List of synbologies that can be enabled only exclusive
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCDepSym <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCDepSym	String	10	List of synbologies that can be enabled only exclusive
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPCDepSym`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCDepSym	String	10	List of synbologies that can be enabled only exclusive

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCDepSym[ETX]`
Read Variable Response:	`[STX]sRA DCPCDepSym 1[ETX]`
Write Variable:	`[STX]sWN DCPCDepSym 1[ETX]`
Write Variable Response:	`[STX]sWA DCPCDepSym[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.3. Variable: PostCodeDPI

The following section contains a detailed description of the variable PostCodeDPI.

Variable Overview

Variable Name	Description
PostCodeDPI	Image resolution in dots per inch

Communication Name	DCPCPcDpi
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	258
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..500
Initialisation	250
Physical Unit	DPI
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPcDpi
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPcDpi	String	9	Image resolution in dots per inch

Read Variable Response:

```
sRA DCPCPcDpi <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPcDpi	String	9	Image resolution in dots per inch
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCPCPcDpi <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPcDpi	String	9	Image resolution in dots per inch
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCPCPcDpi
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPcDpi	String	9	Image resolution in dots per inch

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPcDpi[ETX]`
Read Variable Response:	`[STX]sRA DCPCPcDpi FA[ETX]`
Write Variable:	`[STX]sWN DCPCPcDpi FA[ETX]`
Write Variable Response:	`[STX]sWA DCPCPcDpi[ETX]`

2.12.3.4. Variable: PostCodesOrientation

The following section contains a detailed description of the variable PostCodesOrientation.

Variable Overview

Variable Name	Description
PostCodesOrientation	List of orientations

Communication Name	DCPCOrint
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	259
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_OMNIDIRECTIONAL	
	1	TX_HORIZONTAL	
	2	TX_VERTICAL	
	3	TX_HOR_N_VERTICAL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCOrint`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCOrint	String	9	List of orientations

Read Variable Response:				
`sRA DCPCOrint <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCOrint	String	9	List of orientations
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCOrint <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCOrint	String	9	List of orientations
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPCOrint`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCOrint	String	9	List of orientations

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCOrint[ETX]`
Read Variable Response:	`[STX]sRA DCPCOrint 0[ETX]`
Write Variable:	`[STX]sWN DCPCOrint 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCOrint[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.5. Variable: PostCodeKixLengthMode

The following section contains a detailed description of the variable PostCodeKixLengthMode.

Variable Overview

Variable Name	Description
PostCodeKixLengthMode	Codelength mode of Kix code

Communication Name	DCPCPKixLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	260
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPKixLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPKixLenMode	String	15	Codelength mode of Kix code

Read Variable Response:

```
sRA DCPCPKixLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPKixLenMode	String	15	Codelength mode of Kix code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPCPKixLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPKixLenMode	String	15	Codelength mode of Kix code
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCPCPKixLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPKixLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCPKixLenMode	String	15	Codelength mode of Kix code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPKixLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCPKixLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCPKixLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCPKixLenMode[ETX]

2.12.3.6. Variable: PostCodeKixFixLenList

The following section contains a detailed description of the variable PostCodeKixFixLenList.

Variable Overview

Variable Name	Description
PostCodeKixFixLenList	List of fix code lengths

Communication Name	DCPCPKixFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	261
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPKixFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPKixFixLen	String	14	List of fix code lengths

Read Variable Response:				
`sRA DCPCPKixFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPKixFixLen	String	14	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPKixFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPKixFixLen	String	14	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCPKixFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPKixFixLen	String	14	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPKixFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPKixFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPKixFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPKixFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.7. Variable: PostCodeKixIntLenList

The following section contains a detailed description of the variable PostCodeKixIntLenList.

Variable Overview

Variable Name	Description
PostCodeKixIntLenList	List of interval code lengths

Communication Name	DCPCPKixIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	262
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPKixIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPKixIntLen	String	14	List of interval code lengths

Read Variable Response:

```
sRA DCPCPKixIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPKixIntLen	String	14	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCPKixIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPKixIntLen	String	14	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPKixIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPKixIntLen	String	14	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPKixIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCPKixIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCPKixIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPKixIntLen[ETX]

2.12.3.8. Variable: PostCodeRMMailmarkActive

The following section contains a detailed description of the variable PostCodeRMMailmarkActive.

Variable Overview

Variable Name	Description
PostCodeRMMailmarkActive	Activates the Royal Mail Mailmark 4-state code

Communication Name	DCPCPRMMailmarkAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	263
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMMailmarkAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMMailmarkAct	String	18	Activates the Royal Mail Mailmark 4-state code

Read Variable Response:				
`sRA DCPCPRMMailmarkAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMMailmarkAct	String	18	Activates the Royal Mail Mailmark 4-state code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCPRMMailmarkAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMMailmarkAct	String	18	Activates the Royal Mail Mailmark 4-state code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCPRMMailmarkAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMMailmarkAct	String	18	Activates the Royal Mail Mailmark 4-state code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMMailmarkAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMMailmarkAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMMailmarkAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMMailmarkAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.9. Variable: PostCodeRMMailmarkLengthMode

The following section contains a detailed description of the variable PostCodeRMMailmarkLengthMode.

Variable Overview

Variable Name	Description
PostCodeRMMailmarkLengthMode	Codelength mode of Royal Mail Mailmark 4-state code

Communication Name	DCPCPRMMailmarkLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	264
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPRMMailmarkLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMMailmarkLenMode	String	22	Codelength mode of Royal Mail Mailmark 4-state code

Read Variable Response:

```
sRA DCPCPRMMailmarkLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMMailmarkLenMode	String	22	Codelength mode of Royal Mail Mailmark 4-state code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPCPRMMailmarkLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMMailmarkLenMode	String	22	Codelength mode of Royal Mail Mailmark 4-state code
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMMailmarkLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMMailmarkLenMode	String	22	Codelength mode of Royal Mail Mailmark 4-state code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMMailmarkLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCPRMMailmarkLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCPRMMailmarkLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMMailmarkLenMode[ETX]

2.12.3.10. Variable: PostCodeRMMailmarkFixLenList

The following section contains a detailed description of the variable PostCodeRMMailmarkFixLenList.

Variable Overview

Variable Name	Description
PostCodeRMMailmarkFixLenList	List of fix code lengths

Communication Name	DCPCPRMMailmarkFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	265
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMMailmarkFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMMailmarkFixLen	String	21	List of fix code lengths

Read Variable Response:				
`sRA DCPCPRMMailmarkFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMMailmarkFixLen	String	21	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPRMMailmarkFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMMailmarkFixLen	String	21	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCPRMMailmarkFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMMailmarkFixLen	String	21	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMMailmarkFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMMailmarkFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMMailmarkFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMMailmarkFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.11. Variable: PostCodeRMMailmarkIntLenList

The following section contains a detailed description of the variable PostCodeRMMailmarkIntLenList.

Variable Overview

Variable Name	Description
PostCodeRMMailmarkIntLenList	List of interval code lengths

Communication Name	DCPCPRMMailmarkIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	266
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	2
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPRMMailmarkIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMMailmarkIntLen	String	21	List of interval code lengths

Read Variable Response:

```
sRA DCPCPRMMailmarkIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMMailmarkIntLen	String	21	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCPRMMailmarkIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMMailmarkIntLen	String	21	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMMailmarkIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMMailmarkIntLen	String	21	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMMailmarkIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCPRMMailmarkIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCPRMMailmarkIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMMailmarkIntLen[ETX]

2.12.3.12. Variable: PostCodeRMRM4SCCActive

The following section contains a detailed description of the variable PostCodeRMRM4SCCActive.

Variable Overview

Variable Name	Description
PostCodeRMRM4SCCActive	Activates the Royal Mail RM4SCC code

Communication Name	DCPCPRMRM4SCCAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	267
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMRM4SCCAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMRM4SCCAct	String	16	Activates the Royal Mail RM4SCC code

Read Variable Response:				
`sRA DCPCPRMRM4SCCAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMRM4SCCAct	String	16	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCPRMRM4SCCAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMRM4SCCAct	String	16	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCPRMRM4SCCAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMRM4SCCAct	String	16	Activates the Royal Mail RM4SCC code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMRM4SCCAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMRM4SCCAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMRM4SCCAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMRM4SCCAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.13. Variable: PostCodeRMRM4SCCLengthMode

The following section contains a detailed description of the variable PostCodeRMRM4SCCLengthMode.

Variable Overview

Variable Name	Description
PostCodeRMRM4SCCLengthMode	Codelength mode of Royal Mail RM4SCC code

Communication Name	DCPCPRMRM4SCCLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	268
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPRMRM4SCCLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMRM4SCCLenMode	String	20	Codelength mode of Royal Mail RM4SCC code

Read Variable Response:

```
sRA DCPCPRMRM4SCCLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMRM4SCCLenMode	String	20	Codelength mode of Royal Mail RM4SCC code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPCPRMRM4SCCLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMRM4SCCLenMode	String	20	Codelength mode of Royal Mail RM4SCC code
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCPCPRMRM4SCCLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMRM4SCCLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCPRMRM4SCCLenMode	String	20	Codelength mode of Royal Mail RM4SCC code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMRM4SCCLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCPRMRM4SCCLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCPRMRM4SCCLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMRM4SCCLenMode[ETX]

2.12.3.14. Variable: PostCodeRMRM4SCCFixLenList

The following section contains a detailed description of the variable PostCodeRMRM4SCCFixLenList.

Variable Overview

Variable Name	Description
PostCodeRMRM4SCCFixLenList	List of fix code lengths

Communication Name	DCPCPRMRM4SCCFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	269
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMRM4SCCFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMRM4SCCFixLen	String	19	List of fix code lengths

Read Variable Response:				
`sRA DCPCPRMRM4SCCFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMRM4SCCFixLen	String	19	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPRMRM4SCCFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMRM4SCCFixLen	String	19	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCPRMRM4SCCFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMRM4SCCFixLen	String	19	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMRM4SCCFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMRM4SCCFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMRM4SCCFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMRM4SCCFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.15. Variable: PostCodeRMRM4SCCIntLenList

The following section contains a detailed description of the variable PostCodeRMRM4SCCIntLenList.

Variable Overview

Variable Name	Description
PostCodeRMRM4SCCIntLenList	List of interval code lengths

Communication Name	DCPCPRMRM4SCCIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	270
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	2
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPRMRM4SCCIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMRM4SCCIntLen	String	19	List of interval code lengths

Read Variable Response:

```
sRA DCPCPRMRM4SCCIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMRM4SCCIntLen	String	19	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCPRMRM4SCCIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMRM4SCCIntLen	String	19	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMRM4SCCIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMRM4SCCIntLen	String	19	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMRM4SCCIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCPRMRM4SCCIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCPRMRM4SCCIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMRM4SCCIntLen[ETX]

2.12.3.16. Variable: PostCodeRMInfomailActive

The following section contains a detailed description of the variable PostCodeRMInfomailActive.

Variable Overview

Variable Name	Description
PostCodeRMInfomailActive	Activates the Royal Mail RM4SCC code

Communication Name	DCPCPRMInfmlAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	271
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMInfmlAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMInfmlAct	String	15	Activates the Royal Mail RM4SCC code

Read Variable Response:				
`sRA DCPCPRMInfmlAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMInfmlAct	String	15	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCPRMInfmlAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMInfmlAct	String	15	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCPRMInfmlAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMInfmlAct	String	15	Activates the Royal Mail RM4SCC code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMInfmlAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMInfmlAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMInfmlAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMInfmlAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.17. Variable: PostCodeRMInfomailLengthMode

The following section contains a detailed description of the variable PostCodeRMInfomailLengthMode.

Variable Overview

Variable Name	Description
PostCodeRMInfomailLengthMode	Codelength mode of Royal Mail Infomail code

Communication Name	DCPCPRMInfmlLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	272
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPRMInfmlLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMInfmlLenMode	String	19	Codelength mode of Royal Mail Infomail code

Read Variable Response:

```
sRA DCPCPRMInfmlLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMInfmlLenMode	String	19	Codelength mode of Royal Mail Infomail code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPCPRMInfmlLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMInfmlLenMode	String	19	Codelength mode of Royal Mail Infomail code
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCPCPRMInfmlLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMInfmlLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCPRMInfmlLenMode	String	19	Codelength mode of Royal Mail Infomail code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMInfmlLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCPRMInfmlLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCPRMInfmlLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMInfmlLenMode[ETX]

2.12.3.18. Variable: PostCodeRMInfomailFixLenList

The following section contains a detailed description of the variable PostCodeRMInfomailFixLenList.

Variable Overview

Variable Name	Description
PostCodeRMInfomailFixLenList	List of fix code lengths

Communication Name	DCPCPRMInfmlFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	273
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMInfmlFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMInfmlFixLen	String	18	List of fix code lengths

Read Variable Response:				
`sRA DCPCPRMInfmlFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMInfmlFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPRMInfmlFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMInfmlFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCPRMInfmlFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMInfmlFixLen	String	18	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMInfmlFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMInfmlFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMInfmlFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMInfmlFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.19. Variable: PostCodeRMInfomailIntLenList

The following section contains a detailed description of the variable PostCodeRMInfomailIntLenList.

Variable Overview

Variable Name	Description
PostCodeRMInfomailIntLenList	List of interval code lengths

Communication Name	DCPCPRMInfmlIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	274
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	2
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPRMInfmlIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMInfmlIntLen	String	18	List of interval code lengths

Read Variable Response:

```
sRA DCPCPRMInfmlIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMInfmlIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCPRMInfmlIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMInfmlIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMInfmlIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMInfmlIntLen	String	18	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMInfmlIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCPRMInfmlIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCPRMInfmlIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMInfmlIntLen[ETX]

2.12.3.20. Variable: PostCodeRMPostSingaporeActive

The following section contains a detailed description of the variable PostCodeRMPostSingaporeActive.

Variable Overview

Variable Name	Description
PostCodeRMPostSingaporeActive	Activates the Royal Mail Post Singapore code

Communication Name	DCPCPRMPSAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	275
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMPSAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMPSAct	String	12	Activates the Royal Mail Post Singapore code

Read Variable Response:				
`sRA DCPCPRMPSAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMPSAct	String	12	Activates the Royal Mail Post Singapore code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCPRMPSAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMPSAct	String	12	Activates the Royal Mail Post Singapore code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCPRMPSAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMPSAct	String	12	Activates the Royal Mail Post Singapore code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMPSAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMPSAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMPSAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMPSAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.21. Variable: PostCodeRMPostSingaporeLengthMode

The following section contains a detailed description of the variable PostCodeRMPostSingaporeLengthMode.

Variable Overview

Variable Name	Description
PostCodeRMPostSingaporeLengthMode	Codelength mode of Royal Mail Post Singapore code

Communication Name	DCPCPRMPSLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	276
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMPSLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMPSLenMode	String	16	Codelength mode of Royal Mail Post Singapore code

Read Variable Response:				
`sRA DCPCPRMPSLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMPSLenMode	String	16	Codelength mode of Royal Mail Post Singapore code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCPRMPSLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMPSLenMode	String	16	Codelength mode of Royal Mail Post Singapore code
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMPSLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMPSLenMode	String	16	Codelength mode of Royal Mail Post Singapore code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMPSLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCPRMPSLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCPRMPSLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMPSLenMode[ETX]

2.12.3.22. Variable: PostCodeRMPostSingaporeFixLenList

The following section contains a detailed description of the variable PostCodeRMPostSingaporeFixLenList.

Variable Overview

Variable Name	Description
PostCodeRMPostSingaporeFixLenList	List of fix code lengths

Communication Name	DCPCPRMPSFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	277
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMPSFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMPSFixLen	String	15	List of fix code lengths

Read Variable Response:				
`sRA DCPCPRMPSFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMPSFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPRMPSFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMPSFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCPRMPSFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMPSFixLen	String	15	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPRMPSFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPRMPSFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPRMPSFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPRMPSFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.23. Variable: PostCodeRMPostSingaporeIntLenList

The following section contains a detailed description of the variable PostCodeRMPostSingaporeIntLenList.

Variable Overview

Variable Name	Description
PostCodeRMPostSingaporeIntLenList	List of interval code lengths

Communication Name	DCPCPRMPSIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	278
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	2
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPRMPSIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPRMPSIntLen	String	15	List of interval code lengths

Read Variable Response:				
`sRA DCPCPRMPSIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPRMPSIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCPCPRMPSIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPRMPSIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPRMPSIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPRMPSIntLen	String	15	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPRMPSIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCPRMPSIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCPRMPSIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPRMPSIntLen[ETX]

2.12.3.24. Variable: PostCodePostJapanLengthMode

The following section contains a detailed description of the variable PostCodePostJapanLengthMode.

Variable Overview

Variable Name	Description
PostCodePostJapanLengthMode	Codelength mode of Post Japan code

Communication Name	DCPCPJpnLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	279
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPJpnLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPJpnLenMode	String	15	Codelength mode of Post Japan code

Read Variable Response:				
`sRA DCPCPJpnLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPJpnLenMode	String	15	Codelength mode of Post Japan code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCPJpnLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPJpnLenMode	String	15	Codelength mode of Post Japan code
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPCPJpnLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPJpnLenMode	String	15	Codelength mode of Post Japan code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPJpnLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCPCPJpnLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCPCPJpnLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPJpnLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.25. Variable: PostCodePostJapanFixLenList

The following section contains a detailed description of the variable PostCodePostJapanFixLenList.

Variable Overview

Variable Name	Description
PostCodePostJapanFixLenList	List of fix code lengths

Communication Name	DCPCPJpnFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	280
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	5
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPJpnFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPJpnFixLen	String	14	List of fix code lengths

Read Variable Response:				
`sRA DCPCPJpnFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPJpnFixLen	String	14	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPJpnFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPJpnFixLen	String	14	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPJpnFixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPJpnFixLen	String	14	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPJpnFixLen[ETX]
Read Variable Response:	[STX]sRA DCPCPJpnFixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCPCPJpnFixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPJpnFixLen[ETX]

2.12.3.26. Variable: PostCodePostJapanIntLenList

The following section contains a detailed description of the variable PostCodePostJapanIntLenList.

Variable Overview

Variable Name	Description
PostCodePostJapanIntLenList	List of interval code lengths

Communication Name	DCPCPJpnIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	281
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPJpnIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPJpnIntLen	String	14	List of interval code lengths

Read Variable Response:				
`sRA DCPCPJpnIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPJpnIntLen	String	14	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCPCPJpnIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPJpnIntLen	String	14	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DCPCPJpnIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPJpnIntLen	String	14	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPJpnIntLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPJpnIntLen 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPJpnIntLen 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPJpnIntLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.27. Variable: PostCodePostAustraliaLengthMode

The following section contains a detailed description of the variable PostCodePostAustraliaLengthMode.

Variable Overview

Variable Name	Description
PostCodePostAustraliaLengthMode	Codelength mode of Post Australia code

Communication Name	DCPCPAstrlLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	282
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPAstrlLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPAstrlLenMode	String	17	Codelength mode of Post Australia code

Read Variable Response:

```
sRA DCPCPAstrlLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPAstrlLenMode	String	17	Codelength mode of Post Australia code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPCPAstrlLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPAstrlLenMode	String	17	Codelength mode of Post Australia code
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCPCPAstrlLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPAstrlLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCPAstrlLenMode	String	17	Codelength mode of Post Australia code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPAstrlLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCPAstrlLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCPAstrlLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCPAstrlLenMode[ETX]

2.12.3.28. Variable: PostCodePostAustraliaFixLenList

The following section contains a detailed description of the variable PostCodePostAustraliaFixLenList.

Variable Overview

Variable Name	Description
PostCodePostAustraliaFixLenList	List of fix code lengths

Communication Name	DCPCPAstrlFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	283
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPAstrlFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPAstrlFixLen	String	16	List of fix code lengths

Read Variable Response:				
`sRA DCPCPAstrlFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPAstrlFixLen	String	16	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCPAstrlFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPAstrlFixLen	String	16	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCPAstrlFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPAstrlFixLen	String	16	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPAstrlFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPAstrlFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPAstrlFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPAstrlFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.29. Variable: PostCodePostAustraliaIntLenList

The following section contains a detailed description of the variable PostCodePostAustraliaIntLenList.

Variable Overview

Variable Name	Description
PostCodePostAustraliaIntLenList	List of interval code lengths

Communication Name	DCPCPAstrlIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	284
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPAstrlIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPAstrlIntLen	String	16	List of interval code lengths

Read Variable Response:

```
sRA DCPCPAstrlIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPAstrlIntLen	String	16	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCPAstrlIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPAstrlIntLen	String	16	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPAstrlIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPAstrlIntLen	String	16	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPAstrlIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCPAstrlIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCPAstrlIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPAstrlIntLen[ETX]

2.12.3.30. Variable: PostCodePostAustraliaAllowZeroFCC

The following section contains a detailed description of the variable PostCodePostAustraliaAllowZeroFCC.

Variable Overview

Variable Name	Description
PostCodePostAustraliaAllowZeroFCC	Activates the Post Australia Zero FCC option

Communication Name	DCPCPAstrlZrFCC
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	285
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPAstrlZrFCC`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPAstrlZrFCC	String	15	Activates the Post Australia Zero FCC option

Read Variable Response:				
`sRA DCPCPAstrlZrFCC <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPAstrlZrFCC	String	15	Activates the Post Australia Zero FCC option
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCPAstrlZrFCC <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPAstrlZrFCC	String	15	Activates the Post Australia Zero FCC option
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCPAstrlZrFCC`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPAstrlZrFCC	String	15	Activates the Post Australia Zero FCC option

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPAstrlZrFCC[ETX]`
Read Variable Response:	`[STX]sRA DCPCPAstrlZrFCC 0[ETX]`
Write Variable:	`[STX]sWN DCPCPAstrlZrFCC 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPAstrlZrFCC[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.31. Variable: PostCodeUSPPostNetActive

The following section contains a detailed description of the variable PostCodeUSPPostNetActive.

Variable Overview

Variable Name	Description
PostCodeUSPPostNetActive	Activates the United States Postal Postnet code

Communication Name	DCPCUSPPNAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	286
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCUSPPNAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPPNAct	String	12	Activates the United States Postal Postnet code

Read Variable Response:

```
sRA DCPCUSPPNAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPPNAct	String	12	Activates the United States Postal Postnet code
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCUSPPNAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPPNAct	String	12	Activates the United States Postal Postnet code
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCUSPPNAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPPNAct	String	12	Activates the United States Postal Postnet code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPPNAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPPNAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPPNAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPPNAct[ETX]`

2.12.3.32. Variable: PostCodeUSPPostNetAllowBnBFields

The following section contains a detailed description of the variable PostCodeUSPPostNetAllowBnBFields.

Variable Overview

Variable Name	Description
PostCodeUSPPostNetAllowBnBFields	Activates the United States Postal Postnet B and B-Fields option

Communication Name	DCPCUSPPNBnBFld
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	287
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

`sRN DCPCUSPPNBnBFld`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPPNBnBFld	String	15	Activates the United States Postal Postnet B and B-Fields option

Read Variable Response:

`sRA DCPCUSPPNBnBFld <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPPNBnBFld	String	15	Activates the United States Postal Postnet B and B-Fields option
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPCUSPPNBnBFld <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPPNBnBFld	String	15	Activates the United States Postal Postnet B and B-Fields option
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCPCUSPPNBnBFld				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPPNBnBFld	String	15	Activates the United States Postal Postnet B and B-Fields option

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCUSPPNBnBFld[ETX]
Read Variable Response:	[STX]sRA DCPCUSPPNBnBFld 0[ETX]
Write Variable:	[STX]sWN DCPCUSPPNBnBFld 0[ETX]
Write Variable Response:	[STX]sWA DCPCUSPPNBnBFld[ETX]

2.12.3.33. Variable: PostCodeUSPPlanetActive

The following section contains a detailed description of the variable PostCodeUSPPlanetActive.

Variable Overview

Variable Name	Description
PostCodeUSPPlanetActive	Activates the United States Postal Planet code

Communication Name	DCPCUSPPLAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	288
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPPLAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPPLAct	String	12	Activates the United States Postal Planet code

Read Variable Response:				
`sRA DCPCUSPPLAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPPLAct	String	12	Activates the United States Postal Planet code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCUSPPLAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPPLAct	String	12	Activates the United States Postal Planet code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCUSPPLAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPPLAct	String	12	Activates the United States Postal Planet code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPPLAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPPLAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPPLAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPPLAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.34. Variable: PostCodeUSPLengthMode

The following section contains a detailed description of the variable PostCodeUSPLengthMode.

Variable Overview

Variable Name	Description
PostCodeUSPLengthMode	Codelength mode of United States Postal Planet and PostNet codes

Communication Name	DCPCUSPLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	289
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_Free	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPLenMode	String	14	Codelength mode of United States Postal Planet and PostNet codes

Read Variable Response:				
`sRA DCPCUSPLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPLenMode	String	14	Codelength mode of United States Postal Planet and PostNet codes
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCUSPLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPLenMode	String	14	Codelength mode of United States Postal Planet and PostNet codes
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCUSPLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPLenMode	String	14	Codelength mode of United States Postal Planet and PostNet codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCUSPLenMode[ETX]
Read Variable Response:	[STX]sRA DCPCUSPLenMode 0[ETX]
Write Variable:	[STX]sWN DCPCUSPLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCUSPLenMode[ETX]

2.12.3.35. Variable: PostCodeUSPFixLenList

The following section contains a detailed description of the variable PostCodeUSPFixLenList.

Variable Overview

Variable Name	Description
PostCodeUSPFixLenList	List of fix code lengths for US Postal Planet and PostNet codes

Communication Name	DCPCUSPFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	290
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPFixLen	String	13	List of fix code lengths for US Postal Planet and PostNet codes

Read Variable Response:				
`sRA DCPCUSPFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPFixLen	String	13	List of fix code lengths for US Postal Planet and PostNet codes
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCUSPFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPFixLen	String	13	List of fix code lengths for US Postal Planet and PostNet codes
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCUSPFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPFixLen	String	13	List of fix code lengths for US Postal Planet and PostNet codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.36. Variable: PostCodeUSPIntLenList

The following section contains a detailed description of the variable PostCodeUSPIntLenList.

Variable Overview

Variable Name	Description
PostCodeUSPIntLenList	List of interval code lengths for US Postal Planet and PostNet codes

Communication Name	DCPCUSPIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	291
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	2
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCUSPIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPIntLen	String	13	List of interval code lengths for US Postal Planet and PostNet codes

Read Variable Response:

```
sRA DCPCUSPIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPIntLen	String	13	List of interval code lengths for US Postal Planet and PostNet codes
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCUSPIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPIntLen	String	13	List of interval code lengths for US Postal Planet and PostNet codes
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCUSPIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPIntLen	String	13	List of interval code lengths for US Postal Planet and PostNet codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCUSPIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCUSPIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCUSPIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCUSPIntLen[ETX]

2.12.3.37. Variable: PostCodeUSPUPUActive

The following section contains a detailed description of the variable PostCodeUSPUPUActive.

Variable Overview

Variable Name	Description
PostCodeUSPUPUActive	Activates the United States Postal UPU code

Communication Name	DCPCUSPUPUAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	292
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPUPUAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUPUAct	String	13	Activates the United States Postal UPU code

Read Variable Response:				
`sRA DCPCUSPUPUAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUPUAct	String	13	Activates the United States Postal UPU code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCUSPUPUAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUPUAct	String	13	Activates the United States Postal UPU code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCUSPUPUAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUPUAct	String	13	Activates the United States Postal UPU code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPUPUAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPUPUAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPUPUAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPUPUAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.38. Variable: PostCodeUSPUPULengthMode

The following section contains a detailed description of the variable PostCodeUSPUPULengthMode.

Variable Overview

Variable Name	Description
PostCodeUSPUPULengthMode	Codelength mode of United States Postal UPU code

Communication Name	DCPCUSPUPULenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	293
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPUPULenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUPULenMode	String	17	Codelength mode of United States Postal UPU code

Read Variable Response:				
`sRA DCPCUSPUPULenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUPULenMode	String	17	Codelength mode of United States Postal UPU code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCUSPUPULenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUPULenMode	String	17	Codelength mode of United States Postal UPU code
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCUSPUPULenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUPULenMode	String	17	Codelength mode of United States Postal UPU code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCUSPUPULenMode[ETX]
Read Variable Response:	[STX]sRA DCPCUSPUPULenMode 0[ETX]
Write Variable:	[STX]sWN DCPCUSPUPULenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPCUSPUPULenMode[ETX]

2.12.3.39. Variable: PostCodeUSPUPUFixLenList

The following section contains a detailed description of the variable PostCodeUSPUPUFixLenList.

Variable Overview

Variable Name	Description
PostCodeUSPUPUFixLenList	List of fix code lengths

Communication Name	DCPCUSPUPUFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	294
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPUPUFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUPUFixLen	String	16	List of fix code lengths

Read Variable Response:				
`sRA DCPCUSPUPUFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUPUFixLen	String	16	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCUSPUPUFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUPUFixLen	String	16	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCUSPUPUFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUPUFixLen	String	16	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPUPUFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPUPUFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPUPUFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPUPUFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.40. Variable: PostCodeUSPUPUIntLenList

The following section contains a detailed description of the variable PostCodeUSPUPUIntLenList.

Variable Overview

Variable Name	Description
PostCodeUSPUPUIntLenList	List of interval code lengths

Communication Name	DCPCUSPUPUIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	295
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	2
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPUPUIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUPUIntLen	String	16	List of interval code lengths

Read Variable Response:				
`sRA DCPCUSPUPUIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUPUIntLen	String	16	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCPCUSPUPUIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUPUIntLen	String	16	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCUSPUPUIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUPUIntLen	String	16	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCUSPUPUIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCUSPUPUIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCUSPUPUIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCUSPUPUIntLen[ETX]

2.12.3.41. Variable: PostCodeUSPUsps4StateActive

The following section contains a detailed description of the variable PostCodeUSPUsps4StateActive.

Variable Overview

Variable Name	Description
PostCodeUSPUsps4StateActive	Activates the United States Postal USPS 4-State code

Communication Name	DCPCUSPUsps4SAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	296
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPUsps4SAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUsps4SAct	String	16	Activates the United States Postal USPS 4-State code

Read Variable Response:				
`sRA DCPCUSPUsps4SAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUsps4SAct	String	16	Activates the United States Postal USPS 4-State code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCUSPUsps4SAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUsps4SAct	String	16	Activates the United States Postal USPS 4-State code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCUSPUsps4SAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUsps4SAct	String	16	Activates the United States Postal USPS 4-State code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPUsps4SAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPUsps4SAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPUsps4SAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPUsps4SAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.42. Variable: PostCodeUSPUsps4StateLengthMode

The following section contains a detailed description of the variable PostCodeUSPUsps4StateLengthMode.

Variable Overview

Variable Name	Description
PostCodeUSPUsps4StateLengthMode	Codelength mode of United States Postal USPS 4-State code

Communication Name	DCPCUSPUsps4SLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	297
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCPCUSPUsps4SLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUsps4SLenMode	String	20	Codelength mode of United States Postal USPS 4-State code

Read Variable Response:

```
sRA DCPCUSPUsps4SLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUsps4SLenMode	String	20	Codelength mode of United States Postal USPS 4-State code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPCUSPUsps4SLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUsps4SLenMode	String	20	Codelength mode of United States Postal USPS 4-State code
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCUSPUsps4SLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUsps4SLenMode	String	20	Codelength mode of United States Postal USPS 4-State code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPUsps4SLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPUsps4SLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPUsps4SLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPUsps4SLenMode[ETX]`

2.12.3.43. Variable: PostCodeUSPUsps4StateFixLenList

The following section contains a detailed description of the variable PostCodeUSPUsps4StateFixLenList.

Variable Overview

Variable Name	Description
PostCodeUSPUsps4StateFixLenList	List of fix code lengths

Communication Name	DCPCUSPUsps4SFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	298
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCUSPUsps4SFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUsps4SFixLen	String	19	List of fix code lengths

Read Variable Response:				
`sRA DCPCUSPUsps4SFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUsps4SFixLen	String	19	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPCUSPUsps4SFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUsps4SFixLen	String	19	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPCUSPUsps4SFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUsps4SFixLen	String	19	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCUSPUsps4SFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCUSPUsps4SFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCUSPUsps4SFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCUSPUsps4SFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.44. Variable: PostCodeUSPUsps4StateIntLenList

The following section contains a detailed description of the variable PostCodeUSPUsps4StateIntLenList.

Variable Overview

Variable Name	Description
PostCodeUSPUsps4StateIntLenList	List of interval code lengths

Communication Name	DCPCUSPUsps4SIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	299
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCUSPUsps4SIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCUSPUsps4SIntLen	String	19	List of interval code lengths

Read Variable Response:

```
sRA DCPCUSPUsps4SIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCUSPUsps4SIntLen	String	19	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPCUSPUsps4SIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCUSPUsps4SIntLen	String	19	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCUSPUsps4SIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCUSPUsps4SIntLen	String	19	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCUSPUsps4SIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCUSPUsps4SIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCUSPUsps4SIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCUSPUsps4SIntLen[ETX]

2.12.3.45. Variable: PostCodePostSwedenLengthMode

The following section contains a detailed description of the variable PostCodePostSwedenLengthMode.

Variable Overview

Variable Name	Description
PostCodePostSwedenLengthMode	Codelength mode of Post Sweden code

Communication Name	DCPCPSwdnLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	300
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPSwdnLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPSwdnLenMode	String	16	Codelength mode of Post Sweden code

Read Variable Response:				
`sRA DCPCPSwdnLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPSwdnLenMode	String	16	Codelength mode of Post Sweden code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCPSwdnLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPSwdnLenMode	String	16	Codelength mode of Post Sweden code
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPCPSwdnLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPSwdnLenMode	String	16	Codelength mode of Post Sweden code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPSwdnLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCPCPSwdnLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCPCPSwdnLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPSwdnLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.46. Variable: PostCodePostSwedenFixLenList

The following section contains a detailed description of the variable PostCodePostSwedenFixLenList.

Variable Overview

Variable Name	Description
PostCodePostSwedenFixLenList	List of fix code lengths

Communication Name	DCPCPSwdnFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	301
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	5
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCPSwdnFixLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPSwdnFixLen	String	15	List of fix code lengths

Read Variable Response:

```
sRA DCPCPSwdnFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPSwdnFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:

```
sWN DCPCPSwdnFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPSwdnFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCPSwdnFixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPSwdnFixLen	String	15	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCPSwdnFixLen[ETX]
Read Variable Response:	[STX]sRA DCPCPSwdnFixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCPCPSwdnFixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCPSwdnFixLen[ETX]

2.12.3.47. Variable: PostCodePostSwedenIntLenList

The following section contains a detailed description of the variable PostCodePostSwedenIntLenList.

Variable Overview

Variable Name	Description
PostCodePostSwedenIntLenList	List of interval code lengths

Communication Name	DCPCPSwdnIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	302
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCPSwdnIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCPSwdnIntLen	String	15	List of interval code lengths

Read Variable Response:				
`sRA DCPCPSwdnIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCPSwdnIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCPCPSwdnIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCPSwdnIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DCPCPSwdnIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCPSwdnIntLen	String	15	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCPSwdnIntLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCPSwdnIntLen 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCPSwdnIntLen 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCPSwdnIntLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.48. Variable: PostCodeRawBarOutput2StateActive

The following section contains a detailed description of the variable PostCodeRawBarOutput2StateActive.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput2StateActive	Activates output of 2 state codes, if raw bar mode is enabled

Communication Name	DCPCRaw2StatAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	303
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCRaw2StatAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw2StatAct	String	15	Activates output of 2 state codes, if raw bar mode is enabled

Read Variable Response:

```
sRA DCPCRaw2StatAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw2StatAct	String	15	Activates output of 2 state codes, if raw bar mode is enabled
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCRaw2StatAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw2StatAct	String	15	Activates output of 2 state codes, if raw bar mode is enabled
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCRaw2StatAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCRaw2StatAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCRaw2StatAct	String	15	Activates output of 2 state codes, if raw bar mode is enabled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCRaw2StatAct[ETX]
Read Variable Response:	[STX]sRA DCPCRaw2StatAct 0[ETX]
Write Variable:	[STX]sWN DCPCRaw2StatAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCRaw2StatAct[ETX]

2.12.3.49. Variable: PostCodeRawBarOutput2StateLengthMode

The following section contains a detailed description of the variable PostCodeRawBarOutput2StateLengthMode.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput2StateLengthMode	Codelength mode of 2 state raw bar output

Communication Name	DCPCRaw2StatLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	304
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCRaw2StatLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw2StatLenMode	String	19	Codelength mode of 2 state raw bar output

Read Variable Response:				
`sRA DCPCRaw2StatLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw2StatLenMode	String	19	Codelength mode of 2 state raw bar output
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCRaw2StatLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw2StatLenMode	String	19	Codelength mode of 2 state raw bar output
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPCRaw2StatLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCRaw2StatLenMode	String	19	Codelength mode of 2 state raw bar output

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCRaw2StatLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCPCRaw2StatLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCPCRaw2StatLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCRaw2StatLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.50. Variable: PostCodeRawBarOutput2StateFixLenList

The following section contains a detailed description of the variable PostCodeRawBarOutput2StateFixLenList.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput2StateFixLenList	List of fix code lengths

Communication Name	DCPCRaw2StatFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	305
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	5
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCRaw2StatFixLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw2StatFixLen	String	18	List of fix code lengths

Read Variable Response:

```
sRA DCPCRaw2StatFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw2StatFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:

```
sWN DCPCRaw2StatFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw2StatFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCRaw2StatFixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCRaw2StatFixLen	String	18	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCRaw2StatFixLen[ETX]
Read Variable Response:	[STX]sRA DCPCRaw2StatFixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCPCRaw2StatFixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCRaw2StatFixLen[ETX]

2.12.3.51. Variable: PostCodeRawBarOutput2StateIntLenList

The following section contains a detailed description of the variable PostCodeRawBarOutput2StateIntLenList.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput2StateIntLenList	List of interval code lengths

Communication Name	DCPCRaw2StatIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	306
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN DCPCRaw2StatIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw2StatIntLen	String	18	List of interval code lengths

Read Variable Response:				
sRA DCPCRaw2StatIntLen <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw2StatIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
sWN DCPCRaw2StatIntLen <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw2StatIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
sWA DCPCRaw2StatIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCRaw2StatIntLen	String	18	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCRaw2StatIntLen[ETX]
Read Variable Response:	[STX]sRA DCPCRaw2StatIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPCRaw2StatIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCRaw2StatIntLen[ETX]

© SICK AG - Germany - All rights reserved

2.12.3.52. Variable: PostCodeRawBarOutput4StateActive

The following section contains a detailed description of the variable PostCodeRawBarOutput4StateActive.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput4StateActive	Activates output of 4 state codes, if raw bar mode is enabled

Communication Name	DCPCRaw4StatAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	307
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCRaw4StatAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw4StatAct	String	15	Activates output of 4 state codes, if raw bar mode is enabled

Read Variable Response:

```
sRA DCPCRaw4StatAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw4StatAct	String	15	Activates output of 4 state codes, if raw bar mode is enabled
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCRaw4StatAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw4StatAct	String	15	Activates output of 4 state codes, if raw bar mode is enabled
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCRaw4StatAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCRaw4StatAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCRaw4StatAct	String	15	Activates output of 4 state codes, if raw bar mode is enabled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCRaw4StatAct[ETX]
Read Variable Response:	[STX]sRA DCPCRaw4StatAct 0[ETX]
Write Variable:	[STX]sWN DCPCRaw4StatAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCRaw4StatAct[ETX]

2.12.3.53. Variable: PostCodeRawBarOutput4StateLengthMode

The following section contains a detailed description of the variable PostCodeRawBarOutput4StateLengthMode.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput4StateLengthMode	Codelength mode of 4 state raw bar output

Communication Name	DCPCRaw4StatLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	308
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCRaw4StatLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw4StatLenMode	String	19	Codelength mode of 4 state raw bar output

Read Variable Response:				
`sRA DCPCRaw4StatLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw4StatLenMode	String	19	Codelength mode of 4 state raw bar output
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCPCRaw4StatLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw4StatLenMode	String	19	Codelength mode of 4 state raw bar output
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCPCRaw4StatLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCRaw4StatLenMode	String	19	Codelength mode of 4 state raw bar output

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCRaw4StatLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCPCRaw4StatLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCPCRaw4StatLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCRaw4StatLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.3.54. Variable: PostCodeRawBarOutput4StateFixLenList

The following section contains a detailed description of the variable PostCodeRawBarOutput4StateFixLenList.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput4StateFixLenList	List of fix code lengths

Communication Name	DCPCRaw4StatFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	309
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	5
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPCRaw4StatFixLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw4StatFixLen	String	18	List of fix code lengths

Read Variable Response:

```
sRA DCPCRaw4StatFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw4StatFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:

```
sWN DCPCRaw4StatFixLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw4StatFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCRaw4StatFixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCRaw4StatFixLen	String	18	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCRaw4StatFixLen[ETX]
Read Variable Response:	[STX]sRA DCPCRaw4StatFixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCPCRaw4StatFixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCPCRaw4StatFixLen[ETX]

2.12.3.55. Variable: PostCodeRawBarOutput4StateIntLenList

The following section contains a detailed description of the variable PostCodeRawBarOutput4StateIntLenList.

Variable Overview

Variable Name	Description
PostCodeRawBarOutput4StateIntLenList	List of interval code lengths

Communication Name	DCPCRaw4StatIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	310
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCRaw4StatIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCRaw4StatIntLen	String	18	List of interval code lengths

Read Variable Response:				
`sRA DCPCRaw4StatIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCRaw4StatIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCPCRaw4StatIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCRaw4StatIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DCPCRaw4StatIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCRaw4StatIntLen	String	18	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCRaw4StatIntLen[ETX]`
Read Variable Response:	`[STX]sRA DCPCRaw4StatIntLen 0 0[ETX]`
Write Variable:	`[STX]sWN DCPCRaw4StatIntLen 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCRaw4StatIntLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.4. Group: DecodingPostCodes

2.12.4.1. Variable: SwiftPostCodeRMMailmarkActive

The following section contains a detailed description of the variable SwiftPostCodeRMMailmarkActive.

Variable Overview

Variable Name	Description
SwiftPostCodeRMMailmarkActive	Activates the Royal Mail Mailmark code

Communication Name	DCPCSwftPRMMailmarkAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	311
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCSwftPRMMailmarkAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftPRMMailmarkAct	String	22	Activates the Royal Mail Mailmark code

Read Variable Response:

```
sRA DCPCSwftPRMMailmarkAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftPRMMailmarkAct	String	22	Activates the Royal Mail Mailmark code
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCSwftPRMMailmarkAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftPRMMailmarkAct	String	22	Activates the Royal Mail Mailmark code
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCSwftPRMMailmarkAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPCSwftPRMMailmarkAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPCSwftPRMMailmarkAct	String	22	Activates the Royal Mail Mailmark code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCSwftPRMMailmarkAct[ETX]
Read Variable Response:	[STX]sRA DCPCSwftPRMMailmarkAct 0[ETX]
Write Variable:	[STX]sWN DCPCSwftPRMMailmarkAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCSwftPRMMailmarkAct[ETX]

2.12.4.2. Variable: SwiftPostCodeRMRM4SCCActive

The following section contains a detailed description of the variable SwiftPostCodeRMRM4SCCActive.

Variable Overview

Variable Name	Description
SwiftPostCodeRMRM4SCCActive	Activates the Royal Mail RM4SCC code

Communication Name	DCPCSwftPRMRM4SCCAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	312
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPCSwftPRMRM4SCCAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftPRMRM4SCCAct	String	20	Activates the Royal Mail RM4SCC code

Read Variable Response:				
`sRA DCPCSwftPRMRM4SCCAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftPRMRM4SCCAct	String	20	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPCSwftPRMRM4SCCAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftPRMRM4SCCAct	String	20	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPCSwftPRMRM4SCCAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCSwftPRMRM4SCCAct	String	20	Activates the Royal Mail RM4SCC code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCSwftPRMRM4SCCAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCSwftPRMRM4SCCAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCSwftPRMRM4SCCAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCSwftPRMRM4SCCAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.4.3. Variable: SwiftPostCodeRMInfomailActive

The following section contains a detailed description of the variable SwiftPostCodeRMInfomailActive.

Variable Overview

Variable Name	Description
SwiftPostCodeRMInfomailActive	Activates the Royal Mail RM4SCC code

Communication Name	DCPCSwftPRMInfmlAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	313
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCSwftPRMInfmlAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftPRMInfmlAct	String	19	Activates the Royal Mail RM4SCC code

Read Variable Response:

```
sRA DCPCSwftPRMInfmlAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftPRMInfmlAct	String	19	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCSwftPRMInfmlAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftPRMInfmlAct	String	19	Activates the Royal Mail RM4SCC code
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCSwftPRMInfmlAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCSwftPRMInfmlAct	String	19	Activates the Royal Mail RM4SCC code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCSwftPRMInfmlAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCSwftPRMInfmlAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCSwftPRMInfmlAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCSwftPRMInfmlAct[ETX]`

2.12.4.4. Variable: SwiftPostCodeUSPPostNetActive

The following section contains a detailed description of the variable SwiftPostCodeUSPPostNetActive.

Variable Overview

Variable Name	Description
SwiftPostCodeUSPPostNetActive	Activates the Swift United States Postal Postnet code

Communication Name	DCPCSwftUSPPNAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	314
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCSwftUSPPNAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftUSPPNAct	String	16	Activates the Swift United States Postal Postnet code

Read Variable Response:

```
sRA DCPCSwftUSPPNAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftUSPPNAct	String	16	Activates the Swift United States Postal Postnet code
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPCSwftUSPPNAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftUSPPNAct	String	16	Activates the Swift United States Postal Postnet code
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCPCSwftUSPPNAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCSwftUSPPNAct	String	16	Activates the Swift United States Postal Postnet code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCSwftUSPPNAct[ETX]
Read Variable Response:	[STX]sRA DCPCSwftUSPPNAct 0[ETX]
Write Variable:	[STX]sWN DCPCSwftUSPPNAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCSwftUSPPNAct[ETX]

2.12.4.5. Variable: SwiftPostCodeUSPPlanetActive

The following section contains a detailed description of the variable SwiftPostCodeUSPPlanetActive.

Variable Overview

Variable Name	Description
SwiftPostCodeUSPPlanetActive	Activates the Swift United States Postal Planet code

Communication Name	DCPCSwftUSPPLAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	315
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN DCPCSwftUSPPLAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftUSPPLAct	String	16	Activates the Swift United States Postal Planet code

Read Variable Response:				
sRA DCPCSwftUSPPLAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftUSPPLAct	String	16	Activates the Swift United States Postal Planet code
Variable Data	data	Bool	1	

Write Variable:				
sWN DCPCSwftUSPPLAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftUSPPLAct	String	16	Activates the Swift United States Postal Planet code
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCPCSwftUSPPLAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCSwftUSPPLAct	String	16	Activates the Swift United States Postal Planet code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCSwftUSPPLAct[ETX]
Read Variable Response:	[STX]sRA DCPCSwftUSPPLAct 0[ETX]
Write Variable:	[STX]sWN DCPCSwftUSPPLAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCSwftUSPPLAct[ETX]

© SICK AG - Germany - All rights reserved

2.12.4.6. Variable: SwiftPostCodeUSPUPUActive

The following section contains a detailed description of the variable SwiftPostCodeUSPUPUActive.

Variable Overview

Variable Name	Description
SwiftPostCodeUSPUPUActive	Activates the Swift United States Postal UPU code

Communication Name	DCPCSwftUSPUPUAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	316
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPCSwftUSPUPUAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftUSPUPUAct	String	17	Activates the Swift United States Postal UPU code

Read Variable Response:

```
sRA DCPCSwftUSPUPUAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftUSPUPUAct	String	17	Activates the Swift United States Postal UPU code
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPCSwftUSPUPUAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftUSPUPUAct	String	17	Activates the Swift United States Postal UPU code
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPCSwftUSPUPUAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCSwftUSPUPUAct	String	17	Activates the Swift United States Postal UPU code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPCSwftUSPUPUAct[ETX]`
Read Variable Response:	`[STX]sRA DCPCSwftUSPUPUAct 0[ETX]`
Write Variable:	`[STX]sWN DCPCSwftUSPUPUAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCPCSwftUSPUPUAct[ETX]`

2.12.4.7. Variable: SwiftPostCodeUSPUsps4StateActive

The following section contains a detailed description of the variable SwiftPostCodeUSPUsps4StateActive.

Variable Overview

Variable Name	Description
SwiftPostCodeUSPUsps4StateActive	Activates the Swift United States Postal USPS 4-State code

Communication Name	DCPCSwftUSPUsps4SAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	317
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCPCSwftUSPUsps4SAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPCSwftUSPUsps4SAct	String	20	Activates the Swift United States Postal USPS 4-State code

Read Variable Response:				
`sRA DCPCSwftUSPUsps4SAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPCSwftUSPUsps4SAct	String	20	Activates the Swift United States Postal USPS 4-State code
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPCSwftUSPUsps4SAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPCSwftUSPUsps4SAct	String	20	Activates the Swift United States Postal USPS 4-State code
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCPCSwftUSPUsps4SAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPCSwftUSPUsps4SAct	String	20	Activates the Swift United States Postal USPS 4-State code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPCSwftUSPUsps4SAct[ETX]
Read Variable Response:	[STX]sRA DCPCSwftUSPUsps4SAct 0[ETX]
Write Variable:	[STX]sWN DCPCSwftUSPUsps4SAct 0[ETX]
Write Variable Response:	[STX]sWA DCPCSwftUSPUsps4SAct[ETX]

© SICK AG - Germany - All rights reserved

2.12.5. Group: Decoding1DPlessey

2.12.5.1. Variable: PlesseyActive

The following section contains a detailed description of the variable PlesseyActive.

Variable Overview

Variable Name	Description
PlesseyActive	Activates Plessey Code Decoder

Communication Name	DCPlesseyAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	318
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPlesseyAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPlesseyAct	String	12	Activates Plessey Code Decoder

Read Variable Response:

```
sRA DCPlesseyAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPlesseyAct	String	12	Activates Plessey Code Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPlesseyAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPlesseyAct	String	12	Activates Plessey Code Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPlesseyAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPlesseyAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPlesseyAct	String	12	Activates Plessey Code Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPlesseyAct[ETX]
Read Variable Response:	[STX]sRA DCPlesseyAct 0[ETX]
Write Variable:	[STX]sWN DCPlesseyAct 0[ETX]
Write Variable Response:	[STX]sWA DCPlesseyAct[ETX]

2.12.5.2. Variable: PlesseyMultiRead

The following section contains a detailed description of the variable PlesseyMultiRead.

Variable Overview

Variable Name	Description
PlesseyMultiRead	Multiread of Plessey Code

Communication Name	DCPlesseyMr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	319
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPlesseyMr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPlesseyMr	String	11	Multiread of Plessey Code

Read Variable Response:				
`sRA DCPlesseyMr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPlesseyMr	String	11	Multiread of Plessey Code
Variable Data	data	UInt	2	

Write Variable:				
`sWN DCPlesseyMr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPlesseyMr	String	11	Multiread of Plessey Code
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DCPlesseyMr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPlesseyMr	String	11	Multiread of Plessey Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPlesseyMr[ETX]`
Read Variable Response:	`[STX]sRA DCPlesseyMr 3[ETX]`
Write Variable:	`[STX]sWN DCPlesseyMr 3[ETX]`
Write Variable Response:	`[STX]sWA DCPlesseyMr[ETX]`

© SICK AG - Germany - All rights reserved

2.12.5.3. Variable: PlesseyTransmitCheckDigit

The following section contains a detailed description of the variable PlesseyTransmitCheckDigit.

Variable Overview

Variable Name	Description
PlesseyTransmitCheckDigit	Transmit Check Digit for Plessey

Communication Name	DCPlesseyTrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	320
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPlesseyTrCd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPlesseyTrCd	String	13	Transmit Check Digit for Plessey

Read Variable Response:

```
sRA DCPlesseyTrCd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPlesseyTrCd	String	13	Transmit Check Digit for Plessey
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPlesseyTrCd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPlesseyTrCd	String	13	Transmit Check Digit for Plessey
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPlesseyTrCd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPlesseyTrCd	String	13	Transmit Check Digit for Plessey

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPlesseyTrCd[ETX]`
Read Variable Response:	`[STX]sRA DCPlesseyTrCd 0[ETX]`
Write Variable:	`[STX]sWN DCPlesseyTrCd 0[ETX]`
Write Variable Response:	`[STX]sWA DCPlesseyTrCd[ETX]`

2.12.5.4. Variable: PlesseyLengthMode

The following section contains a detailed description of the variable PlesseyLengthMode.

Variable Overview

Variable Name	Description
PlesseyLengthMode	Codelength mode of Plessey Code

Communication Name	DCPlesseyLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	321
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:				
`sRN DCPlesseyLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPlesseyLenMode	String	16	Codelength mode of Plessey Code

Read Variable Response:				
`sRA DCPlesseyLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPlesseyLenMode	String	16	Codelength mode of Plessey Code
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPlesseyLenMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPlesseyLenMode	String	16	Codelength mode of Plessey Code
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCPlesseyLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPlesseyLenMode	String	16	Codelength mode of Plessey Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPlesseyLenMode[ETX]
Read Variable Response:	[STX]sRA DCPlesseyLenMode 0[ETX]
Write Variable:	[STX]sWN DCPlesseyLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCPlesseyLenMode[ETX]

2.12.5.5. Variable: PlesseyFixLenList

The following section contains a detailed description of the variable PlesseyFixLenList.

Variable Overview

Variable Name	Description
PlesseyFixLenList	List of fix code lengths

Communication Name	DCPlesseyFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	322
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPlesseyFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPlesseyFixLen	String	15	List of fix code lengths

Read Variable Response:				
`sRA DCPlesseyFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPlesseyFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCPlesseyFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPlesseyFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCPlesseyFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPlesseyFixLen	String	15	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPlesseyFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCPlesseyFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCPlesseyFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCPlesseyFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.5.6. Variable: PlesseyIntLenList

The following section contains a detailed description of the variable PlesseyIntLenList.

Variable Overview

Variable Name	Description
PlesseyIntLenList	List of interval code lengths

Communication Name	DCPlesseyIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	323
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCPlesseyIntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPlesseyIntLen	String	15	List of interval code lengths

Read Variable Response:

```
sRA DCPlesseyIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPlesseyIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCPlesseyIntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPlesseyIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPlesseyIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPlesseyIntLen	String	15	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPlesseyIntLen[ETX]
Read Variable Response:	[STX]sRA DCPlesseyIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCPlesseyIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCPlesseyIntLen[ETX]

© SICK AG - Germany - All rights reserved

2.12.6. Group: Decoding1DMSIPlessey

2.12.6.1. Variable: MSIPlesseyActive

The following section contains a detailed description of the variable MSIPlesseyActive.

Variable Overview

Variable Name	Description
MSIPlesseyActive	Activates MSI Plessey Code Decoder

Communication Name	DCMSIPlesseyAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	324
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCMSIPlesseyAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyAct	String	15	Activates MSI Plessey Code Decoder

Read Variable Response:

```
sRA DCMSIPlesseyAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyAct	String	15	Activates MSI Plessey Code Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCMSIPlesseyAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyAct	String	15	Activates MSI Plessey Code Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCMSIPlesseyAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCMSIPlesseyAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCMSIPlesseyAct	String	15	Activates MSI Plessey Code Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCMSIPlesseyAct[ETX]
Read Variable Response:	[STX]sRA DCMSIPlesseyAct 0[ETX]
Write Variable:	[STX]sWN DCMSIPlesseyAct 0[ETX]
Write Variable Response:	[STX]sWA DCMSIPlesseyAct[ETX]

2.12.6.2. Variable: MSIPlesseyMultiRead

The following section contains a detailed description of the variable MSIPlesseyMultiRead.

Variable Overview

Variable Name	Description
MSIPlesseyMultiRead	Multiread of MSI Plessey Code

Communication Name	DCMSIPlesseyMr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	325
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCMSIPlesseyMr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyMr	String	14	Multiread of MSI Plessey Code

Read Variable Response:				
`sRA DCMSIPlesseyMr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyMr	String	14	Multiread of MSI Plessey Code
Variable Data	data	UInt	2	

Write Variable:				
`sWN DCMSIPlesseyMr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyMr	String	14	Multiread of MSI Plessey Code
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DCMSIPlesseyMr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMSIPlesseyMr	String	14	Multiread of MSI Plessey Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMSIPlesseyMr[ETX]`
Read Variable Response:	`[STX]sRA DCMSIPlesseyMr 3[ETX]`
Write Variable:	`[STX]sWN DCMSIPlesseyMr 3[ETX]`
Write Variable Response:	`[STX]sWA DCMSIPlesseyMr[ETX]`

© SICK AG - Germany - All rights reserved

2.12.6.3. Variable: MSIPlesseyCheckDigitTest

The following section contains a detailed description of the variable MSIPlesseyCheckDigitTest.

Variable Overview

Variable Name	Description
MSIPlesseyCheckDigitTest	Check Digit Test for MSI Plessey Code

Communication Name	DCMSIPlesseyCdTst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	326
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_None	
	1	TX_Modulo_10	

Variable Telegram Syntax

Read Variable:				
`sRN DCMSIPlesseyCdTst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyCdTst	String	17	Check Digit Test for MSI Plessey Code

Read Variable Response:				
`sRA DCMSIPlesseyCdTst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyCdTst	String	17	Check Digit Test for MSI Plessey Code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCMSIPlesseyCdTst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyCdTst	String	17	Check Digit Test for MSI Plessey Code
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCMSIPlesseyCdTst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMSIPlesseyCdTst	String	17	Check Digit Test for MSI Plessey Code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMSIPlesseyCdTst[ETX]`
Read Variable Response:	`[STX]sRA DCMSIPlesseyCdTst 1[ETX]`
Write Variable:	`[STX]sWN DCMSIPlesseyCdTst 1[ETX]`
Write Variable Response:	`[STX]sWA DCMSIPlesseyCdTst[ETX]`

2.12.6.4. Variable: MSIPlesseyTransmitCheckDigit

The following section contains a detailed description of the variable MSIPlesseyTransmitCheckDigit.

Variable Overview

Variable Name	Description
MSIPlesseyTransmitCheckDigit	Transmit Check Digit for MSI Plessey

Communication Name	DCMSIPlesseyTrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	327
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCMSIPlesseyTrCd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyTrCd	String	16	Transmit Check Digit for MSI Plessey

Read Variable Response:

```
sRA DCMSIPlesseyTrCd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyTrCd	String	16	Transmit Check Digit for MSI Plessey
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCMSIPlesseyTrCd <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyTrCd	String	16	Transmit Check Digit for MSI Plessey
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCMSIPlesseyTrCd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMSIPlesseyTrCd	String	16	Transmit Check Digit for MSI Plessey

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCMSIPlesseyTrCd[ETX]
Read Variable Response:	[STX]sRA DCMSIPlesseyTrCd 1[ETX]
Write Variable:	[STX]sWN DCMSIPlesseyTrCd 1[ETX]
Write Variable Response:	[STX]sWA DCMSIPlesseyTrCd[ETX]

2.12.6.5. Variable: MSIPlesseyLengthMode

The following section contains a detailed description of the variable MSIPlesseyLengthMode.

Variable Overview

Variable Name	Description
MSIPlesseyLengthMode	Codelength mode of MSI Plessey Code

Communication Name	DCMSIPlesseyLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	328
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCMSIPlesseyLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyLenMode	String	19	Codelength mode of MSI Plessey Code

Read Variable Response:				
`sRA DCMSIPlesseyLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyLenMode	String	19	Codelength mode of MSI Plessey Code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCMSIPlesseyLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyLenMode	String	19	Codelength mode of MSI Plessey Code
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCMSIPlesseyLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMSIPlesseyLenMode	String	19	Codelength mode of MSI Plessey Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMSIPlesseyLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCMSIPlesseyLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCMSIPlesseyLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCMSIPlesseyLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.12.6.6. Variable: MSIPlesseyFixLenList

The following section contains a detailed description of the variable MSIPlesseyFixLenList.

Variable Overview

Variable Name	Description
MSIPlesseyFixLenList	List of fix code lengths

Communication Name	DCMSIPlesseyFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	329
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	5
UDInt	
Value Range	0..50
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCMSIPlesseyFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyFixLen	String	18	List of fix code lengths

Read Variable Response:				
`sRA DCMSIPlesseyFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCMSIPlesseyFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyFixLen	String	18	List of fix code lengths
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCMSIPlesseyFixLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMSIPlesseyFixLen	String	18	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCMSIPlesseyFixLen[ETX]
Read Variable Response:	[STX]sRA DCMSIPlesseyFixLen 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCMSIPlesseyFixLen 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCMSIPlesseyFixLen[ETX]

2.12.6.7. Variable: MSIPlesseyIntLenList

The following section contains a detailed description of the variable MSIPlesseyIntLenList.

Variable Overview

Variable Name	Description
MSIPlesseyIntLenList	List of interval code lengths

Communication Name	DCMSIPlesseyIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	330
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCMSIPlesseyIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMSIPlesseyIntLen	String	18	List of interval code lengths

Read Variable Response:				
`sRA DCMSIPlesseyIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMSIPlesseyIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCMSIPlesseyIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMSIPlesseyIntLen	String	18	List of interval code lengths
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DCMSIPlesseyIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMSIPlesseyIntLen	String	18	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMSIPlesseyIntLen[ETX]`
Read Variable Response:	`[STX]sRA DCMSIPlesseyIntLen 0 0[ETX]`
Write Variable:	`[STX]sWN DCMSIPlesseyIntLen 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCMSIPlesseyIntLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.7. Group: Decoding1DTelepen

2.12.7.1. Variable: TelepenActive

The following section contains a detailed description of the variable TelepenActive.

Variable Overview

Variable Name	Description
TelepenActive	Activates Telepen Code Decoder

Communication Name	DCTelepenAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	331
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCTelepenAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenAct	String	12	Activates Telepen Code Decoder

Read Variable Response:

```
sRA DCTelepenAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenAct	String	12	Activates Telepen Code Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCTelepenAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenAct	String	12	Activates Telepen Code Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCTelepenAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCTelepenAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCTelepenAct	String	12	Activates Telepen Code Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTelepenAct[ETX]
Read Variable Response:	[STX]sRA DCTelepenAct 0[ETX]
Write Variable:	[STX]sWN DCTelepenAct 0[ETX]
Write Variable Response:	[STX]sWA DCTelepenAct[ETX]

2.12.7.2. Variable: TelepenMultiRead

The following section contains a detailed description of the variable TelepenMultiRead.

Variable Overview

Variable Name	Description
TelepenMultiRead	Multiread of Telepen Code

Communication Name	DCTelepenMr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	332
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTelepenMr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenMr	String	11	Multiread of Telepen Code

Read Variable Response:				
`sRA DCTelepenMr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenMr	String	11	Multiread of Telepen Code
Variable Data	data	UInt	2	

Write Variable:				
`sWN DCTelepenMr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenMr	String	11	Multiread of Telepen Code
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DCTelepenMr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTelepenMr	String	11	Multiread of Telepen Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTelepenMr[ETX]`
Read Variable Response:	`[STX]sRA DCTelepenMr 3[ETX]`
Write Variable:	`[STX]sWN DCTelepenMr 3[ETX]`
Write Variable Response:	`[STX]sWA DCTelepenMr[ETX]`

© SICK AG - Germany - All rights reserved

2.12.7.3. Variable: TelepenMode

The following section contains a detailed description of the variable TelepenMode.

Variable Overview

Variable Name	Description
TelepenMode	Decoding mode for Telepen

Communication Name	DCTelepenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	333
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Auto	
	1	TX_ASCII	
	2	TX_Numeric	

Variable Telegram Syntax

Read Variable:

```
sRN DCTelepenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenMode	String	13	Decoding mode for Telepen

Read Variable Response:

```
sRA DCTelepenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenMode	String	13	Decoding mode for Telepen
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCTelepenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenMode	String	13	Decoding mode for Telepen
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCTelepenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCTelepenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCTelepenMode	String	13	Decoding mode for Telepen

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTelepenMode[ETX]
Read Variable Response:	[STX]sRA DCTelepenMode 0[ETX]
Write Variable:	[STX]sWN DCTelepenMode 0[ETX]
Write Variable Response:	[STX]sWA DCTelepenMode[ETX]

2.12.7.4. Variable: TelepenTransmitCheckDigit

The following section contains a detailed description of the variable TelepenTransmitCheckDigit.

Variable Overview

Variable Name	Description
TelepenTransmitCheckDigit	Transmit Check Digit for Telepen

Communication Name	DCTelepenTrCd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	334
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTelepenTrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenTrCd	String	13	Transmit Check Digit for Telepen

Read Variable Response:				
`sRA DCTelepenTrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenTrCd	String	13	Transmit Check Digit for Telepen
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCTelepenTrCd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenTrCd	String	13	Transmit Check Digit for Telepen
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCTelepenTrCd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTelepenTrCd	String	13	Transmit Check Digit for Telepen

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTelepenTrCd[ETX]`
Read Variable Response:	`[STX]sRA DCTelepenTrCd 0[ETX]`
Write Variable:	`[STX]sWN DCTelepenTrCd 0[ETX]`
Write Variable Response:	`[STX]sWA DCTelepenTrCd[ETX]`

© SICK AG - Germany - All rights reserved

2.12.7.5. Variable: TelepenLengthMode

The following section contains a detailed description of the variable TelepenLengthMode.

Variable Overview

Variable Name	Description
TelepenLengthMode	Codelength mode of Telepen Code

Communication Name	DCTelepenLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	335
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_Free	
	1	TX_Interval	
	2	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCTelepenLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenLenMode	String	16	Codelength mode of Telepen Code

Read Variable Response:

```
sRA DCTelepenLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenLenMode	String	16	Codelength mode of Telepen Code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCTelepenLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenLenMode	String	16	Codelength mode of Telepen Code
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCTelepenLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCTelepenLenMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCTelepenLenMode	String	16	Codelength mode of Telepen Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTelepenLenMode[ETX]
Read Variable Response:	[STX]sRA DCTelepenLenMode 0[ETX]
Write Variable:	[STX]sWN DCTelepenLenMode 0[ETX]
Write Variable Response:	[STX]sWA DCTelepenLenMode[ETX]

2.12.7.6. Variable: TelepenFixLenList

The following section contains a detailed description of the variable TelepenFixLenList.

Variable Overview

Variable Name	Description
TelepenFixLenList	List of fix code lengths

Communication Name	DCTelepenFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	336
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTelepenFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenFixLen	String	15	List of fix code lengths

Read Variable Response:				
`sRA DCTelepenFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCTelepenFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenFixLen	String	15	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCTelepenFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTelepenFixLen	String	15	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTelepenFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCTelepenFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCTelepenFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCTelepenFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.7.7. Variable: TelepenIntLenList

The following section contains a detailed description of the variable TelepenIntLenList.

Variable Overview

Variable Name	Description
TelepenIntLenList	List of interval code lengths

Communication Name	DCTelepenIntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	337
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..50
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DCTelepenIntLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTelepenIntLen	String	15	List of interval code lengths

Read Variable Response:				
`sRA DCTelepenIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTelepenIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:				
`sWN DCTelepenIntLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTelepenIntLen	String	15	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCTelepenIntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTelepenIntLen	String	15	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTelepenIntLen[ETX]
Read Variable Response:	[STX]sRA DCTelepenIntLen 0 0[ETX]
Write Variable:	[STX]sWN DCTelepenIntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCTelepenIntLen[ETX]

© SICK AG - Germany - All rights reserved

2.12.8. Group: Decoding1DGS1DataBar

2.12.8.1. Variable: GS1DataBarActive

The following section contains a detailed description of the variable GS1DataBarActive.

Variable Overview

Variable Name	Description
GS1DataBarActive	Activates GS1 DataBar Decoder

Communication Name	DCGS1Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	338
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1Act	String	8	Activates GS1 DataBar Decoder

Read Variable Response:

```
sRA DCGS1Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1Act	String	8	Activates GS1 DataBar Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCGS1Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1Act	String	8	Activates GS1 DataBar Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCGS1Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCGS1Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCGS1Act	String	8	Activates GS1 DataBar Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCGS1Act[ETX]
Read Variable Response:	[STX]sRA DCGS1Act 0[ETX]
Write Variable:	[STX]sWN DCGS1Act 0[ETX]
Write Variable Response:	[STX]sWA DCGS1Act[ETX]

2.12.8.2. Variable: GS114Enabled

The following section contains a detailed description of the variable GS114Enabled.

Variable Overview

Variable Name	Description
GS114Enabled	Activates GS1 DataBar 14

Communication Name	DCGS114Enabled
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	339
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCGS114Enabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS114Enabled	String	14	Activates GS1 DataBar 14

Read Variable Response:				
`sRA DCGS114Enabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS114Enabled	String	14	Activates GS1 DataBar 14
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCGS114Enabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS114Enabled	String	14	Activates GS1 DataBar 14
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCGS114Enabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS114Enabled	String	14	Activates GS1 DataBar 14

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS114Enabled[ETX]`
Read Variable Response:	`[STX]sRA DCGS114Enabled 1[ETX]`
Write Variable:	`[STX]sWN DCGS114Enabled 1[ETX]`
Write Variable Response:	`[STX]sWA DCGS114Enabled[ETX]`

© SICK AG - Germany - All rights reserved

2.12.8.3. Variable: GS1ExpandedEnabled

The following section contains a detailed description of the variable GS1ExpandedEnabled.

Variable Overview

Variable Name	Description
GS1ExpandedEnabled	Activates GS1 DataBar Expanded

Communication Name	DCGS1ExpEnabled
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	340
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1ExpEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1ExpEnabled	String	15	Activates GS1 DataBar Expanded

Read Variable Response:

```
sRA DCGS1ExpEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1ExpEnabled	String	15	Activates GS1 DataBar Expanded
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCGS1ExpEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1ExpEnabled	String	15	Activates GS1 DataBar Expanded
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCGS1ExpEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1ExpEnabled	String	15	Activates GS1 DataBar Expanded

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1ExpEnabled[ETX]`
Read Variable Response:	`[STX]sRA DCGS1ExpEnabled 1[ETX]`
Write Variable:	`[STX]sWN DCGS1ExpEnabled 1[ETX]`
Write Variable Response:	`[STX]sWA DCGS1ExpEnabled[ETX]`

2.12.8.4. Variable: GS1LimitedEnabled

The following section contains a detailed description of the variable GS1LimitedEnabled.

Variable Overview

Variable Name	Description
GS1LimitedEnabled	Activates GS1 DataBar Limited

Communication Name	DCGS1LimEnabled
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	341
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN DCGS1LimEnabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1LimEnabled	String	15	Activates GS1 DataBar Limited

Read Variable Response:				
`sRA DCGS1LimEnabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1LimEnabled	String	15	Activates GS1 DataBar Limited
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCGS1LimEnabled <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1LimEnabled	String	15	Activates GS1 DataBar Limited
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCGS1LimEnabled				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1LimEnabled	String	15	Activates GS1 DataBar Limited

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCGS1LimEnabled[ETX]
Read Variable Response:	[STX]sRA DCGS1LimEnabled 1[ETX]
Write Variable:	[STX]sWN DCGS1LimEnabled 1[ETX]
Write Variable Response:	[STX]sWA DCGS1LimEnabled[ETX]

2.12.8.5. Variable: GS1DataBarStackedCodesActive

The following section contains a detailed description of the variable GS1DataBarStackedCodesActive.

Variable Overview

Variable Name	Description
GS1DataBarStackedCodesActive	Activates GS1 DataBar Stacked Codes

Communication Name	DCGS1StackedAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	342
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCGS1StackedAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1StackedAct	String	15	Activates GS1 DataBar Stacked Codes

Read Variable Response:				
`sRA DCGS1StackedAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1StackedAct	String	15	Activates GS1 DataBar Stacked Codes
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCGS1StackedAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1StackedAct	String	15	Activates GS1 DataBar Stacked Codes
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCGS1StackedAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1StackedAct	String	15	Activates GS1 DataBar Stacked Codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1StackedAct[ETX]`
Read Variable Response:	`[STX]sRA DCGS1StackedAct 0[ETX]`
Write Variable:	`[STX]sWN DCGS1StackedAct 0[ETX]`
Write Variable Response:	`[STX]sWA DCGS1StackedAct[ETX]`

© SICK AG - Germany - All rights reserved

2.12.8.6. Variable: GS1MultiRead

The following section contains a detailed description of the variable GS1MultiRead.

Variable Overview

Variable Name	Description
GS1MultiRead	Multiread of GS1 DataBar

Communication Name	DCGS1Mr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	343
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1Mr	String	7	Multiread of GS1 DataBar

Read Variable Response:

```
sRA DCGS1Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1Mr	String	7	Multiread of GS1 DataBar
Variable Data	data	UInt	2	

Write Variable:

```
sWN DCGS1Mr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1Mr	String	7	Multiread of GS1 DataBar
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA DCGS1Mr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1Mr	String	7	Multiread of GS1 DataBar

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1Mr[ETX]`
Read Variable Response:	`[STX]sRA DCGS1Mr 3[ETX]`
Write Variable:	`[STX]sWN DCGS1Mr 3[ETX]`
Write Variable Response:	`[STX]sWA DCGS1Mr[ETX]`

2.12.8.7. Variable: GS12DComponentMode

The following section contains a detailed description of the variable GS12DComponentMode.

Variable Overview

Variable Name	Description
GS12DComponentMode	GS1 DataBar 2D component mode mode

Communication Name	DCGS12DCompMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	344
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_None	
	Value	Name	Description
	0	TX_None	
	1	TX_Active	
	2	TX_Required	

Variable Telegram Syntax

Read Variable:				
`sRN DCGS12DCompMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS12DCompMode	String	15	GS1 DataBar 2D component mode mode

Read Variable Response:				
`sRA DCGS12DCompMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS12DCompMode	String	15	GS1 DataBar 2D component mode mode
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCGS12DCompMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS12DCompMode	String	15	GS1 DataBar 2D component mode mode
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCGS12DCompMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS12DCompMode	String	15	GS1 DataBar 2D component mode mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCGS12DCompMode[ETX]
Read Variable Response:	[STX]sRA DCGS12DCompMode 0[ETX]
Write Variable:	[STX]sWN DCGS12DCompMode 0[ETX]
Write Variable Response:	[STX]sWA DCGS12DCompMode[ETX]

2.12.8.8. Variable: GS1HexASCIIOutput

The following section contains a detailed description of the variable GS1HexASCIIOutput.

Variable Overview

Variable Name	Description
GS1HexASCIIOutput	Hex ASCII Output of GS1 DataBar

Communication Name	DCGS1HxAOut
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	345
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCGS1HxAOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1HxAOut	String	11	Hex ASCII Output of GS1 DataBar

Read Variable Response:				
`sRA DCGS1HxAOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1HxAOut	String	11	Hex ASCII Output of GS1 DataBar
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCGS1HxAOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1HxAOut	String	11	Hex ASCII Output of GS1 DataBar
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCGS1HxAOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1HxAOut	String	11	Hex ASCII Output of GS1 DataBar

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1HxAOut[ETX]`
Read Variable Response:	`[STX]sRA DCGS1HxAOut 0[ETX]`
Write Variable:	`[STX]sWN DCGS1HxAOut 0[ETX]`
Write Variable Response:	`[STX]sWA DCGS1HxAOut[ETX]`

© SICK AG - Germany - All rights reserved

2.12.8.9. Variable: GS1EmulationEnabled

The following section contains a detailed description of the variable GS1EmulationEnabled.

Variable Overview

Variable Name	Description
GS1EmulationEnabled	Activates GS1 DataBar Emulation

Communication Name	DCGS1EmuEnabled
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	346
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1EmuEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1EmuEnabled	String	15	Activates GS1 DataBar Emulation

Read Variable Response:

```
sRA DCGS1EmuEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1EmuEnabled	String	15	Activates GS1 DataBar Emulation
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCGS1EmuEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1EmuEnabled	String	15	Activates GS1 DataBar Emulation
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCGS1EmuEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1EmuEnabled	String	15	Activates GS1 DataBar Emulation

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1EmuEnabled[ETX]`
Read Variable Response:	`[STX]sRA DCGS1EmuEnabled 0[ETX]`
Write Variable:	`[STX]sWN DCGS1EmuEnabled 0[ETX]`
Write Variable Response:	`[STX]sWA DCGS1EmuEnabled[ETX]`

2.12.8.10. Variable: GS1FixLenList

The following section contains a detailed description of the variable GS1FixLenList.

Variable Overview

Variable Name	Description
GS1FixLenList	List of fix code lengths

Communication Name	DCDS1FixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	348
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		5
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDS1FixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDS1FixLen	String	11	List of fix code lengths

Read Variable Response:				
`sRA DCDS1FixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDS1FixLen	String	11	List of fix code lengths
Variable Data	data	Array	20	

Write Variable:				
`sWN DCDS1FixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDS1FixLen	String	11	List of fix code lengths
Variable Data	data	Array	20	

Write Variable Response:				
`sWA DCDS1FixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDS1FixLen	String	11	List of fix code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDS1FixLen[ETX]`
Read Variable Response:	`[STX]sRA DCDS1FixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCDS1FixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCDS1FixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.12.8.11. Variable: GS1IntLenList

The following section contains a detailed description of the variable GS1IntLenList.

Variable Overview

Variable Name	Description
GS1IntLenList	List of interval code lengths

Communication Name	DCGS1IntLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	349
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		2
	UDInt	
	Value Range	0..100
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1IntLen
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1IntLen	String	11	List of interval code lengths

Read Variable Response:

```
sRA DCGS1IntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1IntLen	String	11	List of interval code lengths
Variable Data	data	Array	8	

Write Variable:

```
sWN DCGS1IntLen <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1IntLen	String	11	List of interval code lengths
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCGS1IntLen				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1IntLen	String	11	List of interval code lengths

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCGS1IntLen[ETX]
Read Variable Response:	[STX]sRA DCGS1IntLen 0 0[ETX]
Write Variable:	[STX]sWN DCGS1IntLen 0 0[ETX]
Write Variable Response:	[STX]sWA DCGS1IntLen[ETX]

2.12.8.12. Variable: GS1Min3AdjacentSegments

The following section contains a detailed description of the variable GS1Min3AdjacentSegments.

Variable Overview

Variable Name	Description
GS1Min3AdjacentSegments	minimum of 3 adjacent segments for GS1 DataBar codes

Communication Name	DCGS1Min3AdjSegm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	350
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCGS1Min3AdjSegm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1Min3AdjSegm	String	16	minimum of 3 adjacent segments for GS1 DataBar codes

Read Variable Response:				
`sRA DCGS1Min3AdjSegm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1Min3AdjSegm	String	16	minimum of 3 adjacent segments for GS1 DataBar codes
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCGS1Min3AdjSegm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1Min3AdjSegm	String	16	minimum of 3 adjacent segments for GS1 DataBar codes
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCGS1Min3AdjSegm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1Min3AdjSegm	String	16	minimum of 3 adjacent segments for GS1 DataBar codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1Min3AdjSegm[ETX]`
Read Variable Response:	`[STX]sRA DCGS1Min3AdjSegm 0[ETX]`
Write Variable:	`[STX]sWN DCGS1Min3AdjSegm 0[ETX]`
Write Variable Response:	`[STX]sWA DCGS1Min3AdjSegm[ETX]`

© SICK AG - Germany - All rights reserved

2.12.8.13. Variable: GS1ModuleWidthTolerance

The following section contains a detailed description of the variable GS1ModuleWidthTolerance.

Variable Overview

Variable Name	Description
GS1ModuleWidthTolerance	defines module width tolerance for GS1 DataBar codes

Communication Name	DCGS1ModWidthTol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	351
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	1..4
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1ModWidthTol
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1ModWidthTol	String	16	defines module width tolerance for GS1 DataBar codes

Read Variable Response:

```
sRA DCGS1ModWidthTol <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1ModWidthTol	String	16	defines module width tolerance for GS1 DataBar codes
Variable Data	data	USInt	1	

Write Variable:

```
sWN DCGS1ModWidthTol <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1ModWidthTol	String	16	defines module width tolerance for GS1 DataBar codes
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCGS1ModWidthTol				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1ModWidthTol	String	16	defines module width tolerance for GS1 DataBar codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCGS1ModWidthTol[ETX]
Read Variable Response:	[STX]sRA DCGS1ModWidthTol 1[ETX]
Write Variable:	[STX]sWN DCGS1ModWidthTol 1[ETX]
Write Variable Response:	[STX]sWA DCGS1ModWidthTol[ETX]

2.12.8.14. Variable: GS1NorcaOutputVerifier

The following section contains a detailed description of the variable GS1NorcaOutputVerifier.

Variable Overview

Variable Name	Description
GS1NorcaOutputVerifier	Enable output of Norca verifier

Communication Name	DCGS1OutVrfr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	352
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCGS1OutVrfr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1OutVrfr	String	12	Enable output of Norca verifier

Read Variable Response:				
`sRA DCGS1OutVrfr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1OutVrfr	String	12	Enable output of Norca verifier
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCGS1OutVrfr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1OutVrfr	String	12	Enable output of Norca verifier
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCGS1OutVrfr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1OutVrfr	String	12	Enable output of Norca verifier

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1OutVrfr[ETX]`
Read Variable Response:	`[STX]sRA DCGS1OutVrfr 0[ETX]`
Write Variable:	`[STX]sWN DCGS1OutVrfr 0[ETX]`
Write Variable Response:	`[STX]sWA DCGS1OutVrfr[ETX]`

© SICK AG - Germany - All rights reserved

2.12.8.15. Variable: GS1NorcaIssueUndecodableSymbols

The following section contains a detailed description of the variable GS1NorcaIssueUndecodableSymbols.

Variable Overview

Variable Name	Description
GS1NorcaIssueUndecodableSymbols	Enable output of noread results

Communication Name	DCGS1UndecSymbls
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	353
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCGS1UndecSymbls
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGS1UndecSymbls	String	16	Enable output of noread results

Read Variable Response:

```
sRA DCGS1UndecSymbls <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGS1UndecSymbls	String	16	Enable output of noread results
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCGS1UndecSymbls <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGS1UndecSymbls	String	16	Enable output of noread results
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCGS1UndecSymbls
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGS1UndecSymbls	String	16	Enable output of noread results

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGS1UndecSymbls[ETX]`
Read Variable Response:	`[STX]sRA DCGS1UndecSymbls 0[ETX]`
Write Variable:	`[STX]sWN DCGS1UndecSymbls 0[ETX]`
Write Variable Response:	`[STX]sWA DCGS1UndecSymbls[ETX]`

© SICK AG - Germany - All rights reserved

2.12.9. Group: Decoding1DVerifier

2.12.9.1. Variable: Code1DVerISO15416

The following section contains a detailed description of the variable Code1DVerISO15416.

Variable Overview

Variable Name	Description
Code1DVerISO15416	flag if verification ISO15416 should be computed

Communication Name	DC1DVerISO15416
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	354
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DC1DVerISO15416
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC1DVerISO15416	String	15	flag if verification ISO15416 should be computed

Read Variable Response:

```
sRA DC1DVerISO15416 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC1DVerISO15416	String	15	flag if verification ISO15416 should be computed
Variable Data	data	Bool	1	

Write Variable:

```
sWN DC1DVerISO15416 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC1DVerISO15416	String	15	flag if verification ISO15416 should be computed
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DC1DVerISO15416
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DC1DVerISO15416				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DC1DVerISO15416	String	15	flag if verification ISO15416 should be computed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DC1DVerISO15416[ETX]
Read Variable Response:	[STX]sRA DC1DVerISO15416 1[ETX]
Write Variable:	[STX]sWN DC1DVerISO15416 1[ETX]
Write Variable Response:	[STX]sWA DC1DVerISO15416[ETX]

© SICK AG - Germany - All rights reserved

2.13. Interface Block: GeneralCfgDecoding2DBase

2.13.1. Group: Decoding2DGeneral

2.13.1.1. Variable: CodeContrast2D

The following section contains a detailed description of the variable CodeContrast2D.

Variable Overview

Variable Name	Description
CodeContrast2D	Contrast in per cent that a code should have at least

Communication Name	DC2DContrast
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	357
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_CODE_CONTRAST_30	
	Value	Name	Description
	0	TX_CODE_CONTRAST_0	
	5	TX_CODE_CONTRAST_5	
	10	TX_CODE_CONTRAST_10	
	15	TX_CODE_CONTRAST_15	
	20	TX_CODE_CONTRAST_20	
	25	TX_CODE_CONTRAST_25	
	30	TX_CODE_CONTRAST_30	
	40	TX_CODE_CONTRAST_40	
	50	TX_CODE_CONTRAST_50	
	60	TX_CODE_CONTRAST_60	
	70	TX_CODE_CONTRAST_70	

Variable Telegram Syntax

Read Variable:
`sRN DC2DContrast`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC2DContrast	String	12	Contrast in per cent that a code should have at least

Read Variable Response:
`sRA DC2DContrast <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC2DContrast	String	12	Contrast in per cent that a code should have at least
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DC2DContrast <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC2DContrast	String	12	Contrast in per cent that a code should have at least
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DC2DContrast`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DC2DContrast	String	12	Contrast in per cent that a code should have at least

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DC2DContrast[ETX]`
Read Variable Response:	`[STX]sRA DC2DContrast 1E[ETX]`
Write Variable:	`[STX]sWN DC2DContrast 1E[ETX]`
Write Variable Response:	`[STX]sWA DC2DContrast[ETX]`

2.13.1.2. Variable: MinModuleSize2DMM

The following section contains a detailed description of the variable MinModuleSize2DMM.

Variable Overview

Variable Name	Description
MinModuleSize2DMM	min. module size in mm

Communication Name	DC2DMinModSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	355
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.025..10.0
Initialisation	0.35
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DC2DMinModSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC2DMinModSize	String	14	min. module size in mm

Read Variable Response:				
`sRA DC2DMinModSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC2DMinModSize	String	14	min. module size in mm
Variable Data	data	Real	4	

Write Variable:				
`sWN DC2DMinModSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC2DMinModSize	String	14	min. module size in mm
Variable Data	data	Real	4	

Write Variable Response:				
`sWA DC2DMinModSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DC2DMinModSize	String	14	min. module size in mm

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DC2DMinModSize[ETX]`
Read Variable Response:	`[STX]sRA DC2DMinModSize 3EB33333[ETX]`
Write Variable:	`[STX]sWN DC2DMinModSize 3EB33333[ETX]`
Write Variable Response:	`[STX]sWA DC2DMinModSize[ETX]`

© SICK AG - Germany - All rights reserved

2.13.1.3. Variable: CodeBackground2D

The following section contains a detailed description of the variable CodeBackground2D.

Variable Overview

Variable Name	Description
CodeBackground2D	2D Code background color

Communication Name	DC2DBackground
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	358
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_WHITE	
	Value	Name	Description
	0	TX_WHITE	

Variable Telegram Syntax

Read Variable:

```
sRN DC2DBackground
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC2DBackground	String	14	2D Code background color

Read Variable Response:

```
sRA DC2DBackground <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC2DBackground	String	14	2D Code background color
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DC2DBackground <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC2DBackground	String	14	2D Code background color
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DC2DBackground
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DC2DBackground	String	14	2D Code background color

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DC2DBackground[ETX]`
Read Variable Response:	`[STX]sRA DC2DBackground 0[ETX]`
Write Variable:	`[STX]sWN DC2DBackground 0[ETX]`
Write Variable Response:	`[STX]sWA DC2DBackground[ETX]`

2.13.1.4. Variable: MaxModuleSize2DMM

The following section contains a detailed description of the variable MaxModuleSize2DMM.

Variable Overview

Variable Name	Description
MaxModuleSize2DMM	max. module size in mm

Communication Name	DC2DMaxModSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	356
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.025..10.0
Initialisation	1.4
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DC2DMaxModSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DC2DMaxModSize	String	14	max. module size in mm

Read Variable Response:				
`sRA DC2DMaxModSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DC2DMaxModSize	String	14	max. module size in mm
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DC2DMaxModSize <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DC2DMaxModSize	String	14	max. module size in mm
Variable Data	data	Real	4	

Write Variable Response:				
sWA DC2DMaxModSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DC2DMaxModSize	String	14	max. module size in mm

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DC2DMaxModSize[ETX]
Read Variable Response:	[STX]sRA DC2DMaxModSize 3FB33333[ETX]
Write Variable:	[STX]sWN DC2DMaxModSize 3FB33333[ETX]
Write Variable Response:	[STX]sWA DC2DMaxModSize[ETX]

© SICK AG - Germany - All rights reserved

2.13.2. Group: DecodingDataMatrix

2.13.2.1. Variable: DataMatrixErrorCorr

The following section contains a detailed description of the variable DataMatrixErrorCorr.

Variable Overview

Variable Name	Description
DataMatrixErrorCorr	Data matrix permissible error correction

Communication Name	DCDMErrCor
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	362
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..100
Initialisation	100
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCDMErrCor
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMErrCor	String	10	Data matrix permissible error correction

Read Variable Response:

```
sRA DCDMErrCor <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMErrCor	String	10	Data matrix permissible error correction
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCDMErrCor <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMErrCor	String	10	Data matrix permissible error correction
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMErrCor				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMErrCor	String	10	Data matrix permissible error correction

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMErrCor[ETX]
Read Variable Response:	[STX]sRA DCDMErrCor 64[ETX]
Write Variable:	[STX]sWN DCDMErrCor 64[ETX]
Write Variable Response:	[STX]sWA DCDMErrCor[ETX]

2.13.2.2. Variable: DataMatrixDilateFilterSize

The following section contains a detailed description of the variable DataMatrixDilateFilterSize.

Variable Overview

Variable Name	Description
DataMatrixDilateFilterSize	implicit dilation filter size while scanning (for bad print quality, e.g. dotcodes)

Communication Name	DCDMDilatIFltSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	363
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMDilatlFltSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDilatlFltSize	String	17	implicit dilation filter size while scanning (for bad print quality, e.g. dotcodes)

Read Variable Response:				
`sRA DCDMDilatlFltSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDilatlFltSize	String	17	implicit dilation filter size while scanning (for bad print quality, e.g. dotcodes)
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCDMDilatlFltSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDilatlFltSize	String	17	implicit dilation filter size while scanning (for bad print quality, e.g. dotcodes)
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCDMDilatlFltSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDilatlFltSize	String	17	implicit dilation filter size while scanning (for bad print quality, e.g. dotcodes)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMDilatlFltSize[ETX]`
Read Variable Response:	`[STX]sRA DCDMDilatlFltSize 0[ETX]`
Write Variable:	`[STX]sWN DCDMDilatlFltSize 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMDilatlFltSize[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.3. Variable: DataMatrixErodeFilterSize

The following section contains a detailed description of the variable DataMatrixErodeFilterSize.

Variable Overview

Variable Name	Description
DataMatrixErodeFilterSize	implicit erosion filter size while scanning (for bad print quality, e.g. dotcodes)

Communication Name	DCDMEroslFltSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	364
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCDMEroslFltSize
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMEroslFltSize	String	16	implicit erosion filter size while scanning (for bad print quality, e.g. dotcodes)

Read Variable Response:

```
sRA DCDMEroslFltSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMEroslFltSize	String	16	implicit erosion filter size while scanning (for bad print quality, e.g. dotcodes)
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCDMEroslFltSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMEroslFltSize	String	16	implicit erosion filter size while scanning (for bad print quality, e.g. dotcodes)
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMEroslFltSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMEroslFltSize	String	16	implicit erosion filter size while scanning (for bad print quality, e.g. dotcodes)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMEroslFltSize[ETX]
Read Variable Response:	[STX]sRA DCDMEroslFltSize 0[ETX]
Write Variable:	[STX]sWN DCDMEroslFltSize 0[ETX]
Write Variable Response:	[STX]sWA DCDMEroslFltSize[ETX]

2.13.2.4. Variable: DataMatrixDilateErodeWith2ndValue

The following section contains a detailed description of the variable DataMatrixDilateErodeWith2ndValue.

Variable Overview

Variable Name	Description
DataMatrixDilateErodeWith2ndValue	on dilate / erode take second max/min value if dilating/eroding if flag is set

Communication Name	DCDMFlt2ndVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	365
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMFlt2ndVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMFlt2ndVal	String	13	on dilate / erode take second max/min value if dilating/eroding if flag is set

Read Variable Response:				
`sRA DCDMFlt2ndVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMFlt2ndVal	String	13	on dilate / erode take second max/min value if dilating/eroding if flag is set
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMFlt2ndVal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMFlt2ndVal	String	13	on dilate / erode take second max/min value if dilating/eroding if flag is set
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMFlt2ndVal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMFlt2ndVal	String	13	on dilate / erode take second max/min value if dilating/eroding if flag is set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMFlt2ndVal[ETX]`
Read Variable Response:	`[STX]sRA DCDMFlt2ndVal 0[ETX]`
Write Variable:	`[STX]sWN DCDMFlt2ndVal 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMFlt2ndVal[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.5. Variable: DataMatrixWeakBitsEnabled

The following section contains a detailed description of the variable DataMatrixWeakBitsEnabled.

Variable Overview

Variable Name	Description
DataMatrixWeakBitsEnabled	enables or disables Weak Bits

Communication Name	DCDMWeakBitEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	366
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMWeakBitEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMWeakBitEna	String	14	enables or disables Weak Bits

Read Variable Response:

```
sRA DCDMWeakBitEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMWeakBitEna	String	14	enables or disables Weak Bits
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMWeakBitEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMWeakBitEna	String	14	enables or disables Weak Bits
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMWeakBitEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMWeakBitEna	String	14	enables or disables Weak Bits

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMWeakBitEna[ETX]`
Read Variable Response:	`[STX]sRA DCDMWeakBitEna 0[ETX]`
Write Variable:	`[STX]sWN DCDMWeakBitEna 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMWeakBitEna[ETX]`

2.13.2.6. Variable: DataMatrixPositiveDifferenceAllowed

The following section contains a detailed description of the variable DataMatrixPositiveDifferenceAllowed.

Variable Overview

Variable Name	Description
DataMatrixPositiveDifferenceAllowed	positive difference of grey-treshhold for weak bit allowed

Communication Name	DCDMPosDiffAllwd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	367
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

`sRN DCDMPosDiffAllwd`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMPosDiffAllwd	String	16	positive difference of grey-treshhold for weak bit allowed

Read Variable Response:

`sRA DCDMPosDiffAllwd <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMPosDiffAllwd	String	16	positive difference of grey-treshhold for weak bit allowed
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DCDMPosDiffAllwd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMPosDiffAllwd	String	16	positive difference of grey-treshhold for weak bit allowed
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMPosDiffAllwd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMPosDiffAllwd	String	16	positive difference of grey-treshhold for weak bit allowed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMPosDiffAllwd[ETX]`
Read Variable Response:	`[STX]sRA DCDMPosDiffAllwd 1[ETX]`
Write Variable:	`[STX]sWN DCDMPosDiffAllwd 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMPosDiffAllwd[ETX]`

2.13.2.7. Variable: DataMatrixNegativeDifferenceAllowed

The following section contains a detailed description of the variable DataMatrixNegativeDifferenceAllowed.

Variable Overview

Variable Name	Description
DataMatrixNegativeDifferenceAllowed	negative difference of grey-treshhold for weak bit allowed

Communication Name	DCDMNegDiffAllwd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	368
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMNegDiffAllwd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMNegDiffAllwd	String	16	negative difference of grey-treshhold for weak bit allowed

Read Variable Response:				
`sRA DCDMNegDiffAllwd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMNegDiffAllwd	String	16	negative difference of grey-treshhold for weak bit allowed
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMNegDiffAllwd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMNegDiffAllwd	String	16	negative difference of grey-treshhold for weak bit allowed
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMNegDiffAllwd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMNegDiffAllwd	String	16	negative difference of grey-treshhold for weak bit allowed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMNegDiffAllwd[ETX]`
Read Variable Response:	`[STX]sRA DCDMNegDiffAllwd 1[ETX]`
Write Variable:	`[STX]sWN DCDMNegDiffAllwd 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMNegDiffAllwd[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.8. Variable: DataMatrixNumWeakBitErrorBitsAllowed

The following section contains a detailed description of the variable DataMatrixNumWeakBitErrorBitsAllowed.

Variable Overview

Variable Name	Description
DataMatrixNumWeakBitErrorBitsAllowed	number of allowed Weak Bits for retries

Communication Name	DCDMWeakBitAllwd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	369
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCDMWeakBitAllwd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMWeakBitAllwd	String	16	number of allowed Weak Bits for retries

Read Variable Response:

```
sRA DCDMWeakBitAllwd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMWeakBitAllwd	String	16	number of allowed Weak Bits for retries
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCDMWeakBitAllwd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMWeakBitAllwd	String	16	number of allowed Weak Bits for retries
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DCDMWeakBitAllwd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMWeakBitAllwd	String	16	number of allowed Weak Bits for retries

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMWeakBitAllwd[ETX]`
Read Variable Response:	`[STX]sRA DCDMWeakBitAllwd 0[ETX]`
Write Variable:	`[STX]sWN DCDMWeakBitAllwd 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMWeakBitAllwd[ETX]`

2.13.2.9. Variable: DataMatrixWeakBitTreshhold

The following section contains a detailed description of the variable DataMatrixWeakBitTreshhold.

Variable Overview

Variable Name	Description
DataMatrixWeakBitTreshhold	within treshold detect weak bit

Communication Name	DCDMWeakBitThr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	370
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..100
Initialisation	30
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DCDMWeakBitThr`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMWeakBitThr	String	14	within treshold detect weak bit

Read Variable Response:

`sRA DCDMWeakBitThr <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMWeakBitThr	String	14	within treshold detect weak bit
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMWeakBitThr <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMWeakBitThr	String	14	within treshold detect weak bit
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCDMWeakBitThr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMWeakBitThr	String	14	within treshold detect weak bit

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMWeakBitThr[ETX]
Read Variable Response:	[STX]sRA DCDMWeakBitThr 1E[ETX]
Write Variable:	[STX]sWN DCDMWeakBitThr 1E[ETX]
Write Variable Response:	[STX]sWA DCDMWeakBitThr[ETX]

2.13.2.10. Variable: DataMatrixTolerateErrorsInLPattern

The following section contains a detailed description of the variable DataMatrixTolerateErrorsInLPattern.

Variable Overview

Variable Name	Description
DataMatrixTolerateErrorsInLPattern	tolerate errors when finding the L-pattern

Communication Name	DCDMTolErrLPat
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	371
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DM_SMALL_ERRORS_ALLOWED	
	Value	Name	Description
	0	TX_DM_SMALL_ERRORS_ALLOWED	
	1	TX_DM_BIG_ERRORS_ALLOWED	
	2	TX_DM_NO_ERRORS_ALLOWED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMTolErrLPat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMTolErrLPat	String	14	tolerate errors when finding the L-pattern

Read Variable Response:				
`sRA DCDMTolErrLPat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMTolErrLPat	String	14	tolerate errors when finding the L-pattern
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCDMTolErrLPat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMTolErrLPat	String	14	tolerate errors when finding the L-pattern
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCDMTolErrLPat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMTolErrLPat	String	14	tolerate errors when finding the L-pattern

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMTolErrLPat[ETX]`
Read Variable Response:	`[STX]sRA DCDMTolErrLPat 0[ETX]`
Write Variable:	`[STX]sWN DCDMTolErrLPat 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMTolErrLPat[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.11. Variable: DataMatrixTolerateErrorsInTimingPattern

The following section contains a detailed description of the variable DataMatrixTolerateErrorsInTimingPattern.

Variable Overview

Variable Name	Description
DataMatrixTolerateErrorsInTimingPattern	tolerate errors when scanning timing pattern

Communication Name	DCDMTolErrTPat
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	372
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMTolErrTPat
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMTolErrTPat	String	14	tolerate errors when scanning timing pattern

Read Variable Response:

```
sRA DCDMTolErrTPat <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMTolErrTPat	String	14	tolerate errors when scanning timing pattern
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMTolErrTPat <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMTolErrTPat	String	14	tolerate errors when scanning timing pattern
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMTolErrTPat
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMTolErrTPat	String	14	tolerate errors when scanning timing pattern

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMTolErrTPat[ETX]`
Read Variable Response:	`[STX]sRA DCDMTolErrTPat 0[ETX]`
Write Variable:	`[STX]sWN DCDMTolErrTPat 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMTolErrTPat[ETX]`

2.13.2.12. Variable: DataMatrixEnableSpeedOptimization

The following section contains a detailed description of the variable DataMatrixEnableSpeedOptimization.

Variable Overview

Variable Name	Description
DataMatrixEnableSpeedOptimization	flag for speed optimization (less scanlines)

Communication Name	DCDMSpeedOpt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	373
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMSpeedOpt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMSpeedOpt	String	12	flag for speed optimization (less scanlines)

Read Variable Response:

```
sRA DCDMSpeedOpt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMSpeedOpt	String	12	flag for speed optimization (less scanlines)
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMSpeedOpt <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMSpeedOpt	String	12	flag for speed optimization (less scanlines)
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCDMSpeedOpt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMSpeedOpt	String	12	flag for speed optimization (less scanlines)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMSpeedOpt[ETX]
Read Variable Response:	[STX]sRA DCDMSpeedOpt 0[ETX]
Write Variable:	[STX]sWN DCDMSpeedOpt 0[ETX]
Write Variable Response:	[STX]sWA DCDMSpeedOpt[ETX]

2.13.2.13. Variable: DataMatrixCheckSimpleLPatterns

The following section contains a detailed description of the variable DataMatrixCheckSimpleLPatterns.

Variable Overview

Variable Name	Description
DataMatrixCheckSimpleLPatterns	Speed-up using L-pattern adimistration

Communication Name	DCDMChckSmplL
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	375
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMChckSmplL`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMChckSmplL	String	13	Speed-up using L-pattern adimistration

Read Variable Response:				
`sRA DCDMChckSmplL <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMChckSmplL	String	13	Speed-up using L-pattern adimistration
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMChckSmplL <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMChckSmplL	String	13	Speed-up using L-pattern adimistration
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMChckSmplL`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMChckSmplL	String	13	Speed-up using L-pattern adimistration

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMChckSmplL[ETX]`
Read Variable Response:	`[STX]sRA DCDMChckSmplL 1[ETX]`
Write Variable:	`[STX]sWN DCDMChckSmplL 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMChckSmplL[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.14. Variable: DataMatrixTolerateLPatternDeformation

The following section contains a detailed description of the variable DataMatrixTolerateLPatternDeformation.

Variable Overview

Variable Name	Description
DataMatrixTolerateLPatternDeformation	Tolerate larger deformations in L-pattern

Communication Name	DCDMTolLDef
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	376
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMTolLDef
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMTolLDef	String	11	Tolerate larger deformations in L-pattern

Read Variable Response:

```
sRA DCDMTolLDef <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMTolLDef	String	11	Tolerate larger deformations in L-pattern
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMTolLDef <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMTolLDef	String	11	Tolerate larger deformations in L-pattern
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMTolLDef
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMTolLDef	String	11	Tolerate larger deformations in L-pattern

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMTolLDef[ETX]`
Read Variable Response:	`[STX]sRA DCDMTolLDef 0[ETX]`
Write Variable:	`[STX]sWN DCDMTolLDef 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMTolLDef[ETX]`

2.13.2.15. Variable: DataMatrixEnablePCBSpeedUp

The following section contains a detailed description of the variable DataMatrixEnablePCBSpeedUp.

Variable Overview

Variable Name	Description
DataMatrixEnablePCBSpeedUp	Flag for enabling speedup on PCBs and applications with many even structures

Communication Name	DCDMPCBSpdUp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	377
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMPCBSpdUp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMPCBSpdUp	String	12	Flag for enabling speedup on PCBs and applications with many even structures

Read Variable Response:

```
sRA DCDMPCBSpdUp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMPCBSpdUp	String	12	Flag for enabling speedup on PCBs and applications with many even structures
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DCDMPCBSpdUp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMPCBSpdUp	String	12	Flag for enabling speedup on PCBs and applications with many even structures
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMPCBSpdUp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMPCBSpdUp	String	12	Flag for enabling speedup on PCBs and applications with many even structures

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMPCBSpdUp[ETX]`
Read Variable Response:	`[STX]sRA DCDMPCBSpdUp 0[ETX]`
Write Variable:	`[STX]sWN DCDMPCBSpdUp 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMPCBSpdUp[ETX]`

2.13.2.16. Variable: DataMatrixEnableTextSpeedUp

The following section contains a detailed description of the variable DataMatrixEnableTextSpeedUp.

Variable Overview

Variable Name	Description
DataMatrixEnableTextSpeedUp	flag for enabling speedup on images with Streudruck (curved structures)

Communication Name	DCDMTxtSpdUp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	378
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMTxtSpdUp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMTxtSpdUp	String	12	flag for enabling speedup on images with Streudruck (curved structures)

Read Variable Response:				
`sRA DCDMTxtSpdUp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMTxtSpdUp	String	12	flag for enabling speedup on images with Streudruck (curved structures)
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMTxtSpdUp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMTxtSpdUp	String	12	flag for enabling speedup on images with Streudruck (curved structures)
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMTxtSpdUp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMTxtSpdUp	String	12	flag for enabling speedup on images with Streudruck (curved structures)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMTxtSpdUp[ETX]`
Read Variable Response:	`[STX]sRA DCDMTxtSpdUp 0[ETX]`
Write Variable:	`[STX]sWN DCDMTxtSpdUp 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMTxtSpdUp[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.17. Variable: DataMatrixRedundantCodes

The following section contains a detailed description of the variable DataMatrixRedundantCodes.

Variable Overview

Variable Name	Description
DataMatrixRedundantCodes	Enable to join code content from several redundant codes from one image

Communication Name	DCDMRedundantCodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	379
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMRedundantCodes
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMRedundantCodes	String	18	Enable to join code content from several redundant codes from one image

Read Variable Response:

```
sRA DCDMRedundantCodes <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMRedundantCodes	String	18	Enable to join code content from several redundant codes from one image
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMRedundantCodes <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMRedundantCodes	String	18	Enable to join code content from several redundant codes from one image
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMRedundantCodes
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMRedundantCodes				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCDMRedundantCodes	String	18	Enable to join code content from several redundant codes from one image

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMRedundantCodes[ETX]
Read Variable Response:	[STX]sRA DCDMRedundantCodes 0[ETX]
Write Variable:	[STX]sWN DCDMRedundantCodes 0[ETX]
Write Variable Response:	[STX]sWA DCDMRedundantCodes[ETX]

2.13.2.18. Variable: DataMatrixEnableNewSeg

The following section contains a detailed description of the variable DataMatrixEnableNewSeg.

Variable Overview

Variable Name	Description
DataMatrixEnableNewSeg	Flag for enabling new segmentation method

Communication Name	DCDMNewSegMthd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	380
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMNewSegMthd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMNewSegMthd	String	14	Flag for enabling new segmentation method

Read Variable Response:				
`sRA DCDMNewSegMthd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMNewSegMthd	String	14	Flag for enabling new segmentation method
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMNewSegMthd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMNewSegMthd	String	14	Flag for enabling new segmentation method
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMNewSegMthd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMNewSegMthd	String	14	Flag for enabling new segmentation method

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMNewSegMthd[ETX]`
Read Variable Response:	`[STX]sRA DCDMNewSegMthd 0[ETX]`
Write Variable:	`[STX]sWN DCDMNewSegMthd 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMNewSegMthd[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.19. Variable: DataMatrixNewSegAllowSingleTiles

The following section contains a detailed description of the variable DataMatrixNewSegAllowSingleTiles.

Variable Overview

Variable Name	Description
DataMatrixNewSegAllowSingleTiles	Allow single tiles used for small codes. May increase decoding time.

Communication Name	DCDMNewSegSingTil
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	381
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMNewSegSingTil
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMNewSegSingTil	String	17	Allow single tiles used for small codes. May increase decoding time.

Read Variable Response:

```
sRA DCDMNewSegSingTil <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMNewSegSingTil	String	17	Allow single tiles used for small codes. May increase decoding time.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMNewSegSingTil <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMNewSegSingTil	String	17	Allow single tiles used for small codes. May increase decoding time.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMNewSegSingTil
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMNewSegSingTil				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCDMNewSegSingTil	String	17	Allow single tiles used for small codes. May increase decoding time.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMNewSegSingTil[ETX]
Read Variable Response:	[STX]sRA DCDMNewSegSingTil 0[ETX]
Write Variable:	[STX]sWN DCDMNewSegSingTil 0[ETX]
Write Variable Response:	[STX]sWA DCDMNewSegSingTil[ETX]

2.13.2.20. Variable: DataMatrixFPGASpeedup

The following section contains a detailed description of the variable DataMatrixFPGASpeedup.

Variable Overview

Variable Name	Description
DataMatrixFPGASpeedup	use fpga data for speedup

Communication Name	DCDMFPGASpdUp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	383
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMFPGASpdUp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMFPGASpdUp	String	13	use fpga data for speedup

Read Variable Response:				
`sRA DCDMFPGASpdUp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMFPGASpdUp	String	13	use fpga data for speedup
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMFPGASpdUp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMFPGASpdUp	String	13	use fpga data for speedup
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMFPGASpdUp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMFPGASpdUp	String	13	use fpga data for speedup

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMFPGASpdUp[ETX]`
Read Variable Response:	`[STX]sRA DCDMFPGASpdUp 0[ETX]`
Write Variable:	`[STX]sWN DCDMFPGASpdUp 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMFPGASpdUp[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.21. Variable: DataMatrixMinModuleSize100

The following section contains a detailed description of the variable DataMatrixMinModuleSize100.

Variable Overview

Variable Name	Description
DataMatrixMinModuleSize100	min. module size in pixels multiplied with factor 100 for higher resolution

Communication Name	DCDMMinModSize100
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	384
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	100..4294967295
Initialisation	600
Physical Unit	1/100 pix
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCDMMinModSize100
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMMinModSize100	String	17	min. module size in pixels multiplied with factor 100 for higher resolution

Read Variable Response:

```
sRA DCDMMinModSize100 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMMinModSize100	String	17	min. module size in pixels multiplied with factor 100 for higher resolution
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCDMMinModSize100 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMMinModSize100	String	17	min. module size in pixels multiplied with factor 100 for higher resolution
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMMinModSize100				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMMinModSize100	String	17	min. module size in pixels multiplied with factor 100 for higher resolution

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMMinModSize100[ETX]
Read Variable Response:	[STX]sRA DCDMMinModSize100 258[ETX]
Write Variable:	[STX]sWN DCDMMinModSize100 258[ETX]
Write Variable Response:	[STX]sWA DCDMMinModSize100[ETX]

2.13.2.22. Variable: DataMatrixFormatMode

The following section contains a detailed description of the variable DataMatrixFormatMode.

Variable Overview

Variable Name	Description
DataMatrixFormatMode	Select between standard ECC200 and GS1 mode

Communication Name	DCDMFormatMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	385
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		FORMAT_ECC200	
	Value	Name	Description
	0	FORMAT_ECC200	
	1	FORMAT_GS1	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMFormatMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMFormatMode	String	14	Select between standard ECC200 and GS1 mode

Read Variable Response:				
`sRA DCDMFormatMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMFormatMode	String	14	Select between standard ECC200 and GS1 mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCDMFormatMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMFormatMode	String	14	Select between standard ECC200 and GS1 mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCDMFormatMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMFormatMode	String	14	Select between standard ECC200 and GS1 mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMFormatMode[ETX]`
Read Variable Response:	`[STX]sRA DCDMFormatMode 0[ETX]`
Write Variable:	`[STX]sWN DCDMFormatMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMFormatMode[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.23. Variable: DataMatrixGS1FirstCharReplacement

The following section contains a detailed description of the variable DataMatrixGS1FirstCharReplacement.

Variable Overview

Variable Name	Description
DataMatrixGS1FirstCharReplacement	maximal 4 characters the first FNC1 character should be replaced with

Communication Name	DCDMGS1FirstCharReplace
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	386
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..16
Initialisation	]d2

Variable Telegram Syntax

Read Variable:

```
sRN DCDMGS1FirstCharReplace
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with

Read Variable Response:

```
sRA DCDMGS1FirstCharReplace <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with
Variable Data	data	FlexString	16	

Write Variable:

```
sWN DCDMGS1FirstCharReplace <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with
Variable Data	data	FlexString	16	

Write Variable Response:

```
sWA DCDMGS1FirstCharReplace
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMGS1FirstCharReplace				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCDMGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMGS1FirstCharReplace[ETX]
Read Variable Response:	[STX]sRA DCDMGS1FirstCharReplace 3]d2[ETX]
Write Variable:	[STX]sWN DCDMGS1FirstCharReplace 3]d2[ETX]
Write Variable Response:	[STX]sWA DCDMGS1FirstCharReplace[ETX]

2.13.2.24. Variable: DataMatrixGS1SeparatorCharReplacement

The following section contains a detailed description of the variable DataMatrixGS1SeparatorCharReplacement.

Variable Overview

Variable Name	Description
DataMatrixGS1SeparatorCharReplacement	maximal 4 characters the GS (group separator) characters should be replaced with

Communication Name	DCDMGS1SepCharReplace
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	387
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..16
Initialisation	\x1d

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMGS1SepCharReplace`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with

Read Variable Response:				
`sRA DCDMGS1SepCharReplace <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with
Variable Data	data	FlexString	16	

Write Variable:				
`sWN DCDMGS1SepCharReplace <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with
Variable Data	data	FlexString	16	

Write Variable Response:				
`sWA DCDMGS1SepCharReplace`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMGS1SepCharReplace[ETX]`
Read Variable Response:	`[STX]sRA DCDMGS1SepCharReplace 4 \x1d[ETX]`
Write Variable:	`[STX]sWN DCDMGS1SepCharReplace 4 \x1d[ETX]`
Write Variable Response:	`[STX]sWA DCDMGS1SepCharReplace[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.25. Variable: DataMatrixGS1AIMarking

The following section contains a detailed description of the variable DataMatrixGS1AIMarking.

Variable Overview

Variable Name	Description
DataMatrixGS1AIMarking	GS Datamatrix AI Marking active or not

Communication Name	DCDMGS1AIMark
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	388
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMGS1AIMark
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMGS1AIMark	String	13	GS Datamatrix AI Marking active or not

Read Variable Response:

```
sRA DCDMGS1AIMark <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMGS1AIMark	String	13	GS Datamatrix AI Marking active or not
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMGS1AIMark <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMGS1AIMark	String	13	GS Datamatrix AI Marking active or not
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMGS1AIMark
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMGS1AIMark	String	13	GS Datamatrix AI Marking active or not

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMGS1AIMark[ETX]`
Read Variable Response:	`[STX]sRA DCDMGS1AIMark 0[ETX]`
Write Variable:	`[STX]sWN DCDMGS1AIMark 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMGS1AIMark[ETX]`

2.13.2.26. Variable: DataMatrixVerISO16022

The following section contains a detailed description of the variable DataMatrixVerISO16022.

Variable Overview

Variable Name	Description
DataMatrixVerISO16022	flag if dmx verification IS016022 should be computed

Communication Name	DCDMVerISO16022
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	389
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN DCDMVerISO16022`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMVerISO16022	String	15	flag if dmx verification IS016022 should be computed

Read Variable Response:				
`sRA DCDMVerISO16022 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMVerISO16022	String	15	flag if dmx verification IS016022 should be computed
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMVerISO16022 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMVerISO16022	String	15	flag if dmx verification IS016022 should be computed
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCDMVerISO16022				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMVerISO16022	String	15	flag if dmx verification IS016022 should be computed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMVerISO16022[ETX]
Read Variable Response:	[STX]sRA DCDMVerISO16022 1[ETX]
Write Variable:	[STX]sWN DCDMVerISO16022 1[ETX]
Write Variable Response:	[STX]sWA DCDMVerISO16022[ETX]

2.13.2.27. Variable: DataMatrixVerISO15415

The following section contains a detailed description of the variable DataMatrixVerISO15415.

Variable Overview

Variable Name	Description
DataMatrixVerISO15415	flag if dmx verification ISO15415 should be computed

Communication Name	DCDMVerISO15415
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	390
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMVerISO15415`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMVerISO15415	String	15	flag if dmx verification ISO15415 should be computed

Read Variable Response:				
`sRA DCDMVerISO15415 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMVerISO15415	String	15	flag if dmx verification ISO15415 should be computed
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMVerISO15415 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMVerISO15415	String	15	flag if dmx verification ISO15415 should be computed
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMVerISO15415`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMVerISO15415	String	15	flag if dmx verification ISO15415 should be computed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMVerISO15415[ETX]`
Read Variable Response:	`[STX]sRA DCDMVerISO15415 0[ETX]`
Write Variable:	`[STX]sWN DCDMVerISO15415 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMVerISO15415[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.28. Variable: DataMatrixFullRescan

The following section contains a detailed description of the variable DataMatrixFullRescan.

Variable Overview

Variable Name
DataMatrixFullRescan

Communication Name	DCDMFullRescn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	391
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMFullRescn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMFullRescn	String	13	

Read Variable Response:

```
sRA DCDMFullRescn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMFullRescn	String	13	
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMFullRescn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMFullRescn	String	13	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMFullRescn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMFullRescn	String	13	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMFullRescn[ETX]`
Read Variable Response:	`[STX]sRA DCDMFullRescn 0[ETX]`
Write Variable:	`[STX]sWN DCDMFullRescn 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMFullRescn[ETX]`

2.13.2.29. Variable: DataMatrixRescanTPattern

The following section contains a detailed description of the variable DataMatrixRescanTPattern.

Variable Overview

Variable Name
DataMatrixRescanTPattern

Communication Name	DCDMRescnTPat
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	392
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCDMRescnTPat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMRescnTPat	String	13	

Read Variable Response:				
`sRA DCDMRescnTPat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMRescnTPat	String	13	
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMRescnTPat <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMRescnTPat	String	13	
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCDMRescnTPat				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMRescnTPat	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMRescnTPat[ETX]
Read Variable Response:	[STX]sRA DCDMRescnTPat 0[ETX]
Write Variable:	[STX]sWN DCDMRescnTPat 0[ETX]
Write Variable Response:	[STX]sWA DCDMRescnTPat[ETX]

2.13.2.30. Variable: DataMatrixDefectCorrection

The following section contains a detailed description of the variable DataMatrixDefectCorrection.

Variable Overview

Variable Name
DataMatrixDefectCorrection

Communication Name	DCDMDefCorr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	393
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMDefCorr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDefCorr	String	11	

Read Variable Response:				
`sRA DCDMDefCorr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDefCorr	String	11	
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMDefCorr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDefCorr	String	11	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMDefCorr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDefCorr	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMDefCorr[ETX]`
Read Variable Response:	`[STX]sRA DCDMDefCorr 0[ETX]`
Write Variable:	`[STX]sWN DCDMDefCorr 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMDefCorr[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.31. Variable: DataMatrixGeoEstimation

The following section contains a detailed description of the variable DataMatrixGeoEstimation.

Variable Overview

Variable Name
DataMatrixGeoEstimation

Communication Name	DCDMGeoEst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	394
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMGeoEst
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMGeoEst	String	10	

Read Variable Response:

```
sRA DCDMGeoEst <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMGeoEst	String	10	
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMGeoEst <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMGeoEst	String	10	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMGeoEst
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMGeoEst	String	10	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMGeoEst[ETX]`
Read Variable Response:	`[STX]sRA DCDMGeoEst 0[ETX]`
Write Variable:	`[STX]sWN DCDMGeoEst 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMGeoEst[ETX]`

2.13.2.32. Variable: DataMatrixConstructiveGrid

The following section contains a detailed description of the variable DataMatrixConstructiveGrid.

Variable Overview

Variable Name
DataMatrixConstructiveGrid

Communication Name	DCDMConstGrd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	395
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DCDMConstGrd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMConstGrd	String	12	

Read Variable Response:				
`sRA DCDMConstGrd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMConstGrd	String	12	
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMConstGrd <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMConstGrd	String	12	
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCDMConstGrd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMConstGrd	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMConstGrd[ETX]
Read Variable Response:	[STX]sRA DCDMConstGrd 0[ETX]
Write Variable:	[STX]sWN DCDMConstGrd 0[ETX]
Write Variable Response:	[STX]sWA DCDMConstGrd[ETX]

2.13.2.33. Variable: DataMatrixFilterSamplePoints

The following section contains a detailed description of the variable DataMatrixFilterSamplePoints.

Variable Overview

Variable Name
DataMatrixFilterSamplePoints

Communication Name	DCDMFilterSmplPnts
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	396
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMFilterSmplPnts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMFilterSmplPnts	String	18	

Read Variable Response:				
`sRA DCDMFilterSmplPnts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMFilterSmplPnts	String	18	
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMFilterSmplPnts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMFilterSmplPnts	String	18	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMFilterSmplPnts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMFilterSmplPnts	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMFilterSmplPnts[ETX]`
Read Variable Response:	`[STX]sRA DCDMFilterSmplPnts 0[ETX]`
Write Variable:	`[STX]sWN DCDMFilterSmplPnts 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMFilterSmplPnts[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.34. Variable: DataMatrixExcludeCodeAreas

The following section contains a detailed description of the variable DataMatrixExcludeCodeAreas.

Variable Overview

Variable Name
DataMatrixExcludeCodeAreas

Communication Name	DCDMExCdArs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	397
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMExCdArs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMExCdArs	String	11	

Read Variable Response:

```
sRA DCDMExCdArs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMExCdArs	String	11	
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMExCdArs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMExCdArs	String	11	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMExCdArs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMExCdArs	String	11	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMExCdArs[ETX]`
Read Variable Response:	`[STX]sRA DCDMExCdArs 0[ETX]`
Write Variable:	`[STX]sWN DCDMExCdArs 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMExCdArs[ETX]`

2.13.2.35. Variable: DataMatrixDotActive

The following section contains a detailed description of the variable DataMatrixDotActive.

Variable Overview

Variable Name	Description
DataMatrixDotActive	Activates DataMatrix Decoder for dot peened codes

Communication Name	DCDMDotAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	398
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCDMDotAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotAct	String	10	Activates DataMatrix Decoder for dot peened codes

Read Variable Response:

```
sRA DCDMDotAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotAct	String	10	Activates DataMatrix Decoder for dot peened codes
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMDotAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotAct	String	10	Activates DataMatrix Decoder for dot peened codes
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCDMDotAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotAct	String	10	Activates DataMatrix Decoder for dot peened codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMDotAct[ETX]
Read Variable Response:	[STX]sRA DCDMDotAct 0[ETX]
Write Variable:	[STX]sWN DCDMDotAct 0[ETX]
Write Variable Response:	[STX]sWA DCDMDotAct[ETX]

2.13.2.36. Variable: DataMatrixDotPolarity

The following section contains a detailed description of the variable DataMatrixDotPolarity.

Variable Overview

Variable Name	Description
DataMatrixDotPolarity	Polarity black dots on white background or reverse

Communication Name	DCDMDotPol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	399
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		WHITE_DOT_ON_BLACK	
	Value	Name	Description
	0	BLACK_DOT_ON_WHITE	
	1	WHITE_DOT_ON_BLACK	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMDotPol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotPol	String	10	Polarity black dots on white background or reverse

Read Variable Response:				
`sRA DCDMDotPol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotPol	String	10	Polarity black dots on white background or reverse
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCDMDotPol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotPol	String	10	Polarity black dots on white background or reverse
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCDMDotPol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotPol	String	10	Polarity black dots on white background or reverse

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMDotPol[ETX]`
Read Variable Response:	`[STX]sRA DCDMDotPol 1[ETX]`
Write Variable:	`[STX]sWN DCDMDotPol 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMDotPol[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.37. Variable: DataMatrixDotIntegralBlobSearch

The following section contains a detailed description of the variable DataMatrixDotIntegralBlobSearch.

Variable Overview

Variable Name
DataMatrixDotIntegralBlobSearch

Communication Name	DCDMDotIntBlob
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	400
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCDMDotIntBlob
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotIntBlob	String	14	

Read Variable Response:

```
sRA DCDMDotIntBlob <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotIntBlob	String	14	
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMDotIntBlob <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotIntBlob	String	14	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMDotIntBlob
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotIntBlob	String	14	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMDotIntBlob[ETX]`
Read Variable Response:	`[STX]sRA DCDMDotIntBlob 1[ETX]`
Write Variable:	`[STX]sWN DCDMDotIntBlob 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMDotIntBlob[ETX]`

2.13.2.38. Variable: DataMatrixDotBlobSensitivity

The following section contains a detailed description of the variable DataMatrixDotBlobSensitivity.

Variable Overview

Variable Name	Description
DataMatrixDotBlobSensitivity	threshold for blob detection

Communication Name	DCDMDotBlbSens
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	401
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..100
Initialisation	60
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DCDMDotBlbSens`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotBlbSens	String	14	threshold for blob detection

Read Variable Response:

`sRA DCDMDotBlbSens <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotBlbSens	String	14	threshold for blob detection
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMDotBlbSens <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotBlbSens	String	14	threshold for blob detection
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCDMDotBlbSens				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotBlbSens	String	14	threshold for blob detection

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMDotBlbSens[ETX]
Read Variable Response:	[STX]sRA DCDMDotBlbSens 3C[ETX]
Write Variable:	[STX]sWN DCDMDotBlbSens 3C[ETX]
Write Variable Response:	[STX]sWA DCDMDotBlbSens[ETX]

2.13.2.39. Variable: DataMatrixDotFilterBlobSearch

The following section contains a detailed description of the variable DataMatrixDotFilterBlobSearch.

Variable Overview

Variable Name
DataMatrixDotFilterBlobSearch

Communication Name	DCDMDotFilterBlob
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	402
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMDotFilterBlob`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotFilterBlob	String	17	

Read Variable Response:				
`sRA DCDMDotFilterBlob <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotFilterBlob	String	17	
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMDotFilterBlob <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotFilterBlob	String	17	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMDotFilterBlob`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotFilterBlob	String	17	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMDotFilterBlob[ETX]`
Read Variable Response:	`[STX]sRA DCDMDotFilterBlob 0[ETX]`
Write Variable:	`[STX]sWN DCDMDotFilterBlob 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMDotFilterBlob[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.40. Variable: DataMatrixDotDiameter

The following section contains a detailed description of the variable DataMatrixDotDiameter.

Variable Overview

Variable Name	Description
DataMatrixDotDiameter	Dot diameter in mm

Communication Name	DCDMDotDiam
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	403
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.025..10.0
Initialisation	0.2
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCDMDotDiam
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotDiam	String	11	Dot diameter in mm

Read Variable Response:

```
sRA DCDMDotDiam <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotDiam	String	11	Dot diameter in mm
Variable Data	data	Real	4	

Write Variable:

```
sWN DCDMDotDiam <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotDiam	String	11	Dot diameter in mm
Variable Data	data	Real	4	

Write Variable Response:

```
sWA DCDMDotDiam
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotDiam	String	11	Dot diameter in mm

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMDotDiam[ETX]`
Read Variable Response:	`[STX]sRA DCDMDotDiam 3E4CCCCD[ETX]`
Write Variable:	`[STX]sWN DCDMDotDiam 3E4CCCCD[ETX]`
Write Variable Response:	`[STX]sWA DCDMDotDiam[ETX]`

2.13.2.41. Variable: DataMatrixDotSymbolGeometry

The following section contains a detailed description of the variable DataMatrixDotSymbolGeometry.

Variable Overview

Variable Name	Description
DataMatrixDotSymbolGeometry	Shape of the dots - Squared, Rect or both

Communication Name	DCDMDotSym
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	404
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		DOT_SYMBOL_SQUARED	
	Value	Name	Description
	0	DOT_SYMBOL_SQUARED	
	1	DOT_SYMBOL_RECT	
	2	DOT_SYMBOL_BOTH	

Variable Telegram Syntax

Read Variable:				
`sRN DCDMDotSym`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMDotSym	String	10	Shape of the dots - Squared, Rect or both

Read Variable Response:				
`sRA DCDMDotSym <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMDotSym	String	10	Shape of the dots - Squared, Rect or both
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCDMDotSym <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMDotSym	String	10	Shape of the dots - Squared, Rect or both
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCDMDotSym				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMDotSym	String	10	Shape of the dots - Squared, Rect or both

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMDotSym[ETX]
Read Variable Response:	[STX]sRA DCDMDotSym 0[ETX]
Write Variable:	[STX]sWN DCDMDotSym 0[ETX]
Write Variable Response:	[STX]sWA DCDMDotSym[ETX]

2.13.2.42. Variable: DataMatrixLengthMode

The following section contains a detailed description of the variable DataMatrixLengthMode.

Variable Overview

Variable Name	Description
DataMatrixLengthMode	Codelength mode of DataMatrix

Communication Name	DCDMLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	360
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_Fix	
	Value	Name	Description
	0	TX_Free	
	1	TX_Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMLenMode	String	11	Codelength mode of DataMatrix

Read Variable Response:				
`sRA DCDMLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMLenMode	String	11	Codelength mode of DataMatrix
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCDMLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMLenMode	String	11	Codelength mode of DataMatrix
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCDMLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMLenMode	String	11	Codelength mode of DataMatrix

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCDMLenMode 1[ETX]`
Write Variable:	`[STX]sWN DCDMLenMode 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.13.2.43. Variable: DataMatrixActive

The following section contains a detailed description of the variable DataMatrixActive.

Variable Overview

Variable Name	Description
DataMatrixActive	Activates DataMatrix Decoder

Communication Name	DCDMAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	359
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCDMAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMAct	String	7	Activates DataMatrix Decoder

Read Variable Response:

```
sRA DCDMAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMAct	String	7	Activates DataMatrix Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCDMAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMAct	String	7	Activates DataMatrix Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCDMAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMAct	String	7	Activates DataMatrix Decoder

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMAct[ETX]`
Read Variable Response:	`[STX]sRA DCDMAct 1[ETX]`
Write Variable:	`[STX]sWN DCDMAct 1[ETX]`
Write Variable Response:	`[STX]sWA DCDMAct[ETX]`

2.13.2.44. Variable: DataMatrixFixLenList

The following section contains a detailed description of the variable DataMatrixFixLenList.

Variable Overview

Variable Name	Description
DataMatrixFixLenList	List of code lengths in X direction

Communication Name	DCDMFixLenX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	361
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Array	
Length	5
Default Value	{3,0,0,0,0}
Enum8	

© SICK AG - Germany - All rights reserved

Array				
		Value	Name	Description
		0	TX_NONE	
		1	TX_10_10	
		2	TX_12_12	
		3	TX_14_14	
		4	TX_16_16	
		5	TX_18_18	
		6	TX_20_20	
		7	TX_22_22	
		8	TX_24_24	
		9	TX_26_26	
		10	TX_32_32	
		11	TX_36_36	
		12	TX_40_40	
		13	TX_44_44	
		14	TX_48_48	
		15	TX_52_52	
		16	TX_64_64	
		17	TX_72_72	
		18	TX_80_80	
		19	TX_88_88	
		20	TX_96_96	
		21	TX_104_104	
		22	TX_120_120	
		23	TX_132_132	
		24	TX_144_144	
		25	TX_18_8	
		26	TX_32_8	
		31	TX_48_8	
		32	TX_64_8	
		Error in PreAllocation		
		27	TX_26_12	
		Error in PreAllocation		
		28	TX_36_12	
		Error in PreAllocation		
		33	TX_64_12	
		Error in PreAllocation		
		29	TX_36_16	
		Error in PreAllocation		
		30	TX_48_16	
		Error in PreAllocation		
		34	TX_64_16	
		Error in PreAllocation		
		35	TX_32_24	
		Error in PreAllocation		
		36	TX_36_24	
		Error in PreAllocation		
		37	TX_48_24	
		Error in PreAllocation		
		38	TX_64_24	
		Error in PreAllocation		
		39	TX_32_26	
		Error in PreAllocation		
		40	TX_40_26	

© SICK AG - Germany - All rights reserved

Array				
		Error in PreAllocation		
		41	TX_48_26	
		Error in PreAllocation		
		42	TX_64_26	

Variable Telegram Syntax

Read Variable:				
sRN DCDMFixLenX				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMFixLenX	String	11	List of code lengths in X direction

Read Variable Response:				
sRA DCDMFixLenX <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMFixLenX	String	11	List of code lengths in X direction
Variable Data	data	Array	5	

Write Variable:				
sWN DCDMFixLenX <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMFixLenX	String	11	List of code lengths in X direction
Variable Data	data	Array	5	

Write Variable Response:				
sWA DCDMFixLenX				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMFixLenX	String	11	List of code lengths in X direction

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMFixLenX[ETX]
Read Variable Response:	[STX]sRA DCDMFixLenX 3 0 0 0 0[ETX]
Write Variable:	[STX]sWN DCDMFixLenX 3 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA DCDMFixLenX[ETX]

© SICK AG - Germany - All rights reserved

2.13.2.45. Variable: DataMatrixAggressivityLevel

The following section contains a detailed description of the variable DataMatrixAggressivityLevel.

Variable Overview

Variable Name	Description
DataMatrixAggressivityLevel	Aggressivity level, controls number of methods and retries to find codes

Communication Name	DCDMAggrLvl
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	382
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		AGGRLVL_3	
	Value	Name	Description
	0	AGGRLVL_1	
	2	AGGRLVL_3	

Variable Telegram Syntax

Read Variable:				
`sRN DCDMAggrLvl`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMAggrLvl	String	11	Aggressivity level, controls number of methods and retries to find codes

Read Variable Response:				
`sRA DCDMAggrLvl <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMAggrLvl	String	11	Aggressivity level, controls number of methods and retries to find codes
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCDMAggrLvl <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMAggrLvl	String	11	Aggressivity level, controls number of methods and retries to find codes
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCDMAggrLvl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMAggrLvl	String	11	Aggressivity level, controls number of methods and retries to find codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCDMAggrLvl[ETX]
Read Variable Response:	[STX]sRA DCDMAggrLvl 2[ETX]
Write Variable:	[STX]sWN DCDMAggrLvl 2[ETX]
Write Variable Response:	[STX]sWA DCDMAggrLvl[ETX]

2.13.2.46. Variable: DataMatrixAllowRect

The following section contains a detailed description of the variable DataMatrixAllowRect.

Variable Overview

Variable Name	Description
DataMatrixAllowRect	Allow data matrix code with rectangular fields

Communication Name	DCDMRctFld
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	374
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCDMRctFld`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCDMRctFld	String	10	Allow data matrix code with rectangular fields

Read Variable Response:				
`sRA DCDMRctFld <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCDMRctFld	String	10	Allow data matrix code with rectangular fields
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCDMRctFld <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCDMRctFld	String	10	Allow data matrix code with rectangular fields
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCDMRctFld`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCDMRctFld	String	10	Allow data matrix code with rectangular fields

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCDMRctFld[ETX]`
Read Variable Response:	`[STX]sRA DCDMRctFld 0[ETX]`
Write Variable:	`[STX]sWN DCDMRctFld 0[ETX]`
Write Variable Response:	`[STX]sWA DCDMRctFld[ETX]`

© SICK AG - Germany - All rights reserved

2.13.3. Group: DecodingPDF417

2.13.3.1. Variable: PDF417Active

The following section contains a detailed description of the variable PDF417Active.

Variable Overview

Variable Name	Description
PDF417Active	Activates PDF417 Decoder

Communication Name	DCPDF417Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	405
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCPDF417Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPDF417Act	String	11	Activates PDF417 Decoder

Read Variable Response:

```
sRA DCPDF417Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPDF417Act	String	11	Activates PDF417 Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCPDF417Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPDF417Act	String	11	Activates PDF417 Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCPDF417Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCPDF417Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPDF417Act	String	11	Activates PDF417 Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPDF417Act[ETX]
Read Variable Response:	[STX]sRA DCPDF417Act 0[ETX]
Write Variable:	[STX]sWN DCPDF417Act 0[ETX]
Write Variable Response:	[STX]sWA DCPDF417Act[ETX]

2.13.3.2. Variable: PDF417Truncated

The following section contains a detailed description of the variable PDF417Truncated.

Variable Overview

Variable Name	Description
PDF417Truncated	Allow truncated PDF417 codes

Communication Name	DCPDF417Tru
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	406
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCPDF417Tru`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPDF417Tru	String	11	Allow truncated PDF417 codes

Read Variable Response:				
`sRA DCPDF417Tru <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPDF417Tru	String	11	Allow truncated PDF417 codes
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCPDF417Tru <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCPDF417Tru	String	11	Allow truncated PDF417 codes
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCPDF417Tru`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPDF417Tru	String	11	Allow truncated PDF417 codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCPDF417Tru[ETX]`
Read Variable Response:	`[STX]sRA DCPDF417Tru 0[ETX]`
Write Variable:	`[STX]sWN DCPDF417Tru 0[ETX]`
Write Variable Response:	`[STX]sWA DCPDF417Tru[ETX]`

© SICK AG - Germany - All rights reserved

2.13.3.3. Variable: PDF417DecodingLevel

The following section contains a detailed description of the variable PDF417DecodingLevel.

Variable Overview

Variable Name	Description
PDF417DecodingLevel	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Communication Name	DCPDF417Lvl
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	407
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Aggressive	
	Value	Name	Description
	0	Fast	
	1	Balanced	
	2	Aggressive	
	3	VeryAggressive	

Variable Telegram Syntax

Read Variable:

```
sRN DCPDF417Lvl
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCPDF417Lvl	String	11	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Read Variable Response:

```
sRA DCPDF417Lvl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCPDF417Lvl	String	11	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCPDF417Lvl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCPDF417Lvl <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCPDF417Lvl	String	11	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DCPDF417Lvl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCPDF417Lvl	String	11	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCPDF417Lvl[ETX]
Read Variable Response:	[STX]sRA DCPDF417Lvl 2[ETX]
Write Variable:	[STX]sWN DCPDF417Lvl 2[ETX]
Write Variable Response:	[STX]sWA DCPDF417Lvl[ETX]

© SICK AG - Germany - All rights reserved

2.13.4. Group: DecodingMaxiCode

2.13.4.1. Variable: MaxiCodeActive

The following section contains a detailed description of the variable MaxiCodeActive.

Variable Overview

Variable Name	Description
MaxiCodeActive	Activates MaxiCode Decoder

Communication Name	DCMCAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	408
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCMCAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCAct	String	7	Activates MaxiCode Decoder

Read Variable Response:

```
sRA DCMCAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCAct	String	7	Activates MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCMCAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCAct	String	7	Activates MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCMCAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCMCAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCMCAct	String	7	Activates MaxiCode Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCMCAct[ETX]
Read Variable Response:	[STX]sRA DCMCAct 0[ETX]
Write Variable:	[STX]sWN DCMCAct 0[ETX]
Write Variable Response:	[STX]sWA DCMCAct[ETX]

2.13.4.2. Variable: MaxiCodePrimaryMessage

The following section contains a detailed description of the variable MaxiCodePrimaryMessage.

Variable Overview

Variable Name
MaxiCodePrimaryMessage

Communication Name	DCMCMdPM
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	414
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCMCMdPM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCMdPM	String	8	

Read Variable Response:				
`sRA DCMCMdPM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCMdPM	String	8	
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCMCMdPM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCMdPM	String	8	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCMCMdPM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCMdPM	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMCMdPM[ETX]`
Read Variable Response:	`[STX]sRA DCMCMdPM 1[ETX]`
Write Variable:	`[STX]sWN DCMCMdPM 1[ETX]`
Write Variable Response:	`[STX]sWA DCMCMdPM[ETX]`

© SICK AG - Germany - All rights reserved

2.13.4.3. Variable: MaxiCodeVerifierEnable

The following section contains a detailed description of the variable MaxiCodeVerifierEnable.

Variable Overview

Variable Name
MaxiCodeVerifierEnable

Communication Name	DCMCVeriEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	415
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN DCMCVeriEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCVeriEna	String	11	

Read Variable Response:				
`sRA DCMCVeriEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCVeriEna	String	11	
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCMCVeriEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCVeriEna	String	11	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCMCVeriEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCVeriEna	String	11	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMCVeriEna[ETX]`
Read Variable Response:	`[STX]sRA DCMCVeriEna 1[ETX]`
Write Variable:	`[STX]sWN DCMCVeriEna 1[ETX]`
Write Variable Response:	`[STX]sWA DCMCVeriEna[ETX]`

2.13.4.4. Variable: MaxiCodeMode2Active

The following section contains a detailed description of the variable MaxiCodeMode2Active.

Variable Overview

Variable Name	Description
MaxiCodeMode2Active	Activates the mode 2 in MaxiCode Decoder

Communication Name	DCMCMd2Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	409
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCMCMd2Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCMd2Act	String	10	Activates the mode 2 in MaxiCode Decoder

Read Variable Response:

```
sRA DCMCMd2Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCMd2Act	String	10	Activates the mode 2 in MaxiCode Decoder
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCMCMd2Act <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCMd2Act	String	10	Activates the mode 2 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCMCMd2Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCMd2Act	String	10	Activates the mode 2 in MaxiCode Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCMCMd2Act[ETX]
Read Variable Response:	[STX]sRA DCMCMd2Act 0[ETX]
Write Variable:	[STX]sWN DCMCMd2Act 0[ETX]
Write Variable Response:	[STX]sWA DCMCMd2Act[ETX]

2.13.4.5. Variable: MaxiCodeMode6Active

The following section contains a detailed description of the variable MaxiCodeMode6Active.

Variable Overview

Variable Name	Description
MaxiCodeMode6Active	Activates the mode 6 in MaxiCode Decoder

Communication Name	DCMCMd6Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	413
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCMCMd6Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCMd6Act	String	10	Activates the mode 6 in MaxiCode Decoder

Read Variable Response:				
`sRA DCMCMd6Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCMd6Act	String	10	Activates the mode 6 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCMCMd6Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCMd6Act	String	10	Activates the mode 6 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCMCMd6Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCMd6Act	String	10	Activates the mode 6 in MaxiCode Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMCMd6Act[ETX]`
Read Variable Response:	`[STX]sRA DCMCMd6Act 0[ETX]`
Write Variable:	`[STX]sWN DCMCMd6Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCMCMd6Act[ETX]`

© SICK AG - Germany - All rights reserved

2.13.4.6. Variable: MaxiCodeMode4Active

The following section contains a detailed description of the variable MaxiCodeMode4Active.

Variable Overview

Variable Name	Description
MaxiCodeMode4Active	Activates the mode 4 in MaxiCode Decoder

Communication Name	DCMCMd4Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	411
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCMCMd4Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCMd4Act	String	10	Activates the mode 4 in MaxiCode Decoder

Read Variable Response:

```
sRA DCMCMd4Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCMd4Act	String	10	Activates the mode 4 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCMCMd4Act <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCMd4Act	String	10	Activates the mode 4 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCMCMd4Act
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCMd4Act	String	10	Activates the mode 4 in MaxiCode Decoder

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMCMd4Act[ETX]`
Read Variable Response:	`[STX]sRA DCMCMd4Act 0[ETX]`
Write Variable:	`[STX]sWN DCMCMd4Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCMCMd4Act[ETX]`

2.13.4.7. Variable: MaxiCodeMode5Active

The following section contains a detailed description of the variable MaxiCodeMode5Active.

Variable Overview

Variable Name	Description
MaxiCodeMode5Active	Activates the mode 5 in MaxiCode Decoder

Communication Name	DCMCMd5Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	412
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

`sRN DCMCMd5Act`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCMd5Act	String	10	Activates the mode 5 in MaxiCode Decoder

Read Variable Response:

`sRA DCMCMd5Act <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCMd5Act	String	10	Activates the mode 5 in MaxiCode Decoder
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCMCMd5Act <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCMd5Act	String	10	Activates the mode 5 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DCMCMd5Act				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCMd5Act	String	10	Activates the mode 5 in MaxiCode Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCMCMd5Act[ETX]
Read Variable Response:	[STX]sRA DCMCMd5Act 0[ETX]
Write Variable:	[STX]sWN DCMCMd5Act 0[ETX]
Write Variable Response:	[STX]sWA DCMCMd5Act[ETX]

2.13.4.8. Variable: MaxiCodeMode3Active

The following section contains a detailed description of the variable MaxiCodeMode3Active.

Variable Overview

Variable Name	Description
MaxiCodeMode3Active	Activates the mode 3 in MaxiCode Decoder

Communication Name	DCMCMd3Act
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	410
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCMCMd3Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCMCMd3Act	String	10	Activates the mode 3 in MaxiCode Decoder

Read Variable Response:				
`sRA DCMCMd3Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCMCMd3Act	String	10	Activates the mode 3 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCMCMd3Act <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCMCMd3Act	String	10	Activates the mode 3 in MaxiCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCMCMd3Act`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCMCMd3Act	String	10	Activates the mode 3 in MaxiCode Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCMCMd3Act[ETX]`
Read Variable Response:	`[STX]sRA DCMCMd3Act 0[ETX]`
Write Variable:	`[STX]sWN DCMCMd3Act 0[ETX]`
Write Variable Response:	`[STX]sWA DCMCMd3Act[ETX]`

© SICK AG - Germany - All rights reserved

2.13.5. Group: DecodingQRCode

2.13.5.1. Variable: QRCodeActive

The following section contains a detailed description of the variable QRCodeActive.

Variable Overview

Variable Name	Description
QRCodeActive	Activates QRCode Decoder

Communication Name	DCQRAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	419
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCQRAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRAct	String	7	Activates QRCode Decoder

Read Variable Response:

```
sRA DCQRAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRAct	String	7	Activates QRCode Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCQRAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRAct	String	7	Activates QRCode Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCQRAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCQRAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCQRAct	String	7	Activates QRCode Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCQRAct[ETX]
Read Variable Response:	[STX]sRA DCQRAct 0[ETX]
Write Variable:	[STX]sWN DCQRAct 0[ETX]
Write Variable Response:	[STX]sWA DCQRAct[ETX]

2.13.5.2. Variable: QRMode

The following section contains a detailed description of the variable QRMode.

Variable Overview

Variable Name	Description
QRMode	Determines which of the available QR Code modes should be read.

Communication Name	DCQRMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	420
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		All	
	Value	Name	Description
	0	All	
	1	Model1	
	2	Model2	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCQRMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRMode	String	8	Determines which of the available QR Code modes should be read.

Read Variable Response:				
`sRA DCQRMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRMode	String	8	Determines which of the available QR Code modes should be read.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCQRMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRMode	String	8	Determines which of the available QR Code modes should be read.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCQRMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRMode	String	8	Determines which of the available QR Code modes should be read.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRMode[ETX]`
Read Variable Response:	`[STX]sRA DCQRMode 0[ETX]`
Write Variable:	`[STX]sWN DCQRMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCQRMode[ETX]`

© SICK AG - Germany - All rights reserved

2.13.5.3. Variable: QRLengthMode

The following section contains a detailed description of the variable QRLengthMode.

Variable Overview

Variable Name	Description
QRLengthMode	Codelength mode of QR Code

Communication Name	DCQRLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	421
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_Free	
	Value	Name	Description
	0	TX_Free	
	1	TX_Fix	

Variable Telegram Syntax

Read Variable:

```
sRN DCQRLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRLenMode	String	11	Codelength mode of QR Code

Read Variable Response:

```
sRA DCQRLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRLenMode	String	11	Codelength mode of QR Code
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCQRLenMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRLenMode	String	11	Codelength mode of QR Code
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCQRLenMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRLenMode	String	11	Codelength mode of QR Code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCQRLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCQRLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCQRLenMode[ETX]`

2.13.5.4. Variable: QRFixLenList

The following section contains a detailed description of the variable QRFixLenList.

Variable Overview

Variable Name	Description
QRFixLenList	List of symbol sizes

Communication Name	DCQRFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	422
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Array				
Length			5	
	Enum8			
		Value	Name	Description
		0	TX_NONE	
		1	TX_V1	
		2	TX_V2	
		3	TX_V3	
		4	TX_V4	
		5	TX_V5	
		6	TX_V6	
		7	TX_V7	
		8	TX_V8	
		9	TX_V9	
		10	TX_V10	
		11	TX_V11	
		12	TX_V12	
		13	TX_V13	
		14	TX_V14	
		15	TX_V15	
		16	TX_V16	
		17	TX_V17	
		18	TX_V18	
		19	TX_V19	
		20	TX_V20	
		21	TX_V21	
		22	TX_V22	
		23	TX_V23	
		24	TX_V24	
		25	TX_V25	
		26	TX_V26	
		27	TX_V27	
		28	TX_V28	
		29	TX_V29	
		30	TX_V30	
		31	TX_V31	
		32	TX_V32	
		33	TX_V33	
		34	TX_V34	
		35	TX_V35	
		36	TX_V36	
		37	TX_V37	
		38	TX_V38	
		39	TX_V39	
		40	TX_V40	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCQRFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRFixLen	String	10	List of symbol sizes

Read Variable Response:				
`sRA DCQRFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRFixLen	String	10	List of symbol sizes
Variable Data	data	Array	5	

Write Variable:				
`sWN DCQRFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRFixLen	String	10	List of symbol sizes
Variable Data	data	Array	5	

Write Variable Response:				
`sWA DCQRFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRFixLen	String	10	List of symbol sizes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCQRFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCQRFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCQRFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.13.5.5. Variable: QRVerISO18004

The following section contains a detailed description of the variable QRVerISO18004.

Variable Overview

Variable Name	Description
QRVerISO18004	IS018004 verification for QR codes

Communication Name	DCQRVerISO18004
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	423
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DCQRVerISO18004
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRVerISO18004	String	15	IS018004 verification for QR codes

Read Variable Response:

```
sRA DCQRVerISO18004 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRVerISO18004	String	15	IS018004 verification for QR codes
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCQRVerISO18004 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRVerISO18004	String	15	IS018004 verification for QR codes
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCQRVerISO18004
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRVerISO18004	String	15	IS018004 verification for QR codes

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRVerISO18004[ETX]`
Read Variable Response:	`[STX]sRA DCQRVerISO18004 1[ETX]`
Write Variable:	`[STX]sWN DCQRVerISO18004 1[ETX]`
Write Variable Response:	`[STX]sWA DCQRVerISO18004[ETX]`

2.13.5.6. Variable: QRDecodingLevel

The following section contains a detailed description of the variable QRDecodingLevel.

Variable Overview

Variable Name	Description
QRDecodingLevel	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Communication Name	DCQRLvl
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	424
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Fast	
	Value	Name	Description
	0	Fast	
	1	Balanced	
	2	Aggressive	

Variable Telegram Syntax

Read Variable:				
`sRN DCQRLvl`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRLvl	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Read Variable Response:				
`sRA DCQRLvl <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge

© SICK AG - Germany - All rights reserved

Read Variable Response:				
`sRA DCQRLvl <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCQRLvl	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCQRLvl <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRLvl	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCQRLvl`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRLvl	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRLvl[ETX]`
Read Variable Response:	`[STX]sRA DCQRLvl 0[ETX]`
Write Variable:	`[STX]sWN DCQRLvl 0[ETX]`
Write Variable Response:	`[STX]sWA DCQRLvl[ETX]`

© SICK AG - Germany - All rights reserved

2.13.5.7. Variable: QRFormatMode

The following section contains a detailed description of the variable QRFormatMode.

Variable Overview

Variable Name	Description
QRFormatMode	Select between standard ECC200 and GS1 mode

Communication Name	DCQRFormatMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	425
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		FORMAT_ECC200	
	Value	Name	Description
	0	FORMAT_ECC200	
	1	FORMAT_GS1	

Variable Telegram Syntax

Read Variable:				
`sRN DCQRFormatMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRFormatMode	String	14	Select between standard ECC200 and GS1 mode

Read Variable Response:				
`sRA DCQRFormatMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRFormatMode	String	14	Select between standard ECC200 and GS1 mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCQRFormatMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRFormatMode	String	14	Select between standard ECC200 and GS1 mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCQRFormatMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRFormatMode	String	14	Select between standard ECC200 and GS1 mode

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRFormatMode[ETX]`
Read Variable Response:	`[STX]sRA DCQRFormatMode 0[ETX]`
Write Variable:	`[STX]sWN DCQRFormatMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCQRFormatMode[ETX]`

2.13.5.8. Variable: QRGS1FirstCharReplacement

The following section contains a detailed description of the variable QRGS1FirstCharReplacement.

Variable Overview

Variable Name	Description
QRGS1FirstCharReplacement	maximal 4 characters the first FNC1 character should be replaced with

Communication Name	DCQRGS1FirstCharReplace
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	426
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..16
Initialisation	]Q3

Variable Telegram Syntax

Read Variable:				
`sRN DCQRGS1FirstCharReplace`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with

Read Variable Response:				
`sRA DCQRGS1FirstCharReplace <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with
Variable Data	data	FlexString	16	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DCQRGS1FirstCharReplace <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with
Variable Data	data	FlexString	16	

Write Variable Response:				
`sWA DCQRGS1FirstCharReplace`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRGS1FirstCharReplace	String	23	maximal 4 characters the first FNC1 character should be replaced with

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRGS1FirstCharReplace[ETX]`
Read Variable Response:	`[STX]sRA DCQRGS1FirstCharReplace 3 ]Q3[ETX]`
Write Variable:	`[STX]sWN DCQRGS1FirstCharReplace 3 ]Q3[ETX]`
Write Variable Response:	`[STX]sWA DCQRGS1FirstCharReplace[ETX]`

2.13.5.9. Variable: QRGS1SeparatorCharReplacement

The following section contains a detailed description of the variable QRGS1SeparatorCharReplacement.

Variable Overview

Variable Name	Description
QRGS1SeparatorCharReplacement	maximal 4 characters the GS (group separator) characters should be replaced with

Communication Name	DCQRGS1SepCharReplace
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	427
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..16
Initialisation	\x1d

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCQRGS1SepCharReplace`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with

Read Variable Response:				
`sRA DCQRGS1SepCharReplace <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with
Variable Data	data	FlexString	16	

Write Variable:				
`sWN DCQRGS1SepCharReplace <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with
Variable Data	data	FlexString	16	

Write Variable Response:				
`sWA DCQRGS1SepCharReplace`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRGS1SepCharReplace	String	21	maximal 4 characters the GS (group separator) characters should be replaced with

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRGS1SepCharReplace[ETX]`
Read Variable Response:	`[STX]sRA DCQRGS1SepCharReplace 4 \x1d[ETX]`
Write Variable:	`[STX]sWN DCQRGS1SepCharReplace 4 \x1d[ETX]`
Write Variable Response:	`[STX]sWA DCQRGS1SepCharReplace[ETX]`

© SICK AG - Germany - All rights reserved

2.13.5.10. Variable: QRGS1AIMarking

The following section contains a detailed description of the variable QRGS1AIMarking.

Variable Overview

Variable Name	Description
QRGS1AIMarking	GS QR AI Marking active or not

Communication Name	DCQRGS1AIMark
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	428
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCQRGS1AIMark
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCQRGS1AIMark	String	13	GS QR AI Marking active or not

Read Variable Response:

```
sRA DCQRGS1AIMark <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCQRGS1AIMark	String	13	GS QR AI Marking active or not
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCQRGS1AIMark <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCQRGS1AIMark	String	13	GS QR AI Marking active or not
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCQRGS1AIMark
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCQRGS1AIMark	String	13	GS QR AI Marking active or not

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCQRGS1AIMark[ETX]`
Read Variable Response:	`[STX]sRA DCQRGS1AIMark 0[ETX]`
Write Variable:	`[STX]sWN DCQRGS1AIMark 0[ETX]`
Write Variable Response:	`[STX]sWA DCQRGS1AIMark[ETX]`

© SICK AG - Germany - All rights reserved

2.13.6. Group: VerificationAimDpm

2.13.6.1. Variable: AimDpmActive

The following section contains a detailed description of the variable AimDpmActive.

Variable Overview

Variable Name	Description
AimDpmActive	Activates AIM DPM Verification

Communication Name	VDPMAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	429
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN VDPMAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	VDPMAct	String	7	Activates AIM DPM Verification

Read Variable Response:

```
sRA VDPMAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	VDPMAct	String	7	Activates AIM DPM Verification
Variable Data	data	Bool	1	

Write Variable:

```
sWN VDPMAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	VDPMAct	String	7	Activates AIM DPM Verification
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA VDPMAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA VDPMAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	VDPMAct	String	7	Activates AIM DPM Verification

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN VDPMAct[ETX]
Read Variable Response:	[STX]sRA VDPMAct 0[ETX]
Write Variable:	[STX]sWN VDPMAct 0[ETX]
Write Variable Response:	[STX]sWA VDPMAct[ETX]

2.13.6.2. Variable: AimDpmCalibratedGain

The following section contains a detailed description of the variable AimDpmCalibratedGain.

Variable Overview

Variable Name	Description
AimDpmCalibratedGain	Gain value recorded during AIM DPM calibration

Communication Name	VDPMCalGain
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	430
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754
Initialisation	1.0f
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN VDPMCalGain`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	VDPMCalGain	String	11	Gain value recorded during AIM DPM calibration

Read Variable Response:				
`sRA VDPMCalGain <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	VDPMCalGain	String	11	Gain value recorded during AIM DPM calibration
Variable Data	data	Real	4	

Write Variable:				
`sWN VDPMCalGain <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	VDPMCalGain	String	11	Gain value recorded during AIM DPM calibration
Variable Data	data	Real	4	

Write Variable Response:				
`sWA VDPMCalGain`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	VDPMCalGain	String	11	Gain value recorded during AIM DPM calibration

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN VDPMCalGain[ETX]`
Read Variable Response:	`[STX]sRA VDPMCalGain 3F800000[ETX]`
Write Variable:	`[STX]sWN VDPMCalGain 3F800000[ETX]`
Write Variable Response:	`[STX]sWA VDPMCalGain[ETX]`

© SICK AG - Germany - All rights reserved

2.13.6.3. Variable: AimDpmCalibratedMaxReflectance

The following section contains a detailed description of the variable AimDpmCalibratedMaxReflectance.

Variable Overview

Variable Name	Description
AimDpmCalibratedMaxReflectance	Reported reflectance (Rmax) recorded during AIM DPM calibration

Communication Name	VDPMCalMaxRefl
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	431
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN VDPMCalMaxRefl
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	VDPMCalMaxRefl	String	14	Reported reflectance (Rmax) recorded during AIM DPM calibration

Read Variable Response:

```
sRA VDPMCalMaxRefl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	VDPMCalMaxRefl	String	14	Reported reflectance (Rmax) recorded during AIM DPM calibration
Variable Data	data	USInt	1	

Write Variable:

```
sWN VDPMCalMaxRefl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	VDPMCalMaxRefl	String	14	Reported reflectance (Rmax) recorded during AIM DPM calibration
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA VDPMCalMaxRefl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	VDPMCalMaxRefl	String	14	Reported reflectance (Rmax) recorded during AIM DPM calibration

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN VDPMCalMaxRefl[ETX]
Read Variable Response:	[STX]sRA VDPMCalMaxRefl 0[ETX]
Write Variable:	[STX]sWN VDPMCalMaxRefl 0[ETX]
Write Variable Response:	[STX]sWA VDPMCalMaxRefl[ETX]

2.13.6.4. Variable: AimDpmCalibratedMeanReflectance

The following section contains a detailed description of the variable AimDpmCalibratedMeanReflectance.

Variable Overview

Variable Name	Description
AimDpmCalibratedMeanReflectance	Reported reflectance (Rmean) recorded during AIM DPM calibration

Communication Name	VDPMCalMeanRefl
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	432
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN VDPMCalMeanRefl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	VDPMCalMeanRefl	String	15	Reported reflectance (Rmean) recorded during AIM DPM calibration

Read Variable Response:				
sRA VDPMCalMeanRefl <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	VDPMCalMeanRefl	String	15	Reported reflectance (Rmean) recorded during AIM DPM calibration
Variable Data	data	USInt	1	

Write Variable:				
sWN VDPMCalMeanRefl <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	VDPMCalMeanRefl	String	15	Reported reflectance (Rmean) recorded during AIM DPM calibration
Variable Data	data	USInt	1	

Write Variable Response:				
sWA VDPMCalMeanRefl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	VDPMCalMeanRefl	String	15	Reported reflectance (Rmean) recorded during AIM DPM calibration

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN VDPMCalMeanRefl[ETX]
Read Variable Response:	[STX]sRA VDPMCalMeanRefl 0[ETX]
Write Variable:	[STX]sWN VDPMCalMeanRefl 0[ETX]
Write Variable Response:	[STX]sWA VDPMCalMeanRefl[ETX]

© SICK AG - Germany - All rights reserved

2.13.6.5. Method: StartAimDpmCalib

The following section contains a detailed description of the method StartAimDpmCalib.

Method Overview

Method Name	Description
StartAimDpmCalib	Begin AIM DPM calibration

Communication Name	mVDPMStartCal
Sopas Index	62
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mVDPMStartCal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mVDPMStartCal	String	13	Begin AIM DPM calibration

Method Return Value:				
`sAN mVDPMStartCal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mVDPMStartCal	String	13	Begin AIM DPM calibration

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mVDPMStartCal[ETX]`
Method Return Value:	`[STX]sAN mVDPMStartCal[ETX]`

© SICK AG - Germany - All rights reserved

2.13.6.6. Method: CancelAimDpmCalib

The following section contains a detailed description of the method CancelAimDpmCalib.

Method Overview

Method Name	Description
CancelAimDpmCalib	Cancel AIM DPM calibration and reset values to previous state

Communication Name	mVDPMCancelCal
Sopas Index	63
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mVDPMCancelCal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mVDPMCancelCal	String	14	Cancel AIM DPM calibration and reset values to previous state

Method Return Value:				
`sAN mVDPMCancelCal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mVDPMCancelCal	String	14	Cancel AIM DPM calibration and reset values to previous state

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mVDPMCancelCal[ETX]`
Method Return Value:	`[STX]sAN mVDPMCancelCal[ETX]`

© SICK AG - Germany - All rights reserved

2.13.6.7. Method: FinishAimDpmCalib

The following section contains a detailed description of the method FinishAimDpmCalib.

Method Overview

Method Name	Description
FinishAimDpmCalib	Save the results of AIM DPM calibration

Communication Name	mVDPMFinishCal
Sopas Index	64
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mVDPMFinishCal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mVDPMFinishCal	String	14	Save the results of AIM DPM calibration

Method Return Value:				
`sAN mVDPMFinishCal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mVDPMFinishCal	String	14	Save the results of AIM DPM calibration

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mVDPMFinishCal[ETX]`
Method Return Value:	`[STX]sAN mVDPMFinishCal[ETX]`

© SICK AG - Germany - All rights reserved

2.13.7. Group: DPMGeneral

2.13.7.1. Variable: DPMCodeTypeChoice

The following section contains a detailed description of the variable DPMCodeTypeChoice.

Variable Overview

Variable Name	Description
DPMCodeTypeChoice	Choose the wanted Halcon decoder type. Due to memory usage and time consumption running parallel is not possible.

Communication Name	DPMDecoderChoice
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	434
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		DataMatrix	
	Value	Name	Description
	0	DataMatrix	
	1	QR	

Variable Telegram Syntax

Read Variable:

```
sRN DPMDecoderChoice
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPMDecoderChoice	String	16	Choose the wanted Halcon decoder type. Due to memory usage and time consumption running parallel is not possible.

Read Variable Response:

```
sRA DPMDecoderChoice <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPMDecoderChoice	String	16	Choose the wanted Halcon decoder type. Due to memory usage and time consumption running parallel is not possible.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DPMDecoderChoice <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPMDecoderChoice	String	16	Choose the wanted Halcon decoder type. Due to memory usage and time consumption running parallel is not possible.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DPMDecoderChoice				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPMDecoderChoice	String	16	Choose the wanted Halcon decoder type. Due to memory usage and time consumption running parallel is not possible.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DPMDecoderChoice[ETX]
Read Variable Response:	[STX]sRA DPMDecoderChoice 0[ETX]
Write Variable:	[STX]sWN DPMDecoderChoice 0[ETX]
Write Variable Response:	[STX]sWA DPMDecoderChoice[ETX]

© SICK AG - Germany - All rights reserved

2.13.8. Group: DPMDataMatrix

2.13.8.1. Variable: DPMDataMatrixActive

The following section contains a detailed description of the variable DPMDataMatrixActive.

Variable Overview

Variable Name	Description
DPMDataMatrixActive	Activates DPM Data Matrix Decoder

Communication Name	DDMAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	435
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DDMAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMAct	String	6	Activates DPM Data Matrix Decoder

Read Variable Response:

```
sRA DDMAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMAct	String	6	Activates DPM Data Matrix Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DDMAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMAct	String	6	Activates DPM Data Matrix Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DDMAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DDMAct	String	6	Activates DPM Data Matrix Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMAct[ETX]
Read Variable Response:	[STX]sRA DDMAct 0[ETX]
Write Variable:	[STX]sWN DDMAct 0[ETX]
Write Variable Response:	[STX]sWA DDMAct[ETX]

2.13.8.2. Variable: DPMDataMatrixDecodingLevel

The following section contains a detailed description of the variable DPMDataMatrixDecodingLevel.

Variable Overview

Variable Name	Description
DPMDataMatrixDecodingLevel	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Communication Name	DDMAggr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	436
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Aggressive	
	Value	Name	Description
	0	Fast	
	1	Balanced	
	2	Aggressive	
	3	UserDefined	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMAggr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMAggr	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Read Variable Response:				
`sRA DDMAggr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMAggr	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMAggr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMAggr	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMAggr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMAggr	String	7	Sets the level of determination at which the decoder should search for codes in the image. Higher values could mean better read rates but less runtime performance.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMAggr[ETX]`
Read Variable Response:	`[STX]sRA DDMAggr 2[ETX]`
Write Variable:	`[STX]sWN DDMAggr 2[ETX]`
Write Variable Response:	`[STX]sWA DDMAggr[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.3. Variable: DPMDataMatrixTimeout

The following section contains a detailed description of the variable DPMDataMatrixTimeout.

Variable Overview

Variable Name
DPMDataMatrixTimeout

Communication Name	DDMTmout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	437
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..50000
Initialisation	1500
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DDMTmout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMTmout	String	8	

Read Variable Response:

```
sRA DDMTmout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMTmout	String	8	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DDMTmout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMTmout	String	8	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DDMTmout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMTmout	String	8	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMTmout[ETX]`
Read Variable Response:	`[STX]sRA DDMTmout 5DC[ETX]`
Write Variable:	`[STX]sWN DDMTmout 5DC[ETX]`
Write Variable Response:	`[STX]sWA DDMTmout[ETX]`

2.13.8.4. Variable: DPMDataMatrixNumCodes

The following section contains a detailed description of the variable DPMDataMatrixNumCodes.

Variable Overview

Variable Name	Description
DPMDataMatrixNumCodes	Number of codes to find per image.

Communication Name	DDMNmCds
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	438
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Any	
	Value	Name	Description
	0	Any	
	1	Fixed	

Variable Telegram Syntax

Read Variable:				
`sRN DDMNmCds`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMNmCds	String	8	Number of codes to find per image.

Read Variable Response:				
`sRA DDMNmCds <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMNmCds	String	8	Number of codes to find per image.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DDMNmCds <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMNmCds	String	8	Number of codes to find per image.
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA DDMNmCds				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMNmCds	String	8	Number of codes to find per image.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMNmCds[ETX]
Read Variable Response:	[STX]sRA DDMNmCds 0[ETX]
Write Variable:	[STX]sWN DDMNmCds 0[ETX]
Write Variable Response:	[STX]sWA DDMNmCds[ETX]

2.13.8.5. Variable: DPMDataMatrixFixedNumCodes

The following section contains a detailed description of the variable DPMDataMatrixFixedNumCodes.

Variable Overview

Variable Name	Description
DPMDataMatrixFixedNumCodes	Fixed number of codes to read per image. Only active if DPMDataMatrixNumCodes is set to Fixed.

Communication Name	DDMFxNmCds
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	439
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..4294967295
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMFxNmCds`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMFxNmCds	String	10	Fixed number of codes to read per image. Only active if DPMDataMatrixNumCodes is set to Fixed.

Read Variable Response:				
`sRA DDMFxNmCds <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMFxNmCds	String	10	Fixed number of codes to read per image. Only active if DPMDataMatrixNumCodes is set to Fixed.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DDMFxNmCds <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMFxNmCds	String	10	Fixed number of codes to read per image. Only active if DPMDataMatrixNumCodes is set to Fixed.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DDMFxNmCds`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMFxNmCds	String	10	Fixed number of codes to read per image. Only active if DPMDataMatrixNumCodes is set to Fixed.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMFxNmCds[ETX]`
Read Variable Response:	`[STX]sRA DDMFxNmCds 1[ETX]`
Write Variable:	`[STX]sWN DDMFxNmCds 1[ETX]`
Write Variable Response:	`[STX]sWA DDMFxNmCds[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.6. Variable: DPMDataMatrixMinCellSize

The following section contains a detailed description of the variable DPMDataMatrixMinCellSize.

Variable Overview

Variable Name
DPMDataMatrixMinCellSize

Communication Name	DDMMinCell
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	440
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	2
Physical Unit	px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DDMMinCell
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMinCell	String	10	

Read Variable Response:

```
sRA DDMMinCell <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMinCell	String	10	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DDMMinCell <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMinCell	String	10	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DDMMinCell
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMinCell	String	10	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMMinCell[ETX]`
Read Variable Response:	`[STX]sRA DDMMinCell 2[ETX]`
Write Variable:	`[STX]sWN DDMMinCell 2[ETX]`
Write Variable Response:	`[STX]sWA DDMMinCell[ETX]`

2.13.8.7. Variable: DPMDataMatrixMaxCellSize

The following section contains a detailed description of the variable DPMDataMatrixMaxCellSize.

Variable Overview

Variable Name
DPMDataMatrixMaxCellSize

Communication Name	DDMMaxCell
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	441
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	20
Physical Unit	px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DDMMaxCell`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMaxCell	String	10	

Read Variable Response:

`sRA DDMMaxCell <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMaxCell	String	10	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DDMMaxCell <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMaxCell	String	10	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DDMMaxCell`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMaxCell	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMMaxCell[ETX]`
Read Variable Response:	`[STX]sRA DDMMaxCell 14[ETX]`
Write Variable:	`[STX]sWN DDMMaxCell 14[ETX]`
Write Variable Response:	`[STX]sWA DDMMaxCell[ETX]`

2.13.8.8. Variable: DPMDataMatrixMinNumRows

The following section contains a detailed description of the variable DPMDataMatrixMinNumRows.

Variable Overview

Variable Name
DPMDataMatrixMinNumRows

Communication Name	DDMMinRow
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	442
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		10	
	Value	Name	Description
	8	8	
	10	10	
	12	12	
	14	14	
	16	16	
	18	18	
	20	20	
	22	22	
	24	24	
	26	26	
	32	32	
	36	36	
	40	40	
	44	44	
	48	48	
	52	52	
	64	64	
	72	72	
	80	80	
	88	88	
	96	96	
	104	104	
	120	120	
	132	132	
	144	144	

Variable Telegram Syntax

Read Variable:				
`sRN DDMMinRow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMinRow	String	9	

Read Variable Response:				
`sRA DDMMinRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMinRow	String	9	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMinRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMinRow	String	9	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMMinRow				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMinRow	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMinRow[ETX]
Read Variable Response:	[STX]sRA DDMMinRow A[ETX]
Write Variable:	[STX]sWN DDMMinRow A[ETX]
Write Variable Response:	[STX]sWA DDMMinRow[ETX]

2.13.8.9. Variable: DPMDataMatrixMaxNumRows

The following section contains a detailed description of the variable DPMDataMatrixMaxNumRows.

Variable Overview

Variable Name
DPMDataMatrixMaxNumRows

Communication Name	DDMMaxRow
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	443
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		32	
	Value	Name	Description
	8	8	
	10	10	
	12	12	
	14	14	
	16	16	
	18	18	
	20	20	
	22	22	
	24	24	
	26	26	
	32	32	
	36	36	
	40	40	
	44	44	
	48	48	
	52	52	
	64	64	
	72	72	
	80	80	
	88	88	
	96	96	
	104	104	
	120	120	
	132	132	
	144	144	

Variable Telegram Syntax

Read Variable:				
`sRN DDMMaxRow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMaxRow	String	9	

Read Variable Response:				
`sRA DDMMaxRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMaxRow	String	9	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMaxRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMaxRow	String	9	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMMaxRow				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMaxRow	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMaxRow[ETX]
Read Variable Response:	[STX]sRA DDMMaxRow 20[ETX]
Write Variable:	[STX]sWN DDMMaxRow 20[ETX]
Write Variable Response:	[STX]sWA DDMMaxRow[ETX]

2.13.8.10. Variable: DPMDataMatrixMinNumCols

The following section contains a detailed description of the variable DPMDataMatrixMinNumCols.

Variable Overview

Variable Name
DPMDataMatrixMinNumCols

Communication Name	DDMMinCol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	444
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		10	
	Value	Name	Description
	10	10	
	12	12	
	14	14	
	16	16	
	18	18	
	20	20	
	22	22	
	24	24	
	26	26	
	32	32	
	36	36	
	40	40	
	44	44	
	48	48	
	52	52	
	64	64	
	72	72	
	80	80	
	88	88	
	96	96	
	104	104	
	120	120	
	132	132	
	144	144	

Variable Telegram Syntax

Read Variable:				
`sRN DDMMinCol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMinCol	String	9	

Read Variable Response:				
`sRA DDMMinCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMinCol	String	9	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMinCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMinCol	String	9	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMMinCol				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMinCol	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMinCol[ETX]
Read Variable Response:	[STX]sRA DDMMinCol A[ETX]
Write Variable:	[STX]sWN DDMMinCol A[ETX]
Write Variable Response:	[STX]sWA DDMMinCol[ETX]

2.13.8.11. Variable: DPMDataMatrixMaxNumCols

The following section contains a detailed description of the variable DPMDataMatrixMaxNumCols.

Variable Overview

Variable Name
DPMDataMatrixMaxNumCols

Communication Name	DDMMaxCol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	445
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		32	
	Value	Name	Description
	10	10	
	12	12	
	14	14	
	16	16	
	18	18	
	20	20	
	22	22	
	24	24	
	26	26	
	32	32	
	36	36	
	40	40	
	44	44	
	48	48	
	52	52	
	64	64	
	72	72	
	80	80	
	88	88	
	96	96	
	104	104	
	120	120	
	132	132	
	144	144	

Variable Telegram Syntax

Read Variable:				
`sRN DDMMaxCol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMaxCol	String	9	

Read Variable Response:				
`sRA DDMMaxCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMaxCol	String	9	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMaxCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMaxCol	String	9	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMMaxCol				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMaxCol	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMaxCol[ETX]
Read Variable Response:	[STX]sRA DDMMaxCol 20[ETX]
Write Variable:	[STX]sWN DDMMaxCol 20[ETX]
Write Variable Response:	[STX]sWA DDMMaxCol[ETX]

2.13.8.12. Variable: DPMDataMatrixAllowRectangular

The following section contains a detailed description of the variable DPMDataMatrixAllowRectangular.

Variable Overview

Variable Name
DPMDataMatrixAllowRectangular

Communication Name	DDMAllwRect
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	446
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMAllwRect`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMAllwRect	String	11	

Read Variable Response:				
`sRA DDMAllwRect <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMAllwRect	String	11	
Variable Data	data	Bool	1	

Write Variable:				
`sWN DDMAllwRect <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMAllwRect	String	11	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DDMAllwRect`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMAllwRect	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMAllwRect[ETX]`
Read Variable Response:	`[STX]sRA DDMAllwRect 1[ETX]`
Write Variable:	`[STX]sWN DDMAllwRect 1[ETX]`
Write Variable Response:	`[STX]sWA DDMAllwRect[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.13. Variable: DPMDataMatrixGeometricDistortion

The following section contains a detailed description of the variable DPMDataMatrixGeometricDistortion.

Variable Overview

Variable Name
DPMDataMatrixGeometricDistortion

Communication Name	DDMGeoDis
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	447
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		No	
	Value	Name	Description
	0	No	
	1	Variable	
	2	Both	

Variable Telegram Syntax

Read Variable:				
`sRN DDMGeoDis`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMGeoDis	String	9	

Read Variable Response:				
`sRA DDMGeoDis <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMGeoDis	String	9	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMGeoDis <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMGeoDis	String	9	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMGeoDis`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMGeoDis				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DDMGeoDis	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMGeoDis[ETX]
Read Variable Response:	[STX]sRA DDMGeoDis 0[ETX]
Write Variable:	[STX]sWN DDMGeoDis 0[ETX]
Write Variable Response:	[STX]sWA DDMGeoDis[ETX]

2.13.8.14. Variable: DPMDataMatrixCodeDirection

The following section contains a detailed description of the variable DPMDataMatrixCodeDirection.

Variable Overview

Variable Name	Description
DPMDataMatrixCodeDirection	'Direction' means mirrored or non-mirrored here

Communication Name	DDMDirection
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	448
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	NORMAL	
	1	MIRRORED	
	2	BOTH	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMDirection`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMDirection	String	12	'Direction' means mirrored or non-mirrored here

Read Variable Response:				
`sRA DDMDirection <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMDirection	String	12	'Direction' means mirrored or non-mirrored here
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMDirection <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMDirection	String	12	'Direction' means mirrored or non-mirrored here
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMDirection`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMDirection	String	12	'Direction' means mirrored or non-mirrored here

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMDirection[ETX]`
Read Variable Response:	`[STX]sRA DDMDirection 0[ETX]`
Write Variable:	`[STX]sWN DDMDirection 0[ETX]`
Write Variable Response:	`[STX]sWA DDMDirection[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.15. Variable: DPMDataMatrixCodeContrast

The following section contains a detailed description of the variable DPMDataMatrixCodeContrast.

Variable Overview

Variable Name	Description
DPMDataMatrixCodeContrast	Contrast in grey value (0-255) that a code should have at least

Communication Name	DDMContrast
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	449
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..255
Initialisation	30
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DDMContrast
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMContrast	String	11	Contrast in grey value (0-255) that a code should have at least

Read Variable Response:

```
sRA DDMContrast <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMContrast	String	11	Contrast in grey value (0-255) that a code should have at least
Variable Data	data	UInt	2	

Write Variable:

```
sWN DDMContrast <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMContrast	String	11	Contrast in grey value (0-255) that a code should have at least
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMContrast				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMContrast	String	11	Contrast in grey value (0-255) that a code should have at least

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMContrast[ETX]
Read Variable Response:	[STX]sRA DDMContrast 1E[ETX]
Write Variable:	[STX]sWN DDMContrast 1E[ETX]
Write Variable Response:	[STX]sWA DDMContrast[ETX]

2.13.8.16. Variable: DPMDataMatrixCodeBackground

The following section contains a detailed description of the variable DPMDataMatrixCodeBackground.

Variable Overview

Variable Name	Description
DPMDataMatrixCodeBackground	2D Code background color

Communication Name	DDMBackground
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	450
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		BOTH	
	Value	Name	Description
	0	WHITE	
	1	BLACK	
	2	BOTH	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMBackground`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMBackground	String	13	2D Code background color

Read Variable Response:				
`sRA DDMBackground <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMBackground	String	13	2D Code background color
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMBackground <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMBackground	String	13	2D Code background color
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMBackground`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMBackground	String	13	2D Code background color

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMBackground[ETX]`
Read Variable Response:	`[STX]sRA DDMBackground 2[ETX]`
Write Variable:	`[STX]sWN DDMBackground 2[ETX]`
Write Variable Response:	`[STX]sWA DDMBackground[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.17. Variable: DPMDataMatrixSmallCells

The following section contains a detailed description of the variable DPMDataMatrixSmallCells.

Variable Overview

Variable Name
DPMDataMatrixSmallCells

Communication Name	DDMSmlCell
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	451
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DDMSmlCell
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMSmlCell	String	10	

Read Variable Response:

```
sRA DDMSmlCell <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMSmlCell	String	10	
Variable Data	data	Bool	1	

Write Variable:

```
sWN DDMSmlCell <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMSmlCell	String	10	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DDMSmlCell
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMSmlCell	String	10	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMSmlCell[ETX]`
Read Variable Response:	`[STX]sRA DDMSmlCell 0[ETX]`
Write Variable:	`[STX]sWN DDMSmlCell 0[ETX]`
Write Variable Response:	`[STX]sWA DDMSmlCell[ETX]`

2.13.8.18. Variable: DPMDataMatrixMaxSkew

The following section contains a detailed description of the variable DPMDataMatrixMaxSkew.

Variable Overview

Variable Name
DPMDataMatrixMaxSkew

Communication Name	DDMMaxSkw
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	452
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..30
Initialisation	30
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DDMMaxSkw`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMaxSkw	String	9	

Read Variable Response:

`sRA DDMMaxSkw <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMaxSkw	String	9	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DDMMaxSkw <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMaxSkw	String	9	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DDMMaxSkw				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMaxSkw	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMaxSkw[ETX]
Read Variable Response:	[STX]sRA DDMMaxSkw 1E[ETX]
Write Variable:	[STX]sWN DDMMaxSkw 1E[ETX]
Write Variable Response:	[STX]sWA DDMMaxSkw[ETX]

2.13.8.19. Variable: DPMDataMatrixMinGapRow

The following section contains a detailed description of the variable DPMDataMatrixMinGapRow.

Variable Overview

Variable Name
DPMDataMatrixMinGapRow

Communication Name	DDMMinGapRow
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	453
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		No	
	Value	Name	Description
	0	No	
	1	Small	
	2	Big	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMMinGapRow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMinGapRow	String	12	

Read Variable Response:				
`sRA DDMMinGapRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMinGapRow	String	12	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMinGapRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMinGapRow	String	12	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMMinGapRow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMinGapRow	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMMinGapRow[ETX]`
Read Variable Response:	`[STX]sRA DDMMinGapRow 0[ETX]`
Write Variable:	`[STX]sWN DDMMinGapRow 0[ETX]`
Write Variable Response:	`[STX]sWA DDMMinGapRow[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.20. Variable: DPMDataMatrixMaxGapRow

The following section contains a detailed description of the variable DPMDataMatrixMaxGapRow.

Variable Overview

Variable Name
DPMDataMatrixMaxGapRow

Communication Name	DDMMaxGapRow
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	454
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Big	
	Value	Name	Description
	0	No	
	1	Small	
	2	Big	

Variable Telegram Syntax

Read Variable:				
`sRN DDMMaxGapRow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMaxGapRow	String	12	

Read Variable Response:				
`sRA DDMMaxGapRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMaxGapRow	String	12	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMaxGapRow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMaxGapRow	String	12	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMMaxGapRow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMMaxGapRow				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DDMMaxGapRow	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMaxGapRow[ETX]
Read Variable Response:	[STX]sRA DDMMaxGapRow 2[ETX]
Write Variable:	[STX]sWN DDMMaxGapRow 2[ETX]
Write Variable Response:	[STX]sWA DDMMaxGapRow[ETX]

2.13.8.21. Variable: DPMDataMatrixMinGapCol

The following section contains a detailed description of the variable DPMDataMatrixMinGapCol.

Variable Overview

Variable Name
DPMDataMatrixMinGapCol

Communication Name	DDMMinGapCol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	455
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		No	
	Value	Name	Description
	0	No	
	1	Small	
	2	Big	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMMinGapCol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMinGapCol	String	12	

Read Variable Response:				
`sRA DDMMinGapCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMinGapCol	String	12	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMinGapCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMinGapCol	String	12	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMMinGapCol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMMinGapCol	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMMinGapCol[ETX]`
Read Variable Response:	`[STX]sRA DDMMinGapCol 0[ETX]`
Write Variable:	`[STX]sWN DDMMinGapCol 0[ETX]`
Write Variable Response:	`[STX]sWA DDMMinGapCol[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.22. Variable: DPMDataMatrixMaxGapCol

The following section contains a detailed description of the variable DPMDataMatrixMaxGapCol.

Variable Overview

Variable Name
DPMDataMatrixMaxGapCol

Communication Name	DDMMaxGapCol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	456
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Big	
	Value	Name	Description
	0	No	
	1	Small	
	2	Big	

Variable Telegram Syntax

Read Variable:				
`sRN DDMMaxGapCol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMMaxGapCol	String	12	

Read Variable Response:				
`sRA DDMMaxGapCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMMaxGapCol	String	12	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMMaxGapCol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMMaxGapCol	String	12	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMMaxGapCol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMMaxGapCol				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DDMMaxGapCol	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMMaxGapCol[ETX]
Read Variable Response:	[STX]sRA DDMMaxGapCol 2[ETX]
Write Variable:	[STX]sWN DDMMaxGapCol 2[ETX]
Write Variable Response:	[STX]sWA DDMMaxGapCol[ETX]

2.13.8.23. Variable: DPMDataMatrixFinderPatternTolerance

The following section contains a detailed description of the variable DPMDataMatrixFinderPatternTolerance.

Variable Overview

Variable Name
DPMDataMatrixFinderPatternTolerance

Communication Name	DDMFndPtTol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	457
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Low	
	Value	Name	Description
	0	Low	
	1	High	
	2	Both	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDMFndPtTol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMFndPtTol	String	11	

Read Variable Response:				
`sRA DDMFndPtTol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMFndPtTol	String	11	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMFndPtTol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMFndPtTol	String	11	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMFndPtTol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDMFndPtTol	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDMFndPtTol[ETX]`
Read Variable Response:	`[STX]sRA DDMFndPtTol 0[ETX]`
Write Variable:	`[STX]sWN DDMFndPtTol 0[ETX]`
Write Variable Response:	`[STX]sWA DDMFndPtTol[ETX]`

© SICK AG - Germany - All rights reserved

2.13.8.24. Variable: DPMDataMatrixContrastTolerance

The following section contains a detailed description of the variable DPMDataMatrixContrastTolerance.

Variable Overview

Variable Name
DPMDataMatrixContrastTolerance

Communication Name	DDMCtrstTol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	458
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Low	
	Value	Name	Description
	0	Low	
	1	High	
	2	Both	

Variable Telegram Syntax

Read Variable:				
`sRN DDMCtrstTol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDMCtrstTol	String	11	

Read Variable Response:				
`sRA DDMCtrstTol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDMCtrstTol	String	11	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDMCtrstTol <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDMCtrstTol	String	11	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDMCtrstTol`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDMCtrstTol				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DDMCtrstTol	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDMCtrstTol[ETX]
Read Variable Response:	[STX]sRA DDMCtrstTol 0[ETX]
Write Variable:	[STX]sWN DDMCtrstTol 0[ETX]
Write Variable Response:	[STX]sWA DDMCtrstTol[ETX]

© SICK AG - Germany - All rights reserved

2.13.9. Group: DPMQR

2.13.9.1. Variable: DPMQRModelType

The following section contains a detailed description of the variable DPMQRModelType.

Variable Overview

Variable Name
DPMQRModelType

Communication Name	DQRModelType
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	459
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_QR_MODELTYPE_ANY	
	Value	Name	Description
	0	TX_QR_MODELTYPE_ANY	
	1	TX_QR_MODELTYPE_1	
	2	TX_QR_MODELTYPE_2	

Variable Telegram Syntax

Read Variable:				
`sRN DQRModelType`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DQRModelType	String	12	

Read Variable Response:				
`sRA DQRModelType <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DQRModelType	String	12	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DQRModelType <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DQRModelType	String	12	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DQRModelType				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DQRModelType	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DQRModelType[ETX]
Read Variable Response:	[STX]sRA DQRModelType 0[ETX]
Write Variable:	[STX]sWN DQRModelType 0[ETX]
Write Variable Response:	[STX]sWA DQRModelType[ETX]

2.13.9.2. Variable: DPMQRVersionMin

The following section contains a detailed description of the variable DPMQRVersionMin.

Variable Overview

Variable Name
DPMQRVersionMin

Communication Name	DQRVersionMin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	460
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		1	
	Value	Name	Description
	1	TX_QR_VERSIONMIN_1	
	2	TX_QR_VERSIONMIN_2	
	3	TX_QR_VERSIONMIN_3	
	4	TX_QR_VERSIONMIN_4	
	5	TX_QR_VERSIONMIN_5	
	6	TX_QR_VERSIONMIN_6	
	7	TX_QR_VERSIONMIN_7	
	8	TX_QR_VERSIONMIN_8	
	9	TX_QR_VERSIONMIN_9	
	10	TX_QR_VERSIONMIN_10	
	11	TX_QR_VERSIONMIN_11	
	12	TX_QR_VERSIONMIN_12	
	13	TX_QR_VERSIONMIN_13	
	14	TX_QR_VERSIONMIN_14	
	15	TX_QR_VERSIONMIN_15	
	16	TX_QR_VERSIONMIN_16	
	17	TX_QR_VERSIONMIN_17	
	18	TX_QR_VERSIONMIN_18	
	19	TX_QR_VERSIONMIN_19	
	20	TX_QR_VERSIONMIN_20	
	21	TX_QR_VERSIONMIN_21	
	22	TX_QR_VERSIONMIN_22	
	23	TX_QR_VERSIONMIN_23	
	24	TX_QR_VERSIONMIN_24	
	25	TX_QR_VERSIONMIN_25	
	26	TX_QR_VERSIONMIN_26	
	27	TX_QR_VERSIONMIN_27	
	28	TX_QR_VERSIONMIN_28	
	29	TX_QR_VERSIONMIN_29	
	30	TX_QR_VERSIONMIN_30	
	31	TX_QR_VERSIONMIN_31	
	32	TX_QR_VERSIONMIN_32	
	33	TX_QR_VERSIONMIN_33	
	34	TX_QR_VERSIONMIN_34	
	35	TX_QR_VERSIONMIN_35	
	36	TX_QR_VERSIONMIN_36	
	37	TX_QR_VERSIONMIN_37	
	38	TX_QR_VERSIONMIN_38	
	39	TX_QR_VERSIONMIN_39	
	40	TX_QR_VERSIONMIN_40	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DQRVersionMin`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DQRVersionMin	String	13	

Read Variable Response:				
`sRA DQRVersionMin <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DQRVersionMin	String	13	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DQRVersionMin <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DQRVersionMin	String	13	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DQRVersionMin`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DQRVersionMin	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DQRVersionMin[ETX]`
Read Variable Response:	`[STX]sRA DQRVersionMin 1[ETX]`
Write Variable:	`[STX]sWN DQRVersionMin 1[ETX]`
Write Variable Response:	`[STX]sWA DQRVersionMin[ETX]`

© SICK AG - Germany - All rights reserved

2.13.9.3. Variable: DPMQRVersionMax

The following section contains a detailed description of the variable DPMQRVersionMax.

Variable Overview

Variable Name
DPMQRVersionMax

Communication Name	DQRVersionMax
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	461
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		40	
	Value	Name	Description
	1	TX_QR_VERSIONMAX_1	
	2	TX_QR_VERSIONMAX_2	
	3	TX_QR_VERSIONMAX_3	
	4	TX_QR_VERSIONMAX_4	
	5	TX_QR_VERSIONMAX_5	
	6	TX_QR_VERSIONMAX_6	
	7	TX_QR_VERSIONMAX_7	
	8	TX_QR_VERSIONMAX_8	
	9	TX_QR_VERSIONMAX_9	
	10	TX_QR_VERSIONMAX_10	
	11	TX_QR_VERSIONMAX_11	
	12	TX_QR_VERSIONMAX_12	
	13	TX_QR_VERSIONMAX_13	
	14	TX_QR_VERSIONMAX_14	
	15	TX_QR_VERSIONMAX_15	
	16	TX_QR_VERSIONMAX_16	
	17	TX_QR_VERSIONMAX_17	
	18	TX_QR_VERSIONMAX_18	
	19	TX_QR_VERSIONMAX_19	
	20	TX_QR_VERSIONMAX_20	
	21	TX_QR_VERSIONMAX_21	
	22	TX_QR_VERSIONMAX_22	
	23	TX_QR_VERSIONMAX_23	
	24	TX_QR_VERSIONMAX_24	
	25	TX_QR_VERSIONMAX_25	
	26	TX_QR_VERSIONMAX_26	
	27	TX_QR_VERSIONMAX_27	
	28	TX_QR_VERSIONMAX_28	
	29	TX_QR_VERSIONMAX_29	
	30	TX_QR_VERSIONMAX_30	
	31	TX_QR_VERSIONMAX_31	
	32	TX_QR_VERSIONMAX_32	
	33	TX_QR_VERSIONMAX_33	
	34	TX_QR_VERSIONMAX_34	
	35	TX_QR_VERSIONMAX_35	
	36	TX_QR_VERSIONMAX_36	
	37	TX_QR_VERSIONMAX_37	
	38	TX_QR_VERSIONMAX_38	
	39	TX_QR_VERSIONMAX_39	
	40	TX_QR_VERSIONMAX_40	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DQRVersionMax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DQRVersionMax	String	13	

Read Variable Response:				
`sRA DQRVersionMax <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DQRVersionMax	String	13	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DQRVersionMax <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DQRVersionMax	String	13	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DQRVersionMax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DQRVersionMax	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DQRVersionMax[ETX]`
Read Variable Response:	`[STX]sRA DQRVersionMax 28[ETX]`
Write Variable:	`[STX]sWN DQRVersionMax 28[ETX]`
Write Variable Response:	`[STX]sWA DQRVersionMax[ETX]`

© SICK AG - Germany - All rights reserved

2.13.10. Group: DotCodeTobacco

2.13.10.1. Variable: DotCodeTobaccoActive

The following section contains a detailed description of the variable DotCodeTobaccoActive.

Variable Overview

Variable Name	Description
DotCodeTobaccoActive	Activates tobacco dot code

Communication Name	DCTAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	462
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCTAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTAct	String	6	Activates tobacco dot code

Read Variable Response:

```
sRA DCTAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTAct	String	6	Activates tobacco dot code
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCTAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTAct	String	6	Activates tobacco dot code
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCTAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCTAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCTAct	String	6	Activates tobacco dot code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTAct[ETX]
Read Variable Response:	[STX]sRA DCTAct 0[ETX]
Write Variable:	[STX]sWN DCTAct 0[ETX]
Write Variable Response:	[STX]sWA DCTAct[ETX]

2.13.10.2. Variable: DotCodeTobaccoOrientation

The following section contains a detailed description of the variable DotCodeTobaccoOrientation.

Variable Overview

Variable Name	Description
DotCodeTobaccoOrientation	Orientation of tobacco dot code in image

Communication Name	DCTOrient
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	463
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		HorizontalLeftRight	
	Value	Name	Description
	0	VerticalBottomUp	
	1	HorizontalLeftRight	
	2	VerticalTopBottom	
	3	HorizontalRightLeft	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTOrient`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTOrient	String	9	Orientation of tobacco dot code in image

Read Variable Response:				
`sRA DCTOrient <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTOrient	String	9	Orientation of tobacco dot code in image
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCTOrient <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTOrient	String	9	Orientation of tobacco dot code in image
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCTOrient`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTOrient	String	9	Orientation of tobacco dot code in image

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTOrient[ETX]`
Read Variable Response:	`[STX]sRA DCTOrient 1[ETX]`
Write Variable:	`[STX]sWN DCTOrient 1[ETX]`
Write Variable Response:	`[STX]sWA DCTOrient[ETX]`

© SICK AG - Germany - All rights reserved

2.13.10.3. Variable: DotCodeTobaccoDotDiameter

The following section contains a detailed description of the variable DotCodeTobaccoDotDiameter.

Variable Overview

Variable Name	Description
DotCodeTobaccoDotDiameter	Diameter of dots of tobacco dot code

Communication Name	DCTDia
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	464
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	10..4294967295
Initialisation	46
Physical Unit	/10 px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCTDia
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTDia	String	6	Diameter of dots of tobacco dot code

Read Variable Response:

```
sRA DCTDia <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTDia	String	6	Diameter of dots of tobacco dot code
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCTDia <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTDia	String	6	Diameter of dots of tobacco dot code
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DCTDia
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTDia	String	6	Diameter of dots of tobacco dot code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTDia[ETX]`
Read Variable Response:	`[STX]sRA DCTDia 2E[ETX]`
Write Variable:	`[STX]sWN DCTDia 2E[ETX]`
Write Variable Response:	`[STX]sWA DCTDia[ETX]`

2.13.10.4. Variable: DotCodeTobaccoWidth

The following section contains a detailed description of the variable DotCodeTobaccoWidth.

Variable Overview

Variable Name	Description
DotCodeTobaccoWidth	Number of horizontal dots of tobacco dot code

Communication Name	DCTWidth
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	465
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	58
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DCTWidth`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTWidth	String	8	Number of horizontal dots of tobacco dot code

Read Variable Response:

`sRA DCTWidth <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTWidth	String	8	Number of horizontal dots of tobacco dot code
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCTWidth <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTWidth	String	8	Number of horizontal dots of tobacco dot code
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCTWidth				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTWidth	String	8	Number of horizontal dots of tobacco dot code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTWidth[ETX]
Read Variable Response:	[STX]sRA DCTWidth 3A[ETX]
Write Variable:	[STX]sWN DCTWidth 3A[ETX]
Write Variable Response:	[STX]sWA DCTWidth[ETX]

2.13.10.5. Variable: DotCodeTobaccoHeight

The following section contains a detailed description of the variable DotCodeTobaccoHeight.

Variable Overview

Variable Name	Description
DotCodeTobaccoHeight	Number of vertical dots of tobacco dot code

Communication Name	DCTHeight
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	466
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	7
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTHeight`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTHeight	String	9	Number of vertical dots of tobacco dot code

Read Variable Response:				
`sRA DCTHeight <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTHeight	String	9	Number of vertical dots of tobacco dot code
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCTHeight <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTHeight	String	9	Number of vertical dots of tobacco dot code
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCTHeight`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTHeight	String	9	Number of vertical dots of tobacco dot code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTHeight[ETX]`
Read Variable Response:	`[STX]sRA DCTHeight 7[ETX]`
Write Variable:	`[STX]sWN DCTHeight 7[ETX]`
Write Variable Response:	`[STX]sWA DCTHeight[ETX]`

© SICK AG - Germany - All rights reserved

2.13.10.6. Variable: DotCodeTobaccoBlurWindow

The following section contains a detailed description of the variable DotCodeTobaccoBlurWindow.

Variable Overview

Variable Name
DotCodeTobaccoBlurWindow

Communication Name	DCTBlrWin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	467
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	1
Physical Unit	px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCTBlrWin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTBlrWin	String	9	

Read Variable Response:

```
sRA DCTBlrWin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTBlrWin	String	9	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCTBlrWin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTBlrWin	String	9	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DCTBlrWin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTBlrWin	String	9	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTBlrWin[ETX]`
Read Variable Response:	`[STX]sRA DCTBlrWin 1[ETX]`
Write Variable:	`[STX]sWN DCTBlrWin 1[ETX]`
Write Variable Response:	`[STX]sWA DCTBlrWin[ETX]`

2.13.10.7. Variable: DotCodeTobaccoSauvolaWindow

The following section contains a detailed description of the variable DotCodeTobaccoSauvolaWindow.

Variable Overview

Variable Name
DotCodeTobaccoSauvolaWindow

Communication Name	DCTSauvWin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	468
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	5
Physical Unit	px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCTSauvWin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTSauvWin	String	10	

Read Variable Response:

```
sRA DCTSauvWin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTSauvWin	String	10	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCTSauvWin <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTSauvWin	String	10	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCTSauvWin				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTSauvWin	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTSauvWin[ETX]
Read Variable Response:	[STX]sRA DCTSauvWin 5[ETX]
Write Variable:	[STX]sWN DCTSauvWin 5[ETX]
Write Variable Response:	[STX]sWA DCTSauvWin[ETX]

2.13.10.8. Variable: DotCodeTobaccoSauvolaK

The following section contains a detailed description of the variable DotCodeTobaccoSauvolaK.

Variable Overview

Variable Name
DotCodeTobaccoSauvolaK

Communication Name	DCTSauvK
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	469
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..100
Initialisation	20
Physical Unit	/100
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTSauvK`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTSauvK	String	8	

Read Variable Response:				
`sRA DCTSauvK <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTSauvK	String	8	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCTSauvK <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTSauvK	String	8	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCTSauvK`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTSauvK	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTSauvK[ETX]`
Read Variable Response:	`[STX]sRA DCTSauvK 14[ETX]`
Write Variable:	`[STX]sWN DCTSauvK 14[ETX]`
Write Variable Response:	`[STX]sWA DCTSauvK[ETX]`

© SICK AG - Germany - All rights reserved

2.13.10.9. Variable: DotCodeTobaccoSauvolaR

The following section contains a detailed description of the variable DotCodeTobaccoSauvolaR.

Variable Overview

Variable Name
DotCodeTobaccoSauvolaR

Communication Name	DCTSauvR
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	470
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	128
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCTSauvR
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTSauvR	String	8	

Read Variable Response:

```
sRA DCTSauvR <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTSauvR	String	8	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCTSauvR <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTSauvR	String	8	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DCTSauvR
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTSauvR	String	8	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTSauvR[ETX]`
Read Variable Response:	`[STX]sRA DCTSauvR 80[ETX]`
Write Variable:	`[STX]sWN DCTSauvR 80[ETX]`
Write Variable Response:	`[STX]sWA DCTSauvR[ETX]`

2.13.10.10. Variable: DotCodeTobaccoCloseDiagonal

The following section contains a detailed description of the variable DotCodeTobaccoCloseDiagonal.

Variable Overview

Variable Name
DotCodeTobaccoCloseDiagonal

Communication Name	DCTClseDg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	471
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	3
Physical Unit	px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DCTClseDg`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTClseDg	String	9	

Read Variable Response:

`sRA DCTClseDg <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTClseDg	String	9	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCTClseDg <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTClseDg	String	9	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCTClseDg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTClseDg	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTClseDg[ETX]
Read Variable Response:	[STX]sRA DCTClseDg 3[ETX]
Write Variable:	[STX]sWN DCTClseDg 3[ETX]
Write Variable Response:	[STX]sWA DCTClseDg[ETX]

2.13.10.11. Variable: DotCodeTobaccoCloseX

The following section contains a detailed description of the variable DotCodeTobaccoCloseX.

Variable Overview

Variable Name
DotCodeTobaccoCloseX

Communication Name	DCTClseX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	472
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	21
Physical Unit	px
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTClseX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTClseX	String	8	

Read Variable Response:				
`sRA DCTClseX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTClseX	String	8	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCTClseX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTClseX	String	8	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCTClseX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTClseX	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTClseX[ETX]`
Read Variable Response:	`[STX]sRA DCTClseX 15[ETX]`
Write Variable:	`[STX]sWN DCTClseX 15[ETX]`
Write Variable Response:	`[STX]sWA DCTClseX[ETX]`

© SICK AG - Germany - All rights reserved

2.13.10.12. Variable: DotCodeTobaccoCloseY

The following section contains a detailed description of the variable DotCodeTobaccoCloseY.

Variable Overview

Variable Name
DotCodeTobaccoCloseY

Communication Name	DCTClseY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	473
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	1
Physical Unit	px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCTClseY
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTClseY	String	8	

Read Variable Response:

```
sRA DCTClseY <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTClseY	String	8	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DCTClseY <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTClseY	String	8	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DCTClseY
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTClseY	String	8	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTClseY[ETX]`
Read Variable Response:	`[STX]sRA DCTClseY 1[ETX]`
Write Variable:	`[STX]sWN DCTClseY 1[ETX]`
Write Variable Response:	`[STX]sWA DCTClseY[ETX]`

2.13.10.13. Variable: DotCodeTobaccoDeviationLengthX

The following section contains a detailed description of the variable DotCodeTobaccoDeviationLengthX.

Variable Overview

Variable Name
DotCodeTobaccoDeviationLengthX

Communication Name	DCTDevLenX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	474
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	15
Physical Unit	/10 px
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DCTDevLenX
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTDevLenX	String	10	

Read Variable Response:

```
sRA DCTDevLenX <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTDevLenX	String	10	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DCTDevLenX <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTDevLenX	String	10	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA DCTDevLenX				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTDevLenX	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTDevLenX[ETX]
Read Variable Response:	[STX]sRA DCTDevLenX F[ETX]
Write Variable:	[STX]sWN DCTDevLenX F[ETX]
Write Variable Response:	[STX]sWA DCTDevLenX[ETX]

2.13.10.14. Variable: DotCodeTobaccoDeviationLengthY

The following section contains a detailed description of the variable DotCodeTobaccoDeviationLengthY.

Variable Overview

Variable Name
DotCodeTobaccoDeviationLengthY

Communication Name	DCTDevLenY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	475
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..4294967295
Initialisation	15
Physical Unit	/10 px
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCTDevLenY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTDevLenY	String	10	

Read Variable Response:				
`sRA DCTDevLenY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTDevLenY	String	10	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DCTDevLenY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTDevLenY	String	10	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DCTDevLenY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTDevLenY	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCTDevLenY[ETX]`
Read Variable Response:	`[STX]sRA DCTDevLenY F[ETX]`
Write Variable:	`[STX]sWN DCTDevLenY F[ETX]`
Write Variable Response:	`[STX]sWA DCTDevLenY[ETX]`

© SICK AG - Germany - All rights reserved

2.14. Interface Block: GeneralCfgOCR

2.14.1. Group: OCRGeneral

2.14.1.1. Variable: OCRActive

The following section contains a detailed description of the variable OCRActive.

Variable Overview

Variable Name	Description
OCRActive	Activates OCR Decoder

Communication Name	OCRAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	476
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OCRAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRAct	String	6	Activates OCR Decoder

Read Variable Response:

```
sRA OCRAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRAct	String	6	Activates OCR Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN OCRAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRAct	String	6	Activates OCR Decoder
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCRAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRAct	String	6	Activates OCR Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCRAct[ETX]
Read Variable Response:	[STX]sRA OCRAct 0[ETX]
Write Variable:	[STX]sWN OCRAct 0[ETX]
Write Variable Response:	[STX]sWA OCRAct[ETX]

2.14.1.2. Variable: OCRRegionReferenceMode

The following section contains a detailed description of the variable OCRRegionReferenceMode.

Variable Overview

Variable Name	Description
OCRRegionReferenceMode	Determine if the OCR region is absolute or relative to a code

Communication Name	OCRRegRefMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	477
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		FIXED_POSITION	
	Value	Name	Description
	0	FIXED_POSITION	
	1	FREE_POSITION	
	2	RELATIVE_TO_FRAME	
	3	RELATIVE_TO_CODE	
	4	RELATIVE_TO_PATTERN	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN OCRRegRefMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRRegRefMode	String	13	Determine if the OCR region is absolute or relative to a code

Read Variable Response:				
sRA OCRRegRefMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRRegRefMode	String	13	Determine if the OCR region is absolute or relative to a code
Variable Data	data	Enum8	1	

Write Variable:				
sWN OCRRegRefMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRRegRefMode	String	13	Determine if the OCR region is absolute or relative to a code
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA OCRRegRefMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRRegRefMode	String	13	Determine if the OCR region is absolute or relative to a code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCRRegRefMode[ETX]
Read Variable Response:	[STX]sRA OCRRegRefMode 0[ETX]
Write Variable:	[STX]sWN OCRRegRefMode 0[ETX]
Write Variable Response:	[STX]sWA OCRRegRefMode[ETX]

© SICK AG - Germany - All rights reserved

2.14.1.3. Variable: OCRRegion

The following section contains a detailed description of the variable OCRRegion.

Variable Overview

Variable Name	Description
OCRRegion	Four points defining the OCR region of interest

Communication Name	OCRReg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	478
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
OCRRegionPrimitive	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN OCRReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRReg	String	6	Four points defining the OCR region of interest

Read Variable Response:

```
sRA OCRReg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRReg	String	6	Four points defining the OCR region of interest
Variable Data	data	OCRRegion Primitive	21	

Write Variable:

```
sWN OCRReg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRReg	String	6	Four points defining the OCR region of interest
Variable Data	data	OCRRegion Primitive	21	

Write Variable Response:

```
sWA OCRReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRReg	String	6	Four points defining the OCR region of interest

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCRReg[ETX]`
Read Variable Response:	`[STX]sRA OCRReg 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN OCRReg 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA OCRReg[ETX]`

2.14.1.4. Variable: OCRReferenceCodeRegion

The following section contains a detailed description of the variable OCRReferenceCodeRegion.

Variable Overview

Variable Name	Description
OCRReferenceCodeRegion	Four points defining the Datamatrix reference region for OCR

Communication Name	OCRRefCodeReg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	479
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array			
Length			4
	Struct		
	x		
		DInt	
		Value Range	-2147483648..2147483647
		Initialisation	-1
		Physical Unit	
		Physical Unit Factor	0.0
	y		
		DInt	
		Value Range	-2147483648..2147483647
		Initialisation	-1
		Physical Unit	
		Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN OCRRefCodeReg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRRefCodeReg	String	13	Four points defining the Datamatrix reference region for OCR

Read Variable Response:				
sRA OCRRefCodeReg <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRRefCodeReg	String	13	Four points defining the Datamatrix reference region for OCR
Variable Data	data	Array	32	

Write Variable:				
sWN OCRRefCodeReg <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRRefCodeReg	String	13	Four points defining the Datamatrix reference region for OCR
Variable Data	data	Array	32	

Write Variable Response:				
sWA OCRRefCodeReg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRRefCodeReg	String	13	Four points defining the Datamatrix reference region for OCR

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCRRefCodeReg[ETX]
Read Variable Response:	[STX]sRA OCRRefCodeReg FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF[ETX]
Write Variable:	[STX]sWN OCRRefCodeReg FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF[ETX]
Write Variable Response:	[STX]sWA OCRRefCodeReg[ETX]

© SICK AG - Germany - All rights reserved

2.14.1.5. Variable: OCRReferencePatternRegion

The following section contains a detailed description of the variable OCRReferencePatternRegion.

Variable Overview

Variable Name	Description
OCRReferencePatternRegion	Region containing the reference pattern

Communication Name	OCRRefPatReg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	480
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
OCRRegionPrimitive	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN OCRRefPatReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRRefPatReg	String	12	Region containing the reference pattern

Read Variable Response:

```
sRA OCRRefPatReg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRRefPatReg	String	12	Region containing the reference pattern
Variable Data	data	OCRRegion Primitive	21	

Write Variable:

```
sWN OCRRefPatReg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRRefPatReg	String	12	Region containing the reference pattern
Variable Data	data	OCRRegion Primitive	21	

Write Variable Response:

```
sWA OCRRefPatReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRRefPatReg	String	12	Region containing the reference pattern

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCRRefPatReg[ETX]`
Read Variable Response:	`[STX]sRA OCRRefPatReg 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN OCRRefPatReg 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA OCRRefPatReg[ETX]`

2.14.1.6. Variable: OCRReferencePatternExclusionRegions

The following section contains a detailed description of the variable OCRReferencePatternExclusionRegions.

Variable Overview

Variable Name	Description
OCRReferencePatternExclusionRegions	Region containing the reference pattern

Communication Name	OCRRefPatExRegs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	481
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	0..4
UserType	
OCRRegionPrimitive	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN OCRRefPatExRegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRRefPatExRegs	String	15	Region containing the reference pattern

Read Variable Response:				
`sRA OCRRefPatExRegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRRefPatExRegs	String	15	Region containing the reference pattern
Variable Data	data	Array	84	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OCRRefPatExRegs <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRRefPatExRegs	String	15	Region containing the reference pattern
Variable Data	data	Array	84	

Write Variable Response:				
sWA OCRRefPatExRegs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRRefPatExRegs	String	15	Region containing the reference pattern

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCRRefPatExRegs[ETX]
Read Variable Response:	[STX]sRA OCRRefPatExRegs 0[ETX]
Write Variable:	[STX]sWN OCRRefPatExRegs 0[ETX]
Write Variable Response:	[STX]sWA OCRRefPatExRegs[ETX]

2.14.1.7. Variable: OCRPreprocessMode

The following section contains a detailed description of the variable OCRPreprocessMode.

Variable Overview

Variable Name
OCRPreprocessMode

Communication Name	OCRPreMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	485
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_PREPROCESS_NONE	
	Value	Name	Description
	0	TX_PREPROCESS_NONE	
	1	TX_PREPROCESS_INVERT	
	2	TX_PREPROCESS_AUTOINVERT	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCRPreMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRPreMode	String	10	

Read Variable Response:				
`sRA OCRPreMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRPreMode	String	10	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OCRPreMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRPreMode	String	10	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OCRPreMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRPreMode	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCRPreMode[ETX]`
Read Variable Response:	`[STX]sRA OCRPreMode 0[ETX]`
Write Variable:	`[STX]sWN OCRPreMode 0[ETX]`
Write Variable Response:	`[STX]sWA OCRPreMode[ETX]`

© SICK AG - Germany - All rights reserved

2.14.1.8. Variable: OCRRegionFinderDoTraining

The following section contains a detailed description of the variable OCRRegionFinderDoTraining.

Variable Overview

Variable Name	Description
OCRRegionFinderDoTraining	Flag to start a region teach in with the next image. Resets itself afterwards.

Communication Name	OCRRegDoTrain
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	486
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OCRRegDoTrain
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRRegDoTrain	String	13	Flag to start a region teach in with the next image. Resets itself afterwards.

Read Variable Response:

```
sRA OCRRegDoTrain <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRRegDoTrain	String	13	Flag to start a region teach in with the next image. Resets itself afterwards.
Variable Data	data	Bool	1	

Write Variable:

```
sWN OCRRegDoTrain <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRRegDoTrain	String	13	Flag to start a region teach in with the next image. Resets itself afterwards.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OCRRegDoTrain
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCRRegDoTrain				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OCRRegDoTrain	String	13	Flag to start a region teach in with the next image. Resets itself afterwards.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCRRegDoTrain[ETX]
Read Variable Response:	[STX]sRA OCRRegDoTrain 0[ETX]
Write Variable:	[STX]sWN OCRRegDoTrain 0[ETX]
Write Variable Response:	[STX]sWA OCRRegDoTrain[ETX]

2.14.1.9. Variable: OCRShowScores

The following section contains a detailed description of the variable OCRShowScores.

Variable Overview

Variable Name
OCRShowScores

Communication Name	OCRShwSc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	487
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCRShwSc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRShwSc	String	8	

Read Variable Response:				
`sRA OCRShwSc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRShwSc	String	8	
Variable Data	data	Bool	1	

Write Variable:				
`sWN OCRShwSc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRShwSc	String	8	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OCRShwSc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRShwSc	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCRShwSc[ETX]`
Read Variable Response:	`[STX]sRA OCRShwSc 0[ETX]`
Write Variable:	`[STX]sWN OCRShwSc 0[ETX]`
Write Variable Response:	`[STX]sWA OCRShwSc[ETX]`

© SICK AG - Germany - All rights reserved

2.14.1.10. Variable: OCRDiagLevel

The following section contains a detailed description of the variable OCRDiagLevel.

Variable Overview

Variable Name
OCRDiagLevel

Communication Name	OCRDiagLvl
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	488
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..7
Initialisation	6
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OCRDiagLvl
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCRDiagLvl	String	10	

Read Variable Response:

```
sRA OCRDiagLvl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCRDiagLvl	String	10	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN OCRDiagLvl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCRDiagLvl	String	10	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA OCRDiagLvl
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCRDiagLvl	String	10	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCRDiagLvl[ETX]`
Read Variable Response:	`[STX]sRA OCRDiagLvl 6[ETX]`
Write Variable:	`[STX]sWN OCRDiagLvl 6[ETX]`
Write Variable Response:	`[STX]sWA OCRDiagLvl[ETX]`

2.14.1.11. Method: OCRPushParams

The following section contains a detailed description of the method OCRPushParams.

Method Overview

Method Name	Description
OCRPushParams	Stores the OCR data and parameters to a temporary object (start the Wizard)

Communication Name	OCRPshPrm
Sopas Index	65
Invocation Access	Always

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN OCRPshPrm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	OCRPshPrm	String	9	Stores the OCR data and parameters to a temporary object (start the Wizard)

Method Return Value:				
`sAN OCRPshPrm <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	OCRPshPrm	String	9	Stores the OCR data and parameters to a temporary object (start the Wizard)
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN OCRPshPrm[ETX]`
Method Return Value:	`[STX]sAN OCRPshPrm 0[ETX]`

2.14.1.12. Method: OCRPopParams

The following section contains a detailed description of the method OCRPopParams.

Method Overview

Method Name	Description
OCRPopParams	Restores the OCR parameters and data from the temporary object (Wizard was cancelled)

Communication Name	OCRPopPrm
Sopas Index	66
Invocation Access	Always

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN OCRPopPrm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	OCRPopPrm	String	9	Restores the OCR parameters and data from the temporary object (Wizard was cancelled)

Method Return Value:				
`sAN OCRPopPrm <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	OCRPopPrm	String	9	Restores the OCR parameters and data from the temporary object (Wizard was cancelled)
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN OCRPopPrm[ETX]`
Method Return Value:	`[STX]sAN OCRPopPrm 0[ETX]`

2.14.1.13. Method: RequestOCRInformation

The following section contains a detailed description of the method RequestOCRInformation.

Method Overview

Method Name	Description
RequestOCRInformation	Requests information related to the several OCR engines used

Sopas Index	67
Invocation Access	Always

Return Values			
NumItems			
	UDInt		
	Value Range		0..4294967295
	Initialisation		0
	Physical Unit		
	Physical Unit Factor		0.0
NumItemsStored			
	UDInt		
	Value Range		0..4294967295
	Initialisation		0
	Physical Unit		
	Physical Unit Factor		0.0
ItemNameArray			
	Array		
	Length		128
		FlexString	
		Length	0..32
		Initialisation	
ItemContentArray			
	Array		
	Length		128
		FlexString	
		Length	0..128
		Initialisation	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN RequestOCRInformation				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	RequestOCRInformation	String	21	Requests information related to the several OCR engines used

Method Return Value:				
sAN RequestOCRInformation <NumItems> <NumItemsStored> <ItemNameArray> <ItemContentArray>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	RequestOCRInformation	String	21	Requests information related to the several OCR engines used
Return Value 1	NumItems	UDInt	4	
Return Value 2	NumItemsStored	UDInt	4	
Return Value 3	ItemNameArray	Array	4096	
Return Value 4	ItemContentArray	Array	16384	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN RequestOCRInformation[ETX]
Method Return Value:	[STX]sAN RequestOCRInformation 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

2.14.2. Group: OCR3

2.14.2.1. Variable: OCR3AbortTime_ms

The following section contains a detailed description of the variable OCR3AbortTime_ms.

Variable Overview

Variable Name	Description
OCR3AbortTime_ms	Abort time in ms

Communication Name	OCR3Abtms
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	489
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	-1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OCR3Abtms
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3Abtms	String	9	Abort time in ms

Read Variable Response:

```
sRA OCR3Abtms <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3Abtms	String	9	Abort time in ms
Variable Data	data	DInt	4	

Write Variable:

```
sWN OCR3Abtms <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3Abtms	String	9	Abort time in ms
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCR3Abtms				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3Abtms	String	9	Abort time in ms

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3Abtms[ETX]
Read Variable Response:	[STX]sRA OCR3Abtms FFFFFFFF[ETX]
Write Variable:	[STX]sWN OCR3Abtms FFFFFFFF[ETX]
Write Variable Response:	[STX]sWA OCR3Abtms[ETX]

2.14.2.2. Variable: OCR3UseFullReader

The following section contains a detailed description of the variable OCR3UseFullReader.

Variable Overview

Variable Name	Description
OCR3UseFullReader	Enables using the full reader

Communication Name	OCR3FullRd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	490
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCR3FullRd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3FullRd	String	10	Enables using the full reader

Read Variable Response:				
`sRA OCR3FullRd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3FullRd	String	10	Enables using the full reader
Variable Data	data	Bool	1	

Write Variable:				
`sWN OCR3FullRd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3FullRd	String	10	Enables using the full reader
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OCR3FullRd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3FullRd	String	10	Enables using the full reader

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3FullRd[ETX]`
Read Variable Response:	`[STX]sRA OCR3FullRd 1[ETX]`
Write Variable:	`[STX]sWN OCR3FullRd 1[ETX]`
Write Variable Response:	`[STX]sWA OCR3FullRd[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.3. Variable: OCR3DoRowFind

The following section contains a detailed description of the variable OCR3DoRowFind.

Variable Overview

Variable Name	Description
OCR3DoRowFind	Enables row finding

Communication Name	OCR3DoRwFnd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	491
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN OCR3DoRwFnd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3DoRwFnd	String	11	Enables row finding

Read Variable Response:

```
sRA OCR3DoRwFnd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3DoRwFnd	String	11	Enables row finding
Variable Data	data	Bool	1	

Write Variable:

```
sWN OCR3DoRwFnd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3DoRwFnd	String	11	Enables row finding
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OCR3DoRwFnd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3DoRwFnd	String	11	Enables row finding

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3DoRwFnd[ETX]`
Read Variable Response:	`[STX]sRA OCR3DoRwFnd 1[ETX]`
Write Variable:	`[STX]sWN OCR3DoRwFnd 1[ETX]`
Write Variable Response:	`[STX]sWA OCR3DoRwFnd[ETX]`

2.14.2.4. Variable: OCR3NumRows

The following section contains a detailed description of the variable OCR3NumRows.

Variable Overview

Variable Name	Description
OCR3NumRows	Expected number of rows to be found

Communication Name	OCR3NRw
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	492
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..10
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN OCR3NRw`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3NRw	String	7	Expected number of rows to be found

Read Variable Response:

`sRA OCR3NRw <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3NRw	String	7	Expected number of rows to be found
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OCR3NRw <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3NRw	String	7	Expected number of rows to be found
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA OCR3NRw				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3NRw	String	7	Expected number of rows to be found

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3NRw[ETX]
Read Variable Response:	[STX]sRA OCR3NRw 0[ETX]
Write Variable:	[STX]sWN OCR3NRw 0[ETX]
Write Variable Response:	[STX]sWA OCR3NRw[ETX]

2.14.2.5. Variable: OCR3DoTraining

The following section contains a detailed description of the variable OCR3DoTraining.

Variable Overview

Variable Name
OCR3DoTraining

Communication Name	OCR3DoTrn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	493
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCR3DoTrn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3DoTrn	String	9	

Read Variable Response:				
`sRA OCR3DoTrn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3DoTrn	String	9	
Variable Data	data	Bool	1	

Write Variable:				
`sWN OCR3DoTrn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3DoTrn	String	9	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OCR3DoTrn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3DoTrn	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3DoTrn[ETX]`
Read Variable Response:	`[STX]sRA OCR3DoTrn 0[ETX]`
Write Variable:	`[STX]sWN OCR3DoTrn 0[ETX]`
Write Variable Response:	`[STX]sWA OCR3DoTrn[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.6. Variable: OCR3DontUseHW

The following section contains a detailed description of the variable OCR3DontUseHW.

Variable Overview

Variable Name	Description
OCR3DontUseHW	Disables the usage of height width ratio from the trained font

Communication Name	OCR3NoUseHW
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	494
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OCR3NoUseHW
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3NoUseHW	String	11	Disables the usage of height width ratio from the trained font

Read Variable Response:

```
sRA OCR3NoUseHW <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3NoUseHW	String	11	Disables the usage of height width ratio from the trained font
Variable Data	data	Bool	1	

Write Variable:

```
sWN OCR3NoUseHW <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3NoUseHW	String	11	Disables the usage of height width ratio from the trained font
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OCR3NoUseHW
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCR3NoUseHW				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OCR3NoUseHW	String	11	Disables the usage of height width ratio from the trained font

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3NoUseHW[ETX]
Read Variable Response:	[STX]sRA OCR3NoUseHW 0[ETX]
Write Variable:	[STX]sWN OCR3NoUseHW 0[ETX]
Write Variable Response:	[STX]sWA OCR3NoUseHW[ETX]

2.14.2.7. Variable: OCR3DoDeslant

The following section contains a detailed description of the variable OCR3DoDeslant.

Variable Overview

Variable Name	Description
OCR3DoDeslant	Enables automatic deslanting

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	495
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCR3DoDeslant`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3DoDeslant	String	13	Enables automatic deslanting

Read Variable Response:				
`sRA OCR3DoDeslant <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3DoDeslant	String	13	Enables automatic deslanting
Variable Data	data	Bool	1	

Write Variable:				
`sWN OCR3DoDeslant <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3DoDeslant	String	13	Enables automatic deslanting
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OCR3DoDeslant`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3DoDeslant	String	13	Enables automatic deslanting

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3DoDeslant[ETX]`
Read Variable Response:	`[STX]sRA OCR3DoDeslant 0[ETX]`
Write Variable:	`[STX]sWN OCR3DoDeslant 0[ETX]`
Write Variable Response:	`[STX]sWA OCR3DoDeslant[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.8. Variable: OCR3SlantAngleInDegrees

The following section contains a detailed description of the variable OCR3SlantAngleInDegrees.

Variable Overview

Variable Name	Description
OCR3SlantAngleInDegrees	An integer variable that sets the slant angle

Communication Name	OCR3SlantAngle
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	496
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-180..180
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OCR3SlantAngle
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3SlantAngle	String	14	An integer variable that sets the slant angle

Read Variable Response:

```
sRA OCR3SlantAngle <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3SlantAngle	String	14	An integer variable that sets the slant angle
Variable Data	data	DInt	4	

Write Variable:

```
sWN OCR3SlantAngle <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3SlantAngle	String	14	An integer variable that sets the slant angle
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA OCR3SlantAngle
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3SlantAngle	String	14	An integer variable that sets the slant angle

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3SlantAngle[ETX]`
Read Variable Response:	`[STX]sRA OCR3SlantAngle 0[ETX]`
Write Variable:	`[STX]sWN OCR3SlantAngle 0[ETX]`
Write Variable Response:	`[STX]sWA OCR3SlantAngle[ETX]`

2.14.2.9. Variable: OCR3FieldingMode

The following section contains a detailed description of the variable OCR3FieldingMode.

Variable Overview

Variable Name	Description
OCR3FieldingMode	Switch between OCR and OCV mode

Communication Name	OCR3FMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	498
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		OCV	
	Value	Name	Description
	0	OCR	
	1	OCV	

Variable Telegram Syntax

Read Variable:				
`sRN OCR3FMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3FMd	String	7	Switch between OCR and OCV mode

Read Variable Response:				
`sRA OCR3FMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3FMd	String	7	Switch between OCR and OCV mode
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OCR3FMd <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3FMd	String	7	Switch between OCR and OCV mode
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA OCR3FMd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3FMd	String	7	Switch between OCR and OCV mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3FMd[ETX]
Read Variable Response:	[STX]sRA OCR3FMd 1[ETX]
Write Variable:	[STX]sWN OCR3FMd 1[ETX]
Write Variable Response:	[STX]sWA OCR3FMd[ETX]

2.14.2.10. Variable: OCR3Classifier

The following section contains a detailed description of the variable OCR3Classifier.

Variable Overview

Variable Name	Description
OCR3Classifier	Enabled option does OCR, disabled option should be used for OCV.

Communication Name	OCR3Clss
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	499
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		ALTERNATE	
	Value	Name	Description
	0	STANDARD	
	1	ALTERNATE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCR3Clss`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3Clss	String	8	Enabled option does OCR, disabled option should be used for OCV.

Read Variable Response:				
`sRA OCR3Clss <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3Clss	String	8	Enabled option does OCR, disabled option should be used for OCV.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OCR3Clss <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3Clss	String	8	Enabled option does OCR, disabled option should be used for OCV.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OCR3Clss`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3Clss	String	8	Enabled option does OCR, disabled option should be used for OCV.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3Clss[ETX]`
Read Variable Response:	`[STX]sRA OCR3Clss 1[ETX]`
Write Variable:	`[STX]sWN OCR3Clss 1[ETX]`
Write Variable Response:	`[STX]sWA OCR3Clss[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.11. Variable: OCR3UseAlternateScore

The following section contains a detailed description of the variable OCR3UseAlternateScore.

Variable Overview

Variable Name
OCR3UseAlternateScore

Communication Name	OCR3UseAltSc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	500
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OCR3UseAltSc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3UseAltSc	String	12	

Read Variable Response:

```
sRA OCR3UseAltSc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3UseAltSc	String	12	
Variable Data	data	Bool	1	

Write Variable:

```
sWN OCR3UseAltSc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3UseAltSc	String	12	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OCR3UseAltSc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3UseAltSc	String	12	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3UseAltSc[ETX]`
Read Variable Response:	`[STX]sRA OCR3UseAltSc 0[ETX]`
Write Variable:	`[STX]sWN OCR3UseAltSc 0[ETX]`
Write Variable Response:	`[STX]sWA OCR3UseAltSc[ETX]`

2.14.2.12. Variable: OCR3SubstituteCharacter

The following section contains a detailed description of the variable OCR3SubstituteCharacter.

Variable Overview

Variable Name
OCR3SubstituteCharacter

Communication Name	OCR3SbstCh
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	501
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	1
Initialisation	?

Variable Telegram Syntax

Read Variable:

`sRN OCR3SbstCh`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3SbstCh	String	10	

Read Variable Response:

`sRA OCR3SbstCh <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3SbstCh	String	10	
Variable Data	data	String	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OCR3SbstCh <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3SbstCh	String	10	
Variable Data	data	String	1	

Write Variable Response:				
sWA OCR3SbstCh				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3SbstCh	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3SbstCh[ETX]
Read Variable Response:	[STX]sRA OCR3SbstCh ?[ETX]
Write Variable:	[STX]sWN OCR3SbstCh ?[ETX]
Write Variable Response:	[STX]sWA OCR3SbstCh[ETX]

2.14.2.13. Variable: OCR3UseIdealCharacter

The following section contains a detailed description of the variable OCR3UseIdealCharacter.

Variable Overview

Variable Name
OCR3UseIdealCharacter

Communication Name	OCR3UseIdCh
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	502
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCR3UseIdCh`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3UseIdCh	String	11	

Read Variable Response:				
`sRA OCR3UseIdCh <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3UseIdCh	String	11	
Variable Data	data	Bool	1	

Write Variable:				
`sWN OCR3UseIdCh <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3UseIdCh	String	11	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OCR3UseIdCh`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3UseIdCh	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3UseIdCh[ETX]`
Read Variable Response:	`[STX]sRA OCR3UseIdCh 1[ETX]`
Write Variable:	`[STX]sWN OCR3UseIdCh 1[ETX]`
Write Variable Response:	`[STX]sWA OCR3UseIdCh[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.14. Variable: OCR3IdealCharacterIndices

The following section contains a detailed description of the variable OCR3IdealCharacterIndices.

Variable Overview

Variable Name
OCR3IdealCharacterIndices

Communication Name	OCR3GldChIdx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	503
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		256
	Int	
	Value Range	-1..32767
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN OCR3GldChIdx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3GldChIdx	String	12	

Read Variable Response:				
`sRA OCR3GldChIdx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3GldChIdx	String	12	
Variable Data	data	Array	512	

Write Variable:				
`sWN OCR3GldChIdx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3GldChIdx	String	12	
Variable Data	data	Array	512	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCR3GldChIdx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3GldChIdx	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3GldChIdx[ETX]
Read Variable Response:	[STX]sRA OCR3GldChIdx 0 0 0

Array	
Length	10
Struct	
NumCharacters	
UDInt	
Value Range	0..64
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
Fielding	
FlexString	
Length	0..448
Initialisation	
WarnScore	
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
FailScore	
UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
TrainingString	
FlexString	
Length	0..64
Initialisation	

Variable Telegram Syntax

Read Variable:				
`sRN OCR3RwCfg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3RwCfg	String	9	

Read Variable Response:				
`sRA OCR3RwCfg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3RwCfg	String	9	
Variable Data	data	Array	5240	

Write Variable:				
`sWN OCR3RwCfg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OCR3RwCfg <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OCR3RwCfg	String	9	
Variable Data	data	Array	5240	

Write Variable Response:				
sWA OCR3RwCfg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3RwCfg	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3RwCfg[ETX]
Read Variable Response:	[STX]sRA OCR3RwCfg 0 0 0

Variable Telegram Syntax

Read Variable:				
`sRN OCR3EdWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3EdWd	String	8	Edge width

Read Variable Response:				
`sRA OCR3EdWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3EdWd	String	8	Edge width
Variable Data	data	UDInt	4	

Write Variable:				
`sWN OCR3EdWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3EdWd	String	8	Edge width
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA OCR3EdWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3EdWd	String	8	Edge width

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3EdWd[ETX]`
Read Variable Response:	`[STX]sRA OCR3EdWd 1[ETX]`
Write Variable:	`[STX]sWN OCR3EdWd 1[ETX]`
Write Variable Response:	`[STX]sWA OCR3EdWd[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.17. Variable: OCR3NumBlocks

The following section contains a detailed description of the variable OCR3NumBlocks.

Variable Overview

Variable Name	Description
OCR3NumBlocks	Number of blocks the image is divided into for threshold computation

Communication Name	OCR3NBlcks
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	506
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	4
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OCR3NBlcks
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3NBlcks	String	10	Number of blocks the image is divided into for threshold computation

Read Variable Response:

```
sRA OCR3NBlcks <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3NBlcks	String	10	Number of blocks the image is divided into for threshold computation
Variable Data	data	UDInt	4	

Write Variable:

```
sWN OCR3NBlcks <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3NBlcks	String	10	Number of blocks the image is divided into for threshold computation
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCR3NBlcks				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3NBlcks	String	10	Number of blocks the image is divided into for threshold computation

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3NBlcks[ETX]
Read Variable Response:	[STX]sRA OCR3NBlcks 4[ETX]
Write Variable:	[STX]sWN OCR3NBlcks 4[ETX]
Write Variable Response:	[STX]sWA OCR3NBlcks[ETX]

2.14.2.18. Variable: OCR3ThresholdGain

The following section contains a detailed description of the variable OCR3ThresholdGain.

Variable Overview

Variable Name
OCR3ThresholdGain

Communication Name	OCR3ThGn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	507
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

LReal	
Value Range	See specification IEEE 754
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OCR3ThGn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3ThGn	String	8	

Read Variable Response:				
`sRA OCR3ThGn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3ThGn	String	8	
Variable Data	data	LReal	8	

Write Variable:				
`sWN OCR3ThGn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3ThGn	String	8	
Variable Data	data	LReal	8	

Write Variable Response:				
`sWA OCR3ThGn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3ThGn	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3ThGn[ETX]`
Read Variable Response:	`[STX]sRA OCR3ThGn 3FF0000000000000[ETX]`
Write Variable:	`[STX]sWN OCR3ThGn 3FF0000000000000[ETX]`
Write Variable Response:	`[STX]sWA OCR3ThGn[ETX]`

© SICK AG - Germany - All rights reserved

2.14.2.19. Variable: OCR3ThresholdOffset

The following section contains a detailed description of the variable OCR3ThresholdOffset.

Variable Overview

Variable Name
OCR3ThresholdOffset

Communication Name	OCR3ThOf
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	508
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

LReal	
Value Range	See specification IEEE 754
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OCR3ThOf
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3ThOf	String	8	

Read Variable Response:

```
sRA OCR3ThOf <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3ThOf	String	8	
Variable Data	data	LReal	8	

Write Variable:

```
sWN OCR3ThOf <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3ThOf	String	8	
Variable Data	data	LReal	8	

Write Variable Response:

```
sWA OCR3ThOf
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3ThOf	String	8	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OCR3ThOf[ETX]`
Read Variable Response:	`[STX]sRA OCR3ThOf 0000000000000000[ETX]`
Write Variable:	`[STX]sWN OCR3ThOf 0000000000000000[ETX]`
Write Variable Response:	`[STX]sWA OCR3ThOf[ETX]`

2.14.2.20. Variable: OCR3RowConfigExArray

The following section contains a detailed description of the variable OCR3RowConfigExArray.

Variable Overview

Variable Name
OCR3RowConfigExArray

Communication Name	OCR3RwCfgEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	509
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
HorizontalSpacing			Space between dots in x-direction
	Array		
	Length		10
		UDInt	
		Value Range	0..4294967295
		Initialisation	1
		Physical Unit	
		Physical Unit Factor	0.0
VerticalSpacing			Space between dots in y-direction
	Array		
	Length		10
		UDInt	
		Value Range	0..4294967295
		Initialisation	0
		Physical Unit	
		Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct		
Acceptance		Min expected acceptance. Default value changed from 68 to 62 at advice of Jim Saudargas - ZOPF.20130219
	Array	
	Length	10
		UDInt
		Value Range: 0..4294967295
		Initialisation: 62
		Physical Unit:
		Physical Unit Factor: 0.0
Spacing		Space between two consecutive rows
	Array	
	Length	10
		UDInt
		Value Range: 0..4294967295
		Initialisation: 1
		Physical Unit:
		Physical Unit Factor: 0.0
MinHeight		Minimal height of the row in pixels
	Array	
	Length	10
		UDInt
		Value Range: 0..4294967295
		Initialisation: 20
		Physical Unit:
		Physical Unit Factor: 0.0
MaxHeight		Maximal height of the row in pixels
	Array	
	Length	10
		UDInt
		Value Range: 0..4294967295
		Initialisation: 55
		Physical Unit:
		Physical Unit Factor: 0.0

© SICK AG - Germany - All rights reserved

Struct	
CharacterConstraints	The character specific additonal constraints
Struct	
AspectChangePercent	
Array	
Length	10
UDInt	
Value Range	0..4294967295
Initialisation	400
Physical Unit	
Physical Unit Factor	0.0
MinSizeX	
Array	
Length	10
UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
MaxSizeX	
Array	
Length	10
UDInt	
Value Range	0..4294967295
Initialisation	999
Physical Unit	
Physical Unit Factor	0.0
MinSizeY	
Array	
Length	10
UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
MaxSizeY	
Array	
Length	10
UDInt	
Value Range	0..4294967295
Initialisation	999
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct			
Struct			
Spacing			
	Array		
	Length		10
		UDInt	
		Value Range	0..4294967295
		Initialisation	1
		Physical Unit	
		Physical Unit Factor	0.0
MinArea			Minimal area of a character in pixels
	Array		
	Length		10
		UDInt	
		Value Range	0..4294967295
		Initialisation	20
		Physical Unit	
		Physical Unit Factor	0.0
MaxArea			Maximal area of a character in pixels
	Array		
	Length		10
		UDInt	
		Value Range	0..4294967295
		Initialisation	10000
		Physical Unit	
		Physical Unit Factor	0.0
VariableSplit			
	Array		
	Length		10
		Bool	
		Value Range	False, True
		Initialisation	False
DiscardUndersizeObjects			
	Array		
	Length		10
		Bool	
		Value Range	False, True
		Initialisation	False
DiscardOversizeObjects			
	Array		
	Length		10
		Bool	
		Value Range	False, True
		Initialisation	False

© SICK AG - Germany - All rights reserved

Struct			
	Struct		
	StringSplitting		
		Array	
		Length	10
			Bool
			Value Range	False, True
			Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OCR3RwCfgEx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OCR3RwCfgEx	String	11	

Read Variable Response:

```
sRA OCR3RwCfgEx <HorizontalSpacing> <VerticalSpacing> <Acceptance> <Spacing> <MinHeight> <MaxHeight>
<CharacterConstraints>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OCR3RwCfgEx	String	11	
Variable Data 1	HorizontalSpacing	Array	40	Space between dots in x-direction
Variable Data 2	VerticalSpacing	Array	40	Space between dots in y-direction
Variable Data 3	Acceptance	Array	40	Min expected acceptance. Default value changed from 68 to 62 at advice of Jim Saudargas - ZOPF.20130219
Variable Data 4	Spacing	Array	40	Space between two consecutive rows
Variable Data 5	MinHeight	Array	40	Minimal height of the row in pixels
Variable Data 6	MaxHeight	Array	40	Maximal height of the row in pixels
Variable Data 7	CharacterConstraints	Struct	325	The character specific additonal constraints

Write Variable:

```
sWN OCR3RwCfgEx <HorizontalSpacing> <VerticalSpacing> <Acceptance> <Spacing> <MinHeight> <MaxHeight>
<CharacterConstraints>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OCR3RwCfgEx	String	11	
Variable Data 1	HorizontalSpacing	Array	40	Space between dots in x-direction
Variable Data 2	VerticalSpacing	Array	40	Space between dots in y-direction
Variable Data 3	Acceptance	Array	40	Min expected acceptance. Default value changed from 68 to 62 at advice of Jim Saudargas - ZOPF.20130219
Variable Data 4	Spacing	Array	40	Space between two consecutive rows
Variable Data 5	MinHeight	Array	40	Minimal height of the row in pixels
Variable Data 6	MaxHeight	Array	40	Maximal height of the row in pixels
Variable Data 7	CharacterConstraints	Struct	325	The character specific additonal constraints

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OCR3RwCfgEx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OCR3RwCfgEx	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OCR3RwCfgEx[ETX]
Read Variable Response:	[STX]sRA OCR3RwCfgEx 1 1 1 1 1 1 1 1 1 1 0 0 0 0 0 0 0 0 0 0 3E 3E 3E 3E 3E 3E 3E 3E 3E 3E 1 1 1 1 1 1 1 1 1 1 14 14 14 14 14 14 14 14 14 14 37 37 37 37 37 37 37 37 37 37 190 190 190 190 190 190 190 190 190 190 0 0 0 0 0 0 0 0 0 0 3E7 3E7 3E7 3E7 3E7 3E7 3E7 3E7 3E7 3E7 0 0 0 0 0 0 0 0 0 0 3E7 3E7 3E7 3E7 3E7 3E7 3E7 3E7 3E7 3E7 1 1 1 1 1 1 1 1 1 1 14 14 14 14 14 14 14 14 14 14 2710 2710 2710 2710 2710 2710 2710 2710 2710 2710 2710 0 0 0 0 0 0 0 0 0 0

Method Telegram Syntax

Method Invocation:				
sMN CinCOCDlFt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	CinCOCDlFt	String	10	Deletes the CinC in memory and also the font file

Method Return Value:				
sAN CinCOCDlFt <Success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	CinCOCDlFt	String	10	Deletes the CinC in memory and also the font file
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN CinCOCDlFt[ETX]
Method Return Value:	[STX]sAN CinCOCDlFt 0[ETX]

2.14.2.22. Method: OCR3SetFielding

The following section contains a detailed description of the method OCR3SetFielding.

Method Overview

Method Name	Description
OCR3SetFielding	Changes the fielding (allowed characters) variable without interrupting operation mode of the device. This method can be used for OCR applications.

Communication Name	mSetFielding
Sopas Index	69
Invocation Access	Always

Parameters			
FieldingRows			
	Array		
	Length		0..10
		FlexString	
		Length	0..448
		Initialisation	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mSetFielding <FieldingRows>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSetFielding	String	12	Changes the fielding (allowed characters) variable without interrupting operation mode of the device. This method can be used for OCR applications.
Parameter 1	FieldingRows	Array	4480	

Method Return Value:				
`sAN mSetFielding`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSetFielding	String	12	Changes the fielding (allowed characters) variable without interrupting operation mode of the device. This method can be used for OCR applications.

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSetFielding 0[ETX]`
Method Return Value:	`[STX]sAN mSetFielding[ETX]`

2.14.2.23. Method: OCR3OCVInput

The following section contains a detailed description of the method OCR3OCVInput.

Method Overview

Method Name	Description
OCR3OCVInput	Changes the fielding (allowed characters) variable without interrupting operation mode of the device. This method can be used for OCV applications. There can be up to 10 rows with 64 characters each.

Communication Name	mOCVInput
Sopas Index	70
Invocation Access	Always

Parameters			
OCVTextRows			
	Array		
	Length		0..10
		FlexString	
		Length	0..64
		Initialisation	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mOCVInput <OCVTextRows>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mOCVInput	String	9	Changes the fielding (allowed characters) variable without interrupting operation mode of the device. This method can be used for OCV applications. There can be up to 10 rows with 64 characters each.
Parameter 1	OCVTextRows	Array	640	

Method Return Value:				
`sAN mOCVInput`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mOCVInput	String	9	Changes the fielding (allowed characters) variable without interrupting operation mode of the device. This method can be used for OCV applications. There can be up to 10 rows with 64 characters each.

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mOCVInput 0[ETX]`
Method Return Value:	`[STX]sAN mOCVInput[ETX]`

2.14.2.24. Method: OCR3GetCharInfo

The following section contains a detailed description of the method OCR3GetCharInfo.

Method Overview

Method Name	Description
OCR3GetCharInfo	Retrieves informations about a trained character template

Communication Name	OCR3ChInf
Sopas Index	71
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Parameters	
Character	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
Index	
UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values				
Success				
Bool				
Value Range				False, True
Initialisation				False
Image				
Array				
Length				32
	Array			
	Length			24
		USInt		
		Value Range		0..255
		Initialisation		
		Physical Unit		
		Physical Unit Factor		0.0

Method Telegram Syntax

Method Invocation:

```
sMN OCR3ChInf <Character> <Index>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	OCR3ChInf	String	9	Retrieves informations about a trained character template
Parameter 1	Character	USInt	1	
Parameter 2	Index	UInt	2	

Method Return Value:

```
sAN OCR3ChInf <Success> <Image>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	OCR3ChInf	String	9	Retrieves informations about a trained character template
Return Value 1	Success	Bool	1	
Return Value 2	Image	Array	768	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN OCR3ChInf 0 0[ETX]`
Method Return Value:	`[STX]sAN OCR3ChInf 0 0 0

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN OCR3DlCh <Character> <Index>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	OCR3DlCh	String	8	Deletes a single character template
Parameter 1	Character	USInt	1	
Parameter 2	Index	UInt	2	

Method Return Value:				
`sAN OCR3DlCh <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	OCR3DlCh	String	8	Deletes a single character template
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN OCR3DlCh 0 0[ETX]`
Method Return Value:	`[STX]sAN OCR3DlCh 0[ETX]`

2.14.2.26. Method: OCR3ResetCharStatistics

The following section contains a detailed description of the method OCR3ResetCharStatistics.

Method Overview

Method Name	Description
OCR3ResetCharStatistics	Resets all character statistics to 0

Communication Name	OCR3sChSt
Sopas Index	73
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN OCR3sChSt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	OCR3sChSt	String	9	Resets all character statistics to 0

Method Return Value:				
sAN OCR3sChSt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	OCR3sChSt	String	9	Resets all character statistics to 0

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN OCR3sChSt[ETX]
Method Return Value:	[STX]sAN OCR3sChSt[ETX]

2.14.2.27. Event: OCR3CharStatistics

The following section contains a detailed description of the event OCR3CharStatistics.

Event Overview

Event Name	Description
OCR3CharStatistics	Device may send statistics for each character to sopas

Communication Name	CinOCChSt
Sopas Index	125
Queue Length	1

Parameters	
Character	
USInt	
Value Range	0..255
Index	
UInt	
Value Range	0..65535
Successes	
UDInt	
Value Range	0..4294967295

© SICK AG - Germany - All rights reserved

2.15. Interface Block: GeneralCfgObjAdminBase

2.15.1. Group: TrackingBase

2.15.1.1. Variable: TrackingMode

The following section contains a detailed description of the variable TrackingMode.

Variable Overview

Variable Name	Description
TrackingMode	Operating mode of Tracking

Communication Name	TRTrMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	512
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DISABLED	
	2	TX_SLAVE_OUTPUT	
	4	TX_IMAGE_BASED_TRACKING	

Variable Telegram Syntax

Read Variable:

```
sRN TRTrMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRTrMode	String	8	Operating mode of Tracking

Read Variable Response:

```
sRA TRTrMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRTrMode	String	8	Operating mode of Tracking
Variable Data	data	Enum8	1	

Write Variable:

```
sWN TRTrMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRTrMode	String	8	Operating mode of Tracking
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TRTrMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRTrMode	String	8	Operating mode of Tracking

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TRTrMode[ETX]
Read Variable Response:	[STX]sRA TRTrMode 0[ETX]
Write Variable:	[STX]sWN TRTrMode 0[ETX]
Write Variable Response:	[STX]sWA TRTrMode[ETX]

2.15.1.2. Variable: TrackingTimeOut

The following section contains a detailed description of the variable TrackingTimeOut.

Variable Overview

Variable Name	Description
TrackingTimeOut	Timeout for Tracking

Communication Name	TRTimeout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	513
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..5000
Initialisation	150
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TRTimeout`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRTimeout	String	9	Timeout for Tracking

Read Variable Response:				
`sRA TRTimeout <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRTimeout	String	9	Timeout for Tracking
Variable Data	data	UDInt	4	

Write Variable:				
`sWN TRTimeout <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRTimeout	String	9	Timeout for Tracking
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA TRTimeout`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRTimeout	String	9	Timeout for Tracking

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRTimeout[ETX]`
Read Variable Response:	`[STX]sRA TRTimeout 96[ETX]`
Write Variable:	`[STX]sWN TRTimeout 96[ETX]`
Write Variable Response:	`[STX]sWA TRTimeout[ETX]`

© SICK AG - Germany - All rights reserved

2.15.1.3. Variable: ObjectReleasePoint

The following section contains a detailed description of the variable ObjectReleasePoint.

Variable Overview

Variable Name	Description
ObjectReleasePoint	Object Release Point

Communication Name	TRObjRel
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	514
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..50000
Initialisation	2000
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TRObjRel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRObjRel	String	8	Object Release Point

Read Variable Response:

```
sRA TRObjRel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRObjRel	String	8	Object Release Point
Variable Data	data	UDInt	4	

Write Variable:

```
sWN TRObjRel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRObjRel	String	8	Object Release Point
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA TRObjRel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRObjRel	String	8	Object Release Point

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRObjRel[ETX]`
Read Variable Response:	`[STX]sRA TRObjRel 7D0[ETX]`
Write Variable:	`[STX]sWN TRObjRel 7D0[ETX]`
Write Variable Response:	`[STX]sWA TRObjRel[ETX]`

2.15.1.4. Variable: UseReleaseDelayTime

The following section contains a detailed description of the variable UseReleaseDelayTime.

Variable Overview

Variable Name	Description
UseReleaseDelayTime	Use Release Delay Time for Tracking

Communication Name	TRUseReleaseDelayTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	515
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN TRUseReleaseDelayTime
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRUseReleaseDelayTime	String	21	Use Release Delay Time for Tracking

Read Variable Response:

```
sRA TRUseReleaseDelayTime <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRUseReleaseDelayTime	String	21	Use Release Delay Time for Tracking
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN TRUseReleaseDelayTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRUseReleaseDelayTime	String	21	Use Release Delay Time for Tracking
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA TRUseReleaseDelayTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRUseReleaseDelayTime	String	21	Use Release Delay Time for Tracking

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRUseReleaseDelayTime[ETX]`
Read Variable Response:	`[STX]sRA TRUseReleaseDelayTime 0[ETX]`
Write Variable:	`[STX]sWN TRUseReleaseDelayTime 0[ETX]`
Write Variable Response:	`[STX]sWA TRUseReleaseDelayTime[ETX]`

2.15.1.5. Variable: ReleaseDelayTime

The following section contains a detailed description of the variable ReleaseDelayTime.

Variable Overview

Variable Name	Description
ReleaseDelayTime	Post Release Time for Tracking

Communication Name	TRReleaseDelayTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	516
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..10000
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TRReleaseDelayTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRReleaseDelayTime	String	18	Post Release Time for Tracking

Read Variable Response:				
`sRA TRReleaseDelayTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRReleaseDelayTime	String	18	Post Release Time for Tracking
Variable Data	data	UDInt	4	

Write Variable:				
`sWN TRReleaseDelayTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRReleaseDelayTime	String	18	Post Release Time for Tracking
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA TRReleaseDelayTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRReleaseDelayTime	String	18	Post Release Time for Tracking

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRReleaseDelayTime[ETX]`
Read Variable Response:	`[STX]sRA TRReleaseDelayTime 0[ETX]`
Write Variable:	`[STX]sWN TRReleaseDelayTime 0[ETX]`
Write Variable Response:	`[STX]sWA TRReleaseDelayTime[ETX]`

© SICK AG - Germany - All rights reserved

2.15.1.6. Variable: LabelAssTol

The following section contains a detailed description of the variable LabelAssTol.

Variable Overview

Variable Name	Description
LabelAssTol	Label Assignment Tolerance

Communication Name	TRLabAssTol
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	517
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_LAB_ASS_AUTO	
	1	TX_LAB_ASS_FIX	

Variable Telegram Syntax

Read Variable:

```
sRN TRLabAssTol
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRLabAssTol	String	11	Label Assignment Tolerance

Read Variable Response:

```
sRA TRLabAssTol <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRLabAssTol	String	11	Label Assignment Tolerance
Variable Data	data	Enum8	1	

Write Variable:

```
sWN TRLabAssTol <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRLabAssTol	String	11	Label Assignment Tolerance
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA TRLabAssTol
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRLabAssTol	String	11	Label Assignment Tolerance

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRLabAssTol[ETX]`
Read Variable Response:	`[STX]sRA TRLabAssTol 0[ETX]`
Write Variable:	`[STX]sWN TRLabAssTol 0[ETX]`
Write Variable Response:	`[STX]sWA TRLabAssTol[ETX]`

2.15.1.7. Variable: LabelAssMax

The following section contains a detailed description of the variable LabelAssMax.

Variable Overview

Variable Name	Description
LabelAssMax	Max Label Assignment

Communication Name	TRLabAssMax
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	518
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	50..1000
Initialisation	200
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TRLabAssMax
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRLabAssMax	String	11	Max Label Assignment

Read Variable Response:

```
sRA TRLabAssMax <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRLabAssMax	String	11	Max Label Assignment
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TRLabAssMax <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRLabAssMax	String	11	Max Label Assignment
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA TRLabAssMax				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRLabAssMax	String	11	Max Label Assignment

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TRLabAssMax[ETX]
Read Variable Response:	[STX]sRA TRLabAssMax C8[ETX]
Write Variable:	[STX]sWN TRLabAssMax C8[ETX]
Write Variable Response:	[STX]sWA TRLabAssMax[ETX]

2.15.1.8. Variable: LabelAssFix

The following section contains a detailed description of the variable LabelAssFix.

Variable Overview

Variable Name	Description
LabelAssFix	Fix Label Assignment

Communication Name	TRLabAssFix
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	519
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-1000..1000
Initialisation	50
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TRLabAssFix`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRLabAssFix	String	11	Fix Label Assignment

Read Variable Response:				
`sRA TRLabAssFix <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRLabAssFix	String	11	Fix Label Assignment
Variable Data	data	DInt	4	

Write Variable:				
`sWN TRLabAssFix <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRLabAssFix	String	11	Fix Label Assignment
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA TRLabAssFix`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRLabAssFix	String	11	Fix Label Assignment

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRLabAssFix[ETX]`
Read Variable Response:	`[STX]sRA TRLabAssFix 32[ETX]`
Write Variable:	`[STX]sWN TRLabAssFix 32[ETX]`
Write Variable Response:	`[STX]sWA TRLabAssFix[ETX]`

© SICK AG - Germany - All rights reserved

2.15.1.9. Variable: AssignmentMode

The following section contains a detailed description of the variable AssignmentMode.

Variable Overview

Variable Name	Description
AssignmentMode	Mode for assignment

Communication Name	TRAssMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	520
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_INCREMENT_BASED	
	1	TX_3D_OBJECT_BASED	

Variable Telegram Syntax

Read Variable:				
`sRN TRAssMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRAssMode	String	9	Mode for assignment

Read Variable Response:				
`sRA TRAssMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRAssMode	String	9	Mode for assignment
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TRAssMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRAssMode	String	9	Mode for assignment
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA TRAssMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRAssMode	String	9	Mode for assignment

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRAssMode[ETX]`
Read Variable Response:	`[STX]sRA TRAssMode 0[ETX]`
Write Variable:	`[STX]sWN TRAssMode 0[ETX]`
Write Variable Response:	`[STX]sWA TRAssMode[ETX]`

2.15.1.10. Variable: MinTolerance3D

The following section contains a detailed description of the variable MinTolerance3D.

Variable Overview

Variable Name	Description
MinTolerance3D	Min Tolerance for 3D Assignment

Communication Name	TRMinTol3D
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	521
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-1000..1000
Initialisation	30
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TRMinTol3D
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRMinTol3D	String	10	Min Tolerance for 3D Assignment

Read Variable Response:

```
sRA TRMinTol3D <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRMinTol3D	String	10	Min Tolerance for 3D Assignment
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TRMinTol3D <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRMinTol3D	String	10	Min Tolerance for 3D Assignment
Variable Data	data	DInt	4	

Write Variable Response:				
sWA TRMinTol3D				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRMinTol3D	String	10	Min Tolerance for 3D Assignment

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TRMinTol3D[ETX]
Read Variable Response:	[STX]sRA TRMinTol3D 1E[ETX]
Write Variable:	[STX]sWN TRMinTol3D 1E[ETX]
Write Variable Response:	[STX]sWA TRMinTol3D[ETX]

2.15.1.11. Variable: MaxTolerance3D

The following section contains a detailed description of the variable MaxTolerance3D.

Variable Overview

Variable Name	Description
MaxTolerance3D	Max Tolerance for 3D Assignment

Communication Name	TRMaxTol3D
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	522
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-1000..1000
Initialisation	50
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TRMaxTol3D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRMaxTol3D	String	10	Max Tolerance for 3D Assignment

Read Variable Response:				
`sRA TRMaxTol3D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRMaxTol3D	String	10	Max Tolerance for 3D Assignment
Variable Data	data	DInt	4	

Write Variable:				
`sWN TRMaxTol3D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRMaxTol3D	String	10	Max Tolerance for 3D Assignment
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA TRMaxTol3D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRMaxTol3D	String	10	Max Tolerance for 3D Assignment

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRMaxTol3D[ETX]`
Read Variable Response:	`[STX]sRA TRMaxTol3D 32[ETX]`
Write Variable:	`[STX]sWN TRMaxTol3D 32[ETX]`
Write Variable Response:	`[STX]sWA TRMaxTol3D[ETX]`

© SICK AG - Germany - All rights reserved

2.15.1.12. Variable: StartOfAssignment

The following section contains a detailed description of the variable StartOfAssignment.

Variable Overview

Variable Name	Description
StartOfAssignment	Start of Assignment for 3D Assignment

Communication Name	TRStartOfAss
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	523
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..50000
Initialisation	1000
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TRStartOfAss
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRStartOfAss	String	12	Start of Assignment for 3D Assignment

Read Variable Response:

```
sRA TRStartOfAss <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRStartOfAss	String	12	Start of Assignment for 3D Assignment
Variable Data	data	UDInt	4	

Write Variable:

```
sWN TRStartOfAss <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRStartOfAss	String	12	Start of Assignment for 3D Assignment
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA TRStartOfAss
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRStartOfAss	String	12	Start of Assignment for 3D Assignment

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRStartOfAss[ETX]`
Read Variable Response:	`[STX]sRA TRStartOfAss 3E8[ETX]`
Write Variable:	`[STX]sWN TRStartOfAss 3E8[ETX]`
Write Variable Response:	`[STX]sWA TRStartOfAss[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2. Group: OutputTimingBase

2.15.2.1. Variable: OutputTimingControl

The following section contains a detailed description of the variable OutputTimingControl.

Variable Overview

Variable Name	Description
OutputTimingControl	Switch wether output timing is time or track controlled

Communication Name	OTControl
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	524
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

Variable Telegram Syntax

Read Variable:

```
sRN OTControl
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTControl	String	9	Switch wether output timing is time or track controlled

Read Variable Response:

```
sRA OTControl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTControl	String	9	Switch wether output timing is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:

```
sWN OTControl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTControl	String	9	Switch wether output timing is time or track controlled
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OTControl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTControl	String	9	Switch wether output timing is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OTControl[ETX]
Read Variable Response:	[STX]sRA OTControl 0[ETX]
Write Variable:	[STX]sWN OTControl 0[ETX]
Write Variable Response:	[STX]sWA OTControl[ETX]

2.15.2.2. Variable: OPSendPointTracking

The following section contains a detailed description of the variable OPSendPointTracking.

Variable Overview

Variable Name	Description
OPSendPointTracking	Point of result output if Tracking active

Communication Name	OTSndPntTr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	525
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_OBJECT_RELATED	
	1	TX_END_OF_LABEL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTSndPntTr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSndPntTr	String	10	Point of result output if Tracking active

Read Variable Response:				
`sRA OTSndPntTr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSndPntTr	String	10	Point of result output if Tracking active
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OTSndPntTr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSndPntTr	String	10	Point of result output if Tracking active
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OTSndPntTr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSndPntTr	String	10	Point of result output if Tracking active

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTSndPntTr[ETX]`
Read Variable Response:	`[STX]sRA OTSndPntTr 0[ETX]`
Write Variable:	`[STX]sWN OTSndPntTr 0[ETX]`
Write Variable Response:	`[STX]sWA OTSndPntTr[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.3. Variable: OPCondASAPenum

The following section contains a detailed description of the variable OPCondASAPenum.

Variable Overview

Variable Name	Description
OPCondASAPenum	Condition enum for output if "As soon as possible" active

Communication Name	OTCondASAPenum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	527
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_GOOD_READ	

Variable Telegram Syntax

Read Variable:				
`sRN OTCondASAPenum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTCondASAPenum	String	14	Condition enum for output if "As soon as possible" active

Read Variable Response:				
`sRA OTCondASAPenum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTCondASAPenum	String	14	Condition enum for output if "As soon as possible" active
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OTCondASAPenum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTCondASAPenum	String	14	Condition enum for output if "As soon as possible" active
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OTCondASAPenum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OTCondASAPenum				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OTCondASAPenum	String	14	Condition enum for output if "As soon as possible" active

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OTCondASAPenum[ETX]
Read Variable Response:	[STX]sRA OTCondASAPenum 0[ETX]
Write Variable:	[STX]sWN OTCondASAPenum 0[ETX]
Write Variable Response:	[STX]sWA OTCondASAPenum[ETX]

2.15.2.4. Variable: OPCondASAPstruct

The following section contains a detailed description of the variable OPCondASAPstruct.

Variable Overview

Variable Name	Description
OPCondASAPstruct	Condition struct for output if "As soon as possible" active

Communication Name	OTCondASAPstruct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	528
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTCondASAPstruct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTCondASAPstruct	String	16	Condition struct for output if "As soon as possible" active

Read Variable Response:				
`sRA OTCondASAPstruct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTCondASAPstruct	String	16	Condition struct for output if "As soon as possible" active
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable:				
`sWN OTCondASAPstruct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTCondASAPstruct	String	16	Condition struct for output if "As soon as possible" active
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:				
`sWA OTCondASAPstruct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTCondASAPstruct	String	16	Condition struct for output if "As soon as possible" active

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTCondASAPstruct[ETX]`
Read Variable Response:	`[STX]sRA OTCondASAPstruct 0 0[ETX]`
Write Variable:	`[STX]sWN OTCondASAPstruct 0 0[ETX]`
Write Variable Response:	`[STX]sWA OTCondASAPstruct[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.5. Variable: OutputSendingPointReference

The following section contains a detailed description of the variable OutputSendingPointReference.

Variable Overview

Variable Name	Description
OutputSendingPointReference	Point of result output if object related

Communication Name	OTSndPntRef
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	529
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_REFERED_TO_TRAILING_EDGE	
	1	TX_REFERED_TO_LEADING_EDGE	

Variable Telegram Syntax

Read Variable:				
`sRN OTSndPntRef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSndPntRef	String	11	Point of result output if object related

Read Variable Response:				
`sRA OTSndPntRef <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSndPntRef	String	11	Point of result output if object related
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OTSndPntRef <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSndPntRef	String	11	Point of result output if object related
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OTSndPntRef`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSndPntRef	String	11	Point of result output if object related

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTSndPntRef[ETX]`
Read Variable Response:	`[STX]sRA OTSndPntRef 0[ETX]`
Write Variable:	`[STX]sWN OTSndPntRef 0[ETX]`
Write Variable Response:	`[STX]sWA OTSndPntRef[ETX]`

2.15.2.6. Variable: OutputSendingPointDistance

The following section contains a detailed description of the variable OutputSendingPointDistance.

Variable Overview

Variable Name	Description
OutputSendingPointDistance	Distance of result output if object related

Communication Name	OTSndPntDst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	530
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	2500
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OTSndPntDst
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSndPntDst	String	11	Distance of result output if object related

Read Variable Response:

```
sRA OTSndPntDst <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSndPntDst	String	11	Distance of result output if object related
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OTSndPntDst <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSndPntDst	String	11	Distance of result output if object related
Variable Data	data	UInt	2	

Write Variable Response:				
sWA OTSndPntDst				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSndPntDst	String	11	Distance of result output if object related

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OTSndPntDst[ETX]
Read Variable Response:	[STX]sRA OTSndPntDst 9C4[ETX]
Write Variable:	[STX]sWN OTSndPntDst 9C4[ETX]
Write Variable Response:	[STX]sWA OTSndPntDst[ETX]

2.15.2.7. Variable: OutputSendingPointTime

The following section contains a detailed description of the variable OutputSendingPointTime.

Variable Overview

Variable Name	Description
OutputSendingPointTime	Time of result output if object related

Communication Name	OTSndPntTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	531
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	2500
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTSndPntTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSndPntTime	String	12	Time of result output if object related

Read Variable Response:				
`sRA OTSndPntTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSndPntTime	String	12	Time of result output if object related
Variable Data	data	UInt	2	

Write Variable:				
`sWN OTSndPntTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSndPntTime	String	12	Time of result output if object related
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA OTSndPntTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSndPntTime	String	12	Time of result output if object related

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTSndPntTime[ETX]`
Read Variable Response:	`[STX]sRA OTSndPntTime 9C4[ETX]`
Write Variable:	`[STX]sWN OTSndPntTime 9C4[ETX]`
Write Variable Response:	`[STX]sWA OTSndPntTime[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.8. Variable: OutputDelayTime

The following section contains a detailed description of the variable OutputDelayTime.

Variable Overview

Variable Name	Description
OutputDelayTime	Output delay if time controlled

Communication Name	OTDelayTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	532
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..5000
Initialisation	200
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OTDelayTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTDelayTm	String	9	Output delay if time controlled

Read Variable Response:

```
sRA OTDelayTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTDelayTm	String	9	Output delay if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN OTDelayTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTDelayTm	String	9	Output delay if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA OTDelayTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTDelayTm	String	9	Output delay if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTDelayTm[ETX]`
Read Variable Response:	`[STX]sRA OTDelayTm C8[ETX]`
Write Variable:	`[STX]sWN OTDelayTm C8[ETX]`
Write Variable Response:	`[STX]sWA OTDelayTm[ETX]`

2.15.2.9. Variable: OutputDelayTrack

The following section contains a detailed description of the variable OutputDelayTrack.

Variable Overview

Variable Name	Description
OutputDelayTrack	Output delay if track controlled

Communication Name	OTDelayTk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	533
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..50000
Initialisation	200
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN OTDelayTk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTDelayTk	String	9	Output delay if track controlled

Read Variable Response:

`sRA OTDelayTk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTDelayTk	String	9	Output delay if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN OTDelayTk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTDelayTk	String	9	Output delay if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA OTDelayTk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTDelayTk	String	9	Output delay if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTDelayTk[ETX]`
Read Variable Response:	`[STX]sRA OTDelayTk C8[ETX]`
Write Variable:	`[STX]sWN OTDelayTk C8[ETX]`
Write Variable Response:	`[STX]sWA OTDelayTk[ETX]`

2.15.2.10. Variable: TimeoutTime

The following section contains a detailed description of the variable TimeoutTime.

Variable Overview

Variable Name	Description
TimeoutTime	End of Label and asap timeout if time controlled

Communication Name	OTTimoTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	534
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	500
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTTimoTm	String	8	End of Label and asap timeout if time controlled

Read Variable Response:				
`sRA OTTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTTimoTm	String	8	End of Label and asap timeout if time controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN OTTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTTimoTm	String	8	End of Label and asap timeout if time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA OTTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTTimoTm	String	8	End of Label and asap timeout if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTTimoTm[ETX]`
Read Variable Response:	`[STX]sRA OTTimoTm 1F4[ETX]`
Write Variable:	`[STX]sWN OTTimoTm 1F4[ETX]`
Write Variable Response:	`[STX]sWA OTTimoTm[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.11. Variable: TimeoutTrack

The following section contains a detailed description of the variable TimeoutTrack.

Variable Overview

Variable Name	Description
TimeoutTrack	End of label and asap timeout if track controlled

Communication Name	OTTimoTk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	535
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	500
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OTTimoTk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTTimoTk	String	8	End of label and asap timeout if track controlled

Read Variable Response:

```
sRA OTTimoTk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTTimoTk	String	8	End of label and asap timeout if track controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN OTTimoTk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTTimoTk	String	8	End of label and asap timeout if track controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA OTTimoTk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTTimoTk	String	8	End of label and asap timeout if track controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTTimoTk[ETX]`
Read Variable Response:	`[STX]sRA OTTimoTk 1F4[ETX]`
Write Variable:	`[STX]sWN OTTimoTk 1F4[ETX]`
Write Variable Response:	`[STX]sWA OTTimoTk[ETX]`

2.15.2.12. Variable: ASAPLabelTimoutTrack

The following section contains a detailed description of the variable ASAPLabelTimoutTrack.

Variable Overview

Variable Name	Description
ASAPLabelTimoutTrack	Timeout distance for one label in ASAP mode

Communication Name	TRASAPLabTimoTk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	538
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..50000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN TRASAPLabTimoTk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRASAPLabTimoTk	String	15	Timeout distance for one label in ASAP mode

Read Variable Response:

`sRA TRASAPLabTimoTk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRASAPLabTimoTk	String	15	Timeout distance for one label in ASAP mode
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TRASAPLabTimoTk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRASAPLabTimoTk	String	15	Timeout distance for one label in ASAP mode
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA TRASAPLabTimoTk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRASAPLabTimoTk	String	15	Timeout distance for one label in ASAP mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TRASAPLabTimoTk[ETX]
Read Variable Response:	[STX]sRA TRASAPLabTimoTk 64[ETX]
Write Variable:	[STX]sWN TRASAPLabTimoTk 64[ETX]
Write Variable Response:	[STX]sWA TRASAPLabTimoTk[ETX]

2.15.2.13. Variable: ASAPConditionTimoutTrack

The following section contains a detailed description of the variable ASAPConditionTimoutTrack.

Variable Overview

Variable Name	Description
ASAPConditionTimoutTrack	Timeout distance for one condition in ASAP mode

Communication Name	TRASAPCondTimoTk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	540
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..50000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TRASAPCondTimoTk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRASAPCondTimoTk	String	16	Timeout distance for one condition in ASAP mode

Read Variable Response:				
`sRA TRASAPCondTimoTk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRASAPCondTimoTk	String	16	Timeout distance for one condition in ASAP mode
Variable Data	data	UDInt	4	

Write Variable:				
`sWN TRASAPCondTimoTk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRASAPCondTimoTk	String	16	Timeout distance for one condition in ASAP mode
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA TRASAPCondTimoTk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRASAPCondTimoTk	String	16	Timeout distance for one condition in ASAP mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRASAPCondTimoTk[ETX]`
Read Variable Response:	`[STX]sRA TRASAPCondTimoTk 64[ETX]`
Write Variable:	`[STX]sWN TRASAPCondTimoTk 64[ETX]`
Write Variable Response:	`[STX]sWA TRASAPCondTimoTk[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.14. Variable: CodeFilterDepth

The following section contains a detailed description of the variable CodeFilterDepth.

Variable Overview

Variable Name	Description
CodeFilterDepth	Depth of the label content filter

Communication Name	TRCdFltrDpt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	541
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..50
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TRCdFltrDpt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRCdFltrDpt	String	11	Depth of the label content filter

Read Variable Response:

```
sRA TRCdFltrDpt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRCdFltrDpt	String	11	Depth of the label content filter
Variable Data	data	UDInt	4	

Write Variable:

```
sWN TRCdFltrDpt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRCdFltrDpt	String	11	Depth of the label content filter
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA TRCdFltrDpt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRCdFltrDpt	String	11	Depth of the label content filter

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRCdFltrDpt[ETX]`
Read Variable Response:	`[STX]sRA TRCdFltrDpt 1[ETX]`
Write Variable:	`[STX]sWN TRCdFltrDpt 1[ETX]`
Write Variable Response:	`[STX]sWA TRCdFltrDpt[ETX]`

2.15.2.15. Variable: LabelTimoutTimeActive

The following section contains a detailed description of the variable LabelTimoutTimeActive.

Variable Overview

Variable Name	Description
LabelTimoutTimeActive	Aktivates the label timeout

Communication Name	OTLabTimoAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	542
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN OTLabTimoAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTLabTimoAct	String	12	Aktivates the label timeout

Read Variable Response:				
`sRA OTLabTimoAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTLabTimoAct	String	12	Aktivates the label timeout
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OTLabTimoAct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTLabTimoAct	String	12	Aktivates the label timeout
Variable Data	data	Bool	1	

Write Variable Response:				
sWA OTLabTimoAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTLabTimoAct	String	12	Aktivates the label timeout

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OTLabTimoAct[ETX]
Read Variable Response:	[STX]sRA OTLabTimoAct 0[ETX]
Write Variable:	[STX]sWN OTLabTimoAct 0[ETX]
Write Variable Response:	[STX]sWA OTLabTimoAct[ETX]

2.15.2.16. Variable: LabelTimoutTime

The following section contains a detailed description of the variable LabelTimoutTime.

Variable Overview

Variable Name	Description
LabelTimoutTime	Timeout time for one label

Communication Name	OTLabTimoTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	543
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..60000
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTLabTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTLabTimoTm	String	11	Timeout time for one label

Read Variable Response:				
`sRA OTLabTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTLabTimoTm	String	11	Timeout time for one label
Variable Data	data	UDInt	4	

Write Variable:				
`sWN OTLabTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTLabTimoTm	String	11	Timeout time for one label
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA OTLabTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTLabTimoTm	String	11	Timeout time for one label

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTLabTimoTm[ETX]`
Read Variable Response:	`[STX]sRA OTLabTimoTm 64[ETX]`
Write Variable:	`[STX]sWN OTLabTimoTm 64[ETX]`
Write Variable Response:	`[STX]sWA OTLabTimoTm[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.17. Variable: LabelTimoutTrack

The following section contains a detailed description of the variable LabelTimoutTrack.

Variable Overview

Variable Name	Description
LabelTimoutTrack	Timeout distance for one label

Communication Name	TRLabTimoTk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	544
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..50000
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TRLabTimoTk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TRLabTimoTk	String	11	Timeout distance for one label

Read Variable Response:

```
sRA TRLabTimoTk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TRLabTimoTk	String	11	Timeout distance for one label
Variable Data	data	UDInt	4	

Write Variable:

```
sWN TRLabTimoTk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TRLabTimoTk	String	11	Timeout distance for one label
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA TRLabTimoTk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TRLabTimoTk	String	11	Timeout distance for one label

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TRLabTimoTk[ETX]`
Read Variable Response:	`[STX]sRA TRLabTimoTk 64[ETX]`
Write Variable:	`[STX]sWN TRLabTimoTk 64[ETX]`
Write Variable Response:	`[STX]sWA TRLabTimoTk[ETX]`

2.15.2.18. Variable: SlaveTimeoutTime

The following section contains a detailed description of the variable SlaveTimeoutTime.

Variable Overview

Variable Name	Description
SlaveTimeoutTime	Timeout for slave output mode if time controlled

Communication Name	OTSlvTimoTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	545
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	20
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OTSlvTimoTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSlvTimoTm	String	11	Timeout for slave output mode if time controlled

Read Variable Response:

```
sRA OTSlvTimoTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSlvTimoTm	String	11	Timeout for slave output mode if time controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN OTSlvTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSlvTimoTm	String	11	Timeout for slave output mode if time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA OTSlvTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSlvTimoTm	String	11	Timeout for slave output mode if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTSlvTimoTm[ETX]`
Read Variable Response:	`[STX]sRA OTSlvTimoTm 14[ETX]`
Write Variable:	`[STX]sWN OTSlvTimoTm 14[ETX]`
Write Variable Response:	`[STX]sWA OTSlvTimoTm[ETX]`

2.15.2.19. Variable: SlaveTimeoutTrack

The following section contains a detailed description of the variable SlaveTimeoutTrack.

Variable Overview

Variable Name	Description
SlaveTimeoutTrack	Timeout for slave output if track controlled

Communication Name	OTSlvTimoTk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	546
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	20
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTSlvTimoTk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSlvTimoTk	String	11	Timeout for slave output if track controlled

Read Variable Response:				
`sRA OTSlvTimoTk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSlvTimoTk	String	11	Timeout for slave output if track controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN OTSlvTimoTk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSlvTimoTk	String	11	Timeout for slave output if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA OTSlvTimoTk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSlvTimoTk	String	11	Timeout for slave output if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTSlvTimoTk[ETX]`
Read Variable Response:	`[STX]sRA OTSlvTimoTk 14[ETX]`
Write Variable:	`[STX]sWN OTSlvTimoTk 14[ETX]`
Write Variable Response:	`[STX]sWA OTSlvTimoTk[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.20. Variable: OPSendPointNonTracking

The following section contains a detailed description of the variable OPSendPointNonTracking.

Variable Overview

Variable Name	Description
OPSendPointNonTracking	Point of result output if Tracking disabled

Communication Name	OTSndPntNoTr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	526
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_AS_SOON_AS_POSSIBLE	
	Value	Name	Description
	1	TX_AS_SOON_AS_POSSIBLE	
	3	TX_NEW_LABEL_CONTENT	

Variable Telegram Syntax

Read Variable:				
`sRN OTSndPntNoTr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTSndPntNoTr	String	12	Point of result output if Tracking disabled

Read Variable Response:				
`sRA OTSndPntNoTr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTSndPntNoTr	String	12	Point of result output if Tracking disabled
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OTSndPntNoTr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTSndPntNoTr	String	12	Point of result output if Tracking disabled
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OTSndPntNoTr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTSndPntNoTr	String	12	Point of result output if Tracking disabled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTSndPntNoTr[ETX]`
Read Variable Response:	`[STX]sRA OTSndPntNoTr 1[ETX]`
Write Variable:	`[STX]sWN OTSndPntNoTr 1[ETX]`
Write Variable Response:	`[STX]sWA OTSndPntNoTr[ETX]`

2.15.2.21. Variable: ASAPConditionTimoutTime

The following section contains a detailed description of the variable ASAPConditionTimoutTime.

Variable Overview

Variable Name	Description
ASAPConditionTimoutTime	Timeout time for one condition in ASAP mode

Communication Name	OTASAPCondTimoTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	539
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..60000
Initialisation	1
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OTASAPCondTimoTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTASAPCondTimoTm	String	16	Timeout time for one condition in ASAP mode

Read Variable Response:

```
sRA OTASAPCondTimoTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTASAPCondTimoTm	String	16	Timeout time for one condition in ASAP mode
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OTASAPCondTimoTm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTASAPCondTimoTm	String	16	Timeout time for one condition in ASAP mode
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA OTASAPCondTimoTm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTASAPCondTimoTm	String	16	Timeout time for one condition in ASAP mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OTASAPCondTimoTm[ETX]
Read Variable Response:	[STX]sRA OTASAPCondTimoTm 1[ETX]
Write Variable:	[STX]sWN OTASAPCondTimoTm 1[ETX]
Write Variable Response:	[STX]sWA OTASAPCondTimoTm[ETX]

2.15.2.22. Variable: ASAPLabelTimoutTime

The following section contains a detailed description of the variable ASAPLabelTimoutTime.

Variable Overview

Variable Name	Description
ASAPLabelTimoutTime	Timeout time for one label in ASAP mode

Communication Name	OTASAPLabTimoTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	537
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..60000
Initialisation	1
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OTASAPLabTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTASAPLabTimoTm	String	15	Timeout time for one label in ASAP mode

Read Variable Response:				
`sRA OTASAPLabTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTASAPLabTimoTm	String	15	Timeout time for one label in ASAP mode
Variable Data	data	UDInt	4	

Write Variable:				
`sWN OTASAPLabTimoTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTASAPLabTimoTm	String	15	Timeout time for one label in ASAP mode
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA OTASAPLabTimoTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTASAPLabTimoTm	String	15	Timeout time for one label in ASAP mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTASAPLabTimoTm[ETX]`
Read Variable Response:	`[STX]sRA OTASAPLabTimoTm 1[ETX]`
Write Variable:	`[STX]sWN OTASAPLabTimoTm 1[ETX]`
Write Variable Response:	`[STX]sWA OTASAPLabTimoTm[ETX]`

© SICK AG - Germany - All rights reserved

2.15.2.23. Variable: OutputOutputMode

The following section contains a detailed description of the variable OutputOutputMode.

Variable Overview

Variable Name	Description
OutputOutputMode	Swithces output mode between single and multiple

Communication Name	OTOutMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	536
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_MULTIPLE	
	Value	Name	Description
	0	TX_SINGLE	
	1	TX_MULTIPLE	

Variable Telegram Syntax

Read Variable:				
`sRN OTOutMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OTOutMode	String	9	Swithces output mode between single and multiple

Read Variable Response:				
`sRA OTOutMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OTOutMode	String	9	Swithces output mode between single and multiple
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OTOutMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OTOutMode	String	9	Swithces output mode between single and multiple
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OTOutMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OTOutMode	String	9	Swithces output mode between single and multiple

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OTOutMode[ETX]`
Read Variable Response:	`[STX]sRA OTOutMode 1[ETX]`
Write Variable:	`[STX]sWN OTOutMode 1[ETX]`
Write Variable Response:	`[STX]sWA OTOutMode[ETX]`

© SICK AG - Germany - All rights reserved

2.15.3. Group: OutputFormattingBase

2.15.3.1. Variable: HeartbeatString

The following section contains a detailed description of the variable HeartbeatString.

Variable Overview

Variable Name	Description
HeartbeatString	Heartbeat telegram string

Communication Name	OFHBString
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	549
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..256
Initialisation	\x02HeartBeat\x03

Variable Telegram Syntax

Read Variable:

```
sRN OFHBString
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFHBString	String	10	Heartbeat telegram string

Read Variable Response:

```
sRA OFHBString <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFHBString	String	10	Heartbeat telegram string
Variable Data	data	FlexString	256	

Write Variable:

```
sWN OFHBString <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFHBString	String	10	Heartbeat telegram string
Variable Data	data	FlexString	256	

Write Variable Response:

```
sWA OFHBString
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OFHBString				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OFHBString	String	10	Heartbeat telegram string

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFHBString[ETX]
Read Variable Response:	[STX]sRA OFHBString 11 \x02HeartBeat\x03[ETX]
Write Variable:	[STX]sWN OFHBString 11 \x02HeartBeat\x03[ETX]
Write Variable Response:	[STX]sWA OFHBString[ETX]

2.15.3.2. Variable: OFEmbodimentMode

The following section contains a detailed description of the variable OFEmbodimentMode.

Variable Overview

Variable Name	Description
OFEmbodimentMode	Describes how short the output format should be

Communication Name	OFembmode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	550
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_SHORT	
	1	TX_NORMAL	
	2	TX_FULL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OFembmode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFembmode	String	9	Describes how short the output format should be

Read Variable Response:				
`sRA OFembmode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFembmode	String	9	Describes how short the output format should be
Variable Data	data	Enum8	1	

Write Variable:				
`sWN OFembmode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFembmode	String	9	Describes how short the output format should be
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA OFembmode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFembmode	String	9	Describes how short the output format should be

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFembmode[ETX]`
Read Variable Response:	`[STX]sRA OFembmode 0[ETX]`
Write Variable:	`[STX]sWN OFembmode 0[ETX]`
Write Variable Response:	`[STX]sWA OFembmode[ETX]`

© SICK AG - Germany - All rights reserved

2.15.3.3. Variable: OFTemplateString1Maximized

The following section contains a detailed description of the variable OFTemplateString1Maximized.

Variable Overview

Variable Name	Description
OFTemplateString1Maximized	Template String 1 always maximized displayed

Communication Name	OFtplstr1max
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	551
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN OFtplstr1max
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstr1max	String	12	Template String 1 always maximized displayed

Read Variable Response:

```
sRA OFtplstr1max <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstr1max	String	12	Template String 1 always maximized displayed
Variable Data	data	Bool	1	

Write Variable:

```
sWN OFtplstr1max <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstr1max	String	12	Template String 1 always maximized displayed
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OFtplstr1max
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstr1max	String	12	Template String 1 always maximized displayed

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFtplstr1max[ETX]`
Read Variable Response:	`[STX]sRA OFtplstr1max 1[ETX]`
Write Variable:	`[STX]sWN OFtplstr1max 1[ETX]`
Write Variable Response:	`[STX]sWA OFtplstr1max[ETX]`

2.15.3.4. Variable: OFTemplateString2Maximized

The following section contains a detailed description of the variable OFTemplateString2Maximized.

Variable Overview

Variable Name	Description
OFTemplateString2Maximized	Template String 2 always maximized displayed

Communication Name	OFtplstr2max
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	552
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

`sRN OFtplstr2max`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstr2max	String	12	Template String 2 always maximized displayed

Read Variable Response:

`sRA OFtplstr2max <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstr2max	String	12	Template String 2 always maximized displayed
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OFtplstr2max <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstr2max	String	12	Template String 2 always maximized displayed
Variable Data	data	Bool	1	

Write Variable Response:				
sWA OFtplstr2max				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstr2max	String	12	Template String 2 always maximized displayed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFtplstr2max[ETX]
Read Variable Response:	[STX]sRA OFtplstr2max 1[ETX]
Write Variable:	[STX]sWN OFtplstr2max 1[ETX]
Write Variable Response:	[STX]sWA OFtplstr2max[ETX]

2.15.3.5. Variable: OFTemplateStringFixString1

The following section contains a detailed description of the variable OFTemplateStringFixString1.

Variable Overview

Variable Name	Description
OFTemplateStringFixString1	Fix format string 1 editable by SOPAS ET

Communication Name	OFtplstrFix1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	553
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..62
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OFtplstrFix1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstrFix1	String	12	Fix format string 1 editable by SOPAS ET

Read Variable Response:				
`sRA OFtplstrFix1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstrFix1	String	12	Fix format string 1 editable by SOPAS ET
Variable Data	data	FlexString	62	

Write Variable:				
`sWN OFtplstrFix1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstrFix1	String	12	Fix format string 1 editable by SOPAS ET
Variable Data	data	FlexString	62	

Write Variable Response:				
`sWA OFtplstrFix1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstrFix1	String	12	Fix format string 1 editable by SOPAS ET

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFtplstrFix1[ETX]`
Read Variable Response:	`[STX]sRA OFtplstrFix1 0[ETX]`
Write Variable:	`[STX]sWN OFtplstrFix1 0[ETX]`
Write Variable Response:	`[STX]sWA OFtplstrFix1[ETX]`

© SICK AG - Germany - All rights reserved

2.15.3.6. Variable: OFTemplateStringFixString2

The following section contains a detailed description of the variable OFTemplateStringFixString2.

Variable Overview

Variable Name	Description
OFTemplateStringFixString2	Fix format string 2 editable by SOPAS ET

Communication Name	OFtplstrFix2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	554
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..62
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN OFtplstrFix2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstrFix2	String	12	Fix format string 2 editable by SOPAS ET

Read Variable Response:

```
sRA OFtplstrFix2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstrFix2	String	12	Fix format string 2 editable by SOPAS ET
Variable Data	data	FlexString	62	

Write Variable:

```
sWN OFtplstrFix2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstrFix2	String	12	Fix format string 2 editable by SOPAS ET
Variable Data	data	FlexString	62	

Write Variable Response:

```
sWA OFtplstrFix2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstrFix2	String	12	Fix format string 2 editable by SOPAS ET

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFtplstrFix2[ETX]`
Read Variable Response:	`[STX]sRA OFtplstrFix2 0[ETX]`
Write Variable:	`[STX]sWN OFtplstrFix2 0[ETX]`
Write Variable Response:	`[STX]sWA OFtplstrFix2[ETX]`

2.15.3.7. Variable: OFTemplateStringFixString3

The following section contains a detailed description of the variable OFTemplateStringFixString3.

Variable Overview

Variable Name	Description
OFTemplateStringFixString3	Fix format string 3 editable by SOPAS ET

Communication Name	OFtplstrFix3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	555
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..62
Initialisation	

Variable Telegram Syntax

Read Variable:

`sRN OFtplstrFix3`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstrFix3	String	12	Fix format string 3 editable by SOPAS ET

Read Variable Response:

`sRA OFtplstrFix3 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstrFix3	String	12	Fix format string 3 editable by SOPAS ET
Variable Data	data	FlexString	62	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OFtplstrFix3 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstrFix3	String	12	Fix format string 3 editable by SOPAS ET
Variable Data	data	FlexString	62	

Write Variable Response:				
sWA OFtplstrFix3				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstrFix3	String	12	Fix format string 3 editable by SOPAS ET

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFtplstrFix3[ETX]
Read Variable Response:	[STX]sRA OFtplstrFix3 0[ETX]
Write Variable:	[STX]sWN OFtplstrFix3 0[ETX]
Write Variable Response:	[STX]sWA OFtplstrFix3[ETX]

2.15.3.8. Variable: OFTemplateString1

The following section contains a detailed description of the variable OFTemplateString1.

Variable Overview

Variable Name	Description
OFTemplateString1	Temlate string defintion for output definition #1

Communication Name	OFtplstr1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	547
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..1024
Initialisation	\x02[iec _GoodReadCond][f][$BC];[$XMCL];[$YMCL];[$AN2P];[$FAMS][e][e]\x03

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OFtplstr1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstr1	String	9	Temlate string defintion for output definition #1

Read Variable Response:				
`sRA OFtplstr1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstr1	String	9	Temlate string defintion for output definition #1
Variable Data	data	FlexString	1024	

Write Variable:				
`sWN OFtplstr1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstr1	String	9	Temlate string defintion for output definition #1
Variable Data	data	FlexString	1024	

Write Variable Response:				
`sWA OFtplstr1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstr1	String	9	Temlate string defintion for output definition #1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFtplstr1[ETX]`
Read Variable Response:	`[STX]sRA OFtplstr1 49 \x02[iec _GoodReadCond][f][$BC];[$XMCL];[$YMCL];[$AN2P];[$FAMS][e][e]\x03[ETX]`
Write Variable:	`[STX]sWN OFtplstr1 49 \x02[iec _GoodReadCond][f][$BC];[$XMCL];[$YMCL];[$AN2P];[$FAMS][e][e]\x03[ETX]`
Write Variable Response:	`[STX]sWA OFtplstr1[ETX]`

© SICK AG - Germany - All rights reserved

2.15.3.9. Variable: OFTemplateString2

The following section contains a detailed description of the variable OFTemplateString2.

Variable Overview

Variable Name	Description
OFTemplateString2	Template string defintion for output definition #2

Communication Name	OFtplstr2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	548
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..1024
Initialisation	\x02[iec _GoodReadCond][f][$CTX];[$FAMS][e][e]\x03

Variable Telegram Syntax

Read Variable:

```
sRN OFtplstr2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFtplstr2	String	9	Template string defintion for output definition #2

Read Variable Response:

```
sRA OFtplstr2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFtplstr2	String	9	Template string defintion for output definition #2
Variable Data	data	FlexString	1024	

Write Variable:

```
sWN OFtplstr2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFtplstr2	String	9	Template string defintion for output definition #2
Variable Data	data	FlexString	1024	

Write Variable Response:

```
sWA OFtplstr2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFtplstr2	String	9	Template string defintion for output definition #2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFtplstr2[ETX]`
Read Variable Response:	`[STX]sRA OFtplstr2 32 \x02[iec_GoodReadCond][f][$CTX];[$FAMS][e][e]\x03[ETX]`
Write Variable:	`[STX]sWN OFtplstr2 32 \x02[iec_GoodReadCond][f][$CTX];[$FAMS][e][e]\x03[ETX]`
Write Variable Response:	`[STX]sWA OFtplstr2[ETX]`

© SICK AG - Germany - All rights reserved

2.15.4. Group: OutputFormattingScript

2.15.4.1. Variable: OFUsageMode2

The following section contains a detailed description of the variable OFUsageMode2.

Variable Overview

Variable Name	Description
OFUsageMode2	Defines wether OFTemplatString or OFScript should be used for output formattin

Communication Name	OFusmd2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	556
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_STANDARD	
	1	TX_SCRIPT	

Variable Telegram Syntax

Read Variable:

```
sRN OFusmd2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFusmd2	String	7	Defines wether OFTemplatString or OFScript should be used for output formattin

Read Variable Response:

```
sRA OFusmd2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFusmd2	String	7	Defines wether OFTemplatString or OFScript should be used for output formattin
Variable Data	data	Enum8	1	

Write Variable:

```
sWN OFusmd2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFusmd2	String	7	Defines wether OFTemplatString or OFScript should be used for output formattin
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OFusmd2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFusmd2	String	7	Defines wether OFTemplatString or OFScript should be used for output formattin

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFusmd2[ETX]
Read Variable Response:	[STX]sRA OFusmd2 0[ETX]
Write Variable:	[STX]sWN OFusmd2 0[ETX]
Write Variable Response:	[STX]sWA OFusmd2[ETX]

© SICK AG - Germany - All rights reserved

2.15.5. Group: SorterFilterBase

2.15.5.1. Variable: SFStructure1

The following section contains a detailed description of the variable SFStructure1.

Variable Overview

Variable Name	Description
SFStructure1	Describes the structure of the filter/sorter #1

Communication Name	SFstrct1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	558
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	0..128
Default Value	{3, {20, 22, 0}}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SFstrct1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SFstrct1	String	8	Describes the structure of the filter/sorter #1

Read Variable Response:

```
sRA SFstrct1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SFstrct1	String	8	Describes the structure of the filter/sorter #1
Variable Data	data	Array	128	

Write Variable:

```
sWN SFstrct1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SFstrct1	String	8	Describes the structure of the filter/sorter #1
Variable Data	data	Array	128	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SFstrct1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SFstrct1	String	8	Describes the structure of the filter/sorter #1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SFstrct1[ETX]
Read Variable Response:	[STX]sRA SFstrct1 3 14 16 0[ETX]
Write Variable:	[STX]sWN SFstrct1 3 14 16 0[ETX]
Write Variable Response:	[STX]sWA SFstrct1[ETX]

2.15.5.2. Variable: SFStructure2

The following section contains a detailed description of the variable SFStructure2.

Variable Overview

Variable Name	Description
SFStructure2	Describes the structure of the filter/sorter #2

Communication Name	SFstrct2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	559
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		0..128
Default Value		{3, {21, 23, 0}}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN SFstrct2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SFstrct2	String	8	Describes the structure of the filter/sorter #2

Read Variable Response:				
sRA SFstrct2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SFstrct2	String	8	Describes the structure of the filter/sorter #2
Variable Data	data	Array	128	

Write Variable:				
sWN SFstrct2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SFstrct2	String	8	Describes the structure of the filter/sorter #2
Variable Data	data	Array	128	

Write Variable Response:				
sWA SFstrct2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SFstrct2	String	8	Describes the structure of the filter/sorter #2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SFstrct2[ETX]
Read Variable Response:	[STX]sRA SFstrct2 3 15 17 0[ETX]
Write Variable:	[STX]sWN SFstrct2 3 15 17 0[ETX]
Write Variable Response:	[STX]sWA SFstrct2[ETX]

© SICK AG - Germany - All rights reserved

2.15.5.3. Variable: SFParameter

The following section contains a detailed description of the variable SFParameter.

Variable Overview

Variable Name	Description
SFParameter	Parameters of the all filters and sorters

Communication Name	SFprms
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	560
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array				
Length			16	
Default Value			{{1, 0, {5, {0x56, 0x41, 0x4C, 0x3E, 0x30}}},{1, 0, {5, {0x56, 0x41, 0x4C, 0x3E, 0x30}}},{2, 1, {2, {0x43, 0x53}}},{2, 1, {2, {0x43, 0x53}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}},{0, 0, {0, {}}}	
	Struct			
	Type			
		Enum8		
		Default Value	0	
		Value	Name	Description
		0	TX_UNUSED	
		1	TX_FILTER	
		2	TX_SORTER	
	SortDir			
		Enum8		
		Default Value	0	
		Value	Name	Description
		0	TX_ASCENDING	
		1	TX_DESCENDING	
	Condition			
		FlexString		
		Length	0..16	
		Initialisation		

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SFprms`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SFprms	String	6	Parameters of the all filters and sorters

Read Variable Response:				
`sRA SFprms <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SFprms	String	6	Parameters of the all filters and sorters
Variable Data	data	Array	288	

Write Variable:				
`sWN SFprms <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SFprms	String	6	Parameters of the all filters and sorters
Variable Data	data	Array	288	

Write Variable Response:				
`sWA SFprms`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SFprms	String	6	Parameters of the all filters and sorters

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SFprms[ETX]`
Read Variable Response:	`[STX]sRA SFprms 1 0 5 VAL>0 1 0 5 VAL>0 2 1 2 CS 2 1 2 CS 0 0 0

2.15.6. Group: EvalConditions

2.15.6.1. Variable: EVMainGoodReadStruct

The following section contains a detailed description of the variable EVMainGoodReadStruct.

Variable Overview

Variable Name	Description
EVMainGoodReadStruct	Structure for defining good read condition

Communication Name	EVstrgoodr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	561
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_USE_MIN_MAX_CODE_LEN	
UseExtraValue			
	Bool		
	Value Range	False, True	
	Initialisation	False	
ExtraValue			
	FlexString		
	Length	0..18	
	Initialisation		

Variable Telegram Syntax

Read Variable:				
`sRN EVstrgoodr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVstrgoodr	String	10	Structure for defining good read condition

Read Variable Response:				
`sRA EVstrgoodr <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVstrgoodr	String	10	Structure for defining good read condition
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN EVstrgoodr <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVstrgoodr	String	10	Structure for defining good read condition
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA EVstrgoodr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVstrgoodr	String	10	Structure for defining good read condition

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVstrgoodr[ETX]`
Read Variable Response:	`[STX]sRA EVstrgoodr 0 0 0[ETX]`
Write Variable:	`[STX]sWN EVstrgoodr 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA EVstrgoodr[ETX]`

2.15.6.2. Variable: EVMinNbrCodes

The following section contains a detailed description of the variable EVMinNbrCodes.

Variable Overview

Variable Name	Description
EVMinNbrCodes	Minimum number of codes which should be read

Communication Name	EVmincodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	562
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..500
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EVmincodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVmincodes	String	10	Minimum number of codes which should be read

Read Variable Response:				
`sRA EVmincodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVmincodes	String	10	Minimum number of codes which should be read
Variable Data	data	UInt	2	

Write Variable:				
`sWN EVmincodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVmincodes	String	10	Minimum number of codes which should be read
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EVmincodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVmincodes	String	10	Minimum number of codes which should be read

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVmincodes[ETX]`
Read Variable Response:	`[STX]sRA EVmincodes 1[ETX]`
Write Variable:	`[STX]sWN EVmincodes 1[ETX]`
Write Variable Response:	`[STX]sWA EVmincodes[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.3. Variable: EVCheckMinNbr

The following section contains a detailed description of the variable EVCheckMinNbr.

Variable Overview

Variable Name	Description
EVCheckMinNbr	Check minimum number of codes which should be read

Communication Name	EVchkmin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	563
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EVchkmin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVchkmin	String	8	Check minimum number of codes which should be read

Read Variable Response:

```
sRA EVchkmin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVchkmin	String	8	Check minimum number of codes which should be read
Variable Data	data	Bool	1	

Write Variable:

```
sWN EVchkmin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVchkmin	String	8	Check minimum number of codes which should be read
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EVchkmin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EVchkmin				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EVchkmin	String	8	Check minimum number of codes which should be read

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EVchkmin[ETX]
Read Variable Response:	[STX]sRA EVchkmin 0[ETX]
Write Variable:	[STX]sWN EVchkmin 0[ETX]
Write Variable Response:	[STX]sWA EVchkmin[ETX]

2.15.6.4. Variable: EVMaxNbrCodes

The following section contains a detailed description of the variable EVMaxNbrCodes.

Variable Overview

Variable Name	Description
EVMaxNbrCodes	Maximum number of codes which should be read

Communication Name	EVmaxcodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	564
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..500
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EVmaxcodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVmaxcodes	String	10	Maximum number of codes which should be read

Read Variable Response:				
`sRA EVmaxcodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVmaxcodes	String	10	Maximum number of codes which should be read
Variable Data	data	UInt	2	

Write Variable:				
`sWN EVmaxcodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVmaxcodes	String	10	Maximum number of codes which should be read
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EVmaxcodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVmaxcodes	String	10	Maximum number of codes which should be read

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVmaxcodes[ETX]`
Read Variable Response:	`[STX]sRA EVmaxcodes 1[ETX]`
Write Variable:	`[STX]sWN EVmaxcodes 1[ETX]`
Write Variable Response:	`[STX]sWA EVmaxcodes[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.5. Variable: EVCheckMaxNbr

The following section contains a detailed description of the variable EVCheckMaxNbr.

Variable Overview

Variable Name	Description
EVCheckMaxNbr	Check maximum number of codes which should be read

Communication Name	EVchkmax
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	565
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EVchkmax
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVchkmax	String	8	Check maximum number of codes which should be read

Read Variable Response:

```
sRA EVchkmax <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVchkmax	String	8	Check maximum number of codes which should be read
Variable Data	data	Bool	1	

Write Variable:

```
sWN EVchkmax <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVchkmax	String	8	Check maximum number of codes which should be read
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EVchkmax
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EVchkmax				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EVchkmax	String	8	Check maximum number of codes which should be read

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EVchkmax[ETX]
Read Variable Response:	[STX]sRA EVchkmax 0[ETX]
Write Variable:	[STX]sWN EVchkmax 0[ETX]
Write Variable Response:	[STX]sWA EVchkmax[ETX]

2.15.6.6. Variable: EVUserDefCondtionNames

The following section contains a detailed description of the variable EVUserDefCondtionNames.

Variable Overview

Variable Name	Description
EVUserDefCondtionNames	Names of available user defined conditions

Communication Name	EVuserdefcndnames
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	568
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		0..10
Default Value		{0,{}}
	FlexString	
	Length	0..18
	Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EVuserdefcndnames`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVuserdefcndnames	String	17	Names of available user defined conditions

Read Variable Response:				
`sRA EVuserdefcndnames <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVuserdefcndnames	String	17	Names of available user defined conditions
Variable Data	data	Array	180	

Write Variable:				
`sWN EVuserdefcndnames <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVuserdefcndnames	String	17	Names of available user defined conditions
Variable Data	data	Array	180	

Write Variable Response:				
`sWA EVuserdefcndnames`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVuserdefcndnames	String	17	Names of available user defined conditions

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVuserdefcndnames[ETX]`
Read Variable Response:	`[STX]sRA EVuserdefcndnames 0[ETX]`
Write Variable:	`[STX]sWN EVuserdefcndnames 0[ETX]`
Write Variable Response:	`[STX]sWA EVuserdefcndnames[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.7. Variable: EVCondtionDiag

The following section contains a detailed description of the variable EVCondtionDiag.

Variable Overview

Variable Name	Description
EVCondtionDiag	Diagnosis strings buffer when conditon is wrong/missing

Communication Name	EVdiag
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	569
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array				
Length			0..10	
Default Value			{0,{}}	
	Struct			
	CauseKey			
		FlexString		
		Length	0..8	
		Initialisation		
	ConditionName			
		FlexString		
		Length	0..18	
		Initialisation		
	ErrorState			
		Enum8		
		Value	Name	Description
		0	UNKNOWN	
		1	CONDITION_NOT_EXISTS	
		2	CONDITION_OBJ_RELATED_INSTEAD_OF_CODE_RELATED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EVdiag`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVdiag	String	6	Diagnosis strings buffer when conditon is wrong/missing

Read Variable Response:				
`sRA EVdiag <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVdiag	String	6	Diagnosis strings buffer when conditon is wrong/missing
Variable Data	data	Array	270	

Write Variable:				
`sWN EVdiag <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVdiag	String	6	Diagnosis strings buffer when conditon is wrong/missing
Variable Data	data	Array	270	

Write Variable Response:				
`sWA EVdiag`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVdiag	String	6	Diagnosis strings buffer when conditon is wrong/missing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVdiag[ETX]`
Read Variable Response:	`[STX]sRA EVdiag 0[ETX]`
Write Variable:	`[STX]sWN EVdiag 0[ETX]`
Write Variable Response:	`[STX]sWA EVdiag[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.8. Variable: EVRebootOnNoreadEnable

The following section contains a detailed description of the variable EVRebootOnNoreadEnable.

Variable Overview

Variable Name	Description
EVRebootOnNoreadEnable	Enables the reboot on a continious number of noreads

Communication Name	EVrebnoread
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	570
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EVrebnoread
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVrebnoread	String	11	Enables the reboot on a continious number of noreads

Read Variable Response:

```
sRA EVrebnoread <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVrebnoread	String	11	Enables the reboot on a continious number of noreads
Variable Data	data	Bool	1	

Write Variable:

```
sWN EVrebnoread <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVrebnoread	String	11	Enables the reboot on a continious number of noreads
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EVrebnoread
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EVrebnoread				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EVrebnoread	String	11	Enables the reboot on a continious number of noreads

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EVrebnoread[ETX]
Read Variable Response:	[STX]sRA EVrebnoread 0[ETX]
Write Variable:	[STX]sWN EVrebnoread 0[ETX]
Write Variable Response:	[STX]sWA EVrebnoread[ETX]

2.15.6.9. Variable: EVRebootOnNoreadCntr

The following section contains a detailed description of the variable EVRebootOnNoreadCntr.

Variable Overview

Variable Name	Description
EVRebootOnNoreadCntr	Limit of continious no reads after which a reboot is executed

Communication Name	EVrebnoreadcnt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	571
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	1..10000
Initialisation	100
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EVrebnoreadcnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVrebnoreadcnt	String	14	Limit of continious no reads after which a reboot is executed

Read Variable Response:				
`sRA EVrebnoreadcnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVrebnoreadcnt	String	14	Limit of continious no reads after which a reboot is executed
Variable Data	data	UInt	2	

Write Variable:				
`sWN EVrebnoreadcnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVrebnoreadcnt	String	14	Limit of continious no reads after which a reboot is executed
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EVrebnoreadcnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVrebnoreadcnt	String	14	Limit of continious no reads after which a reboot is executed

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVrebnoreadcnt[ETX]`
Read Variable Response:	`[STX]sRA EVrebnoreadcnt 64[ETX]`
Write Variable:	`[STX]sWN EVrebnoreadcnt 64[ETX]`
Write Variable Response:	`[STX]sWA EVrebnoreadcnt[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.10. Variable: EVCondtions

The following section contains a detailed description of the variable EVCondtions.

Variable Overview

Variable Name	Description
EVCondtions	Eval conditions

Communication Name	EVcond
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	566
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array			
Length		0..48	
	Struct		
	Mode		
		Enum8	
		Default Value	0
		Value	Name	Description
		0	TX_NORMAL	
		1	TX_ALWAYS_TRUE	
		2	TX_ALWAYS_FALSE	
	Type		
		Enum8	
		Default Value	0
		Value	Name	Description
		0	TX_MATCH	
		1	TX_FREE	
		2	TX_COMBINATION	
	Relation		
		Enum8	
		Default Value	0
		Value	Name	Description
		0	TX_OBJ_RELATED	
		1	TX_CODE_RELATED	
	DependencyLevel		
		USInt	
		Value Range	0..255
		Initialisation	0
		Physical Unit	
		Physical Unit Factor	0.0
	Condition		
		FlexString	
		Length	0..1024
		Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EVcond`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVcond	String	6	Eval conditions

Read Variable Response:				
`sRA EVcond <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVcond	String	6	Eval conditions
Variable Data	data	Array	49344	

Write Variable:				
`sWN EVcond <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVcond	String	6	Eval conditions
Variable Data	data	Array	49344	

Write Variable Response:				
`sWA EVcond`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVcond	String	6	Eval conditions

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVcond[ETX]`
Read Variable Response:	`[STX]sRA EVcond 0[ETX]`
Write Variable:	`[STX]sWN EVcond 0[ETX]`
Write Variable Response:	`[STX]sWA EVcond[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.11. Variable: EVCondtionNames

The following section contains a detailed description of the variable EVCondtionNames.

Variable Overview

Variable Name	Description
EVCondtionNames	Names of available conditions

Communication Name	EVcndnames
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	567
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	0..48
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN EVcndnames
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVcndnames	String	10	Names of available conditions

Read Variable Response:

```
sRA EVcndnames <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVcndnames	String	10	Names of available conditions
Variable Data	data	Array	864	

Write Variable:

```
sWN EVcndnames <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVcndnames	String	10	Names of available conditions
Variable Data	data	Array	864	

Write Variable Response:

```
sWA EVcndnames
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVcndnames	String	10	Names of available conditions

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EVcndnames[ETX]`
Read Variable Response:	`[STX]sRA EVcndnames 0[ETX]`
Write Variable:	`[STX]sWN EVcndnames 0[ETX]`
Write Variable Response:	`[STX]sWA EVcndnames[ETX]`

2.15.6.12. Method: EVSetMatchCode

The following section contains a detailed description of the method EVSetMatchCode.

Method Overview

Method Name	Description
EVSetMatchCode	Easy matchcode setter

Communication Name	mEVSetMatchCode
Sopas Index	74
Invocation Access	AuthorizedClient, Service

Parameters		
Parameters		
	FlexString	
	Length	0..192
	Initialisation	

Return Values		
Success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mEVSetMatchCode <Parameters>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEVSetMatchCode	String	15	Easy matchcode setter
Parameter 1	Parameters	FlexString	192	

Method Return Value:				
sAN mEVSetMatchCode <Success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEVSetMatchCode	String	15	Easy matchcode setter
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mEVSetMatchCode 0[ETX]
Method Return Value:	[STX]sAN mEVSetMatchCode 0[ETX]

2.15.6.13. Method: mSetMatch

The following section contains a detailed description of the method mSetMatch.

Method Overview

Method Name	Description
mSetMatch	Short matchcode setter

Sopas Index	75
Invocation Access	Always

Parameters		
Name		Name N mapped to MatchN
	String	
	Length	1
	Initialisation	1
CodeID		Ally Welch. * means dont care
	String	
	Length	1
	Initialisation	*

© SICK AG - Germany - All rights reserved

Parameters	
CodeLength	0 means dont care
USInt	
Value Range	0..127
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
CodeContent	no RegEx allowed
FlexString	
Length	0..127
Initialisation	

Return Values	
Success	Could MC be set?
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mSetMatch <Name> <CodeID> <CodeLength> <CodeContent>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSetMatch	String	9	Short matchcode setter
Parameter 1	Name	String	1	Name N mapped to MatchN
Parameter 2	CodeID	String	1	Ally Welch. * means dont care
Parameter 3	CodeLength	USInt	1	0 means dont care
Parameter 4	CodeContent	FlexString	127	no RegEx allowed

Method Return Value:

```
sAN mSetMatch <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSetMatch	String	9	Short matchcode setter
Return Value 1	Success	Bool	1	Could MC be set?

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mSetMatch 1 * 0 0[ETX]`
Method Return Value:	`[STX]sAN mSetMatch 0[ETX]`

© SICK AG - Germany - All rights reserved

2.15.6.14. Method: mGetMatch

The following section contains a detailed description of the method mGetMatch.

Method Overview

Method Name	Description
mGetMatch	Short matchcode getter

Sopas Index	76
Invocation Access	Always

Parameters	
Name	Name N mapped to MatchN
String	
Length	1
Initialisation	1

Return Values	
Success	Could MC be found?
Bool	
Value Range	False, True
Initialisation	False
CodeID	Ally Welch. * means dont care
String	
Length	1
Initialisation	*
CodeLengthMin	0 means dont care
USInt	
Value Range	0..127
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
CodeLengthMax	0 means dont care
USInt	
Value Range	0..127
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
MatchOnlyValidCodes	
Bool	
Value Range	False, True
Initialisation	True
CodeContent	
FlexString	
Length	0..127
Initialisation	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mGetMatch <Name>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mGetMatch	String	9	Short matchcode getter
Parameter 1	Name	String	1	Name N mapped to MatchN

Method Return Value:				
`sAN mGetMatch <Success> <CodeID> <CodeLengthMin> <CodeLengthMax> <MatchOnlyValidCodes> <CodeContent>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mGetMatch	String	9	Short matchcode getter
Return Value 1	Success	Bool	1	Could MC be found?
Return Value 2	CodeID	String	1	Ally Welch. * means dont care
Return Value 3	CodeLengthMin	USInt	1	0 means dont care
Return Value 4	CodeLengthMax	USInt	1	0 means dont care
Return Value 5	MatchOnlyValidCodes	Bool	1	
Return Value 6	CodeContent	FlexString	127	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mGetMatch 1[ETX]`
Method Return Value:	`[STX]sAN mGetMatch 0 * 0 0 1 0[ETX]`

© SICK AG - Germany - All rights reserved

2.15.7. Group: CodePosCompare

2.15.7.1. Variable: CPUseComparison

The following section contains a detailed description of the variable CPUseComparison.

Variable Overview

Variable Name	Description
CPUseComparison	Flag if CP compare is on (TRUE) or off (FALSE)

Communication Name	CPComp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	572
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CPComp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CPComp	String	6	Flag if CP compare is on (TRUE) or off (FALSE)

Read Variable Response:

```
sRA CPComp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CPComp	String	6	Flag if CP compare is on (TRUE) or off (FALSE)
Variable Data	data	Bool	1	

Write Variable:

```
sWN CPComp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CPComp	String	6	Flag if CP compare is on (TRUE) or off (FALSE)
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CPComp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CPComp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CPComp	String	6	Flag if CP compare is on (TRUE) or off (FALSE)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CPComp[ETX]
Read Variable Response:	[STX]sRA CPComp 0[ETX]
Write Variable:	[STX]sWN CPComp 0[ETX]
Write Variable Response:	[STX]sWA CPComp[ETX]

2.15.7.2. Variable: CPCodeDistance

The following section contains a detailed description of the variable CPCodeDistance.

Variable Overview

Variable Name	Description
CPCodeDistance	Max. code distance

Communication Name	CPDist
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	573
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..5000
Initialisation	10
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CPDist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CPDist	String	6	Max. code distance

Read Variable Response:				
`sRA CPDist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CPDist	String	6	Max. code distance
Variable Data	data	UInt	2	

Write Variable:				
`sWN CPDist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CPDist	String	6	Max. code distance
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CPDist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CPDist	String	6	Max. code distance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CPDist[ETX]`
Read Variable Response:	`[STX]sRA CPDist A[ETX]`
Write Variable:	`[STX]sWN CPDist A[ETX]`
Write Variable Response:	`[STX]sWA CPDist[ETX]`

© SICK AG - Germany - All rights reserved

2.15.7.3. Variable: CPCompareDeviceID

The following section contains a detailed description of the variable CPCompareDeviceID.

Variable Overview

Variable Name	Description
CPCompareDeviceID	Flag if device ID shall also be compared

Communication Name	CPCompDID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	574
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CPCompDID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CPCompDID	String	9	Flag if device ID shall also be compared

Read Variable Response:

```
sRA CPCompDID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CPCompDID	String	9	Flag if device ID shall also be compared
Variable Data	data	Bool	1	

Write Variable:

```
sWN CPCompDID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CPCompDID	String	9	Flag if device ID shall also be compared
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CPCompDID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CPCompDID	String	9	Flag if device ID shall also be compared

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CPCompDID[ETX]`
Read Variable Response:	`[STX]sRA CPCompDID 0[ETX]`
Write Variable:	`[STX]sWN CPCompDID 0[ETX]`
Write Variable Response:	`[STX]sWA CPCompDID[ETX]`

© SICK AG - Germany - All rights reserved

2.16. Interface Block: ExtDataString

2.16.1. Group: ExternalDataInput

2.16.1.1. Variable: ExtDataStringDefault

The following section contains a detailed description of the variable ExtDataStringDefault.

Variable Overview

Variable Name	Description
ExtDataStringDefault	When no external data string was received during reading gate ExtDataStringDflt is inserted

Communication Name	ExtDatStrDflt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	575
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..50
Initialisation	"-"

Variable Telegram Syntax

Read Variable:				
`sRN ExtDatStrDflt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExtDatStrDflt	String	13	When no external data string was received during reading gate ExtDataStringDflt is inserted

Read Variable Response:				
`sRA ExtDatStrDflt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExtDatStrDflt	String	13	When no external data string was received during reading gate ExtDataStringDflt is inserted
Variable Data	data	FlexString	50	

Write Variable:				
`sWN ExtDatStrDflt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExtDatStrDflt	String	13	When no external data string was received during reading gate ExtDataStringDflt is inserted
Variable Data	data	FlexString	50	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExtDatStrDflt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExtDatStrDflt	String	13	When no external data string was received during reading gate ExtDataStringDflt is inserted

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExtDatStrDflt[ETX]
Read Variable Response:	[STX]sRA ExtDatStrDflt 3 "-"[ETX]
Write Variable:	[STX]sWN ExtDatStrDflt 3 "-"[ETX]
Write Variable Response:	[STX]sWA ExtDatStrDflt[ETX]

© SICK AG - Germany - All rights reserved

2.17. Interface Block: GeneralCfgCAN1Base

2.17.1. Group: CAN1BusBase

2.17.1.1. Variable: CAN1Baudrate

The following section contains a detailed description of the variable CAN1Baudrate.

Variable Overview

Variable Name	Description
CAN1Baudrate	CAN baudrate (1000, 500, 250, ...)

Communication Name	CIbaud
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	579
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		3	
	Value	Name	Description
	0	TX_1000kB	
	1	TX_800kB	
	2	TX_500kB	
	3	TX_250kB	
	4	TX_125kB	
	5	TX_100kB	
	6	TX_50kB	
	7	TX_20kB	

Variable Telegram Syntax

Read Variable:

```
sRN CIbaud
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIbaud	String	6	CAN baudrate (1000, 500, 250, ...)

Read Variable Response:

```
sRA CIbaud <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIbaud	String	6	CAN baudrate (1000, 500, 250, ...)
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CIbaud <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIbaud	String	6	CAN baudrate (1000, 500, 250, ...)
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA CIbaud				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIbaud	String	6	CAN baudrate (1000, 500, 250, ...)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CIbaud[ETX]
Read Variable Response:	[STX]sRA CIbaud 3[ETX]
Write Variable:	[STX]sWN CIbaud 3[ETX]
Write Variable Response:	[STX]sWA CIbaud[ETX]

2.17.1.2. Variable: CAN1Format

The following section contains a detailed description of the variable CAN1Format.

Variable Overview

Variable Name	Description
CAN1Format	Output format for CAN 1

Communication Name	CIHstFrm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	580
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_OUTPUT	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_OUTPUT_FORMAT_DEF_1	
	2	TX_OUTPUT_FORMAT_DEF_2	
	3	TX_READ_DIAG	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CIHstFrm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIHstFrm	String	8	Output format for CAN 1

Read Variable Response:				
`sRA CIHstFrm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIHstFrm	String	8	Output format for CAN 1
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CIHstFrm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIHstFrm	String	8	Output format for CAN 1
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CIHstFrm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIHstFrm	String	8	Output format for CAN 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIHstFrm[ETX]`
Read Variable Response:	`[STX]sRA CIHstFrm 0[ETX]`
Write Variable:	`[STX]sWN CIHstFrm 0[ETX]`
Write Variable Response:	`[STX]sWA CIHstFrm[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.3. Variable: CAN1DigOutputPdoId

The following section contains a detailed description of the variable CAN1DigOutputPdoId.

Variable Overview

Variable Name	Description
CAN1DigOutputPdoId	COB-Id for the PDO which sends digital Outputs of the sensor

Communication Name	C1_DoID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	581
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x280
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_DoID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_DoID	String	7	COB-Id for the PDO which sends digital Outputs of the sensor

Read Variable Response:

```
sRA C1_DoID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_DoID	String	7	COB-Id for the PDO which sends digital Outputs of the sensor
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_DoID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_DoID	String	7	COB-Id for the PDO which sends digital Outputs of the sensor
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_DoID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_DoID	String	7	COB-Id for the PDO which sends digital Outputs of the sensor

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_DoID[ETX]
Read Variable Response:	[STX]sRA C1_DoID 280[ETX]
Write Variable:	[STX]sWN C1_DoID 280[ETX]
Write Variable Response:	[STX]sWA C1_DoID[ETX]

2.17.1.4. Variable: CAN1DigOutputPdoEna

The following section contains a detailed description of the variable CAN1DigOutputPdoEna.

Variable Overview

Variable Name	Description
CAN1DigOutputPdoEna	Enables sending of Digital output PDO

Communication Name	C1_DoEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	582
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_DoEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_DoEna	String	8	Enables sending of Digital output PDO

Read Variable Response:				
`sRA C1_DoEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_DoEna	String	8	Enables sending of Digital output PDO
Variable Data	data	Bool	1	

Write Variable:				
`sWN C1_DoEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_DoEna	String	8	Enables sending of Digital output PDO
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA C1_DoEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_DoEna	String	8	Enables sending of Digital output PDO

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_DoEna[ETX]`
Read Variable Response:	`[STX]sRA C1_DoEna 0[ETX]`
Write Variable:	`[STX]sWN C1_DoEna 0[ETX]`
Write Variable Response:	`[STX]sWA C1_DoEna[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.5. Variable: CAN1DigInputPdoId

The following section contains a detailed description of the variable CAN1DigInputPdoId.

Variable Overview

Variable Name	Description
CAN1DigInputPdoId	COB-Id for the PDO which receives digital inputs to the sensor

Communication Name	C1_DiIID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	583
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x200
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_DiIID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_DiIID	String	8	COB-Id for the PDO which receives digital inputs to the sensor

Read Variable Response:

```
sRA C1_DiIID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_DiIID	String	8	COB-Id for the PDO which receives digital inputs to the sensor
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_DiIID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_DiIID	String	8	COB-Id for the PDO which receives digital inputs to the sensor
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_DiIID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_DiIID	String	8	COB-Id for the PDO which receives digital inputs to the sensor

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_DiIID[ETX]
Read Variable Response:	[STX]sRA C1_DiIID 200[ETX]
Write Variable:	[STX]sWN C1_DiIID 200[ETX]
Write Variable Response:	[STX]sWA C1_DiIID[ETX]

2.17.1.6. Variable: CAN1DigInputMask

The following section contains a detailed description of the variable CAN1DigInputMask.

Variable Overview

Variable Name	Description
CAN1DigInputMask	Mask for receiving digital input bits

Communication Name	C1_DiMsk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	584
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0xFFFF
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_DiMsk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_DiMsk	String	8	Mask for receiving digital input bits

Read Variable Response:				
`sRA C1_DiMsk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_DiMsk	String	8	Mask for receiving digital input bits
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_DiMsk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_DiMsk	String	8	Mask for receiving digital input bits
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1_DiMsk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_DiMsk	String	8	Mask for receiving digital input bits

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_DiMsk[ETX]`
Read Variable Response:	`[STX]sRA C1_DiMsk FFFF[ETX]`
Write Variable:	`[STX]sWN C1_DiMsk FFFF[ETX]`
Write Variable Response:	`[STX]sWA C1_DiMsk[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.7. Variable: CAN1HBEna

The following section contains a detailed description of the variable CAN1HBEna.

Variable Overview

Variable Name
CAN1HBEna

Communication Name	C1HBEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	585
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN C1HBEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1HBEna	String	7	

Read Variable Response:				
`sRA C1HBEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1HBEna	String	7	
Variable Data	data	Bool	1	

Write Variable:				
`sWN C1HBEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1HBEna	String	7	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA C1HBEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1HBEna	String	7	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1HBEna[ETX]`
Read Variable Response:	`[STX]sRA C1HBEna 0[ETX]`
Write Variable:	`[STX]sWN C1HBEna 0[ETX]`
Write Variable Response:	`[STX]sWA C1HBEna[ETX]`

2.17.1.8. Variable: CAN1HBInterval

The following section contains a detailed description of the variable CAN1HBInterval.

Variable Overview

Variable Name
CAN1HBInterval

Communication Name	C1HBInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	586
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..600
Initialisation	30
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN C1HBInt`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1HBInt	String	7	

Read Variable Response:

`sRA C1HBInt <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1HBInt	String	7	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN C1HBInt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1HBInt	String	7	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1HBInt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1HBInt	String	7	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1HBInt[ETX]`
Read Variable Response:	`[STX]sRA C1HBInt 1E[ETX]`
Write Variable:	`[STX]sWN C1HBInt 1E[ETX]`
Write Variable Response:	`[STX]sWA C1HBInt[ETX]`

2.17.1.9. Variable: CAN1RetrHB

The following section contains a detailed description of the variable CAN1RetrHB.

Variable Overview

Variable Name	Description
CAN1RetrHB	Retrigger heartbeat on Hostinterface

Communication Name	C1RetrHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	587
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1RetrHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1RetrHB	String	8	Retrigger heartbeat on Hostinterface

Read Variable Response:				
`sRA C1RetrHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1RetrHB	String	8	Retrigger heartbeat on Hostinterface
Variable Data	data	Bool	1	

Write Variable:				
`sWN C1RetrHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1RetrHB	String	8	Retrigger heartbeat on Hostinterface
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA C1RetrHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1RetrHB	String	8	Retrigger heartbeat on Hostinterface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1RetrHB[ETX]`
Read Variable Response:	`[STX]sRA C1RetrHB 1[ETX]`
Write Variable:	`[STX]sWN C1RetrHB 1[ETX]`
Write Variable Response:	`[STX]sWA C1RetrHB[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.10. Variable: CAN1UsrIOEna

The following section contains a detailed description of the variable CAN1UsrIOEna.

Variable Overview

Variable Name	Description
CAN1UsrIOEna	Enables receiving ans Sending PDO with user Io data which may be handled by speed skript

Communication Name	C1UIOEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	588
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN C1UIOEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1UIOEna	String	8	Enables receiving ans Sending PDO with user Io data which may be handled by speed skript

Read Variable Response:

```
sRA C1UIOEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1UIOEna	String	8	Enables receiving ans Sending PDO with user Io data which may be handled by speed skript
Variable Data	data	Bool	1	

Write Variable:

```
sWN C1UIOEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1UIOEna	String	8	Enables receiving ans Sending PDO with user Io data which may be handled by speed skript
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA C1UIOEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1UIOEna				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	C1UIOEna	String	8	Enables receiving ans Sending PDO with user Io data which may be handled by speed skript

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1UIOEna[ETX]
Read Variable Response:	[STX]sRA C1UIOEna 0[ETX]
Write Variable:	[STX]sWN C1UIOEna 0[ETX]
Write Variable Response:	[STX]sWA C1UIOEna[ETX]

2.17.1.11. Variable: CAN1UserInpPdoId

The following section contains a detailed description of the variable CAN1UserInpPdoId.

Variable Overview

Variable Name	Description
CAN1UserInpPdoId	COB-Id for the PDO which receives user digital inputs bits which may be handled by SPEED skript

Communication Name	C1UInpID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	589
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x481
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1UInpID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1UInpID	String	8	COB-Id for the PDO which receives user digital inputs bits which may be handled by SPEED skript

Read Variable Response:				
`sRA C1UInpID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1UInpID	String	8	COB-Id for the PDO which receives user digital inputs bits which may be handled by SPEED skript
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1UInpID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1UInpID	String	8	COB-Id for the PDO which receives user digital inputs bits which may be handled by SPEED skript
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1UInpID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1UInpID	String	8	COB-Id for the PDO which receives user digital inputs bits which may be handled by SPEED skript

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1UInpID[ETX]`
Read Variable Response:	`[STX]sRA C1UInpID 481[ETX]`
Write Variable:	`[STX]sWN C1UInpID 481[ETX]`
Write Variable Response:	`[STX]sWA C1UInpID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.12. Variable: CAN1UserInpByteNum

The following section contains a detailed description of the variable CAN1UserInpByteNum.

Variable Overview

Variable Name	Description
CAN1UserInpByteNum	Number of bytes mapped in CAN1UserInpPdo

Communication Name	C1UInpByNum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	590
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x01
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1UInpByNum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1UInpByNum	String	11	Number of bytes mapped in CAN1UserInpPdo

Read Variable Response:

```
sRA C1UInpByNum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1UInpByNum	String	11	Number of bytes mapped in CAN1UserInpPdo
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1UInpByNum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1UInpByNum	String	11	Number of bytes mapped in CAN1UserInpPdo
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA C1UInpByNum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1UInpByNum	String	11	Number of bytes mapped in CAN1UserInpPdo

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1UInpByNum[ETX]`
Read Variable Response:	`[STX]sRA C1UInpByNum 1[ETX]`
Write Variable:	`[STX]sWN C1UInpByNum 1[ETX]`
Write Variable Response:	`[STX]sWA C1UInpByNum[ETX]`

2.17.1.13. Variable: CAN1UserOutpPdoId

The following section contains a detailed description of the variable CAN1UserOutpPdoId.

Variable Overview

Variable Name	Description
CAN1UserOutpPdoId	COB-Id for the PDO which transmits user digital output bits which may be handled by SPEED skript

Communication Name	C1UOutpID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	591
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x480
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN C1UOutpID`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1UOutpID	String	9	COB-Id for the PDO which transmits user digital output bits which may be handled by SPEED skript

Read Variable Response:

`sRA C1UOutpID <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1UOutpID	String	9	COB-Id for the PDO which transmits user digital output bits which may be handled by SPEED skript
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1UOutpID <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1UOutpID	String	9	COB-Id for the PDO which transmits user digital output bits which may be handled by SPEED skript
Variable Data	data	UInt	2	

Write Variable Response:				
sWA C1UOutpID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1UOutpID	String	9	COB-Id for the PDO which transmits user digital output bits which may be handled by SPEED skript

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1UOutpID[ETX]
Read Variable Response:	[STX]sRA C1UOutpID 480[ETX]
Write Variable:	[STX]sWN C1UOutpID 480[ETX]
Write Variable Response:	[STX]sWA C1UOutpID[ETX]

2.17.1.14. Variable: CAN1UserOutpByteNum

The following section contains a detailed description of the variable CAN1UserOutpByteNum.

Variable Overview

Variable Name	Description
CAN1UserOutpByteNum	Number of bytes mapped in CAN1UserOutpPdo

Communication Name	C1UOutpByNum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	592
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x01
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1UOutpByNum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1UOutpByNum	String	12	Number of bytes mapped in CAN1UserOutpPdo

Read Variable Response:				
`sRA C1UOutpByNum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1UOutpByNum	String	12	Number of bytes mapped in CAN1UserOutpPdo
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1UOutpByNum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1UOutpByNum	String	12	Number of bytes mapped in CAN1UserOutpPdo
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1UOutpByNum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1UOutpByNum	String	12	Number of bytes mapped in CAN1UserOutpPdo

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1UOutpByNum[ETX]`
Read Variable Response:	`[STX]sRA C1UOutpByNum 1[ETX]`
Write Variable:	`[STX]sWN C1UOutpByNum 1[ETX]`
Write Variable Response:	`[STX]sWA C1UOutpByNum[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.15. Variable: CAN1TimeStampMode

The following section contains a detailed description of the variable CAN1TimeStampMode.

Variable Overview

Variable Name	Description
CAN1TimeStampMode	The synced timestamp transfer mode

Communication Name	C1TSMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	593
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_CONSUMER	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CONSUMER	
	2	TX_PRODUCER	

Variable Telegram Syntax

Read Variable:

```
sRN C1TSMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1TSMode	String	8	The synced timestamp transfer mode

Read Variable Response:

```
sRA C1TSMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1TSMode	String	8	The synced timestamp transfer mode
Variable Data	data	Enum8	1	

Write Variable:

```
sWN C1TSMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1TSMode	String	8	The synced timestamp transfer mode
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA C1TSMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1TSMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	C1TSMode	String	8	The synced timestamp transfer mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1TSMode[ETX]
Read Variable Response:	[STX]sRA C1TSMode 1[ETX]
Write Variable:	[STX]sWN C1TSMode 1[ETX]
Write Variable Response:	[STX]sWA C1TSMode[ETX]

2.17.1.16. Variable: CAN1TimeStampPeriod

The following section contains a detailed description of the variable CAN1TimeStampPeriod.

Variable Overview

Variable Name	Description
CAN1TimeStampPeriod	Period of the TimeStamp producer in milliseconds

Communication Name	C1TSPeriod
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	594
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	10..3600000
Initialisation	10000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1TSPeriod`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1TSPeriod	String	10	Period of the TimeStamp producer in milliseconds

Read Variable Response:				
`sRA C1TSPeriod <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1TSPeriod	String	10	Period of the TimeStamp producer in milliseconds
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1TSPeriod <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1TSPeriod	String	10	Period of the TimeStamp producer in milliseconds
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1TSPeriod`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1TSPeriod	String	10	Period of the TimeStamp producer in milliseconds

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1TSPeriod[ETX]`
Read Variable Response:	`[STX]sRA C1TSPeriod 2710[ETX]`
Write Variable:	`[STX]sWN C1TSPeriod 2710[ETX]`
Write Variable Response:	`[STX]sWA C1TSPeriod[ETX]`

© SICK AG - Germany - All rights reserved

2.17.1.17. Variable: CAN1Mode

The following section contains a detailed description of the variable CAN1Mode.

Variable Overview

Variable Name	Description
CAN1Mode	CAN mode (none, CANopen, OTC-Mode, ...)

Communication Name	CImode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	577
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_INACTIVE	
	1	TX_SICK_NETWORK	
	2	TX_CAN_OPEN	

Variable Telegram Syntax

Read Variable:

```
sRN CImode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CImode	String	6	CAN mode (none, CANopen, OTC-Mode, ...)

Read Variable Response:

```
sRA CImode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CImode	String	6	CAN mode (none, CANopen, OTC-Mode, ...)
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CImode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CImode	String	6	CAN mode (none, CANopen, OTC-Mode, ...)
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA CImode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CImode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CImode	String	6	CAN mode (none, CANopen, OTC-Mode, ...)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CImode[ETX]
Read Variable Response:	[STX]sRA CImode 0[ETX]
Write Variable:	[STX]sWN CImode 0[ETX]
Write Variable Response:	[STX]sWA CImode[ETX]

© SICK AG - Germany - All rights reserved

2.17.2. Group: CAN1BusCANopen

2.17.2.1. Variable: CAN1ProdHbTime

The following section contains a detailed description of the variable CAN1ProdHbTime.

Variable Overview

Variable Name	Description
CAN1ProdHbTime	Heartbeat time in ms. 0: no Heartbeating

Communication Name	C1_HbTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	595
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_HbTime
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_HbTime	String	9	Heartbeat time in ms. 0: no Heartbeating

Read Variable Response:

```
sRA C1_HbTime <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_HbTime	String	9	Heartbeat time in ms. 0: no Heartbeating
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_HbTime <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_HbTime	String	9	Heartbeat time in ms. 0: no Heartbeating
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_HbTime				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_HbTime	String	9	Heartbeat time in ms. 0: no Heartbeating

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_HbTime[ETX]
Read Variable Response:	[STX]sRA C1_HbTime 0[ETX]
Write Variable:	[STX]sWN C1_HbTime 0[ETX]
Write Variable Response:	[STX]sWA C1_HbTime[ETX]

2.17.2.2. Variable: CAN1ReadResultEnable

The following section contains a detailed description of the variable CAN1ReadResultEnable.

Variable Overview

Variable Name	Description
CAN1ReadResultEnable	If true, device fills objects 0x2000 and ox2001 with read result data. It sends a 'data available PDO' to initiate SDO upload of read result data.

Communication Name	C1_ResEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	596
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_ResEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_ResEna	String	9	If true, device fills objects 0x2000 and ox2001 with read result data. It sends a 'data available PDO' to initiate SDO upload of read result data.

Read Variable Response:				
`sRA C1_ResEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_ResEna	String	9	If true, device fills objects 0x2000 and ox2001 with read result data. It sends a 'data available PDO' to initiate SDO upload of read result data.
Variable Data	data	Bool	1	

Write Variable:				
`sWN C1_ResEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_ResEna	String	9	If true, device fills objects 0x2000 and ox2001 with read result data. It sends a 'data available PDO' to initiate SDO upload of read result data.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA C1_ResEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_ResEna	String	9	If true, device fills objects 0x2000 and ox2001 with read result data. It sends a 'data available PDO' to initiate SDO upload of read result data.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_ResEna[ETX]`
Read Variable Response:	`[STX]sRA C1_ResEna 1[ETX]`
Write Variable:	`[STX]sWN C1_ResEna 1[ETX]`
Write Variable Response:	`[STX]sWA C1_ResEna[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.3. Variable: CAN1SendMode

The following section contains a detailed description of the variable CAN1SendMode.

Variable Overview

Variable Name	Description
CAN1SendMode	Mode to send read result (BySDO, ByPDO)

Communication Name	C1_SMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	597
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_BY_SDO	
	Value	Name	Description
	0	TX_BY_SDO	
	1	TX_BY_PDO	
	2	TX_DISABLED	

Variable Telegram Syntax

Read Variable:

```
sRN C1_SMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_SMode	String	8	Mode to send read result (BySDO, ByPDO)

Read Variable Response:

```
sRA C1_SMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_SMode	String	8	Mode to send read result (BySDO, ByPDO)
Variable Data	data	Enum8	1	

Write Variable:

```
sWN C1_SMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_SMode	String	8	Mode to send read result (BySDO, ByPDO)
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA C1_SMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_SMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	C1_SMode	String	8	Mode to send read result (BySDO, ByPDO)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_SMode[ETX]
Read Variable Response:	[STX]sRA C1_SMode 0[ETX]
Write Variable:	[STX]sWN C1_SMode 0[ETX]
Write Variable Response:	[STX]sWA C1_SMode[ETX]

2.17.2.4. Variable: CAN1_ReadResultTimeout

The following section contains a detailed description of the variable CAN1_ReadResultTimeout.

Variable Overview

Variable Name	Description
CAN1_ReadResultTimeout	Timeout in ms for read result upload after Data available PDO was startet

Communication Name	C1_ResTmo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	598
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	2000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_ResTmo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_ResTmo	String	9	Timeout in ms for read result upload after Data available PDO was startet

Read Variable Response:				
`sRA C1_ResTmo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_ResTmo	String	9	Timeout in ms for read result upload after Data available PDO was startet
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_ResTmo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_ResTmo	String	9	Timeout in ms for read result upload after Data available PDO was startet
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1_ResTmo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_ResTmo	String	9	Timeout in ms for read result upload after Data available PDO was startet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_ResTmo[ETX]`
Read Variable Response:	`[STX]sRA C1_ResTmo 7D0[ETX]`
Write Variable:	`[STX]sWN C1_ResTmo 7D0[ETX]`
Write Variable Response:	`[STX]sWA C1_ResTmo[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.5. Variable: CAN1AutoSdoRelease

The following section contains a detailed description of the variable CAN1AutoSdoRelease.

Variable Overview

Variable Name	Description
CAN1AutoSdoRelease	when to release read result data in SDO mode: user access (write 0 to 0x2000/3) or automatic after first SDO upload was finished

Communication Name	C1_SdoRel
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	599
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN C1_SdoRel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_SdoRel	String	9	when to release read result data in SDO mode: user access (write 0 to 0x2000/3) or automatic after first SDO upload was finished

Read Variable Response:

```
sRA C1_SdoRel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_SdoRel	String	9	when to release read result data in SDO mode: user access (write 0 to 0x2000/3) or automatic after first SDO upload was finished
Variable Data	data	Bool	1	

Write Variable:

```
sWN C1_SdoRel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_SdoRel	String	9	when to release read result data in SDO mode: user access (write 0 to 0x2000/3) or automatic after first SDO upload was finished
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_SdoRel				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_SdoRel	String	9	when to release read result data in SDO mode: user access (write 0 to 0x2000/3) or automatic after first SDO upload was finished

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_SdoRel[ETX]
Read Variable Response:	[STX]sRA C1_SdoRel 0[ETX]
Write Variable:	[STX]sWN C1_SdoRel 0[ETX]
Write Variable Response:	[STX]sWA C1_SdoRel[ETX]

2.17.2.6. Variable: CAN1PdoNum

The following section contains a detailed description of the variable CAN1PdoNum.

Variable Overview

Variable Name	Description
CAN1PdoNum	Number of PDOs to be sent if send mode is TX_BY_PDO. Each PDO has 7 bytes of read result

Communication Name	C1_PdoNum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	600
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	1..7
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_PdoNum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_PdoNum	String	9	Number of PDOs to be sent if send mode is TX_BY_PDO. Each PDO has 7 bytes of read result

Read Variable Response:				
`sRA C1_PdoNum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_PdoNum	String	9	Number of PDOs to be sent if send mode is TX_BY_PDO. Each PDO has 7 bytes of read result
Variable Data	data	USInt	1	

Write Variable:				
`sWN C1_PdoNum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_PdoNum	String	9	Number of PDOs to be sent if send mode is TX_BY_PDO. Each PDO has 7 bytes of read result
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA C1_PdoNum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_PdoNum	String	9	Number of PDOs to be sent if send mode is TX_BY_PDO. Each PDO has 7 bytes of read result

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_PdoNum[ETX]`
Read Variable Response:	`[STX]sRA C1_PdoNum 1[ETX]`
Write Variable:	`[STX]sWN C1_PdoNum 1[ETX]`
Write Variable Response:	`[STX]sWA C1_PdoNum[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.7. Variable: CAN1PdoID

The following section contains a detailed description of the variable CAN1PdoID.

Variable Overview

Variable Name	Description
CAN1PdoID	COB-id of the first PDO of the read result PDO set. The other PDOs have successive identifiers

Communication Name	C1_PdoId
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	601
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x480
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_PdoId
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_PdoId	String	8	COB-id of the first PDO of the read result PDO set. The other PDOs have successive identifiers

Read Variable Response:

```
sRA C1_PdoId <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_PdoId	String	8	COB-id of the first PDO of the read result PDO set. The other PDOs have successive identifiers
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_PdoId <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_PdoId	String	8	COB-id of the first PDO of the read result PDO set. The other PDOs have successive identifiers
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_PdoId				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_PdoId	String	8	COB-id of the first PDO of the read result PDO set. The other PDOs have successive identifiers

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_PdoId[ETX]
Read Variable Response:	[STX]sRA C1_PdoId 480[ETX]
Write Variable:	[STX]sWN C1_PdoId 480[ETX]
Write Variable Response:	[STX]sWA C1_PdoId[ETX]

2.17.2.8. Variable: CAN1PdoTrmType

The following section contains a detailed description of the variable CAN1PdoTrmType.

Variable Overview

Variable Name	Description
CAN1PdoTrmType	Transmission type for all read result TPDOs.

Communication Name	C1_PdoTT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	602
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_PdoTT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_PdoTT	String	8	Transmission type for all read result TPDOs.

Read Variable Response:				
`sRA C1_PdoTT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_PdoTT	String	8	Transmission type for all read result TPDOs.
Variable Data	data	USInt	1	

Write Variable:				
`sWN C1_PdoTT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_PdoTT	String	8	Transmission type for all read result TPDOs.
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA C1_PdoTT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_PdoTT	String	8	Transmission type for all read result TPDOs.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_PdoTT[ETX]`
Read Variable Response:	`[STX]sRA C1_PdoTT FE[ETX]`
Write Variable:	`[STX]sWN C1_PdoTT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_PdoTT[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.9. Variable: CAN1PdoInhibitTime

The following section contains a detailed description of the variable CAN1PdoInhibitTime.

Variable Overview

Variable Name	Description
CAN1PdoInhibitTime	Inhibit time for all read result TPDOs. Unit 100 us

Communication Name	C1_PdoIT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	603
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_PdoIT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_PdoIT	String	8	Inhibit time for all read result TPDOs. Unit 100 us

Read Variable Response:

```
sRA C1_PdoIT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_PdoIT	String	8	Inhibit time for all read result TPDOs. Unit 100 us
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_PdoIT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_PdoIT	String	8	Inhibit time for all read result TPDOs. Unit 100 us
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA C1_PdoIT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_PdoIT	String	8	Inhibit time for all read result TPDOs. Unit 100 us

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_PdoIT[ETX]`
Read Variable Response:	`[STX]sRA C1_PdoIT 0[ETX]`
Write Variable:	`[STX]sWN C1_PdoIT 0[ETX]`
Write Variable Response:	`[STX]sWA C1_PdoIT[ETX]`

2.17.2.10. Variable: CAN1PdoEventTime

The following section contains a detailed description of the variable CAN1PdoEventTime.

Variable Overview

Variable Name	Description
CAN1PdoEventTime	Event time for all read result TPDOs. Unit 1 ms

Communication Name	C1_PdoET
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	604
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_PdoET
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_PdoET	String	8	Event time for all read result TPDOs. Unit 1 ms

Read Variable Response:

```
sRA C1_PdoET <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_PdoET	String	8	Event time for all read result TPDOs. Unit 1 ms
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_PdoET <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_PdoET	String	8	Event time for all read result TPDOs. Unit 1 ms
Variable Data	data	UInt	2	

Write Variable Response:				
sWA C1_PdoET				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_PdoET	String	8	Event time for all read result TPDOs. Unit 1 ms

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_PdoET[ETX]
Read Variable Response:	[STX]sRA C1_PdoET 0[ETX]
Write Variable:	[STX]sWN C1_PdoET 0[ETX]
Write Variable Response:	[STX]sWA C1_PdoET[ETX]

2.17.2.11. Variable: CAN1DiagEnable

The following section contains a detailed description of the variable CAN1DiagEnable.

Variable Overview

Variable Name	Description
CAN1DiagEnable	If true, device fills object 0x2010 with diagnosis data string. It sends a 'data available PDO' to initiate SDO upload

Communication Name	C1_DiagEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	605
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_DiagEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_DiagEna	String	10	If true, device fills object 0x2010 with diagnosis data string. It sends a 'data available PDO' to initiate SDO upload

Read Variable Response:				
`sRA C1_DiagEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_DiagEna	String	10	If true, device fills object 0x2010 with diagnosis data string. It sends a 'data available PDO' to initiate SDO upload
Variable Data	data	Bool	1	

Write Variable:				
`sWN C1_DiagEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_DiagEna	String	10	If true, device fills object 0x2010 with diagnosis data string. It sends a 'data available PDO' to initiate SDO upload
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA C1_DiagEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_DiagEna	String	10	If true, device fills object 0x2010 with diagnosis data string. It sends a 'data available PDO' to initiate SDO upload

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_DiagEna[ETX]`
Read Variable Response:	`[STX]sRA C1_DiagEna 0[ETX]`
Write Variable:	`[STX]sWN C1_DiagEna 0[ETX]`
Write Variable Response:	`[STX]sWA C1_DiagEna[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.12. Variable: CAN1_DiagDataTimeout

The following section contains a detailed description of the variable CAN1_DiagDataTimeout.

Variable Overview

Variable Name	Description
CAN1_DiagDataTimeout	Timeout in ms for read result upload after Data available PDO was startet

Communication Name	C1_DiagTmo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	606
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	2000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN C1_DiagTmo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_DiagTmo	String	10	Timeout in ms for read result upload after Data available PDO was startet

Read Variable Response:				
`sRA C1_DiagTmo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_DiagTmo	String	10	Timeout in ms for read result upload after Data available PDO was startet
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_DiagTmo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_DiagTmo	String	10	Timeout in ms for read result upload after Data available PDO was startet
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_DiagTmo				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_DiagTmo	String	10	Timeout in ms for read result upload after Data available PDO was startet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_DiagTmo[ETX]
Read Variable Response:	[STX]sRA C1_DiagTmo 7D0[ETX]
Write Variable:	[STX]sWN C1_DiagTmo 7D0[ETX]
Write Variable Response:	[STX]sWA C1_DiagTmo[ETX]

2.17.2.13. Variable: CAN1CmdRespEnable

The following section contains a detailed description of the variable CAN1CmdRespEnable.

Variable Overview

Variable Name	Description
CAN1CmdRespEnable	If true, device fills object 0x2020 with command response data string after a command was received via object 0x2200. It sends a 'data available PDO' to initiate SDO upload

Communication Name	C1_CmdRespEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	607
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_CmdRespEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_CmdRespEna	String	13	If true, device fills object 0x2020 with command response data string after a command was received via object 0x2200. It sends a 'data available PDO' to initiate SDO upload

Read Variable Response:				
`sRA C1_CmdRespEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_CmdRespEna	String	13	If true, device fills object 0x2020 with command response data string after a command was received via object 0x2200. It sends a 'data available PDO' to initiate SDO upload
Variable Data	data	Bool	1	

Write Variable:				
`sWN C1_CmdRespEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_CmdRespEna	String	13	If true, device fills object 0x2020 with command response data string after a command was received via object 0x2200. It sends a 'data available PDO' to initiate SDO upload
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA C1_CmdRespEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_CmdRespEna	String	13	If true, device fills object 0x2020 with command response data string after a command was received via object 0x2200. It sends a 'data available PDO' to initiate SDO upload

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_CmdRespEna[ETX]`
Read Variable Response:	`[STX]sRA C1_CmdRespEna 1[ETX]`
Write Variable:	`[STX]sWN C1_CmdRespEna 1[ETX]`
Write Variable Response:	`[STX]sWA C1_CmdRespEna[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.14. Variable: CAN1_CmdResponseTimeout

The following section contains a detailed description of the variable CAN1_CmdResponseTimeout.

Variable Overview

Variable Name	Description
CAN1_CmdResponseTimeout	Timeout in ms for command response (0x2020) upload after Data available PDO was startet

Communication Name	C1_CmdRespTmo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	608
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	2000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_CmdRespTmo
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_CmdRespTmo	String	13	Timeout in ms for command response (0x2020) upload after Data available PDO was startet

Read Variable Response:

```
sRA C1_CmdRespTmo <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_CmdRespTmo	String	13	Timeout in ms for command response (0x2020) upload after Data available PDO was startet
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_CmdRespTmo <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_CmdRespTmo	String	13	Timeout in ms for command response (0x2020) upload after Data available PDO was startet
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_CmdRespTmo				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_CmdRespTmo	String	13	Timeout in ms for command response (0x2020) upload after Data available PDO was startet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_CmdRespTmo[ETX]
Read Variable Response:	[STX]sRA C1_CmdRespTmo 7D0[ETX]
Write Variable:	[STX]sWN C1_CmdRespTmo 7D0[ETX]
Write Variable Response:	[STX]sWA C1_CmdRespTmo[ETX]

2.17.2.15. Variable: CAN1EmcyID

The following section contains a detailed description of the variable CAN1EmcyID.

Variable Overview

Variable Name	Description
CAN1EmcyID	COB-id of the Emercency object: Default value = 0: used defoult ID = 0x80 + Node ID

Communication Name	C1_EmcyId
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	609
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..0
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_EmcyId`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_EmcyId	String	9	COB-id of the Emercency object: Default value = 0: used defoult ID = 0x80 + Node ID

Read Variable Response:				
`sRA C1_EmcyId <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_EmcyId	String	9	COB-id of the Emercency object: Default value = 0: used defoult ID = 0x80 + Node ID
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_EmcyId <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_EmcyId	String	9	COB-id of the Emercency object: Default value = 0: used defoult ID = 0x80 + Node ID
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1_EmcyId`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_EmcyId	String	9	COB-id of the Emercency object: Default value = 0: used defoult ID = 0x80 + Node ID

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_EmcyId[ETX]`
Read Variable Response:	`[STX]sRA C1_EmcyId 0[ETX]`
Write Variable:	`[STX]sWN C1_EmcyId 0[ETX]`
Write Variable Response:	`[STX]sWA C1_EmcyId[ETX]`

© SICK AG - Germany - All rights reserved

2.17.2.16. Variable: CAN1EmcyInhibitTime

The following section contains a detailed description of the variable CAN1EmcyInhibitTime.

Variable Overview

Variable Name	Description
CAN1EmcyInhibitTime	Inhibit time for all read result TPDOs. Unit 100 us

Communication Name	C1_EmcyIT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	610
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_EmcyIT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_EmcyIT	String	9	Inhibit time for all read result TPDOs. Unit 100 us

Read Variable Response:

```
sRA C1_EmcyIT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_EmcyIT	String	9	Inhibit time for all read result TPDOs. Unit 100 us
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_EmcyIT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_EmcyIT	String	9	Inhibit time for all read result TPDOs. Unit 100 us
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA C1_EmcyIT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_EmcyIT	String	9	Inhibit time for all read result TPDOs. Unit 100 us

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_EmcyIT[ETX]`
Read Variable Response:	`[STX]sRA C1_EmcyIT 0[ETX]`
Write Variable:	`[STX]sWN C1_EmcyIT 0[ETX]`
Write Variable Response:	`[STX]sWA C1_EmcyIT[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3. Group: CAN1BusTPDO

2.17.3.1. Variable: C1_TPDO1_MapNum

The following section contains a detailed description of the variable C1_TPDO1_MapNum.

Variable Overview

Variable Name	Description
C1_TPDO1_MapNum	Number of mapping entries for TPDO1

Communication Name	C1_TP1_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	611
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP1_MN
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_MN	String	9	Number of mapping entries for TPDO1

Read Variable Response:

```
sRA C1_TP1_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_MN	String	9	Number of mapping entries for TPDO1
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_TP1_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_MN	String	9	Number of mapping entries for TPDO1
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_TP1_MN				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_MN	String	9	Number of mapping entries for TPDO1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP1_MN[ETX]
Read Variable Response:	[STX]sRA C1_TP1_MN 0[ETX]
Write Variable:	[STX]sWN C1_TP1_MN 0[ETX]
Write Variable Response:	[STX]sWA C1_TP1_MN[ETX]

2.17.3.2. Variable: C1_TPDO1_MapObjs

The following section contains a detailed description of the variable C1_TPDO1_MapObjs.

Variable Overview

Variable Name	Description
C1_TPDO1_MapObjs	array[8] of mapping objects for TPDO1

Communication Name	C1_TP1_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	612
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
Mapping0		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x00000000
	Physical Unit	
	Physical Unit Factor	0.0
Mapping1		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x00000000
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP1_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_MOBJ	String	11	array[8] of mapping objects for TPDO1

Read Variable Response:				
`sRA C1_TP1_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_MOBJ	String	11	array[8] of mapping objects for TPDO1
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
`sWN C1_TP1_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_MOBJ	String	11	array[8] of mapping objects for TPDO1
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
`sWA C1_TP1_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_MOBJ	String	11	array[8] of mapping objects for TPDO1

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP1_MOBJ[ETX]`
Read Variable Response:	`[STX]sRA C1_TP1_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN C1_TP1_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP1_MOBJ[ETX]`

2.17.3.3. Variable: C1_TPDO1_PreConnSet

The following section contains a detailed description of the variable C1_TPDO1_PreConnSet.

Variable Overview

Variable Name	Description
C1_TPDO1_PreConnSet	Define use of predefined connection set

Communication Name	C1_TP1_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	613
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

`sRN C1_TP1_PCS`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_PCS	String	10	Define use of predefined connection set

Read Variable Response:

`sRA C1_TP1_PCS <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP1_PCS <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
sWA C1_TP1_PCS				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP1_PCS[ETX]
Read Variable Response:	[STX]sRA C1_TP1_PCS 1[ETX]
Write Variable:	[STX]sWN C1_TP1_PCS 1[ETX]
Write Variable Response:	[STX]sWA C1_TP1_PCS[ETX]

2.17.3.4. Variable: C1_TPDO1_CobId

The following section contains a detailed description of the variable C1_TPDO1_CobId.

Variable Overview

Variable Name	Description
C1_TPDO1_CobId	Can identifier for TPDO1

Communication Name	C1_TP1_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	614
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP1_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_ID	String	9	Can identifier for TPDO1

Read Variable Response:				
`sRA C1_TP1_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_ID	String	9	Can identifier for TPDO1
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1_TP1_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_ID	String	9	Can identifier for TPDO1
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1_TP1_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_ID	String	9	Can identifier for TPDO1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP1_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_TP1_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_TP1_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_TP1_ID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.5. Variable: C1_TPDO1_TrmType

The following section contains a detailed description of the variable C1_TPDO1_TrmType.

Variable Overview

Variable Name	Description
C1_TPDO1_TrmType	Transmission type for TPDO1

Communication Name	C1_TP1_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	615
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP1_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_TT	String	9	Transmission type for TPDO1

Read Variable Response:

```
sRA C1_TP1_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_TT	String	9	Transmission type for TPDO1
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_TP1_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_TT	String	9	Transmission type for TPDO1
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_TP1_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_TT	String	9	Transmission type for TPDO1

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP1_TT[ETX]`
Read Variable Response:	`[STX]sRA C1_TP1_TT FE[ETX]`
Write Variable:	`[STX]sWN C1_TP1_TT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_TP1_TT[ETX]`

2.17.3.6. Variable: C1_TPDO1_InhibtTime

The following section contains a detailed description of the variable C1_TPDO1_InhibtTime.

Variable Overview

Variable Name	Description
C1_TPDO1_InhibtTime	Inhibt time for TPDO1

Communication Name	C1_TP1_IT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	616
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP1_IT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_IT	String	9	Inhibt time for TPDO1

Read Variable Response:

```
sRA C1_TP1_IT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_IT	String	9	Inhibt time for TPDO1
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP1_IT <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_IT	String	9	Inhibt time for TPDO1
Variable Data	data	UInt	2	

Write Variable Response:				
sWA C1_TP1_IT				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_IT	String	9	Inhibt time for TPDO1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP1_IT[ETX]
Read Variable Response:	[STX]sRA C1_TP1_IT 0[ETX]
Write Variable:	[STX]sWN C1_TP1_IT 0[ETX]
Write Variable Response:	[STX]sWA C1_TP1_IT[ETX]

2.17.3.7. Variable: C1_TPDO1_EventTime

The following section contains a detailed description of the variable C1_TPDO1_EventTime.

Variable Overview

Variable Name	Description
C1_TPDO1_EventTime	Event time for TPDO1

Communication Name	C1_TP1_ET
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	617
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP1_ET`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP1_ET	String	9	Event time for TPDO1

Read Variable Response:				
`sRA C1_TP1_ET <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP1_ET	String	9	Event time for TPDO1
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_TP1_ET <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP1_ET	String	9	Event time for TPDO1
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1_TP1_ET`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP1_ET	String	9	Event time for TPDO1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP1_ET[ETX]`
Read Variable Response:	`[STX]sRA C1_TP1_ET 0[ETX]`
Write Variable:	`[STX]sWN C1_TP1_ET 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP1_ET[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.8. Variable: C1_TPDO2_MapNum

The following section contains a detailed description of the variable C1_TPDO2_MapNum.

Variable Overview

Variable Name	Description
C1_TPDO2_MapNum	Number of mapping entries for TPDO2

Communication Name	C1_TP2_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	618
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	2
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP2_MN
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_MN	String	9	Number of mapping entries for TPDO2

Read Variable Response:

```
sRA C1_TP2_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_MN	String	9	Number of mapping entries for TPDO2
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_TP2_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_MN	String	9	Number of mapping entries for TPDO2
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_TP2_MN
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_MN	String	9	Number of mapping entries for TPDO2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP2_MN[ETX]`
Read Variable Response:	`[STX]sRA C1_TP2_MN 2[ETX]`
Write Variable:	`[STX]sWN C1_TP2_MN 2[ETX]`
Write Variable Response:	`[STX]sWA C1_TP2_MN[ETX]`

2.17.3.9. Variable: C1_TPDO2_MapObjs

The following section contains a detailed description of the variable C1_TPDO2_MapObjs.

Variable Overview

Variable Name	Description
C1_TPDO2_MapObjs	array[8] of mapping objects for TPDO2

Communication Name	C1_TP2_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	619
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
Mapping0		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x60000108
	Physical Unit	
	Physical Unit Factor	0.0
Mapping1		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x60000208
	Physical Unit	
	Physical Unit Factor	0.0
Mapping2		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x00000000
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP2_MOBJ
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_MOBJ	String	11	array[8] of mapping objects for TPDO2

Read Variable Response:

```
sRA C1_TP2_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6>
<Mapping7>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_MOBJ	String	11	array[8] of mapping objects for TPDO2
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	

© SICK AG - Germany - All rights reserved

Read Variable Response:				
sRA C1_TP2_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
sWN C1_TP2_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_MOBJ	String	11	array[8] of mapping objects for TPDO2
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
sWA C1_TP2_MOBJ				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_MOBJ	String	11	array[8] of mapping objects for TPDO2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP2_MOBJ[ETX]
Read Variable Response:	[STX]sRA C1_TP2_MOBJ 60000108 60000208 0 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN C1_TP2_MOBJ 60000108 60000208 0 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA C1_TP2_MOBJ[ETX]

© SICK AG - Germany - All rights reserved

2.17.3.10. Variable: C1_TPDO2_PreConnSet

The following section contains a detailed description of the variable C1_TPDO2_PreConnSet.

Variable Overview

Variable Name	Description
C1_TPDO2_PreConnSet	Define use of predefined connection set

Communication Name	C1_TP2_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	620
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP2_PCS
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_PCS	String	10	Define use of predefined connection set

Read Variable Response:

```
sRA C1_TP2_PCS <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable:

```
sWN C1_TP2_PCS <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:

```
sWA C1_TP2_PCS
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_PCS	String	10	Define use of predefined connection set

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP2_PCS[ETX]`
Read Variable Response:	`[STX]sRA C1_TP2_PCS 1[ETX]`
Write Variable:	`[STX]sWN C1_TP2_PCS 1[ETX]`
Write Variable Response:	`[STX]sWA C1_TP2_PCS[ETX]`

2.17.3.11. Variable: C1_TPDO2_CobId

The following section contains a detailed description of the variable C1_TPDO2_CobId.

Variable Overview

Variable Name	Description
C1_TPDO2_CobId	Can identifier for TPDO2

Communication Name	C1_TP2_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	621
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP2_ID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_ID	String	9	Can identifier for TPDO2

Read Variable Response:

```
sRA C1_TP2_ID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_ID	String	9	Can identifier for TPDO2
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP2_ID <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_ID	String	9	Can identifier for TPDO2
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA C1_TP2_ID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_ID	String	9	Can identifier for TPDO2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP2_ID[ETX]
Read Variable Response:	[STX]sRA C1_TP2_ID 80000000[ETX]
Write Variable:	[STX]sWN C1_TP2_ID 80000000[ETX]
Write Variable Response:	[STX]sWA C1_TP2_ID[ETX]

2.17.3.12. Variable: C1_TPDO2_TrmType

The following section contains a detailed description of the variable C1_TPDO2_TrmType.

Variable Overview

Variable Name	Description
C1_TPDO2_TrmType	Transmission type for TPDO2

Communication Name	C1_TP2_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	622
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP2_TT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_TT	String	9	Transmission type for TPDO2

Read Variable Response:				
`sRA C1_TP2_TT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_TT	String	9	Transmission type for TPDO2
Variable Data	data	USInt	1	

Write Variable:				
`sWN C1_TP2_TT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_TT	String	9	Transmission type for TPDO2
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA C1_TP2_TT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_TT	String	9	Transmission type for TPDO2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP2_TT[ETX]`
Read Variable Response:	`[STX]sRA C1_TP2_TT FE[ETX]`
Write Variable:	`[STX]sWN C1_TP2_TT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_TP2_TT[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.13. Variable: C1_TPDO2_InhibtTime

The following section contains a detailed description of the variable C1_TPDO2_InhibtTime.

Variable Overview

Variable Name	Description
C1_TPDO2_InhibtTime	Inhibt time for TPDO2

Communication Name	C1_TP2_IT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	623
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP2_IT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_IT	String	9	Inhibt time for TPDO2

Read Variable Response:

```
sRA C1_TP2_IT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_IT	String	9	Inhibt time for TPDO2
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_TP2_IT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_IT	String	9	Inhibt time for TPDO2
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA C1_TP2_IT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_IT	String	9	Inhibt time for TPDO2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP2_IT[ETX]`
Read Variable Response:	`[STX]sRA C1_TP2_IT 0[ETX]`
Write Variable:	`[STX]sWN C1_TP2_IT 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP2_IT[ETX]`

2.17.3.14. Variable: C1_TPDO2_EventTime

The following section contains a detailed description of the variable C1_TPDO2_EventTime.

Variable Overview

Variable Name	Description
C1_TPDO2_EventTime	Event time for TPDO2

Communication Name	C1_TP2_ET
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	624
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN C1_TP2_ET`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP2_ET	String	9	Event time for TPDO2

Read Variable Response:

`sRA C1_TP2_ET <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP2_ET	String	9	Event time for TPDO2
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP2_ET <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP2_ET	String	9	Event time for TPDO2
Variable Data	data	UInt	2	

Write Variable Response:				
sWA C1_TP2_ET				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP2_ET	String	9	Event time for TPDO2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP2_ET[ETX]
Read Variable Response:	[STX]sRA C1_TP2_ET 0[ETX]
Write Variable:	[STX]sWN C1_TP2_ET 0[ETX]
Write Variable Response:	[STX]sWA C1_TP2_ET[ETX]

2.17.3.15. Variable: C1_TPDO3_MapNum

The following section contains a detailed description of the variable C1_TPDO3_MapNum.

Variable Overview

Variable Name	Description
C1_TPDO3_MapNum	Number of mapping entries for TPDO3

Communication Name	C1_TP3_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	625
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP3_MN`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_MN	String	9	Number of mapping entries for TPDO3

Read Variable Response:				
`sRA C1_TP3_MN <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_MN	String	9	Number of mapping entries for TPDO3
Variable Data	data	USInt	1	

Write Variable:				
`sWN C1_TP3_MN <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_MN	String	9	Number of mapping entries for TPDO3
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA C1_TP3_MN`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_MN	String	9	Number of mapping entries for TPDO3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP3_MN[ETX]`
Read Variable Response:	`[STX]sRA C1_TP3_MN 0[ETX]`
Write Variable:	`[STX]sWN C1_TP3_MN 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP3_MN[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.16. Variable: C1_TPDO3_MapObjs

The following section contains a detailed description of the variable C1_TPDO3_MapObjs.

Variable Overview

Variable Name	Description
C1_TPDO3_MapObjs	array[8] of mapping objects for TPDO3

Communication Name	C1_TP3_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	626
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
Mapping0	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping1	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP3_MOBJ
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_MOBJ	String	11	array[8] of mapping objects for TPDO3

Read Variable Response:

```
sRA C1_TP3_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6>
<Mapping7>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_MOBJ	String	11	array[8] of mapping objects for TPDO3
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:

```
sWN C1_TP3_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6>
<Mapping7>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_MOBJ	String	11	array[8] of mapping objects for TPDO3
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP3_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
sWA C1_TP3_MOBJ				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_MOBJ	String	11	array[8] of mapping objects for TPDO3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP3_MOBJ[ETX]
Read Variable Response:	[STX]sRA C1_TP3_MOBJ 0 0 0 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN C1_TP3_MOBJ 0 0 0 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA C1_TP3_MOBJ[ETX]

2.17.3.17. Variable: C1_TPDO3_PreConnSet

The following section contains a detailed description of the variable C1_TPDO3_PreConnSet.

Variable Overview

Variable Name	Description
C1_TPDO3_PreConnSet	Define use of predefined connection set

Communication Name	C1_TP3_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	627
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP3_PCS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_PCS	String	10	Define use of predefined connection set

Read Variable Response:				
`sRA C1_TP3_PCS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable:				
`sWN C1_TP3_PCS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
`sWA C1_TP3_PCS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP3_PCS[ETX]`
Read Variable Response:	`[STX]sRA C1_TP3_PCS 1[ETX]`
Write Variable:	`[STX]sWN C1_TP3_PCS 1[ETX]`
Write Variable Response:	`[STX]sWA C1_TP3_PCS[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.18. Variable: C1_TPDO3_CobId

The following section contains a detailed description of the variable C1_TPDO3_CobId.

Variable Overview

Variable Name	Description
C1_TPDO3_CobId	Can identifier for TPDO3

Communication Name	C1_TP3_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	628
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP3_ID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_ID	String	9	Can identifier for TPDO3

Read Variable Response:

```
sRA C1_TP3_ID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_ID	String	9	Can identifier for TPDO3
Variable Data	data	UDInt	4	

Write Variable:

```
sWN C1_TP3_ID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_ID	String	9	Can identifier for TPDO3
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA C1_TP3_ID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_ID	String	9	Can identifier for TPDO3

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP3_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_TP3_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_TP3_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_TP3_ID[ETX]`

2.17.3.19. Variable: C1_TPDO3_TrmType

The following section contains a detailed description of the variable C1_TPDO3_TrmType.

Variable Overview

Variable Name	Description
C1_TPDO3_TrmType	Transmission type for TPDO3

Communication Name	C1_TP3_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	629
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN C1_TP3_TT`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_TT	String	9	Transmission type for TPDO3

Read Variable Response:

`sRA C1_TP3_TT <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_TT	String	9	Transmission type for TPDO3
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP3_TT <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_TT	String	9	Transmission type for TPDO3
Variable Data	data	USInt	1	

Write Variable Response:				
sWA C1_TP3_TT				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_TT	String	9	Transmission type for TPDO3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP3_TT[ETX]
Read Variable Response:	[STX]sRA C1_TP3_TT FE[ETX]
Write Variable:	[STX]sWN C1_TP3_TT FE[ETX]
Write Variable Response:	[STX]sWA C1_TP3_TT[ETX]

2.17.3.20. Variable: C1_TPDO3_InhibtTime

The following section contains a detailed description of the variable C1_TPDO3_InhibtTime.

Variable Overview

Variable Name	Description
C1_TPDO3_InhibtTime	Inhibt time for TPDO3

Communication Name	C1_TP3_IT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	630
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP3_IT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_IT	String	9	Inhibt time for TPDO3

Read Variable Response:				
`sRA C1_TP3_IT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_IT	String	9	Inhibt time for TPDO3
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_TP3_IT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_IT	String	9	Inhibt time for TPDO3
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1_TP3_IT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_IT	String	9	Inhibt time for TPDO3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP3_IT[ETX]`
Read Variable Response:	`[STX]sRA C1_TP3_IT 0[ETX]`
Write Variable:	`[STX]sWN C1_TP3_IT 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP3_IT[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.21. Variable: C1_TPDO3_EventTime

The following section contains a detailed description of the variable C1_TPDO3_EventTime.

Variable Overview

Variable Name	Description
C1_TPDO3_EventTime	Event time for TPDO3

Communication Name	C1_TP3_ET
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	631
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP3_ET
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP3_ET	String	9	Event time for TPDO3

Read Variable Response:

```
sRA C1_TP3_ET <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP3_ET	String	9	Event time for TPDO3
Variable Data	data	UInt	2	

Write Variable:

```
sWN C1_TP3_ET <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP3_ET	String	9	Event time for TPDO3
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA C1_TP3_ET
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP3_ET	String	9	Event time for TPDO3

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP3_ET[ETX]`
Read Variable Response:	`[STX]sRA C1_TP3_ET 0[ETX]`
Write Variable:	`[STX]sWN C1_TP3_ET 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP3_ET[ETX]`

2.17.3.22. Variable: C1_TPDO4_MapNum

The following section contains a detailed description of the variable C1_TPDO4_MapNum.

Variable Overview

Variable Name	Description
C1_TPDO4_MapNum	Number of mapping entries for TPDO4

Communication Name	C1_TP4_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	632
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP4_MN
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_MN	String	9	Number of mapping entries for TPDO4

Read Variable Response:

```
sRA C1_TP4_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_MN	String	9	Number of mapping entries for TPDO4
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP4_MN <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_MN	String	9	Number of mapping entries for TPDO4
Variable Data	data	USInt	1	

Write Variable Response:				
sWA C1_TP4_MN				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_MN	String	9	Number of mapping entries for TPDO4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP4_MN[ETX]
Read Variable Response:	[STX]sRA C1_TP4_MN 0[ETX]
Write Variable:	[STX]sWN C1_TP4_MN 0[ETX]
Write Variable Response:	[STX]sWA C1_TP4_MN[ETX]

2.17.3.23. Variable: C1_TPDO4_MapObjs

The following section contains a detailed description of the variable C1_TPDO4_MapObjs.

Variable Overview

Variable Name	Description
C1_TPDO4_MapObjs	array[8] of mapping objects for TPDO4

Communication Name	C1_TP4_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	633
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
Mapping0	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping1	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP4_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_MOBJ	String	11	array[8] of mapping objects for TPDO4

Read Variable Response:				
`sRA C1_TP4_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_MOBJ	String	11	array[8] of mapping objects for TPDO4
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
`sWN C1_TP4_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_MOBJ	String	11	array[8] of mapping objects for TPDO4
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
`sWA C1_TP4_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_MOBJ	String	11	array[8] of mapping objects for TPDO4

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP4_MOBJ[ETX]`
Read Variable Response:	`[STX]sRA C1_TP4_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN C1_TP4_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP4_MOBJ[ETX]`

2.17.3.24. Variable: C1_TPDO4_PreConnSet

The following section contains a detailed description of the variable C1_TPDO4_PreConnSet.

Variable Overview

Variable Name	Description
C1_TPDO4_PreConnSet	Define use of predefined connection set

Communication Name	C1_TP4_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	634
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

`sRN C1_TP4_PCS`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_PCS	String	10	Define use of predefined connection set

Read Variable Response:

`sRA C1_TP4_PCS <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP4_PCS <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
sWA C1_TP4_PCS				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP4_PCS[ETX]
Read Variable Response:	[STX]sRA C1_TP4_PCS 1[ETX]
Write Variable:	[STX]sWN C1_TP4_PCS 1[ETX]
Write Variable Response:	[STX]sWA C1_TP4_PCS[ETX]

2.17.3.25. Variable: C1_TPDO4_CobId

The following section contains a detailed description of the variable C1_TPDO4_CobId.

Variable Overview

Variable Name	Description
C1_TPDO4_CobId	Can identifier for TPDO4

Communication Name	C1_TP4_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	635
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP4_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_ID	String	9	Can identifier for TPDO4

Read Variable Response:				
`sRA C1_TP4_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_ID	String	9	Can identifier for TPDO4
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1_TP4_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_ID	String	9	Can identifier for TPDO4
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1_TP4_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_ID	String	9	Can identifier for TPDO4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP4_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_TP4_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_TP4_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_TP4_ID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.3.26. Variable: C1_TPDO4_TrmType

The following section contains a detailed description of the variable C1_TPDO4_TrmType.

Variable Overview

Variable Name	Description
C1_TPDO4_TrmType	Transmission type for TPDO4

Communication Name	C1_TP4_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	636
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP4_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_TT	String	9	Transmission type for TPDO4

Read Variable Response:

```
sRA C1_TP4_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_TT	String	9	Transmission type for TPDO4
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_TP4_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_TT	String	9	Transmission type for TPDO4
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_TP4_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_TT	String	9	Transmission type for TPDO4

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP4_TT[ETX]`
Read Variable Response:	`[STX]sRA C1_TP4_TT FE[ETX]`
Write Variable:	`[STX]sWN C1_TP4_TT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_TP4_TT[ETX]`

2.17.3.27. Variable: C1_TPDO4_InhibtTime

The following section contains a detailed description of the variable C1_TPDO4_InhibtTime.

Variable Overview

Variable Name	Description
C1_TPDO4_InhibtTime	Inhibt time for TPDO4

Communication Name	C1_TP4_IT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	637
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_TP4_IT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_IT	String	9	Inhibt time for TPDO4

Read Variable Response:

```
sRA C1_TP4_IT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_IT	String	9	Inhibt time for TPDO4
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_TP4_IT <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_IT	String	9	Inhibt time for TPDO4
Variable Data	data	UInt	2	

Write Variable Response:				
sWA C1_TP4_IT				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_IT	String	9	Inhibt time for TPDO4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_TP4_IT[ETX]
Read Variable Response:	[STX]sRA C1_TP4_IT 0[ETX]
Write Variable:	[STX]sWN C1_TP4_IT 0[ETX]
Write Variable Response:	[STX]sWA C1_TP4_IT[ETX]

2.17.3.28. Variable: C1_TPDO4_EventTime

The following section contains a detailed description of the variable C1_TPDO4_EventTime.

Variable Overview

Variable Name	Description
C1_TPDO4_EventTime	Event time for TPDO4

Communication Name	C1_TP4_ET
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	638
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0x00
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_TP4_ET`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_TP4_ET	String	9	Event time for TPDO4

Read Variable Response:				
`sRA C1_TP4_ET <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_TP4_ET	String	9	Event time for TPDO4
Variable Data	data	UInt	2	

Write Variable:				
`sWN C1_TP4_ET <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_TP4_ET	String	9	Event time for TPDO4
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA C1_TP4_ET`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_TP4_ET	String	9	Event time for TPDO4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_TP4_ET[ETX]`
Read Variable Response:	`[STX]sRA C1_TP4_ET 0[ETX]`
Write Variable:	`[STX]sWN C1_TP4_ET 0[ETX]`
Write Variable Response:	`[STX]sWA C1_TP4_ET[ETX]`

© SICK AG - Germany - All rights reserved

2.17.4. Group: CAN1BusRPDO

2.17.4.1. Variable: C1_RPDO1_MapNum

The following section contains a detailed description of the variable C1_RPDO1_MapNum.

Variable Overview

Variable Name	Description
C1_RPDO1_MapNum	Number of mapping entries for RPDO1

Communication Name	C1_RP1_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	639
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	2
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_RP1_MN
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP1_MN	String	9	Number of mapping entries for RPDO1

Read Variable Response:

```
sRA C1_RP1_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP1_MN	String	9	Number of mapping entries for RPDO1
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_RP1_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP1_MN	String	9	Number of mapping entries for RPDO1
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA C1_RP1_MN				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP1_MN	String	9	Number of mapping entries for RPDO1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP1_MN[ETX]
Read Variable Response:	[STX]sRA C1_RP1_MN 2[ETX]
Write Variable:	[STX]sWN C1_RP1_MN 2[ETX]
Write Variable Response:	[STX]sWA C1_RP1_MN[ETX]

2.17.4.2. Variable: C1_RPDO1_MapObjs

The following section contains a detailed description of the variable C1_RPDO1_MapObjs.

Variable Overview

Variable Name	Description
C1_RPDO1_MapObjs	array[8] of mapping objects for RPDO1

Communication Name	C1_RP1_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	640
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
Mapping0		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x62000108
	Physical Unit	
	Physical Unit Factor	0.0
Mapping1		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x62000208
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP1_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP1_MOBJ	String	11	array[8] of mapping objects for RPDO1

Read Variable Response:				
`sRA C1_RP1_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP1_MOBJ	String	11	array[8] of mapping objects for RPDO1
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
`sWN C1_RP1_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP1_MOBJ	String	11	array[8] of mapping objects for RPDO1
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
`sWA C1_RP1_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP1_MOBJ	String	11	array[8] of mapping objects for RPDO1

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP1_MOBJ[ETX]`
Read Variable Response:	`[STX]sRA C1_RP1_MOBJ 62000108 62000208 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN C1_RP1_MOBJ 62000108 62000208 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA C1_RP1_MOBJ[ETX]`

2.17.4.3. Variable: C1_RPDO1_PreConnSet

The following section contains a detailed description of the variable C1_RPDO1_PreConnSet.

Variable Overview

Variable Name	Description
C1_RPDO1_PreConnSet	Define use of predefined connection set

Communication Name	C1_RP1_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	641
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP1_PCS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP1_PCS	String	10	Define use of predefined connection set

Read Variable Response:				
`sRA C1_RP1_PCS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP1_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP1_PCS <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP1_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
sWA C1_RP1_PCS				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP1_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP1_PCS[ETX]
Read Variable Response:	[STX]sRA C1_RP1_PCS 1[ETX]
Write Variable:	[STX]sWN C1_RP1_PCS 1[ETX]
Write Variable Response:	[STX]sWA C1_RP1_PCS[ETX]

2.17.4.4. Variable: C1_RPDO1_CobId

The following section contains a detailed description of the variable C1_RPDO1_CobId.

Variable Overview

Variable Name	Description
C1_RPDO1_CobId	Can identifier for RPDO1

Communication Name	C1_RP1_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	642
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP1_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP1_ID	String	9	Can identifier for RPDO1

Read Variable Response:				
`sRA C1_RP1_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP1_ID	String	9	Can identifier for RPDO1
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1_RP1_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP1_ID	String	9	Can identifier for RPDO1
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1_RP1_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP1_ID	String	9	Can identifier for RPDO1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP1_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_RP1_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_RP1_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_RP1_ID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.4.5. Variable: C1_RPDO1_TrmType

The following section contains a detailed description of the variable C1_RPDO1_TrmType.

Variable Overview

Variable Name	Description
C1_RPDO1_TrmType	Transmission type for RPDO1

Communication Name	C1_RP1_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	643
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_RP1_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP1_TT	String	9	Transmission type for RPDO1

Read Variable Response:

```
sRA C1_RP1_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP1_TT	String	9	Transmission type for RPDO1
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_RP1_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP1_TT	String	9	Transmission type for RPDO1
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_RP1_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP1_TT	String	9	Transmission type for RPDO1

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP1_TT[ETX]`
Read Variable Response:	`[STX]sRA C1_RP1_TT FE[ETX]`
Write Variable:	`[STX]sWN C1_RP1_TT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_RP1_TT[ETX]`

2.17.4.6. Variable: C1_RPDO2_MapNum

The following section contains a detailed description of the variable C1_RPDO2_MapNum.

Variable Overview

Variable Name	Description
C1_RPDO2_MapNum	Number of mapping entries for RPDO2

Communication Name	C1_RP2_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	644
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN C1_RP2_MN`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP2_MN	String	9	Number of mapping entries for RPDO2

Read Variable Response:

`sRA C1_RP2_MN <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP2_MN	String	9	Number of mapping entries for RPDO2
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP2_MN <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP2_MN	String	9	Number of mapping entries for RPDO2
Variable Data	data	USInt	1	

Write Variable Response:				
sWA C1_RP2_MN				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP2_MN	String	9	Number of mapping entries for RPDO2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP2_MN[ETX]
Read Variable Response:	[STX]sRA C1_RP2_MN 0[ETX]
Write Variable:	[STX]sWN C1_RP2_MN 0[ETX]
Write Variable Response:	[STX]sWA C1_RP2_MN[ETX]

2.17.4.7. Variable: C1_RPDO2_MapObjs

The following section contains a detailed description of the variable C1_RPDO2_MapObjs.

Variable Overview

Variable Name	Description
C1_RPDO2_MapObjs	array[8] of mapping objects for RPDO2

Communication Name	C1_RP2_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	645
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
Mapping0	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping1	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP2_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP2_MOBJ	String	11	array[8] of mapping objects for RPDO2

Read Variable Response:				
`sRA C1_RP2_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP2_MOBJ	String	11	array[8] of mapping objects for RPDO2
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
`sWN C1_RP2_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP2_MOBJ	String	11	array[8] of mapping objects for RPDO2
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
`sWA C1_RP2_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP2_MOBJ	String	11	array[8] of mapping objects for RPDO2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP2_MOBJ[ETX]`
Read Variable Response:	`[STX]sRA C1_RP2_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN C1_RP2_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA C1_RP2_MOBJ[ETX]`

2.17.4.8. Variable: C1_RPDO2_PreConnSet

The following section contains a detailed description of the variable C1_RPDO2_PreConnSet.

Variable Overview

Variable Name	Description
C1_RPDO2_PreConnSet	Define use of predefined connection set

Communication Name	C1_RP2_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	646
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP2_PCS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP2_PCS	String	10	Define use of predefined connection set

Read Variable Response:				
`sRA C1_RP2_PCS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP2_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP2_PCS <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP2_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
sWA C1_RP2_PCS				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP2_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP2_PCS[ETX]
Read Variable Response:	[STX]sRA C1_RP2_PCS 1[ETX]
Write Variable:	[STX]sWN C1_RP2_PCS 1[ETX]
Write Variable Response:	[STX]sWA C1_RP2_PCS[ETX]

2.17.4.9. Variable: C1_RPDO2_CobId

The following section contains a detailed description of the variable C1_RPDO2_CobId.

Variable Overview

Variable Name	Description
C1_RPDO2_CobId	Can identifier for RPDO2

Communication Name	C1_RP2_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	647
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP2_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP2_ID	String	9	Can identifier for RPDO2

Read Variable Response:				
`sRA C1_RP2_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP2_ID	String	9	Can identifier for RPDO2
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1_RP2_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP2_ID	String	9	Can identifier for RPDO2
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1_RP2_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP2_ID	String	9	Can identifier for RPDO2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP2_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_RP2_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_RP2_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_RP2_ID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.4.10. Variable: C1_RPDO2_TrmType

The following section contains a detailed description of the variable C1_RPDO2_TrmType.

Variable Overview

Variable Name	Description
C1_RPDO2_TrmType	Transmission type for RPDO2

Communication Name	C1_RP2_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	648
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_RP2_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP2_TT	String	9	Transmission type for RPDO2

Read Variable Response:

```
sRA C1_RP2_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP2_TT	String	9	Transmission type for RPDO2
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_RP2_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP2_TT	String	9	Transmission type for RPDO2
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_RP2_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP2_TT	String	9	Transmission type for RPDO2

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP2_TT[ETX]`
Read Variable Response:	`[STX]sRA C1_RP2_TT FE[ETX]`
Write Variable:	`[STX]sWN C1_RP2_TT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_RP2_TT[ETX]`

2.17.4.11. Variable: C1_RPDO3_MapNum

The following section contains a detailed description of the variable C1_RPDO3_MapNum.

Variable Overview

Variable Name	Description
C1_RPDO3_MapNum	Number of mapping entries for RPDO3

Communication Name	C1_RP3_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	649
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_RP3_MN
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP3_MN	String	9	Number of mapping entries for RPDO3

Read Variable Response:

```
sRA C1_RP3_MN <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP3_MN	String	9	Number of mapping entries for RPDO3
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP3_MN <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP3_MN	String	9	Number of mapping entries for RPDO3
Variable Data	data	USInt	1	

Write Variable Response:				
sWA C1_RP3_MN				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP3_MN	String	9	Number of mapping entries for RPDO3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP3_MN[ETX]
Read Variable Response:	[STX]sRA C1_RP3_MN 0[ETX]
Write Variable:	[STX]sWN C1_RP3_MN 0[ETX]
Write Variable Response:	[STX]sWA C1_RP3_MN[ETX]

2.17.4.12. Variable: C1_RPDO3_MapObjs

The following section contains a detailed description of the variable C1_RPDO3_MapObjs.

Variable Overview

Variable Name	Description
C1_RPDO3_MapObjs	array[8] of mapping objects for RPDO3

Communication Name	C1_RP3_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	650
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
Mapping0	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping1	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP3_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP3_MOBJ	String	11	array[8] of mapping objects for RPDO3

Read Variable Response:				
`sRA C1_RP3_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP3_MOBJ	String	11	array[8] of mapping objects for RPDO3
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
`sWN C1_RP3_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP3_MOBJ	String	11	array[8] of mapping objects for RPDO3
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
`sWA C1_RP3_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP3_MOBJ	String	11	array[8] of mapping objects for RPDO3

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP3_MOBJ[ETX]`
Read Variable Response:	`[STX]sRA C1_RP3_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN C1_RP3_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA C1_RP3_MOBJ[ETX]`

2.17.4.13. Variable: C1_RPDO3_PreConnSet

The following section contains a detailed description of the variable C1_RPDO3_PreConnSet.

Variable Overview

Variable Name	Description
C1_RPDO3_PreConnSet	Define use of predefined connection set

Communication Name	C1_RP3_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	651
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP3_PCS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP3_PCS	String	10	Define use of predefined connection set

Read Variable Response:				
`sRA C1_RP3_PCS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP3_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP3_PCS <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP3_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
sWA C1_RP3_PCS				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP3_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP3_PCS[ETX]
Read Variable Response:	[STX]sRA C1_RP3_PCS 1[ETX]
Write Variable:	[STX]sWN C1_RP3_PCS 1[ETX]
Write Variable Response:	[STX]sWA C1_RP3_PCS[ETX]

2.17.4.14. Variable: C1_RPDO3_CobId

The following section contains a detailed description of the variable C1_RPDO3_CobId.

Variable Overview

Variable Name	Description
C1_RPDO3_CobId	Can identifier for RPDO3

Communication Name	C1_RP3_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	652
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP3_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP3_ID	String	9	Can identifier for RPDO3

Read Variable Response:				
`sRA C1_RP3_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP3_ID	String	9	Can identifier for RPDO3
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1_RP3_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP3_ID	String	9	Can identifier for RPDO3
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1_RP3_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP3_ID	String	9	Can identifier for RPDO3

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP3_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_RP3_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_RP3_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_RP3_ID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.4.15. Variable: C1_RPDO3_TrmType

The following section contains a detailed description of the variable C1_RPDO3_TrmType.

Variable Overview

Variable Name	Description
C1_RPDO3_TrmType	Transmission type for RPDO3

Communication Name	C1_RP3_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	653
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_RP3_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP3_TT	String	9	Transmission type for RPDO3

Read Variable Response:

```
sRA C1_RP3_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP3_TT	String	9	Transmission type for RPDO3
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_RP3_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP3_TT	String	9	Transmission type for RPDO3
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_RP3_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP3_TT	String	9	Transmission type for RPDO3

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP3_TT[ETX]`
Read Variable Response:	`[STX]sRA C1_RP3_TT FE[ETX]`
Write Variable:	`[STX]sWN C1_RP3_TT FE[ETX]`
Write Variable Response:	`[STX]sWA C1_RP3_TT[ETX]`

2.17.4.16. Variable: C1_RPDO4_MapNum

The following section contains a detailed description of the variable C1_RPDO4_MapNum.

Variable Overview

Variable Name	Description
C1_RPDO4_MapNum	Number of mapping entries for RPDO4

Communication Name	C1_RP4_MN
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	654
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..8
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN C1_RP4_MN`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP4_MN	String	9	Number of mapping entries for RPDO4

Read Variable Response:

`sRA C1_RP4_MN <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP4_MN	String	9	Number of mapping entries for RPDO4
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP4_MN <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP4_MN	String	9	Number of mapping entries for RPDO4
Variable Data	data	USInt	1	

Write Variable Response:				
sWA C1_RP4_MN				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP4_MN	String	9	Number of mapping entries for RPDO4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP4_MN[ETX]
Read Variable Response:	[STX]sRA C1_RP4_MN 0[ETX]
Write Variable:	[STX]sWN C1_RP4_MN 0[ETX]
Write Variable Response:	[STX]sWA C1_RP4_MN[ETX]

2.17.4.17. Variable: C1_RPDO4_MapObjs

The following section contains a detailed description of the variable C1_RPDO4_MapObjs.

Variable Overview

Variable Name	Description
C1_RPDO4_MapObjs	array[8] of mapping objects for RPDO4

Communication Name	C1_RP4_MOBJ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	655
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
Mapping0		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0x00000000
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
Mapping1	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping2	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping3	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping4	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping5	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping6	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0
Mapping7	
UDInt	
Value Range	0..4294967295
Initialisation	0x00000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP4_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP4_MOBJ	String	11	array[8] of mapping objects for RPDO4

Read Variable Response:				
`sRA C1_RP4_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP4_MOBJ	String	11	array[8] of mapping objects for RPDO4
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable:				
`sWN C1_RP4_MOBJ <Mapping0> <Mapping1> <Mapping2> <Mapping3> <Mapping4> <Mapping5> <Mapping6> <Mapping7>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP4_MOBJ	String	11	array[8] of mapping objects for RPDO4
Variable Data 1	Mapping0	UDInt	4	
Variable Data 2	Mapping1	UDInt	4	
Variable Data 3	Mapping2	UDInt	4	
Variable Data 4	Mapping3	UDInt	4	
Variable Data 5	Mapping4	UDInt	4	
Variable Data 6	Mapping5	UDInt	4	
Variable Data 7	Mapping6	UDInt	4	
Variable Data 8	Mapping7	UDInt	4	

Write Variable Response:				
`sWA C1_RP4_MOBJ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP4_MOBJ	String	11	array[8] of mapping objects for RPDO4

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP4_MOBJ[ETX]`
Read Variable Response:	`[STX]sRA C1_RP4_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN C1_RP4_MOBJ 0 0 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA C1_RP4_MOBJ[ETX]`

2.17.4.18. Variable: C1_RPDO4_PreConnSet

The following section contains a detailed description of the variable C1_RPDO4_PreConnSet.

Variable Overview

Variable Name	Description
C1_RPDO4_PreConnSet	Define use of predefined connection set

Communication Name	C1_RP4_PCS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	656
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
eUsePredConnSetType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

`sRN C1_RP4_PCS`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP4_PCS	String	10	Define use of predefined connection set

Read Variable Response:

`sRA C1_RP4_PCS <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP4_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN C1_RP4_PCS <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP4_PCS	String	10	Define use of predefined connection set
Variable Data	data	eUsePredConnSetType	1	

Write Variable Response:				
sWA C1_RP4_PCS				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP4_PCS	String	10	Define use of predefined connection set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP4_PCS[ETX]
Read Variable Response:	[STX]sRA C1_RP4_PCS 1[ETX]
Write Variable:	[STX]sWN C1_RP4_PCS 1[ETX]
Write Variable Response:	[STX]sWA C1_RP4_PCS[ETX]

2.17.4.19. Variable: C1_RPDO4_CobId

The following section contains a detailed description of the variable C1_RPDO4_CobId.

Variable Overview

Variable Name	Description
C1_RPDO4_CobId	Can identifier for RPDO4

Communication Name	C1_RP4_ID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	657
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0x80000000
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN C1_RP4_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP4_ID	String	9	Can identifier for RPDO4

Read Variable Response:				
`sRA C1_RP4_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP4_ID	String	9	Can identifier for RPDO4
Variable Data	data	UDInt	4	

Write Variable:				
`sWN C1_RP4_ID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP4_ID	String	9	Can identifier for RPDO4
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA C1_RP4_ID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP4_ID	String	9	Can identifier for RPDO4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN C1_RP4_ID[ETX]`
Read Variable Response:	`[STX]sRA C1_RP4_ID 80000000[ETX]`
Write Variable:	`[STX]sWN C1_RP4_ID 80000000[ETX]`
Write Variable Response:	`[STX]sWA C1_RP4_ID[ETX]`

© SICK AG - Germany - All rights reserved

2.17.4.20. Variable: C1_RPDO4_TrmType

The following section contains a detailed description of the variable C1_RPDO4_TrmType.

Variable Overview

Variable Name	Description
C1_RPDO4_TrmType	Transmission type for RPDO4

Communication Name	C1_RP4_TT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	658
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0xFE
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN C1_RP4_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	C1_RP4_TT	String	9	Transmission type for RPDO4

Read Variable Response:

```
sRA C1_RP4_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	C1_RP4_TT	String	9	Transmission type for RPDO4
Variable Data	data	USInt	1	

Write Variable:

```
sWN C1_RP4_TT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	C1_RP4_TT	String	9	Transmission type for RPDO4
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA C1_RP4_TT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	C1_RP4_TT	String	9	Transmission type for RPDO4

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN C1_RP4_TT[ETX]
Read Variable Response:	[STX]sRA C1_RP4_TT FE[ETX]
Write Variable:	[STX]sWN C1_RP4_TT FE[ETX]
Write Variable Response:	[STX]sWA C1_RP4_TT[ETX]

© SICK AG - Germany - All rights reserved

2.18. Interface Block: GeneralCfgSerialBase

2.18.1. Group: SerialBase

2.18.1.1. Variable: SerHostProtocol

The following section contains a detailed description of the variable SerHostProtocol.

Variable Overview

Variable Name	Description
SerHostProtocol	Protocol for Serial Host

Communication Name	SIHstProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	659
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_OUTPUT_FORMAT_DEF_1	
	2	TX_OUTPUT_FORMAT_DEF_2	
	3	TX_USERDEF_FORMAT	

Variable Telegram Syntax

Read Variable:

```
sRN SIHstProt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstProt	String	9	Protocol for Serial Host

Read Variable Response:

```
sRA SIHstProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstProt	String	9	Protocol for Serial Host
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SIHstProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstProt	String	9	Protocol for Serial Host
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SIHstProt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstProt	String	9	Protocol for Serial Host

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIHstProt[ETX]
Read Variable Response:	[STX]sRA SIHstProt 1[ETX]
Write Variable:	[STX]sWN SIHstProt 1[ETX]
Write Variable Response:	[STX]sWA SIHstProt[ETX]

2.18.1.2. Variable: SerHostMultiplex

The following section contains a detailed description of the variable SerHostMultiplex.

Variable Overview

Variable Name	Description
SerHostMultiplex	Output multiplexer data on serial host

Communication Name	SIHstMux
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	660
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIHstMux`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstMux	String	8	Output multiplexer data on serial host

Read Variable Response:				
`sRA SIHstMux <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstMux	String	8	Output multiplexer data on serial host
Variable Data	data	Bool	1	

Write Variable:				
`sWN SIHstMux <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstMux	String	8	Output multiplexer data on serial host
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SIHstMux`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstMux	String	8	Output multiplexer data on serial host

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIHstMux[ETX]`
Read Variable Response:	`[STX]sRA SIHstMux 1[ETX]`
Write Variable:	`[STX]sWN SIHstMux 1[ETX]`
Write Variable Response:	`[STX]sWA SIHstMux[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.3. Variable: SerHostBaudrate

The following section contains a detailed description of the variable SerHostBaudrate.

Variable Overview

Variable Name	Description
SerHostBaudrate	Baudrate for HostInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)

Communication Name	SIHstBaud
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	661
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		8	
	Value	Name	Description
	1	600	
	2	1200	
	3	2400	
	4	4800	
	5	9600	
	6	19200	
	7	38400	
	8	57600	
	9	115200	

Variable Telegram Syntax

Read Variable:

```
sRN SIHstBaud
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstBaud	String	9	Baudrate for HostInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)

Read Variable Response:

```
sRA SIHstBaud <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstBaud	String	9	Baudrate for HostInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SIHstBaud <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SIHstBaud <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	SIHstBaud	String	9	Baudrate for HostInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA SIHstBaud				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstBaud	String	9	Baudrate for HostInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIHstBaud[ETX]
Read Variable Response:	[STX]sRA SIHstBaud 8[ETX]
Write Variable:	[STX]sWN SIHstBaud 8[ETX]
Write Variable Response:	[STX]sWA SIHstBaud[ETX]

2.18.1.4. Variable: SerHostStopbits

The following section contains a detailed description of the variable SerHostStopbits.

Variable Overview

Variable Name	Description
SerHostStopbits	Number of Stop Bits (1, 2)

Communication Name	SIHstStop
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	662
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	1	
	1	2	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIHstStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstStop	String	9	Number of Stop Bits (1, 2)

Read Variable Response:				
`sRA SIHstStop <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstStop	String	9	Number of Stop Bits (1, 2)
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SIHstStop <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstStop	String	9	Number of Stop Bits (1, 2)
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SIHstStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstStop	String	9	Number of Stop Bits (1, 2)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIHstStop[ETX]`
Read Variable Response:	`[STX]sRA SIHstStop 0[ETX]`
Write Variable:	`[STX]sWN SIHstStop 0[ETX]`
Write Variable Response:	`[STX]sWA SIHstStop[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.5. Variable: SerHostParity

The following section contains a detailed description of the variable SerHostParity.

Variable Overview

Variable Name	Description
SerHostParity	Combination of Number of Data Bits and Parity settings

Communication Name	SIHstPar
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	663
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DATA8_NO_PARITY	
	1	TX_DATA8_EVEN_PARITY	
	2	TX_DATA7_EVEN_PARITY	
	3	TX_DATA8_ODD_PARITY	
	4	TX_DATA7_ODD_PARITY	

Variable Telegram Syntax

Read Variable:

```
sRN SIHstPar
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstPar	String	8	Combination of Number of Data Bits and Parity settings

Read Variable Response:

```
sRA SIHstPar <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstPar	String	8	Combination of Number of Data Bits and Parity settings
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SIHstPar <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstPar	String	8	Combination of Number of Data Bits and Parity settings
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SIHstPar				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstPar	String	8	Combination of Number of Data Bits and Parity settings

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIHstPar[ETX]
Read Variable Response:	[STX]sRA SIHstPar 0[ETX]
Write Variable:	[STX]sWN SIHstPar 0[ETX]
Write Variable Response:	[STX]sWA SIHstPar[ETX]

2.18.1.6. Variable: SerHostHardware

The following section contains a detailed description of the variable SerHostHardware.

Variable Overview

Variable Name	Description
SerHostHardware	Hardware settings for Host Interface (RS232, RS422 / 485)

Communication Name	SIHstHw
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	664
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_RS232	
	1	TX_RS422_485_4WIRE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIHstHw`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstHw	String	7	Hardware settings for Host Interface (RS232, RS422 / 485)

Read Variable Response:				
`sRA SIHstHw <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstHw	String	7	Hardware settings for Host Interface (RS232, RS422 / 485)
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SIHstHw <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstHw	String	7	Hardware settings for Host Interface (RS232, RS422 / 485)
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SIHstHw`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstHw	String	7	Hardware settings for Host Interface (RS232, RS422 / 485)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIHstHw[ETX]`
Read Variable Response:	`[STX]sRA SIHstHw 0[ETX]`
Write Variable:	`[STX]sWN SIHstHw 0[ETX]`
Write Variable Response:	`[STX]sWA SIHstHw[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.7. Variable: SerHostEnHB

The following section contains a detailed description of the variable SerHostEnHB.

Variable Overview

Variable Name	Description
SerHostEnHB	Enable heartbeat on Hostinterface

Communication Name	SIHstEnHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	665
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN SIHstEnHB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstEnHB	String	9	Enable heartbeat on Hostinterface

Read Variable Response:

```
sRA SIHstEnHB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstEnHB	String	9	Enable heartbeat on Hostinterface
Variable Data	data	Bool	1	

Write Variable:

```
sWN SIHstEnHB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstEnHB	String	9	Enable heartbeat on Hostinterface
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA SIHstEnHB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstEnHB	String	9	Enable heartbeat on Hostinterface

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIHstEnHB[ETX]`
Read Variable Response:	`[STX]sRA SIHstEnHB 0[ETX]`
Write Variable:	`[STX]sWN SIHstEnHB 0[ETX]`
Write Variable Response:	`[STX]sWA SIHstEnHB[ETX]`

2.18.1.8. Variable: SerHostHBInterval

The following section contains a detailed description of the variable SerHostHBInterval.

Variable Overview

Variable Name	Description
SerHostHBInterval	Heartbeat interval on Hostinterface

Communication Name	SIHstHBInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	666
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..600
Initialisation	30
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SIHstHBInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstHBInt	String	10	Heartbeat interval on Hostinterface

Read Variable Response:

```
sRA SIHstHBInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstHBInt	String	10	Heartbeat interval on Hostinterface
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SIHstHBInt <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstHBInt	String	10	Heartbeat interval on Hostinterface
Variable Data	data	UInt	2	

Write Variable Response:				
sWA SIHstHBInt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstHBInt	String	10	Heartbeat interval on Hostinterface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIHstHBInt[ETX]
Read Variable Response:	[STX]sRA SIHstHBInt 1E[ETX]
Write Variable:	[STX]sWN SIHstHBInt 1E[ETX]
Write Variable Response:	[STX]sWA SIHstHBInt[ETX]

2.18.1.9. Variable: SerHostRetrHB

The following section contains a detailed description of the variable SerHostRetrHB.

Variable Overview

Variable Name	Description
SerHostRetrHB	Retrigger heartbeat on Hostinterface

Communication Name	SIHstRetrHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	667
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIHstRetrHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstRetrHB	String	11	Retrigger heartbeat on Hostinterface

Read Variable Response:				
`sRA SIHstRetrHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstRetrHB	String	11	Retrigger heartbeat on Hostinterface
Variable Data	data	Bool	1	

Write Variable:				
`sWN SIHstRetrHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstRetrHB	String	11	Retrigger heartbeat on Hostinterface
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SIHstRetrHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstRetrHB	String	11	Retrigger heartbeat on Hostinterface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIHstRetrHB[ETX]`
Read Variable Response:	`[STX]sRA SIHstRetrHB 1[ETX]`
Write Variable:	`[STX]sWN SIHstRetrHB 1[ETX]`
Write Variable Response:	`[STX]sWA SIHstRetrHB[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.10. Variable: SerAuxProtocol

The following section contains a detailed description of the variable SerAuxProtocol.

Variable Overview

Variable Name	Description
SerAuxProtocol	Protocol of serial aux interface

Communication Name	SIAuxProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	668
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_READ_DIAG	
	2	TX_MONITOR_SERIAL_HOST1	
	3	TX_OUTPUT_FORMAT_DEF_1	
	4	TX_OUTPUT_FORMAT_DEF_2	

Variable Telegram Syntax

Read Variable:

```
sRN SIAuxProt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxProt	String	9	Protocol of serial aux interface

Read Variable Response:

```
sRA SIAuxProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxProt	String	9	Protocol of serial aux interface
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SIAuxProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxProt	String	9	Protocol of serial aux interface
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SIAuxProt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxProt	String	9	Protocol of serial aux interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIAuxProt[ETX]
Read Variable Response:	[STX]sRA SIAuxProt 1[ETX]
Write Variable:	[STX]sWN SIAuxProt 1[ETX]
Write Variable Response:	[STX]sWA SIAuxProt[ETX]

2.18.1.11. Variable: SerAuxBaudrate

The following section contains a detailed description of the variable SerAuxBaudrate.

Variable Overview

Variable Name	Description
SerAuxBaudrate	Baudrate for AuxInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)

Communication Name	SIAuxBaud
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	669
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		8	
	Value	Name	Description
	0	300	
	1	600	
	2	1200	
	3	2400	
	4	4800	
	5	9600	
	6	19200	
	7	38400	
	8	57600	
	9	115200	
	10	250000	
	11	500000	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIAuxBaud`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxBaud	String	9	Baudrate for AuxInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)

Read Variable Response:				
`sRA SIAuxBaud <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxBaud	String	9	Baudrate for AuxInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SIAuxBaud <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxBaud	String	9	Baudrate for AuxInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SIAuxBaud`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxBaud	String	9	Baudrate for AuxInterface (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115k Baud)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIAuxBaud[ETX]`
Read Variable Response:	`[STX]sRA SIAuxBaud 8[ETX]`
Write Variable:	`[STX]sWN SIAuxBaud 8[ETX]`
Write Variable Response:	`[STX]sWA SIAuxBaud[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.12. Variable: SerAuxStopbits

The following section contains a detailed description of the variable SerAuxStopbits.

Variable Overview

Variable Name	Description
SerAuxStopbits	Number of Stop Bits (1, 2)

Communication Name	SIAuxStop
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	670
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	1	
	1	2	

Variable Telegram Syntax

Read Variable:				
`sRN SIAuxStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxStop	String	9	Number of Stop Bits (1, 2)

Read Variable Response:				
`sRA SIAuxStop <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxStop	String	9	Number of Stop Bits (1, 2)
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SIAuxStop <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxStop	String	9	Number of Stop Bits (1, 2)
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SIAuxStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxStop	String	9	Number of Stop Bits (1, 2)

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIAuxStop[ETX]`
Read Variable Response:	`[STX]sRA SIAuxStop 0[ETX]`
Write Variable:	`[STX]sWN SIAuxStop 0[ETX]`
Write Variable Response:	`[STX]sWA SIAuxStop[ETX]`

2.18.1.13. Variable: SerAuxParity

The following section contains a detailed description of the variable SerAuxParity.

Variable Overview

Variable Name	Description
SerAuxParity	Combination of Number of Data Bits and Parity settings

Communication Name	SIAuxPar
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	671
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DATA8_NO_PARITY	
	1	TX_DATA8_EVEN_PARITY	
	2	TX_DATA7_EVEN_PARITY	
	3	TX_DATA8_ODD_PARITY	
	4	TX_DATA7_ODD_PARITY	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIAuxPar`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxPar	String	8	Combination of Number of Data Bits and Parity settings

Read Variable Response:				
`sRA SIAuxPar <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxPar	String	8	Combination of Number of Data Bits and Parity settings
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SIAuxPar <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxPar	String	8	Combination of Number of Data Bits and Parity settings
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SIAuxPar`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxPar	String	8	Combination of Number of Data Bits and Parity settings

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIAuxPar[ETX]`
Read Variable Response:	`[STX]sRA SIAuxPar 0[ETX]`
Write Variable:	`[STX]sWN SIAuxPar 0[ETX]`
Write Variable Response:	`[STX]sWA SIAuxPar[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.14. Variable: SerAuxHardware

The following section contains a detailed description of the variable SerAuxHardware.

Variable Overview

Variable Name	Description
SerAuxHardware	Hardware settings for Aux Interface (RS232, RS422 / 485)

Communication Name	SIAuxHw
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	672
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_RS232	
	1	TX_RS485_2WIRE	
	2	TX_RS422_485_4WIRE	

Variable Telegram Syntax

Read Variable:

```
sRN SIAuxHw
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxHw	String	7	Hardware settings for Aux Interface (RS232, RS422 / 485)

Read Variable Response:

```
sRA SIAuxHw <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxHw	String	7	Hardware settings for Aux Interface (RS232, RS422 / 485)
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SIAuxHw <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxHw	String	7	Hardware settings for Aux Interface (RS232, RS422 / 485)
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SIAuxHw				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxHw	String	7	Hardware settings for Aux Interface (RS232, RS422 / 485)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIAuxHw[ETX]
Read Variable Response:	[STX]sRA SIAuxHw 0[ETX]
Write Variable:	[STX]sWN SIAuxHw 0[ETX]
Write Variable Response:	[STX]sWA SIAuxHw[ETX]

2.18.1.15. Variable: SerAuxEnHB

The following section contains a detailed description of the variable SerAuxEnHB.

Variable Overview

Variable Name	Description
SerAuxEnHB	Enable heartbeat on Auxinterface

Communication Name	SIAuxEnHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	673
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIAuxEnHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxEnHB	String	9	Enable heartbeat on Auxinterface

Read Variable Response:				
`sRA SIAuxEnHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxEnHB	String	9	Enable heartbeat on Auxinterface
Variable Data	data	Bool	1	

Write Variable:				
`sWN SIAuxEnHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxEnHB	String	9	Enable heartbeat on Auxinterface
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SIAuxEnHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxEnHB	String	9	Enable heartbeat on Auxinterface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIAuxEnHB[ETX]`
Read Variable Response:	`[STX]sRA SIAuxEnHB 0[ETX]`
Write Variable:	`[STX]sWN SIAuxEnHB 0[ETX]`
Write Variable Response:	`[STX]sWA SIAuxEnHB[ETX]`

© SICK AG - Germany - All rights reserved

2.18.1.16. Variable: SerAuxHBInterval

The following section contains a detailed description of the variable SerAuxHBInterval.

Variable Overview

Variable Name	Description
SerAuxHBInterval	Heartbeat interval on Auxinterface

Communication Name	SIAuxHBInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	674
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..600
Initialisation	30
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SIAuxHBInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxHBInt	String	10	Heartbeat interval on Auxinterface

Read Variable Response:

```
sRA SIAuxHBInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxHBInt	String	10	Heartbeat interval on Auxinterface
Variable Data	data	UInt	2	

Write Variable:

```
sWN SIAuxHBInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxHBInt	String	10	Heartbeat interval on Auxinterface
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA SIAuxHBInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxHBInt	String	10	Heartbeat interval on Auxinterface

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIAuxHBInt[ETX]`
Read Variable Response:	`[STX]sRA SIAuxHBInt 1E[ETX]`
Write Variable:	`[STX]sWN SIAuxHBInt 1E[ETX]`
Write Variable Response:	`[STX]sWA SIAuxHBInt[ETX]`

2.18.1.17. Variable: SerAuxRetrHB

The following section contains a detailed description of the variable SerAuxRetrHB.

Variable Overview

Variable Name	Description
SerAuxRetrHB	Retrigger heartbeat on Auxinterface

Communication Name	SIAuxRetrHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	675
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

`sRN SIAuxRetrHB`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxRetrHB	String	11	Retrigger heartbeat on Auxinterface

Read Variable Response:

`sRA SIAuxRetrHB <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxRetrHB	String	11	Retrigger heartbeat on Auxinterface
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SIAuxRetrHB <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxRetrHB	String	11	Retrigger heartbeat on Auxinterface
Variable Data	data	Bool	1	

Write Variable Response:				
sWA SIAuxRetrHB				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxRetrHB	String	11	Retrigger heartbeat on Auxinterface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIAuxRetrHB[ETX]
Read Variable Response:	[STX]sRA SIAuxRetrHB 1[ETX]
Write Variable:	[STX]sWN SIAuxRetrHB 1[ETX]
Write Variable Response:	[STX]sWA SIAuxRetrHB[ETX]

© SICK AG - Germany - All rights reserved

2.19. Interface Block: GeneralCfgEthernetBase

2.19.1. Group: EthernetBase

2.19.1.1. Variable: EtherIPAddress

The following section contains a detailed description of the variable EtherIPAddress.

Variable Overview

Variable Name	Description
EtherIPAddress	IP-Address of the Device

Communication Name	EIIpAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	676
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{192,168,0,1}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EIIpAddr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIIpAddr	String	8	IP-Address of the Device

Read Variable Response:

```
sRA EIIpAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIIpAddr	String	8	IP-Address of the Device
Variable Data	data	Array	4	

Write Variable:

```
sWN EIIpAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIIpAddr	String	8	IP-Address of the Device

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIIpAddr <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Array	4	

Write Variable Response:				
sWA EIIpAddr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIIpAddr	String	8	IP-Address of the Device

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIIpAddr[ETX]
Read Variable Response:	[STX]sRA EIIpAddr C0 A8 0 1[ETX]
Write Variable:	[STX]sWN EIIpAddr C0 A8 0 1[ETX]
Write Variable Response:	[STX]sWA EIIpAddr[ETX]

2.19.1.2. Variable: EtherIPGateAddress

The following section contains a detailed description of the variable EtherIPGateAddress.

Variable Overview

Variable Name	Description
EtherIPGateAddress	IP-Address of the Ethernet Gateway

Communication Name	EIgate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	677
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIgate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIgate	String	6	IP-Address of the Ethernet Gateway

Read Variable Response:				
`sRA EIgate <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIgate	String	6	IP-Address of the Ethernet Gateway
Variable Data	data	Array	4	

Write Variable:				
`sWN EIgate <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIgate	String	6	IP-Address of the Ethernet Gateway
Variable Data	data	Array	4	

Write Variable Response:				
`sWA EIgate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIgate	String	6	IP-Address of the Ethernet Gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIgate[ETX]`
Read Variable Response:	`[STX]sRA EIgate 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN EIgate 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA EIgate[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.3. Variable: EtherIPMask

The following section contains a detailed description of the variable EtherIPMask.

Variable Overview

Variable Name	Description
EtherIPMask	Netmask

Communication Name	EImask
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	678
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{255,255,255,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EImask
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImask	String	6	Netmask

Read Variable Response:

```
sRA EImask <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImask	String	6	Netmask
Variable Data	data	Array	4	

Write Variable:

```
sWN EImask <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImask	String	6	Netmask
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EImask				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImask	String	6	Netmask

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EImask[ETX]
Read Variable Response:	[STX]sRA EImask FF FF FF 0[ETX]
Write Variable:	[STX]sWN EImask FF FF FF 0[ETX]
Write Variable Response:	[STX]sWA EImask[ETX]

2.19.1.4. Variable: EtherIPSpeedDuplex

The following section contains a detailed description of the variable EtherIPSpeedDuplex.

Variable Overview

Variable Name	Description
EtherIPSpeedDuplex	Speed and Duplex settings

Communication Name	EISpdDpx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	679
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_AUTO	
	Value	Name	Description
	0	TX_AUTO	
	1	TX_10MB_HALF	
	2	TX_10MB_FULL	
	3	TX_100MB_HALF	
	4	TX_100MB_FULL	
	5	TX_1000MB_HALF	
	6	TX_1000MB_FULL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EISpdDpx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EISpdDpx	String	8	Speed and Duplex settings

Read Variable Response:				
`sRA EISpdDpx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EISpdDpx	String	8	Speed and Duplex settings
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EISpdDpx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EISpdDpx	String	8	Speed and Duplex settings
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EISpdDpx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EISpdDpx	String	8	Speed and Duplex settings

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EISpdDpx[ETX]`
Read Variable Response:	`[STX]sRA EISpdDpx 0[ETX]`
Write Variable:	`[STX]sWN EISpdDpx 0[ETX]`
Write Variable Response:	`[STX]sWA EISpdDpx[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.5. Variable: EtherHostProtocol

The following section contains a detailed description of the variable EtherHostProtocol.

Variable Overview

Variable Name	Description
EtherHostProtocol	Protocol for Ethernet Host

Communication Name	EIHstProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	680
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_OUTPUT_FORMAT_DEF_1	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_OUTPUT_FORMAT_DEF_1	
	2	TX_OUTPUT_FORMAT_DEF_2	
	3	TX_USERDEF_FORMAT	

Variable Telegram Syntax

Read Variable:

```
sRN EIHstProt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstProt	String	9	Protocol for Ethernet Host

Read Variable Response:

```
sRA EIHstProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstProt	String	9	Protocol for Ethernet Host
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EIHstProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstProt	String	9	Protocol for Ethernet Host
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIHstProt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstProt	String	9	Protocol for Ethernet Host

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIHstProt[ETX]
Read Variable Response:	[STX]sRA EIHstProt 1[ETX]
Write Variable:	[STX]sWN EIHstProt 1[ETX]
Write Variable Response:	[STX]sWA EIHstProt[ETX]

2.19.1.6. Variable: EtherHostFTPProtocol

The following section contains a detailed description of the variable EtherHostFTPProtocol.

Variable Overview

Variable Name	Description
EtherHostFTPProtocol	Protocol for Ethernet Host FTP client

Communication Name	EIHstFTPProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	681
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_OUTPUT	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_OUTPUT_FORMAT_DEF_1	
	2	TX_OUTPUT_FORMAT_DEF_2	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIHstFTPProt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstFTPProt	String	12	Protocol for Ethernet Host FTP client

Read Variable Response:				
`sRA EIHstFTPProt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstFTPProt	String	12	Protocol for Ethernet Host FTP client
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIHstFTPProt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstFTPProt	String	12	Protocol for Ethernet Host FTP client
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIHstFTPProt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstFTPProt	String	12	Protocol for Ethernet Host FTP client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstFTPProt[ETX]`
Read Variable Response:	`[STX]sRA EIHstFTPProt 0[ETX]`
Write Variable:	`[STX]sWN EIHstFTPProt 0[ETX]`
Write Variable Response:	`[STX]sWA EIHstFTPProt[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.7. Variable: EtherHostFTPUsername

The following section contains a detailed description of the variable EtherHostFTPUsername.

Variable Overview

Variable Name	Description
EtherHostFTPUsername	Username of Host FTP client

Communication Name	EIHstFTPClntUsrNm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	682
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

Variable Telegram Syntax

Read Variable:

```
sRN EIHstFTPClntUsrNm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstFTPClntUsrNm	String	17	Username of Host FTP client

Read Variable Response:

```
sRA EIHstFTPClntUsrNm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstFTPClntUsrNm	String	17	Username of Host FTP client
Variable Data	data	FlexString	20	

Write Variable:

```
sWN EIHstFTPClntUsrNm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstFTPClntUsrNm	String	17	Username of Host FTP client
Variable Data	data	FlexString	20	

Write Variable Response:

```
sWA EIHstFTPClntUsrNm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstFTPClntUsrNm	String	17	Username of Host FTP client

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstFTPClntUsrNm[ETX]`
Read Variable Response:	`[STX]sRA EIHstFTPClntUsrNm 9 anonymous[ETX]`
Write Variable:	`[STX]sWN EIHstFTPClntUsrNm 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA EIHstFTPClntUsrNm[ETX]`

2.19.1.8. Variable: EtherHostFTPPassword

The following section contains a detailed description of the variable EtherHostFTPPassword.

Variable Overview

Variable Name	Description
EtherHostFTPPassword	Password of Host FTP client

Communication Name	EIHstFTPClntPasWd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	683
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

Variable Telegram Syntax

Read Variable:

`sRN EIHstFTPClntPasWd`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstFTPClntPasWd	String	17	Password of Host FTP client

Read Variable Response:

`sRA EIHstFTPClntPasWd <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstFTPClntPasWd	String	17	Password of Host FTP client
Variable Data	data	FlexString	20	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIHstFTPClntPasWd <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstFTPClntPasWd	String	17	Password of Host FTP client
Variable Data	data	FlexString	20	

Write Variable Response:				
sWA EIHstFTPClntPasWd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstFTPClntPasWd	String	17	Password of Host FTP client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIHstFTPClntPasWd[ETX]
Read Variable Response:	[STX]sRA EIHstFTPClntPasWd 9 anonymous[ETX]
Write Variable:	[STX]sWN EIHstFTPClntPasWd 9 anonymous[ETX]
Write Variable Response:	[STX]sWA EIHstFTPClntPasWd[ETX]

2.19.1.9. Variable: EtherHostFTPUploadPath

The following section contains a detailed description of the variable EtherHostFTPUploadPath.

Variable Overview

Variable Name	Description
EtherHostFTPUploadPath	Upload Path of Host FTP client

Communication Name	EIHstFTPClntUpPath
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	684
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..100
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIHstFTPClntUpPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstFTPClntUpPath	String	18	Upload Path of Host FTP client

Read Variable Response:				
`sRA EIHstFTPClntUpPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstFTPClntUpPath	String	18	Upload Path of Host FTP client
Variable Data	data	FlexString	100	

Write Variable:				
`sWN EIHstFTPClntUpPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstFTPClntUpPath	String	18	Upload Path of Host FTP client
Variable Data	data	FlexString	100	

Write Variable Response:				
`sWA EIHstFTPClntUpPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstFTPClntUpPath	String	18	Upload Path of Host FTP client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstFTPClntUpPath[ETX]`
Read Variable Response:	`[STX]sRA EIHstFTPClntUpPath 0[ETX]`
Write Variable:	`[STX]sWN EIHstFTPClntUpPath 0[ETX]`
Write Variable Response:	`[STX]sWA EIHstFTPClntUpPath[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.10. Variable: EtherHostMultiplex

The following section contains a detailed description of the variable EtherHostMultiplex.

Variable Overview

Variable Name	Description
EtherHostMultiplex	Output multiplexer data on ethernet host

Communication Name	EIHstMux
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	685
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EIHstMux
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstMux	String	8	Output multiplexer data on ethernet host

Read Variable Response:

```
sRA EIHstMux <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstMux	String	8	Output multiplexer data on ethernet host
Variable Data	data	Bool	1	

Write Variable:

```
sWN EIHstMux <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstMux	String	8	Output multiplexer data on ethernet host
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EIHstMux
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstMux	String	8	Output multiplexer data on ethernet host

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstMux[ETX]`
Read Variable Response:	`[STX]sRA EIHstMux 0[ETX]`
Write Variable:	`[STX]sWN EIHstMux 0[ETX]`
Write Variable Response:	`[STX]sWA EIHstMux[ETX]`

2.19.1.11. Variable: EtherHostServerClient

The following section contains a detailed description of the variable EtherHostServerClient.

Variable Overview

Variable Name	Description
EtherHostServerClient	Selects if Ethernet Host is server or client

Communication Name	EIHstSrvClnt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	686
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_SERVER	
	Value	Name	Description
	0	TX_SERVER	
	1	TX_CLIENT	

Variable Telegram Syntax

Read Variable:				
`sRN EIHstSrvClnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstSrvClnt	String	12	Selects if Ethernet Host is server or client

Read Variable Response:				
`sRA EIHstSrvClnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstSrvClnt	String	12	Selects if Ethernet Host is server or client
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIHstSrvClnt <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstSrvClnt	String	12	Selects if Ethernet Host is server or client
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA EIHstSrvClnt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstSrvClnt	String	12	Selects if Ethernet Host is server or client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIHstSrvClnt[ETX]
Read Variable Response:	[STX]sRA EIHstSrvClnt 0[ETX]
Write Variable:	[STX]sWN EIHstSrvClnt 0[ETX]
Write Variable Response:	[STX]sWA EIHstSrvClnt[ETX]

2.19.1.12. Variable: EtherHostIPPort

The following section contains a detailed description of the variable EtherHostIPPort.

Variable Overview

Variable Name	Description
EtherHostIPPort	Port for TCP/IP communication Aux

Communication Name	EIHstPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	687
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2112
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIHstPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstPort	String	9	Port for TCP/IP communication Aux

Read Variable Response:				
`sRA EIHstPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstPort	String	9	Port for TCP/IP communication Aux
Variable Data	data	UInt	2	

Write Variable:				
`sWN EIHstPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstPort	String	9	Port for TCP/IP communication Aux
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EIHstPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstPort	String	9	Port for TCP/IP communication Aux

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstPort[ETX]`
Read Variable Response:	`[STX]sRA EIHstPort 840[ETX]`
Write Variable:	`[STX]sWN EIHstPort 840[ETX]`
Write Variable Response:	`[STX]sWA EIHstPort[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.13. Variable: EtherHostIPServerAddress

The following section contains a detailed description of the variable EtherHostIPServerAddress.

Variable Overview

Variable Name	Description
EtherHostIPServerAddress	Server address needed if client active

Communication Name	EIHstSrvAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	688
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{192,168,0,11}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EIHstSrvAddr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstSrvAddr	String	12	Server address needed if client active

Read Variable Response:

```
sRA EIHstSrvAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstSrvAddr	String	12	Server address needed if client active
Variable Data	data	Array	4	

Write Variable:

```
sWN EIHstSrvAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstSrvAddr	String	12	Server address needed if client active
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIHstSrvAddr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstSrvAddr	String	12	Server address needed if client active

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIHstSrvAddr[ETX]
Read Variable Response:	[STX]sRA EIHstSrvAddr C0 A8 0 B[ETX]
Write Variable:	[STX]sWN EIHstSrvAddr C0 A8 0 B[ETX]
Write Variable Response:	[STX]sWA EIHstSrvAddr[ETX]

2.19.1.14. Variable: EtherHostCoLaDialect

The following section contains a detailed description of the variable EtherHostCoLaDialect.

Variable Overview

Variable Name	Description
EtherHostCoLaDialect	Selects if Ethernet Host is CoLaA or CoLaB

Communication Name	EIHstCola
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	689
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_COLA_ASCII	
	Value	Name	Description
	0	TX_COLA_ASCII	
	1	TX_COLA_BINARY	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIHstCola`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstCola	String	9	Selects if Ethernet Host is CoLaA or CoLaB

Read Variable Response:				
`sRA EIHstCola <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstCola	String	9	Selects if Ethernet Host is CoLaA or CoLaB
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIHstCola <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstCola	String	9	Selects if Ethernet Host is CoLaA or CoLaB
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIHstCola`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstCola	String	9	Selects if Ethernet Host is CoLaA or CoLaB

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstCola[ETX]`
Read Variable Response:	`[STX]sRA EIHstCola 0[ETX]`
Write Variable:	`[STX]sWN EIHstCola 0[ETX]`
Write Variable Response:	`[STX]sWA EIHstCola[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.15. Variable: EtherHostEnHB

The following section contains a detailed description of the variable EtherHostEnHB.

Variable Overview

Variable Name	Description
EtherHostEnHB	Enable heartbeat on Ethernet Host

Communication Name	EIHstEnHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	690
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EIHstEnHB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstEnHB	String	9	Enable heartbeat on Ethernet Host

Read Variable Response:

```
sRA EIHstEnHB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstEnHB	String	9	Enable heartbeat on Ethernet Host
Variable Data	data	Bool	1	

Write Variable:

```
sWN EIHstEnHB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstEnHB	String	9	Enable heartbeat on Ethernet Host
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EIHstEnHB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstEnHB	String	9	Enable heartbeat on Ethernet Host

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstEnHB[ETX]`
Read Variable Response:	`[STX]sRA EIHstEnHB 0[ETX]`
Write Variable:	`[STX]sWN EIHstEnHB 0[ETX]`
Write Variable Response:	`[STX]sWA EIHstEnHB[ETX]`

2.19.1.16. Variable: EtherHostHBInterval

The following section contains a detailed description of the variable EtherHostHBInterval.

Variable Overview

Variable Name	Description
EtherHostHBInterval	Heartbeat interval on Ethernet Host

Communication Name	EIHstHBInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	691
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..600
Initialisation	30
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN EIHstHBInt`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstHBInt	String	10	Heartbeat interval on Ethernet Host

Read Variable Response:

`sRA EIHstHBInt <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstHBInt	String	10	Heartbeat interval on Ethernet Host
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIHstHBInt <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstHBInt	String	10	Heartbeat interval on Ethernet Host
Variable Data	data	UInt	2	

Write Variable Response:				
sWA EIHstHBInt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstHBInt	String	10	Heartbeat interval on Ethernet Host

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIHstHBInt[ETX]
Read Variable Response:	[STX]sRA EIHstHBInt 1E[ETX]
Write Variable:	[STX]sWN EIHstHBInt 1E[ETX]
Write Variable Response:	[STX]sWA EIHstHBInt[ETX]

2.19.1.17. Variable: EtherHostRetrHB

The following section contains a detailed description of the variable EtherHostRetrHB.

Variable Overview

Variable Name	Description
EtherHostRetrHB	Retrigger heartbeat on Ethernet Host

Communication Name	EIHstRetrHB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	692
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIHstRetrHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstRetrHB	String	11	Retrigger heartbeat on Ethernet Host

Read Variable Response:				
`sRA EIHstRetrHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstRetrHB	String	11	Retrigger heartbeat on Ethernet Host
Variable Data	data	Bool	1	

Write Variable:				
`sWN EIHstRetrHB <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstRetrHB	String	11	Retrigger heartbeat on Ethernet Host
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EIHstRetrHB`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstRetrHB	String	11	Retrigger heartbeat on Ethernet Host

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIHstRetrHB[ETX]`
Read Variable Response:	`[STX]sRA EIHstRetrHB 1[ETX]`
Write Variable:	`[STX]sWN EIHstRetrHB 1[ETX]`
Write Variable Response:	`[STX]sWA EIHstRetrHB[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.18. Variable: EtherAuxProtocol

The following section contains a detailed description of the variable EtherAuxProtocol.

Variable Overview

Variable Name	Description
EtherAuxProtocol	Protocol for Ethernet Aux

Communication Name	EIAuxProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	693
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_READ_DIAG	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_READ_DIAG	
	2	TX_OUTPUT_FORMAT_DEF_1	
	3	TX_OUTPUT_FORMAT_DEF_2	
	4	TX_MONITOR_ETHERNET_HOST1	

Variable Telegram Syntax

Read Variable:

```
sRN EIAuxProt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIAuxProt	String	9	Protocol for Ethernet Aux

Read Variable Response:

```
sRA EIAuxProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIAuxProt	String	9	Protocol for Ethernet Aux
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EIAuxProt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIAuxProt	String	9	Protocol for Ethernet Aux
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIAuxProt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIAuxProt	String	9	Protocol for Ethernet Aux

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIAuxProt[ETX]
Read Variable Response:	[STX]sRA EIAuxProt 1[ETX]
Write Variable:	[STX]sWN EIAuxProt 1[ETX]
Write Variable Response:	[STX]sWA EIAuxProt[ETX]

2.19.1.19. Variable: EtherAuxIPPort

The following section contains a detailed description of the variable EtherAuxIPPort.

Variable Overview

Variable Name	Description
EtherAuxIPPort	Port for TCP/IP communication Aux

Communication Name	EIAuxPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	694
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2111
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIAuxPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIAuxPort	String	9	Port for TCP/IP communication Aux

Read Variable Response:				
`sRA EIAuxPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIAuxPort	String	9	Port for TCP/IP communication Aux
Variable Data	data	UInt	2	

Write Variable:				
`sWN EIAuxPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIAuxPort	String	9	Port for TCP/IP communication Aux
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EIAuxPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIAuxPort	String	9	Port for TCP/IP communication Aux

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIAuxPort[ETX]`
Read Variable Response:	`[STX]sRA EIAuxPort 83F[ETX]`
Write Variable:	`[STX]sWN EIAuxPort 83F[ETX]`
Write Variable Response:	`[STX]sWA EIAuxPort[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.20. Variable: EtherRDTServerClient

The following section contains a detailed description of the variable EtherRDTServerClient.

Variable Overview

Variable Name	Description
EtherRDTServerClient	Selects if Ethernet RDT400 is inactive or client

Communication Name	EIRDTSrvClnt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	697
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DISABLED	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CLIENT	

Variable Telegram Syntax

Read Variable:				
`sRN EIRDTSrvClnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIRDTSrvClnt	String	12	Selects if Ethernet RDT400 is inactive or client

Read Variable Response:				
`sRA EIRDTSrvClnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIRDTSrvClnt	String	12	Selects if Ethernet RDT400 is inactive or client
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIRDTSrvClnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIRDTSrvClnt	String	12	Selects if Ethernet RDT400 is inactive or client
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIRDTSrvClnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIRDTSrvClnt	String	12	Selects if Ethernet RDT400 is inactive or client

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIRDTSrvClnt[ETX]`
Read Variable Response:	`[STX]sRA EIRDTSrvClnt 0[ETX]`
Write Variable:	`[STX]sWN EIRDTSrvClnt 0[ETX]`
Write Variable Response:	`[STX]sWA EIRDTSrvClnt[ETX]`

2.19.1.21. Variable: EtherRDT_ID

The following section contains a detailed description of the variable EtherRDT_ID.

Variable Overview

Variable Name	Description
EtherRDT_ID	ID for RDT400 communication RDT400

Communication Name	EIRDTID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	698
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..99
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN EIRDTID`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIRDTID	String	7	ID for RDT400 communication RDT400

Read Variable Response:

`sRA EIRDTID <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIRDTID	String	7	ID for RDT400 communication RDT400
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIRDTID <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIRDTID	String	7	ID for RDT400 communication RDT400
Variable Data	data	UInt	2	

Write Variable Response:				
sWA EIRDTID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIRDTID	String	7	ID for RDT400 communication RDT400

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIRDTID[ETX]
Read Variable Response:	[STX]sRA EIRDTID 0[ETX]
Write Variable:	[STX]sWN EIRDTID 0[ETX]
Write Variable Response:	[STX]sWA EIRDTID[ETX]

2.19.1.22. Variable: EtherRDTIPPort

The following section contains a detailed description of the variable EtherRDTIPPort.

Variable Overview

Variable Name	Description
EtherRDTIPPort	Port for TCP/IP communication RDT400

Communication Name	EIRDTPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	699
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2001
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIRDTPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIRDTPort	String	9	Port for TCP/IP communication RDT400

Read Variable Response:				
`sRA EIRDTPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIRDTPort	String	9	Port for TCP/IP communication RDT400
Variable Data	data	UInt	2	

Write Variable:				
`sWN EIRDTPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIRDTPort	String	9	Port for TCP/IP communication RDT400
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EIRDTPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIRDTPort	String	9	Port for TCP/IP communication RDT400

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIRDTPort[ETX]`
Read Variable Response:	`[STX]sRA EIRDTPort 7D1[ETX]`
Write Variable:	`[STX]sWN EIRDTPort 7D1[ETX]`
Write Variable Response:	`[STX]sWA EIRDTPort[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.23. Variable: EtherRDTIPServerAddress

The following section contains a detailed description of the variable EtherRDTIPServerAddress.

Variable Overview

Variable Name	Description
EtherRDTIPServerAddress	Server address needed if client active

Communication Name	EIRDTSrvAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	700
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{192,168,0,20}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EIRDTSrvAddr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIRDTSrvAddr	String	12	Server address needed if client active

Read Variable Response:

```
sRA EIRDTSrvAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIRDTSrvAddr	String	12	Server address needed if client active
Variable Data	data	Array	4	

Write Variable:

```
sWN EIRDTSrvAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIRDTSrvAddr	String	12	Server address needed if client active
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIRDTSrvAddr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIRDTSrvAddr	String	12	Server address needed if client active

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIRDTSrvAddr[ETX]
Read Variable Response:	[STX]sRA EIRDTSrvAddr C0 A8 0 14[ETX]
Write Variable:	[STX]sWN EIRDTSrvAddr C0 A8 0 14[ETX]
Write Variable Response:	[STX]sWA EIRDTSrvAddr[ETX]

2.19.1.24. Variable: EtherMonOutputFormat1

The following section contains a detailed description of the variable EtherMonOutputFormat1.

Variable Overview

Variable Name	Description
EtherMonOutputFormat1	Monitors output format 1 on ethernet

Communication Name	EImonou1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	701
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EImonou1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonou1	String	8	Monitors output format 1 on ethernet

Read Variable Response:				
`sRA EImonou1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonou1	String	8	Monitors output format 1 on ethernet
Variable Data	data	Bool	1	

Write Variable:				
`sWN EImonou1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonou1	String	8	Monitors output format 1 on ethernet
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EImonou1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonou1	String	8	Monitors output format 1 on ethernet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EImonou1[ETX]`
Read Variable Response:	`[STX]sRA EImonou1 0[ETX]`
Write Variable:	`[STX]sWN EImonou1 0[ETX]`
Write Variable Response:	`[STX]sWA EImonou1[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.25. Variable: EtherMonOutputFormat2

The following section contains a detailed description of the variable EtherMonOutputFormat2.

Variable Overview

Variable Name	Description
EtherMonOutputFormat2	Monitors output format 2 on ethernet

Communication Name	EImonou2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	702
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EImonou2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonou2	String	8	Monitors output format 2 on ethernet

Read Variable Response:

```
sRA EImonou2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonou2	String	8	Monitors output format 2 on ethernet
Variable Data	data	Bool	1	

Write Variable:

```
sWN EImonou2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonou2	String	8	Monitors output format 2 on ethernet
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EImonou2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonou2	String	8	Monitors output format 2 on ethernet

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EImonou2[ETX]`
Read Variable Response:	`[STX]sRA EImonou2 0[ETX]`
Write Variable:	`[STX]sWN EImonou2 0[ETX]`
Write Variable Response:	`[STX]sWA EImonou2[ETX]`

2.19.1.26. Variable: EtherMonSerAux

The following section contains a detailed description of the variable EtherMonSerAux.

Variable Overview

Variable Name	Description
EtherMonSerAux	Monitors serial aux on ethernet

Communication Name	EImonseraux
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	703
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN EImonseraux`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonseraux	String	11	Monitors serial aux on ethernet

Read Variable Response:				
`sRA EImonseraux <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonseraux	String	11	Monitors serial aux on ethernet
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EImonseraux <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonseraux	String	11	Monitors serial aux on ethernet
Variable Data	data	Bool	1	

Write Variable Response:				
sWA EImonseraux				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonseraux	String	11	Monitors serial aux on ethernet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EImonseraux[ETX]
Read Variable Response:	[STX]sRA EImonseraux 0[ETX]
Write Variable:	[STX]sWN EImonseraux 0[ETX]
Write Variable Response:	[STX]sWA EImonseraux[ETX]

2.19.1.27. Variable: EtherMonSerHost

The following section contains a detailed description of the variable EtherMonSerHost.

Variable Overview

Variable Name	Description
EtherMonSerHost	Monitors serial host on ethernet

Communication Name	EImonserhost
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	704
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EImonserhost`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonserhost	String	12	Monitors serial host on ethernet

Read Variable Response:				
`sRA EImonserhost <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonserhost	String	12	Monitors serial host on ethernet
Variable Data	data	Bool	1	

Write Variable:				
`sWN EImonserhost <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonserhost	String	12	Monitors serial host on ethernet
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EImonserhost`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonserhost	String	12	Monitors serial host on ethernet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EImonserhost[ETX]`
Read Variable Response:	`[STX]sRA EImonserhost 0[ETX]`
Write Variable:	`[STX]sWN EImonserhost 0[ETX]`
Write Variable Response:	`[STX]sWA EImonserhost[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.28. Variable: EtherMonSerAux2

The following section contains a detailed description of the variable EtherMonSerAux2.

Variable Overview

Variable Name	Description
EtherMonSerAux2	Monitors serial aux 2 on ethernet

Communication Name	EImonseraux2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	705
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EImonseraux2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonseraux2	String	12	Monitors serial aux 2 on ethernet

Read Variable Response:

```
sRA EImonseraux2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonseraux2	String	12	Monitors serial aux 2 on ethernet
Variable Data	data	Bool	1	

Write Variable:

```
sWN EImonseraux2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonseraux2	String	12	Monitors serial aux 2 on ethernet
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EImonseraux2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonseraux2	String	12	Monitors serial aux 2 on ethernet

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EImonseraux2[ETX]`
Read Variable Response:	`[STX]sRA EImonseraux2 0[ETX]`
Write Variable:	`[STX]sWN EImonseraux2 0[ETX]`
Write Variable Response:	`[STX]sWA EImonseraux2[ETX]`

2.19.1.29. Variable: EtherMonSerHost2

The following section contains a detailed description of the variable EtherMonSerHost2.

Variable Overview

Variable Name	Description
EtherMonSerHost2	Monitors serial host 2 on ethernet

Communication Name	EImonserhost2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	706
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

`sRN EImonserhost2`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonserhost2	String	13	Monitors serial host 2 on ethernet

Read Variable Response:

`sRA EImonserhost2 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonserhost2	String	13	Monitors serial host 2 on ethernet
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EImonserhost2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonserhost2	String	13	Monitors serial host 2 on ethernet
Variable Data	data	Bool	1	

Write Variable Response:				
sWA EImonserhost2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonserhost2	String	13	Monitors serial host 2 on ethernet

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EImonserhost2[ETX]
Read Variable Response:	[STX]sRA EImonserhost2 0[ETX]
Write Variable:	[STX]sWN EImonserhost2 0[ETX]
Write Variable Response:	[STX]sWA EImonserhost2[ETX]

2.19.1.30. Variable: EtherMonCAN1

The following section contains a detailed description of the variable EtherMonCAN1.

Variable Overview

Variable Name	Description
EtherMonCAN1	Defines monitoring of CAN1

Communication Name	EImonCAN1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	707
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_DISABLED	
	Value	Name	Description
	0	TX_FULL	
	1	TX_DIMENSION_DATA	
	2	TX_OBJECT_DATA	
	3	TX_READING_DATA	
	4	TX_DISABLED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EImonCAN1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonCAN1	String	9	Defines monitoring of CAN1

Read Variable Response:				
`sRA EImonCAN1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonCAN1	String	9	Defines monitoring of CAN1
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EImonCAN1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonCAN1	String	9	Defines monitoring of CAN1
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EImonCAN1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonCAN1	String	9	Defines monitoring of CAN1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EImonCAN1[ETX]`
Read Variable Response:	`[STX]sRA EImonCAN1 4[ETX]`
Write Variable:	`[STX]sWN EImonCAN1 4[ETX]`
Write Variable Response:	`[STX]sWA EImonCAN1[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.31. Variable: EtherMonCAN2

The following section contains a detailed description of the variable EtherMonCAN2.

Variable Overview

Variable Name	Description
EtherMonCAN2	Defines monitoring of CAN2

Communication Name	EImonCAN2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	708
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_DISABLED	
	Value	Name	Description
	0	TX_FULL	
	1	TX_DIMENSION_DATA	
	2	TX_OBJECT_DATA	
	3	TX_READING_DATA	
	4	TX_DISABLED	

Variable Telegram Syntax

Read Variable:

```
sRN EImonCAN2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EImonCAN2	String	9	Defines monitoring of CAN2

Read Variable Response:

```
sRA EImonCAN2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EImonCAN2	String	9	Defines monitoring of CAN2
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EImonCAN2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EImonCAN2	String	9	Defines monitoring of CAN2
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EImonCAN2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EImonCAN2	String	9	Defines monitoring of CAN2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EImonCAN2[ETX]
Read Variable Response:	[STX]sRA EImonCAN2 4[ETX]
Write Variable:	[STX]sWN EImonCAN2 4[ETX]
Write Variable Response:	[STX]sWA EImonCAN2[ETX]

2.19.1.32. Variable: EtherAddressingMode

The following section contains a detailed description of the variable EtherAddressingMode.

Variable Overview

Variable Name	Description
EtherAddressingMode	Which mode to use for Ethernet address assignement

Communication Name	EIAddrMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	709
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_IP_STATIC	
	Value	Name	Description
	0	TX_IP_STATIC	
	1	TX_IP_DHCP	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIAddrMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIAddrMode	String	10	Which mode to use for Ethernet address assignement

Read Variable Response:				
`sRA EIAddrMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIAddrMode	String	10	Which mode to use for Ethernet address assignement
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIAddrMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIAddrMode	String	10	Which mode to use for Ethernet address assignement
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIAddrMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIAddrMode	String	10	Which mode to use for Ethernet address assignement

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIAddrMode[ETX]`
Read Variable Response:	`[STX]sRA EIAddrMode 0[ETX]`
Write Variable:	`[STX]sWN EIAddrMode 0[ETX]`
Write Variable Response:	`[STX]sWA EIAddrMode[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.33. Variable: EtherDHCPFallback

The following section contains a detailed description of the variable EtherDHCPFallback.

Variable Overview

Variable Name	Description
EtherDHCPFallback	Fallback if DHCP not successfull

Communication Name	EIDHCPFallback
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	710
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_RETRY_DHCP	
	Value	Name	Description
	0	TX_USE_STATIC_IP	
	1	TX_RETRY_DHCP	

Variable Telegram Syntax

Read Variable:				
`sRN EIDHCPFallback`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIDHCPFallback	String	14	Fallback if DHCP not successfull

Read Variable Response:				
`sRA EIDHCPFallback <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIDHCPFallback	String	14	Fallback if DHCP not successfull
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIDHCPFallback <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIDHCPFallback	String	14	Fallback if DHCP not successfull
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIDHCPFallback`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIDHCPFallback	String	14	Fallback if DHCP not successfull

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIDHCPFallback[ETX]`
Read Variable Response:	`[STX]sRA EIDHCPFallback 1[ETX]`
Write Variable:	`[STX]sWN EIDHCPFallback 1[ETX]`
Write Variable Response:	`[STX]sWA EIDHCPFallback[ETX]`

2.19.1.34. Variable: EtherUpdateNeeded

The following section contains a detailed description of the variable EtherUpdateNeeded.

Variable Overview

Variable Name	Description
EtherUpdateNeeded	Signs that due to parameter changes a update is meaningful

Communication Name	EIUpdtNdd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	711
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EIUpdtNdd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIUpdtNdd	String	9	Signs that due to parameter changes a update is meaningful

Read Variable Response:

```
sRA EIUpdtNdd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIUpdtNdd	String	9	Signs that due to parameter changes a update is meaningful
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN EIUpdtNdd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIUpdtNdd	String	9	Signs that due to parameter changes a update is meaningful
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EIUpdtNdd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIUpdtNdd	String	9	Signs that due to parameter changes a update is meaningful

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIUpdtNdd[ETX]`
Read Variable Response:	`[STX]sRA EIUpdtNdd 0[ETX]`
Write Variable:	`[STX]sWN EIUpdtNdd 0[ETX]`
Write Variable Response:	`[STX]sWA EIUpdtNdd[ETX]`

2.19.1.35. Variable: EtherUDPIPPort

The following section contains a detailed description of the variable EtherUDPIPPort.

Variable Overview

Variable Name	Description
EtherUDPIPPort	Port for UDP/IP communication

Communication Name	EIUDPPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	712
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2213
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIUDPPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIUDPPort	String	9	Port for UDP/IP communication

Read Variable Response:				
`sRA EIUDPPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIUDPPort	String	9	Port for UDP/IP communication
Variable Data	data	UInt	2	

Write Variable:				
`sWN EIUDPPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIUDPPort	String	9	Port for UDP/IP communication
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EIUDPPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIUDPPort	String	9	Port for UDP/IP communication

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIUDPPort[ETX]`
Read Variable Response:	`[STX]sRA EIUDPPort 8A5[ETX]`
Write Variable:	`[STX]sWN EIUDPPort 8A5[ETX]`
Write Variable Response:	`[STX]sWA EIUDPPort[ETX]`

© SICK AG - Germany - All rights reserved

2.19.1.36. Variable: EtherUDPCoLaDialect

The following section contains a detailed description of the variable EtherUDPCoLaDialect.

Variable Overview

Variable Name	Description
EtherUDPCoLaDialect	Selects if UDP is CoLaA or CoLaB

Communication Name	EIUDPCola
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	713
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_COLA_ASCII	
	Value	Name	Description
	0	TX_COLA_ASCII	
	1	TX_COLA_BINARY	

Variable Telegram Syntax

Read Variable:

```
sRN EIUDPCola
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIUDPCola	String	9	Selects if UDP is CoLaA or CoLaB

Read Variable Response:

```
sRA EIUDPCola <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIUDPCola	String	9	Selects if UDP is CoLaA or CoLaB
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EIUDPCola <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIUDPCola	String	9	Selects if UDP is CoLaA or CoLaB
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA EIUDPCola
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIUDPCola	String	9	Selects if UDP is CoLaA or CoLaB

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIUDPCola[ETX]`
Read Variable Response:	`[STX]sRA EIUDPCola 0[ETX]`
Write Variable:	`[STX]sWN EIUDPCola 0[ETX]`
Write Variable Response:	`[STX]sWA EIUDPCola[ETX]`

2.19.1.37. Method: EthernetPing

The following section contains a detailed description of the method EthernetPing.

Method Overview

Method Name	**Description**
EthernetPing	tests the ethernet connection

Communication Name	mEthPing
Sopas Index	77
Invocation Access	Service

Parameters			
IPAddress			
	Array		
	Length	4	
		USInt	
		Value Range	0..255
		Initialisation	
		Physical Unit	
		Physical Unit Factor	0.0
Timeout		Ping-Timeout in MS	
	UDInt		
	Value Range	0..10000	
	Initialisation	1000	
	Physical Unit	ms	
	Physical Unit Factor	0.0	
InterfaceNumber		Ethernet interface number	
	Enum8		
		Value	Name	Description
		0	TX_ETH_1	
		1	TX_ETH_2	
		2	TX_ETH_3	
		3	TX_ETH_4	
		4	TX_ETH_5	
		5	TX_ETH_6	
		6	TX_ETH_7	
		7	TX_ETH_8	

© SICK AG - Germany - All rights reserved

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN mEthPing <IPAddress> <Timeout> <InterfaceNumber>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEthPing	String	8	tests the ethernet connection
Parameter 1	IPAddress	Array	4	
Parameter 2	Timeout	UDInt	4	Ping-Timeout in MS
Parameter 3	InterfaceNumber	Enum8	1	Ethernet interface number

Method Return Value:				
`sAN mEthPing <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEthPing	String	8	tests the ethernet connection
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEthPing 0 0 0 0 3E8 0[ETX]`
Method Return Value:	`[STX]sAN mEthPing 0[ETX]`

2.19.1.38. Method: EthernetUpdate

The following section contains a detailed description of the method EthernetUpdate.

Method Overview

Method Name	Description
EthernetUpdate	updates the ethernet connection

Communication Name	mEthUpdt
Sopas Index	78
Invocation Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mEthUpdt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEthUpdt	String	8	updates the ethernet connection

Method Return Value:				
`sAN mEthUpdt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEthUpdt	String	8	updates the ethernet connection

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEthUpdt[ETX]`
Method Return Value:	`[STX]sAN mEthUpdt[ETX]`

© SICK AG - Germany - All rights reserved

2.19.2. Group: FTPServer

2.19.2.1. Variable: FTPSrvEnabled

The following section contains a detailed description of the variable FTPSrvEnabled.

Variable Overview

Variable Name	Description
FTPSrvEnabled	Enables / disables the FTP server

Communication Name	FTPSEnable
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	714
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN FTPSEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTPSEnable	String	10	Enables / disables the FTP server

Read Variable Response:

```
sRA FTPSEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTPSEnable	String	10	Enables / disables the FTP server
Variable Data	data	Bool	1	

Write Variable:

```
sWN FTPSEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTPSEnable	String	10	Enables / disables the FTP server
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA FTPSEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FTPSEnable				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	FTPSEnable	String	10	Enables / disables the FTP server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTPSEnable[ETX]
Read Variable Response:	[STX]sRA FTPSEnable 0[ETX]
Write Variable:	[STX]sWN FTPSEnable 0[ETX]
Write Variable Response:	[STX]sWA FTPSEnable[ETX]

2.19.2.2. Variable: FTPSrvUsrPassword

The following section contains a detailed description of the variable FTPSrvUsrPassword.

Variable Overview

Variable Name	Description
FTPSrvUsrPassword	Password of FTP server user

Communication Name	FTPSUsrPasWd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	715
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTPSUsrPasWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTPSUsrPasWd	String	12	Password of FTP server user

Read Variable Response:				
`sRA FTPSUsrPasWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTPSUsrPasWd	String	12	Password of FTP server user
Variable Data	data	FlexString	20	

Write Variable:				
`sWN FTPSUsrPasWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTPSUsrPasWd	String	12	Password of FTP server user
Variable Data	data	FlexString	20	

Write Variable Response:				
`sWA FTPSUsrPasWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTPSUsrPasWd	String	12	Password of FTP server user

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTPSUsrPasWd[ETX]`
Read Variable Response:	`[STX]sRA FTPSUsrPasWd 9 anonymous[ETX]`
Write Variable:	`[STX]sWN FTPSUsrPasWd 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA FTPSUsrPasWd[ETX]`

© SICK AG - Germany - All rights reserved

2.19.2.3. Variable: FTPSrvUsrName

The following section contains a detailed description of the variable FTPSrvUsrName.

Variable Overview

Variable Name	Description
FTPSrvUsrName	Username of FTP server user

Communication Name	FTPSUsrNm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	716
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

Variable Telegram Syntax

Read Variable:

```
sRN FTPSUsrNm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTPSUsrNm	String	9	Username of FTP server user

Read Variable Response:

```
sRA FTPSUsrNm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTPSUsrNm	String	9	Username of FTP server user
Variable Data	data	FlexString	20	

Write Variable:

```
sWN FTPSUsrNm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTPSUsrNm	String	9	Username of FTP server user
Variable Data	data	FlexString	20	

Write Variable Response:

```
sWA FTPSUsrNm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTPSUsrNm	String	9	Username of FTP server user

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTPSUsrNm[ETX]`
Read Variable Response:	`[STX]sRA FTPSUsrNm 9 anonymous[ETX]`
Write Variable:	`[STX]sWN FTPSUsrNm 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA FTPSUsrNm[ETX]`

2.19.2.4. Variable: FTPSrvPort

The following section contains a detailed description of the variable FTPSrvPort.

Variable Overview

Variable Name	Description
FTPSrvPort	Port for FTP server

Communication Name	FTPSPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	717
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	21
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FTPSPort
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTPSPort	String	8	Port for FTP server

Read Variable Response:

```
sRA FTPSPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTPSPort	String	8	Port for FTP server
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FTPSPort <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTPSPort	String	8	Port for FTP server
Variable Data	data	UInt	2	

Write Variable Response:				
sWA FTPSPort				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTPSPort	String	8	Port for FTP server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTPSPort[ETX]
Read Variable Response:	[STX]sRA FTPSPort 15[ETX]
Write Variable:	[STX]sWN FTPSPort 15[ETX]
Write Variable Response:	[STX]sWA FTPSPort[ETX]

2.19.2.5. Variable: FTPRootPath

The following section contains a detailed description of the variable FTPRootPath.

Variable Overview

Variable Name	Description
FTPRootPath	Root path for FTP server

Communication Name	FTPSRootPath
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	718
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..100
Initialisation	ram:/FTProot

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTPSRootPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTPSRootPath	String	12	Root path for FTP server

Read Variable Response:				
`sRA FTPSRootPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTPSRootPath	String	12	Root path for FTP server
Variable Data	data	FlexString	100	

Write Variable:				
`sWN FTPSRootPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTPSRootPath	String	12	Root path for FTP server
Variable Data	data	FlexString	100	

Write Variable Response:				
`sWA FTPSRootPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTPSRootPath	String	12	Root path for FTP server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTPSRootPath[ETX]`
Read Variable Response:	`[STX]sRA FTPSRootPath C ram:/FTProot[ETX]`
Write Variable:	`[STX]sWN FTPSRootPath C ram:/FTProot[ETX]`
Write Variable Response:	`[STX]sWA FTPSRootPath[ETX]`

© SICK AG - Germany - All rights reserved

2.20. Interface Block: GeneralCfgEthernet1Base

2.20.1. Group: Ethernet1Base

2.20.1.1. Variable: Ether1IPAddress

The following section contains a detailed description of the variable Ether1IPAddress.

Variable Overview

Variable Name	Description
Ether1IPAddress	IP-Address of the Device

Communication Name	EI1IpAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	726
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{192,168,1,1}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EI1IpAddr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1IpAddr	String	9	IP-Address of the Device

Read Variable Response:

```
sRA EI1IpAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1IpAddr	String	9	IP-Address of the Device
Variable Data	data	Array	4	

Write Variable:

```
sWN EI1IpAddr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1IpAddr	String	9	IP-Address of the Device

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EI1IpAddr <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Array	4	

Write Variable Response:				
sWA EI1IpAddr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1IpAddr	String	9	IP-Address of the Device

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1IpAddr[ETX]
Read Variable Response:	[STX]sRA EI1IpAddr C0 A8 1 1[ETX]
Write Variable:	[STX]sWN EI1IpAddr C0 A8 1 1[ETX]
Write Variable Response:	[STX]sWA EI1IpAddr[ETX]

2.20.1.2. Variable: Ether1IPGateAddress

The following section contains a detailed description of the variable Ether1IPGateAddress.

Variable Overview

Variable Name	Description
Ether1IPGateAddress	IP-Address of the Ethernet Gateway

Communication Name	EI1gate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	727
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{0,0,0,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI1gate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1gate	String	7	IP-Address of the Ethernet Gateway

Read Variable Response:				
`sRA EI1gate <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1gate	String	7	IP-Address of the Ethernet Gateway
Variable Data	data	Array	4	

Write Variable:				
`sWN EI1gate <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1gate	String	7	IP-Address of the Ethernet Gateway
Variable Data	data	Array	4	

Write Variable Response:				
`sWA EI1gate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1gate	String	7	IP-Address of the Ethernet Gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1gate[ETX]`
Read Variable Response:	`[STX]sRA EI1gate 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN EI1gate 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA EI1gate[ETX]`

© SICK AG - Germany - All rights reserved

2.20.1.3. Variable: Ether1IPMask

The following section contains a detailed description of the variable Ether1IPMask.

Variable Overview

Variable Name	Description
Ether1IPMask	Netmask

Communication Name	EI1mask
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	728
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{255,255,255,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EI1mask
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1mask	String	7	Netmask

Read Variable Response:

```
sRA EI1mask <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1mask	String	7	Netmask
Variable Data	data	Array	4	

Write Variable:

```
sWN EI1mask <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1mask	String	7	Netmask
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EI1mask				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1mask	String	7	Netmask

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1mask[ETX]
Read Variable Response:	[STX]sRA EI1mask FF FF FF 0[ETX]
Write Variable:	[STX]sWN EI1mask FF FF FF 0[ETX]
Write Variable Response:	[STX]sWA EI1mask[ETX]

2.20.1.4. Variable: Ether1IPSpeedDuplex

The following section contains a detailed description of the variable Ether1IPSpeedDuplex.

Variable Overview

Variable Name	Description
Ether1IPSpeedDuplex	Speed and Duplex settings

Communication Name	EI1SpdDpx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	729
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_AUTO	
	Value	Name	Description
	0	TX_AUTO	
	1	TX_10MB_HALF	
	2	TX_10MB_FULL	
	3	TX_100MB_HALF	
	4	TX_100MB_FULL	
	5	TX_1000MB_HALF	
	6	TX_1000MB_FULL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI1SpdDpx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1SpdDpx	String	9	Speed and Duplex settings

Read Variable Response:				
`sRA EI1SpdDpx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1SpdDpx	String	9	Speed and Duplex settings
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI1SpdDpx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1SpdDpx	String	9	Speed and Duplex settings
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EI1SpdDpx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1SpdDpx	String	9	Speed and Duplex settings

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1SpdDpx[ETX]`
Read Variable Response:	`[STX]sRA EI1SpdDpx 0[ETX]`
Write Variable:	`[STX]sWN EI1SpdDpx 0[ETX]`
Write Variable Response:	`[STX]sWA EI1SpdDpx[ETX]`

© SICK AG - Germany - All rights reserved

2.20.1.5. Variable: Ether1DHCPFallback

The following section contains a detailed description of the variable Ether1DHCPFallback.

Variable Overview

Variable Name	Description
Ether1DHCPFallback	Fallback if DHCP not successfull

Communication Name	EI1DHCPFallback
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	730
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_RETRY_DHCP	
	Value	Name	Description
	0	TX_USE_STATIC_IP	
	1	TX_RETRY_DHCP	

Variable Telegram Syntax

Read Variable:				
`sRN EI1DHCPFallback`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1DHCPFallback	String	15	Fallback if DHCP not successfull

Read Variable Response:				
`sRA EI1DHCPFallback <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1DHCPFallback	String	15	Fallback if DHCP not successfull
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI1DHCPFallback <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1DHCPFallback	String	15	Fallback if DHCP not successfull
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EI1DHCPFallback`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1DHCPFallback	String	15	Fallback if DHCP not successfull

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1DHCPFallback[ETX]`
Read Variable Response:	`[STX]sRA EI1DHCPFallback 1[ETX]`
Write Variable:	`[STX]sWN EI1DHCPFallback 1[ETX]`
Write Variable Response:	`[STX]sWA EI1DHCPFallback[ETX]`

2.20.1.6. Variable: Ether1AddressingMode

The following section contains a detailed description of the variable Ether1AddressingMode.

Variable Overview

Variable Name	Description
Ether1AddressingMode	Which mode to use for Ethernet address assignement

Communication Name	EI1AddrMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	731
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_IP_STATIC	
	Value	Name	Description
	0	TX_IP_STATIC	
	1	TX_IP_DHCP	

Variable Telegram Syntax

Read Variable:				
`sRN EI1AddrMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1AddrMode	String	11	Which mode to use for Ethernet address assignement

Read Variable Response:				
`sRA EI1AddrMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1AddrMode	String	11	Which mode to use for Ethernet address assignement
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EI1AddrMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1AddrMode	String	11	Which mode to use for Ethernet address assignement
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA EI1AddrMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1AddrMode	String	11	Which mode to use for Ethernet address assignement

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1AddrMode[ETX]
Read Variable Response:	[STX]sRA EI1AddrMode 0[ETX]
Write Variable:	[STX]sWN EI1AddrMode 0[ETX]
Write Variable Response:	[STX]sWA EI1AddrMode[ETX]

2.20.1.7. Variable: Ether1AuxProtocol

The following section contains a detailed description of the variable Ether1AuxProtocol.

Variable Overview

Variable Name	Description
Ether1AuxProtocol	Protocol for Ethernet Aux

Communication Name	EI1AuxProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	733
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_OUTPUT	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_READ_DIAG	
	2	TX_OUTPUT_FORMAT_DEF_1	
	3	TX_OUTPUT_FORMAT_DEF_2	
	4	TX_MONITOR_ETHERNET_HOST1	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EI1AuxProt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1AuxProt	String	10	Protocol for Ethernet Aux

Read Variable Response:				
`sRA EI1AuxProt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1AuxProt	String	10	Protocol for Ethernet Aux
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EI1AuxProt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1AuxProt	String	10	Protocol for Ethernet Aux
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EI1AuxProt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1AuxProt	String	10	Protocol for Ethernet Aux

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1AuxProt[ETX]`
Read Variable Response:	`[STX]sRA EI1AuxProt 0[ETX]`
Write Variable:	`[STX]sWN EI1AuxProt 0[ETX]`
Write Variable Response:	`[STX]sWA EI1AuxProt[ETX]`

© SICK AG - Germany - All rights reserved

2.20.1.8. Variable: Ether1AuxIPPort

The following section contains a detailed description of the variable Ether1AuxIPPort.

Variable Overview

Variable Name	Description
Ether1AuxIPPort	Port for TCP/IP communication Aux

Communication Name	EI1AuxPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	734
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2111
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EI1AuxPort
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1AuxPort	String	10	Port for TCP/IP communication Aux

Read Variable Response:

```
sRA EI1AuxPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1AuxPort	String	10	Port for TCP/IP communication Aux
Variable Data	data	UInt	2	

Write Variable:

```
sWN EI1AuxPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1AuxPort	String	10	Port for TCP/IP communication Aux
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA EI1AuxPort
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1AuxPort	String	10	Port for TCP/IP communication Aux

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EI1AuxPort[ETX]`
Read Variable Response:	`[STX]sRA EI1AuxPort 83F[ETX]`
Write Variable:	`[STX]sWN EI1AuxPort 83F[ETX]`
Write Variable Response:	`[STX]sWA EI1AuxPort[ETX]`

© SICK AG - Germany - All rights reserved

2.21. Interface Block: GeneralCfgTrigCtrlBase

2.21.1. Group: TrigCtrlBase

2.21.1.1. Variable: TrigControl

The following section contains a detailed description of the variable TrigControl.

Variable Overview

Variable Name	Description
TrigControl	Switch wether trigger is time or track controlled

Communication Name	TCControl
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	741
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TIME_BASED	
	1	TX_TRACK_BASED	

Variable Telegram Syntax

Read Variable:

```
sRN TCControl
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCControl	String	9	Switch wether trigger is time or track controlled

Read Variable Response:

```
sRA TCControl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCControl	String	9	Switch wether trigger is time or track controlled
Variable Data	data	Enum8	1	

Write Variable:

```
sWN TCControl <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCControl	String	9	Switch wether trigger is time or track controlled
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TCControl				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCControl	String	9	Switch wether trigger is time or track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCControl[ETX]
Read Variable Response:	[STX]sRA TCControl 0[ETX]
Write Variable:	[STX]sWN TCControl 0[ETX]
Write Variable Response:	[STX]sWA TCControl[ETX]

2.21.1.2. Variable: TrigStartDelayTime

The following section contains a detailed description of the variable TrigStartDelayTime.

Variable Overview

Variable Name	Description
TrigStartDelayTime	Start delay value if time controlled

Communication Name	TCStartDelTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	742
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCStartDelTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStartDelTm	String	12	Start delay value if time controlled

Read Variable Response:				
`sRA TCStartDelTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStartDelTm	String	12	Start delay value if time controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN TCStartDelTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStartDelTm	String	12	Start delay value if time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA TCStartDelTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStartDelTm	String	12	Start delay value if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStartDelTm[ETX]`
Read Variable Response:	`[STX]sRA TCStartDelTm 0[ETX]`
Write Variable:	`[STX]sWN TCStartDelTm 0[ETX]`
Write Variable Response:	`[STX]sWA TCStartDelTm[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.3. Variable: TrigStartDelayTrack

The following section contains a detailed description of the variable TrigStartDelayTrack.

Variable Overview

Variable Name	Description
TrigStartDelayTrack	Start delay value if track controlled

Communication Name	TCStartDelTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	743
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCStartDelTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStartDelTrk	String	13	Start delay value if track controlled

Read Variable Response:

```
sRA TCStartDelTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStartDelTrk	String	13	Start delay value if track controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN TCStartDelTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStartDelTrk	String	13	Start delay value if track controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA TCStartDelTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStartDelTrk	String	13	Start delay value if track controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStartDelTrk[ETX]`
Read Variable Response:	`[STX]sRA TCStartDelTrk 0[ETX]`
Write Variable:	`[STX]sWN TCStartDelTrk 0[ETX]`
Write Variable Response:	`[STX]sWA TCStartDelTrk[ETX]`

2.21.1.4. Variable: TrigStopTimerTime

The following section contains a detailed description of the variable TrigStopTimerTime.

Variable Overview

Variable Name	Description
TrigStopTimerTime	Stop timer value if time controlled

Communication Name	TCStopTimerTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	744
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	1000
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCStopTimerTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopTimerTm	String	13	Stop timer value if time controlled

Read Variable Response:

```
sRA TCStopTimerTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopTimerTm	String	13	Stop timer value if time controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TCStopTimerTm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopTimerTm	String	13	Stop timer value if time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA TCStopTimerTm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopTimerTm	String	13	Stop timer value if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCStopTimerTm[ETX]
Read Variable Response:	[STX]sRA TCStopTimerTm 3E8[ETX]
Write Variable:	[STX]sWN TCStopTimerTm 3E8[ETX]
Write Variable Response:	[STX]sWA TCStopTimerTm[ETX]

2.21.1.5. Variable: TrigStopTimerTrack

The following section contains a detailed description of the variable TrigStopTimerTrack.

Variable Overview

Variable Name	Description
TrigStopTimerTrack	Stop timer value if track controlled

Communication Name	TCStopTimerTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	745
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50000
Initialisation	1000
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCStopTimerTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopTimerTrk	String	14	Stop timer value if track controlled

Read Variable Response:				
`sRA TCStopTimerTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopTimerTrk	String	14	Stop timer value if track controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN TCStopTimerTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopTimerTrk	String	14	Stop timer value if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA TCStopTimerTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopTimerTrk	String	14	Stop timer value if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStopTimerTrk[ETX]`
Read Variable Response:	`[STX]sRA TCStopTimerTrk 3E8[ETX]`
Write Variable:	`[STX]sWN TCStopTimerTrk 3E8[ETX]`
Write Variable Response:	`[STX]sWA TCStopTimerTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.6. Variable: TrigStopDelayTime

The following section contains a detailed description of the variable TrigStopDelayTime.

Variable Overview

Variable Name	Description
TrigStopDelayTime	Stop delay value if time controlled

Communication Name	TCStopDelTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	746
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCStopDelTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopDelTm	String	11	Stop delay value if time controlled

Read Variable Response:

```
sRA TCStopDelTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopDelTm	String	11	Stop delay value if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN TCStopDelTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopDelTm	String	11	Stop delay value if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA TCStopDelTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopDelTm	String	11	Stop delay value if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStopDelTm[ETX]`
Read Variable Response:	`[STX]sRA TCStopDelTm 0[ETX]`
Write Variable:	`[STX]sWN TCStopDelTm 0[ETX]`
Write Variable Response:	`[STX]sWA TCStopDelTm[ETX]`

2.21.1.7. Variable: TrigStopDelayTrack

The following section contains a detailed description of the variable TrigStopDelayTrack.

Variable Overview

Variable Name	Description
TrigStopDelayTrack	Stop delay value if track controlled

Communication Name	TCStopDelTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	747
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN TCStopDelTrk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopDelTrk	String	12	Stop delay value if track controlled

Read Variable Response:

`sRA TCStopDelTrk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopDelTrk	String	12	Stop delay value if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TCStopDelTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopDelTrk	String	12	Stop delay value if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA TCStopDelTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopDelTrk	String	12	Stop delay value if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCStopDelTrk[ETX]
Read Variable Response:	[STX]sRA TCStopDelTrk 0[ETX]
Write Variable:	[STX]sWN TCStopDelTrk 0[ETX]
Write Variable Response:	[STX]sWA TCStopDelTrk[ETX]

2.21.1.8. Variable: TrigAutoCyclePulseTime

The following section contains a detailed description of the variable TrigAutoCyclePulseTime.

Variable Overview

Variable Name	Description
TrigAutoCyclePulseTime	Duration of Pulse if autocycle mode and time controlled

Communication Name	TCacPlsTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	748
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	1000
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCacPlsTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCacPlsTm	String	9	Duration of Pulse if autocycle mode and time controlled

Read Variable Response:				
`sRA TCacPlsTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCacPlsTm	String	9	Duration of Pulse if autocycle mode and time controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN TCacPlsTm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCacPlsTm	String	9	Duration of Pulse if autocycle mode and time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA TCacPlsTm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCacPlsTm	String	9	Duration of Pulse if autocycle mode and time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCacPlsTm[ETX]`
Read Variable Response:	`[STX]sRA TCacPlsTm 3E8[ETX]`
Write Variable:	`[STX]sWN TCacPlsTm 3E8[ETX]`
Write Variable Response:	`[STX]sWA TCacPlsTm[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.9. Variable: TrigAutoCyclePauseTime

The following section contains a detailed description of the variable TrigAutoCyclePauseTime.

Variable Overview

Variable Name	Description
TrigAutoCyclePauseTime	Duration of Pause if autocycle mode and time controlled

Communication Name	TCacPauTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	749
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	1000
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCacPauTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCacPauTm	String	9	Duration of Pause if autocycle mode and time controlled

Read Variable Response:

```
sRA TCacPauTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCacPauTm	String	9	Duration of Pause if autocycle mode and time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN TCacPauTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCacPauTm	String	9	Duration of Pause if autocycle mode and time controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TCacPauTm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCacPauTm	String	9	Duration of Pause if autocycle mode and time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCacPauTm[ETX]
Read Variable Response:	[STX]sRA TCacPauTm 3E8[ETX]
Write Variable:	[STX]sWN TCacPauTm 3E8[ETX]
Write Variable Response:	[STX]sWA TCacPauTm[ETX]

2.21.1.10. Variable: TrigAutoCyclePulseTrack

The following section contains a detailed description of the variable TrigAutoCyclePulseTrack.

Variable Overview

Variable Name	Description
TrigAutoCyclePulseTrack	Duration of Pulse if autocycle mode and track controlled

Communication Name	TCacPlsTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	750
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	1000
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCacPlsTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCacPlsTrk	String	10	Duration of Pulse if autocycle mode and track controlled

Read Variable Response:				
`sRA TCacPlsTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCacPlsTrk	String	10	Duration of Pulse if autocycle mode and track controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN TCacPlsTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCacPlsTrk	String	10	Duration of Pulse if autocycle mode and track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA TCacPlsTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCacPlsTrk	String	10	Duration of Pulse if autocycle mode and track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCacPlsTrk[ETX]`
Read Variable Response:	`[STX]sRA TCacPlsTrk 3E8[ETX]`
Write Variable:	`[STX]sWN TCacPlsTrk 3E8[ETX]`
Write Variable Response:	`[STX]sWA TCacPlsTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.11. Variable: TrigAutoCyclePauseTrack

The following section contains a detailed description of the variable TrigAutoCyclePauseTrack.

Variable Overview

Variable Name	Description
TrigAutoCyclePauseTrack	Duration of Pause if autocycle mode and track controlled

Communication Name	TCacPauTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	751
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	50..10000
Initialisation	1000
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCacPauTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCacPauTrk	String	10	Duration of Pause if autocycle mode and track controlled

Read Variable Response:

```
sRA TCacPauTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCacPauTrk	String	10	Duration of Pause if autocycle mode and track controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN TCacPauTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCacPauTrk	String	10	Duration of Pause if autocycle mode and track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TCacPauTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCacPauTrk	String	10	Duration of Pause if autocycle mode and track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCacPauTrk[ETX]
Read Variable Response:	[STX]sRA TCacPauTrk 3E8[ETX]
Write Variable:	[STX]sWN TCacPauTrk 3E8[ETX]
Write Variable Response:	[STX]sWA TCacPauTrk[ETX]

2.21.1.12. Variable: TrigCANSource

The following section contains a detailed description of the variable TrigCANSource.

Variable Overview

Variable Name	Description
TrigCANSource	Object trigger distribution source on CAN-Bus

Communication Name	TCcantrgsrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	752
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	1..63
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCcantrgsrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCcantrgsrc	String	11	Object trigger distribution source on CAN-Bus

Read Variable Response:				
`sRA TCcantrgsrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCcantrgsrc	String	11	Object trigger distribution source on CAN-Bus
Variable Data	data	USInt	1	

Write Variable:				
`sWN TCcantrgsrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCcantrgsrc	String	11	Object trigger distribution source on CAN-Bus
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA TCcantrgsrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCcantrgsrc	String	11	Object trigger distribution source on CAN-Bus

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCcantrgsrc[ETX]`
Read Variable Response:	`[STX]sRA TCcantrgsrc 1[ETX]`
Write Variable:	`[STX]sWN TCcantrgsrc 1[ETX]`
Write Variable Response:	`[STX]sWA TCcantrgsrc[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.13. Variable: TrigDistribute

The following section contains a detailed description of the variable TrigDistribute.

Variable Overview

Variable Name	Description
TrigDistribute	Object trigger distribution on CAN-Bus

Communication Name	TCtrgdist
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	753
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CAN_1	

Variable Telegram Syntax

Read Variable:				
`sRN TCtrgdist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCtrgdist	String	9	Object trigger distribution on CAN-Bus

Read Variable Response:				
`sRA TCtrgdist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCtrgdist	String	9	Object trigger distribution on CAN-Bus
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TCtrgdist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCtrgdist	String	9	Object trigger distribution on CAN-Bus
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA TCtrgdist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCtrgdist	String	9	Object trigger distribution on CAN-Bus

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCtrgdist[ETX]`
Read Variable Response:	`[STX]sRA TCtrgdist 0[ETX]`
Write Variable:	`[STX]sWN TCtrgdist 0[ETX]`
Write Variable Response:	`[STX]sWA TCtrgdist[ETX]`

2.21.1.14. Variable: TrigExpansionTime

The following section contains a detailed description of the variable TrigExpansionTime.

Variable Overview

Variable Name	Description
TrigExpansionTime	Object trigger expansion behind object if time controlled

Communication Name	TCExpansTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	755
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..3000
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCExpansTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCExpansTm	String	10	Object trigger expansion behind object if time controlled

Read Variable Response:

```
sRA TCExpansTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCExpansTm	String	10	Object trigger expansion behind object if time controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TCExpansTm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCExpansTm	String	10	Object trigger expansion behind object if time controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA TCExpansTm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCExpansTm	String	10	Object trigger expansion behind object if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCExpansTm[ETX]
Read Variable Response:	[STX]sRA TCExpansTm 0[ETX]
Write Variable:	[STX]sWN TCExpansTm 0[ETX]
Write Variable Response:	[STX]sWA TCExpansTm[ETX]

2.21.1.15. Variable: TrigExpansionTrack

The following section contains a detailed description of the variable TrigExpansionTrack.

Variable Overview

Variable Name	Description
TrigExpansionTrack	Object trigger expansion behind object if track controlled

Communication Name	TCExpansTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	756
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..30000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCExpansTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCExpansTrk	String	11	Object trigger expansion behind object if track controlled

Read Variable Response:				
`sRA TCExpansTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCExpansTrk	String	11	Object trigger expansion behind object if track controlled
Variable Data	data	UInt	2	

Write Variable:				
`sWN TCExpansTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCExpansTrk	String	11	Object trigger expansion behind object if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA TCExpansTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCExpansTrk	String	11	Object trigger expansion behind object if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCExpansTrk[ETX]`
Read Variable Response:	`[STX]sRA TCExpansTrk 0[ETX]`
Write Variable:	`[STX]sWN TCExpansTrk 0[ETX]`
Write Variable Response:	`[STX]sWA TCExpansTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.16. Variable: TrigPreExpansionTime

The following section contains a detailed description of the variable TrigPreExpansionTime.

Variable Overview

Variable Name	Description
TrigPreExpansionTime	Object trigger expansion before if time controlled

Communication Name	TCExpPreTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	757
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..3000
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCExpPreTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCExpPreTm	String	10	Object trigger expansion before if time controlled

Read Variable Response:

```
sRA TCExpPreTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCExpPreTm	String	10	Object trigger expansion before if time controlled
Variable Data	data	UInt	2	

Write Variable:

```
sWN TCExpPreTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCExpPreTm	String	10	Object trigger expansion before if time controlled
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA TCExpPreTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCExpPreTm	String	10	Object trigger expansion before if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCExpPreTm[ETX]`
Read Variable Response:	`[STX]sRA TCExpPreTm 0[ETX]`
Write Variable:	`[STX]sWN TCExpPreTm 0[ETX]`
Write Variable Response:	`[STX]sWA TCExpPreTm[ETX]`

2.21.1.17. Variable: TrigPreExpansionTrack

The following section contains a detailed description of the variable TrigPreExpansionTrack.

Variable Overview

Variable Name	Description
TrigPreExpansionTrack	Object trigger expansion before if track controlled

Communication Name	TCExpPreTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	758
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..30000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCExpPreTrk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCExpPreTrk	String	11	Object trigger expansion before if track controlled

Read Variable Response:

```
sRA TCExpPreTrk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCExpPreTrk	String	11	Object trigger expansion before if track controlled
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TCExpPreTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCExpPreTrk	String	11	Object trigger expansion before if track controlled
Variable Data	data	UInt	2	

Write Variable Response:				
sWA TCExpPreTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCExpPreTrk	String	11	Object trigger expansion before if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCExpPreTrk[ETX]
Read Variable Response:	[STX]sRA TCExpPreTrk 0[ETX]
Write Variable:	[STX]sWN TCExpPreTrk 0[ETX]
Write Variable Response:	[STX]sWA TCExpPreTrk[ETX]

2.21.1.18. Variable: ObjTrigSource

The following section contains a detailed description of the variable ObjTrigSource.

Variable Overview

Variable Name	Description
ObjTrigSource	Defines the source of the object trigger

Communication Name	TCObjTrigSrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	759
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_CLUSTER_TRIGGER	
	1	TX_POLYGON	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCObjTrigSrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCObjTrigSrc	String	12	Defines the source of the object trigger

Read Variable Response:				
`sRA TCObjTrigSrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCObjTrigSrc	String	12	Defines the source of the object trigger
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TCObjTrigSrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCObjTrigSrc	String	12	Defines the source of the object trigger
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA TCObjTrigSrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCObjTrigSrc	String	12	Defines the source of the object trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCObjTrigSrc[ETX]`
Read Variable Response:	`[STX]sRA TCObjTrigSrc 0[ETX]`
Write Variable:	`[STX]sWN TCObjTrigSrc 0[ETX]`
Write Variable Response:	`[STX]sWA TCObjTrigSrc[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.19. Variable: MaxIndexValue

The following section contains a detailed description of the variable MaxIndexValue.

Variable Overview

Variable Name	Description
MaxIndexValue	Defines the max. value of the internal index

Communication Name	TCMaxIdxVal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	760
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	1..2147483647
Initialisation	99999999
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TCMaxIdxVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCMaxIdxVal	String	11	Defines the max. value of the internal index

Read Variable Response:

```
sRA TCMaxIdxVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCMaxIdxVal	String	11	Defines the max. value of the internal index
Variable Data	data	DInt	4	

Write Variable:

```
sWN TCMaxIdxVal <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCMaxIdxVal	String	11	Defines the max. value of the internal index
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA TCMaxIdxVal
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCMaxIdxVal	String	11	Defines the max. value of the internal index

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCMaxIdxVal[ETX]`
Read Variable Response:	`[STX]sRA TCMaxIdxVal 5F5E0FF[ETX]`
Write Variable:	`[STX]sWN TCMaxIdxVal 5F5E0FF[ETX]`
Write Variable Response:	`[STX]sWA TCMaxIdxVal[ETX]`

2.21.1.20. Variable: InvalidIndex

The following section contains a detailed description of the variable InvalidIndex.

Variable Overview

Variable Name	Description
InvalidIndex	Defines the invalid index for external index telegram

Communication Name	TCInvalidIdx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	761
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..2147483647
Initialisation	9999
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN TCInvalidIdx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCInvalidIdx	String	12	Defines the invalid index for external index telegram

Read Variable Response:				
`sRA TCInvalidIdx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCInvalidIdx	String	12	Defines the invalid index for external index telegram
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TCInvalidIdx <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCInvalidIdx	String	12	Defines the invalid index for external index telegram
Variable Data	data	DInt	4	

Write Variable Response:				
sWA TCInvalidIdx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCInvalidIdx	String	12	Defines the invalid index for external index telegram

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCInvalidIdx[ETX]
Read Variable Response:	[STX]sRA TCInvalidIdx 270F[ETX]
Write Variable:	[STX]sWN TCInvalidIdx 270F[ETX]
Write Variable Response:	[STX]sWA TCInvalidIdx[ETX]

2.21.1.21. Method: ReadingGateOn

The following section contains a detailed description of the method ReadingGateOn.

Method Overview

Method Name	Description
ReadingGateOn	starts a reading gate if parametrized

Communication Name	mTCgateon
Sopas Index	79
Invocation Access	Always

Return Values		
Success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCgateon				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCgateon	String	9	starts a reading gate if parametrized

Method Return Value:				
sAN mTCgateon <Success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCgateon	String	9	starts a reading gate if parametrized
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCgateon[ETX]
Method Return Value:	[STX]sAN mTCgateon 0[ETX]

2.21.1.22. Method: ReadingGateOff

The following section contains a detailed description of the method ReadingGateOff.

Method Overview

Method Name	Description
ReadingGateOff	stops a reading gate if parametrized

Communication Name	mTCgateoff
Sopas Index	80
Invocation Access	Always

Return Values		
Success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCgateoff				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCgateoff	String	10	stops a reading gate if parametrized

Method Return Value:				
sAN mTCgateoff <Success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCgateoff	String	10	stops a reading gate if parametrized
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCgateoff[ETX]
Method Return Value:	[STX]sAN mTCgateoff 0[ETX]

2.21.1.23. Method: ReadingGateOnDiag

The following section contains a detailed description of the method ReadingGateOnDiag.

Method Overview

Method Name	Description
ReadingGateOnDiag	starts a reading gate always

Communication Name	mTCgateondiag
Sopas Index	81
Invocation Access	Always

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCgateondiag				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCgateondiag	String	13	starts a reading gate always

Method Return Value:				
sAN mTCgateondiag <Success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCgateondiag	String	13	starts a reading gate always
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCgateondiag[ETX]
Method Return Value:	[STX]sAN mTCgateondiag 0[ETX]

2.21.1.24. Method: ReadingGateOffDiag

The following section contains a detailed description of the method ReadingGateOffDiag.

Method Overview

Method Name	Description
ReadingGateOffDiag	stops a reading gate always

Communication Name	mTCgateoffdiag
Sopas Index	82
Invocation Access	Always

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCgateoffdiag				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCgateoffdiag	String	14	stops a reading gate always

Method Return Value:				
sAN mTCgateoffdiag <Success>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCgateoffdiag	String	14	stops a reading gate always
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCgateoffdiag[ETX]
Method Return Value:	[STX]sAN mTCgateoffdiag 0[ETX]

2.21.1.25. Method: DoDiagReading

The following section contains a detailed description of the method DoDiagReading.

Method Overview

Method Name	Description
DoDiagReading	starts the diagnostic reading for the number of reading gates

Communication Name	mTCdodiagread
Sopas Index	83
Invocation Access	Always

Parameters		
NbrReadingGates		
	UDInt	
	Value Range	1..100000
	Initialisation	100
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Parameters	
Timeout	
UDInt	
Value Range	1..100000
Initialisation	10
Physical Unit	s
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mTCdodiagread <NbrReadingGates> <Timeout>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCdodiagread	String	13	starts the diagnostic reading for the number of reading gates
Parameter 1	NbrReadingGates	UDInt	4	
Parameter 2	Timeout	UDInt	4	

Method Return Value:

```
sAN mTCdodiagread
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCdodiagread	String	13	starts the diagnostic reading for the number of reading gates

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mTCdodiagread 64 A[ETX]`
Method Return Value:	`[STX]sAN mTCdodiagread[ETX]`

© SICK AG - Germany - All rights reserved

2.21.1.26. Method: StartDiagReading

The following section contains a detailed description of the method StartDiagReading.

Method Overview

Method Name	Description
StartDiagReading	starts the diagnostic reading for the number of reading gates and restartes immediately the diagnostic reading, until the EndDiagReading method is called

Communication Name	mTCstartdiagread
Sopas Index	84
Invocation Access	Always

Parameters	
NbrReadingGates	
UDInt	
Value Range	1..100000
Initialisation	100
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mTCstartdiagread <NbrReadingGates>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCstartdiagread	String	16	starts the diagnostic reading for the number of reading gates and restartes immediately the diagnostic reading, until the EndDiagReading method is called
Parameter 1	NbrReadingGates	UDInt	4	

Method Return Value:

```
sAN mTCstartdiagread
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCstartdiagread	String	16	starts the diagnostic reading for the number of reading gates and restartes immediately the diagnostic reading, until the EndDiagReading method is called

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mTCstartdiagread 64[ETX]`
Method Return Value:	`[STX]sAN mTCstartdiagread[ETX]`

2.21.1.27. Method: EndDiagReading

The following section contains a detailed description of the method EndDiagReading.

Method Overview

Method Name	Description
EndDiagReading	finishes the diagnostic reading

Communication Name	mTCenddiagread
Sopas Index	85
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

`sMN mTCenddiagread`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCenddiagread	String	14	finishes the diagnostic reading

Method Return Value:

`sAN mTCenddiagread`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCenddiagread	String	14	finishes the diagnostic reading

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mTCenddiagread[ETX]`
Method Return Value:	`[STX]sAN mTCenddiagread[ETX]`

© SICK AG - Germany - All rights reserved

2.22. Interface Block: GeneralCfgFileSystem2Base

2.22.1. Group: FileSystem2Base

2.22.1.1. Method: FileSystemAccess

The following section contains a detailed description of the method FileSystemAccess.

Method Overview

Method Name	Description
FileSystemAccess	EDP2 File system accessor

Communication Name	mFSAcc
Sopas Index	90
Invocation Access	Always

Parameters		
URL		
	FlexString	
	Length	0..286
	Initialisation	
Buffer		
	FlexString	
	Length	0..1022
	Initialisation	
BufferCRC		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Return Values		
URL		
	FlexString	
	Length	0..286
	Initialisation	
Buffer		
	FlexString	
	Length	0..1022
	Initialisation	
BufferCRC		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mFSAcc <URL> <Buffer> <BufferCRC>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFSAcc	String	6	EDP2 File system accessor
Parameter 1	URL	FlexString	286	
Parameter 2	Buffer	FlexString	1022	
Parameter 3	BufferCRC	UDInt	4	

Method Return Value:				
`sAN mFSAcc <URL> <Buffer> <BufferCRC>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFSAcc	String	6	EDP2 File system accessor
Return Value 1	URL	FlexString	286	
Return Value 2	Buffer	FlexString	1022	
Return Value 3	BufferCRC	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFSAcc 0 0 0[ETX]`
Method Return Value:	`[STX]sAN mFSAcc 0 0 0[ETX]`

© SICK AG - Germany - All rights reserved

2.23. Interface Block: GeneralCfgNetworkBase

2.23.1. Group: NetworkBase

2.23.1.1. Variable: NetDeviceID

The following section contains a detailed description of the variable NetDeviceID.

Variable Overview

Variable Name	Description
NetDeviceID	ID of the Device

Communication Name	NWDevID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	767
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..127
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN NWDevID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWDevID	String	7	ID of the Device

Read Variable Response:

```
sRA NWDevID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWDevID	String	7	ID of the Device
Variable Data	data	UInt	2	

Write Variable:

```
sWN NWDevID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWDevID	String	7	ID of the Device
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA NWDevID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWDevID	String	7	ID of the Device

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN NWDevID[ETX]
Read Variable Response:	[STX]sRA NWDevID 1[ETX]
Write Variable:	[STX]sWN NWDevID 1[ETX]
Write Variable Response:	[STX]sWA NWDevID[ETX]

2.23.1.2. Variable: NetMasterSlave

The following section contains a detailed description of the variable NetMasterSlave.

Variable Overview

Variable Name	Description
NetMasterSlave	Master/Slave Function

Communication Name	NWMstSlv
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	768
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_STAND_ALONE	
	1	TX_SLAVE	
	2	TX_MASTER	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN NWMstSlv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWMstSlv	String	8	Master/Slave Function

Read Variable Response:				
`sRA NWMstSlv <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWMstSlv	String	8	Master/Slave Function
Variable Data	data	Enum8	1	

Write Variable:				
`sWN NWMstSlv <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWMstSlv	String	8	Master/Slave Function
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA NWMstSlv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWMstSlv	String	8	Master/Slave Function

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWMstSlv[ETX]`
Read Variable Response:	`[STX]sRA NWMstSlv 0[ETX]`
Write Variable:	`[STX]sWN NWMstSlv 0[ETX]`
Write Variable Response:	`[STX]sWA NWMstSlv[ETX]`

© SICK AG - Germany - All rights reserved

2.23.1.3. Variable: NetworkAssignment

The following section contains a detailed description of the variable NetworkAssignment.

Variable Overview

Variable Name	Description
NetworkAssignment	Network on which Master/Slave function is assigned

Communication Name	NWNtwAsgn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	769
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_CAN_1	

Variable Telegram Syntax

Read Variable:				
`sRN NWNtwAsgn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWNtwAsgn	String	9	Network on which Master/Slave function is assigned

Read Variable Response:				
`sRA NWNtwAsgn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWNtwAsgn	String	9	Network on which Master/Slave function is assigned
Variable Data	data	Enum8	1	

Write Variable:				
`sWN NWNtwAsgn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWNtwAsgn	String	9	Network on which Master/Slave function is assigned
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA NWNtwAsgn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA NWNtwAsgn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	NWNtwAsgn	String	9	Network on which Master/Slave function is assigned

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN NWNtwAsgn[ETX]
Read Variable Response:	[STX]sRA NWNtwAsgn 0[ETX]
Write Variable:	[STX]sWN NWNtwAsgn 0[ETX]
Write Variable Response:	[STX]sWA NWNtwAsgn[ETX]

2.23.1.4. Variable: NetSlaveList

The following section contains a detailed description of the variable NetSlaveList.

Variable Overview

Variable Name	Description
NetSlaveList	Slave-List of Master/Slave functionality

Communication Name	NWslvlst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	770
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..180
Initialisation	2,3

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN NWslvlst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWslvlst	String	8	Slave-List of Master/Slave functionality

Read Variable Response:				
`sRA NWslvlst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWslvlst	String	8	Slave-List of Master/Slave functionality
Variable Data	data	FlexString	180	

Write Variable:				
`sWN NWslvlst <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWslvlst	String	8	Slave-List of Master/Slave functionality
Variable Data	data	FlexString	180	

Write Variable Response:				
`sWA NWslvlst`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWslvlst	String	8	Slave-List of Master/Slave functionality

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWslvlst[ETX]`
Read Variable Response:	`[STX]sRA NWslvlst 3 2,3[ETX]`
Write Variable:	`[STX]sWN NWslvlst 3 2,3[ETX]`
Write Variable Response:	`[STX]sWA NWslvlst[ETX]`

© SICK AG - Germany - All rights reserved

2.23.1.5. Variable: NetMultiplexerAssignment

The following section contains a detailed description of the variable NetMultiplexerAssignment.

Variable Overview

Variable Name	Description
NetMultiplexerAssignment	Network on which Multiplexer function is assigned

Communication Name	NWMuxAsgn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	771
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CAN_1	

Variable Telegram Syntax

Read Variable:				
`sRN NWMuxAsgn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWMuxAsgn	String	9	Network on which Multiplexer function is assigned

Read Variable Response:				
`sRA NWMuxAsgn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWMuxAsgn	String	9	Network on which Multiplexer function is assigned
Variable Data	data	Enum8	1	

Write Variable:				
`sWN NWMuxAsgn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWMuxAsgn	String	9	Network on which Multiplexer function is assigned
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA NWMuxAsgn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWMuxAsgn	String	9	Network on which Multiplexer function is assigned

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWMuxAsgn[ETX]`
Read Variable Response:	`[STX]sRA NWMuxAsgn 0[ETX]`
Write Variable:	`[STX]sWN NWMuxAsgn 0[ETX]`
Write Variable Response:	`[STX]sWA NWMuxAsgn[ETX]`

2.23.1.6. Variable: NetServerList

The following section contains a detailed description of the variable NetServerList.

Variable Overview

Variable Name	Description
NetServerList	Server-List of Multiplexer functionality

Communication Name	NWsrvlst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	772
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..180
Initialisation	2,3

Variable Telegram Syntax

Read Variable:

```
sRN NWsrvlst
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWsrvlst	String	8	Server-List of Multiplexer functionality

Read Variable Response:

```
sRA NWsrvlst <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWsrvlst	String	8	Server-List of Multiplexer functionality
Variable Data	data	FlexString	180	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN NWsrvlst <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWsrvlst	String	8	Server-List of Multiplexer functionality
Variable Data	data	FlexString	180	

Write Variable Response:				
sWA NWsrvlst				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWsrvlst	String	8	Server-List of Multiplexer functionality

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN NWsrvlst[ETX]
Read Variable Response:	[STX]sRA NWsrvlst 3 2,3[ETX]
Write Variable:	[STX]sWN NWsrvlst 3 2,3[ETX]
Write Variable Response:	[STX]sWA NWsrvlst[ETX]

2.23.1.7. Variable: NetMonAssignment1

The following section contains a detailed description of the variable NetMonAssignment1.

Variable Overview

Variable Name	Description
NetMonAssignment1	Network on which monitoring function is assigned

Communication Name	NWmonasgn1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	773
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CAN_1	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN NWmonasgn1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWmonasgn1	String	10	Network on which monitoring function is assigned

Read Variable Response:				
`sRA NWmonasgn1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWmonasgn1	String	10	Network on which monitoring function is assigned
Variable Data	data	Enum8	1	

Write Variable:				
`sWN NWmonasgn1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWmonasgn1	String	10	Network on which monitoring function is assigned
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA NWmonasgn1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWmonasgn1	String	10	Network on which monitoring function is assigned

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWmonasgn1[ETX]`
Read Variable Response:	`[STX]sRA NWmonasgn1 0[ETX]`
Write Variable:	`[STX]sWN NWmonasgn1 0[ETX]`
Write Variable Response:	`[STX]sWA NWmonasgn1[ETX]`

© SICK AG - Germany - All rights reserved

2.23.1.8. Variable: NetMonDevList1

The following section contains a detailed description of the variable NetMonDevList1.

Variable Overview

Variable Name	Description
NetMonDevList1	List of devices which are monitored

Communication Name	NWmondevlst1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	774
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..180
Initialisation	2,3

Variable Telegram Syntax

Read Variable:

```
sRN NWmondevlst1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWmondevlst1	String	12	List of devices which are monitored

Read Variable Response:

```
sRA NWmondevlst1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWmondevlst1	String	12	List of devices which are monitored
Variable Data	data	FlexString	180	

Write Variable:

```
sWN NWmondevlst1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWmondevlst1	String	12	List of devices which are monitored
Variable Data	data	FlexString	180	

Write Variable Response:

```
sWA NWmondevlst1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWmondevlst1	String	12	List of devices which are monitored

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWmondevlst1[ETX]`
Read Variable Response:	`[STX]sRA NWmondevlst1 3 2,3[ETX]`
Write Variable:	`[STX]sWN NWmondevlst1 3 2,3[ETX]`
Write Variable Response:	`[STX]sWA NWmondevlst1[ETX]`

2.23.1.9. Variable: NetMonAssignment2

The following section contains a detailed description of the variable NetMonAssignment2.

Variable Overview

Variable Name	Description
NetMonAssignment2	Network on which monitoring function is assigned

Communication Name	NWmonasgn2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	775
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CAN_1	

Variable Telegram Syntax

Read Variable:				
`sRN NWmonasgn2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWmonasgn2	String	10	Network on which monitoring function is assigned

Read Variable Response:				
`sRA NWmonasgn2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWmonasgn2	String	10	Network on which monitoring function is assigned
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN NWmonasgn2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWmonasgn2	String	10	Network on which monitoring function is assigned
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA NWmonasgn2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWmonasgn2	String	10	Network on which monitoring function is assigned

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN NWmonasgn2[ETX]
Read Variable Response:	[STX]sRA NWmonasgn2 0[ETX]
Write Variable:	[STX]sWN NWmonasgn2 0[ETX]
Write Variable Response:	[STX]sWA NWmonasgn2[ETX]

2.23.1.10. Variable: NetMonDevList2

The following section contains a detailed description of the variable NetMonDevList2.

Variable Overview

Variable Name	Description
NetMonDevList2	List of devices which are monitored

Communication Name	NWmondevlst2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	776
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..180
Initialisation	2,3

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN NWmondevlst2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWmondevlst2	String	12	List of devices which are monitored

Read Variable Response:				
`sRA NWmondevlst2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWmondevlst2	String	12	List of devices which are monitored
Variable Data	data	FlexString	180	

Write Variable:				
`sWN NWmondevlst2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWmondevlst2	String	12	List of devices which are monitored
Variable Data	data	FlexString	180	

Write Variable Response:				
`sWA NWmondevlst2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWmondevlst2	String	12	List of devices which are monitored

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWmondevlst2[ETX]`
Read Variable Response:	`[STX]sRA NWmondevlst2 3 2,3[ETX]`
Write Variable:	`[STX]sWN NWmondevlst2 3 2,3[ETX]`
Write Variable Response:	`[STX]sWA NWmondevlst2[ETX]`

© SICK AG - Germany - All rights reserved

2.23.1.11. Variable: NetMonTimeout

The following section contains a detailed description of the variable NetMonTimeout.

Variable Overview

Variable Name	Description
NetMonTimeout	Timeout for monitoring

Communication Name	NWmontimeout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	777
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..300
Initialisation	80
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN NWmontimeout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	NWmontimeout	String	12	Timeout for monitoring

Read Variable Response:

```
sRA NWmontimeout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	NWmontimeout	String	12	Timeout for monitoring
Variable Data	data	UInt	2	

Write Variable:

```
sWN NWmontimeout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	NWmontimeout	String	12	Timeout for monitoring
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA NWmontimeout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	NWmontimeout	String	12	Timeout for monitoring

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN NWmontimeout[ETX]`
Read Variable Response:	`[STX]sRA NWmontimeout 50[ETX]`
Write Variable:	`[STX]sWN NWmontimeout 50[ETX]`
Write Variable Response:	`[STX]sWA NWmontimeout[ETX]`

© SICK AG - Germany - All rights reserved

2.24. Interface Block: GeneralCfgRDT400Base

2.24.1. Group: RDT400ConfigBase

2.24.1.1. Variable: RDTCTCond1Enum

The following section contains a detailed description of the variable RDTCTCond1Enum.

Variable Overview

Variable Name	Description
RDTCTCond1Enum	Enum of Condition for codetype1 for RDT

Communication Name	RCBrdtctcond1enum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	778
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_WILDCARD	

Variable Telegram Syntax

Read Variable:				
`sRN RCBrdtctcond1enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCBrdtctcond1enum	String	17	Enum of Condition for codetype1 for RDT

Read Variable Response:				
`sRA RCBrdtctcond1enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCBrdtctcond1enum	String	17	Enum of Condition for codetype1 for RDT
Variable Data	data	Enum8	1	

Write Variable:				
`sWN RCBrdtctcond1enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCBrdtctcond1enum	String	17	Enum of Condition for codetype1 for RDT
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RCBrdtctcond1enum				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCBrdtctcond1enum	String	17	Enum of Condition for codetype1 for RDT

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RCBrdtctcond1enum[ETX]
Read Variable Response:	[STX]sRA RCBrdtctcond1enum 0[ETX]
Write Variable:	[STX]sWN RCBrdtctcond1enum 0[ETX]
Write Variable Response:	[STX]sWA RCBrdtctcond1enum[ETX]

2.24.1.2. Variable: RDTCTCond1Struct

The following section contains a detailed description of the variable RDTCTCond1Struct.

Variable Overview

Variable Name	Description
RDTCTCond1Struct	Struct of Condition for codetype1 for RDT

Communication Name	RCBrdtctcond1struct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	779
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RCBrdtctcond1struct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCBrdtctcond1struct	String	19	Struct of Condition for codetype1 for RDT

Read Variable Response:				
`sRA RCBrdtctcond1struct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCBrdtctcond1struct	String	19	Struct of Condition for codetype1 for RDT
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable:				
`sWN RCBrdtctcond1struct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCBrdtctcond1struct	String	19	Struct of Condition for codetype1 for RDT
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:				
`sWA RCBrdtctcond1struct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCBrdtctcond1struct	String	19	Struct of Condition for codetype1 for RDT

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCBrdtctcond1struct[ETX]`
Read Variable Response:	`[STX]sRA RCBrdtctcond1struct 0 0[ETX]`
Write Variable:	`[STX]sWN RCBrdtctcond1struct 0 0[ETX]`
Write Variable Response:	`[STX]sWA RCBrdtctcond1struct[ETX]`

© SICK AG - Germany - All rights reserved

2.24.1.3. Variable: RDTCTCond2Enum

The following section contains a detailed description of the variable RDTCTCond2Enum.

Variable Overview

Variable Name	Description
RDTCTCond2Enum	Enum of Condition for codetype2 for RDT

Communication Name	RCBrdtctcond2enum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	780
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_WILDCARD	

Variable Telegram Syntax

Read Variable:				
`sRN RCBrdtctcond2enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCBrdtctcond2enum	String	17	Enum of Condition for codetype2 for RDT

Read Variable Response:				
`sRA RCBrdtctcond2enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCBrdtctcond2enum	String	17	Enum of Condition for codetype2 for RDT
Variable Data	data	Enum8	1	

Write Variable:				
`sWN RCBrdtctcond2enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCBrdtctcond2enum	String	17	Enum of Condition for codetype2 for RDT
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA RCBrdtctcond2enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCBrdtctcond2enum	String	17	Enum of Condition for codetype2 for RDT

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCBrdtctcond2enum[ETX]`
Read Variable Response:	`[STX]sRA RCBrdtctcond2enum 0[ETX]`
Write Variable:	`[STX]sWN RCBrdtctcond2enum 0[ETX]`
Write Variable Response:	`[STX]sWA RCBrdtctcond2enum[ETX]`

2.24.1.4. Variable: RDTCTCond2Struct

The following section contains a detailed description of the variable RDTCTCond2Struct.

Variable Overview

Variable Name	Description
RDTCTCond2Struct	Struct of Condition for codetype2 for RDT

Communication Name	RCBrdtctcond2struct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	781
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN RCBrdtctcond2struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCBrdtctcond2struct	String	19	Struct of Condition for codetype2 for RDT

Read Variable Response:

```
sRA RCBrdtctcond2struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCBrdtctcond2struct	String	19	Struct of Condition for codetype2 for RDT
Variable Data	data	SETEditExtendibleEnum	19	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN RCBrdtctcond2struct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCBrdtctcond2struct	String	19	Struct of Condition for codetype2 for RDT
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:				
sWA RCBrdtctcond2struct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCBrdtctcond2struct	String	19	Struct of Condition for codetype2 for RDT

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RCBrdtctcond2struct[ETX]
Read Variable Response:	[STX]sRA RCBrdtctcond2struct 0 0[ETX]
Write Variable:	[STX]sWN RCBrdtctcond2struct 0 0[ETX]
Write Variable Response:	[STX]sWA RCBrdtctcond2struct[ETX]

2.24.1.5. Variable: RDTCTCond3Enum

The following section contains a detailed description of the variable RDTCTCond3Enum.

Variable Overview

Variable Name	Description
RDTCTCond3Enum	Enum of Condition for codetype3 for RDT

Communication Name	RCBrdtctcond3enum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	782
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_WILDCARD	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RCBrdtctcond3enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCBrdtctcond3enum	String	17	Enum of Condition for codetype3 for RDT

Read Variable Response:				
`sRA RCBrdtctcond3enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCBrdtctcond3enum	String	17	Enum of Condition for codetype3 for RDT
Variable Data	data	Enum8	1	

Write Variable:				
`sWN RCBrdtctcond3enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCBrdtctcond3enum	String	17	Enum of Condition for codetype3 for RDT
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA RCBrdtctcond3enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCBrdtctcond3enum	String	17	Enum of Condition for codetype3 for RDT

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCBrdtctcond3enum[ETX]`
Read Variable Response:	`[STX]sRA RCBrdtctcond3enum 0[ETX]`
Write Variable:	`[STX]sWN RCBrdtctcond3enum 0[ETX]`
Write Variable Response:	`[STX]sWA RCBrdtctcond3enum[ETX]`

© SICK AG - Germany - All rights reserved

2.24.1.6. Variable: RDTCTCond3Struct

The following section contains a detailed description of the variable RDTCTCond3Struct.

Variable Overview

Variable Name	Description
RDTCTCond3Struct	Struct of Condition for codetype3 for RDT

Communication Name	RCBrdtctcond3struct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	783
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN RCBrdtctcond3struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCBrdtctcond3struct	String	19	Struct of Condition for codetype3 for RDT

Read Variable Response:

```
sRA RCBrdtctcond3struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCBrdtctcond3struct	String	19	Struct of Condition for codetype3 for RDT
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable:

```
sWN RCBrdtctcond3struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCBrdtctcond3struct	String	19	Struct of Condition for codetype3 for RDT
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:

```
sWA RCBrdtctcond3struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCBrdtctcond3struct	String	19	Struct of Condition for codetype3 for RDT

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCBrdtctcond3struct[ETX]`
Read Variable Response:	`[STX]sRA RCBrdtctcond3struct 0 0[ETX]`
Write Variable:	`[STX]sWN RCBrdtctcond3struct 0 0[ETX]`
Write Variable Response:	`[STX]sWA RCBrdtctcond3struct[ETX]`

2.24.1.7. Variable: RDTSendTraces

The following section contains a detailed description of the variable RDTSendTraces.

Variable Overview

Variable Name	Description
RDTSendTraces	Activates the traces to RDT interface

Communication Name	OFrdtsendtraces
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	784
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OFrdtsendtraces
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFrdtsendtraces	String	15	Activates the traces to RDT interface

Read Variable Response:

```
sRA OFrdtsendtraces <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFrdtsendtraces	String	15	Activates the traces to RDT interface
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN OFrdtsendtraces <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFrdtsendtraces	String	15	Activates the traces to RDT interface
Variable Data	data	Bool	1	

Write Variable Response:				
sWA OFrdtsendtraces				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFrdtsendtraces	String	15	Activates the traces to RDT interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFrdtsendtraces[ETX]
Read Variable Response:	[STX]sRA OFrdtsendtraces 0[ETX]
Write Variable:	[STX]sWN OFrdtsendtraces 0[ETX]
Write Variable Response:	[STX]sWA OFrdtsendtraces[ETX]

2.24.1.8. Variable: RDTSendCommTraces

The following section contains a detailed description of the variable RDTSendCommTraces.

Variable Overview

Variable Name	Description
RDTSendCommTraces	Activates the communication traces to RDT interface

Communication Name	OFrdtsendcommtraces
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	785
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OFrdtsendcommtraces`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFrdtsendcommtraces	String	19	Activates the communication traces to RDT interface

Read Variable Response:				
`sRA OFrdtsendcommtraces <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFrdtsendcommtraces	String	19	Activates the communication traces to RDT interface
Variable Data	data	Bool	1	

Write Variable:				
`sWN OFrdtsendcommtraces <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFrdtsendcommtraces	String	19	Activates the communication traces to RDT interface
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OFrdtsendcommtraces`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFrdtsendcommtraces	String	19	Activates the communication traces to RDT interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFrdtsendcommtraces[ETX]`
Read Variable Response:	`[STX]sRA OFrdtsendcommtraces 0[ETX]`
Write Variable:	`[STX]sWN OFrdtsendcommtraces 0[ETX]`
Write Variable Response:	`[STX]sWA OFrdtsendcommtraces[ETX]`

© SICK AG - Germany - All rights reserved

2.24.1.9. Variable: RDTEnableErrors

The following section contains a detailed description of the variable RDTEnableErrors.

Variable Overview

Variable Name	Description
RDTEnableErrors	Activates the error numbers in the telegram of RDT interface

Communication Name	OFrdtenaerrors
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	786
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN OFrdtenaerrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFrdtenaerrors	String	14	Activates the error numbers in the telegram of RDT interface

Read Variable Response:

```
sRA OFrdtenaerrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFrdtenaerrors	String	14	Activates the error numbers in the telegram of RDT interface
Variable Data	data	Bool	1	

Write Variable:

```
sWN OFrdtenaerrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFrdtenaerrors	String	14	Activates the error numbers in the telegram of RDT interface
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OFrdtenaerrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OFrdtenaerrors				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OFrdtenaerrors	String	14	Activates the error numbers in the telegram of RDT interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFrdtenaerrors[ETX]
Read Variable Response:	[STX]sRA OFrdtenaerrors 1[ETX]
Write Variable:	[STX]sWN OFrdtenaerrors 1[ETX]
Write Variable Response:	[STX]sWA OFrdtenaerrors[ETX]

2.24.1.10. Variable: RDTVMSSendTraces

The following section contains a detailed description of the variable RDTVMSSendTraces.

Variable Overview

Variable Name	Description
RDTVMSSendTraces	Activates the traces to RDT VMS interface

Communication Name	OFrdtvmssendtraces
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	787
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OFrdtvmssendtraces`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFrdtvmssendtraces	String	18	Activates the traces to RDT VMS interface

Read Variable Response:				
`sRA OFrdtvmssendtraces <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFrdtvmssendtraces	String	18	Activates the traces to RDT VMS interface
Variable Data	data	Bool	1	

Write Variable:				
`sWN OFrdtvmssendtraces <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFrdtvmssendtraces	String	18	Activates the traces to RDT VMS interface
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OFrdtvmssendtraces`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFrdtvmssendtraces	String	18	Activates the traces to RDT VMS interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFrdtvmssendtraces[ETX]`
Read Variable Response:	`[STX]sRA OFrdtvmssendtraces 0[ETX]`
Write Variable:	`[STX]sWN OFrdtvmssendtraces 0[ETX]`
Write Variable Response:	`[STX]sWA OFrdtvmssendtraces[ETX]`

© SICK AG - Germany - All rights reserved

2.24.1.11. Variable: RDTVMSSendCommTraces

The following section contains a detailed description of the variable RDTVMSSendCommTraces.

Variable Overview

Variable Name	Description
RDTVMSSendCommTraces	Activates the communication traces to RDT VMS interface

Communication Name	OFrdtvmssendcommtraces
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	788
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN OFrdtvmssendcommtraces
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFrdtvmssendcommtraces	String	22	Activates the communication traces to RDT VMS interface

Read Variable Response:

```
sRA OFrdtvmssendcommtraces <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFrdtvmssendcommtraces	String	22	Activates the communication traces to RDT VMS interface
Variable Data	data	Bool	1	

Write Variable:

```
sWN OFrdtvmssendcommtraces <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFrdtvmssendcommtraces	String	22	Activates the communication traces to RDT VMS interface
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA OFrdtvmssendcommtraces
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OFrdtvmssendcommtraces				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	OFrdtvmssendcommtraces	String	22	Activates the communication traces to RDT VMS interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OFrdtvmssendcommtraces[ETX]
Read Variable Response:	[STX]sRA OFrdtvmssendcommtraces 0[ETX]
Write Variable:	[STX]sWN OFrdtvmssendcommtraces 0[ETX]
Write Variable Response:	[STX]sWA OFrdtvmssendcommtraces[ETX]

2.24.1.12. Variable: RDTVMSEnableErrors

The following section contains a detailed description of the variable RDTVMSEnableErrors.

Variable Overview

Variable Name	Description
RDTVMSEnableErrors	Activates the error numbers in the telegram of RDT VMS interface

Communication Name	OFrdtvmsenaerrors
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	789
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OFrdtvmsenaerrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OFrdtvmsenaerrors	String	17	Activates the error numbers in the telegram of RDT VMS interface

Read Variable Response:				
`sRA OFrdtvmsenaerrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OFrdtvmsenaerrors	String	17	Activates the error numbers in the telegram of RDT VMS interface
Variable Data	data	Bool	1	

Write Variable:				
`sWN OFrdtvmsenaerrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OFrdtvmsenaerrors	String	17	Activates the error numbers in the telegram of RDT VMS interface
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA OFrdtvmsenaerrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OFrdtvmsenaerrors	String	17	Activates the error numbers in the telegram of RDT VMS interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OFrdtvmsenaerrors[ETX]`
Read Variable Response:	`[STX]sRA OFrdtvmsenaerrors 1[ETX]`
Write Variable:	`[STX]sWN OFrdtvmsenaerrors 1[ETX]`
Write Variable Response:	`[STX]sWA OFrdtvmsenaerrors[ETX]`

© SICK AG - Germany - All rights reserved

2.25. Interface Block: GeneralCfgCDFpublic

2.25.1. Group: CDF_Config

2.25.1.1. Variable: CDF_FramingHeaderInputSelect_1

The following section contains a detailed description of the variable CDF_FramingHeaderInputSelect_1.

Variable Overview

Variable Name	Description
CDF_FramingHeaderInputSelect_1	Status selects wheather CDF_FramingHeaderIn (Bit0)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!

Communication Name	CdfPlcFhInSel_1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	790
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		SEL_PIS1_FOR_FH1	
	Value	Name	Description
	0	SEL_PIS1_FOR_FH1	
	1	SEL_PIS2_FOR_FH1	
	2	SEL_PLCLIS1_FOR_FH1	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPlcFhInSel_1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPlcFhInSel_1	String	15	Status selects wheather CDF_FramingHeaderIn (Bit0)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!

Read Variable Response:

```
sRA CdfPlcFhInSel_1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPlcFhInSel_1	String	15	Status selects wheather CDF_FramingHeaderIn (Bit0)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CdfPlcFhInSel_1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CdfPlcFhInSel_1 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPlcFhInSel_1	String	15	Status selects wheather CDF_FramingHeaderIn (Bit0)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA CdfPlcFhInSel_1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPlcFhInSel_1	String	15	Status selects wheather CDF_FramingHeaderIn (Bit0)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPlcFhInSel_1[ETX]
Read Variable Response:	[STX]sRA CdfPlcFhInSel_1 0[ETX]
Write Variable:	[STX]sWN CdfPlcFhInSel_1 0[ETX]
Write Variable Response:	[STX]sWA CdfPlcFhInSel_1[ETX]

2.25.1.2. Variable: CDF_FramingHeaderInputSelect_2

The following section contains a detailed description of the variable CDF_FramingHeaderInputSelect_2.

Variable Overview

Variable Name	Description
CDF_FramingHeaderInputSelect_2	Status selects wheather CDF_FramingHeaderIn (Bit1)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!

Communication Name	CdfPlcFhInSel_2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	791
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		SEL_PIS2_FOR_FH2	
	Value	Name	Description
	0	SEL_PIS1_FOR_FH2	
	1	SEL_PIS2_FOR_FH2	
	2	SEL_PLCLIS2_FOR_FH2	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPlcFhInSel_2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPlcFhInSel_2	String	15	Status selects wheather CDF_FramingHeaderIn (Bit1)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!

Read Variable Response:				
`sRA CdfPlcFhInSel_2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPlcFhInSel_2	String	15	Status selects wheather CDF_FramingHeaderIn (Bit1)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CdfPlcFhInSel_2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPlcFhInSel_2	String	15	Status selects wheather CDF_FramingHeaderIn (Bit1)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CdfPlcFhInSel_2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPlcFhInSel_2	String	15	Status selects wheather CDF_FramingHeaderIn (Bit1)is copied from CDF_PhysicalInputsState or from CDF_PlcLogicalInputState_FH Note: only CMF400 mode!

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPlcFhInSel_2[ETX]`
Read Variable Response:	`[STX]sRA CdfPlcFhInSel_2 1[ETX]`
Write Variable:	`[STX]sWN CdfPlcFhInSel_2 1[ETX]`
Write Variable Response:	`[STX]sWA CdfPlcFhInSel_2[ETX]`

© SICK AG - Germany - All rights reserved

2.25.1.3. Variable: CDF_PhysOutputSelect_1

The following section contains a detailed description of the variable CDF_PhysOutputSelect_1.

Variable Overview

Variable Name	Description
CDF_PhysOutputSelect_1	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!

Communication Name	CdfPhysOutSel_1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	792
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		SEL_FHOUT1_FOR_POS1	
	Value	Name	Description
	0	SEL_PLCOUT1_FOR_POS1	
	1	SEL_PLCOUT2_FOR_POS1	
	2	SEL_FHOUT1_FOR_POS1	
	3	SEL_FHOUT2_FOR_POS1	
	4	SEL_SENSLOS1_FOR_POS1	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPhysOutSel_1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPhysOutSel_1	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!

Read Variable Response:

```
sRA CdfPhysOutSel_1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPhysOutSel_1	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CdfPhysOutSel_1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN CdfPhysOutSel_1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfPhysOutSel_1	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CdfPhysOutSel_1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPhysOutSel_1	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPhysOutSel_1[ETX]`
Read Variable Response:	`[STX]sRA CdfPhysOutSel_1 2[ETX]`
Write Variable:	`[STX]sWN CdfPhysOutSel_1 2[ETX]`
Write Variable Response:	`[STX]sWA CdfPhysOutSel_1[ETX]`

2.25.1.4. Variable: CDF_PhysOutputSelect_2

The following section contains a detailed description of the variable CDF_PhysOutputSelect_2.

Variable Overview

Variable Name	Description
CDF_PhysOutputSelect_2	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!

Communication Name	CdfPhysOutSel_2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	793
Read-Access	Always
Write-Access	Always

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		SEL_FHOUT2_FOR_POS2	
	Value	Name	Description
	0	SEL_PLCOUT1_FOR_POS2	
	1	SEL_PLCOUT2_FOR_POS2	
	2	SEL_FHOUT1_FOR_POS2	
	3	SEL_FHOUT2_FOR_POS2	
	4	SEL_SENSLOS2_FOR_POS2	

Variable Telegram Syntax

Read Variable:

```
sRN CdfPhysOutSel_2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPhysOutSel_2	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!

Read Variable Response:

```
sRA CdfPhysOutSel_2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPhysOutSel_2	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CdfPhysOutSel_2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPhysOutSel_2	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA CdfPhysOutSel_2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPhysOutSel_2	String	15	Status selects wheather CDF_PhysicalOutputsState (Bit0) is copied from CDF_SensorPhysicalOutputState or from CDF_PlcOutputState_FH Note: only CMF400 mode!

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPhysOutSel_2[ETX]`
Read Variable Response:	`[STX]sRA CdfPhysOutSel_2 3[ETX]`
Write Variable:	`[STX]sWN CdfPhysOutSel_2 3[ETX]`
Write Variable Response:	`[STX]sWA CdfPhysOutSel_2[ETX]`

2.25.1.5. Variable: CDF_PhysInDebounceTime_1

The following section contains a detailed description of the variable CDF_PhysInDebounceTime_1.

Variable Overview

Variable Name	Description
CDF_PhysInDebounceTime_1	Debouncing time for Input 1 of CDF600.

Communication Name	CdfPhysInDeb_1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	794
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..10000
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN CdfPhysInDeb_1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPhysInDeb_1	String	14	Debouncing time for Input 1 of CDF600.

Read Variable Response:				
`sRA CdfPhysInDeb_1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPhysInDeb_1	String	14	Debouncing time for Input 1 of CDF600.
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CdfPhysInDeb_1 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPhysInDeb_1	String	14	Debouncing time for Input 1 of CDF600.
Variable Data	data	UInt	2	

Write Variable Response:				
sWA CdfPhysInDeb_1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPhysInDeb_1	String	14	Debouncing time for Input 1 of CDF600.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfPhysInDeb_1[ETX]
Read Variable Response:	[STX]sRA CdfPhysInDeb_1 A[ETX]
Write Variable:	[STX]sWN CdfPhysInDeb_1 A[ETX]
Write Variable Response:	[STX]sWA CdfPhysInDeb_1[ETX]

2.25.1.6. Variable: CDF_PhysInDebounceTime_2

The following section contains a detailed description of the variable CDF_PhysInDebounceTime_2.

Variable Overview

Variable Name	Description
CDF_PhysInDebounceTime_2	Debouncing time for Input 2 of CDF600

Communication Name	CdfPhysInDeb_2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	795
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..10000
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPhysInDeb_2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPhysInDeb_2	String	14	Debouncing time for Input 2 of CDF600

Read Variable Response:				
`sRA CdfPhysInDeb_2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPhysInDeb_2	String	14	Debouncing time for Input 2 of CDF600
Variable Data	data	UInt	2	

Write Variable:				
`sWN CdfPhysInDeb_2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPhysInDeb_2	String	14	Debouncing time for Input 2 of CDF600
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CdfPhysInDeb_2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPhysInDeb_2	String	14	Debouncing time for Input 2 of CDF600

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPhysInDeb_2[ETX]`
Read Variable Response:	`[STX]sRA CdfPhysInDeb_2 A[ETX]`
Write Variable:	`[STX]sWN CdfPhysInDeb_2 A[ETX]`
Write Variable Response:	`[STX]sWA CdfPhysInDeb_2[ETX]`

© SICK AG - Germany - All rights reserved

2.25.2. Group: CDF_IoPublic

2.25.2.1. Variable: CDF_PlcLogicalInputState_FH

The following section contains a detailed description of the variable CDF_PlcLogicalInputState_FH.

Variable Overview

Variable Name	Description
CDF_PlcLogicalInputState_FH	Logical input state of PLC, which may be sent within fieldbus framing header. From sensors point of view, this is an output function: A sensor can map up to two of its output functions to the framing header input bits.

Communication Name	CdfLis
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	810
Read-Access	Always
Write-Access	Always

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfLis
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfLis	String	6	Logical input state of PLC, which may be sent within fieldbus framing header. From sensors point of view, this is an output function: A sensor can map up to two of its output functions to the framing header input bits.

Read Variable Response:

```
sRA CdfLis <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfLis	String	6	Logical input state of PLC, which may be sent within fieldbus framing header. From sensors point of view, this is an output function: A sensor can map up to two of its output functions to the framing header input bits.
Variable Data	data	USInt	1	

Write Variable:

```
sWN CdfLis <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN CdfLis <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfLis	String	6	Logical input state of PLC, which may be sent within fieldbus framing header. From sensors point of view, this is an output function: A sensor can map up to two of its output functions to the framing header input bits.
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA CdfLis`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfLis	String	6	Logical input state of PLC, which may be sent within fieldbus framing header. From sensors point of view, this is an output function: A sensor can map up to two of its output functions to the framing header input bits.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfLis[ETX]`
Read Variable Response:	`[STX]sRA CdfLis 0[ETX]`
Write Variable:	`[STX]sWN CdfLis 0[ETX]`
Write Variable Response:	`[STX]sWA CdfLis[ETX]`

2.25.2.2. Variable: CDF_PlcLogicalInputState_Map

The following section contains a detailed description of the variable CDF_PlcLogicalInputState_Map.

Variable Overview

Variable Name	Description
CDF_PlcLogicalInputState_Map	Logical input state of PLC, which may be sent as mapped Fieldbus data from CDF to PLC. (16 bit)

Communication Name	CdfPlcLisMap
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	812
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfPlcLisMap`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfPlcLisMap	String	12	Logical input state of PLC, which may be sent as mapped Fieldbus data from CDF to PLC. (16 bit)

Read Variable Response:				
`sRA CdfPlcLisMap <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfPlcLisMap	String	12	Logical input state of PLC, which may be sent as mapped Fieldbus data from CDF to PLC. (16 bit)
Variable Data	data	UInt	2	

Write Variable:				
`sWN CdfPlcLisMap <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfPlcLisMap	String	12	Logical input state of PLC, which may be sent as mapped Fieldbus data from CDF to PLC. (16 bit)
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CdfPlcLisMap`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfPlcLisMap	String	12	Logical input state of PLC, which may be sent as mapped Fieldbus data from CDF to PLC. (16 bit)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfPlcLisMap[ETX]`
Read Variable Response:	`[STX]sRA CdfPlcLisMap 0[ETX]`
Write Variable:	`[STX]sWN CdfPlcLisMap 0[ETX]`
Write Variable Response:	`[STX]sWA CdfPlcLisMap[ETX]`

© SICK AG - Germany - All rights reserved

2.25.2.3. Variable: CDF_SensorPhysicalOutputState

The following section contains a detailed description of the variable CDF_SensorPhysicalOutputState.

Variable Overview

Variable Name	Description
CDF_SensorPhysicalOutputState	Output state of sensor, which may be put to physical outpus, depending on selectors status.

Communication Name	CdfSensPos
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	814
Read-Access	Always
Write-Access	Always

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CdfSensPos
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfSensPos	String	10	Output state of sensor, which may be put to physical outpus, depending on selectors status.

Read Variable Response:

```
sRA CdfSensPos <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfSensPos	String	10	Output state of sensor, which may be put to physical outpus, depending on selectors status.
Variable Data	data	USInt	1	

Write Variable:

```
sWN CdfSensPos <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfSensPos	String	10	Output state of sensor, which may be put to physical outpus, depending on selectors status.
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA CdfSensPos
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfSensPos				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CdfSensPos	String	10	Output state of sensor, which may be put to physical outpus, depending on selectors status.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfSensPos[ETX]
Read Variable Response:	[STX]sRA CdfSensPos 0[ETX]
Write Variable:	[STX]sWN CdfSensPos 0[ETX]
Write Variable Response:	[STX]sWA CdfSensPos[ETX]

© SICK AG - Germany - All rights reserved

2.25.3. Group: CDF_ProfinetPublic

2.25.3.1. Variable: CdfSyncStationNameToLocationName

The following section contains a detailed description of the variable CdfSyncStationNameToLocationName.

Variable Overview

Variable Name	Description
CdfSyncStationNameToLocationName	For CDF600-2 CDF manages the PN StationName. PN StationName can be sync to LocationName for SopasET visability

Communication Name	CdfStatNameSync
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	817
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN CdfStatNameSync
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfStatNameSync	String	15	For CDF600-2 CDF manages the PN StationName. PN StationName can be sync to LocationName for SopasET visability

Read Variable Response:

```
sRA CdfStatNameSync <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfStatNameSync	String	15	For CDF600-2 CDF manages the PN StationName. PN StationName can be sync to LocationName for SopasET visability
Variable Data	data	Bool	1	

Write Variable:

```
sWN CdfStatNameSync <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfStatNameSync	String	15	For CDF600-2 CDF manages the PN StationName. PN StationName can be sync to LocationName for SopasET visability
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfStatNameSync				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfStatNameSync	String	15	For CDF600-2 CDF manages the PN StationName. PN StationName can be sync to LocationName for SopasET visability

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfStatNameSync[ETX]
Read Variable Response:	[STX]sRA CdfStatNameSync 1[ETX]
Write Variable:	[STX]sWN CdfStatNameSync 1[ETX]
Write Variable Response:	[STX]sWA CdfStatNameSync[ETX]

2.25.3.2. Variable: CdfCm_CDF600HS

The following section contains a detailed description of the variable CdfCm_CDF600HS.

Variable Overview

Variable Name	Description
CdfCm_CDF600HS	For CDF600-2 Profinet we use only CDF600 HS/NH Mode (no longer selection via GSD modules) . With postwrite we contol CdfProfiCmMode (see above) !

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	818
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_MODE_CDF600_HANDSHAKE	
	Value	Name	Description
	3	TX_MODE_CDF600_HANDSHAKE	
	4	TX_MODE_CDF600_NO_HANDSHAKE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfCm_CDF600HS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfCm_CDF600HS	String	14	For CDF600-2 Profinet we use only CDF600 HS/NH Mode (no longer selection via GSD modules) . With postwrite we contol CdfProfiCmMode (see above) !

Read Variable Response:				
`sRA CdfCm_CDF600HS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfCm_CDF600HS	String	14	For CDF600-2 Profinet we use only CDF600 HS/NH Mode (no longer selection via GSD modules) . With postwrite we contol CdfProfiCmMode (see above) !
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CdfCm_CDF600HS <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfCm_CDF600HS	String	14	For CDF600-2 Profinet we use only CDF600 HS/NH Mode (no longer selection via GSD modules) . With postwrite we contol CdfProfiCmMode (see above) !
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CdfCm_CDF600HS`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfCm_CDF600HS	String	14	For CDF600-2 Profinet we use only CDF600 HS/NH Mode (no longer selection via GSD modules) . With postwrite we contol CdfProfiCmMode (see above) !

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfCm_CDF600HS[ETX]`
Read Variable Response:	`[STX]sRA CdfCm_CDF600HS 3[ETX]`
Write Variable:	`[STX]sWN CdfCm_CDF600HS 3[ETX]`
Write Variable Response:	`[STX]sWA CdfCm_CDF600HS[ETX]`

© SICK AG - Germany - All rights reserved

2.25.3.3. Method: CdfUpDatePnConfig

The following section contains a detailed description of the method CdfUpDatePnConfig.

Method Overview

Method Name	Description
CdfUpDatePnConfig	Writes Sopas variable to let CDF know about up-date requirement

Communication Name	mSCCdfUpDatePnConfig
Sopas Index	91
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mSCCdfUpDatePnConfig`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCCdfUpDatePnConfig	String	20	Writes Sopas variable to let CDF know about up-date requirement

Method Return Value:				
`sAN mSCCdfUpDatePnConfig`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCCdfUpDatePnConfig	String	20	Writes Sopas variable to let CDF know about up-date requirement

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCCdfUpDatePnConfig[ETX]`
Method Return Value:	`[STX]sAN mSCCdfUpDatePnConfig[ETX]`

© SICK AG - Germany - All rights reserved

2.26. Interface Block: System

2.26.1. Group: Time

2.26.1.1. Variable: TimeSource

The following section contains a detailed description of the variable TimeSource.

Variable Overview

Variable Name
TimeSource

Communication Name	TISrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	819
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_UserInput	
	Value	Name	Description
	0	TX_TimeServer	
	1	TX_UserInput	

Variable Telegram Syntax

Read Variable:				
`sRN TISrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TISrc	String	5	

Read Variable Response:				
`sRA TISrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TISrc	String	5	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TISrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TISrc	String	5	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TISrc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TISrc	String	5	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TISrc[ETX]
Read Variable Response:	[STX]sRA TISrc 1[ETX]
Write Variable:	[STX]sWN TISrc 1[ETX]
Write Variable Response:	[STX]sWA TISrc[ETX]

2.26.1.2. Variable: TimeServerIPAddress

The following section contains a detailed description of the variable TimeServerIPAddress.

Variable Overview

Variable Name	Description
TimeServerIPAddress	IP-Adress of timeserver

Communication Name	TIServerAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	820
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TIServerAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TIServerAddr	String	12	IP-Adress of timeserver

Read Variable Response:				
`sRA TIServerAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TIServerAddr	String	12	IP-Adress of timeserver
Variable Data	data	Array	4	

Write Variable:				
`sWN TIServerAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TIServerAddr	String	12	IP-Adress of timeserver
Variable Data	data	Array	4	

Write Variable Response:				
`sWA TIServerAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TIServerAddr	String	12	IP-Adress of timeserver

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TIServerAddr[ETX]`
Read Variable Response:	`[STX]sRA TIServerAddr 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN TIServerAddr 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA TIServerAddr[ETX]`

© SICK AG - Germany - All rights reserved

2.26.1.3. Variable: TimeServerIPPort

The following section contains a detailed description of the variable TimeServerIPPort.

Variable Overview

Variable Name	Description
TimeServerIPPort	IP port of timeserver

Communication Name	TIServerPort
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	821
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	123
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN TIServerPort
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TIServerPort	String	12	IP port of timeserver

Read Variable Response:

```
sRA TIServerPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TIServerPort	String	12	IP port of timeserver
Variable Data	data	UInt	2	

Write Variable:

```
sWN TIServerPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TIServerPort	String	12	IP port of timeserver
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA TIServerPort
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TIServerPort	String	12	IP port of timeserver

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TIServerPort[ETX]`
Read Variable Response:	`[STX]sRA TIServerPort 7B[ETX]`
Write Variable:	`[STX]sWN TIServerPort 7B[ETX]`
Write Variable Response:	`[STX]sWA TIServerPort[ETX]`

2.26.1.4. Variable: TimeServerIface

The following section contains a detailed description of the variable TimeServerIface.

Variable Overview

Variable Name	Description
TimeServerIface	Ethernet interface for connection to timeserver

Communication Name	TIServerIface
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	822
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ETHERNET0	
	1	TX_ETHERNET1	

Variable Telegram Syntax

Read Variable:				
`sRN TIServerIface`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TIServerIface	String	13	Ethernet interface for connection to timeserver

Read Variable Response:				
`sRA TIServerIface <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TIServerIface	String	13	Ethernet interface for connection to timeserver
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TIServerIface <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TIServerIface	String	13	Ethernet interface for connection to timeserver
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA TIServerIface				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TIServerIface	String	13	Ethernet interface for connection to timeserver

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TIServerIface[ETX]
Read Variable Response:	[STX]sRA TIServerIface 0[ETX]
Write Variable:	[STX]sWN TIServerIface 0[ETX]
Write Variable Response:	[STX]sWA TIServerIface[ETX]

2.26.1.5. Variable: TimeZoneOffset

The following section contains a detailed description of the variable TimeZoneOffset.

Variable Overview

Variable Name	Description
TimeZoneOffset	Offset, in minutes, to the UTC time from the time server

Communication Name	TITimeZoneOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	824
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Int	
Value Range	-720..720
Initialisation	0
Physical Unit	min
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TITimeZoneOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TITimeZoneOffset	String	16	Offset, in minutes, to the UTC time from the time server

Read Variable Response:				
`sRA TITimeZoneOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TITimeZoneOffset	String	16	Offset, in minutes, to the UTC time from the time server
Variable Data	data	Int	2	

Write Variable:				
`sWN TITimeZoneOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TITimeZoneOffset	String	16	Offset, in minutes, to the UTC time from the time server
Variable Data	data	Int	2	

Write Variable Response:				
`sWA TITimeZoneOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TITimeZoneOffset	String	16	Offset, in minutes, to the UTC time from the time server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TITimeZoneOffset[ETX]`
Read Variable Response:	`[STX]sRA TITimeZoneOffset 0[ETX]`
Write Variable:	`[STX]sWN TITimeZoneOffset 0[ETX]`
Write Variable Response:	`[STX]sWA TITimeZoneOffset[ETX]`

© SICK AG - Germany - All rights reserved

2.26.1.6. Method: GetTime

The following section contains a detailed description of the method GetTime.

Method Overview

Method Name	Description
GetTime	Returns date and time of the device

Sopas Index	92
Invocation Access	Always

Return Values		
Date		
	String	
	Length	10
	Initialisation	1970-01-01
Time		
	String	
	Length	8
	Initialisation	00:00:00

Method Telegram Syntax

Method Invocation:				
`sMN GetTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetTime	String	7	Returns date and time of the device

Method Return Value:				
`sAN GetTime <Date> <Time>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetTime	String	7	Returns date and time of the device
Return Value 1	Date	String	10	
Return Value 2	Time	String	8	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetTime[ETX]`
Method Return Value:	`[STX]sAN GetTime 1970-01-01 00:00:00[ETX]`

© SICK AG - Germany - All rights reserved

2.26.1.7. Method: SetTime

The following section contains a detailed description of the method SetTime.

Method Overview

Method Name	Description
SetTime	Sets date and time of the device. The data will be lost when the device is powered off.

Sopas Index	93
Invocation Access	AuthorizedClient, Service

Parameters		
Date		
	String	
	Length	10
	Initialisation	2011-01-01
Time		
	String	
	Length	8
	Initialisation	00:00:00

Method Telegram Syntax

Method Invocation:

```
sMN SetTime <Date> <Time>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	SetTime	String	7	Sets date and time of the device. The data will be lost when the device is powered off.
Parameter 1	Date	String	10	
Parameter 2	Time	String	8	

Method Return Value:

```
sAN SetTime
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	SetTime	String	7	Sets date and time of the device. The data will be lost when the device is powered off.

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN SetTime 2011-01-01 00:00:00[ETX]`
Method Return Value:	`[STX]sAN SetTime[ETX]`

© SICK AG - Germany - All rights reserved

2.26.1.8. Method: ConnectTimeServer

The following section contains a detailed description of the method ConnectTimeServer.

Method Overview

Method Name	Description
ConnectTimeServer	Invokes a connection attempt to the time server

Communication Name	mTIConnectSrv
Sopas Index	94
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mTIConnectSrv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTIConnectSrv	String	13	Invokes a connection attempt to the time server

Method Return Value:				
`sAN mTIConnectSrv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTIConnectSrv	String	13	Invokes a connection attempt to the time server

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mTIConnectSrv[ETX]`
Method Return Value:	`[STX]sAN mTIConnectSrv[ETX]`

© SICK AG - Germany - All rights reserved

2.26.2. Group: GUI

2.26.2.1. Variable: SYUIMode

The following section contains a detailed description of the variable SYUIMode.

Variable Overview

Variable Name	Description
SYUIMode	Parameter stores in which mode of the user interface the parameter file has been edited

Communication Name	SYUImode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	825
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	SINGLE_DEVICE_UI	
	1	STANDARD_UI	

Variable Telegram Syntax

Read Variable:

```
sRN SYUImode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SYUImode	String	8	Parameter stores in which mode of the user interface the parameter file has been edited

Read Variable Response:

```
sRA SYUImode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SYUImode	String	8	Parameter stores in which mode of the user interface the parameter file has been edited
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SYUImode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SYUImode	String	8	Parameter stores in which mode of the user interface the parameter file has been edited
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SYUImode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SYUImode	String	8	Parameter stores in which mode of the user interface the parameter file has been edited

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SYUImode[ETX]
Read Variable Response:	[STX]sRA SYUImode 0[ETX]
Write Variable:	[STX]sWN SYUImode 0[ETX]
Write Variable Response:	[STX]sWA SYUImode[ETX]

© SICK AG - Germany - All rights reserved

2.26.3. Group: SDCard

2.26.3.1. Method: UmountSdCard

The following section contains a detailed description of the method UmountSdCard.

Method Overview

Method Name	Description
UmountSdCard	Unmounts the SD card and finishes all write operations

Communication Name	mSDUmount
Sopas Index	95
Invocation Access	AuthorizedClient, Service

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mSDUmount
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSDUmount	String	9	Unmounts the SD card and finishes all write operations

Method Return Value:

```
sAN mSDUmount <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSDUmount	String	9	Unmounts the SD card and finishes all write operations
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mSDUmount[ETX]`
Method Return Value:	`[STX]sAN mSDUmount 0[ETX]`

© SICK AG - Germany - All rights reserved

2.26.3.2. Method: CheckSdCard

The following section contains a detailed description of the method CheckSdCard.

Method Overview

Method Name	Description
CheckSdCard	Checks the sd-card and its filesystem

Communication Name	mSDCheck
Sopas Index	96
Invocation Access	Always

Return Values	
AllOk	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mSDCheck
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSDCheck	String	8	Checks the sd-card and its filesystem

Method Return Value:

```
sAN mSDCheck <AllOk>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSDCheck	String	8	Checks the sd-card and its filesystem
Return Value 1	AllOk	Bool	1	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mSDCheck[ETX]`
Method Return Value:	`[STX]sAN mSDCheck 0[ETX]`

© SICK AG - Germany - All rights reserved

2.26.3.3. Method: RepairSdCard

The following section contains a detailed description of the method RepairSdCard.

Method Overview

Method Name	Description
RepairSdCard	Attempts to repair the sd-card filesystem

Communication Name	mSDRepair
Sopas Index	97
Invocation Access	Always

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mSDRepair
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSDRepair	String	9	Attempts to repair the sd-card filesystem

Method Return Value:

```
sAN mSDRepair <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSDRepair	String	9	Attempts to repair the sd-card filesystem
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mSDRepair[ETX]`
Method Return Value:	`[STX]sAN mSDRepair 0[ETX]`

© SICK AG - Germany - All rights reserved

2.27. Interface Block: Calib

2.27.1. Group: HallSensorCalib

2.27.1.1. Method: StartContinuousHallSensorMeasurement

The following section contains a detailed description of the method StartContinuousHallSensorMeasurement.

Method Overview

Method Name
StartContinuousHallSensorMeasurement

Communication Name	mStartContinuousHallSensorMeasurement
Sopas Index	105
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mStartContinuousHallSensorMeasurement`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStartContinuousHallSensorMeasurement	String	37	

Method Return Value:				
`sAN mStartContinuousHallSensorMeasurement`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStartContinuousHallSensorMeasurement	String	37	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStartContinuousHallSensorMeasurement[ETX]`
Method Return Value:	`[STX]sAN mStartContinuousHallSensorMeasurement[ETX]`

© SICK AG - Germany - All rights reserved

2.27.1.2. Method: StopHallSensorMeasurements

The following section contains a detailed description of the method StopHallSensorMeasurements.

Method Overview

Method Name
StopHallSensorMeasurements

Communication Name	mStopHallSensorMeasurements
Sopas Index	106
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:

```
sMN mStopHallSensorMeasurements
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStopHallSensorMeasurements	String	27	

Method Return Value:

```
sAN mStopHallSensorMeasurements
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStopHallSensorMeasurements	String	27	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mStopHallSensorMeasurements[ETX]`
Method Return Value:	`[STX]sAN mStopHallSensorMeasurements[ETX]`

© SICK AG - Germany - All rights reserved

2.27.1.3. Method: StartHallSensorSingleshotMeasurement

The following section contains a detailed description of the method StartHallSensorSingleshotMeasurement.

Method Overview

Method Name
StartHallSensorSingleshotMeasurement

Communication Name	mStartHallSensorSingleshotMeasurement
Sopas Index	107
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mStartHallSensorSingleshotMeasurement`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mStartHallSensorSingleshotMeasurement	String	37	

Method Return Value:				
`sAN mStartHallSensorSingleshotMeasurement`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mStartHallSensorSingleshotMeasurement	String	37	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mStartHallSensorSingleshotMeasurement[ETX]`
Method Return Value:	`[STX]sAN mStartHallSensorSingleshotMeasurement[ETX]`

© SICK AG - Germany - All rights reserved

2.28. Interface Block: GeneralCfgReadingStatisticBase

2.28.1. Group: ReadingStatisticConfigBase

2.28.1.1. Variable: ReadingStatisticEnabled

The following section contains a detailed description of the variable ReadingStatisticEnabled.

Variable Overview

Variable Name	Description
ReadingStatisticEnabled	Activates the ReadingStatistic data capturing

Communication Name	ReadingStatEnabled
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	845
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN ReadingStatEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ReadingStatEnabled	String	18	Activates the ReadingStatistic data capturing

Read Variable Response:

```
sRA ReadingStatEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ReadingStatEnabled	String	18	Activates the ReadingStatistic data capturing
Variable Data	data	Bool	1	

Write Variable:

```
sWN ReadingStatEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ReadingStatEnabled	String	18	Activates the ReadingStatistic data capturing
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ReadingStatEnabled				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ReadingStatEnabled	String	18	Activates the ReadingStatistic data capturing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ReadingStatEnabled[ETX]
Read Variable Response:	[STX]sRA ReadingStatEnabled 0[ETX]
Write Variable:	[STX]sWN ReadingStatEnabled 0[ETX]
Write Variable Response:	[STX]sWA ReadingStatEnabled[ETX]

2.28.1.2. Variable: RSCTCond1Enum

The following section contains a detailed description of the variable RSCTCond1Enum.

Variable Overview

Variable Name	Description
RSCTCond1Enum	Enum of Condition for codetype1 of ReadingStatistic

Communication Name	RSctcond1enum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	846
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_WILDCARD	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RSctcond1enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond1enum	String	13	Enum of Condition for codetype1 of ReadingStatistic

Read Variable Response:				
`sRA RSctcond1enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond1enum	String	13	Enum of Condition for codetype1 of ReadingStatistic
Variable Data	data	Enum8	1	

Write Variable:				
`sWN RSctcond1enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond1enum	String	13	Enum of Condition for codetype1 of ReadingStatistic
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA RSctcond1enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSctcond1enum	String	13	Enum of Condition for codetype1 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RSctcond1enum[ETX]`
Read Variable Response:	`[STX]sRA RSctcond1enum 0[ETX]`
Write Variable:	`[STX]sWN RSctcond1enum 0[ETX]`
Write Variable Response:	`[STX]sWA RSctcond1enum[ETX]`

© SICK AG - Germany - All rights reserved

2.28.1.3. Variable: RSCTCond1Struct

The following section contains a detailed description of the variable RSCTCond1Struct.

Variable Overview

Variable Name	Description
RSCTCond1Struct	Struct of Condition for codetype1 of ReadingStatistic

Communication Name	RSctcond1struct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	847
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN RSctcond1struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond1struct	String	15	Struct of Condition for codetype1 of ReadingStatistic

Read Variable Response:

```
sRA RSctcond1struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond1struct	String	15	Struct of Condition for codetype1 of ReadingStatistic
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable:

```
sWN RSctcond1struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond1struct	String	15	Struct of Condition for codetype1 of ReadingStatistic
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:

```
sWA RSctcond1struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RSctcond1struct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	RSctcond1struct	String	15	Struct of Condition for codetype1 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RSctcond1struct[ETX]
Read Variable Response:	[STX]sRA RSctcond1struct 0 0[ETX]
Write Variable:	[STX]sWN RSctcond1struct 0 0[ETX]
Write Variable Response:	[STX]sWA RSctcond1struct[ETX]

2.28.1.4. Variable: RSCTCond1Name

The following section contains a detailed description of the variable RSCTCond1Name.

Variable Overview

Variable Name	Description
RSCTCond1Name	Name of Condition for codetype1 of ReadingStatistic

Communication Name	RSctcond1name
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	848
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	32
Initialisation	Code Type 1

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RSctcond1name`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond1name	String	13	Name of Condition for codetype1 of ReadingStatistic

Read Variable Response:				
`sRA RSctcond1name <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond1name	String	13	Name of Condition for codetype1 of ReadingStatistic
Variable Data	data	String	32	

Write Variable:				
`sWN RSctcond1name <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond1name	String	13	Name of Condition for codetype1 of ReadingStatistic
Variable Data	data	String	32	

Write Variable Response:				
`sWA RSctcond1name`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSctcond1name	String	13	Name of Condition for codetype1 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RSctcond1name[ETX]`
Read Variable Response:	`[STX]sRA RSctcond1name Code Type 1·····[ETX]`
Write Variable:	`[STX]sWN RSctcond1name Code Type 1·····[ETX]`
Write Variable Response:	`[STX]sWA RSctcond1name[ETX]`

© SICK AG - Germany - All rights reserved

2.28.1.5. Variable: RSCTCond2Enum

The following section contains a detailed description of the variable RSCTCond2Enum.

Variable Overview

Variable Name	Description
RSCTCond2Enum	Enum of Condition for codetype2 of ReadingStatistic

Communication Name	RSctcond2enum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	849
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_WILDCARD	

Variable Telegram Syntax

Read Variable:				
`sRN RSctcond2enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond2enum	String	13	Enum of Condition for codetype2 of ReadingStatistic

Read Variable Response:				
`sRA RSctcond2enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond2enum	String	13	Enum of Condition for codetype2 of ReadingStatistic
Variable Data	data	Enum8	1	

Write Variable:				
`sWN RSctcond2enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond2enum	String	13	Enum of Condition for codetype2 of ReadingStatistic
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RSctcond2enum				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSctcond2enum	String	13	Enum of Condition for codetype2 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RSctcond2enum[ETX]
Read Variable Response:	[STX]sRA RSctcond2enum 0[ETX]
Write Variable:	[STX]sWN RSctcond2enum 0[ETX]
Write Variable Response:	[STX]sWA RSctcond2enum[ETX]

2.28.1.6. Variable: RSCTCond2Struct

The following section contains a detailed description of the variable RSCTCond2Struct.

Variable Overview

Variable Name	Description
RSCTCond2Struct	Struct of Condition for codetype2 of ReadingStatistic

Communication Name	RSctcond2struct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	850
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN RSctcond2struct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond2struct	String	15	Struct of Condition for codetype2 of ReadingStatistic

Read Variable Response:				
sRA RSctcond2struct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond2struct	String	15	Struct of Condition for codetype2 of ReadingStatistic
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable:				
sWN RSctcond2struct <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond2struct	String	15	Struct of Condition for codetype2 of ReadingStatistic
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:				
sWA RSctcond2struct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSctcond2struct	String	15	Struct of Condition for codetype2 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RSctcond2struct[ETX]
Read Variable Response:	[STX]sRA RSctcond2struct 0 0[ETX]
Write Variable:	[STX]sWN RSctcond2struct 0 0[ETX]
Write Variable Response:	[STX]sWA RSctcond2struct[ETX]

© SICK AG - Germany - All rights reserved

2.28.1.7. Variable: RSCTCond2Name

The following section contains a detailed description of the variable RSCTCond2Name.

Variable Overview

Variable Name	Description
RSCTCond2Name	Name of Condition for codetype2 of ReadingStatistic

Communication Name	RSctcond2name
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	851
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	32
Initialisation	Code Type 2

Variable Telegram Syntax

Read Variable:

```
sRN RSctcond2name
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond2name	String	13	Name of Condition for codetype2 of ReadingStatistic

Read Variable Response:

```
sRA RSctcond2name <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond2name	String	13	Name of Condition for codetype2 of ReadingStatistic
Variable Data	data	String	32	

Write Variable:

```
sWN RSctcond2name <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond2name	String	13	Name of Condition for codetype2 of ReadingStatistic
Variable Data	data	String	32	

Write Variable Response:

```
sWA RSctcond2name
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RSctcond2name				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	RSctcond2name	String	13	Name of Condition for codetype2 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RSctcond2name[ETX]
Read Variable Response:	[STX]sRA RSctcond2name Code Type 2·····[ETX]
Write Variable:	[STX]sWN RSctcond2name Code Type 2·····[ETX]
Write Variable Response:	[STX]sWA RSctcond2name[ETX]

2.28.1.8. Variable: RSCTCond3Enum

The following section contains a detailed description of the variable RSCTCond3Enum.

Variable Overview

Variable Name	Description
RSCTCond3Enum	Enum of Condition for codetype3 of ReadingStatistic

Communication Name	RSctcond3enum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	852
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_WILDCARD	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RSctcond3enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond3enum	String	13	Enum of Condition for codetype3 of ReadingStatistic

Read Variable Response:				
`sRA RSctcond3enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond3enum	String	13	Enum of Condition for codetype3 of ReadingStatistic
Variable Data	data	Enum8	1	

Write Variable:				
`sWN RSctcond3enum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond3enum	String	13	Enum of Condition for codetype3 of ReadingStatistic
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA RSctcond3enum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSctcond3enum	String	13	Enum of Condition for codetype3 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RSctcond3enum[ETX]`
Read Variable Response:	`[STX]sRA RSctcond3enum 0[ETX]`
Write Variable:	`[STX]sWN RSctcond3enum 0[ETX]`
Write Variable Response:	`[STX]sWA RSctcond3enum[ETX]`

© SICK AG - Germany - All rights reserved

2.28.1.9. Variable: RSCTCond3Struct

The following section contains a detailed description of the variable RSCTCond3Struct.

Variable Overview

Variable Name	Description
RSCTCond3Struct	Struct of Condition for codetype3 of ReadingStatistic

Communication Name	RSctcond3struct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	853
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UserType	
SETEditExtendibleEnum	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN RSctcond3struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond3struct	String	15	Struct of Condition for codetype3 of ReadingStatistic

Read Variable Response:

```
sRA RSctcond3struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond3struct	String	15	Struct of Condition for codetype3 of ReadingStatistic
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable:

```
sWN RSctcond3struct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond3struct	String	15	Struct of Condition for codetype3 of ReadingStatistic
Variable Data	data	SETEditExtendibleEnum	19	

Write Variable Response:

```
sWA RSctcond3struct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RSctcond3struct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	RSctcond3struct	String	15	Struct of Condition for codetype3 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RSctcond3struct[ETX]
Read Variable Response:	[STX]sRA RSctcond3struct 0 0[ETX]
Write Variable:	[STX]sWN RSctcond3struct 0 0[ETX]
Write Variable Response:	[STX]sWA RSctcond3struct[ETX]

2.28.1.10. Variable: RSCTCond3Name

The following section contains a detailed description of the variable RSCTCond3Name.

Variable Overview

Variable Name	Description
RSCTCond3Name	Name of Condition for codetype3 of ReadingStatistic

Communication Name	RSctcond31name
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	854
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	32
Initialisation	Code Type 3

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RSctcond31name`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSctcond31name	String	14	Name of Condition for codetype3 of ReadingStatistic

Read Variable Response:				
`sRA RSctcond31name <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSctcond31name	String	14	Name of Condition for codetype3 of ReadingStatistic
Variable Data	data	String	32	

Write Variable:				
`sWN RSctcond31name <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSctcond31name	String	14	Name of Condition for codetype3 of ReadingStatistic
Variable Data	data	String	32	

Write Variable Response:				
`sWA RSctcond31name`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSctcond31name	String	14	Name of Condition for codetype3 of ReadingStatistic

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RSctcond31name[ETX]`
Read Variable Response:	`[STX]sRA RSctcond31name Code Type 3·····[ETX]`
Write Variable:	`[STX]sWN RSctcond31name Code Type 3·····[ETX]`
Write Variable Response:	`[STX]sWA RSctcond31name[ETX]`

© SICK AG - Germany - All rights reserved

2.28.1.11. Method: RSClearStat

The following section contains a detailed description of the method RSClearStat.

Method Overview

Method Name	Description
RSClearStat	clears the statistic data

Communication Name	mRSClearStat
Sopas Index	108
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mRSClearStat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mRSClearStat	String	12	clears the statistic data

Method Return Value:				
`sAN mRSClearStat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mRSClearStat	String	12	clears the statistic data

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mRSClearStat[ETX]`
Method Return Value:	`[STX]sAN mRSClearStat[ETX]`

© SICK AG - Germany - All rights reserved

2.28.2. Group: ReadingStatisticFileView

2.28.2.1. Variable: RSRefreshRunning

The following section contains a detailed description of the variable RSRefreshRunning.

Variable Overview

Variable Name	Description
RSRefreshRunning	Switch that indicates that a refresh is currenlty running

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	855
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN RSRefreshRunning
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSRefreshRunning	String	16	Switch that indicates that a refresh is currenlty running

Read Variable Response:

```
sRA RSRefreshRunning <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSRefreshRunning	String	16	Switch that indicates that a refresh is currenlty running
Variable Data	data	Bool	1	

Write Variable:

```
sWN RSRefreshRunning <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSRefreshRunning	String	16	Switch that indicates that a refresh is currenlty running
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA RSRefreshRunning
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RSRefreshRunning				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	RSRefreshRunning	String	16	Switch that indicates that a refresh is currenlty running

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RSRefreshRunning[ETX]
Read Variable Response:	[STX]sRA RSRefreshRunning 0[ETX]
Write Variable:	[STX]sWN RSRefreshRunning 0[ETX]
Write Variable Response:	[STX]sWA RSRefreshRunning[ETX]

2.28.2.2. Variable: RSRefreshTrigger

The following section contains a detailed description of the variable RSRefreshTrigger.

Variable Overview

Variable Name	Description
RSRefreshTrigger	Switch to signal that a new diagram viewer file for the reading stat is available

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	856
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RSRefreshTrigger`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RSRefreshTrigger	String	16	Switch to signal that a new diagram viewer file for the reading stat is available

Read Variable Response:				
`sRA RSRefreshTrigger <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RSRefreshTrigger	String	16	Switch to signal that a new diagram viewer file for the reading stat is available
Variable Data	data	Bool	1	

Write Variable:				
`sWN RSRefreshTrigger <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RSRefreshTrigger	String	16	Switch to signal that a new diagram viewer file for the reading stat is available
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA RSRefreshTrigger`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RSRefreshTrigger	String	16	Switch to signal that a new diagram viewer file for the reading stat is available

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RSRefreshTrigger[ETX]`
Read Variable Response:	`[STX]sRA RSRefreshTrigger 0[ETX]`
Write Variable:	`[STX]sWN RSRefreshTrigger 0[ETX]`
Write Variable Response:	`[STX]sWA RSRefreshTrigger[ETX]`

© SICK AG - Germany - All rights reserved

2.29. Interface Block: GeneralCfg

2.29.1. Group: DigitalOutputsEnhancements

2.29.1.1. Variable: Out1FuncTeachInMatchCodeEnh

The following section contains a detailed description of the variable Out1FuncTeachInMatchCodeEnh.

Variable Overview

Variable Name
Out1FuncTeachInMatchCodeEnh

Communication Name	DO1FncTIMCE
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	857
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_NOTHING	
UseExtraValue			
	Bool		
	Value Range	False, True	
	Initialisation	False	
ExtraValue			
	FlexString		
	Length	0..18	
	Initialisation		

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO1FncTIMCE`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO1FncTIMCE	String	11	

Read Variable Response:				
`sRA DO1FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO1FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable:				
`sWN DO1FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO1FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA DO1FncTIMCE`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO1FncTIMCE	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO1FncTIMCE[ETX]`
Read Variable Response:	`[STX]sRA DO1FncTIMCE 0 0 0[ETX]`
Write Variable:	`[STX]sWN DO1FncTIMCE 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DO1FncTIMCE[ETX]`

© SICK AG - Germany - All rights reserved

2.29.1.2. Variable: Out2FuncTeachInMatchCodeEnh

The following section contains a detailed description of the variable Out2FuncTeachInMatchCodeEnh.

Variable Overview

Variable Name
Out2FuncTeachInMatchCodeEnh

Communication Name	DO2FncTIMCE
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	858
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_NOTHING	
UseExtraValue			
	Bool		
	Value Range	False, True	
	Initialisation	False	
ExtraValue			
	FlexString		
	Length	0..18	
	Initialisation		

Variable Telegram Syntax

Read Variable:

```
sRN DO2FncTIMCE
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO2FncTIMCE	String	11	

Read Variable Response:

```
sRA DO2FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO2FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DO2FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO2FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA DO2FncTIMCE`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO2FncTIMCE	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO2FncTIMCE[ETX]`
Read Variable Response:	`[STX]sRA DO2FncTIMCE 0 0 0[ETX]`
Write Variable:	`[STX]sWN DO2FncTIMCE 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DO2FncTIMCE[ETX]`

2.29.1.3. Variable: Out3FuncTeachInMatchCodeEnh

The following section contains a detailed description of the variable Out3FuncTeachInMatchCodeEnh.

Variable Overview

Variable Name
Out3FuncTeachInMatchCodeEnh

Communication Name	DO3FncTIMCE
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	859
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_NOTHING	

© SICK AG - Germany - All rights reserved

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..18
	Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DO3FncTIMCE
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO3FncTIMCE	String	11	

Read Variable Response:

```
sRA DO3FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO3FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable:

```
sWN DO3FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO3FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:

```
sWA DO3FncTIMCE
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO3FncTIMCE	String	11	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO3FncTIMCE[ETX]`
Read Variable Response:	`[STX]sRA DO3FncTIMCE 0 0 0[ETX]`
Write Variable:	`[STX]sWN DO3FncTIMCE 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DO3FncTIMCE[ETX]`

2.29.1.4. Variable: Out4FuncTeachInMatchCodeEnh

The following section contains a detailed description of the variable Out4FuncTeachInMatchCodeEnh.

Variable Overview

Variable Name
Out4FuncTeachInMatchCodeEnh

Communication Name	DO4FncTIMCE
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	860
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_NOTHING	
UseExtraValue			
	Bool		
	Value Range	False, True	
	Initialisation	False	
ExtraValue			
	FlexString		
	Length	0..18	
	Initialisation		

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DO4FncTIMCE`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DO4FncTIMCE	String	11	

Read Variable Response:				
`sRA DO4FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DO4FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable:				
`sWN DO4FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DO4FncTIMCE	String	11	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA DO4FncTIMCE`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DO4FncTIMCE	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DO4FncTIMCE[ETX]`
Read Variable Response:	`[STX]sRA DO4FncTIMCE 0 0 0[ETX]`
Write Variable:	`[STX]sWN DO4FncTIMCE 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DO4FncTIMCE[ETX]`

© SICK AG - Germany - All rights reserved

2.29.1.5. Variable: ExtOut1FuncTeachInMatchCodeEnh

The following section contains a detailed description of the variable ExtOut1FuncTeachInMatchCodeEnh.

Variable Overview

Variable Name
ExtOut1FuncTeachInMatchCodeEnh

Communication Name	DOExt1FncTIMCE
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	861
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_NOTHING	
UseExtraValue			
	Bool		
	Value Range	False, True	
	Initialisation	False	
ExtraValue			
	FlexString		
	Length	0..18	
	Initialisation		

Variable Telegram Syntax

Read Variable:				
`sRN DOExt1FncTIMCE`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DOExt1FncTIMCE	String	14	

Read Variable Response:				
`sRA DOExt1FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DOExt1FncTIMCE	String	14	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DOExt1FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DOExt1FncTIMCE	String	14	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:				
sWA DOExt1FncTIMCE				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DOExt1FncTIMCE	String	14	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DOExt1FncTIMCE[ETX]
Read Variable Response:	[STX]sRA DOExt1FncTIMCE 0 0 0[ETX]
Write Variable:	[STX]sWN DOExt1FncTIMCE 0 0 0[ETX]
Write Variable Response:	[STX]sWA DOExt1FncTIMCE[ETX]

2.29.1.6. Variable: ExtOut2FuncTeachInMatchCodeEnh

The following section contains a detailed description of the variable ExtOut2FuncTeachInMatchCodeEnh.

Variable Overview

Variable Name
ExtOut2FuncTeachInMatchCodeEnh

Communication Name	DOExt2FncTIMCE
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	862
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
EnumValue			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_NOTHING	

© SICK AG - Germany - All rights reserved

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..18
	Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DOExt2FncTIMCE
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DOExt2FncTIMCE	String	14	

Read Variable Response:

```
sRA DOExt2FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DOExt2FncTIMCE	String	14	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable:

```
sWN DOExt2FncTIMCE <EnumValue> <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DOExt2FncTIMCE	String	14	
Variable Data 1	EnumValue	Enum8	1	
Variable Data 2	UseExtraValue	Bool	1	
Variable Data 3	ExtraValue	FlexString	18	

Write Variable Response:

```
sWA DOExt2FncTIMCE
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DOExt2FncTIMCE	String	14	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DOExt2FncTIMCE[ETX]`
Read Variable Response:	`[STX]sRA DOExt2FncTIMCE 0 0 0[ETX]`
Write Variable:	`[STX]sWN DOExt2FncTIMCE 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DOExt2FncTIMCE[ETX]`

© SICK AG - Germany - All rights reserved

2.29.2. Group: Serial

2.29.2.1. Variable: SerHostCustomProtNb

The following section contains a detailed description of the variable SerHostCustomProtNb.

Variable Overview

Variable Name	Description
SerHostCustomProtNb	Protocol number for the custom protocol

Communication Name	SIHstCstProtNb
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	863
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..9999
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SIHstCstProtNb
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstCstProtNb	String	14	Protocol number for the custom protocol

Read Variable Response:

```
sRA SIHstCstProtNb <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstCstProtNb	String	14	Protocol number for the custom protocol
Variable Data	data	UInt	2	

Write Variable:

```
sWN SIHstCstProtNb <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstCstProtNb	String	14	Protocol number for the custom protocol
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SIHstCstProtNb				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstCstProtNb	String	14	Protocol number for the custom protocol

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIHstCstProtNb[ETX]
Read Variable Response:	[STX]sRA SIHstCstProtNb 1[ETX]
Write Variable:	[STX]sWN SIHstCstProtNb 1[ETX]
Write Variable Response:	[STX]sWA SIHstCstProtNb[ETX]

© SICK AG - Germany - All rights reserved

2.29.3. Group: Ethernet

2.29.3.1. Variable: EtherHostCustomProtNb

The following section contains a detailed description of the variable EtherHostCustomProtNb.

Variable Overview

Variable Name	Description
EtherHostCustomProtNb	Protocol number for the custom protocol

Communication Name	ETHstCstProtNb
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	864
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..9999
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ETHstCstProtNb
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ETHstCstProtNb	String	14	Protocol number for the custom protocol

Read Variable Response:

```
sRA ETHstCstProtNb <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ETHstCstProtNb	String	14	Protocol number for the custom protocol
Variable Data	data	UInt	2	

Write Variable:

```
sWN ETHstCstProtNb <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ETHstCstProtNb	String	14	Protocol number for the custom protocol
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ETHstCstProtNb				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ETHstCstProtNb	String	14	Protocol number for the custom protocol

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ETHstCstProtNb[ETX]
Read Variable Response:	[STX]sRA ETHstCstProtNb 1[ETX]
Write Variable:	[STX]sWN ETHstCstProtNb 1[ETX]
Write Variable Response:	[STX]sWA ETHstCstProtNb[ETX]

© SICK AG - Germany - All rights reserved

2.29.4. Group: FTP

2.29.4.1. Variable: FTPClientActive

The following section contains a detailed description of the variable FTPClientActive.

Variable Overview

Variable Name	Description
FTPClientActive	Enables FTP Client

Communication Name	FTClntAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	865
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN FTClntAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTClntAct	String	9	Enables FTP Client

Read Variable Response:

```
sRA FTClntAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTClntAct	String	9	Enables FTP Client
Variable Data	data	Bool	1	

Write Variable:

```
sWN FTClntAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTClntAct	String	9	Enables FTP Client
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA FTClntAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FTClntAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	FTClntAct	String	9	Enables FTP Client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTClntAct[ETX]
Read Variable Response:	[STX]sRA FTClntAct 0[ETX]
Write Variable:	[STX]sWN FTClntAct 0[ETX]
Write Variable Response:	[STX]sWA FTClntAct[ETX]

2.29.4.2. Variable: FTPServerIPAddress

The following section contains a detailed description of the variable FTPServerIPAddress.

Variable Overview

Variable Name	Description
FTPServerIPAddress	IP-Adress of Server for FTP

Communication Name	FTSvrAdr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	866
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{192,168,0,11}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTSvrAdr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTSvrAdr	String	8	IP-Adress of Server for FTP

Read Variable Response:				
`sRA FTSvrAdr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTSvrAdr	String	8	IP-Adress of Server for FTP
Variable Data	data	Array	4	

Write Variable:				
`sWN FTSvrAdr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTSvrAdr	String	8	IP-Adress of Server for FTP
Variable Data	data	Array	4	

Write Variable Response:				
`sWA FTSvrAdr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTSvrAdr	String	8	IP-Adress of Server for FTP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTSvrAdr[ETX]`
Read Variable Response:	`[STX]sRA FTSvrAdr C0 A8 0 B[ETX]`
Write Variable:	`[STX]sWN FTSvrAdr C0 A8 0 B[ETX]`
Write Variable Response:	`[STX]sWA FTSvrAdr[ETX]`

© SICK AG - Germany - All rights reserved

2.29.4.3. Variable: FTPServerIPPort

The following section contains a detailed description of the variable FTPServerIPPort.

Variable Overview

Variable Name	Description
FTPServerIPPort	IP-Port of Server for FTP

Communication Name	FTSvrPrt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	867
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	21
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FTSvrPrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTSvrPrt	String	8	IP-Port of Server for FTP

Read Variable Response:

```
sRA FTSvrPrt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTSvrPrt	String	8	IP-Port of Server for FTP
Variable Data	data	UInt	2	

Write Variable:

```
sWN FTSvrPrt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTSvrPrt	String	8	IP-Port of Server for FTP
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA FTSvrPrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTSvrPrt	String	8	IP-Port of Server for FTP

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTSvrPrt[ETX]`
Read Variable Response:	`[STX]sRA FTSvrPrt 15[ETX]`
Write Variable:	`[STX]sWN FTSvrPrt 15[ETX]`
Write Variable Response:	`[STX]sWA FTSvrPrt[ETX]`

2.29.4.4. Variable: FTPHostname

The following section contains a detailed description of the variable FTPHostname.

Variable Overview

Variable Name	Description
FTPHostname	Hostname for FTP client

Communication Name	FTHstNm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	868
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	

Variable Telegram Syntax

Read Variable:				
`sRN FTHstNm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTHstNm	String	7	Hostname for FTP client

Read Variable Response:				
`sRA FTHstNm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTHstNm	String	7	Hostname for FTP client
Variable Data	data	FlexString	20	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FTHstNm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTHstNm	String	7	Hostname for FTP client
Variable Data	data	FlexString	20	

Write Variable Response:				
sWA FTHstNm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTHstNm	String	7	Hostname for FTP client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTHstNm[ETX]
Read Variable Response:	[STX]sRA FTHstNm 1 [ETX]
Write Variable:	[STX]sWN FTHstNm 1 [ETX]
Write Variable Response:	[STX]sWA FTHstNm[ETX]

2.29.4.5. Variable: FTPEthIface

The following section contains a detailed description of the variable FTPEthIface.

Variable Overview

Variable Name	Description
FTPEthIface	Ethernet interface to send FTP output

Communication Name	FTEthIf
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	869
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ETHERNET0	
	1	TX_ETHERNET1	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTEthIf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTEthIf	String	7	Ethernet interface to send FTP output

Read Variable Response:				
`sRA FTEthIf <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTEthIf	String	7	Ethernet interface to send FTP output
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FTEthIf <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTEthIf	String	7	Ethernet interface to send FTP output
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA FTEthIf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTEthIf	String	7	Ethernet interface to send FTP output

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTEthIf[ETX]`
Read Variable Response:	`[STX]sRA FTEthIf 0[ETX]`
Write Variable:	`[STX]sWN FTEthIf 0[ETX]`
Write Variable Response:	`[STX]sWA FTEthIf[ETX]`

© SICK AG - Germany - All rights reserved

2.29.4.6. Variable: FTPProtocol

The following section contains a detailed description of the variable FTPProtocol.

Variable Overview

Variable Name	Description
FTPProtocol	FTP Protocol variant

Communication Name	FTProt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	870
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_FTP	
	Value	Name	Description
	0	TX_FTP	
	1	TX_SFTP	

Variable Telegram Syntax

Read Variable:				
`sRN FTProt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTProt	String	6	FTP Protocol variant

Read Variable Response:				
`sRA FTProt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTProt	String	6	FTP Protocol variant
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FTProt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTProt	String	6	FTP Protocol variant
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA FTProt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTProt	String	6	FTP Protocol variant

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTProt[ETX]`
Read Variable Response:	`[STX]sRA FTProt 0[ETX]`
Write Variable:	`[STX]sWN FTProt 0[ETX]`
Write Variable Response:	`[STX]sWA FTProt[ETX]`

2.29.4.7. Variable: FTPAuthenticationMethod

The following section contains a detailed description of the variable FTPAuthenticationMethod.

Variable Overview

Variable Name	Description
FTPAuthenticationMethod	Authorization mode for sFTP

Communication Name	FTAuthMet
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	871
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_USERPASSWORD	
	Value	Name	Description
	0	TX_USERPASSWORD	
	1	TX_USERKEY	

Variable Telegram Syntax

Read Variable:				
`sRN FTAuthMet`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTAuthMet	String	9	Authorization mode for sFTP

Read Variable Response:				
`sRA FTAuthMet <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTAuthMet	String	9	Authorization mode for sFTP
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FTAuthMet <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTAuthMet	String	9	Authorization mode for sFTP
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA FTAuthMet				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTAuthMet	String	9	Authorization mode for sFTP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTAuthMet[ETX]
Read Variable Response:	[STX]sRA FTAuthMet 0[ETX]
Write Variable:	[STX]sWN FTAuthMet 0[ETX]
Write Variable Response:	[STX]sWA FTAuthMet[ETX]

2.29.4.8. Variable: FTPUsername

The following section contains a detailed description of the variable FTPUsername.

Variable Overview

Variable Name	Description
FTPUsername	Username of FTP client

Communication Name	FTClntUsrNm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	872
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTClntUsrNm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTClntUsrNm	String	11	Username of FTP client

Read Variable Response:				
`sRA FTClntUsrNm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTClntUsrNm	String	11	Username of FTP client
Variable Data	data	FlexString	20	

Write Variable:				
`sWN FTClntUsrNm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTClntUsrNm	String	11	Username of FTP client
Variable Data	data	FlexString	20	

Write Variable Response:				
`sWA FTClntUsrNm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTClntUsrNm	String	11	Username of FTP client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTClntUsrNm[ETX]`
Read Variable Response:	`[STX]sRA FTClntUsrNm 9 anonymous[ETX]`
Write Variable:	`[STX]sWN FTClntUsrNm 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA FTClntUsrNm[ETX]`

© SICK AG - Germany - All rights reserved

2.29.4.9. Variable: FTPPassword

The following section contains a detailed description of the variable FTPPassword.

Variable Overview

Variable Name	Description
FTPPassword	Password of FTP client

Communication Name	FTClntPasWd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	873
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

Variable Telegram Syntax

Read Variable:

```
sRN FTClntPasWd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTClntPasWd	String	11	Password of FTP client

Read Variable Response:

```
sRA FTClntPasWd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTClntPasWd	String	11	Password of FTP client
Variable Data	data	FlexString	20	

Write Variable:

```
sWN FTClntPasWd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTClntPasWd	String	11	Password of FTP client
Variable Data	data	FlexString	20	

Write Variable Response:

```
sWA FTClntPasWd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTClntPasWd	String	11	Password of FTP client

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTClntPasWd[ETX]`
Read Variable Response:	`[STX]sRA FTClntPasWd 9 anonymous[ETX]`
Write Variable:	`[STX]sWN FTClntPasWd 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA FTClntPasWd[ETX]`

2.29.4.10. Variable: FTPPathPrivateKey

The following section contains a detailed description of the variable FTPPathPrivateKey.

Variable Overview

Variable Name	Description
FTPPathPrivateKey	Path for private key for SFTP

Communication Name	FTPrivKey
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	874
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..256
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN FTPrivKey
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTPrivKey	String	9	Path for private key for SFTP

Read Variable Response:

```
sRA FTPrivKey <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTPrivKey	String	9	Path for private key for SFTP
Variable Data	data	FlexString	256	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FTPrivKey <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTPrivKey	String	9	Path for private key for SFTP
Variable Data	data	FlexString	256	

Write Variable Response:				
sWA FTPrivKey				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTPrivKey	String	9	Path for private key for SFTP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTPrivKey[ETX]
Read Variable Response:	[STX]sRA FTPrivKey 0[ETX]
Write Variable:	[STX]sWN FTPrivKey 0[ETX]
Write Variable Response:	[STX]sWA FTPrivKey[ETX]

2.29.4.11. Variable: FTPUploadPath

The following section contains a detailed description of the variable FTPUploadPath.

Variable Overview

Variable Name	Description
FTPUploadPath	Upload Path of FTP client

Communication Name	FTClntUpPath
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	875
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTClntUpPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTClntUpPath	String	12	Upload Path of FTP client

Read Variable Response:				
`sRA FTClntUpPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTClntUpPath	String	12	Upload Path of FTP client
Variable Data	data	FlexString	20	

Write Variable:				
`sWN FTClntUpPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTClntUpPath	String	12	Upload Path of FTP client
Variable Data	data	FlexString	20	

Write Variable Response:				
`sWA FTClntUpPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTClntUpPath	String	12	Upload Path of FTP client

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTClntUpPath[ETX]`
Read Variable Response:	`[STX]sRA FTClntUpPath 1  [ETX]`
Write Variable:	`[STX]sWN FTClntUpPath 1  [ETX]`
Write Variable Response:	`[STX]sWA FTClntUpPath[ETX]`

© SICK AG - Germany - All rights reserved

2.29.4.12. Variable: FTPDevUpload

The following section contains a detailed description of the variable FTPDevUpload.

Variable Overview

Variable Name	Description
FTPDevUpload	Device specific Upload Path of FTP client

Communication Name	FTClntDevUpPath
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	876
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_SERIAL_NUMBER	
	1	TX_HOST_NAME	

Variable Telegram Syntax

Read Variable:				
`sRN FTClntDevUpPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTClntDevUpPath	String	15	Device specific Upload Path of FTP client

Read Variable Response:				
`sRA FTClntDevUpPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTClntDevUpPath	String	15	Device specific Upload Path of FTP client
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FTClntDevUpPath <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTClntDevUpPath	String	15	Device specific Upload Path of FTP client
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA FTClntDevUpPath`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTClntDevUpPath	String	15	Device specific Upload Path of FTP client

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTClntDevUpPath[ETX]`
Read Variable Response:	`[STX]sRA FTClntDevUpPath 0[ETX]`
Write Variable:	`[STX]sWN FTClntDevUpPath 0[ETX]`
Write Variable Response:	`[STX]sWA FTClntDevUpPath[ETX]`

© SICK AG - Germany - All rights reserved

2.29.5. Group: FTPArchiv

2.29.5.1. Variable: FTPArchivUsername

The following section contains a detailed description of the variable FTPArchivUsername.

Variable Overview

Variable Name	Description
FTPArchivUsername	Username of FTP server

Communication Name	FTAUsrNm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	877
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

Variable Telegram Syntax

Read Variable:

```
sRN FTAUsrNm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTAUsrNm	String	8	Username of FTP server

Read Variable Response:

```
sRA FTAUsrNm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTAUsrNm	String	8	Username of FTP server
Variable Data	data	FlexString	20	

Write Variable:

```
sWN FTAUsrNm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTAUsrNm	String	8	Username of FTP server
Variable Data	data	FlexString	20	

Write Variable Response:

```
sWA FTAUsrNm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FTAUsrNm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	FTAUsrNm	String	8	Username of FTP server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTAUsrNm[ETX]
Read Variable Response:	[STX]sRA FTAUsrNm 9 anonymous[ETX]
Write Variable:	[STX]sWN FTAUsrNm 9 anonymous[ETX]
Write Variable Response:	[STX]sWA FTAUsrNm[ETX]

2.29.5.2. Variable: FTPArchibPassword

The following section contains a detailed description of the variable FTPArchibPassword.

Variable Overview

Variable Name	Description
FTPArchibPassword	Password of FTP server

Communication Name	FTAPasWd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	878
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTAPasWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTAPasWd	String	8	Password of FTP server

Read Variable Response:				
`sRA FTAPasWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTAPasWd	String	8	Password of FTP server
Variable Data	data	FlexString	20	

Write Variable:				
`sWN FTAPasWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTAPasWd	String	8	Password of FTP server
Variable Data	data	FlexString	20	

Write Variable Response:				
`sWA FTAPasWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTAPasWd	String	8	Password of FTP server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTAPasWd[ETX]`
Read Variable Response:	`[STX]sRA FTAPasWd 9 anonymous[ETX]`
Write Variable:	`[STX]sWN FTAPasWd 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA FTAPasWd[ETX]`

© SICK AG - Germany - All rights reserved

2.29.5.3. Variable: FTPArchiveIPPort

The following section contains a detailed description of the variable FTPArchiveIPPort.

Variable Overview

Variable Name	Description
FTPArchiveIPPort	IP-Port of Server for FTP

Communication Name	FTASvrPrt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	879
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2021
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FTASvrPrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTASvrPrt	String	9	IP-Port of Server for FTP

Read Variable Response:

```
sRA FTASvrPrt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTASvrPrt	String	9	IP-Port of Server for FTP
Variable Data	data	UInt	2	

Write Variable:

```
sWN FTASvrPrt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTASvrPrt	String	9	IP-Port of Server for FTP
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA FTASvrPrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTASvrPrt	String	9	IP-Port of Server for FTP

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTASvrPrt[ETX]`
Read Variable Response:	`[STX]sRA FTASvrPrt 7E5[ETX]`
Write Variable:	`[STX]sWN FTASvrPrt 7E5[ETX]`
Write Variable Response:	`[STX]sWA FTASvrPrt[ETX]`

2.29.5.4. Variable: FTPArchiveSendBufferSize

The following section contains a detailed description of the variable FTPArchiveSendBufferSize.

Variable Overview

Variable Name	Description
FTPArchiveSendBufferSize	Sendbuffer size

Communication Name	FTASendBufSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	880
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	64
Physical Unit	kB
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN FTASendBufSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTASendBufSize	String	14	Sendbuffer size

Read Variable Response:				
`sRA FTASendBufSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTASendBufSize	String	14	Sendbuffer size
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FTASendBufSize <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTASendBufSize	String	14	Sendbuffer size
Variable Data	data	UInt	2	

Write Variable Response:				
sWA FTASendBufSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTASendBufSize	String	14	Sendbuffer size

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTASendBufSize[ETX]
Read Variable Response:	[STX]sRA FTASendBufSize 40[ETX]
Write Variable:	[STX]sWN FTASendBufSize 40[ETX]
Write Variable Response:	[STX]sWA FTASendBufSize[ETX]

2.29.5.5. Variable: FTPArchiveMaxClients

The following section contains a detailed description of the variable FTPArchiveMaxClients.

Variable Overview

Variable Name	Description
FTPArchiveMaxClients	max number of clients

Communication Name	FTAMaxClients
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	881
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	4
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTAMaxClients`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTAMaxClients	String	13	max number of clients

Read Variable Response:				
`sRA FTAMaxClients <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTAMaxClients	String	13	max number of clients
Variable Data	data	UInt	2	

Write Variable:				
`sWN FTAMaxClients <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTAMaxClients	String	13	max number of clients
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA FTAMaxClients`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTAMaxClients	String	13	max number of clients

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTAMaxClients[ETX]`
Read Variable Response:	`[STX]sRA FTAMaxClients 4[ETX]`
Write Variable:	`[STX]sWN FTAMaxClients 4[ETX]`
Write Variable Response:	`[STX]sWA FTAMaxClients[ETX]`

© SICK AG - Germany - All rights reserved

2.29.5.6. Variable: FTPArchiveClientTimeout

The following section contains a detailed description of the variable FTPArchiveClientTimeout.

Variable Overview

Variable Name	Description
FTPArchiveClientTimeout	clients timout

Communication Name	FTAClientTimeout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	882
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	30
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FTAClientTimeout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTAClientTimeout	String	16	clients timout

Read Variable Response:

```
sRA FTAClientTimeout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTAClientTimeout	String	16	clients timout
Variable Data	data	UInt	2	

Write Variable:

```
sWN FTAClientTimeout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTAClientTimeout	String	16	clients timout
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA FTAClientTimeout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTAClientTimeout	String	16	clients timout

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTAClientTimeout[ETX]`
Read Variable Response:	`[STX]sRA FTAClientTimeout 1E[ETX]`
Write Variable:	`[STX]sWN FTAClientTimeout 1E[ETX]`
Write Variable Response:	`[STX]sWA FTAClientTimeout[ETX]`

2.29.5.7. Variable: FTPArchiveSLocalFileTimeout

The following section contains a detailed description of the variable FTPArchiveSLocalFileTimeout.

Variable Overview

Variable Name	Description
FTPArchiveSLocalFileTimeout	clients timout

Communication Name	FTALocalFileTimeout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	883
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	5
Physical Unit	Min
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN FTALocalFileTimeout`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTALocalFileTimeout	String	19	clients timout

Read Variable Response:

`sRA FTALocalFileTimeout <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTALocalFileTimeout	String	19	clients timout
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FTALocalFileTimeout <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTALocalFileTimeout	String	19	clients timout
Variable Data	data	UInt	2	

Write Variable Response:				
sWA FTALocalFileTimeout				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTALocalFileTimeout	String	19	clients timout

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FTALocalFileTimeout[ETX]
Read Variable Response:	[STX]sRA FTALocalFileTimeout 5[ETX]
Write Variable:	[STX]sWN FTALocalFileTimeout 5[ETX]
Write Variable Response:	[STX]sWA FTALocalFileTimeout[ETX]

2.29.5.8. Variable: FTPArchiveMaxNumObjects

The following section contains a detailed description of the variable FTPArchiveMaxNumObjects.

Variable Overview

Variable Name	Description
FTPArchiveMaxNumObjects	maximum of stored objects

Communication Name	FTAMaxObj
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	884
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	50
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FTAMaxObj`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FTAMaxObj	String	9	maximum of stored objects

Read Variable Response:				
`sRA FTAMaxObj <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FTAMaxObj	String	9	maximum of stored objects
Variable Data	data	UInt	2	

Write Variable:				
`sWN FTAMaxObj <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FTAMaxObj	String	9	maximum of stored objects
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA FTAMaxObj`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FTAMaxObj	String	9	maximum of stored objects

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FTAMaxObj[ETX]`
Read Variable Response:	`[STX]sRA FTAMaxObj 32[ETX]`
Write Variable:	`[STX]sWN FTAMaxObj 32[ETX]`
Write Variable Response:	`[STX]sWA FTAMaxObj[ETX]`

© SICK AG - Germany - All rights reserved

2.29.6. Group: SVP

2.29.6.1. Variable: SVPActive

The following section contains a detailed description of the variable SVPActive.

Variable Overview

Variable Name	Description
SVPActive	Enables SVP

Communication Name	SVPAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	885
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN SVPAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPAct	String	6	Enables SVP

Read Variable Response:

```
sRA SVPAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPAct	String	6	Enables SVP
Variable Data	data	Bool	1	

Write Variable:

```
sWN SVPAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPAct	String	6	Enables SVP
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA SVPAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SVPAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	SVPAct	String	6	Enables SVP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SVPAct[ETX]
Read Variable Response:	[STX]sRA SVPAct 0[ETX]
Write Variable:	[STX]sWN SVPAct 0[ETX]
Write Variable Response:	[STX]sWA SVPAct[ETX]

2.29.6.2. Variable: SVPAppSrvIPAddress

The following section contains a detailed description of the variable SVPAppSrvIPAddress.

Variable Overview

Variable Name	Description
SVPAppSrvIPAddress	IP-Adress of Server for SVP

Communication Name	SVPSvrAdr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	886
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{192,168,0,20}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SVPSvrAdr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPSvrAdr	String	9	IP-Adress of Server for SVP

Read Variable Response:				
`sRA SVPSvrAdr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPSvrAdr	String	9	IP-Adress of Server for SVP
Variable Data	data	Array	4	

Write Variable:				
`sWN SVPSvrAdr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPSvrAdr	String	9	IP-Adress of Server for SVP
Variable Data	data	Array	4	

Write Variable Response:				
`sWA SVPSvrAdr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPSvrAdr	String	9	IP-Adress of Server for SVP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPSvrAdr[ETX]`
Read Variable Response:	`[STX]sRA SVPSvrAdr C0 A8 0 14[ETX]`
Write Variable:	`[STX]sWN SVPSvrAdr C0 A8 0 14[ETX]`
Write Variable Response:	`[STX]sWA SVPSvrAdr[ETX]`

© SICK AG - Germany - All rights reserved

2.29.6.3. Variable: SVPAppSrvIPPort

The following section contains a detailed description of the variable SVPAppSrvIPPort.

Variable Overview

Variable Name	Description
SVPAppSrvIPPort	IP-Port of Server for SVP

Communication Name	SVPSvrPrt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	887
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2008
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SVPSvrPrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPSvrPrt	String	9	IP-Port of Server for SVP

Read Variable Response:

```
sRA SVPSvrPrt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPSvrPrt	String	9	IP-Port of Server for SVP
Variable Data	data	UInt	2	

Write Variable:

```
sWN SVPSvrPrt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPSvrPrt	String	9	IP-Port of Server for SVP
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA SVPSvrPrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPSvrPrt	String	9	IP-Port of Server for SVP

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPSvrPrt[ETX]`
Read Variable Response:	`[STX]sRA SVPSvrPrt 7D8[ETX]`
Write Variable:	`[STX]sWN SVPSvrPrt 7D8[ETX]`
Write Variable Response:	`[STX]sWA SVPSvrPrt[ETX]`

2.29.6.4. Variable: SVPAppSrvIface

The following section contains a detailed description of the variable SVPAppSrvIface.

Variable Overview

Variable Name	Description
SVPAppSrvIface	Ethernet Interface for connection to SVP server

Communication Name	SVPSvrIface
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	888
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ETHERNET0	
	1	TX_ETHERNET1	

Variable Telegram Syntax

Read Variable:				
`sRN SVPSvrIface`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPSvrIface	String	11	Ethernet Interface for connection to SVP server

Read Variable Response:				
`sRA SVPSvrIface <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPSvrIface	String	11	Ethernet Interface for connection to SVP server
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SVPSvrIface <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPSvrIface	String	11	Ethernet Interface for connection to SVP server
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA SVPSvrIface				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPSvrIface	String	11	Ethernet Interface for connection to SVP server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SVPSvrIface[ETX]
Read Variable Response:	[STX]sRA SVPSvrIface 0[ETX]
Write Variable:	[STX]sWN SVPSvrIface 0[ETX]
Write Variable Response:	[STX]sWA SVPSvrIface[ETX]

2.29.6.5. Variable: SVPImageTransfer

The following section contains a detailed description of the variable SVPImageTransfer.

Variable Overview

Variable Name	Description
SVPImageTransfer	Enables SVP image transfer

Communication Name	SVPImg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	889
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SVPImg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPImg	String	6	Enables SVP image transfer

Read Variable Response:				
`sRA SVPImg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPImg	String	6	Enables SVP image transfer
Variable Data	data	Bool	1	

Write Variable:				
`sWN SVPImg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPImg	String	6	Enables SVP image transfer
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SVPImg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPImg	String	6	Enables SVP image transfer

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPImg[ETX]`
Read Variable Response:	`[STX]sRA SVPImg 0[ETX]`
Write Variable:	`[STX]sWN SVPImg 0[ETX]`
Write Variable Response:	`[STX]sWA SVPImg[ETX]`

© SICK AG - Germany - All rights reserved

2.29.6.6. Variable: SVPImgSrvIPAddress

The following section contains a detailed description of the variable SVPImgSrvIPAddress.

Variable Overview

Variable Name	Description
SVPImgSrvIPAddress	IP-Adress SVP image server

Communication Name	SVPImgSrvAdr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	890
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{192,168,0,20}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SVPImgSrvAdr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPImgSrvAdr	String	12	IP-Adress SVP image server

Read Variable Response:

```
sRA SVPImgSrvAdr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPImgSrvAdr	String	12	IP-Adress SVP image server
Variable Data	data	Array	4	

Write Variable:

```
sWN SVPImgSrvAdr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPImgSrvAdr	String	12	IP-Adress SVP image server
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SVPImgSrvAdr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPImgSrvAdr	String	12	IP-Adress SVP image server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SVPImgSrvAdr[ETX]
Read Variable Response:	[STX]sRA SVPImgSrvAdr C0 A8 0 14[ETX]
Write Variable:	[STX]sWN SVPImgSrvAdr C0 A8 0 14[ETX]
Write Variable Response:	[STX]sWA SVPImgSrvAdr[ETX]

2.29.6.7. Variable: SVPImgSrvIPPort

The following section contains a detailed description of the variable SVPImgSrvIPPort.

Variable Overview

Variable Name	Description
SVPImgSrvIPPort	IP-Port of SVP image server

Communication Name	SVPImgSrvPrt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	891
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	2021
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SVPImgSrvPrt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPImgSrvPrt	String	12	IP-Port of SVP image server

Read Variable Response:				
`sRA SVPImgSrvPrt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPImgSrvPrt	String	12	IP-Port of SVP image server
Variable Data	data	UInt	2	

Write Variable:				
`sWN SVPImgSrvPrt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPImgSrvPrt	String	12	IP-Port of SVP image server
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA SVPImgSrvPrt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPImgSrvPrt	String	12	IP-Port of SVP image server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPImgSrvPrt[ETX]`
Read Variable Response:	`[STX]sRA SVPImgSrvPrt 7E5[ETX]`
Write Variable:	`[STX]sWN SVPImgSrvPrt 7E5[ETX]`
Write Variable Response:	`[STX]sWA SVPImgSrvPrt[ETX]`

© SICK AG - Germany - All rights reserved

2.29.6.8. Variable: SVPImgSrvIface

The following section contains a detailed description of the variable SVPImgSrvIface.

Variable Overview

Variable Name	Description
SVPImgSrvIface	Ethernet Interface for connection to SVP server

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	892
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_ETHERNET0	
	1	TX_ETHERNET1	

Variable Telegram Syntax

Read Variable:				
`sRN SVPImgSrvIface`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPImgSrvIface	String	14	Ethernet Interface for connection to SVP server

Read Variable Response:				
`sRA SVPImgSrvIface <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPImgSrvIface	String	14	Ethernet Interface for connection to SVP server
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SVPImgSrvIface <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPImgSrvIface	String	14	Ethernet Interface for connection to SVP server
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SVPImgSrvIface`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPImgSrvIface	String	14	Ethernet Interface for connection to SVP server

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPImgSrvIface[ETX]`
Read Variable Response:	`[STX]sRA SVPImgSrvIface 0[ETX]`
Write Variable:	`[STX]sWN SVPImgSrvIface 0[ETX]`
Write Variable Response:	`[STX]sWA SVPImgSrvIface[ETX]`

2.29.6.9. Variable: SVPImgSrvUsername

The following section contains a detailed description of the variable SVPImgSrvUsername.

Variable Overview

Variable Name	Description
SVPImgSrvUsername	Username of SVP image server

Communication Name	SVPImgSrvUsrNm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	893
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

Variable Telegram Syntax

Read Variable:				
`sRN SVPImgSrvUsrNm`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPImgSrvUsrNm	String	14	Username of SVP image server

Read Variable Response:				
`sRA SVPImgSrvUsrNm <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPImgSrvUsrNm	String	14	Username of SVP image server
Variable Data	data	FlexString	20	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SVPImgSrvUsrNm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPImgSrvUsrNm	String	14	Username of SVP image server
Variable Data	data	FlexString	20	

Write Variable Response:				
sWA SVPImgSrvUsrNm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPImgSrvUsrNm	String	14	Username of SVP image server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SVPImgSrvUsrNm[ETX]
Read Variable Response:	[STX]sRA SVPImgSrvUsrNm 9 anonymous[ETX]
Write Variable:	[STX]sWN SVPImgSrvUsrNm 9 anonymous[ETX]
Write Variable Response:	[STX]sWA SVPImgSrvUsrNm[ETX]

2.29.6.10. Variable: SVPImgSrvPassword

The following section contains a detailed description of the variable SVPImgSrvPassword.

Variable Overview

Variable Name	Description
SVPImgSrvPassword	Password of SVP image server

Communication Name	SVPImgSrvPasWd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	894
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	anonymous

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SVPImgSrvPasWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPImgSrvPasWd	String	14	Password of SVP image server

Read Variable Response:				
`sRA SVPImgSrvPasWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPImgSrvPasWd	String	14	Password of SVP image server
Variable Data	data	FlexString	20	

Write Variable:				
`sWN SVPImgSrvPasWd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPImgSrvPasWd	String	14	Password of SVP image server
Variable Data	data	FlexString	20	

Write Variable Response:				
`sWA SVPImgSrvPasWd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPImgSrvPasWd	String	14	Password of SVP image server

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPImgSrvPasWd[ETX]`
Read Variable Response:	`[STX]sRA SVPImgSrvPasWd 9 anonymous[ETX]`
Write Variable:	`[STX]sWN SVPImgSrvPasWd 9 anonymous[ETX]`
Write Variable Response:	`[STX]sWA SVPImgSrvPasWd[ETX]`

© SICK AG - Germany - All rights reserved

2.29.6.11. Variable: SVPOutputFormat

The following section contains a detailed description of the variable SVPOutputFormat.

Variable Overview

Variable Name	Description
SVPOutputFormat	SVP output format

Communication Name	SVPOutFmt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	895
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_SVP_OUTPUT_FORMAT_1	
	Value	Name	Description
	0	TX_SVP_OUTPUT_NONE	
	1	TX_SVP_OUTPUT_FORMAT_1	
	2	TX_SVP_OUTPUT_FORMAT_2	

Variable Telegram Syntax

Read Variable:

```
sRN SVPOutFmt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPOutFmt	String	9	SVP output format

Read Variable Response:

```
sRA SVPOutFmt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPOutFmt	String	9	SVP output format
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SVPOutFmt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPOutFmt	String	9	SVP output format
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA SVPOutFmt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SVPOutFmt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	SVPOutFmt	String	9	SVP output format

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SVPOutFmt[ETX]
Read Variable Response:	[STX]sRA SVPOutFmt 1[ETX]
Write Variable:	[STX]sWN SVPOutFmt 1[ETX]
Write Variable Response:	[STX]sWA SVPOutFmt[ETX]

2.29.6.12. Variable: SVPSendOnlyErrors

The following section contains a detailed description of the variable SVPSendOnlyErrors.

Variable Overview

Variable Name	Description
SVPSendOnlyErrors	Suppresses warnings when active

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	896
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SVPSendOnlyErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SVPSendOnlyErrors	String	17	Suppresses warnings when active

Read Variable Response:				
`sRA SVPSendOnlyErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SVPSendOnlyErrors	String	17	Suppresses warnings when active
Variable Data	data	Bool	1	

Write Variable:				
`sWN SVPSendOnlyErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SVPSendOnlyErrors	String	17	Suppresses warnings when active
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SVPSendOnlyErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SVPSendOnlyErrors	String	17	Suppresses warnings when active

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SVPSendOnlyErrors[ETX]`
Read Variable Response:	`[STX]sRA SVPSendOnlyErrors 0[ETX]`
Write Variable:	`[STX]sWN SVPSendOnlyErrors 0[ETX]`
Write Variable Response:	`[STX]sWA SVPSendOnlyErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.29.7. Group: HTTP

2.29.7.1. Variable: HTWebserverEnabled

The following section contains a detailed description of the variable HTWebserverEnabled.

Variable Overview

Variable Name	Description
HTWebserverEnabled	Enables HTTP Webserver

Communication Name	HTWSAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	897
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN HTWSAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	HTWSAct	String	7	Enables HTTP Webserver

Read Variable Response:

```
sRA HTWSAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	HTWSAct	String	7	Enables HTTP Webserver
Variable Data	data	Bool	1	

Write Variable:

```
sWN HTWSAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	HTWSAct	String	7	Enables HTTP Webserver
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA HTWSAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA HTWSAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	HTWSAct	String	7	Enables HTTP Webserver

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN HTWSAct[ETX]
Read Variable Response:	[STX]sRA HTWSAct 0[ETX]
Write Variable:	[STX]sWN HTWSAct 0[ETX]
Write Variable Response:	[STX]sWA HTWSAct[ETX]

© SICK AG - Germany - All rights reserved

2.29.8. Group: Gateway

2.29.8.1. Variable: GatewaySerAux

The following section contains a detailed description of the variable GatewaySerAux.

Variable Overview

Variable Name	Description
GatewaySerAux	Defines wether there is a gateway on the serial aux interface

Communication Name	GWSerAuxMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	898
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NONE	
	1	TX_PROFIBUS_DP	
	2	TX_DEVICE_NET	

Variable Telegram Syntax

Read Variable:				
`sRN GWSerAuxMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWSerAuxMd	String	10	Defines wether there is a gateway on the serial aux interface

Read Variable Response:				
`sRA GWSerAuxMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWSerAuxMd	String	10	Defines wether there is a gateway on the serial aux interface
Variable Data	data	Enum8	1	

Write Variable:				
`sWN GWSerAuxMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWSerAuxMd	String	10	Defines wether there is a gateway on the serial aux interface
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA GWSerAuxMd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWSerAuxMd	String	10	Defines wether there is a gateway on the serial aux interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GWSerAuxMd[ETX]
Read Variable Response:	[STX]sRA GWSerAuxMd 0[ETX]
Write Variable:	[STX]sWN GWSerAuxMd 0[ETX]
Write Variable Response:	[STX]sWA GWSerAuxMd[ETX]

2.29.8.2. Variable: GatewaySerHost

The following section contains a detailed description of the variable GatewaySerHost.

Variable Overview

Variable Name	Description
GatewaySerHost	Defines wether there is a gateway on the serial host interface

Communication Name	GWSerHstMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	899
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_NONE	
	1	TX_PROFIBUS_DP	
	2	TX_DEVICE_NET	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GWSerHstMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWSerHstMd	String	10	Defines wether there is a gateway on the serial host interface

Read Variable Response:				
`sRA GWSerHstMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWSerHstMd	String	10	Defines wether there is a gateway on the serial host interface
Variable Data	data	Enum8	1	

Write Variable:				
`sWN GWSerHstMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWSerHstMd	String	10	Defines wether there is a gateway on the serial host interface
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA GWSerHstMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWSerHstMd	String	10	Defines wether there is a gateway on the serial host interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GWSerHstMd[ETX]`
Read Variable Response:	`[STX]sRA GWSerHstMd 0[ETX]`
Write Variable:	`[STX]sWN GWSerHstMd 0[ETX]`
Write Variable Response:	`[STX]sWA GWSerHstMd[ETX]`

© SICK AG - Germany - All rights reserved

2.29.8.3. Variable: GatewayPBDevIDIsPBAdress

The following section contains a detailed description of the variable GatewayPBDevIDIsPBAdress.

Variable Overview

Variable Name	Description
GatewayPBDevIDIsPBAdress	If true, so the device ID is us used as Profilbus address

Communication Name	GWPBdevIDPBAdr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	900
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN GWPBdevIDPBAdr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWPBdevIDPBAdr	String	14	If true, so the device ID is us used as Profilbus address

Read Variable Response:

```
sRA GWPBdevIDPBAdr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWPBdevIDPBAdr	String	14	If true, so the device ID is us used as Profilbus address
Variable Data	data	Bool	1	

Write Variable:

```
sWN GWPBdevIDPBAdr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWPBdevIDPBAdr	String	14	If true, so the device ID is us used as Profilbus address
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA GWPBdevIDPBAdr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA GWPBdevIDPBAdr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	GWPBdevIDPBAdr	String	14	If true, so the device ID is us used as Profilbus address

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GWPBdevIDPBAdr[ETX]
Read Variable Response:	[STX]sRA GWPBdevIDPBAdr 1[ETX]
Write Variable:	[STX]sWN GWPBdevIDPBAdr 1[ETX]
Write Variable Response:	[STX]sWA GWPBdevIDPBAdr[ETX]

2.29.8.4. Variable: GatewayPBAddress

The following section contains a detailed description of the variable GatewayPBAddress.

Variable Overview

Variable Name	Description
GatewayPBAddress	Address of Profibus if device address is not used

Communication Name	GWPBAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	901
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..125
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GWPBAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWPBAddr	String	8	Address of Profibus if device address is not used

Read Variable Response:				
`sRA GWPBAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWPBAddr	String	8	Address of Profibus if device address is not used
Variable Data	data	UInt	2	

Write Variable:				
`sWN GWPBAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWPBAddr	String	8	Address of Profibus if device address is not used
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA GWPBAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWPBAddr	String	8	Address of Profibus if device address is not used

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GWPBAddr[ETX]`
Read Variable Response:	`[STX]sRA GWPBAddr 1[ETX]`
Write Variable:	`[STX]sWN GWPBAddr 1[ETX]`
Write Variable Response:	`[STX]sWA GWPBAddr[ETX]`

© SICK AG - Germany - All rights reserved

2.29.8.5. Variable: GatewayPBOpMode

The following section contains a detailed description of the variable GatewayPBOpMode.

Variable Overview

Variable Name	Description
GatewayPBOpMode	Operating mode of ProfiBUS gateway

Communication Name	GWPBOpMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	902
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_CMF_STD_FORMAT_BYTE_HANDSHAKE	
	1	TX_CMF_STD_FORMAT_NO_BYTE_HANDSHAKE	

Variable Telegram Syntax

Read Variable:

```
sRN GWPBOpMd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWPBOpMd	String	8	Operating mode of ProfiBUS gateway

Read Variable Response:

```
sRA GWPBOpMd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWPBOpMd	String	8	Operating mode of ProfiBUS gateway
Variable Data	data	Enum8	1	

Write Variable:

```
sWN GWPBOpMd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWPBOpMd	String	8	Operating mode of ProfiBUS gateway
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA GWPBOpMd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWPBOpMd	String	8	Operating mode of ProfiBUS gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GWPBOpMd[ETX]
Read Variable Response:	[STX]sRA GWPBOpMd 0[ETX]
Write Variable:	[STX]sWN GWPBOpMd 0[ETX]
Write Variable Response:	[STX]sWA GWPBOpMd[ETX]

2.29.8.6. Variable: GatewayDNAddress

The following section contains a detailed description of the variable GatewayDNAddress.

Variable Overview

Variable Name	Description
GatewayDNAddress	Address of DeviceNet if device address is not used

Communication Name	GWDNAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	903
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..125
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GWDNAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWDNAddr	String	8	Address of DeviceNet if device address is not used

Read Variable Response:				
`sRA GWDNAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWDNAddr	String	8	Address of DeviceNet if device address is not used
Variable Data	data	UInt	2	

Write Variable:				
`sWN GWDNAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWDNAddr	String	8	Address of DeviceNet if device address is not used
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA GWDNAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWDNAddr	String	8	Address of DeviceNet if device address is not used

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GWDNAddr[ETX]`
Read Variable Response:	`[STX]sRA GWDNAddr 1[ETX]`
Write Variable:	`[STX]sWN GWDNAddr 1[ETX]`
Write Variable Response:	`[STX]sWA GWDNAddr[ETX]`

© SICK AG - Germany - All rights reserved

2.29.8.7. Variable: GatewayDNDevIDIsDNAdress

The following section contains a detailed description of the variable GatewayDNDevIDIsDNAdress.

Variable Overview

Variable Name	Description
GatewayDNDevIDIsDNAdress	If true, so the device ID is us used as DeviceNet address

Communication Name	GWDNdevIDDNAdr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	904
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN GWDNdevIDDNAdr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWDNdevIDDNAdr	String	14	If true, so the device ID is us used as DeviceNet address

Read Variable Response:

```
sRA GWDNdevIDDNAdr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWDNdevIDDNAdr	String	14	If true, so the device ID is us used as DeviceNet address
Variable Data	data	Bool	1	

Write Variable:

```
sWN GWDNdevIDDNAdr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWDNdevIDDNAdr	String	14	If true, so the device ID is us used as DeviceNet address
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA GWDNdevIDDNAdr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA GWDNdevIDDNAdr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	GWDNdevIDDNAdr	String	14	If true, so the device ID is us used as DeviceNet address

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GWDNdevIDDNAdr[ETX]
Read Variable Response:	[STX]sRA GWDNdevIDDNAdr 1[ETX]
Write Variable:	[STX]sWN GWDNdevIDDNAdr 1[ETX]
Write Variable Response:	[STX]sWA GWDNdevIDDNAdr[ETX]

2.29.8.8. Variable: GatewayDNOpMode

The following section contains a detailed description of the variable GatewayDNOpMode.

Variable Overview

Variable Name	Description
GatewayDNOpMode	Operating mode of DeviceNet gateway

Communication Name	GWDNOpMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	905
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_CMF_STD_FORMAT_BYTE_HANDSHAKE	
	1	TX_CMF_STD_FORMAT_NO_BYTE_HANDSHAKE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GWDNOpMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWDNOpMd	String	8	Operating mode of DeviceNet gateway

Read Variable Response:				
`sRA GWDNOpMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWDNOpMd	String	8	Operating mode of DeviceNet gateway
Variable Data	data	Enum8	1	

Write Variable:				
`sWN GWDNOpMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWDNOpMd	String	8	Operating mode of DeviceNet gateway
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA GWDNOpMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWDNOpMd	String	8	Operating mode of DeviceNet gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GWDNOpMd[ETX]`
Read Variable Response:	`[STX]sRA GWDNOpMd 0[ETX]`
Write Variable:	`[STX]sWN GWDNOpMd 0[ETX]`
Write Variable Response:	`[STX]sWA GWDNOpMd[ETX]`

© SICK AG - Germany - All rights reserved

2.29.8.9. Variable: GatewayDNBaudrate

The following section contains a detailed description of the variable GatewayDNBaudrate.

Variable Overview

Variable Name	Description
GatewayDNBaudrate	Baudrate DeviceNet gateway

Communication Name	GWDNBdRt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	906
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_125_KBAUD	
	1	TX_250_KBAUD	
	2	TX_500_KBAUD	

Variable Telegram Syntax

Read Variable:

```
sRN GWDNBdRt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWDNBdRt	String	8	Baudrate DeviceNet gateway

Read Variable Response:

```
sRA GWDNBdRt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWDNBdRt	String	8	Baudrate DeviceNet gateway
Variable Data	data	Enum8	1	

Write Variable:

```
sWN GWDNBdRt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWDNBdRt	String	8	Baudrate DeviceNet gateway
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA GWDNBdRt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA GWDNBdRt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	GWDNBdRt	String	8	Baudrate DeviceNet gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GWDNBdRt[ETX]
Read Variable Response:	[STX]sRA GWDNBdRt 0[ETX]
Write Variable:	[STX]sWN GWDNBdRt 0[ETX]
Write Variable Response:	[STX]sWA GWDNBdRt[ETX]

2.29.8.10. Variable: GatewayDNInputDataLength

The following section contains a detailed description of the variable GatewayDNInputDataLength.

Variable Overview

Variable Name	Description
GatewayDNInputDataLength	Input Data length of DeviceNet gateway

Communication Name	GWDNInDtL
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	907
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	8..240
Initialisation	32
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GWDNInDtL`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWDNInDtL	String	9	Input Data length of DeviceNet gateway

Read Variable Response:				
`sRA GWDNInDtL <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWDNInDtL	String	9	Input Data length of DeviceNet gateway
Variable Data	data	USInt	1	

Write Variable:				
`sWN GWDNInDtL <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWDNInDtL	String	9	Input Data length of DeviceNet gateway
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA GWDNInDtL`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWDNInDtL	String	9	Input Data length of DeviceNet gateway

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GWDNInDtL[ETX]`
Read Variable Response:	`[STX]sRA GWDNInDtL 20[ETX]`
Write Variable:	`[STX]sWN GWDNInDtL 20[ETX]`
Write Variable Response:	`[STX]sWA GWDNInDtL[ETX]`

© SICK AG - Germany - All rights reserved

2.29.8.11. Variable: GatewayDNOutputDataLength

The following section contains a detailed description of the variable GatewayDNOutputDataLength.

Variable Overview

Variable Name	Description
GatewayDNOutputDataLength	Output Data length of DeviceNet gateway

Communication Name	GWDNOutDtL
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	908
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	8..240
Initialisation	32
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN GWDNOutDtL
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GWDNOutDtL	String	10	Output Data length of DeviceNet gateway

Read Variable Response:

```
sRA GWDNOutDtL <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GWDNOutDtL	String	10	Output Data length of DeviceNet gateway
Variable Data	data	USInt	1	

Write Variable:

```
sWN GWDNOutDtL <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GWDNOutDtL	String	10	Output Data length of DeviceNet gateway
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA GWDNOutDtL
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GWDNOutDtL	String	10	Output Data length of DeviceNet gateway

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GWDNOutDtL[ETX]`
Read Variable Response:	`[STX]sRA GWDNOutDtL 20[ETX]`
Write Variable:	`[STX]sWN GWDNOutDtL 20[ETX]`
Write Variable Response:	`[STX]sWA GWDNOutDtL[ETX]`

© SICK AG - Germany - All rights reserved

2.29.9. Group: Profibus

2.29.9.1. Variable: CdfProfiCmMode

The following section contains a detailed description of the variable CdfProfiCmMode.

Variable Overview

Variable Name	Description
CdfProfiCmMode	Profibus mode (Mode 1-4)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	909
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_MODE_CDF600_HANDSHAKE	
	Value	Name	Description
	3	TX_MODE_CDF600_HANDSHAKE	
	4	TX_MODE_CDF600_NO_HANDSHAKE	

Variable Telegram Syntax

Read Variable:

```
sRN CdfProfiCmMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfProfiCmMode	String	14	Profibus mode (Mode 1-4)

Read Variable Response:

```
sRA CdfProfiCmMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfProfiCmMode	String	14	Profibus mode (Mode 1-4)
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CdfProfiCmMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfProfiCmMode	String	14	Profibus mode (Mode 1-4)
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfProfiCmMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfProfiCmMode	String	14	Profibus mode (Mode 1-4)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfProfiCmMode[ETX]
Read Variable Response:	[STX]sRA CdfProfiCmMode 3[ETX]
Write Variable:	[STX]sWN CdfProfiCmMode 3[ETX]
Write Variable Response:	[STX]sWA CdfProfiCmMode[ETX]

2.29.9.2. Variable: CdfSelectDataFormat

The following section contains a detailed description of the variable CdfSelectDataFormat.

Variable Overview

Variable Name	Description
CdfSelectDataFormat	Format string for user data

Communication Name	CdfSelDataFrmt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	910
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_NO_OUTPUT	
	1	TX_OUTPUT_FORMAT_DEF_1	
	2	TX_OUTPUT_FORMAT_DEF_2	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CdfSelDataFrmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfSelDataFrmt	String	14	Format string for user data

Read Variable Response:				
`sRA CdfSelDataFrmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfSelDataFrmt	String	14	Format string for user data
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CdfSelDataFrmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfSelDataFrmt	String	14	Format string for user data
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CdfSelDataFrmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfSelDataFrmt	String	14	Format string for user data

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfSelDataFrmt[ETX]`
Read Variable Response:	`[STX]sRA CdfSelDataFrmt 1[ETX]`
Write Variable:	`[STX]sWN CdfSelDataFrmt 1[ETX]`
Write Variable Response:	`[STX]sWA CdfSelDataFrmt[ETX]`

© SICK AG - Germany - All rights reserved

2.29.9.3. Variable: CdfCanMultiplexSend

The following section contains a detailed description of the variable CdfCanMultiplexSend.

Variable Overview

Variable Name	Description
CdfCanMultiplexSend	Enables if CDF sends Multiplexer output data

Communication Name	CdfCanMpxOutEnable
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	911
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CdfCanMpxOutEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfCanMpxOutEnable	String	18	Enables if CDF sends Multiplexer output data

Read Variable Response:

```
sRA CdfCanMpxOutEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfCanMpxOutEnable	String	18	Enables if CDF sends Multiplexer output data
Variable Data	data	Bool	1	

Write Variable:

```
sWN CdfCanMpxOutEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfCanMpxOutEnable	String	18	Enables if CDF sends Multiplexer output data
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CdfCanMpxOutEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfCanMpxOutEnable	String	18	Enables if CDF sends Multiplexer output data

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CdfCanMpxOutEnable[ETX]`
Read Variable Response:	`[STX]sRA CdfCanMpxOutEnable 0[ETX]`
Write Variable:	`[STX]sWN CdfCanMpxOutEnable 0[ETX]`
Write Variable Response:	`[STX]sWA CdfCanMpxOutEnable[ETX]`

2.29.9.4. Variable: Usage_CdfProfibusFhOut1

The following section contains a detailed description of the variable Usage_CdfProfibusFhOut1.

Variable Overview

Variable Name	Description
Usage_CdfProfibusFhOut1	Function for input bit 1 which comes from PLC in the framing header if CDF600 is running in CDF400 mode

Communication Name	PBUsage_CdfFhOut1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	912
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_FUNCTION	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_RD_TRIGGER	
	2	TX_SET_EXTOUT1	
	6	TX_DISTANCE_CONFIG0	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PBUsage_CdfFhOut1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PBUsage_CdfFhOut1	String	17	Function for input bit 1 which comes from PLC in the framing header if CDF600 is running in CDF400 mode

Read Variable Response:				
`sRA PBUsage_CdfFhOut1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PBUsage_CdfFhOut1	String	17	Function for input bit 1 which comes from PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN PBUsage_CdfFhOut1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PBUsage_CdfFhOut1	String	17	Function for input bit 1 which comes from PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA PBUsage_CdfFhOut1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PBUsage_CdfFhOut1	String	17	Function for input bit 1 which comes from PLC in the framing header if CDF600 is running in CDF400 mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PBUsage_CdfFhOut1[ETX]`
Read Variable Response:	`[STX]sRA PBUsage_CdfFhOut1 0[ETX]`
Write Variable:	`[STX]sWN PBUsage_CdfFhOut1 0[ETX]`
Write Variable Response:	`[STX]sWA PBUsage_CdfFhOut1[ETX]`

© SICK AG - Germany - All rights reserved

2.29.9.5. Variable: Usage_CdfProfibusFhOut2

The following section contains a detailed description of the variable Usage_CdfProfibusFhOut2.

Variable Overview

Variable Name	Description
Usage_CdfProfibusFhOut2	Function for bit 2 which comes from PLC in the framing header if CDF600 is running in CDF400 mode

Communication Name	PBUsage_CdfFhOut2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	913
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_FUNCTION	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_RD_TRIGGER	
	2	TX_SET_EXTOUT2	
	6	TX_DISTANCE_CONFIG1	

Variable Telegram Syntax

Read Variable:

```
sRN PBUsage_CdfFhOut2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PBUsage_CdfFhOut2	String	17	Function for bit 2 which comes from PLC in the framing header if CDF600 is running in CDF400 mode

Read Variable Response:

```
sRA PBUsage_CdfFhOut2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PBUsage_CdfFhOut2	String	17	Function for bit 2 which comes from PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

Write Variable:

```
sWN PBUsage_CdfFhOut2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PBUsage_CdfFhOut2	String	17	Function for bit 2 which comes from PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PBUsage_CdfFhOut2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PBUsage_CdfFhOut2	String	17	Function for bit 2 which comes from PLC in the framing header if CDF600 is running in CDF400 mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PBUsage_CdfFhOut2[ETX]
Read Variable Response:	[STX]sRA PBUsage_CdfFhOut2 0[ETX]
Write Variable:	[STX]sWN PBUsage_CdfFhOut2 0[ETX]
Write Variable Response:	[STX]sWA PBUsage_CdfFhOut2[ETX]

2.29.9.6. Variable: Usage_CdfProfibusFhIn1

The following section contains a detailed description of the variable Usage_CdfProfibusFhIn1.

Variable Overview

Variable Name	Description
Usage_CdfProfibusFhIn1	Function for CLV output bit 1 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	914
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_FUNCTION	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_DEV_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_IN1_STATUS	
	6	TX_IN2_STATUS	
	7	TX_EXTIN1_STATUS	
	8	TX_EXTIN2_STATUS	
	9	TX_OUT1_STATUS	
	10	TX_OUT2_STATUS	
	11	TX_EXTOUT1_STATUS	
	12	TX_EXTOUT2_STATUS	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN Usage_CdfProfibusFhIn1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	Usage_CdfProfibusFhIn1	String	22	Function for CLV output bit 1 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode

Read Variable Response:				
`sRA Usage_CdfProfibusFhIn1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	Usage_CdfProfibusFhIn1	String	22	Function for CLV output bit 1 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN Usage_CdfProfibusFhIn1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	Usage_CdfProfibusFhIn1	String	22	Function for CLV output bit 1 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA Usage_CdfProfibusFhIn1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	Usage_CdfProfibusFhIn1	String	22	Function for CLV output bit 1 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN Usage_CdfProfibusFhIn1[ETX]`
Read Variable Response:	`[STX]sRA Usage_CdfProfibusFhIn1 0[ETX]`
Write Variable:	`[STX]sWN Usage_CdfProfibusFhIn1 0[ETX]`
Write Variable Response:	`[STX]sWA Usage_CdfProfibusFhIn1[ETX]`

© SICK AG - Germany - All rights reserved

2.29.9.7. Variable: Usage_CdfProfibusFhIn2

The following section contains a detailed description of the variable Usage_CdfProfibusFhIn2.

Variable Overview

Variable Name	Description
Usage_CdfProfibusFhIn2	Function for CLV output bit 2 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode

Communication Name	PBUsage_CdfFhIn2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	915
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_FUNCTION	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_DEV_READY	
	3	TX_GOOD_READ	
	4	TX_NO_READ	
	5	TX_IN1_STATUS	
	6	TX_IN2_STATUS	
	7	TX_EXTIN1_STATUS	
	8	TX_EXTIN2_STATUS	
	9	TX_OUT1_STATUS	
	10	TX_OUT2_STATUS	
	11	TX_EXTOUT1_STATUS	
	12	TX_EXTOUT2_STATUS	

Variable Telegram Syntax

Read Variable:

```
sRN PBUsage_CdfFhIn2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PBUsage_CdfFhIn2	String	16	Function for CLV output bit 2 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode

Read Variable Response:

```
sRA PBUsage_CdfFhIn2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PBUsage_CdfFhIn2	String	16	Function for CLV output bit 2 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN PBUsage_CdfFhIn2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PBUsage_CdfFhIn2	String	16	Function for CLV output bit 2 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA PBUsage_CdfFhIn2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PBUsage_CdfFhIn2	String	16	Function for CLV output bit 2 which is sent to PLC in the framing header if CDF600 is running in CDF400 mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PBUsage_CdfFhIn2[ETX]
Read Variable Response:	[STX]sRA PBUsage_CdfFhIn2 0[ETX]
Write Variable:	[STX]sWN PBUsage_CdfFhIn2 0[ETX]
Write Variable Response:	[STX]sWA PBUsage_CdfFhIn2[ETX]

© SICK AG - Germany - All rights reserved

2.29.10. Group: Ethercat

2.29.10.1. Variable: CdfEcatCmMode

The following section contains a detailed description of the variable CdfEcatCmMode.

Variable Overview

Variable Name	Description
CdfEcatCmMode	Ethercat mode (only 2 CDF600 modes) --> other parameters like Profibus (no entry here -> see VID)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	916
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_MODE_CDF600_HANDSHAKE	
	Value	Name	Description
	3	TX_MODE_CDF600_HANDSHAKE	
	4	TX_MODE_CDF600_NO_HANDSHAKE	

Variable Telegram Syntax

Read Variable:

```
sRN CdfEcatCmMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CdfEcatCmMode	String	13	Ethercat mode (only 2 CDF600 modes) --> other parameters like Profibus (no entry here -> see VID)

Read Variable Response:

```
sRA CdfEcatCmMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CdfEcatCmMode	String	13	Ethercat mode (only 2 CDF600 modes) --> other parameters like Profibus (no entry here -> see VID)
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CdfEcatCmMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CdfEcatCmMode	String	13	Ethercat mode (only 2 CDF600 modes) --> other parameters like Profibus (no entry here -> see VID)
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CdfEcatCmMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CdfEcatCmMode	String	13	Ethercat mode (only 2 CDF600 modes) --> other parameters like Profibus (no entry here -> see VID)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CdfEcatCmMode[ETX]
Read Variable Response:	[STX]sRA CdfEcatCmMode 3[ETX]
Write Variable:	[STX]sWN CdfEcatCmMode 3[ETX]
Write Variable Response:	[STX]sWA CdfEcatCmMode[ETX]

© SICK AG - Germany - All rights reserved

2.29.11. Group: EthernetIP

2.29.11.1. Variable: EIPAct

The following section contains a detailed description of the variable EIPAct.

Variable Overview

Variable Name	Description
EIPAct	EthernetIP Activated

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	917
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EIPAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPAct	String	6	EthernetIP Activated

Read Variable Response:

```
sRA EIPAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPAct	String	6	EthernetIP Activated
Variable Data	data	Bool	1	

Write Variable:

```
sWN EIPAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPAct	String	6	EthernetIP Activated
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EIPAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPAct	String	6	EthernetIP Activated

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPAct[ETX]`
Read Variable Response:	`[STX]sRA EIPAct 0[ETX]`
Write Variable:	`[STX]sWN EIPAct 0[ETX]`
Write Variable Response:	`[STX]sWA EIPAct[ETX]`

2.29.11.2. Variable: EIPMode

The following section contains a detailed description of the variable EIPMode.

Variable Overview

Variable Name	Description
EIPMode	EthernetIP Mode

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	918
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_EIP_NO_HANDSHAKE	
	1	TX_EIP_HANDSHAKE	

Variable Telegram Syntax

Read Variable:				
`sRN EIPMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPMode	String	7	EthernetIP Mode

Read Variable Response:				
`sRA EIPMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPMode	String	7	EthernetIP Mode
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIPMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPMode	String	7	EthernetIP Mode
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA EIPMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPMode	String	7	EthernetIP Mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIPMode[ETX]
Read Variable Response:	[STX]sRA EIPMode 0[ETX]
Write Variable:	[STX]sWN EIPMode 0[ETX]
Write Variable Response:	[STX]sWA EIPMode[ETX]

2.29.11.3. Variable: EIPMultiplex

The following section contains a detailed description of the variable EIPMultiplex.

Variable Overview

Variable Name	Description
EIPMultiplex	EthernetIP multiplexer activated

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	919
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIPMultiplex`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPMultiplex	String	12	EthernetIP multiplexer activated

Read Variable Response:				
`sRA EIPMultiplex <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPMultiplex	String	12	EthernetIP multiplexer activated
Variable Data	data	Bool	1	

Write Variable:				
`sWN EIPMultiplex <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPMultiplex	String	12	EthernetIP multiplexer activated
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EIPMultiplex`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPMultiplex	String	12	EthernetIP multiplexer activated

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPMultiplex[ETX]`
Read Variable Response:	`[STX]sRA EIPMultiplex 0[ETX]`
Write Variable:	`[STX]sWN EIPMultiplex 0[ETX]`
Write Variable Response:	`[STX]sWA EIPMultiplex[ETX]`

© SICK AG - Germany - All rights reserved

2.29.11.4. Variable: EIPDataFormat

The following section contains a detailed description of the variable EIPDataFormat.

Variable Overview

Variable Name	Description
EIPDataFormat	EthernetIP Mode

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	920
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_EIP_OUTPUT_FORMAT_1	
	1	TX_EIP_OUTPUT_FORMAT_2	
	2	TX_EIP_NO_OUTPUT_FORMAT	

Variable Telegram Syntax

Read Variable:				
`sRN EIPDataFormat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPDataFormat	String	13	EthernetIP Mode

Read Variable Response:				
`sRA EIPDataFormat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPDataFormat	String	13	EthernetIP Mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIPDataFormat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPDataFormat	String	13	EthernetIP Mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIPDataFormat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPDataFormat	String	13	EthernetIP Mode

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPDataFormat[ETX]`
Read Variable Response:	`[STX]sRA EIPDataFormat 0[ETX]`
Write Variable:	`[STX]sWN EIPDataFormat 0[ETX]`
Write Variable Response:	`[STX]sWA EIPDataFormat[ETX]`

2.29.11.5. Variable: EIPControlBitsPlcOutMask

The following section contains a detailed description of the variable EIPControlBitsPlcOutMask.

Variable Overview

Variable Name	Description
EIPControlBitsPlcOutMask	Mask for command Word received by sensor from EthernetIP

Communication Name	EIPCMCtrlOutMask
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	921
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	0xFFFF
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN EIPCMCtrlOutMask`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPCMCtrlOutMask	String	16	Mask for command Word received by sensor from EthernetIP

Read Variable Response:

`sRA EIPCMCtrlOutMask <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPCMCtrlOutMask	String	16	Mask for command Word received by sensor from EthernetIP
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIPCMCtrlOutMask <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPCMCtrlOutMask	String	16	Mask for command Word received by sensor from EthernetIP
Variable Data	data	UInt	2	

Write Variable Response:				
sWA EIPCMCtrlOutMask				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPCMCtrlOutMask	String	16	Mask for command Word received by sensor from EthernetIP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIPCMCtrlOutMask[ETX]
Read Variable Response:	[STX]sRA EIPCMCtrlOutMask FFFF[ETX]
Write Variable:	[STX]sWN EIPCMCtrlOutMask FFFF[ETX]
Write Variable Response:	[STX]sWA EIPCMCtrlOutMask[ETX]

2.29.11.6. Variable: EIPHBEna

The following section contains a detailed description of the variable EIPHBEna.

Variable Overview

Variable Name
EIPHBEna

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	922
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIPHBEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPHBEna	String	8	

Read Variable Response:				
`sRA EIPHBEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPHBEna	String	8	
Variable Data	data	Bool	1	

Write Variable:				
`sWN EIPHBEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPHBEna	String	8	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EIPHBEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPHBEna	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPHBEna[ETX]`
Read Variable Response:	`[STX]sRA EIPHBEna 0[ETX]`
Write Variable:	`[STX]sWN EIPHBEna 0[ETX]`
Write Variable Response:	`[STX]sWA EIPHBEna[ETX]`

© SICK AG - Germany - All rights reserved

2.29.11.7. Variable: EIPHBInterval

The following section contains a detailed description of the variable EIPHBInterval.

Variable Overview

Variable Name
EIPHBInterval

Communication Name	EIPHBInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	923
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..600
Initialisation	30
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EIPHBInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPHBInt	String	8	

Read Variable Response:

```
sRA EIPHBInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPHBInt	String	8	
Variable Data	data	UInt	2	

Write Variable:

```
sWN EIPHBInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPHBInt	String	8	
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA EIPHBInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPHBInt	String	8	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPHBInt[ETX]`
Read Variable Response:	`[STX]sRA EIPHBInt 1E[ETX]`
Write Variable:	`[STX]sWN EIPHBInt 1E[ETX]`
Write Variable Response:	`[STX]sWA EIPHBInt[ETX]`

2.29.11.8. Variable: EIPRetrHB

The following section contains a detailed description of the variable EIPRetrHB.

Variable Overview

Variable Name	Description
EIPRetrHB	Retrigger heartbeat on Ethernet/IP

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	924
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN EIPRetrHB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPRetrHB	String	9	Retrigger heartbeat on Ethernet/IP

Read Variable Response:

```
sRA EIPRetrHB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPRetrHB	String	9	Retrigger heartbeat on Ethernet/IP
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIPRetrHB <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPRetrHB	String	9	Retrigger heartbeat on Ethernet/IP
Variable Data	data	Bool	1	

Write Variable Response:				
sWA EIPRetrHB				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPRetrHB	String	9	Retrigger heartbeat on Ethernet/IP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIPRetrHB[ETX]
Read Variable Response:	[STX]sRA EIPRetrHB 1[ETX]
Write Variable:	[STX]sWN EIPRetrHB 1[ETX]
Write Variable Response:	[STX]sWA EIPRetrHB[ETX]

2.29.11.9. Variable: EIPAssemblySizeOutput

The following section contains a detailed description of the variable EIPAssemblySizeOutput.

Variable Overview

Variable Name
EIPAssemblySizeOutput

Communication Name	EIPAsSizeOut
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	925
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	8..500
Initialisation	200
Physical Unit	Byte
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIPAsSizeOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPAsSizeOut	String	12	

Read Variable Response:				
`sRA EIPAsSizeOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPAsSizeOut	String	12	
Variable Data	data	UInt	2	

Write Variable:				
`sWN EIPAsSizeOut <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPAsSizeOut	String	12	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EIPAsSizeOut`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPAsSizeOut	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPAsSizeOut[ETX]`
Read Variable Response:	`[STX]sRA EIPAsSizeOut C8[ETX]`
Write Variable:	`[STX]sWN EIPAsSizeOut C8[ETX]`
Write Variable Response:	`[STX]sWA EIPAsSizeOut[ETX]`

© SICK AG - Germany - All rights reserved

2.29.11.10. Variable: EIPAssemblySizeInput

The following section contains a detailed description of the variable EIPAssemblySizeInput.

Variable Overview

Variable Name
EIPAssemblySizeInput

Communication Name	EIPAsSizeIn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	926
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	8..500
Initialisation	200
Physical Unit	Byte
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN EIPAsSizeIn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPAsSizeIn	String	11	

Read Variable Response:				
`sRA EIPAsSizeIn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPAsSizeIn	String	11	
Variable Data	data	UInt	2	

Write Variable:				
`sWN EIPAsSizeIn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPAsSizeIn	String	11	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA EIPAsSizeIn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPAsSizeIn	String	11	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPAsSizeIn[ETX]`
Read Variable Response:	`[STX]sRA EIPAsSizeIn C8[ETX]`
Write Variable:	`[STX]sWN EIPAsSizeIn C8[ETX]`
Write Variable Response:	`[STX]sWA EIPAsSizeIn[ETX]`

2.29.11.11. Variable: EIPTxBufferSize

The following section contains a detailed description of the variable EIPTxBufferSize.

Variable Overview

Variable Name
EIPTxBufferSize

Communication Name	EIPTxBufSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	927
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	5..50
Initialisation	30
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EIPTxBufSize
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPTxBufSize	String	12	

Read Variable Response:

```
sRA EIPTxBufSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPTxBufSize	String	12	
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EIPTxBufSize <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPTxBufSize	String	12	
Variable Data	data	USInt	1	

Write Variable Response:				
sWA EIPTxBufSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPTxBufSize	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIPTxBufSize[ETX]
Read Variable Response:	[STX]sRA EIPTxBufSize 1E[ETX]
Write Variable:	[STX]sWN EIPTxBufSize 1E[ETX]
Write Variable Response:	[STX]sWA EIPTxBufSize[ETX]

© SICK AG - Germany - All rights reserved

2.29.12. Group: ModbusTcp

2.29.12.1. Variable: ModbusTcpMode

The following section contains a detailed description of the variable ModbusTcpMode.

Variable Overview

Variable Name	Description
ModbusTcpMode	Modbus/TCP slave mode

Communication Name	MoTcpMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	928
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_MODBUS_DISABLED	
	1	TX_ANYBUS_GATEWAY_EMU	

Variable Telegram Syntax

Read Variable:

```
sRN MoTcpMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MoTcpMode	String	9	Modbus/TCP slave mode

Read Variable Response:

```
sRA MoTcpMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MoTcpMode	String	9	Modbus/TCP slave mode
Variable Data	data	Enum8	1	

Write Variable:

```
sWN MoTcpMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MoTcpMode	String	9	Modbus/TCP slave mode
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA MoTcpMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MoTcpMode	String	9	Modbus/TCP slave mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN MoTcpMode[ETX]
Read Variable Response:	[STX]sRA MoTcpMode 0[ETX]
Write Variable:	[STX]sWN MoTcpMode 0[ETX]
Write Variable Response:	[STX]sWA MoTcpMode[ETX]

2.29.12.2. Variable: ModbusAddress

The following section contains a detailed description of the variable ModbusAddress.

Variable Overview

Variable Name	Description
ModbusAddress	Modbus bus address of Modbus slave

Communication Name	MoTcpAddr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	929
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	1..247
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN MoTcpAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MoTcpAddr	String	9	Modbus bus address of Modbus slave

Read Variable Response:				
`sRA MoTcpAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MoTcpAddr	String	9	Modbus bus address of Modbus slave
Variable Data	data	USInt	1	

Write Variable:				
`sWN MoTcpAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MoTcpAddr	String	9	Modbus bus address of Modbus slave
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA MoTcpAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MoTcpAddr	String	9	Modbus bus address of Modbus slave

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN MoTcpAddr[ETX]`
Read Variable Response:	`[STX]sRA MoTcpAddr 1[ETX]`
Write Variable:	`[STX]sWN MoTcpAddr 1[ETX]`
Write Variable Response:	`[STX]sWA MoTcpAddr[ETX]`

© SICK AG - Germany - All rights reserved

2.29.13. Group: Profinet1Port

2.29.13.1. Variable: PN1PortActive

The following section contains a detailed description of the variable PN1PortActive.

Variable Overview

Variable Name	Description
PN1PortActive	Shows activation of 1-port PN

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	932
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN PN1PortActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PN1PortActive	String	13	Shows activation of 1-port PN

Read Variable Response:

```
sRA PN1PortActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PN1PortActive	String	13	Shows activation of 1-port PN
Variable Data	data	Bool	1	

Write Variable:

```
sWN PN1PortActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PN1PortActive	String	13	Shows activation of 1-port PN
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA PN1PortActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PN1PortActive	String	13	Shows activation of 1-port PN

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PN1PortActive[ETX]`
Read Variable Response:	`[STX]sRA PN1PortActive 0[ETX]`
Write Variable:	`[STX]sWN PN1PortActive 0[ETX]`
Write Variable Response:	`[STX]sWA PN1PortActive[ETX]`

2.29.13.2. Variable: PNAutoDetect

The following section contains a detailed description of the variable PNAutoDetect.

Variable Overview

Variable Name	Description
PNAutoDetect	Enable/Disable out-of-the-box activation of Profinet (Default: True!)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	933
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN PNAutoDetect
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PNAutoDetect	String	12	Enable/Disable out-of-the-box activation of Profinet (Default: True!)

Read Variable Response:

```
sRA PNAutoDetect <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PNAutoDetect	String	12	Enable/Disable out-of-the-box activation of Profinet (Default: True!)
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN PNAutoDetect <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PNAutoDetect	String	12	Enable/Disable out-of-the-box activation of Profinet (Default: True!)
Variable Data	data	Bool	1	

Write Variable Response:				
sWA PNAutoDetect				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PNAutoDetect	String	12	Enable/Disable out-of-the-box activation of Profinet (Default: True!)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PNAutoDetect[ETX]
Read Variable Response:	[STX]sRA PNAutoDetect 1[ETX]
Write Variable:	[STX]sWN PNAutoDetect 1[ETX]
Write Variable Response:	[STX]sWA PNAutoDetect[ETX]

2.29.13.3. Variable: PNAutoDetectTO

The following section contains a detailed description of the variable PNAutoDetectTO.

Variable Overview

Variable Name	Description
PNAutoDetectTO	Timeout for PN autodetect funtion (stops after TO)

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	934
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	3
Physical Unit	Min
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PNAutoDetectTO`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PNAutoDetectTO	String	14	Timeout for PN autodetect funtion (stops after TO)

Read Variable Response:				
`sRA PNAutoDetectTO <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PNAutoDetectTO	String	14	Timeout for PN autodetect funtion (stops after TO)
Variable Data	data	UInt	2	

Write Variable:				
`sWN PNAutoDetectTO <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PNAutoDetectTO	String	14	Timeout for PN autodetect funtion (stops after TO)
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA PNAutoDetectTO`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PNAutoDetectTO	String	14	Timeout for PN autodetect funtion (stops after TO)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PNAutoDetectTO[ETX]`
Read Variable Response:	`[STX]sRA PNAutoDetectTO 3[ETX]`
Write Variable:	`[STX]sWN PNAutoDetectTO 3[ETX]`
Write Variable Response:	`[STX]sWA PNAutoDetectTO[ETX]`

© SICK AG - Germany - All rights reserved

2.29.14. Group: ExternalParameters

2.29.14.1. Variable: UseExtParams

The following section contains a detailed description of the variable UseExtParams.

Variable Overview

Variable Name	Description
UseExtParams	If TRUE a valid parameters set of an external device will be loaded while starting device. If False it will be ignored.

Communication Name	EParUse
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	935
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN EParUse
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EParUse	String	7	If TRUE a valid parameters set of an external device will be loaded while starting device. If False it will be ignored.

Read Variable Response:

```
sRA EParUse <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EParUse	String	7	If TRUE a valid parameters set of an external device will be loaded while starting device. If False it will be ignored.
Variable Data	data	Bool	1	

Write Variable:

```
sWN EParUse <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EParUse	String	7	If TRUE a valid parameters set of an external device will be loaded while starting device. If False it will be ignored.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EParUse				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EParUse	String	7	If TRUE a valid parameters set of an external device will be loaded while starting device. If False it will be ignored.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EParUse[ETX]
Read Variable Response:	[STX]sRA EParUse 1[ETX]
Write Variable:	[STX]sWN EParUse 1[ETX]
Write Variable Response:	[STX]sWA EParUse[ETX]

© SICK AG - Germany - All rights reserved

2.29.15. Group: EthernetInterface1

2.29.15.1. Variable: Ether1Enable

The following section contains a detailed description of the variable Ether1Enable.

Variable Overview

Variable Name
Ether1Enable

Communication Name	EIEnaEth1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	938
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN EIEnaEth1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIEnaEth1	String	9	

Read Variable Response:

```
sRA EIEnaEth1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIEnaEth1	String	9	
Variable Data	data	Bool	1	

Write Variable:

```
sWN EIEnaEth1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIEnaEth1	String	9	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EIEnaEth1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIEnaEth1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EIEnaEth1	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIEnaEth1[ETX]
Read Variable Response:	[STX]sRA EIEnaEth1 1[ETX]
Write Variable:	[STX]sWN EIEnaEth1 1[ETX]
Write Variable Response:	[STX]sWA EIEnaEth1[ETX]

2.29.15.2. Variable: EIPInterface

The following section contains a detailed description of the variable EIPInterface.

Variable Overview

Variable Name	Description
EIPInterface	Selects the ethernet interface for EthernetIP

Communication Name	EIPInterf
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	939
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_INTERFACE_P3	
	Value	Name	Description
	0	TX_INTERFACE_P3	
	1	TX_INTERFACE_P1	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIPInterf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPInterf	String	9	Selects the ethernet interface for EthernetIP

Read Variable Response:				
`sRA EIPInterf <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPInterf	String	9	Selects the ethernet interface for EthernetIP
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIPInterf <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPInterf	String	9	Selects the ethernet interface for EthernetIP
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIPInterf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPInterf	String	9	Selects the ethernet interface for EthernetIP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIPInterf[ETX]`
Read Variable Response:	`[STX]sRA EIPInterf 0[ETX]`
Write Variable:	`[STX]sWN EIPInterf 0[ETX]`
Write Variable Response:	`[STX]sWA EIPInterf[ETX]`

© SICK AG - Germany - All rights reserved

2.29.15.3. Variable: Ether1AuxInputHandling

The following section contains a detailed description of the variable Ether1AuxInputHandling.

Variable Overview

Variable Name	Description
Ether1AuxInputHandling	Handling method for Input data on Ethernet Aux interface

Communication Name	EI1AuxInp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	940
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_INPUT_DATA	
	Value	Name	Description
	0	TX_NO_INPUT_DATA	
	1	TX_INPUT_DATA_FORWARDING	
	2	TX_INPUT_DATA_AUXRESULT	
	3	TX_INPUT_DATA_STRING_FOR_OUTFORMAT	

Variable Telegram Syntax

Read Variable:

```
sRN EI1AuxInp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EI1AuxInp	String	9	Handling method for Input data on Ethernet Aux interface

Read Variable Response:

```
sRA EI1AuxInp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EI1AuxInp	String	9	Handling method for Input data on Ethernet Aux interface
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EI1AuxInp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EI1AuxInp	String	9	Handling method for Input data on Ethernet Aux interface
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EI1AuxInp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EI1AuxInp	String	9	Handling method for Input data on Ethernet Aux interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EI1AuxInp[ETX]
Read Variable Response:	[STX]sRA EI1AuxInp 0[ETX]
Write Variable:	[STX]sWN EI1AuxInp 0[ETX]
Write Variable Response:	[STX]sWA EI1AuxInp[ETX]

© SICK AG - Germany - All rights reserved

2.29.16. Group: SystemControlLector65x

2.29.16.1. Method: LoadApplicationDefaultsSystemSlave

The following section contains a detailed description of the method LoadApplicationDefaultsSystemSlave.

Method Overview

Method Name	Description
LoadApplicationDefaultsSystemSlave	The method resets all application relevant variables to their tracking default value, See also method LoadApplicationDefaults

Communication Name	mSCloadappdefsysslave
Sopas Index	109
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mSCloadappdefsysslave`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSCloadappdefsysslave	String	21	The method resets all application relevant variables to their tracking default value, See also method LoadApplicationDefaults

Method Return Value:				
`sAN mSCloadappdefsysslave`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSCloadappdefsysslave	String	21	The method resets all application relevant variables to their tracking default value, See also method LoadApplicationDefaults

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSCloadappdefsysslave[ETX]`
Method Return Value:	`[STX]sAN mSCloadappdefsysslave[ETX]`

© SICK AG - Germany - All rights reserved

2.29.17. Group: CDPMethods

2.29.17.1. Method: Method_4

The following section contains a detailed description of the method Method_4.

Method Overview

Method Name
Method_4

Sopas Index	110
Invocation Access	Always

Return Values	
NMTOKEN	
Bool	
Value Range	False, True
Initialisation	True

Method Telegram Syntax

Method Invocation:				
`sMN Method_4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	Method_4	String	8	

Method Return Value:				
`sAN Method_4 <NMTOKEN>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	Method_4	String	8	
Return Value 1	NMTOKEN	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN Method_4[ETX]`
Method Return Value:	`[STX]sAN Method_4 1[ETX]`

© SICK AG - Germany - All rights reserved

2.29.18. Group: Script

2.29.18.1. Variable: EnableActiveScript

The following section contains a detailed description of the variable EnableActiveScript.

Variable Overview

Variable Name
EnableActiveScript

Communication Name	AScriptEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	941
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN AScriptEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	AScriptEna	String	10	

Read Variable Response:

```
sRA AScriptEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	AScriptEna	String	10	
Variable Data	data	Bool	1	

Write Variable:

```
sWN AScriptEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	AScriptEna	String	10	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA AScriptEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA AScriptEna				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	AScriptEna	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN AScriptEna[ETX]
Read Variable Response:	[STX]sRA AScriptEna 0[ETX]
Write Variable:	[STX]sWN AScriptEna 0[ETX]
Write Variable Response:	[STX]sWA AScriptEna[ETX]

2.29.18.2. Method: ScriptCommand

The following section contains a detailed description of the method ScriptCommand.

Method Overview

Method Name	Description
ScriptCommand	Runs a Script command

Communication Name	mScrptCmd
Sopas Index	111
Invocation Access	Always

Parameters	
SLCmd	
FlexString	
Length	0..200
Initialisation	

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mScrptCmd <SLCmd>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mScrptCmd	String	9	Runs a Script command
Parameter 1	SLCmd	FlexString	200	

Method Return Value:				
`sAN mScrptCmd <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mScrptCmd	String	9	Runs a Script command
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mScrptCmd 0[ETX]`
Method Return Value:	`[STX]sAN mScrptCmd 0[ETX]`

© SICK AG - Germany - All rights reserved

2.29.19. Group: NetworkAddressTranslation

2.29.19.1. Variable: IpAddressChoiceForImageTransmission

The following section contains a detailed description of the variable IpAddressChoiceForImageTransmission.

Variable Overview

Variable Name	Description
IpAddressChoiceForImageTransmission	Choice of user, which ip address to use for image transmission

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	945
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		TX_DEFAULT	
	Value	Name	Description
	0	TX_DEFAULT	
	1	TX_EXPLICIT	
	2	TX_COLACONNECTION	

Variable Telegram Syntax

Read Variable:

```
sRN IpAddressChoiceForImageTransmission
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	IpAddressChoiceForImageTransmission	String	35	Choice of user, which ip address to use for image transmission

Read Variable Response:

```
sRA IpAddressChoiceForImageTransmission <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	IpAddressChoiceForImageTransmission	String	35	Choice of user, which ip address to use for image transmission
Variable Data	data	Enum8	1	

Write Variable:

```
sWN IpAddressChoiceForImageTransmission <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	IpAddressChoiceForImageTransmission	String	35	Choice of user, which ip address to use for image transmission
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA IpAddressChoiceForImageTransmission				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	IpAddressChoiceForImageTransmission	String	35	Choice of user, which ip address to use for image transmission

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN IpAddressChoiceForImageTransmission[ETX]
Read Variable Response:	[STX]sRA IpAddressChoiceForImageTransmission 0[ETX]
Write Variable:	[STX]sWN IpAddressChoiceForImageTransmission 0[ETX]
Write Variable Response:	[STX]sWA IpAddressChoiceForImageTransmission[ETX]

2.29.19.2. Variable: TcpPortChoiceForImageTransmission

The following section contains a detailed description of the variable TcpPortChoiceForImageTransmission.

Variable Overview

Variable Name	Description
TcpPortChoiceForImageTransmission	Choice of user, which port to use for image transmission

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	946
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEFAULT	
	Value	Name	Description
	0	TX_DEFAULT	
	1	TX_EXPLICIT	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TcpPortChoiceForImageTransmission`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TcpPortChoiceForImageTransmission	String	33	Choice of user, which port to use for image transmission

Read Variable Response:				
`sRA TcpPortChoiceForImageTransmission <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TcpPortChoiceForImageTransmission	String	33	Choice of user, which port to use for image transmission
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TcpPortChoiceForImageTransmission <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TcpPortChoiceForImageTransmission	String	33	Choice of user, which port to use for image transmission
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA TcpPortChoiceForImageTransmission`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TcpPortChoiceForImageTransmission	String	33	Choice of user, which port to use for image transmission

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TcpPortChoiceForImageTransmission[ETX]`
Read Variable Response:	`[STX]sRA TcpPortChoiceForImageTransmission 0[ETX]`
Write Variable:	`[STX]sWN TcpPortChoiceForImageTransmission 0[ETX]`
Write Variable Response:	`[STX]sWA TcpPortChoiceForImageTransmission[ETX]`

© SICK AG - Germany - All rights reserved

2.29.19.3. Variable: ManualBlobIpAddress

The following section contains a detailed description of the variable ManualBlobIpAddress.

Variable Overview

Variable Name	Description
ManualBlobIpAddress	IP address of the device before altered by the first NAT router. Has to be inserted manually.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	947
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{192,168,0,1}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ManualBlobIpAddress
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ManualBlobIpAddress	String	19	IP address of the device before altered by the first NAT router. Has to be inserted manually.

Read Variable Response:

```
sRA ManualBlobIpAddress <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ManualBlobIpAddress	String	19	IP address of the device before altered by the first NAT router. Has to be inserted manually.
Variable Data	data	Array	4	

Write Variable:

```
sWN ManualBlobIpAddress <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ManualBlobIpAddress	String	19	IP address of the device before altered by the first NAT router. Has to be inserted manually.
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ManualBlobIpAddress				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ManualBlobIpAddress	String	19	IP address of the device before altered by the first NAT router. Has to be inserted manually.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ManualBlobIpAddress[ETX]
Read Variable Response:	[STX]sRA ManualBlobIpAddress C0 A8 0 1[ETX]
Write Variable:	[STX]sWN ManualBlobIpAddress C0 A8 0 1[ETX]
Write Variable Response:	[STX]sWA ManualBlobIpAddress[ETX]

2.29.19.4. Variable: ManualBlobTcpPort

The following section contains a detailed description of the variable ManualBlobTcpPort.

Variable Overview

Variable Name	Description
ManualBlobTcpPort	Tcp port of the device before altered by a NAT router. Has to be inserted manually.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	948
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..65535
Initialisation	2113
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ManualBlobTcpPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ManualBlobTcpPort	String	17	Tcp port of the device before altered by a NAT router. Has to be inserted manually.

Read Variable Response:				
`sRA ManualBlobTcpPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ManualBlobTcpPort	String	17	Tcp port of the device before altered by a NAT router. Has to be inserted manually.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN ManualBlobTcpPort <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ManualBlobTcpPort	String	17	Tcp port of the device before altered by a NAT router. Has to be inserted manually.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA ManualBlobTcpPort`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ManualBlobTcpPort	String	17	Tcp port of the device before altered by a NAT router. Has to be inserted manually.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ManualBlobTcpPort[ETX]`
Read Variable Response:	`[STX]sRA ManualBlobTcpPort 841[ETX]`
Write Variable:	`[STX]sWN ManualBlobTcpPort 841[ETX]`
Write Variable Response:	`[STX]sWA ManualBlobTcpPort[ETX]`

© SICK AG - Germany - All rights reserved

2.30. Interface Block: CdpApiBlock

2.30.1. Group: CdpApiVariables

2.30.1.1. Variable: cdpFbCommStatusReg

The following section contains a detailed description of the variable cdpFbCommStatusReg.

Variable Overview

Variable Name
cdpFbCommStatusReg

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	949
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		BOOT	
	Value	Name	Description
	0	BOOT	
	1	IDLE	
	2	READY	
	3	PARAM_FINISHED	
	4	ONLINE	
	5	OFFLINE	
	255	FATAL_ERROR	

Variable Telegram Syntax

Read Variable:				
`sRN cdpFbCommStatusReg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpFbCommStatusReg	String	18	

Read Variable Response:				
`sRA cdpFbCommStatusReg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpFbCommStatusReg	String	18	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN cdpFbCommStatusReg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpFbCommStatusReg	String	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpFbCommStatusReg <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA cdpFbCommStatusReg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpFbCommStatusReg	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpFbCommStatusReg[ETX]
Read Variable Response:	[STX]sRA cdpFbCommStatusReg 0[ETX]
Write Variable:	[STX]sWN cdpFbCommStatusReg 0[ETX]
Write Variable Response:	[STX]sWA cdpFbCommStatusReg[ETX]

2.30.1.2. Variable: cdpCmdReg

The following section contains a detailed description of the variable cdpCmdReg.

Variable Overview

Variable Name
cdpCmdReg

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	950
Read-Access	Always
Write-Access	Service

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpCmdReg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmdReg	String	9	

Read Variable Response:				
`sRA cdpCmdReg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmdReg	String	9	
Variable Data	data	USInt	1	

Write Variable:				
`sWN cdpCmdReg <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmdReg	String	9	
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA cdpCmdReg`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmdReg	String	9	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpCmdReg[ETX]`
Read Variable Response:	`[STX]sRA cdpCmdReg 0[ETX]`
Write Variable:	`[STX]sWN cdpCmdReg 0[ETX]`
Write Variable Response:	`[STX]sWA cdpCmdReg[ETX]`

© SICK AG - Germany - All rights reserved

2.30.1.3. Variable: cdpResStatusReg

The following section contains a detailed description of the variable cdpResStatusReg.

Variable Overview

Variable Name
cdpResStatusReg

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	951
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpResStatusReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpResStatusReg	String	15	

Read Variable Response:

```
sRA cdpResStatusReg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpResStatusReg	String	15	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpResStatusReg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpResStatusReg	String	15	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpResStatusReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpResStatusReg	String	15	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpResStatusReg[ETX]`
Read Variable Response:	`[STX]sRA cdpResStatusReg 0[ETX]`
Write Variable:	`[STX]sWN cdpResStatusReg 0[ETX]`
Write Variable Response:	`[STX]sWA cdpResStatusReg[ETX]`

2.30.1.4. Variable: cdpEndianCheck

The following section contains a detailed description of the variable cdpEndianCheck.

Variable Overview

Variable Name
cdpEndianCheck

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	952
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	4660
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN cdpEndianCheck`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpEndianCheck	String	14	

Read Variable Response:

`sRA cdpEndianCheck <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpEndianCheck	String	14	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN cdpEndianCheck <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpEndianCheck	String	14	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA cdpEndianCheck`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpEndianCheck	String	14	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpEndianCheck[ETX]`
Read Variable Response:	`[STX]sRA cdpEndianCheck 1234[ETX]`
Write Variable:	`[STX]sWN cdpEndianCheck 1234[ETX]`
Write Variable Response:	`[STX]sWA cdpEndianCheck[ETX]`

© SICK AG - Germany - All rights reserved

2.30.2. Group: CdpApiTracerVariables

2.30.2.1. Variable: cdpApiTracerMode

The following section contains a detailed description of the variable cdpApiTracerMode.

Variable Overview

Variable Name
cdpApiTracerMode

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	953
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		FIFO	
	Value	Name	Description
	0	LEASH	
	1	ONE_SHOT	
	2	FIFO	

Variable Telegram Syntax

Read Variable:				
`sRN cdpApiTracerMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpApiTracerMode	String	16	

Read Variable Response:				
`sRA cdpApiTracerMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpApiTracerMode	String	16	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN cdpApiTracerMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpApiTracerMode	String	16	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpApiTracerMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpApiTracerMode	String	16	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpApiTracerMode[ETX]
Read Variable Response:	[STX]sRA cdpApiTracerMode 2[ETX]
Write Variable:	[STX]sWN cdpApiTracerMode 2[ETX]
Write Variable Response:	[STX]sWA cdpApiTracerMode[ETX]

2.30.2.2. Variable: cdpApiTracerCommProc

The following section contains a detailed description of the variable cdpApiTracerCommProc.

Variable Overview

Variable Name
cdpApiTracerCommProc

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	954
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpApiTracerCommProc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpApiTracerCommProc	String	20	

Read Variable Response:				
`sRA cdpApiTracerCommProc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpApiTracerCommProc	String	20	
Variable Data	data	Bool	1	

Write Variable:				
`sWN cdpApiTracerCommProc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpApiTracerCommProc	String	20	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA cdpApiTracerCommProc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpApiTracerCommProc	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpApiTracerCommProc[ETX]`
Read Variable Response:	`[STX]sRA cdpApiTracerCommProc 0[ETX]`
Write Variable:	`[STX]sWN cdpApiTracerCommProc 0[ETX]`
Write Variable Response:	`[STX]sWA cdpApiTracerCommProc[ETX]`

© SICK AG - Germany - All rights reserved

2.30.2.3. Variable: cdpApiTracerEnabled

The following section contains a detailed description of the variable cdpApiTracerEnabled.

Variable Overview

Variable Name
cdpApiTracerEnabled

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	955
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN cdpApiTracerEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpApiTracerEnabled	String	19	

Read Variable Response:

```
sRA cdpApiTracerEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpApiTracerEnabled	String	19	
Variable Data	data	Bool	1	

Write Variable:

```
sWN cdpApiTracerEnabled <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpApiTracerEnabled	String	19	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA cdpApiTracerEnabled
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpApiTracerEnabled	String	19	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpApiTracerEnabled[ETX]`
Read Variable Response:	`[STX]sRA cdpApiTracerEnabled 0[ETX]`
Write Variable:	`[STX]sWN cdpApiTracerEnabled 0[ETX]`
Write Variable Response:	`[STX]sWA cdpApiTracerEnabled[ETX]`

2.30.2.4. Variable: cdpApiTracerMaxRecords

The following section contains a detailed description of the variable cdpApiTracerMaxRecords.

Variable Overview

Variable Name
cdpApiTracerMaxRecords

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	956
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	5000
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpApiTracerMaxRecords
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpApiTracerMaxRecords	String	22	

Read Variable Response:

```
sRA cdpApiTracerMaxRecords <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpApiTracerMaxRecords	String	22	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpApiTracerMaxRecords <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpApiTracerMaxRecords	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpApiTracerMaxRecords				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpApiTracerMaxRecords	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpApiTracerMaxRecords[ETX]
Read Variable Response:	[STX]sRA cdpApiTracerMaxRecords 1388[ETX]
Write Variable:	[STX]sWN cdpApiTracerMaxRecords 1388[ETX]
Write Variable Response:	[STX]sWA cdpApiTracerMaxRecords[ETX]

2.30.2.5. Variable: cdpApiTracerCycleThresholdUpperUs

The following section contains a detailed description of the variable cdpApiTracerCycleThresholdUpperUs.

Variable Overview

Variable Name
cdpApiTracerCycleThresholdUpperUs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	957
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpApiTracerCycleThresholdUpperUs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpApiTracerCycleThresholdUpperUs	String	33	

Read Variable Response:				
`sRA cdpApiTracerCycleThresholdUpperUs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpApiTracerCycleThresholdUpperUs	String	33	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpApiTracerCycleThresholdUpperUs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpApiTracerCycleThresholdUpperUs	String	33	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpApiTracerCycleThresholdUpperUs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpApiTracerCycleThresholdUpperUs	String	33	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpApiTracerCycleThresholdUpperUs[ETX]`
Read Variable Response:	`[STX]sRA cdpApiTracerCycleThresholdUpperUs 0[ETX]`
Write Variable:	`[STX]sWN cdpApiTracerCycleThresholdUpperUs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpApiTracerCycleThresholdUpperUs[ETX]`

© SICK AG - Germany - All rights reserved

2.30.2.6. Variable: cdpApiTracerCycleThresholdLowerUs

The following section contains a detailed description of the variable cdpApiTracerCycleThresholdLowerUs.

Variable Overview

Variable Name
cdpApiTracerCycleThresholdLowerUs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	958
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpApiTracerCycleThresholdLowerUs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpApiTracerCycleThresholdLowerUs	String	33	

Read Variable Response:

```
sRA cdpApiTracerCycleThresholdLowerUs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpApiTracerCycleThresholdLowerUs	String	33	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpApiTracerCycleThresholdLowerUs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpApiTracerCycleThresholdLowerUs	String	33	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpApiTracerCycleThresholdLowerUs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpApiTracerCycleThresholdLowerUs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpApiTracerCycleThresholdLowerUs	String	33	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpApiTracerCycleThresholdLowerUs[ETX]
Read Variable Response:	[STX]sRA cdpApiTracerCycleThresholdLowerUs 0[ETX]
Write Variable:	[STX]sWN cdpApiTracerCycleThresholdLowerUs 0[ETX]
Write Variable Response:	[STX]sWA cdpApiTracerCycleThresholdLowerUs[ETX]

© SICK AG - Germany - All rights reserved

2.30.3. Group: CdpApiEvents

2.30.3.1. Event: cdpApiErrorEvent

The following section contains a detailed description of the event cdpApiErrorEvent.

Event Overview

Event Name
cdpApiErrorEvent

Sopas Index	219
Queue Length	1

Parameters		
ERRORID		
	UDInt	
	Value Range	0..4294967295
ERRORSTATE		
	Bool	
	Value Range	False, True
	Initialisation	True

2.30.3.2. Event: cdpApiWarningEvent

The following section contains a detailed description of the event cdpApiWarningEvent.

Event Overview

Event Name
cdpApiWarningEvent

Sopas Index	220
Queue Length	1

Parameters		
WARNINGID		
	UDInt	
	Value Range	0..4294967295
WARNINGSTATE		
	Bool	
	Value Range	False, True
	Initialisation	True

© SICK AG - Germany - All rights reserved

2.30.3.3. Event: cdpApiRstToFactorySettingsEvent

The following section contains a detailed description of the event cdpApiRstToFactorySettingsEvent.

Event Overview

Event Name
cdpApiRstToFactorySettingsEvent

Sopas Index	221
Queue Length	1

Parameters		
RESET		
	Bool	
	Value Range	False, True
	Initialisation	True

© SICK AG - Germany - All rights reserved

2.30.4. Group: CDPApiMethodes

2.30.4.1. Method: cdpApiStoreParams

The following section contains a detailed description of the method cdpApiStoreParams.

Method Overview

Method Name
cdpApiStoreParams

Sopas Index	112
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN cdpApiStoreParams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	cdpApiStoreParams	String	17	

Method Return Value:				
`sAN cdpApiStoreParams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	cdpApiStoreParams	String	17	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN cdpApiStoreParams[ETX]`
Method Return Value:	`[STX]sAN cdpApiStoreParams[ETX]`

© SICK AG - Germany - All rights reserved

2.30.4.2. Method: cdpApiUpDateDiagExt

The following section contains a detailed description of the method cdpApiUpDateDiagExt.

Method Overview

Method Name	Description
cdpApiUpDateDiagExt	Updates the extended diagnose data

Communication Name	mcdpApiUpDateDiagExt
Sopas Index	113
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mcdpApiUpDateDiagExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mcdpApiUpDateDiagExt	String	20	Updates the extended diagnose data

Method Return Value:				
`sAN mcdpApiUpDateDiagExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mcdpApiUpDateDiagExt	String	20	Updates the extended diagnose data

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mcdpApiUpDateDiagExt[ETX]`
Method Return Value:	`[STX]sAN mcdpApiUpDateDiagExt[ETX]`

© SICK AG - Germany - All rights reserved

2.30.5. Group: CDPApiTracerMethodes

2.30.5.1. Method: cdpApiRequestTracepointInfo

The following section contains a detailed description of the method cdpApiRequestTracepointInfo.

Method Overview

Method Name	Description
cdpApiRequestTracepointInfo	Requests the information about the CDP trace points declared within the system

Sopas Index	114
Invocation Access	Service

Parameters		
StartTPNo		
	UDInt	
	Value Range	0..4294967295
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

Return Values			
NumOfTPs			
	UDInt		
	Value Range		0..4294967295
	Initialisation		0
	Physical Unit		
	Physical Unit Factor		0.0
TPNo			index of the TP
	Array		
	Length		256
		UDInt	
		Value Range	0..4294967295
		Initialisation	
		Physical Unit	
		Physical Unit Factor	0.0
TPNameArray			
	Array		
	Length		256
		FlexString	
		Length	0..128
		Initialisation	
TPState			States of the TP: enabled, disabled
	Array		
	Length		256
		FlexString	
		Length	0..12
		Initialisation	

© SICK AG - Germany - All rights reserved

Return Values		
TPType		Type of the TP: start, stop, toggle
	Array	
	Length	256
		FlexString
		Length: 0..12
		Initialisation:

Method Telegram Syntax

Method Invocation:

```
sMN cdpApiRequestTracepointInfo <StartTPNo>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	cdpApiRequestTracepointInfo	String	27	Requests the information about the CDP trace points declared within the system
Parameter 1	StartTPNo	UDInt	4	

Method Return Value:

```
sAN cdpApiRequestTracepointInfo <NumOfTPs> <TPNo> <TPNameArray> <TPState> <TPType>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	cdpApiRequestTracepointInfo	String	27	Requests the information about the CDP trace points declared within the system
Return Value 1	NumOfTPs	UDInt	4	
Return Value 2	TPNo	Array	1024	index of the TP
Return Value 3	TPNameArray	Array	32768	
Return Value 4	TPState	Array	3072	States of the TP: enabled, disabled
Return Value 5	TPType	Array	3072	Type of the TP: start, stop, toggle

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:

```
[STX]sMN cdpApiRequestTracepointInfo 0[ETX]
```


© SICK AG - Germany - All rights reserved

Method Return Value:	[STX]sAN cdpApiRequestTracepointInfo 0 0 0

Parameters			
Enable			
	Bool		
	Value Range	False, True	
	Initialisation	False	
Property			
	Enum8		
	Default Value	DEFAULT	
	Value	Name	Description
	0	DEFAULT	
	2	TP_PROP_START	
	4	TP_PROP_STOP	
	8	TP_PROP_TOGGLE	

Method Telegram Syntax

Method Invocation:
`sMN cdpApiTracerSetTPProp <TPNoFrom> <TPNoTo> <Enable> <Property>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	cdpApiTracerSetTPProp	String	21	Sets the properties of the tracer
Parameter 1	TPNoFrom	UDInt	4	
Parameter 2	TPNoTo	UDInt	4	
Parameter 3	Enable	Bool	1	
Parameter 4	Property	Enum8	1	

Method Return Value:
`sAN cdpApiTracerSetTPProp`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	cdpApiTracerSetTPProp	String	21	Sets the properties of the tracer

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN cdpApiTracerSetTPProp 0 0 0 0[ETX]`
Method Return Value:	`[STX]sAN cdpApiTracerSetTPProp[ETX]`

© SICK AG - Germany - All rights reserved

2.31. Interface Block: Profinet_Address_FBParam

2.31.1. Group: Profinet_Address_ParamData_grp

2.31.1.1. Variable: cdpPnioStationName

The following section contains a detailed description of the variable cdpPnioStationName.

Variable Overview

Variable Name
cdpPnioStationName

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	968
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..240
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioStationName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioStationName	String	18	

Read Variable Response:

```
sRA cdpPnioStationName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioStationName	String	18	
Variable Data	data	FlexString	240	

Write Variable:

```
sWN cdpPnioStationName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioStationName	String	18	
Variable Data	data	FlexString	240	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioStationName				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioStationName	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioStationName[ETX]
Read Variable Response:	[STX]sRA cdpPnioStationName 0[ETX]
Write Variable:	[STX]sWN cdpPnioStationName 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioStationName[ETX]

2.31.1.2. Variable: cdpPnioIpAddressType

The following section contains a detailed description of the variable cdpPnioIpAddressType.

Variable Overview

Variable Name
cdpPnioIpAddressType

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	969
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..240
Initialisation	Permanent

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioIpAddressType`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIpAddressType	String	20	

Read Variable Response:				
`sRA cdpPnioIpAddressType <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIpAddressType	String	20	
Variable Data	data	FlexString	240	

Write Variable:				
`sWN cdpPnioIpAddressType <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIpAddressType	String	20	
Variable Data	data	FlexString	240	

Write Variable Response:				
`sWA cdpPnioIpAddressType`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIpAddressType	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioIpAddressType[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioIpAddressType 9 Permanent[ETX]`
Write Variable:	`[STX]sWN cdpPnioIpAddressType 9 Permanent[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioIpAddressType[ETX]`

© SICK AG - Germany - All rights reserved

2.31.1.3. Variable: cdpPnioIpAddress

The following section contains a detailed description of the variable cdpPnioIpAddress.

Variable Overview

Variable Name
cdpPnioIpAddress

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	970
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{192,168,0,123}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:
`sRN cdpPnioIpAddress`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIpAddress	String	16	

Read Variable Response:
`sRA cdpPnioIpAddress <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIpAddress	String	16	
Variable Data	data	Array	4	

Write Variable:
`sWN cdpPnioIpAddress <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIpAddress	String	16	
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioIpAddress				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIpAddress	String	16	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioIpAddress[ETX]
Read Variable Response:	[STX]sRA cdpPnioIpAddress C0 A8 0 7B[ETX]
Write Variable:	[STX]sWN cdpPnioIpAddress C0 A8 0 7B[ETX]
Write Variable Response:	[STX]sWA cdpPnioIpAddress[ETX]

2.31.1.4. Variable: cdpPnioSubNetMaskAddr

The following section contains a detailed description of the variable cdpPnioSubNetMaskAddr.

Variable Overview

Variable Name
cdpPnioSubNetMaskAddr

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	971
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{255,255,255,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioSubNetMaskAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioSubNetMaskAddr	String	21	

Read Variable Response:				
`sRA cdpPnioSubNetMaskAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioSubNetMaskAddr	String	21	
Variable Data	data	Array	4	

Write Variable:				
`sWN cdpPnioSubNetMaskAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioSubNetMaskAddr	String	21	
Variable Data	data	Array	4	

Write Variable Response:				
`sWA cdpPnioSubNetMaskAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioSubNetMaskAddr	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioSubNetMaskAddr[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioSubNetMaskAddr FF FF FF 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioSubNetMaskAddr FF FF FF 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioSubNetMaskAddr[ETX]`

© SICK AG - Germany - All rights reserved

2.31.1.5. Variable: cdpPnioGateWayAddr

The following section contains a detailed description of the variable cdpPnioGateWayAddr.

Variable Overview

Variable Name
cdpPnioGateWayAddr

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	972
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioGateWayAddr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioGateWayAddr	String	18	

Read Variable Response:				
`sRA cdpPnioGateWayAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioGateWayAddr	String	18	
Variable Data	data	Array	4	

Write Variable:				
`sWN cdpPnioGateWayAddr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioGateWayAddr	String	18	
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioGateWayAddr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioGateWayAddr	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioGateWayAddr[ETX]
Read Variable Response:	[STX]sRA cdpPnioGateWayAddr 0 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioGateWayAddr 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioGateWayAddr[ETX]

2.31.1.6. Variable: cdpPnioPLCSetNameRemanent

The following section contains a detailed description of the variable cdpPnioPLCSetNameRemanent.

Variable Overview

Variable Name
cdpPnioPLCSetNameRemanent

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	973
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioPLCSetNameRemanent`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioPLCSetNameRemanent	String	25	

Read Variable Response:				
`sRA cdpPnioPLCSetNameRemanent <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioPLCSetNameRemanent	String	25	
Variable Data	data	Bool	1	

Write Variable:				
`sWN cdpPnioPLCSetNameRemanent <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioPLCSetNameRemanent	String	25	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA cdpPnioPLCSetNameRemanent`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioPLCSetNameRemanent	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioPLCSetNameRemanent[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioPLCSetNameRemanent 1[ETX]`
Write Variable:	`[STX]sWN cdpPnioPLCSetNameRemanent 1[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioPLCSetNameRemanent[ETX]`

© SICK AG - Germany - All rights reserved

2.31.1.7. Variable: cdpPnioPLCSetAddrRemanent

The following section contains a detailed description of the variable cdpPnioPLCSetAddrRemanent.

Variable Overview

Variable Name
cdpPnioPLCSetAddrRemanent

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	974
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioPLCSetAddrRemanent
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioPLCSetAddrRemanent	String	25	

Read Variable Response:

```
sRA cdpPnioPLCSetAddrRemanent <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioPLCSetAddrRemanent	String	25	
Variable Data	data	Bool	1	

Write Variable:

```
sWN cdpPnioPLCSetAddrRemanent <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioPLCSetAddrRemanent	String	25	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA cdpPnioPLCSetAddrRemanent
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioPLCSetAddrRemanent	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioPLCSetAddrRemanent[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioPLCSetAddrRemanent 1[ETX]`
Write Variable:	`[STX]sWN cdpPnioPLCSetAddrRemanent 1[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioPLCSetAddrRemanent[ETX]`

© SICK AG - Germany - All rights reserved

2.31.2. Group: Profinet_Address_VolatileData_grp

2.31.2.1. Variable: cdpPnioDHCP_Support

The following section contains a detailed description of the variable cdpPnioDHCP_Support.

Variable Overview

Variable Name
cdpPnioDHCP_Support

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	975
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioDHCP_Support
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioDHCP_Support	String	19	

Read Variable Response:

```
sRA cdpPnioDHCP_Support <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioDHCP_Support	String	19	
Variable Data	data	Bool	1	

Write Variable:

```
sWN cdpPnioDHCP_Support <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioDHCP_Support	String	19	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA cdpPnioDHCP_Support
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioDHCP_Support	String	19	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioDHCP_Support[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioDHCP_Support 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioDHCP_Support 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioDHCP_Support[ETX]`

2.31.2.2. Variable: cdpPnioDHCP_Status

The following section contains a detailed description of the variable cdpPnioDHCP_Status.

Variable Overview

Variable Name
cdpPnioDHCP_Status

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	976
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioDHCP_Status`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioDHCP_Status	String	18	

Read Variable Response:				
`sRA cdpPnioDHCP_Status <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioDHCP_Status	String	18	
Variable Data	data	Bool	1	

Write Variable:				
`sWN cdpPnioDHCP_Status <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN cdpPnioDHCP_Status <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioDHCP_Status	String	18	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA cdpPnioDHCP_Status`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioDHCP_Status	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioDHCP_Status[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioDHCP_Status 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioDHCP_Status 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioDHCP_Status[ETX]`

© SICK AG - Germany - All rights reserved

2.31.3. Group: Profinet_Address_ApplData_grp

2.31.3.1. Variable: cdpPnioSyncStationNameToLocationName

The following section contains a detailed description of the variable cdpPnioSyncStationNameToLocationName.

Variable Overview

Variable Name	Description
cdpPnioSyncStationNameToLocationName	Profinet StationName can be synced to LocationName for SopasET visability

Communication Name	cdpPnioStatNameSync
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	977
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioStatNameSync
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioStatNameSync	String	19	Profinet StationName can be synced to LocationName for SopasET visability

Read Variable Response:

```
sRA cdpPnioStatNameSync <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioStatNameSync	String	19	Profinet StationName can be synced to LocationName for SopasET visability
Variable Data	data	Bool	1	

Write Variable:

```
sWN cdpPnioStatNameSync <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioStatNameSync	String	19	Profinet StationName can be synced to LocationName for SopasET visability
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
`sWA cdpPnioStatNameSync`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioStatNameSync	String	19	Profinet StationName can be synced to LocationName for SopasET visability

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioStatNameSync[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioStatNameSync 1[ETX]`
Write Variable:	`[STX]sWN cdpPnioStatNameSync 1[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioStatNameSync[ETX]`

2.31.3.2. Method: cdpPnioUpDatePnConfig

The following section contains a detailed description of the method cdpPnioUpDatePnConfig.

Method Overview

Method Name	Description
cdpPnioUpDatePnConfig	Applies Profinet parameters

Communication Name	mcdpPnioUpdPnConfig
Sopas Index	116
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
`sMN mcdpPnioUpdPnConfig`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mcdpPnioUpdPnConfig	String	19	Applies Profinet parameters

Method Return Value:				
`sAN mcdpPnioUpdPnConfig`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mcdpPnioUpdPnConfig	String	19	Applies Profinet parameters

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mcdpPnioUpdPnConfig[ETX]`
Method Return Value:	`[STX]sAN mcdpPnioUpdPnConfig[ETX]`

© SICK AG - Germany - All rights reserved

2.32. Interface Block: Profinet_DeviceInfoFBParam

2.32.1. Group: Profinet_DeviceInfo_ParamData_grp

2.32.1.1. Variable: cdpPnioIMTagLocation

The following section contains a detailed description of the variable cdpPnioIMTagLocation.

Variable Overview

Variable Name
cdpPnioIMTagLocation

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	980
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	22
Initialisation	

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioIMTagLocation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIMTagLocation	String	20	

Read Variable Response:				
`sRA cdpPnioIMTagLocation <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIMTagLocation	String	20	
Variable Data	data	String	22	

Write Variable:				
`sWN cdpPnioIMTagLocation <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIMTagLocation	String	20	
Variable Data	data	String	22	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioIMTagLocation				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIMTagLocation	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioIMTagLocation[ETX]
Read Variable Response:	[STX]sRA cdpPnioIMTagLocation [ETX]
Write Variable:	[STX]sWN cdpPnioIMTagLocation [ETX]
Write Variable Response:	[STX]sWA cdpPnioIMTagLocation[ETX]

2.32.1.2. Variable: cdpPnioIMTagFunction

The following section contains a detailed description of the variable cdpPnioIMTagFunction.

Variable Overview

Variable Name
cdpPnioIMTagFunction

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	981
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioIMTagFunction`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIMTagFunction	String	20	

Read Variable Response:				
`sRA cdpPnioIMTagFunction <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIMTagFunction	String	20	
Variable Data	data	String	32	

Write Variable:				
`sWN cdpPnioIMTagFunction <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIMTagFunction	String	20	
Variable Data	data	String	32	

Write Variable Response:				
`sWA cdpPnioIMTagFunction`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIMTagFunction	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioIMTagFunction[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioIMTagFunction [ETX]`
Write Variable:	`[STX]sWN cdpPnioIMTagFunction [ETX]`
Write Variable Response:	`[STX]sWA cdpPnioIMTagFunction[ETX]`

© SICK AG - Germany - All rights reserved

2.32.1.3. Variable: cdpPnioIMDate

The following section contains a detailed description of the variable cdpPnioIMDate.

Variable Overview

Variable Name
cdpPnioIMDate

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	982
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..16
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioIMDate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIMDate	String	13	

Read Variable Response:

```
sRA cdpPnioIMDate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIMDate	String	13	
Variable Data	data	FlexString	16	

Write Variable:

```
sWN cdpPnioIMDate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIMDate	String	13	
Variable Data	data	FlexString	16	

Write Variable Response:

```
sWA cdpPnioIMDate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIMDate	String	13	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioIMDate[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioIMDate 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioIMDate 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioIMDate[ETX]`

2.32.1.4. Variable: cdpPnioIMDescriptor

The following section contains a detailed description of the variable cdpPnioIMDescriptor.

Variable Overview

Variable Name
cdpPnioIMDescriptor

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	983
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..54
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioIMDescriptor
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIMDescriptor	String	19	

Read Variable Response:

```
sRA cdpPnioIMDescriptor <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIMDescriptor	String	19	
Variable Data	data	FlexString	54	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioIMDescriptor <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIMDescriptor	String	19	
Variable Data	data	FlexString	54	

Write Variable Response:				
sWA cdpPnioIMDescriptor				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIMDescriptor	String	19	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioIMDescriptor[ETX]
Read Variable Response:	[STX]sRA cdpPnioIMDescriptor 0[ETX]
Write Variable:	[STX]sWN cdpPnioIMDescriptor 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioIMDescriptor[ETX]

2.32.1.5. Variable: cdpPnioIMSignature

The following section contains a detailed description of the variable cdpPnioIMSignature.

Variable Overview

Variable Name
cdpPnioIMSignature

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	984
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..54
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioIMSignature`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioIMSignature	String	18	

Read Variable Response:				
`sRA cdpPnioIMSignature <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioIMSignature	String	18	
Variable Data	data	FlexString	54	

Write Variable:				
`sWN cdpPnioIMSignature <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioIMSignature	String	18	
Variable Data	data	FlexString	54	

Write Variable Response:				
`sWA cdpPnioIMSignature`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioIMSignature	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioIMSignature[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioIMSignature 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioIMSignature 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioIMSignature[ETX]`

© SICK AG - Germany - All rights reserved

2.32.1.6. Variable: cdpPnioEpMAnnotation

The following section contains a detailed description of the variable cdpPnioEpMAnnotation.

Variable Overview

Variable Name
cdpPnioEpMAnnotation

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	985
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..54
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioEpMAnnotation
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioEpMAnnotation	String	20	

Read Variable Response:

```
sRA cdpPnioEpMAnnotation <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioEpMAnnotation	String	20	
Variable Data	data	FlexString	54	

Write Variable:

```
sWN cdpPnioEpMAnnotation <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioEpMAnnotation	String	20	
Variable Data	data	FlexString	54	

Write Variable Response:

```
sWA cdpPnioEpMAnnotation
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioEpMAnnotation	String	20	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioEpMAnnotation[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioEpMAnnotation 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioEpMAnnotation 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioEpMAnnotation[ETX]`

2.32.1.7. Variable: cdpPnioEpMOrderID

The following section contains a detailed description of the variable cdpPnioEpMOrderID.

Variable Overview

Variable Name
cdpPnioEpMOrderID

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	986
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..54
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioEpMOrderID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioEpMOrderID	String	17	

Read Variable Response:

```
sRA cdpPnioEpMOrderID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioEpMOrderID	String	17	
Variable Data	data	FlexString	54	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioEpMOrderID <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioEpMOrderID	String	17	
Variable Data	data	FlexString	54	

Write Variable Response:				
sWA cdpPnioEpMOrderID				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioEpMOrderID	String	17	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioEpMOrderID[ETX]
Read Variable Response:	[STX]sRA cdpPnioEpMOrderID 0[ETX]
Write Variable:	[STX]sWN cdpPnioEpMOrderID 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioEpMOrderID[ETX]

2.32.1.8. Variable: cdpPnioAlarmsSupported

The following section contains a detailed description of the variable cdpPnioAlarmsSupported.

Variable Overview

Variable Name
cdpPnioAlarmsSupported

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	987
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioAlarmsSupported`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioAlarmsSupported	String	22	

Read Variable Response:				
`sRA cdpPnioAlarmsSupported <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioAlarmsSupported	String	22	
Variable Data	data	USInt	1	

Write Variable:				
`sWN cdpPnioAlarmsSupported <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioAlarmsSupported	String	22	
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA cdpPnioAlarmsSupported`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioAlarmsSupported	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioAlarmsSupported[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioAlarmsSupported 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioAlarmsSupported 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioAlarmsSupported[ETX]`

© SICK AG - Germany - All rights reserved

2.33. Interface Block: Profinet_Diagnosis

2.33.1. Group: Profinet_Diagnosis_grp

2.33.1.1. Variable: cdpPnioStateApplication

The following section contains a detailed description of the variable cdpPnioStateApplication.

Variable Overview

Variable Name
cdpPnioStateApplication

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	988
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioStateApplication
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioStateApplication	String	23	

Read Variable Response:

```
sRA cdpPnioStateApplication <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioStateApplication	String	23	
Variable Data	data	Array	4	

Write Variable:

```
sWN cdpPnioStateApplication <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioStateApplication	String	23	
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioStateApplication				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioStateApplication	String	23	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioStateApplication[ETX]
Read Variable Response:	[STX]sRA cdpPnioStateApplication 0 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioStateApplication 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioStateApplication[ETX]

2.33.1.2. Variable: cdpPnioStateCommunication

The following section contains a detailed description of the variable cdpPnioStateCommunication.

Variable Overview

Variable Name
cdpPnioStateCommunication

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	989
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioStateCommunication`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioStateCommunication	String	25	

Read Variable Response:				
`sRA cdpPnioStateCommunication <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioStateCommunication	String	25	
Variable Data	data	Array	4	

Write Variable:				
`sWN cdpPnioStateCommunication <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioStateCommunication	String	25	
Variable Data	data	Array	4	

Write Variable Response:				
`sWA cdpPnioStateCommunication`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioStateCommunication	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioStateCommunication[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioStateCommunication 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioStateCommunication 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioStateCommunication[ETX]`

© SICK AG - Germany - All rights reserved

2.33.1.3. Variable: cdpPnioStateDeviceSummaryDiagnosis

The following section contains a detailed description of the variable cdpPnioStateDeviceSummaryDiagnosis.

Variable Overview

Variable Name
cdpPnioStateDeviceSummaryDiagnosis

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	990
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Default Value	{0,0,0,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioStateDeviceSummaryDiagnosis
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioStateDeviceSummaryDiagnosis	String	34	

Read Variable Response:

```
sRA cdpPnioStateDeviceSummaryDiagnosis <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioStateDeviceSummaryDiagnosis	String	34	
Variable Data	data	Array	4	

Write Variable:

```
sWN cdpPnioStateDeviceSummaryDiagnosis <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioStateDeviceSummaryDiagnosis	String	34	
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioStateDeviceSummaryDiagnosis				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioStateDeviceSummaryDiagnosis	String	34	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioStateDeviceSummaryDiagnosis[ETX]
Read Variable Response:	[STX]sRA cdpPnioStateDeviceSummaryDiagnosis 0 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioStateDeviceSummaryDiagnosis 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioStateDeviceSummaryDiagnosis[ETX]

2.33.1.4. Variable: cdpPnioLedStateBF

The following section contains a detailed description of the variable cdpPnioLedStateBF.

Variable Overview

Variable Name
cdpPnioLedStateBF

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	991
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioLedStateBF`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioLedStateBF	String	17	

Read Variable Response:				
`sRA cdpPnioLedStateBF <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioLedStateBF	String	17	
Variable Data	data	USInt	1	

Write Variable:				
`sWN cdpPnioLedStateBF <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioLedStateBF	String	17	
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA cdpPnioLedStateBF`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioLedStateBF	String	17	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioLedStateBF[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioLedStateBF 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioLedStateBF 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioLedStateBF[ETX]`

© SICK AG - Germany - All rights reserved

2.33.1.5. Variable: cdpPnioLedStateSF

The following section contains a detailed description of the variable cdpPnioLedStateSF.

Variable Overview

Variable Name
cdpPnioLedStateSF

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	992
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioLedStateSF
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioLedStateSF	String	17	

Read Variable Response:

```
sRA cdpPnioLedStateSF <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioLedStateSF	String	17	
Variable Data	data	USInt	1	

Write Variable:

```
sWN cdpPnioLedStateSF <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioLedStateSF	String	17	
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA cdpPnioLedStateSF
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioLedStateSF	String	17	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioLedStateSF[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioLedStateSF 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioLedStateSF 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioLedStateSF[ETX]`

2.33.1.6. Variable: cdpPnioStateCommunicationFSM

The following section contains a detailed description of the variable cdpPnioStateCommunicationFSM.

Variable Overview

Variable Name
cdpPnioStateCommunicationFSM

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	993
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{0,0,0,0}
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioStateCommunicationFSM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioStateCommunicationFSM	String	28	

Read Variable Response:				
`sRA cdpPnioStateCommunicationFSM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioStateCommunicationFSM	String	28	
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioStateCommunicationFSM <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioStateCommunicationFSM	String	28	
Variable Data	data	Array	4	

Write Variable Response:				
sWA cdpPnioStateCommunicationFSM				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioStateCommunicationFSM	String	28	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioStateCommunicationFSM[ETX]
Read Variable Response:	[STX]sRA cdpPnioStateCommunicationFSM 0 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioStateCommunicationFSM 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioStateCommunicationFSM[ETX]

2.33.1.7. Variable: cdpPnioMibSysDesc

The following section contains a detailed description of the variable cdpPnioMibSysDesc.

Variable Overview

Variable Name
cdpPnioMibSysDesc

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	994
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	256
Initialisation	cdpPnioMibSysDesc

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMibSysDesc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMibSysDesc	String	17	

Read Variable Response:				
`sRA cdpPnioMibSysDesc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMibSysDesc	String	17	
Variable Data	data	String	256	

Write Variable:				
`sWN cdpPnioMibSysDesc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMibSysDesc	String	17	
Variable Data	data	String	256	

Write Variable Response:				
`sWA cdpPnioMibSysDesc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMibSysDesc	String	17	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMibSysDesc[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMibSysDesc cdpPnioMibSysDesc` ···· `[ETX]`
Write Variable:	`[STX]sWN cdpPnioMibSysDesc cdpPnioMibSysDesc` ···· `[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMibSysDesc[ETX]`

© SICK AG - Germany - All rights reserved

2.33.1.8. Variable: cdpPnioMibSysUpTime

The following section contains a detailed description of the variable cdpPnioMibSysUpTime.

Variable Overview

Variable Name
cdpPnioMibSysUpTime

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	995
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMibSysUpTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMibSysUpTime	String	19	

Read Variable Response:				
`sRA cdpPnioMibSysUpTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMibSysUpTime	String	19	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMibSysUpTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMibSysUpTime	String	19	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMibSysUpTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMibSysUpTime	String	19	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMibSysUpTime[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMibSysUpTime 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMibSysUpTime 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMibSysUpTime[ETX]`

2.33.1.9. Variable: cdpPnioMibSysContact

The following section contains a detailed description of the variable cdpPnioMibSysContact.

Variable Overview

Variable Name
cdpPnioMibSysContact

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	996
Read-Access	Always
Write-Access	AuthorizedClient, Service

String	
Length	256
Initialisation	cdpPnioMibSysContact

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMibSysContact
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMibSysContact	String	20	

Read Variable Response:

```
sRA cdpPnioMibSysContact <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMibSysContact	String	20	
Variable Data	data	String	256	

Write Variable:

```
sWN cdpPnioMibSysContact <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMibSysContact <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMibSysContact	String	20	
Variable Data	data	String	256	

Write Variable Response:				
sWA cdpPnioMibSysContact				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMibSysContact	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMibSysContact[ETX]
Read Variable Response:	[STX]sRA cdpPnioMibSysContact cdpPnioMibSysContact·····[ETX]
Write Variable:	[STX]sWN cdpPnioMibSysContact cdpPnioMibSysContact·····[ETX]
Write Variable Response:	[STX]sWA cdpPnioMibSysContact[ETX]

© SICK AG - Germany - All rights reserved

2.33.2. Group: Profinet_Diagnosis_Mib1_grp

2.33.2.1. Variable: cdpPnioMib1_ifNumber

The following section contains a detailed description of the variable cdpPnioMib1_ifNumber.

Variable Overview

Variable Name
cdpPnioMib1_ifNumber

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	997
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ifNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifNumber	String	20	

Read Variable Response:

```
sRA cdpPnioMib1_ifNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifNumber	String	20	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ifNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifNumber	String	20	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ifNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib1_ifNumber				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib1_ifNumber	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ifNumber[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ifNumber 1[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ifNumber 1[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ifNumber[ETX]

2.33.2.2. Variable: cdpPnioMib1_ifSpeed

The following section contains a detailed description of the variable cdpPnioMib1_ifSpeed.

Variable Overview

Variable Name
cdpPnioMib1_ifSpeed

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	998
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifSpeed	String	19	

Read Variable Response:				
`sRA cdpPnioMib1_ifSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifSpeed	String	19	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ifSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifSpeed	String	19	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifSpeed	String	19	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifSpeed[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifSpeed 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifSpeed 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifSpeed[ETX]`

© SICK AG - Germany - All rights reserved

2.33.2.3. Variable: cdpPnioMib1_ifPhysAddress

The following section contains a detailed description of the variable cdpPnioMib1_ifPhysAddress.

Variable Overview

Variable Name
cdpPnioMib1_ifPhysAddress

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	999
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	6
Default Value	{0,6,119,0,0,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:
`sRN cdpPnioMib1_ifPhysAddress`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifPhysAddress	String	25	

Read Variable Response:
`sRA cdpPnioMib1_ifPhysAddress <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifPhysAddress	String	25	
Variable Data	data	Array	6	

Write Variable:
`sWN cdpPnioMib1_ifPhysAddress <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifPhysAddress	String	25	
Variable Data	data	Array	6	

Write Variable Response:
`sWA cdpPnioMib1_ifPhysAddress`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib1_ifPhysAddress				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib1_ifPhysAddress	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ifPhysAddress[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ifPhysAddress 0 6 77 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ifPhysAddress 0 6 77 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ifPhysAddress[ETX]

2.33.2.4. Variable: cdpPnioMib1_ifOperStatus

The following section contains a detailed description of the variable cdpPnioMib1_ifOperStatus.

Variable Overview

Variable Name
cdpPnioMib1_ifOperStatus

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1000
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifOperStatus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifOperStatus	String	24	

Read Variable Response:				
`sRA cdpPnioMib1_ifOperStatus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifOperStatus	String	24	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ifOperStatus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifOperStatus	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifOperStatus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifOperStatus	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifOperStatus[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifOperStatus 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifOperStatus 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifOperStatus[ETX]`

© SICK AG - Germany - All rights reserved

2.33.2.5. Variable: cdpPnioMib1_ifLastChange

The following section contains a detailed description of the variable cdpPnioMib1_ifLastChange.

Variable Overview

Variable Name
cdpPnioMib1_ifLastChange

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1001
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifLastChange`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifLastChange	String	24	

Read Variable Response:				
`sRA cdpPnioMib1_ifLastChange <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifLastChange	String	24	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ifLastChange <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifLastChange	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifLastChange`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifLastChange	String	24	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifLastChange[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifLastChange 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifLastChange 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifLastChange[ETX]`

2.33.2.6. Variable: cdpPnioMib1_ifInOctets

The following section contains a detailed description of the variable cdpPnioMib1_ifInOctets.

Variable Overview

Variable Name
cdpPnioMib1_ifInOctets

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1002
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifInOctets`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifInOctets	String	22	

Read Variable Response:				
`sRA cdpPnioMib1_ifInOctets <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifInOctets	String	22	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_ifInOctets <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifInOctets	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_ifInOctets				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifInOctets	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ifInOctets[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ifInOctets 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ifInOctets 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ifInOctets[ETX]

2.33.2.7. Variable: cdpPnioMib1_ifInUcastPkts

The following section contains a detailed description of the variable cdpPnioMib1_ifInUcastPkts.

Variable Overview

Variable Name
cdpPnioMib1_ifInUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1003
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifInUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifInUcastPkts	String	25	

Read Variable Response:				
`sRA cdpPnioMib1_ifInUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifInUcastPkts	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ifInUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifInUcastPkts	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifInUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifInUcastPkts	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifInUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifInUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifInUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifInUcastPkts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.2.8. Variable: cdpPnioMib1_ifInNUcastPkts

The following section contains a detailed description of the variable cdpPnioMib1_ifInNUcastPkts.

Variable Overview

Variable Name
cdpPnioMib1_ifInNUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1004
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ifInNUcastPkts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifInNUcastPkts	String	26	

Read Variable Response:

```
sRA cdpPnioMib1_ifInNUcastPkts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifInNUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ifInNUcastPkts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifInNUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ifInNUcastPkts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifInNUcastPkts	String	26	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifInNUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifInNUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifInNUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifInNUcastPkts[ETX]`

2.33.2.9. Variable: cdpPnioMib1_ifInDiscards

The following section contains a detailed description of the variable cdpPnioMib1_ifInDiscards.

Variable Overview

Variable Name
cdpPnioMib1_ifInDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1005
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifInDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifInDiscards	String	24	

Read Variable Response:				
`sRA cdpPnioMib1_ifInDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifInDiscards	String	24	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_ifInDiscards <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifInDiscards	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_ifInDiscards				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifInDiscards	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ifInDiscards[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ifInDiscards 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ifInDiscards 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ifInDiscards[ETX]

2.33.2.10. Variable: cdpPnioMib1_ifInErrors

The following section contains a detailed description of the variable cdpPnioMib1_ifInErrors.

Variable Overview

Variable Name
cdpPnioMib1_ifInErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1006
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifInErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifInErrors	String	22	

Read Variable Response:				
`sRA cdpPnioMib1_ifInErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifInErrors	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ifInErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifInErrors	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifInErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifInErrors	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifInErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifInErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifInErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifInErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.2.11. Variable: cdpPnioMib1_ifOutOctets

The following section contains a detailed description of the variable cdpPnioMib1_ifOutOctets.

Variable Overview

Variable Name
cdpPnioMib1_ifOutOctets

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1007
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ifOutOctets
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifOutOctets	String	23	

Read Variable Response:

```
sRA cdpPnioMib1_ifOutOctets <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifOutOctets	String	23	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ifOutOctets <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifOutOctets	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ifOutOctets
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifOutOctets	String	23	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifOutOctets[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifOutOctets 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifOutOctets 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifOutOctets[ETX]`

2.33.2.12. Variable: cdpPnioMib1_ifOutUcastPkts

The following section contains a detailed description of the variable cdpPnioMib1_ifOutUcastPkts.

Variable Overview

Variable Name
cdpPnioMib1_ifOutUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1008
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifOutUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifOutUcastPkts	String	26	

Read Variable Response:				
`sRA cdpPnioMib1_ifOutUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifOutUcastPkts	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_ifOutUcastPkts <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifOutUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_ifOutUcastPkts				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifOutUcastPkts	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ifOutUcastPkts[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ifOutUcastPkts 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ifOutUcastPkts 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ifOutUcastPkts[ETX]

2.33.2.13. Variable: cdpPnioMib1_ifOutNUcastPkts

The following section contains a detailed description of the variable cdpPnioMib1_ifOutNUcastPkts.

Variable Overview

Variable Name
cdpPnioMib1_ifOutNUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1009
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifOutNUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifOutNUcastPkts	String	27	

Read Variable Response:				
`sRA cdpPnioMib1_ifOutNUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifOutNUcastPkts	String	27	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ifOutNUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifOutNUcastPkts	String	27	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifOutNUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifOutNUcastPkts	String	27	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifOutNUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifOutNUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifOutNUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifOutNUcastPkts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.2.14. Variable: cdpPnioMib1_ifOutDiscards

The following section contains a detailed description of the variable cdpPnioMib1_ifOutDiscards.

Variable Overview

Variable Name
cdpPnioMib1_ifOutDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1010
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ifOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifOutDiscards	String	25	

Read Variable Response:

```
sRA cdpPnioMib1_ifOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ifOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ifOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifOutDiscards	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifOutDiscards[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifOutDiscards 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifOutDiscards 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifOutDiscards[ETX]`

2.33.2.15. Variable: cdpPnioMib1_ifOutErrors

The following section contains a detailed description of the variable cdpPnioMib1_ifOutErrors.

Variable Overview

Variable Name
cdpPnioMib1_ifOutErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1011
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ifOutErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ifOutErrors	String	23	

Read Variable Response:				
`sRA cdpPnioMib1_ifOutErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ifOutErrors	String	23	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN cdpPnioMib1_ifOutErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ifOutErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ifOutErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ifOutErrors	String	23	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ifOutErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ifOutErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ifOutErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ifOutErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.3. Group: Profinet_Diagnosis_Mib1_optional_grp

2.33.3.1. Variable: cdpPnioMib1_ipInReceives

The following section contains a detailed description of the variable cdpPnioMib1_ipInReceives.

Variable Overview

Variable Name
cdpPnioMib1_ipInReceives

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1012
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ipInReceives
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ipInReceives	String	24	

Read Variable Response:

```
sRA cdpPnioMib1_ipInReceives <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ipInReceives	String	24	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ipInReceives <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ipInReceives	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ipInReceives
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib1_ipInReceives				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib1_ipInReceives	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ipInReceives[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ipInReceives 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ipInReceives 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ipInReceives[ETX]

2.33.3.2. Variable: cdpPnioMib1_ipInHdrErrors

The following section contains a detailed description of the variable cdpPnioMib1_ipInHdrErrors.

Variable Overview

Variable Name
cdpPnioMib1_ipInHdrErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1013
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ipInHdrErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ipInHdrErrors	String	25	

Read Variable Response:				
`sRA cdpPnioMib1_ipInHdrErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ipInHdrErrors	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ipInHdrErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ipInHdrErrors	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ipInHdrErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ipInHdrErrors	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ipInHdrErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ipInHdrErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ipInHdrErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ipInHdrErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.3.3. Variable: cdpPnioMib1_ipInAddrErrors

The following section contains a detailed description of the variable cdpPnioMib1_ipInAddrErrors.

Variable Overview

Variable Name
cdpPnioMib1_ipInAddrErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1014
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ipInAddrErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ipInAddrErrors	String	26	

Read Variable Response:

```
sRA cdpPnioMib1_ipInAddrErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ipInAddrErrors	String	26	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ipInAddrErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ipInAddrErrors	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ipInAddrErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ipInAddrErrors	String	26	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ipInAddrErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ipInAddrErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ipInAddrErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ipInAddrErrors[ETX]`

2.33.3.4. Variable: cdpPnioMib1_ipInDiscards

The following section contains a detailed description of the variable cdpPnioMib1_ipInDiscards.

Variable Overview

Variable Name
cdpPnioMib1_ipInDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1015
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ipInDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ipInDiscards	String	24	

Read Variable Response:				
`sRA cdpPnioMib1_ipInDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ipInDiscards	String	24	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_ipInDiscards <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ipInDiscards	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_ipInDiscards				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ipInDiscards	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_ipInDiscards[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_ipInDiscards 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_ipInDiscards 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_ipInDiscards[ETX]

2.33.3.5. Variable: cdpPnioMib1_ipOutRequests

The following section contains a detailed description of the variable cdpPnioMib1_ipOutRequests.

Variable Overview

Variable Name
cdpPnioMib1_ipOutRequests

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1016
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_ipOutRequests`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ipOutRequests	String	25	

Read Variable Response:				
`sRA cdpPnioMib1_ipOutRequests <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ipOutRequests	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_ipOutRequests <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ipOutRequests	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_ipOutRequests`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ipOutRequests	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ipOutRequests[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ipOutRequests 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ipOutRequests 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ipOutRequests[ETX]`

© SICK AG - Germany - All rights reserved

2.33.3.6. Variable: cdpPnioMib1_ipOutDiscards

The following section contains a detailed description of the variable cdpPnioMib1_ipOutDiscards.

Variable Overview

Variable Name
cdpPnioMib1_ipOutDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1017
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_ipOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_ipOutDiscards	String	25	

Read Variable Response:

```
sRA cdpPnioMib1_ipOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_ipOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_ipOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_ipOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_ipOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_ipOutDiscards	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_ipOutDiscards[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_ipOutDiscards 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_ipOutDiscards 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_ipOutDiscards[ETX]`

2.33.3.7. Variable: cdpPnioMib1_udpInDatagrams

The following section contains a detailed description of the variable cdpPnioMib1_udpInDatagrams.

Variable Overview

Variable Name
cdpPnioMib1_udpInDatagrams

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1018
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_udpInDatagrams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_udpInDatagrams	String	26	

Read Variable Response:				
`sRA cdpPnioMib1_udpInDatagrams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_udpInDatagrams	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_udpInDatagrams <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_udpInDatagrams	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_udpInDatagrams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_udpInDatagrams	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_udpInDatagrams[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_udpInDatagrams 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_udpInDatagrams 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_udpInDatagrams[ETX]

2.33.3.8. Variable: cdpPnioMib1_udpNoPorts

The following section contains a detailed description of the variable cdpPnioMib1_udpNoPorts.

Variable Overview

Variable Name
cdpPnioMib1_udpNoPorts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1019
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_udpNoPorts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_udpNoPorts	String	22	

Read Variable Response:				
`sRA cdpPnioMib1_udpNoPorts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_udpNoPorts	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_udpNoPorts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_udpNoPorts	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_udpNoPorts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_udpNoPorts	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_udpNoPorts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_udpNoPorts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_udpNoPorts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_udpNoPorts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.3.9. Variable: cdpPnioMib1_udpInErrors

The following section contains a detailed description of the variable cdpPnioMib1_udpInErrors.

Variable Overview

Variable Name
cdpPnioMib1_udpInErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1020
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_udpInErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_udpInErrors	String	23	

Read Variable Response:

```
sRA cdpPnioMib1_udpInErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_udpInErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_udpInErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_udpInErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_udpInErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_udpInErrors	String	23	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_udpInErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_udpInErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_udpInErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_udpInErrors[ETX]`

2.33.3.10. Variable: cdpPnioMib1_udpOutDatagrams

The following section contains a detailed description of the variable cdpPnioMib1_udpOutDatagrams.

Variable Overview

Variable Name
cdpPnioMib1_udpOutDatagrams

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1021
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_udpOutDatagrams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_udpOutDatagrams	String	27	

Read Variable Response:				
`sRA cdpPnioMib1_udpOutDatagrams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_udpOutDatagrams	String	27	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_udpOutDatagrams <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_udpOutDatagrams	String	27	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_udpOutDatagrams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_udpOutDatagrams	String	27	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_udpOutDatagrams[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_udpOutDatagrams 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_udpOutDatagrams 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_udpOutDatagrams[ETX]

2.33.3.11. Variable: cdpPnioMib1_tcpInSegs

The following section contains a detailed description of the variable cdpPnioMib1_tcpInSegs.

Variable Overview

Variable Name
cdpPnioMib1_tcpInSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1022
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_tcpInSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_tcpInSegs	String	21	

Read Variable Response:				
`sRA cdpPnioMib1_tcpInSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_tcpInSegs	String	21	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_tcpInSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_tcpInSegs	String	21	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_tcpInSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_tcpInSegs	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_tcpInSegs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_tcpInSegs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_tcpInSegs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_tcpInSegs[ETX]`

© SICK AG - Germany - All rights reserved

2.33.3.12. Variable: cdpPnioMib1_tcpOutSegs

The following section contains a detailed description of the variable cdpPnioMib1_tcpOutSegs.

Variable Overview

Variable Name
cdpPnioMib1_tcpOutSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1023
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_tcpOutSegs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_tcpOutSegs	String	22	

Read Variable Response:

```
sRA cdpPnioMib1_tcpOutSegs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_tcpOutSegs	String	22	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_tcpOutSegs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_tcpOutSegs	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_tcpOutSegs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_tcpOutSegs	String	22	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_tcpOutSegs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_tcpOutSegs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_tcpOutSegs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_tcpOutSegs[ETX]`

2.33.3.13. Variable: cdpPnioMib1_tcpRetransSegs

The following section contains a detailed description of the variable cdpPnioMib1_tcpRetransSegs.

Variable Overview

Variable Name
cdpPnioMib1_tcpRetransSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1024
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_tcpRetransSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_tcpRetransSegs	String	26	

Read Variable Response:				
`sRA cdpPnioMib1_tcpRetransSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_tcpRetransSegs	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib1_tcpRetransSegs <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_tcpRetransSegs	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib1_tcpRetransSegs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_tcpRetransSegs	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib1_tcpRetransSegs[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib1_tcpRetransSegs 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib1_tcpRetransSegs 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib1_tcpRetransSegs[ETX]

2.33.3.14. Variable: cdpPnioMib1_tcpInErrs

The following section contains a detailed description of the variable cdpPnioMib1_tcpInErrs.

Variable Overview

Variable Name
cdpPnioMib1_tcpInErrs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1025
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib1_tcpInErrs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_tcpInErrs	String	21	

Read Variable Response:				
`sRA cdpPnioMib1_tcpInErrs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_tcpInErrs	String	21	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib1_tcpInErrs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_tcpInErrs	String	21	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib1_tcpInErrs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_tcpInErrs	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_tcpInErrs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_tcpInErrs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_tcpInErrs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_tcpInErrs[ETX]`

© SICK AG - Germany - All rights reserved

2.33.3.15. Variable: cdpPnioMib1_tcpOutRsts

The following section contains a detailed description of the variable cdpPnioMib1_tcpOutRsts.

Variable Overview

Variable Name
cdpPnioMib1_tcpOutRsts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1026
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib1_tcpOutRsts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib1_tcpOutRsts	String	22	

Read Variable Response:

```
sRA cdpPnioMib1_tcpOutRsts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib1_tcpOutRsts	String	22	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib1_tcpOutRsts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib1_tcpOutRsts	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib1_tcpOutRsts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib1_tcpOutRsts	String	22	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib1_tcpOutRsts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib1_tcpOutRsts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib1_tcpOutRsts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib1_tcpOutRsts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.4. Group: Profinet_Diagnosis_Mib2_grp

2.33.4.1. Variable: cdpPnioMib2_ifNumber

The following section contains a detailed description of the variable cdpPnioMib2_ifNumber.

Variable Overview

Variable Name
cdpPnioMib2_ifNumber

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1027
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	2
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_ifNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifNumber	String	20	

Read Variable Response:

```
sRA cdpPnioMib2_ifNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifNumber	String	20	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_ifNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifNumber	String	20	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_ifNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib2_ifNumber				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib2_ifNumber	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ifNumber[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ifNumber 2[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ifNumber 2[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ifNumber[ETX]

2.33.4.2. Variable: cdpPnioMib2_ifSpeed

The following section contains a detailed description of the variable cdpPnioMib2_ifSpeed.

Variable Overview

Variable Name
cdpPnioMib2_ifSpeed

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1028
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifSpeed	String	19	

Read Variable Response:				
`sRA cdpPnioMib2_ifSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifSpeed	String	19	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ifSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifSpeed	String	19	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifSpeed	String	19	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifSpeed[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifSpeed 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifSpeed 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifSpeed[ETX]`

© SICK AG - Germany - All rights reserved

2.33.4.3. Variable: cdpPnioMib2_ifPhysAddress

The following section contains a detailed description of the variable cdpPnioMib2_ifPhysAddress.

Variable Overview

Variable Name
cdpPnioMib2_ifPhysAddress

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1029
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	6
Default Value	{0,6,119,0,0,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:
`sRN cdpPnioMib2_ifPhysAddress`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifPhysAddress	String	25	

Read Variable Response:
`sRA cdpPnioMib2_ifPhysAddress <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifPhysAddress	String	25	
Variable Data	data	Array	6	

Write Variable:
`sWN cdpPnioMib2_ifPhysAddress <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifPhysAddress	String	25	
Variable Data	data	Array	6	

Write Variable Response:
`sWA cdpPnioMib2_ifPhysAddress`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib2_ifPhysAddress				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib2_ifPhysAddress	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ifPhysAddress[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ifPhysAddress 0 6 77 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ifPhysAddress 0 6 77 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ifPhysAddress[ETX]

2.33.4.4. Variable: cdpPnioMib2_ifOperStatus

The following section contains a detailed description of the variable cdpPnioMib2_ifOperStatus.

Variable Overview

Variable Name
cdpPnioMib2_ifOperStatus

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1030
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifOperStatus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifOperStatus	String	24	

Read Variable Response:				
`sRA cdpPnioMib2_ifOperStatus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifOperStatus	String	24	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ifOperStatus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifOperStatus	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifOperStatus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifOperStatus	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifOperStatus[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifOperStatus 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifOperStatus 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifOperStatus[ETX]`

© SICK AG - Germany - All rights reserved

2.33.4.5. Variable: cdpPnioMib2_ifLastChange

The following section contains a detailed description of the variable cdpPnioMib2_ifLastChange.

Variable Overview

Variable Name
cdpPnioMib2_ifLastChange

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1031
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifLastChange`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifLastChange	String	24	

Read Variable Response:				
`sRA cdpPnioMib2_ifLastChange <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifLastChange	String	24	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ifLastChange <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifLastChange	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifLastChange`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifLastChange	String	24	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifLastChange[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifLastChange 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifLastChange 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifLastChange[ETX]`

2.33.4.6. Variable: cdpPnioMib2_ifInOctets

The following section contains a detailed description of the variable cdpPnioMib2_ifInOctets.

Variable Overview

Variable Name
cdpPnioMib2_ifInOctets

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1032
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifInOctets`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifInOctets	String	22	

Read Variable Response:				
`sRA cdpPnioMib2_ifInOctets <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifInOctets	String	22	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_ifInOctets <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifInOctets	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_ifInOctets				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifInOctets	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ifInOctets[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ifInOctets 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ifInOctets 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ifInOctets[ETX]

2.33.4.7. Variable: cdpPnioMib2_ifInUcastPkts

The following section contains a detailed description of the variable cdpPnioMib2_ifInUcastPkts.

Variable Overview

Variable Name
cdpPnioMib2_ifInUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1033
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifInUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifInUcastPkts	String	25	

Read Variable Response:				
`sRA cdpPnioMib2_ifInUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifInUcastPkts	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ifInUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifInUcastPkts	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifInUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifInUcastPkts	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifInUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifInUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifInUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifInUcastPkts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.4.8. Variable: cdpPnioMib2_ifInNUcastPkts

The following section contains a detailed description of the variable cdpPnioMib2_ifInNUcastPkts.

Variable Overview

Variable Name
cdpPnioMib2_ifInNUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1034
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_ifInNUcastPkts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifInNUcastPkts	String	26	

Read Variable Response:

```
sRA cdpPnioMib2_ifInNUcastPkts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifInNUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_ifInNUcastPkts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifInNUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_ifInNUcastPkts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifInNUcastPkts	String	26	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifInNUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifInNUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifInNUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifInNUcastPkts[ETX]`

2.33.4.9. Variable: cdpPnioMib2_ifInDiscards

The following section contains a detailed description of the variable cdpPnioMib2_ifInDiscards.

Variable Overview

Variable Name
cdpPnioMib2_ifInDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1035
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifInDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifInDiscards	String	24	

Read Variable Response:				
`sRA cdpPnioMib2_ifInDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifInDiscards	String	24	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_ifInDiscards <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifInDiscards	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_ifInDiscards				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifInDiscards	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ifInDiscards[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ifInDiscards 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ifInDiscards 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ifInDiscards[ETX]

2.33.4.10. Variable: cdpPnioMib2_ifInErrors

The following section contains a detailed description of the variable cdpPnioMib2_ifInErrors.

Variable Overview

Variable Name
cdpPnioMib2_ifInErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1036
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifInErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifInErrors	String	22	

Read Variable Response:				
`sRA cdpPnioMib2_ifInErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifInErrors	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ifInErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifInErrors	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifInErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifInErrors	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifInErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifInErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifInErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifInErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.4.11. Variable: cdpPnioMib2_ifOutOctets

The following section contains a detailed description of the variable cdpPnioMib2_ifOutOctets.

Variable Overview

Variable Name
cdpPnioMib2_ifOutOctets

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1037
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_ifOutOctets
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifOutOctets	String	23	

Read Variable Response:

```
sRA cdpPnioMib2_ifOutOctets <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifOutOctets	String	23	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_ifOutOctets <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifOutOctets	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_ifOutOctets
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifOutOctets	String	23	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifOutOctets[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifOutOctets 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifOutOctets 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifOutOctets[ETX]`

2.33.4.12. Variable: cdpPnioMib2_ifOutUcastPkts

The following section contains a detailed description of the variable cdpPnioMib2_ifOutUcastPkts.

Variable Overview

Variable Name
cdpPnioMib2_ifOutUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1038
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifOutUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifOutUcastPkts	String	26	

Read Variable Response:				
`sRA cdpPnioMib2_ifOutUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifOutUcastPkts	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_ifOutUcastPkts <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifOutUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_ifOutUcastPkts				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifOutUcastPkts	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ifOutUcastPkts[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ifOutUcastPkts 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ifOutUcastPkts 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ifOutUcastPkts[ETX]

2.33.4.13. Variable: cdpPnioMib2_ifOutNUcastPkts

The following section contains a detailed description of the variable cdpPnioMib2_ifOutNUcastPkts.

Variable Overview

Variable Name
cdpPnioMib2_ifOutNUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1039
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifOutNUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifOutNUcastPkts	String	27	

Read Variable Response:				
`sRA cdpPnioMib2_ifOutNUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifOutNUcastPkts	String	27	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ifOutNUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifOutNUcastPkts	String	27	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifOutNUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifOutNUcastPkts	String	27	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifOutNUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifOutNUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifOutNUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifOutNUcastPkts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.4.14. Variable: cdpPnioMib2_ifOutDiscards

The following section contains a detailed description of the variable cdpPnioMib2_ifOutDiscards.

Variable Overview

Variable Name
cdpPnioMib2_ifOutDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1040
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_ifOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifOutDiscards	String	25	

Read Variable Response:

```
sRA cdpPnioMib2_ifOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_ifOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_ifOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifOutDiscards	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifOutDiscards[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifOutDiscards 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifOutDiscards 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifOutDiscards[ETX]`

2.33.4.15. Variable: cdpPnioMib2_ifOutErrors

The following section contains a detailed description of the variable cdpPnioMib2_ifOutErrors.

Variable Overview

Variable Name
cdpPnioMib2_ifOutErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1041
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ifOutErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ifOutErrors	String	23	

Read Variable Response:				
`sRA cdpPnioMib2_ifOutErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ifOutErrors	String	23	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN cdpPnioMib2_ifOutErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ifOutErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ifOutErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ifOutErrors	String	23	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ifOutErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ifOutErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ifOutErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ifOutErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.5. Group: Profinet_Diagnosis_Mib2_Optional_grp

2.33.5.1. Variable: cdpPnioMib2_ipInReceives

The following section contains a detailed description of the variable cdpPnioMib2_ipInReceives.

Variable Overview

Variable Name
cdpPnioMib2_ipInReceives

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1042
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_ipInReceives
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ipInReceives	String	24	

Read Variable Response:

```
sRA cdpPnioMib2_ipInReceives <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ipInReceives	String	24	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_ipInReceives <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ipInReceives	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_ipInReceives
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib2_ipInReceives				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib2_ipInReceives	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ipInReceives[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ipInReceives 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ipInReceives 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ipInReceives[ETX]

2.33.5.2. Variable: cdpPnioMib2_ipInHdrErrors

The following section contains a detailed description of the variable cdpPnioMib2_ipInHdrErrors.

Variable Overview

Variable Name
cdpPnioMib2_ipInHdrErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1043
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ipInHdrErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ipInHdrErrors	String	25	

Read Variable Response:				
`sRA cdpPnioMib2_ipInHdrErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ipInHdrErrors	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ipInHdrErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ipInHdrErrors	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ipInHdrErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ipInHdrErrors	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ipInHdrErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ipInHdrErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ipInHdrErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ipInHdrErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.5.3. Variable: cdpPnioMib2_ipInAddrErrors

The following section contains a detailed description of the variable cdpPnioMib2_ipInAddrErrors.

Variable Overview

Variable Name
cdpPnioMib2_ipInAddrErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1044
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_ipInAddrErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ipInAddrErrors	String	26	

Read Variable Response:

```
sRA cdpPnioMib2_ipInAddrErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ipInAddrErrors	String	26	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_ipInAddrErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ipInAddrErrors	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_ipInAddrErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ipInAddrErrors	String	26	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ipInAddrErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ipInAddrErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ipInAddrErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ipInAddrErrors[ETX]`

2.33.5.4. Variable: cdpPnioMib2_ipInDiscards

The following section contains a detailed description of the variable cdpPnioMib2_ipInDiscards.

Variable Overview

Variable Name
cdpPnioMib2_ipInDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1045
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ipInDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ipInDiscards	String	24	

Read Variable Response:				
`sRA cdpPnioMib2_ipInDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ipInDiscards	String	24	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_ipInDiscards <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ipInDiscards	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_ipInDiscards				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ipInDiscards	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_ipInDiscards[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_ipInDiscards 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_ipInDiscards 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_ipInDiscards[ETX]

2.33.5.5. Variable: cdpPnioMib2_ipOutRequests

The following section contains a detailed description of the variable cdpPnioMib2_ipOutRequests.

Variable Overview

Variable Name
cdpPnioMib2_ipOutRequests

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1046
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ipOutRequests`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ipOutRequests	String	25	

Read Variable Response:				
`sRA cdpPnioMib2_ipOutRequests <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ipOutRequests	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ipOutRequests <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ipOutRequests	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ipOutRequests`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ipOutRequests	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ipOutRequests[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ipOutRequests 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ipOutRequests 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ipOutRequests[ETX]`

© SICK AG - Germany - All rights reserved

2.33.5.6. Variable: cdpPnioMib2_ipOutDiscards

The following section contains a detailed description of the variable cdpPnioMib2_ipOutDiscards.

Variable Overview

Variable Name
cdpPnioMib2_ipOutDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1047
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_ipOutDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_ipOutDiscards	String	25	

Read Variable Response:				
`sRA cdpPnioMib2_ipOutDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_ipOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_ipOutDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_ipOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_ipOutDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_ipOutDiscards	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_ipOutDiscards[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_ipOutDiscards 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_ipOutDiscards 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_ipOutDiscards[ETX]`

2.33.5.7. Variable: cdpPnioMib2_udpInDatagrams

The following section contains a detailed description of the variable cdpPnioMib2_udpInDatagrams.

Variable Overview

Variable Name
cdpPnioMib2_udpInDatagrams

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1048
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_udpInDatagrams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_udpInDatagrams	String	26	

Read Variable Response:				
`sRA cdpPnioMib2_udpInDatagrams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_udpInDatagrams	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_udpInDatagrams <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_udpInDatagrams	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_udpInDatagrams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_udpInDatagrams	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_udpInDatagrams[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_udpInDatagrams 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_udpInDatagrams 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_udpInDatagrams[ETX]

2.33.5.8. Variable: cdpPnioMib2_udpNoPorts

The following section contains a detailed description of the variable cdpPnioMib2_udpNoPorts.

Variable Overview

Variable Name
cdpPnioMib2_udpNoPorts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1049
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_udpNoPorts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_udpNoPorts	String	22	

Read Variable Response:				
`sRA cdpPnioMib2_udpNoPorts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_udpNoPorts	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_udpNoPorts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_udpNoPorts	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_udpNoPorts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_udpNoPorts	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_udpNoPorts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_udpNoPorts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_udpNoPorts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_udpNoPorts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.5.9. Variable: cdpPnioMib2_udpInErrors

The following section contains a detailed description of the variable cdpPnioMib2_udpInErrors.

Variable Overview

Variable Name
cdpPnioMib2_udpInErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1050
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib2_udpInErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_udpInErrors	String	23	

Read Variable Response:

```
sRA cdpPnioMib2_udpInErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_udpInErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib2_udpInErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_udpInErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib2_udpInErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_udpInErrors	String	23	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_udpInErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_udpInErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_udpInErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_udpInErrors[ETX]`

2.33.5.10. Variable: cdpPnioMib2_udpOutDatagrams

The following section contains a detailed description of the variable cdpPnioMib2_udpOutDatagrams.

Variable Overview

Variable Name
cdpPnioMib2_udpOutDatagrams

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1051
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_udpOutDatagrams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_udpOutDatagrams	String	27	

Read Variable Response:				
`sRA cdpPnioMib2_udpOutDatagrams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_udpOutDatagrams	String	27	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_udpOutDatagrams <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_udpOutDatagrams	String	27	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_udpOutDatagrams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_udpOutDatagrams	String	27	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_udpOutDatagrams[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_udpOutDatagrams 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_udpOutDatagrams 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_udpOutDatagrams[ETX]

2.33.5.11. Variable: cdpPnioMib2_tcpInSegs

The following section contains a detailed description of the variable cdpPnioMib2_tcpInSegs.

Variable Overview

Variable Name
cdpPnioMib2_tcpInSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1052
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_tcpInSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_tcpInSegs	String	21	

Read Variable Response:				
`sRA cdpPnioMib2_tcpInSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_tcpInSegs	String	21	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_tcpInSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_tcpInSegs	String	21	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_tcpInSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_tcpInSegs	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_tcpInSegs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_tcpInSegs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_tcpInSegs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_tcpInSegs[ETX]`

© SICK AG - Germany - All rights reserved

2.33.5.12. Variable: cdpPnioMib2_tcpOutSegs

The following section contains a detailed description of the variable cdpPnioMib2_tcpOutSegs.

Variable Overview

Variable Name
cdpPnioMib2_tcpOutSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1053
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_tcpOutSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_tcpOutSegs	String	22	

Read Variable Response:				
`sRA cdpPnioMib2_tcpOutSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_tcpOutSegs	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_tcpOutSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_tcpOutSegs	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_tcpOutSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_tcpOutSegs	String	22	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_tcpOutSegs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_tcpOutSegs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_tcpOutSegs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_tcpOutSegs[ETX]`

2.33.5.13. Variable: cdpPnioMib2_tcpRetransSegs

The following section contains a detailed description of the variable cdpPnioMib2_tcpRetransSegs.

Variable Overview

Variable Name
cdpPnioMib2_tcpRetransSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1054
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_tcpRetransSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_tcpRetransSegs	String	26	

Read Variable Response:				
`sRA cdpPnioMib2_tcpRetransSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_tcpRetransSegs	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib2_tcpRetransSegs <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_tcpRetransSegs	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib2_tcpRetransSegs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_tcpRetransSegs	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib2_tcpRetransSegs[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib2_tcpRetransSegs 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib2_tcpRetransSegs 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib2_tcpRetransSegs[ETX]

2.33.5.14. Variable: cdpPnioMib2_tcpInErrs

The following section contains a detailed description of the variable cdpPnioMib2_tcpInErrs.

Variable Overview

Variable Name
cdpPnioMib2_tcpInErrs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1055
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_tcpInErrs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_tcpInErrs	String	21	

Read Variable Response:				
`sRA cdpPnioMib2_tcpInErrs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_tcpInErrs	String	21	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_tcpInErrs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_tcpInErrs	String	21	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_tcpInErrs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_tcpInErrs	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_tcpInErrs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_tcpInErrs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_tcpInErrs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_tcpInErrs[ETX]`

© SICK AG - Germany - All rights reserved

2.33.5.15. Variable: cdpPnioMib2_tcpOutRsts

The following section contains a detailed description of the variable cdpPnioMib2_tcpOutRsts.

Variable Overview

Variable Name
cdpPnioMib2_tcpOutRsts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1056
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib2_tcpOutRsts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib2_tcpOutRsts	String	22	

Read Variable Response:				
`sRA cdpPnioMib2_tcpOutRsts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib2_tcpOutRsts	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib2_tcpOutRsts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib2_tcpOutRsts	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib2_tcpOutRsts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib2_tcpOutRsts	String	22	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib2_tcpOutRsts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib2_tcpOutRsts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib2_tcpOutRsts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib2_tcpOutRsts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.6. Group: Profinet_Diagnosis_Mib3_grp

2.33.6.1. Variable: cdpPnioMib3_ifNumber

The following section contains a detailed description of the variable cdpPnioMib3_ifNumber.

Variable Overview

Variable Name
cdpPnioMib3_ifNumber

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1057
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ifNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifNumber	String	20	

Read Variable Response:

```
sRA cdpPnioMib3_ifNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifNumber	String	20	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ifNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifNumber	String	20	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ifNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib3_ifNumber				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib3_ifNumber	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ifNumber[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ifNumber 3[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ifNumber 3[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ifNumber[ETX]

2.33.6.2. Variable: cdpPnioMib3_ifSpeed

The following section contains a detailed description of the variable cdpPnioMib3_ifSpeed.

Variable Overview

Variable Name
cdpPnioMib3_ifSpeed

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1058
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifSpeed	String	19	

Read Variable Response:				
`sRA cdpPnioMib3_ifSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifSpeed	String	19	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ifSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifSpeed	String	19	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ifSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifSpeed	String	19	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifSpeed[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifSpeed 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifSpeed 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifSpeed[ETX]`

© SICK AG - Germany - All rights reserved

2.33.6.3. Variable: cdpPnioMib3_ifPhysAddress

The following section contains a detailed description of the variable cdpPnioMib3_ifPhysAddress.

Variable Overview

Variable Name
cdpPnioMib3_ifPhysAddress

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1059
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	6
Default Value	{0,6,119,0,0,0}
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:
`sRN cdpPnioMib3_ifPhysAddress`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifPhysAddress	String	25	

Read Variable Response:
`sRA cdpPnioMib3_ifPhysAddress <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifPhysAddress	String	25	
Variable Data	data	Array	6	

Write Variable:
`sWN cdpPnioMib3_ifPhysAddress <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifPhysAddress	String	25	
Variable Data	data	Array	6	

Write Variable Response:
`sWA cdpPnioMib3_ifPhysAddress`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib3_ifPhysAddress				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib3_ifPhysAddress	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ifPhysAddress[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ifPhysAddress 0 6 77 0 0 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ifPhysAddress 0 6 77 0 0 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ifPhysAddress[ETX]

2.33.6.4. Variable: cdpPnioMib3_ifOperStatus

The following section contains a detailed description of the variable cdpPnioMib3_ifOperStatus.

Variable Overview

Variable Name
cdpPnioMib3_ifOperStatus

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1060
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifOperStatus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifOperStatus	String	24	

Read Variable Response:				
`sRA cdpPnioMib3_ifOperStatus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifOperStatus	String	24	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ifOperStatus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifOperStatus	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ifOperStatus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifOperStatus	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifOperStatus[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifOperStatus 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifOperStatus 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifOperStatus[ETX]`

© SICK AG - Germany - All rights reserved

2.33.6.5. Variable: cdpPnioMib3_ifLastChange

The following section contains a detailed description of the variable cdpPnioMib3_ifLastChange.

Variable Overview

Variable Name
cdpPnioMib3_ifLastChange

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1061
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ifLastChange
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifLastChange	String	24	

Read Variable Response:

```
sRA cdpPnioMib3_ifLastChange <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifLastChange	String	24	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ifLastChange <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifLastChange	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ifLastChange
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifLastChange	String	24	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifLastChange[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifLastChange 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifLastChange 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifLastChange[ETX]`

2.33.6.6. Variable: cdpPnioMib3_ifInOctets

The following section contains a detailed description of the variable cdpPnioMib3_ifInOctets.

Variable Overview

Variable Name
cdpPnioMib3_ifInOctets

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1062
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifInOctets`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifInOctets	String	22	

Read Variable Response:				
`sRA cdpPnioMib3_ifInOctets <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifInOctets	String	22	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_ifInOctets <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifInOctets	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_ifInOctets				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifInOctets	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ifInOctets[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ifInOctets 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ifInOctets 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ifInOctets[ETX]

2.33.6.7. Variable: cdpPnioMib3_ifInUcastPkts

The following section contains a detailed description of the variable cdpPnioMib3_ifInUcastPkts.

Variable Overview

Variable Name
cdpPnioMib3_ifInUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1063
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifInUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifInUcastPkts	String	25	

Read Variable Response:				
`sRA cdpPnioMib3_ifInUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifInUcastPkts	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ifInUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifInUcastPkts	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ifInUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifInUcastPkts	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifInUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifInUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifInUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifInUcastPkts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.6.8. Variable: cdpPnioMib3_ifInNUcastPkts

The following section contains a detailed description of the variable cdpPnioMib3_ifInNUcastPkts.

Variable Overview

Variable Name
cdpPnioMib3_ifInNUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1064
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ifInNUcastPkts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifInNUcastPkts	String	26	

Read Variable Response:

```
sRA cdpPnioMib3_ifInNUcastPkts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifInNUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ifInNUcastPkts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifInNUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ifInNUcastPkts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifInNUcastPkts	String	26	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifInNUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifInNUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifInNUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifInNUcastPkts[ETX]`

2.33.6.9. Variable: cdpPnioMib3_ifInDiscards

The following section contains a detailed description of the variable cdpPnioMib3_ifInDiscards.

Variable Overview

Variable Name
cdpPnioMib3_ifInDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1065
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifInDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifInDiscards	String	24	

Read Variable Response:				
`sRA cdpPnioMib3_ifInDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifInDiscards	String	24	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_ifInDiscards <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifInDiscards	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_ifInDiscards				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifInDiscards	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ifInDiscards[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ifInDiscards 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ifInDiscards 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ifInDiscards[ETX]

2.33.6.10. Variable: cdpPnioMib3_ifInErrors

The following section contains a detailed description of the variable cdpPnioMib3_ifInErrors.

Variable Overview

Variable Name
cdpPnioMib3_ifInErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1066
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifInErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifInErrors	String	22	

Read Variable Response:				
`sRA cdpPnioMib3_ifInErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifInErrors	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ifInErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifInErrors	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ifInErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifInErrors	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifInErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifInErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifInErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifInErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.6.11. Variable: cdpPnioMib3_ifOutOctets

The following section contains a detailed description of the variable cdpPnioMib3_ifOutOctets.

Variable Overview

Variable Name
cdpPnioMib3_ifOutOctets

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1067
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ifOutOctets
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifOutOctets	String	23	

Read Variable Response:

```
sRA cdpPnioMib3_ifOutOctets <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifOutOctets	String	23	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ifOutOctets <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifOutOctets	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ifOutOctets
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifOutOctets	String	23	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifOutOctets[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifOutOctets 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifOutOctets 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifOutOctets[ETX]`

2.33.6.12. Variable: cdpPnioMib3_ifOutUcastPkts

The following section contains a detailed description of the variable cdpPnioMib3_ifOutUcastPkts.

Variable Overview

Variable Name
cdpPnioMib3_ifOutUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1068
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifOutUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifOutUcastPkts	String	26	

Read Variable Response:				
`sRA cdpPnioMib3_ifOutUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifOutUcastPkts	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_ifOutUcastPkts <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifOutUcastPkts	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_ifOutUcastPkts				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifOutUcastPkts	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ifOutUcastPkts[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ifOutUcastPkts 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ifOutUcastPkts 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ifOutUcastPkts[ETX]

2.33.6.13. Variable: cdpPnioMib3_ifOutNUcastPkts

The following section contains a detailed description of the variable cdpPnioMib3_ifOutNUcastPkts.

Variable Overview

Variable Name
cdpPnioMib3_ifOutNUcastPkts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1069
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifOutNUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifOutNUcastPkts	String	27	

Read Variable Response:				
`sRA cdpPnioMib3_ifOutNUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifOutNUcastPkts	String	27	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ifOutNUcastPkts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifOutNUcastPkts	String	27	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ifOutNUcastPkts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifOutNUcastPkts	String	27	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifOutNUcastPkts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifOutNUcastPkts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifOutNUcastPkts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifOutNUcastPkts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.6.14. Variable: cdpPnioMib3_ifOutDiscards

The following section contains a detailed description of the variable cdpPnioMib3_ifOutDiscards.

Variable Overview

Variable Name
cdpPnioMib3_ifOutDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1070
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ifOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifOutDiscards	String	25	

Read Variable Response:

```
sRA cdpPnioMib3_ifOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ifOutDiscards <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ifOutDiscards
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifOutDiscards	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifOutDiscards[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifOutDiscards 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifOutDiscards 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifOutDiscards[ETX]`

2.33.6.15. Variable: cdpPnioMib3_ifOutErrors

The following section contains a detailed description of the variable cdpPnioMib3_ifOutErrors.

Variable Overview

Variable Name
cdpPnioMib3_ifOutErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1071
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ifOutErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ifOutErrors	String	23	

Read Variable Response:				
`sRA cdpPnioMib3_ifOutErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ifOutErrors	String	23	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN cdpPnioMib3_ifOutErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ifOutErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ifOutErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ifOutErrors	String	23	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ifOutErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ifOutErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ifOutErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ifOutErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.7. Group: Profinet_Diagnosis_Mib3_Optional_grp

2.33.7.1. Variable: cdpPnioMib3_ipInReceives

The following section contains a detailed description of the variable cdpPnioMib3_ipInReceives.

Variable Overview

Variable Name
cdpPnioMib3_ipInReceives

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1072
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ipInReceives
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ipInReceives	String	24	

Read Variable Response:

```
sRA cdpPnioMib3_ipInReceives <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ipInReceives	String	24	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ipInReceives <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ipInReceives	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ipInReceives
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioMib3_ipInReceives				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpPnioMib3_ipInReceives	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ipInReceives[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ipInReceives 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ipInReceives 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ipInReceives[ETX]

2.33.7.2. Variable: cdpPnioMib3_ipInHdrErrors

The following section contains a detailed description of the variable cdpPnioMib3_ipInHdrErrors.

Variable Overview

Variable Name
cdpPnioMib3_ipInHdrErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1073
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ipInHdrErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ipInHdrErrors	String	25	

Read Variable Response:				
`sRA cdpPnioMib3_ipInHdrErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ipInHdrErrors	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ipInHdrErrors <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ipInHdrErrors	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ipInHdrErrors`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ipInHdrErrors	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ipInHdrErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ipInHdrErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ipInHdrErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ipInHdrErrors[ETX]`

© SICK AG - Germany - All rights reserved

2.33.7.3. Variable: cdpPnioMib3_ipInAddrErrors

The following section contains a detailed description of the variable cdpPnioMib3_ipInAddrErrors.

Variable Overview

Variable Name
cdpPnioMib3_ipInAddrErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1074
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_ipInAddrErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ipInAddrErrors	String	26	

Read Variable Response:

```
sRA cdpPnioMib3_ipInAddrErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ipInAddrErrors	String	26	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_ipInAddrErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ipInAddrErrors	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_ipInAddrErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ipInAddrErrors	String	26	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ipInAddrErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ipInAddrErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ipInAddrErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ipInAddrErrors[ETX]`

2.33.7.4. Variable: cdpPnioMib3_ipInDiscards

The following section contains a detailed description of the variable cdpPnioMib3_ipInDiscards.

Variable Overview

Variable Name
cdpPnioMib3_ipInDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1075
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ipInDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ipInDiscards	String	24	

Read Variable Response:				
`sRA cdpPnioMib3_ipInDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ipInDiscards	String	24	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_ipInDiscards <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ipInDiscards	String	24	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_ipInDiscards				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ipInDiscards	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_ipInDiscards[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_ipInDiscards 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_ipInDiscards 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_ipInDiscards[ETX]

2.33.7.5. Variable: cdpPnioMib3_ipOutRequests

The following section contains a detailed description of the variable cdpPnioMib3_ipOutRequests.

Variable Overview

Variable Name
cdpPnioMib3_ipOutRequests

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1076
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ipOutRequests`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ipOutRequests	String	25	

Read Variable Response:				
`sRA cdpPnioMib3_ipOutRequests <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ipOutRequests	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ipOutRequests <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ipOutRequests	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ipOutRequests`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ipOutRequests	String	25	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ipOutRequests[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ipOutRequests 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ipOutRequests 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ipOutRequests[ETX]`

© SICK AG - Germany - All rights reserved

2.33.7.6. Variable: cdpPnioMib3_ipOutDiscards

The following section contains a detailed description of the variable cdpPnioMib3_ipOutDiscards.

Variable Overview

Variable Name
cdpPnioMib3_ipOutDiscards

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1077
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_ipOutDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_ipOutDiscards	String	25	

Read Variable Response:				
`sRA cdpPnioMib3_ipOutDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_ipOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_ipOutDiscards <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_ipOutDiscards	String	25	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_ipOutDiscards`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_ipOutDiscards	String	25	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_ipOutDiscards[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_ipOutDiscards 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_ipOutDiscards 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_ipOutDiscards[ETX]`

2.33.7.7. Variable: cdpPnioMib3_udpInDatagrams

The following section contains a detailed description of the variable cdpPnioMib3_udpInDatagrams.

Variable Overview

Variable Name
cdpPnioMib3_udpInDatagrams

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1078
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_udpInDatagrams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_udpInDatagrams	String	26	

Read Variable Response:				
`sRA cdpPnioMib3_udpInDatagrams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_udpInDatagrams	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_udpInDatagrams <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_udpInDatagrams	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_udpInDatagrams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_udpInDatagrams	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_udpInDatagrams[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_udpInDatagrams 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_udpInDatagrams 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_udpInDatagrams[ETX]

2.33.7.8. Variable: cdpPnioMib3_udpNoPorts

The following section contains a detailed description of the variable cdpPnioMib3_udpNoPorts.

Variable Overview

Variable Name
cdpPnioMib3_udpNoPorts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1079
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_udpNoPorts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_udpNoPorts	String	22	

Read Variable Response:				
`sRA cdpPnioMib3_udpNoPorts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_udpNoPorts	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_udpNoPorts <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_udpNoPorts	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_udpNoPorts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_udpNoPorts	String	22	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_udpNoPorts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_udpNoPorts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_udpNoPorts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_udpNoPorts[ETX]`

© SICK AG - Germany - All rights reserved

2.33.7.9. Variable: cdpPnioMib3_udpInErrors

The following section contains a detailed description of the variable cdpPnioMib3_udpInErrors.

Variable Overview

Variable Name
cdpPnioMib3_udpInErrors

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1080
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_udpInErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_udpInErrors	String	23	

Read Variable Response:

```
sRA cdpPnioMib3_udpInErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_udpInErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_udpInErrors <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_udpInErrors	String	23	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_udpInErrors
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_udpInErrors	String	23	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_udpInErrors[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_udpInErrors 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_udpInErrors 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_udpInErrors[ETX]`

2.33.7.10. Variable: cdpPnioMib3_udpOutDatagrams

The following section contains a detailed description of the variable cdpPnioMib3_udpOutDatagrams.

Variable Overview

Variable Name
cdpPnioMib3_udpOutDatagrams

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1081
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_udpOutDatagrams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_udpOutDatagrams	String	27	

Read Variable Response:				
`sRA cdpPnioMib3_udpOutDatagrams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_udpOutDatagrams	String	27	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_udpOutDatagrams <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_udpOutDatagrams	String	27	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_udpOutDatagrams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_udpOutDatagrams	String	27	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_udpOutDatagrams[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_udpOutDatagrams 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_udpOutDatagrams 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_udpOutDatagrams[ETX]

2.33.7.11. Variable: cdpPnioMib3_tcpInSegs

The following section contains a detailed description of the variable cdpPnioMib3_tcpInSegs.

Variable Overview

Variable Name
cdpPnioMib3_tcpInSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1082
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_tcpInSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_tcpInSegs	String	21	

Read Variable Response:				
`sRA cdpPnioMib3_tcpInSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_tcpInSegs	String	21	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_tcpInSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_tcpInSegs	String	21	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_tcpInSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_tcpInSegs	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_tcpInSegs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_tcpInSegs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_tcpInSegs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_tcpInSegs[ETX]`

© SICK AG - Germany - All rights reserved

2.33.7.12. Variable: cdpPnioMib3_tcpOutSegs

The following section contains a detailed description of the variable cdpPnioMib3_tcpOutSegs.

Variable Overview

Variable Name
cdpPnioMib3_tcpOutSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1083
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_tcpOutSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_tcpOutSegs	String	22	

Read Variable Response:				
`sRA cdpPnioMib3_tcpOutSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_tcpOutSegs	String	22	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_tcpOutSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_tcpOutSegs	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_tcpOutSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_tcpOutSegs	String	22	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_tcpOutSegs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_tcpOutSegs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_tcpOutSegs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_tcpOutSegs[ETX]`

2.33.7.13. Variable: cdpPnioMib3_tcpRetransSegs

The following section contains a detailed description of the variable cdpPnioMib3_tcpRetransSegs.

Variable Overview

Variable Name
cdpPnioMib3_tcpRetransSegs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1084
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_tcpRetransSegs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_tcpRetransSegs	String	26	

Read Variable Response:				
`sRA cdpPnioMib3_tcpRetransSegs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_tcpRetransSegs	String	26	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN cdpPnioMib3_tcpRetransSegs <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_tcpRetransSegs	String	26	
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA cdpPnioMib3_tcpRetransSegs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_tcpRetransSegs	String	26	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioMib3_tcpRetransSegs[ETX]
Read Variable Response:	[STX]sRA cdpPnioMib3_tcpRetransSegs 0[ETX]
Write Variable:	[STX]sWN cdpPnioMib3_tcpRetransSegs 0[ETX]
Write Variable Response:	[STX]sWA cdpPnioMib3_tcpRetransSegs[ETX]

2.33.7.14. Variable: cdpPnioMib3_tcpInErrs

The following section contains a detailed description of the variable cdpPnioMib3_tcpInErrs.

Variable Overview

Variable Name
cdpPnioMib3_tcpInErrs

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1085
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioMib3_tcpInErrs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_tcpInErrs	String	21	

Read Variable Response:				
`sRA cdpPnioMib3_tcpInErrs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_tcpInErrs	String	21	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpPnioMib3_tcpInErrs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_tcpInErrs	String	21	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA cdpPnioMib3_tcpInErrs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_tcpInErrs	String	21	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_tcpInErrs[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_tcpInErrs 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_tcpInErrs 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_tcpInErrs[ETX]`

© SICK AG - Germany - All rights reserved

2.33.7.15. Variable: cdpPnioMib3_tcpOutRsts

The following section contains a detailed description of the variable cdpPnioMib3_tcpOutRsts.

Variable Overview

Variable Name
cdpPnioMib3_tcpOutRsts

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1086
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpPnioMib3_tcpOutRsts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioMib3_tcpOutRsts	String	22	

Read Variable Response:

```
sRA cdpPnioMib3_tcpOutRsts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioMib3_tcpOutRsts	String	22	
Variable Data	data	UDInt	4	

Write Variable:

```
sWN cdpPnioMib3_tcpOutRsts <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioMib3_tcpOutRsts	String	22	
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA cdpPnioMib3_tcpOutRsts
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioMib3_tcpOutRsts	String	22	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpPnioMib3_tcpOutRsts[ETX]`
Read Variable Response:	`[STX]sRA cdpPnioMib3_tcpOutRsts 0[ETX]`
Write Variable:	`[STX]sWN cdpPnioMib3_tcpOutRsts 0[ETX]`
Write Variable Response:	`[STX]sWA cdpPnioMib3_tcpOutRsts[ETX]`

© SICK AG - Germany - All rights reserved

2.34. Interface Block: ConfirmedMsgControl

2.34.1. Group: ConfirmMsgCtrlBitsIn

2.34.1.1. Variable: cdpCmCtrlBitsIn

The following section contains a detailed description of the variable cdpCmCtrlBitsIn.

Variable Overview

Variable Name
cdpCmCtrlBitsIn

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1087
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpCmCtrlBitsIn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmCtrlBitsIn	String	15	

Read Variable Response:				
`sRA cdpCmCtrlBitsIn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmCtrlBitsIn	String	15	
Variable Data	data	UInt	2	

Write Variable:				
`sWN cdpCmCtrlBitsIn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmCtrlBitsIn	String	15	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmCtrlBitsIn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmCtrlBitsIn	String	15	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmCtrlBitsIn[ETX]
Read Variable Response:	[STX]sRA cdpCmCtrlBitsIn 0[ETX]
Write Variable:	[STX]sWN cdpCmCtrlBitsIn 0[ETX]
Write Variable Response:	[STX]sWA cdpCmCtrlBitsIn[ETX]

© SICK AG - Germany - All rights reserved

2.34.2. Group: ConfirmMsgCtrlBitsOut

2.34.2.1. Variable: cdpCmCtrlBitsOut

The following section contains a detailed description of the variable cdpCmCtrlBitsOut.

Variable Overview

Variable Name
cdpCmCtrlBitsOut

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1088
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmCtrlBitsOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmCtrlBitsOut	String	16	

Read Variable Response:

```
sRA cdpCmCtrlBitsOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmCtrlBitsOut	String	16	
Variable Data	data	UInt	2	

Write Variable:

```
sWN cdpCmCtrlBitsOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmCtrlBitsOut	String	16	
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA cdpCmCtrlBitsOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmCtrlBitsOut				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpCmCtrlBitsOut	String	16	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmCtrlBitsOut[ETX]
Read Variable Response:	[STX]sRA cdpCmCtrlBitsOut 0[ETX]
Write Variable:	[STX]sWN cdpCmCtrlBitsOut 0[ETX]
Write Variable Response:	[STX]sWA cdpCmCtrlBitsOut[ETX]

© SICK AG - Germany - All rights reserved

2.34.3. Group: ConfirmMsgStatus

2.34.3.1. Variable: cdpCmStatus

The following section contains a detailed description of the variable cdpCmStatus.

Variable Overview

Variable Name	Description
cdpCmStatus	Status of CM module

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1089
Read-Access	Always
Write-Access	Service

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmStatus
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmStatus	String	11	Status of CM module

Read Variable Response:

```
sRA cdpCmStatus <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmStatus	String	11	Status of CM module
Variable Data	data	USInt	1	

Write Variable:

```
sWN cdpCmStatus <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmStatus	String	11	Status of CM module
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA cdpCmStatus
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmStatus				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpCmStatus	String	11	Status of CM module

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmStatus[ETX]
Read Variable Response:	[STX]sRA cdpCmStatus 0[ETX]
Write Variable:	[STX]sWN cdpCmStatus 0[ETX]
Write Variable Response:	[STX]sWA cdpCmStatus[ETX]

© SICK AG - Germany - All rights reserved

2.34.4. Group: ConfirmMsgConfig

2.34.4.1. Variable: cdpCmConfig

The following section contains a detailed description of the variable cdpCmConfig.

Variable Overview

Variable Name	Description
cdpCmConfig	Protocol configuration

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1090
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		WITH_HANDSHAKE	
	Value	Name	Description
	0	NO_HANDSHAKE	without handshake and without retry
	1	HANDSHAKE_NO_RETRY	handshake but without retry
	2	RETRY_NO_HANDSHAKE	retry but without handshake
	3	WITH_HANDSHAKE	with both handshake and retry

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmConfig
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmConfig	String	11	Protocol configuration

Read Variable Response:

```
sRA cdpCmConfig <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmConfig	String	11	Protocol configuration
Variable Data	data	Enum8	1	

Write Variable:

```
sWN cdpCmConfig <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmConfig	String	11	Protocol configuration
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmConfig				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmConfig	String	11	Protocol configuration

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmConfig[ETX]
Read Variable Response:	[STX]sRA cdpCmConfig 3[ETX]
Write Variable:	[STX]sWN cdpCmConfig 3[ETX]
Write Variable Response:	[STX]sWA cdpCmConfig[ETX]

2.34.4.2. Variable: cdpCmInFrameLength

The following section contains a detailed description of the variable cdpCmInFrameLength.

Variable Overview

Variable Name	Description
cdpCmInFrameLength	Length of input frames

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1091
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN cdpCmInFrameLength`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmInFrameLength	String	18	Length of input frames

Read Variable Response:				
`sRA cdpCmInFrameLength <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmInFrameLength	String	18	Length of input frames
Variable Data	data	UInt	2	

Write Variable:				
`sWN cdpCmInFrameLength <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmInFrameLength	String	18	Length of input frames
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA cdpCmInFrameLength`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmInFrameLength	String	18	Length of input frames

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpCmInFrameLength[ETX]`
Read Variable Response:	`[STX]sRA cdpCmInFrameLength 0[ETX]`
Write Variable:	`[STX]sWN cdpCmInFrameLength 0[ETX]`
Write Variable Response:	`[STX]sWA cdpCmInFrameLength[ETX]`

© SICK AG - Germany - All rights reserved

2.34.4.3. Variable: cdpCmOutFrameLength

The following section contains a detailed description of the variable cdpCmOutFrameLength.

Variable Overview

Variable Name	Description
cdpCmOutFrameLength	Length of output frames

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1092
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmOutFrameLength
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmOutFrameLength	String	19	Length of output frames

Read Variable Response:

```
sRA cdpCmOutFrameLength <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmOutFrameLength	String	19	Length of output frames
Variable Data	data	UInt	2	

Write Variable:

```
sWN cdpCmOutFrameLength <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmOutFrameLength	String	19	Length of output frames
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA cdpCmOutFrameLength
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmOutFrameLength	String	19	Length of output frames

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpCmOutFrameLength[ETX]`
Read Variable Response:	`[STX]sRA cdpCmOutFrameLength 0[ETX]`
Write Variable:	`[STX]sWN cdpCmOutFrameLength 0[ETX]`
Write Variable Response:	`[STX]sWA cdpCmOutFrameLength[ETX]`

2.34.4.4. Variable: cdpCmProtocolVariant

The following section contains a detailed description of the variable cdpCmProtocolVariant.

Variable Overview

Variable Name	Description
cdpCmProtocolVariant	Protocol variant

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1093
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		STANDARD	
	Value	Name	Description
	0	STANDARD	compatible to CDF600 PROFINET: Telegram length field is in little-endian byte order (Intel format)
	1	ETHERNETIP	compatible to CLV6xx, RFU63x, Lector6xx EtherNet/IP: Telegram length field is in big-endian byte order (Motorola format)

Variable Telegram Syntax

Read Variable:				
`sRN cdpCmProtocolVariant`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmProtocolVariant	String	20	Protocol variant

Read Variable Response:				
`sRA cdpCmProtocolVariant <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmProtocolVariant	String	20	Protocol variant
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN cdpCmProtocolVariant <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmProtocolVariant	String	20	Protocol variant
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA cdpCmProtocolVariant`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmProtocolVariant	String	20	Protocol variant

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN cdpCmProtocolVariant[ETX]`
Read Variable Response:	`[STX]sRA cdpCmProtocolVariant 0[ETX]`
Write Variable:	`[STX]sWN cdpCmProtocolVariant 0[ETX]`
Write Variable Response:	`[STX]sWA cdpCmProtocolVariant[ETX]`

© SICK AG - Germany - All rights reserved

2.34.5. Group: ConfirmMsgInput

2.34.5.1. Variable: cdpCmInMsgLength

The following section contains a detailed description of the variable cdpCmInMsgLength.

Variable Overview

Variable Name	Description
cdpCmInMsgLength	Length of current input message

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1094
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmInMsgLength
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmInMsgLength	String	16	Length of current input message

Read Variable Response:

```
sRA cdpCmInMsgLength <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmInMsgLength	String	16	Length of current input message
Variable Data	data	UInt	2	

Write Variable:

```
sWN cdpCmInMsgLength <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmInMsgLength	String	16	Length of current input message
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA cdpCmInMsgLength
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmInMsgLength				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	cdpCmInMsgLength	String	16	Length of current input message

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmInMsgLength[ETX]
Read Variable Response:	[STX]sRA cdpCmInMsgLength 0[ETX]
Write Variable:	[STX]sWN cdpCmInMsgLength 0[ETX]
Write Variable Response:	[STX]sWA cdpCmInMsgLength[ETX]

© SICK AG - Germany - All rights reserved

2.34.6. Group: ConfirmMsgOutput

2.34.6.1. Variable: cdpCmOutMsg

The following section contains a detailed description of the variable cdpCmOutMsg.

Variable Overview

Variable Name	Description
cdpCmOutMsg	Length and data of current output message

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1095
Read-Access	Always
Write-Access	Service

Array		
Length		0..4094
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmOutMsg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmOutMsg	String	11	Length and data of current output message

Read Variable Response:

```
sRA cdpCmOutMsg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmOutMsg	String	11	Length and data of current output message
Variable Data	data	Array	4094	

Write Variable:

```
sWN cdpCmOutMsg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmOutMsg	String	11	Length and data of current output message
Variable Data	data	Array	4094	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmOutMsg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmOutMsg	String	11	Length and data of current output message

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmOutMsg[ETX]
Read Variable Response:	[STX]sRA cdpCmOutMsg 0[ETX]
Write Variable:	[STX]sWN cdpCmOutMsg 0[ETX]
Write Variable Response:	[STX]sWA cdpCmOutMsg[ETX]

© SICK AG - Germany - All rights reserved

2.35. Interface Block: ConfirmMsgFrames

2.35.1. Group: ConfirmMsgInputFrame

2.35.1.1. Variable: cdpCmInternalDataIn

The following section contains a detailed description of the variable cdpCmInternalDataIn.

Variable Overview

Variable Name	Description
cdpCmInternalDataIn	Buffer for input frame

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1096
Read-Access	Always
Write-Access	Service

Array		
Length		128
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmInternalDataIn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmInternalDataIn	String	19	Buffer for input frame

Read Variable Response:

```
sRA cdpCmInternalDataIn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmInternalDataIn	String	19	Buffer for input frame
Variable Data	data	Array	128	

Write Variable:

```
sWN cdpCmInternalDataIn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmInternalDataIn	String	19	Buffer for input frame
Variable Data	data	Array	128	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmInternalDataIn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmInternalDataIn	String	19	Buffer for input frame

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmInternalDataIn[ETX]
Read Variable Response:	[STX]sRA cdpCmInternalDataIn 0 0 0

2.35.2. Group: ConfirmMsgOutputFrame

2.35.2.1. Variable: cdpCmInternalDataOut

The following section contains a detailed description of the variable cdpCmInternalDataOut.

Variable Overview

Variable Name	Description
cdpCmInternalDataOut	Buffer for output frame

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1097
Read-Access	Always
Write-Access	Service

Array		
Length		128
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN cdpCmInternalDataOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpCmInternalDataOut	String	20	Buffer for output frame

Read Variable Response:

```
sRA cdpCmInternalDataOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpCmInternalDataOut	String	20	Buffer for output frame
Variable Data	data	Array	128	

Write Variable:

```
sWN cdpCmInternalDataOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpCmInternalDataOut	String	20	Buffer for output frame
Variable Data	data	Array	128	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpCmInternalDataOut				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpCmInternalDataOut	String	20	Buffer for output frame

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpCmInternalDataOut[ETX]
Read Variable Response:	[STX]sRA cdpCmInternalDataOut 0 0 0

2.36. Interface Block: DigIORegisters

2.36.1. Group: DigIORegisters

2.36.1.1. Variable: cdpDigIoReg0

The following section contains a detailed description of the variable cdpDigIoReg0.

Variable Overview

Variable Name
cdpDigIoReg0

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1098
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN cdpDigIoReg0`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpDigIoReg0	String	12	

Read Variable Response:				
`sRA cdpDigIoReg0 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpDigIoReg0	String	12	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN cdpDigIoReg0 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpDigIoReg0	String	12	
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpDigIoReg0				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpDigIoReg0	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpDigIoReg0[ETX]
Read Variable Response:	[STX]sRA cdpDigIoReg0 0[ETX]
Write Variable:	[STX]sWN cdpDigIoReg0 0[ETX]
Write Variable Response:	[STX]sWA cdpDigIoReg0[ETX]

© SICK AG - Germany - All rights reserved

2.37. Interface Block: GeneralCfgApp

2.37.1. Group: System

2.37.1.1. Variable: SYParaPasswordGuarded

The following section contains a detailed description of the variable SYParaPasswordGuarded.

Variable Overview

Variable Name	Description
SYParaPasswordGuarded	If true parametrization if password guarded. (Parameter is only mentioned by SOPAS ET)

Communication Name	SYPwGuarded
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1099
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN SYPwGuarded
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SYPwGuarded	String	11	If true parametrization if password guarded. (Parameter is only mentioned by SOPAS ET)

Read Variable Response:

```
sRA SYPwGuarded <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SYPwGuarded	String	11	If true parametrization if password guarded. (Parameter is only mentioned by SOPAS ET)
Variable Data	data	Bool	1	

Write Variable:

```
sWN SYPwGuarded <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SYPwGuarded	String	11	If true parametrization if password guarded. (Parameter is only mentioned by SOPAS ET)
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SYPwGuarded				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SYPwGuarded	String	11	If true parametrization if password guarded. (Parameter is only mentioned by SOPAS ET)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SYPwGuarded[ETX]
Read Variable Response:	[STX]sRA SYPwGuarded 0[ETX]
Write Variable:	[STX]sWN SYPwGuarded 0[ETX]
Write Variable Response:	[STX]sWA SYPwGuarded[ETX]

2.37.1.2. Variable: SYNoQuickstart

The following section contains a detailed description of the variable SYNoQuickstart.

Variable Overview

Variable Name	Description
SYNoQuickstart	If true there is no quickstart shown if device is added. (Parameter is only mentioned by SOPAS ET)

Communication Name	SYNoQkStrt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1100
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SYNoQkStrt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SYNoQkStrt	String	10	If true there is no quickstart shown if device is added. (Parameter is only mentioned by SOPAS ET)

Read Variable Response:				
`sRA SYNoQkStrt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SYNoQkStrt	String	10	If true there is no quickstart shown if device is added. (Parameter is only mentioned by SOPAS ET)
Variable Data	data	Bool	1	

Write Variable:				
`sWN SYNoQkStrt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SYNoQkStrt	String	10	If true there is no quickstart shown if device is added. (Parameter is only mentioned by SOPAS ET)
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SYNoQkStrt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SYNoQkStrt	String	10	If true there is no quickstart shown if device is added. (Parameter is only mentioned by SOPAS ET)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SYNoQkStrt[ETX]`
Read Variable Response:	`[STX]sRA SYNoQkStrt 0[ETX]`
Write Variable:	`[STX]sWN SYNoQkStrt 0[ETX]`
Write Variable Response:	`[STX]sWA SYNoQkStrt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2. Group: Camera

2.37.2.1. Variable: UseFrameRate

The following section contains a detailed description of the variable UseFrameRate.

Variable Overview

Variable Name	Description
UseFrameRate	Flag to activate the user defined frame rate

Communication Name	CAMUseFrameRate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1106
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN CAMUseFrameRate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMUseFrameRate	String	15	Flag to activate the user defined frame rate

Read Variable Response:

```
sRA CAMUseFrameRate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMUseFrameRate	String	15	Flag to activate the user defined frame rate
Variable Data	data	Bool	1	

Write Variable:

```
sWN CAMUseFrameRate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMUseFrameRate	String	15	Flag to activate the user defined frame rate
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CAMUseFrameRate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMUseFrameRate				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CAMUseFrameRate	String	15	Flag to activate the user defined frame rate

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMUseFrameRate[ETX]
Read Variable Response:	[STX]sRA CAMUseFrameRate 1[ETX]
Write Variable:	[STX]sWN CAMUseFrameRate 1[ETX]
Write Variable Response:	[STX]sWA CAMUseFrameRate[ETX]

2.37.2.2. Variable: ImgAcqMode

The following section contains a detailed description of the variable ImgAcqMode.

Variable Overview

Variable Name	Description
ImgAcqMode	Mode of image acquisition

Communication Name	CAMAcqMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1108
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Continuous	
	Value	Name	Description
	0	Continuous	
	1	Burst	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMAcqMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMAcqMode	String	10	Mode of image acquisition

Read Variable Response:				
`sRA CAMAcqMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMAcqMode	String	10	Mode of image acquisition
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMAcqMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMAcqMode	String	10	Mode of image acquisition
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CAMAcqMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMAcqMode	String	10	Mode of image acquisition

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMAcqMode[ETX]`
Read Variable Response:	`[STX]sRA CAMAcqMode 0[ETX]`
Write Variable:	`[STX]sWN CAMAcqMode 0[ETX]`
Write Variable Response:	`[STX]sWA CAMAcqMode[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.3. Variable: ImgAcqBurstModeNumImages

The following section contains a detailed description of the variable ImgAcqBurstModeNumImages.

Variable Overview

Variable Name	Description
ImgAcqBurstModeNumImages	Number of images taken in burst mode

Communication Name	CAMBurstImgNum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1109
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..64000
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMBurstImgNum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMBurstImgNum	String	14	Number of images taken in burst mode

Read Variable Response:

```
sRA CAMBurstImgNum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMBurstImgNum	String	14	Number of images taken in burst mode
Variable Data	data	UDInt	4	

Write Variable:

```
sWN CAMBurstImgNum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMBurstImgNum	String	14	Number of images taken in burst mode
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA CAMBurstImgNum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMBurstImgNum	String	14	Number of images taken in burst mode

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMBurstImgNum[ETX]`
Read Variable Response:	`[STX]sRA CAMBurstImgNum 1[ETX]`
Write Variable:	`[STX]sWN CAMBurstImgNum 1[ETX]`
Write Variable Response:	`[STX]sWA CAMBurstImgNum[ETX]`

2.37.2.4. Variable: UseNumFramesInQueue

The following section contains a detailed description of the variable UseNumFramesInQueue.

Variable Overview

Variable Name	Description
UseNumFramesInQueue	Flag to activate the NumFramesInQueue parameter

Communication Name	CAMUseNumFramesQueue
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1110
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CAMUseNumFramesQueue
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMUseNumFramesQueue	String	20	Flag to activate the NumFramesInQueue parameter

Read Variable Response:

```
sRA CAMUseNumFramesQueue <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMUseNumFramesQueue	String	20	Flag to activate the NumFramesInQueue parameter
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CAMUseNumFramesQueue <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMUseNumFramesQueue	String	20	Flag to activate the NumFramesInQueue parameter
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CAMUseNumFramesQueue				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMUseNumFramesQueue	String	20	Flag to activate the NumFramesInQueue parameter

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMUseNumFramesQueue[ETX]
Read Variable Response:	[STX]sRA CAMUseNumFramesQueue 0[ETX]
Write Variable:	[STX]sWN CAMUseNumFramesQueue 0[ETX]
Write Variable Response:	[STX]sWA CAMUseNumFramesQueue[ETX]

2.37.2.5. Variable: NumFramesInQueue

The following section contains a detailed description of the variable NumFramesInQueue.

Variable Overview

Variable Name	Description
NumFramesInQueue	Number of images that are stored in the internal frame queue

Communication Name	CAMNumFramesQueue
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1111
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	4..160
Initialisation	90
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMNumFramesQueue`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMNumFramesQueue	String	17	Number of images that are stored in the internal frame queue

Read Variable Response:				
`sRA CAMNumFramesQueue <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMNumFramesQueue	String	17	Number of images that are stored in the internal frame queue
Variable Data	data	UDInt	4	

Write Variable:				
`sWN CAMNumFramesQueue <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMNumFramesQueue	String	17	Number of images that are stored in the internal frame queue
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA CAMNumFramesQueue`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMNumFramesQueue	String	17	Number of images that are stored in the internal frame queue

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMNumFramesQueue[ETX]`
Read Variable Response:	`[STX]sRA CAMNumFramesQueue 5A[ETX]`
Write Variable:	`[STX]sWN CAMNumFramesQueue 5A[ETX]`
Write Variable Response:	`[STX]sWA CAMNumFramesQueue[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.6. Variable: Brightness

The following section contains a detailed description of the variable Brightness.

Variable Overview

Variable Name	Description
Brightness	Brightness of the image (gain)

Communication Name	CAMBrightness
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1113
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	50
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMBrightness
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMBrightness	String	13	Brightness of the image (gain)

Read Variable Response:

```
sRA CAMBrightness <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMBrightness	String	13	Brightness of the image (gain)
Variable Data	data	UInt	2	

Write Variable:

```
sWN CAMBrightness <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMBrightness	String	13	Brightness of the image (gain)
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA CAMBrightness
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMBrightness	String	13	Brightness of the image (gain)

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMBrightness[ETX]`
Read Variable Response:	`[STX]sRA CAMBrightness 32[ETX]`
Write Variable:	`[STX]sWN CAMBrightness 32[ETX]`
Write Variable Response:	`[STX]sWA CAMBrightness[ETX]`

2.37.2.7. Variable: Contrast

The following section contains a detailed description of the variable Contrast.

Variable Overview

Variable Name	Description
Contrast	Contrast of the image (gamma correction)

Communication Name	CAMContrast
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1115
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	10
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN CAMContrast`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMContrast	String	11	Contrast of the image (gamma correction)

Read Variable Response:

`sRA CAMContrast <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMContrast	String	11	Contrast of the image (gamma correction)
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CAMContrast <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMContrast	String	11	Contrast of the image (gamma correction)
Variable Data	data	UInt	2	

Write Variable Response:				
sWA CAMContrast				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMContrast	String	11	Contrast of the image (gamma correction)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMContrast[ETX]
Read Variable Response:	[STX]sRA CAMContrast A[ETX]
Write Variable:	[STX]sWN CAMContrast A[ETX]
Write Variable Response:	[STX]sWA CAMContrast[ETX]

2.37.2.8. Variable: GammaCorrectionTurningPoint10bit

The following section contains a detailed description of the variable GammaCorrectionTurningPoint10bit.

Variable Overview

Variable Name	Description
GammaCorrectionTurningPoint10bit	Contrast of the image (gamma correction) with 10 bit resolution

Communication Name	CAMGammaTurningPoint10bit
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1116
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	512
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMGammaTurningPoint10bit`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMGammaTurningPoint10bit	String	25	Contrast of the image (gamma correction) with 10 bit resolution

Read Variable Response:				
`sRA CAMGammaTurningPoint10bit <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMGammaTurningPoint10bit	String	25	Contrast of the image (gamma correction) with 10 bit resolution
Variable Data	data	UInt	2	

Write Variable:				
`sWN CAMGammaTurningPoint10bit <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMGammaTurningPoint10bit	String	25	Contrast of the image (gamma correction) with 10 bit resolution
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CAMGammaTurningPoint10bit`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMGammaTurningPoint10bit	String	25	Contrast of the image (gamma correction) with 10 bit resolution

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMGammaTurningPoint10bit[ETX]`
Read Variable Response:	`[STX]sRA CAMGammaTurningPoint10bit 200[ETX]`
Write Variable:	`[STX]sWN CAMGammaTurningPoint10bit 200[ETX]`
Write Variable Response:	`[STX]sWA CAMGammaTurningPoint10bit[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.9. Variable: NoiseReductionFilter

The following section contains a detailed description of the variable NoiseReductionFilter.

Variable Overview

Variable Name	Description
NoiseReductionFilter	Noise reduction filter (median filter)

Communication Name	CAMNoiseRedFilter
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1117
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_RANK_MEDIAN_OFF	
	1	TX_RANK_MEDIAN_3X3	

Variable Telegram Syntax

Read Variable:				
`sRN CAMNoiseRedFilter`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMNoiseRedFilter	String	17	Noise reduction filter (median filter)

Read Variable Response:				
`sRA CAMNoiseRedFilter <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMNoiseRedFilter	String	17	Noise reduction filter (median filter)
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMNoiseRedFilter <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMNoiseRedFilter	String	17	Noise reduction filter (median filter)
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CAMNoiseRedFilter`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMNoiseRedFilter	String	17	Noise reduction filter (median filter)

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMNoiseRedFilter[ETX]`
Read Variable Response:	`[STX]sRA CAMNoiseRedFilter 0[ETX]`
Write Variable:	`[STX]sWN CAMNoiseRedFilter 0[ETX]`
Write Variable Response:	`[STX]sWA CAMNoiseRedFilter[ETX]`

2.37.2.10. Variable: MorphologicalFilter

The following section contains a detailed description of the variable MorphologicalFilter.

Variable Overview

Variable Name
MorphologicalFilter

Communication Name	CAMRMorphFilter
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1118
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-4..4
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN CAMRMorphFilter`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMRMorphFilter	String	15	

Read Variable Response:

`sRA CAMRMorphFilter <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMRMorphFilter	String	15	
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CAMRMorphFilter <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMRMorphFilter	String	15	
Variable Data	data	DInt	4	

Write Variable Response:				
sWA CAMRMorphFilter				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMRMorphFilter	String	15	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMRMorphFilter[ETX]
Read Variable Response:	[STX]sRA CAMRMorphFilter 0[ETX]
Write Variable:	[STX]sWN CAMRMorphFilter 0[ETX]
Write Variable Response:	[STX]sWA CAMRMorphFilter[ETX]

2.37.2.11. Variable: InternalIlluminationMode

The following section contains a detailed description of the variable InternalIlluminationMode.

Variable Overview

Variable Name	Description
InternalIlluminationMode	Enables or disables internal illumination LEDs.

Communication Name	CAMInternalIllum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1119
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		On	
	Value	Name	Description
	0	Off	
	1	On	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMInternalIllum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMInternalIllum	String	16	Enables or disables internal illumination LEDs.

Read Variable Response:				
`sRA CAMInternalIllum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMInternalIllum	String	16	Enables or disables internal illumination LEDs.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMInternalIllum <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMInternalIllum	String	16	Enables or disables internal illumination LEDs.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CAMInternalIllum`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMInternalIllum	String	16	Enables or disables internal illumination LEDs.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMInternalIllum[ETX]`
Read Variable Response:	`[STX]sRA CAMInternalIllum 1[ETX]`
Write Variable:	`[STX]sWN CAMInternalIllum 1[ETX]`
Write Variable Response:	`[STX]sWA CAMInternalIllum[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.12. Variable: InternalIlluminationColor

The following section contains a detailed description of the variable InternalIlluminationColor.

Variable Overview

Variable Name	Description
InternalIlluminationColor	Selects the internal illumination color if the device supports it.

Communication Name	CAMInternalIllumColor
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1120
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Both	
	Value	Name	Description
	0	Color1	
	1	Color2	
	2	Both	

Variable Telegram Syntax

Read Variable:				
`sRN CAMInternalIllumColor`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMInternalIllumColor	String	21	Selects the internal illumination color if the device supports it.

Read Variable Response:				
`sRA CAMInternalIllumColor <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMInternalIllumColor	String	21	Selects the internal illumination color if the device supports it.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMInternalIllumColor <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMInternalIllumColor	String	21	Selects the internal illumination color if the device supports it.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMInternalIllumColor				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMInternalIllumColor	String	21	Selects the internal illumination color if the device supports it.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMInternalIllumColor[ETX]
Read Variable Response:	[STX]sRA CAMInternalIllumColor 2[ETX]
Write Variable:	[STX]sWN CAMInternalIllumColor 2[ETX]
Write Variable Response:	[STX]sWA CAMInternalIllumColor[ETX]

2.37.2.13. Variable: ExternalIlluminationMode

The following section contains a detailed description of the variable ExternalIlluminationMode.

Variable Overview

Variable Name	Description
ExternalIlluminationMode	Control of an external illumination device

Communication Name	CAMExternalIllum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1121
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Enum8			
Default Value		TX_EXTERNAL_ILLUMINATION_OFF	
	Value	Name	Description
	0	TX_EXTERNAL_ILLUMINATION_OFF	
	1	TX_EXTERNAL_ILLUMINATION_ICL110	
	2	TX_EXTERNAL_ILLUMINATION_ICL170	
	3	TX_EXTERNAL_ILLUMINATION_ICL260	
	4	TX_EXTERNAL_ILLUMINATION_ICL280	
	5	TX_EXTERNAL_ILLUMINATION_ICL280_F202S01	
	6	TX_EXTERNAL_ILLUMINATION_ICL300	
	7	TX_EXTERNAL_ILLUMINATION_ICL300_F202S01	
	8	TX_EXTERNAL_ILLUMINATION_ACTIVE_LOW_CONTINUOUS	
	9	TX_EXTERNAL_ILLUMINATION_ACTIVE_LOW_FLASHING	
	10	TX_EXTERNAL_ILLUMINATION_ACTIVE_HIGH_CONTINUOUS	
	11	TX_EXTERNAL_ILLUMINATION_ACTIVE_HIGH_FLASHING	

Variable Telegram Syntax

Read Variable:

```
sRN CAMExternalIllum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMExternalIllum	String	16	Control of an external illumination device

Read Variable Response:

```
sRA CAMExternalIllum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMExternalIllum	String	16	Control of an external illumination device
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CAMExternalIllum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMExternalIllum	String	16	Control of an external illumination device
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA CAMExternalIllum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMExternalIllum	String	16	Control of an external illumination device

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMExternalIllum[ETX]`
Read Variable Response:	`[STX]sRA CAMExternalIllum 0[ETX]`
Write Variable:	`[STX]sWN CAMExternalIllum 0[ETX]`
Write Variable Response:	`[STX]sWA CAMExternalIllum[ETX]`

2.37.2.14. Variable: ExternalLightConnectorMode

The following section contains a detailed description of the variable ExternalLightConnectorMode.

Variable Overview

Variable Name	Description
ExternalLightConnectorMode	Control of an external illumination device via the external light connector

Communication Name	CAMExtLightConnMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1122
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		EXT_LIGHT_CONN_ILL_OFF	
	Value	Name	Description
	0	EXT_LIGHT_CONN_ILL_OFF	
	1	EXT_LIGHT_CONN_ILL_VLR_CSS_FLASHING	
	2	EXT_LIGHT_CONN_ILL_VLR_CSS_CONTINUOUS	
	3	EXT_LIGHT_CONN_ICL110	
	4	EXT_LIGHT_CONN_ICL170	
	5	EXT_LIGHT_CONN_ICL260	
	6	EXT_LIGHT_CONN_ICL280	
	7	EXT_LIGHT_CONN_ICL280_F202S01	
	8	EXT_LIGHT_CONN_ICL300	
	9	EXT_LIGHT_CONN_ICL300_F202S01	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMExtLightConnMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMExtLightConnMode	String	19	Control of an external illumination device via the external light connector

Read Variable Response:				
`sRA CAMExtLightConnMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMExtLightConnMode	String	19	Control of an external illumination device via the external light connector
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMExtLightConnMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMExtLightConnMode	String	19	Control of an external illumination device via the external light connector
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CAMExtLightConnMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMExtLightConnMode	String	19	Control of an external illumination device via the external light connector

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMExtLightConnMode[ETX]`
Read Variable Response:	`[STX]sRA CAMExtLightConnMode 0[ETX]`
Write Variable:	`[STX]sWN CAMExtLightConnMode 0[ETX]`
Write Variable Response:	`[STX]sWA CAMExtLightConnMode[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.15. Variable: AimingLaser

The following section contains a detailed description of the variable AimingLaser.

Variable Overview

Variable Name	Description
AimingLaser	Specifies when to activate the two aiming lasers.

Communication Name	CAMAimingLaser
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1123
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_AIMING_LASER_OFF	
	1	TX_AIMING_LASER_LIVEIMG_AUTOSETUP	
	2	TX_AIMING_LASER_LIVEIMG_AUTOSETUP_TRIGGER	
	3	TX_AIMING_LASER_PRESENT_MODE	

Variable Telegram Syntax

Read Variable:				
`sRN CAMAimingLaser`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMAimingLaser	String	14	Specifies when to activate the two aiming lasers.

Read Variable Response:				
`sRA CAMAimingLaser <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMAimingLaser	String	14	Specifies when to activate the two aiming lasers.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMAimingLaser <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMAimingLaser	String	14	Specifies when to activate the two aiming lasers.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMAimingLaser				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMAimingLaser	String	14	Specifies when to activate the two aiming lasers.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMAimingLaser[ETX]
Read Variable Response:	[STX]sRA CAMAimingLaser 1[ETX]
Write Variable:	[STX]sWN CAMAimingLaser 1[ETX]
Write Variable Response:	[STX]sWA CAMAimingLaser[ETX]

2.37.2.16. Variable: LedTimeout

The following section contains a detailed description of the variable LedTimeout.

Variable Overview

Variable Name	Description
LedTimeout	Time in minutes until the LEDs will be switched off if timout is enabled.

Communication Name	CAMLedTimeout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1125
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..1500
Initialisation	10
Physical Unit	Min
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMLedTimeout`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMLedTimeout	String	13	Time in minutes until the LEDs will be switched off if timout is enabled.

Read Variable Response:				
`sRA CAMLedTimeout <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMLedTimeout	String	13	Time in minutes until the LEDs will be switched off if timout is enabled.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN CAMLedTimeout <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMLedTimeout	String	13	Time in minutes until the LEDs will be switched off if timout is enabled.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA CAMLedTimeout`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMLedTimeout	String	13	Time in minutes until the LEDs will be switched off if timout is enabled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMLedTimeout[ETX]`
Read Variable Response:	`[STX]sRA CAMLedTimeout A[ETX]`
Write Variable:	`[STX]sWN CAMLedTimeout A[ETX]`
Write Variable Response:	`[STX]sWA CAMLedTimeout[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.17. Variable: ImageAcqROI

The following section contains a detailed description of the variable ImageAcqROI.

Variable Overview

Variable Name	Description
ImageAcqROI	Rectangular region of the field of view. Values are given in percent.

Communication Name	CAMImageRoi
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1126
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
MinX	
DInt	
Value Range	0..100
Initialisation	0
Physical Unit	%
Physical Unit Factor	0.0
MaxX	
DInt	
Value Range	0..100
Initialisation	100
Physical Unit	%
Physical Unit Factor	0.0
MinY	
DInt	
Value Range	0..100
Initialisation	0
Physical Unit	%
Physical Unit Factor	0.0
MaxY	
DInt	
Value Range	0..100
Initialisation	100
Physical Unit	%
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN CAMImageRoi				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMImageRoi	String	11	Rectangular region of the field of view. Values are given in percent.

Read Variable Response:				
sRA CAMImageRoi <MinX> <MaxX> <MinY> <MaxY>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMImageRoi	String	11	Rectangular region of the field of view. Values are given in percent.
Variable Data 1	MinX	DInt	4	
Variable Data 2	MaxX	DInt	4	
Variable Data 3	MinY	DInt	4	
Variable Data 4	MaxY	DInt	4	

Write Variable:				
sWN CAMImageRoi <MinX> <MaxX> <MinY> <MaxY>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMImageRoi	String	11	Rectangular region of the field of view. Values are given in percent.
Variable Data 1	MinX	DInt	4	
Variable Data 2	MaxX	DInt	4	
Variable Data 3	MinY	DInt	4	
Variable Data 4	MaxY	DInt	4	

Write Variable Response:				
sWA CAMImageRoi				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMImageRoi	String	11	Rectangular region of the field of view. Values are given in percent.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMImageRoi[ETX]
Read Variable Response:	[STX]sRA CAMImageRoi 0 64 0 64[ETX]
Write Variable:	[STX]sWN CAMImageRoi 0 64 0 64[ETX]
Write Variable Response:	[STX]sWA CAMImageRoi[ETX]

© SICK AG - Germany - All rights reserved

2.37.2.18. Variable: ImageResolution

The following section contains a detailed description of the variable ImageResolution.

Variable Overview

Variable Name	Description
ImageResolution	reduces image resolution if set to low

Communication Name	CAMImgResolution
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1127
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_IMAGE_RESOLUTION_HIGH	
	Value	Name	Description
	0	TX_IMAGE_RESOLUTION_HIGH	
	1	TX_IMAGE_RESOLUTION_LOW	

Variable Telegram Syntax

Read Variable:

```
sRN CAMImgResolution
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMImgResolution	String	16	reduces image resolution if set to low

Read Variable Response:

```
sRA CAMImgResolution <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMImgResolution	String	16	reduces image resolution if set to low
Variable Data	data	Enum8	1	

Write Variable:

```
sWN CAMImgResolution <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMImgResolution	String	16	reduces image resolution if set to low
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA CAMImgResolution
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMImgResolution	String	16	reduces image resolution if set to low

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMImgResolution[ETX]`
Read Variable Response:	`[STX]sRA CAMImgResolution 0[ETX]`
Write Variable:	`[STX]sWN CAMImgResolution 0[ETX]`
Write Variable Response:	`[STX]sWA CAMImgResolution[ETX]`

2.37.2.19. Variable: ImageVerticalFlip

The following section contains a detailed description of the variable ImageVerticalFlip.

Variable Overview

Variable Name	Description
ImageVerticalFlip	option to flip the image vertically

Communication Name	CAMVerticalFlip
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1128
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CAMVerticalFlip`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMVerticalFlip	String	15	option to flip the image vertically

Read Variable Response:				
`sRA CAMVerticalFlip <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMVerticalFlip	String	15	option to flip the image vertically
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CAMVerticalFlip <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMVerticalFlip	String	15	option to flip the image vertically
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CAMVerticalFlip				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMVerticalFlip	String	15	option to flip the image vertically

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMVerticalFlip[ETX]
Read Variable Response:	[STX]sRA CAMVerticalFlip 0[ETX]
Write Variable:	[STX]sWN CAMVerticalFlip 0[ETX]
Write Variable Response:	[STX]sWA CAMVerticalFlip[ETX]

2.37.2.20. Variable: ImageMirroring

The following section contains a detailed description of the variable ImageMirroring.

Variable Overview

Variable Name	Description
ImageMirroring	option to mirror the captured image

Communication Name	CAMMirroring
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1129
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMMirroring`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMMirroring	String	12	option to mirror the captured image

Read Variable Response:				
`sRA CAMMirroring <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMMirroring	String	12	option to mirror the captured image
Variable Data	data	Bool	1	

Write Variable:				
`sWN CAMMirroring <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMMirroring	String	12	option to mirror the captured image
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CAMMirroring`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMMirroring	String	12	option to mirror the captured image

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMMirroring[ETX]`
Read Variable Response:	`[STX]sRA CAMMirroring 0[ETX]`
Write Variable:	`[STX]sWN CAMMirroring 0[ETX]`
Write Variable Response:	`[STX]sWA CAMMirroring[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.21. Variable: UseCCDToWorldTransformMatrix

The following section contains a detailed description of the variable UseCCDToWorldTransformMatrix.

Variable Overview

Variable Name
UseCCDToWorldTransformMatrix

Communication Name	CAMUseCCDToWrldTrnsfMtrx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1130
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CAMUseCCDToWrldTrnsfMtrx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMUseCCDToWrldTrnsfMtrx	String	24	

Read Variable Response:				
`sRA CAMUseCCDToWrldTrnsfMtrx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMUseCCDToWrldTrnsfMtrx	String	24	
Variable Data	data	Bool	1	

Write Variable:				
`sWN CAMUseCCDToWrldTrnsfMtrx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMUseCCDToWrldTrnsfMtrx	String	24	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CAMUseCCDToWrldTrnsfMtrx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMUseCCDToWrldTrnsfMtrx	String	24	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMUseCCDToWrldTrnsfMtrx[ETX]`
Read Variable Response:	`[STX]sRA CAMUseCCDToWrldTrnsfMtrx 0[ETX]`
Write Variable:	`[STX]sWN CAMUseCCDToWrldTrnsfMtrx 0[ETX]`
Write Variable Response:	`[STX]sWA CAMUseCCDToWrldTrnsfMtrx[ETX]`

2.37.2.22. Variable: AutoAdjustGain

The following section contains a detailed description of the variable AutoAdjustGain.

Variable Overview

Variable Name	Description
AutoAdjustGain	Gain is adjusted over several frames to increase read rate

Communication Name	CAMAutGain
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1131
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CAMAutGain`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMAutGain	String	10	Gain is adjusted over several frames to increase read rate

Read Variable Response:				
`sRA CAMAutGain <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMAutGain	String	10	Gain is adjusted over several frames to increase read rate
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CAMAutGain <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMAutGain	String	10	Gain is adjusted over several frames to increase read rate
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CAMAutGain				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMAutGain	String	10	Gain is adjusted over several frames to increase read rate

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMAutGain[ETX]
Read Variable Response:	[STX]sRA CAMAutGain 0[ETX]
Write Variable:	[STX]sWN CAMAutGain 0[ETX]
Write Variable Response:	[STX]sWA CAMAutGain[ETX]

2.37.2.23. Variable: AutoAdjustRegion

The following section contains a detailed description of the variable AutoAdjustRegion.

Variable Overview

Variable Name	Description
AutoAdjustRegion	Rectangular region of the auto brightness region of interest. Values are given in percent.

Communication Name	CAMAutAdjReg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1132
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
MinX	
UInt	
Value Range	0..100
Initialisation	30
Physical Unit	%
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Struct	
MaxX	
UInt	
Value Range	0..100
Initialisation	70
Physical Unit	%
Physical Unit Factor	0.0
MinY	
UInt	
Value Range	0..100
Initialisation	30
Physical Unit	%
Physical Unit Factor	0.0
MaxY	
UInt	
Value Range	0..100
Initialisation	70
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMAutAdjReg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMAutAdjReg	String	12	Rectangular region of the auto brightness region of interest. Values are given in percent.

Read Variable Response:

```
sRA CAMAutAdjReg <MinX> <MaxX> <MinY> <MaxY>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMAutAdjReg	String	12	Rectangular region of the auto brightness region of interest. Values are given in percent.
Variable Data 1	MinX	UInt	2	
Variable Data 2	MaxX	UInt	2	
Variable Data 3	MinY	UInt	2	
Variable Data 4	MaxY	UInt	2	

Write Variable:

```
sWN CAMAutAdjReg <MinX> <MaxX> <MinY> <MaxY>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMAutAdjReg	String	12	Rectangular region of the auto brightness region of interest. Values are given in percent.
Variable Data 1	MinX	UInt	2	
Variable Data 2	MaxX	UInt	2	
Variable Data 3	MinY	UInt	2	
Variable Data 4	MaxY	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMAutAdjReg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMAutAdjReg	String	12	Rectangular region of the auto brightness region of interest. Values are given in percent.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMAutAdjReg[ETX]
Read Variable Response:	[STX]sRA CAMAutAdjReg 1E 46 1E 46[ETX]
Write Variable:	[STX]sWN CAMAutAdjReg 1E 46 1E 46[ETX]
Write Variable Response:	[STX]sWA CAMAutAdjReg[ETX]

2.37.2.24. Variable: AutoAdjustGainRangeMin

The following section contains a detailed description of the variable AutoAdjustGainRangeMin.

Variable Overview

Variable Name
AutoAdjustGainRangeMin

Communication Name	CAMAutGainMin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1133
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	2
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMAutGainMin`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMAutGainMin	String	13	

Read Variable Response:				
`sRA CAMAutGainMin <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMAutGainMin	String	13	
Variable Data	data	UInt	2	

Write Variable:				
`sWN CAMAutGainMin <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMAutGainMin	String	13	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CAMAutGainMin`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMAutGainMin	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMAutGainMin[ETX]`
Read Variable Response:	`[STX]sRA CAMAutGainMin 2[ETX]`
Write Variable:	`[STX]sWN CAMAutGainMin 2[ETX]`
Write Variable Response:	`[STX]sWA CAMAutGainMin[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.25. Variable: AutoAdjustGainRangeMax

The following section contains a detailed description of the variable AutoAdjustGainRangeMax.

Variable Overview

Variable Name
AutoAdjustGainRangeMax

Communication Name	CAMAutGainMax
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1134
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	100
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMAutGainMax
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMAutGainMax	String	13	

Read Variable Response:

```
sRA CAMAutGainMax <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMAutGainMax	String	13	
Variable Data	data	UInt	2	

Write Variable:

```
sWN CAMAutGainMax <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMAutGainMax	String	13	
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA CAMAutGainMax
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMAutGainMax	String	13	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMAutGainMax[ETX]`
Read Variable Response:	`[STX]sRA CAMAutGainMax 64[ETX]`
Write Variable:	`[STX]sWN CAMAutGainMax 64[ETX]`
Write Variable Response:	`[STX]sWA CAMAutGainMax[ETX]`

2.37.2.26. Variable: ImageBinningMode

The following section contains a detailed description of the variable ImageBinningMode.

Variable Overview

Variable Name
ImageBinningMode

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1140
Storage	Variable is stored in ParamEEprom
Read-Access	AuthorizedClient, Service
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_IMG_BINN_NONE	
	1	TX_IMG_BINN_2X2	

Variable Telegram Syntax

Read Variable:				
`sRN ImageBinningMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ImageBinningMode	String	16	

Read Variable Response:				
`sRA ImageBinningMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ImageBinningMode	String	16	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN ImageBinningMode <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ImageBinningMode	String	16	
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA ImageBinningMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ImageBinningMode	String	16	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ImageBinningMode[ETX]
Read Variable Response:	[STX]sRA ImageBinningMode 0[ETX]
Write Variable:	[STX]sWN ImageBinningMode 0[ETX]
Write Variable Response:	[STX]sWA ImageBinningMode[ETX]

2.37.2.27. Variable: LedTimeoutEnabled

The following section contains a detailed description of the variable LedTimeoutEnabled.

Variable Overview

Variable Name	Description
LedTimeoutEnabled	Turn LED timout on or off

Communication Name	CAMLedTimeoutEnabled
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1124
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMLedTimeoutEnabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMLedTimeoutEnabled	String	20	Turn LED timout on or off

Read Variable Response:				
`sRA CAMLedTimeoutEnabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMLedTimeoutEnabled	String	20	Turn LED timout on or off
Variable Data	data	Bool	1	

Write Variable:				
`sWN CAMLedTimeoutEnabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMLedTimeoutEnabled	String	20	Turn LED timout on or off
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CAMLedTimeoutEnabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMLedTimeoutEnabled	String	20	Turn LED timout on or off

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMLedTimeoutEnabled[ETX]`
Read Variable Response:	`[STX]sRA CAMLedTimeoutEnabled 0[ETX]`
Write Variable:	`[STX]sWN CAMLedTimeoutEnabled 0[ETX]`
Write Variable Response:	`[STX]sWA CAMLedTimeoutEnabled[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.28. Variable: ReadingDistanceInput

The following section contains a detailed description of the variable ReadingDistanceInput.

Variable Overview

Variable Name	Description
ReadingDistanceInput	When the user wants to set a FocusPosition manually, in mm.

Communication Name	CAMReadDistInput
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1101
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMReadDistInput
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMReadDistInput	String	16	When the user wants to set a FocusPosition manually, in mm.

Read Variable Response:

```
sRA CAMReadDistInput <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMReadDistInput	String	16	When the user wants to set a FocusPosition manually, in mm.
Variable Data	data	UDInt	4	

Write Variable:

```
sWN CAMReadDistInput <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMReadDistInput	String	16	When the user wants to set a FocusPosition manually, in mm.
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA CAMReadDistInput
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMReadDistInput				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CAMReadDistInput	String	16	When the user wants to set a FocusPosition manually, in mm.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMReadDistInput[ETX]
Read Variable Response:	[STX]sRA CAMReadDistInput 64[ETX]
Write Variable:	[STX]sWN CAMReadDistInput 64[ETX]
Write Variable Response:	[STX]sWA CAMReadDistInput[ETX]

2.37.2.29. Variable: FocusPosition

The following section contains a detailed description of the variable FocusPosition.

Variable Overview

Variable Name	Description
FocusPosition	Focus position i.e. distance from camera to object in mm.

Communication Name	CAMFocPos
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1102
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	100
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMFocPos`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMFocPos	String	9	Focus position i.e. distance from camera to object in mm.

Read Variable Response:				
`sRA CAMFocPos <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMFocPos	String	9	Focus position i.e. distance from camera to object in mm.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN CAMFocPos <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMFocPos	String	9	Focus position i.e. distance from camera to object in mm.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA CAMFocPos`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMFocPos	String	9	Focus position i.e. distance from camera to object in mm.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMFocPos[ETX]`
Read Variable Response:	`[STX]sRA CAMFocPos 64[ETX]`
Write Variable:	`[STX]sWN CAMFocPos 64[ETX]`
Write Variable Response:	`[STX]sWA CAMFocPos[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.30. Variable: FrameRate

The following section contains a detailed description of the variable FrameRate.

Variable Overview

Variable Name	Description
FrameRate	Number of images that are captured by the camera each second

Communication Name	CAMFrameRate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1107
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 1.0..999.0
Initialisation	50.0
Physical Unit	Hz
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMFrameRate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMFrameRate	String	12	Number of images that are captured by the camera each second

Read Variable Response:

```
sRA CAMFrameRate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMFrameRate	String	12	Number of images that are captured by the camera each second
Variable Data	data	Real	4	

Write Variable:

```
sWN CAMFrameRate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMFrameRate	String	12	Number of images that are captured by the camera each second
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMFrameRate				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMFrameRate	String	12	Number of images that are captured by the camera each second

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMFrameRate[ETX]
Read Variable Response:	[STX]sRA CAMFrameRate 42480000[ETX]
Write Variable:	[STX]sWN CAMFrameRate 42480000[ETX]
Write Variable Response:	[STX]sWA CAMFrameRate[ETX]

2.37.2.31. Variable: ShutterTime

The following section contains a detailed description of the variable ShutterTime.

Variable Overview

Variable Name	Description
ShutterTime	Shutter time of the imager in us

Communication Name	CAMShutterTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1105
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	60..5000
Initialisation	335
Physical Unit	µs
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMShutterTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMShutterTime	String	14	Shutter time of the imager in us

Read Variable Response:				
`sRA CAMShutterTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMShutterTime	String	14	Shutter time of the imager in us
Variable Data	data	UInt	2	

Write Variable:				
`sWN CAMShutterTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMShutterTime	String	14	Shutter time of the imager in us
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CAMShutterTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMShutterTime	String	14	Shutter time of the imager in us

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMShutterTime[ETX]`
Read Variable Response:	`[STX]sRA CAMShutterTime 14F[ETX]`
Write Variable:	`[STX]sWN CAMShutterTime 14F[ETX]`
Write Variable Response:	`[STX]sWA CAMShutterTime[ETX]`

© SICK AG - Germany - All rights reserved

2.37.2.32. Method: GetCurrentFrameRate

The following section contains a detailed description of the method GetCurrentFrameRate.

Method Overview

Method Name
GetCurrentFrameRate

Communication Name	mCAMGetCurrFrameRate
Sopas Index	117
Invocation Access	Always

Return Values	
FrameRate	
Real	
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	Hz
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mCAMGetCurrFrameRate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mCAMGetCurrFrameRate	String	20	

Method Return Value:				
`sAN mCAMGetCurrFrameRate <FrameRate>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mCAMGetCurrFrameRate	String	20	
Return Value 1	FrameRate	Real	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mCAMGetCurrFrameRate[ETX]`
Method Return Value:	`[STX]sAN mCAMGetCurrFrameRate 00000000[ETX]`

© SICK AG - Germany - All rights reserved

2.37.3. Group: Camera65x

2.37.3.1. Variable: FlashFrequencyControlLevel

The following section contains a detailed description of the variable FlashFrequencyControlLevel.

Variable Overview

Variable Name
FlashFrequencyControlLevel

Communication Name	CAMFlashContrLev
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1142
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Level1	
	Value	Name	Description
	0	Level1	
	1	Level2	

Variable Telegram Syntax

Read Variable:				
`sRN CAMFlashContrLev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMFlashContrLev	String	16	

Read Variable Response:				
`sRA CAMFlashContrLev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMFlashContrLev	String	16	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CAMFlashContrLev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMFlashContrLev	String	16	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMFlashContrLev				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMFlashContrLev	String	16	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMFlashContrLev[ETX]
Read Variable Response:	[STX]sRA CAMFlashContrLev 0[ETX]
Write Variable:	[STX]sWN CAMFlashContrLev 0[ETX]
Write Variable Response:	[STX]sWA CAMFlashContrLev[ETX]

2.37.3.2. Variable: PanoramaHoodActive

The following section contains a detailed description of the variable PanoramaHoodActive.

Variable Overview

Variable Name
PanoramaHoodActive

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1150
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PanoramaHoodActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PanoramaHoodActive	String	18	

Read Variable Response:				
`sRA PanoramaHoodActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PanoramaHoodActive	String	18	
Variable Data	data	Bool	1	

Write Variable:				
`sWN PanoramaHoodActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PanoramaHoodActive	String	18	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA PanoramaHoodActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PanoramaHoodActive	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PanoramaHoodActive[ETX]`
Read Variable Response:	`[STX]sRA PanoramaHoodActive 0[ETX]`
Write Variable:	`[STX]sWN PanoramaHoodActive 0[ETX]`
Write Variable Response:	`[STX]sWA PanoramaHoodActive[ETX]`

© SICK AG - Germany - All rights reserved

2.37.3.3. Variable: PanoramaHoodImageOverlapping

The following section contains a detailed description of the variable PanoramaHoodImageOverlapping.

Variable Overview

Variable Name	Description
PanoramaHoodImageOverlapping	Overlapping area with unclear position information

Communication Name	CAMPanoImgOverlap
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1151
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

USInt	
Value Range	0..100
Initialisation	20
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMPanoImgOverlap
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMPanoImgOverlap	String	17	Overlapping area with unclear position information

Read Variable Response:

```
sRA CAMPanoImgOverlap <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMPanoImgOverlap	String	17	Overlapping area with unclear position information
Variable Data	data	USInt	1	

Write Variable:

```
sWN CAMPanoImgOverlap <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMPanoImgOverlap	String	17	Overlapping area with unclear position information
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA CAMPanoImgOverlap
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMPanoImgOverlap	String	17	Overlapping area with unclear position information

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMPanoImgOverlap[ETX]`
Read Variable Response:	`[STX]sRA CAMPanoImgOverlap 14[ETX]`
Write Variable:	`[STX]sWN CAMPanoImgOverlap 14[ETX]`
Write Variable Response:	`[STX]sWA CAMPanoImgOverlap[ETX]`

2.37.3.4. Variable: IlluSyncEnable

The following section contains a detailed description of the variable IlluSyncEnable.

Variable Overview

Variable Name
IlluSyncEnable

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1152
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN IlluSyncEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	IlluSyncEnable	String	14	

Read Variable Response:

```
sRA IlluSyncEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	IlluSyncEnable	String	14	
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN IlluSyncEnable <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	IlluSyncEnable	String	14	
Variable Data	data	Bool	1	

Write Variable Response:				
sWA IlluSyncEnable				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	IlluSyncEnable	String	14	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN IlluSyncEnable[ETX]
Read Variable Response:	[STX]sRA IlluSyncEnable 0[ETX]
Write Variable:	[STX]sWN IlluSyncEnable 0[ETX]
Write Variable Response:	[STX]sWA IlluSyncEnable[ETX]

2.37.3.5. Variable: IlluSyncDevDelayMs

The following section contains a detailed description of the variable IlluSyncDevDelayMs.

Variable Overview

Variable Name
IlluSyncDevDelayMs

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1153
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..100
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN IlluSyncDevDelayMs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	IlluSyncDevDelayMs	String	18	

Read Variable Response:				
`sRA IlluSyncDevDelayMs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	IlluSyncDevDelayMs	String	18	
Variable Data	data	UDInt	4	

Write Variable:				
`sWN IlluSyncDevDelayMs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	IlluSyncDevDelayMs	String	18	
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA IlluSyncDevDelayMs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	IlluSyncDevDelayMs	String	18	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN IlluSyncDevDelayMs[ETX]`
Read Variable Response:	`[STX]sRA IlluSyncDevDelayMs 0[ETX]`
Write Variable:	`[STX]sWN IlluSyncDevDelayMs 0[ETX]`
Write Variable Response:	`[STX]sWA IlluSyncDevDelayMs[ETX]`

© SICK AG - Germany - All rights reserved

2.37.3.6. Variable: IlluOffDelayEnable

The following section contains a detailed description of the variable IlluOffDelayEnable.

Variable Overview

Variable Name	Description
IlluOffDelayEnable	Enables the off delay of the illumination

Communication Name	CAMIlluOffDelayEnable
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1156
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CAMIlluOffDelayEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMIlluOffDelayEnable	String	21	Enables the off delay of the illumination

Read Variable Response:

```
sRA CAMIlluOffDelayEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMIlluOffDelayEnable	String	21	Enables the off delay of the illumination
Variable Data	data	Bool	1	

Write Variable:

```
sWN CAMIlluOffDelayEnable <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMIlluOffDelayEnable	String	21	Enables the off delay of the illumination
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CAMIlluOffDelayEnable
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMIlluOffDelayEnable	String	21	Enables the off delay of the illumination

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMIlluOffDelayEnable[ETX]`
Read Variable Response:	`[STX]sRA CAMIlluOffDelayEnable 0[ETX]`
Write Variable:	`[STX]sWN CAMIlluOffDelayEnable 0[ETX]`
Write Variable Response:	`[STX]sWA CAMIlluOffDelayEnable[ETX]`

2.37.3.7. Variable: IlluOffDelayTime

The following section contains a detailed description of the variable IlluOffDelayTime.

Variable Overview

Variable Name	Description
IlluOffDelayTime	Enables the off delay time of the illumination

Communication Name	CAMIlluOffDelayTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1157
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..1000
Initialisation	5
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN CAMIlluOffDelayTime`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMIlluOffDelayTime	String	19	Enables the off delay time of the illumination

Read Variable Response:

`sRA CAMIlluOffDelayTime <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMIlluOffDelayTime	String	19	Enables the off delay time of the illumination
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CAMIlluOffDelayTime <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMIlluOffDelayTime	String	19	Enables the off delay time of the illumination
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA CAMIlluOffDelayTime				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMIlluOffDelayTime	String	19	Enables the off delay time of the illumination

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMIlluOffDelayTime[ETX]
Read Variable Response:	[STX]sRA CAMIlluOffDelayTime 5[ETX]
Write Variable:	[STX]sWN CAMIlluOffDelayTime 5[ETX]
Write Variable Response:	[STX]sWA CAMIlluOffDelayTime[ETX]

2.37.3.8. Variable: CCDToWorldTransformMatrix

The following section contains a detailed description of the variable CCDToWorldTransformMatrix.

Variable Overview

Variable Name	Description
CCDToWorldTransformMatrix	The Inverse Transform Matrix as calibrated with CALIB_GEO code

Communication Name	CAMCCDMtx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1160
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Struct		
Valid		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Struct		
DistanceMM		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	0
	Physical Unit	mm
	Physical Unit Factor	0.0
Matrix		
	Array	
	Length	9
		Real
		Value Range	See specification IEEE 754
		Initialisation	
		Physical Unit	
		Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CAMCCDMtx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMCCDMtx	String	9	The Inverse Transform Matrix as calibrated with CALIB_GEO code

Read Variable Response:

```
sRA CAMCCDMtx <Valid> <DistanceMM> <Matrix>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMCCDMtx	String	9	The Inverse Transform Matrix as calibrated with CALIB_GEO code
Variable Data 1	Valid	Bool	1	
Variable Data 2	DistanceMM	DInt	4	
Variable Data 3	Matrix	Array	36	

Write Variable:

```
sWN CAMCCDMtx <Valid> <DistanceMM> <Matrix>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMCCDMtx	String	9	The Inverse Transform Matrix as calibrated with CALIB_GEO code
Variable Data 1	Valid	Bool	1	
Variable Data 2	DistanceMM	DInt	4	
Variable Data 3	Matrix	Array	36	

Write Variable Response:

```
sWA CAMCCDMtx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMCCDMtx	String	9	The Inverse Transform Matrix as calibrated with CALIB_GEO code

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMCCDMtx[ETX]`
Read Variable Response:	`[STX]sRA CAMCCDMtx 0 0 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000[ETX]`
Write Variable:	`[STX]sWN CAMCCDMtx 0 0 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000[ETX]`
Write Variable Response:	`[STX]sWA CAMCCDMtx[ETX]`

2.37.3.9. Variable: CalibratedMmPerPix

The following section contains a detailed description of the variable CalibratedMmPerPix.

Variable Overview

Variable Name	Description
CalibratedMmPerPix	The width of a pixel in mm, as calibrated with a CALIB code or a CALIB_GEO code

Communication Name	CAMCalMMPix
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1161
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
Valid		
	Bool	
	Value Range	False, True
	Initialisation	False
PixelWidthMM		
	Real	
	Value Range	See specification IEEE 754
	Initialisation	0
	Physical Unit	mm
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CAMCalMMPix`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMCalMMPix	String	11	The width of a pixel in mm, as calibrated with a CALIB code or a CALIB_GEO code

Read Variable Response:				
`sRA CAMCalMMPix <Valid> <PixelWidthMM>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMCalMMPix	String	11	The width of a pixel in mm, as calibrated with a CALIB code or a CALIB_GEO code
Variable Data 1	Valid	Bool	1	
Variable Data 2	PixelWidthMM	Real	4	

Write Variable:				
`sWN CAMCalMMPix <Valid> <PixelWidthMM>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMCalMMPix	String	11	The width of a pixel in mm, as calibrated with a CALIB code or a CALIB_GEO code
Variable Data 1	Valid	Bool	1	
Variable Data 2	PixelWidthMM	Real	4	

Write Variable Response:				
`sWA CAMCalMMPix`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CAMCalMMPix	String	11	The width of a pixel in mm, as calibrated with a CALIB code or a CALIB_GEO code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CAMCalMMPix[ETX]`
Read Variable Response:	`[STX]sRA CAMCalMMPix 0 00000000[ETX]`
Write Variable:	`[STX]sWN CAMCalMMPix 0 00000000[ETX]`
Write Variable Response:	`[STX]sWA CAMCalMMPix[ETX]`

© SICK AG - Germany - All rights reserved

2.37.3.10. Variable: FlashFrequencyControlEnable

The following section contains a detailed description of the variable FlashFrequencyControlEnable.

Variable Overview

Variable Name	Description
FlashFrequencyControlEnable	Enable flash frequency and exposure ratio parameters to achieve flicker free illumination.

Communication Name	CAMFlashContrEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1141
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CAMFlashContrEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CAMFlashContrEna	String	16	Enable flash frequency and exposure ratio parameters to achieve flicker free illumination.

Read Variable Response:

```
sRA CAMFlashContrEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CAMFlashContrEna	String	16	Enable flash frequency and exposure ratio parameters to achieve flicker free illumination.
Variable Data	data	Bool	1	

Write Variable:

```
sWN CAMFlashContrEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CAMFlashContrEna	String	16	Enable flash frequency and exposure ratio parameters to achieve flicker free illumination.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CAMFlashContrEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CAMFlashContrEna				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CAMFlashContrEna	String	16	Enable flash frequency and exposure ratio parameters to achieve flicker free illumination.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CAMFlashContrEna[ETX]
Read Variable Response:	[STX]sRA CAMFlashContrEna 0[ETX]
Write Variable:	[STX]sWN CAMFlashContrEna 0[ETX]
Write Variable Response:	[STX]sWA CAMFlashContrEna[ETX]

2.37.3.11. Event: FlashDutyCycleViolation

The following section contains a detailed description of the event FlashDutyCycleViolation.

Event Overview

Event Name
FlashDutyCycleViolation

Communication Name	CAMDutyCycViol
Sopas Index	380
Queue Length	1

© SICK AG - Germany - All rights reserved

2.37.4. Group: Lector61xIllumination

2.37.4.1. Variable: L61xIlluminationLEDStates1

The following section contains a detailed description of the variable L61xIlluminationLEDStates1.

Variable Overview

Variable Name	Description
L61xIlluminationLEDStates1	Used to control the LED states of Group A,B,C, and D.

Communication Name	L61xIlluLEDStat1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1163
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
A1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True
B1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True
C1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True
D1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN L61xIlluLEDStat1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	L61xIlluLEDStat1	String	16	Used to control the LED states of Group A,B,C, and D.

Read Variable Response:				
`sRA L61xIlluLEDStat1 <A1_ENABLED> <B1_ENABLED> <C1_ENABLED> <D1_ENABLED>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	L61xIlluLEDStat1	String	16	Used to control the LED states of Group A,B,C, and D.
Variable Data 1	A1_ENABLED	Bool	1	
Variable Data 2	B1_ENABLED	Bool	1	
Variable Data 3	C1_ENABLED	Bool	1	
Variable Data 4	D1_ENABLED	Bool	1	

Write Variable:				
`sWN L61xIlluLEDStat1 <A1_ENABLED> <B1_ENABLED> <C1_ENABLED> <D1_ENABLED>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	L61xIlluLEDStat1	String	16	Used to control the LED states of Group A,B,C, and D.
Variable Data 1	A1_ENABLED	Bool	1	
Variable Data 2	B1_ENABLED	Bool	1	
Variable Data 3	C1_ENABLED	Bool	1	
Variable Data 4	D1_ENABLED	Bool	1	

Write Variable Response:				
`sWA L61xIlluLEDStat1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	L61xIlluLEDStat1	String	16	Used to control the LED states of Group A,B,C, and D.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN L61xIlluLEDStat1[ETX]`
Read Variable Response:	`[STX]sRA L61xIlluLEDStat1 1 1 1 1[ETX]`
Write Variable:	`[STX]sWN L61xIlluLEDStat1 1 1 1 1[ETX]`
Write Variable Response:	`[STX]sWA L61xIlluLEDStat1[ETX]`

© SICK AG - Germany - All rights reserved

2.37.4.2. Variable: L61xIlluminationIntensity

The following section contains a detailed description of the variable L61xIlluminationIntensity.

Variable Overview

Variable Name	Description
L61xIlluminationIntensity	Global intensity (brightness) for all LEDs

Communication Name	L61xIlluInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1165
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..100
Initialisation	100
Physical Unit	%
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN L61xIlluInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	L61xIlluInt	String	11	Global intensity (brightness) for all LEDs

Read Variable Response:

```
sRA L61xIlluInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	L61xIlluInt	String	11	Global intensity (brightness) for all LEDs
Variable Data	data	UInt	2	

Write Variable:

```
sWN L61xIlluInt <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	L61xIlluInt	String	11	Global intensity (brightness) for all LEDs
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA L61xIlluInt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	L61xIlluInt	String	11	Global intensity (brightness) for all LEDs

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN L61xIlluInt[ETX]`
Read Variable Response:	`[STX]sRA L61xIlluInt 64[ETX]`
Write Variable:	`[STX]sWN L61xIlluInt 64[ETX]`
Write Variable Response:	`[STX]sWA L61xIlluInt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.5. Group: DeShading

2.37.5.1. Variable: DeShadingActive

The following section contains a detailed description of the variable DeShadingActive.

Variable Overview

Variable Name
DeShadingActive

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1168
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DeShadingActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DeShadingActive	String	15	

Read Variable Response:

```
sRA DeShadingActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DeShadingActive	String	15	
Variable Data	data	Bool	1	

Write Variable:

```
sWN DeShadingActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DeShadingActive	String	15	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DeShadingActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DeShadingActive	String	15	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DeShadingActive[ETX]`
Read Variable Response:	`[STX]sRA DeShadingActive 1[ETX]`
Write Variable:	`[STX]sWN DeShadingActive 1[ETX]`
Write Variable Response:	`[STX]sWA DeShadingActive[ETX]`

2.37.5.2. Variable: DeShadingIlluminationNonUniformity

The following section contains a detailed description of the variable DeShadingIlluminationNonUniformity.

Variable Overview

Variable Name
DeShadingIlluminationNonUniformity

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1169
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{65, 100, 100, 65}
	UInt	
	Value Range	1..100
	Initialisation	100
	Physical Unit	%
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DeShadingIlluminationNonUniformity`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DeShadingIlluminationNonUniformity	String	34	

Read Variable Response:				
`sRA DeShadingIlluminationNonUniformity <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DeShadingIlluminationNonUniformity	String	34	
Variable Data	data	Array	8	

Write Variable:				
`sWN DeShadingIlluminationNonUniformity <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DeShadingIlluminationNonUniformity	String	34	
Variable Data	data	Array	8	

Write Variable Response:				
`sWA DeShadingIlluminationNonUniformity`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DeShadingIlluminationNonUniformity	String	34	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DeShadingIlluminationNonUniformity[ETX]`
Read Variable Response:	`[STX]sRA DeShadingIlluminationNonUniformity 41 64 64 41[ETX]`
Write Variable:	`[STX]sWN DeShadingIlluminationNonUniformity 41 64 64 41[ETX]`
Write Variable Response:	`[STX]sWA DeShadingIlluminationNonUniformity[ETX]`

© SICK AG - Germany - All rights reserved

2.37.5.3. Variable: RotateDeShadingMetric

The following section contains a detailed description of the variable RotateDeShadingMetric.

Variable Overview

Variable Name
RotateDeShadingMetric

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1170
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum16			
	Value	Name	Description
	0	0	
	90	90	
	180	180	
	270	270	

Variable Telegram Syntax

Read Variable:				
`sRN RotateDeShadingMetric`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RotateDeShadingMetric	String	21	

Read Variable Response:				
`sRA RotateDeShadingMetric <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RotateDeShadingMetric	String	21	
Variable Data	data	Enum16	2	

Write Variable:				
`sWN RotateDeShadingMetric <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RotateDeShadingMetric	String	21	
Variable Data	data	Enum16	2	

Write Variable Response:				
`sWA RotateDeShadingMetric`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RotateDeShadingMetric	String	21	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RotateDeShadingMetric[ETX]`
Read Variable Response:	`[STX]sRA RotateDeShadingMetric 0[ETX]`
Write Variable:	`[STX]sWN RotateDeShadingMetric 0[ETX]`
Write Variable Response:	`[STX]sWA RotateDeShadingMetric[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6. Group: FocusControlCfg

2.37.6.1. Variable: FocusControlMode

The following section contains a detailed description of the variable FocusControlMode.

Variable Overview

Variable Name	Description
FocusControlMode	Major mode of focus control

Communication Name	FCctrlmd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1171
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_FIX_FOCUS	
	Value	Name	Description
	0	TX_FIX_FOCUS	
	1	TX_DYNAMIC_FOCUS	

Variable Telegram Syntax

Read Variable:

```
sRN FCctrlmd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCctrlmd	String	8	Major mode of focus control

Read Variable Response:

```
sRA FCctrlmd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCctrlmd	String	8	Major mode of focus control
Variable Data	data	Enum8	1	

Write Variable:

```
sWN FCctrlmd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCctrlmd	String	8	Major mode of focus control
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FCctrlmd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCctrlmd	String	8	Major mode of focus control

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCctrlmd[ETX]
Read Variable Response:	[STX]sRA FCctrlmd 0[ETX]
Write Variable:	[STX]sWN FCctrlmd 0[ETX]
Write Variable Response:	[STX]sWA FCctrlmd[ETX]

2.37.6.2. Variable: FocusControlSource

The following section contains a detailed description of the variable FocusControlSource.

Variable Overview

Variable Name	Description
FocusControlSource	Source for focus position switching

Communication Name	FCSrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1172
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_MLG	
	Value	Name	Description
	0	TX_SW_COMMAND	
	1	TX_TIMER	
	3	TX_SENSOR_INPUTS	
	5	TX_MLG	
	6	TX_LTR	
	7	TX_SW_COMMAND_DIST	
	8	TX_SW_PROFILE_CODE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCSrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCSrc	String	5	Source for focus position switching

Read Variable Response:				
`sRA FCSrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCSrc	String	5	Source for focus position switching
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FCSrc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCSrc	String	5	Source for focus position switching
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA FCSrc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCSrc	String	5	Source for focus position switching

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCSrc[ETX]`
Read Variable Response:	`[STX]sRA FCSrc 5[ETX]`
Write Variable:	`[STX]sWN FCSrc 5[ETX]`
Write Variable Response:	`[STX]sWA FCSrc[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.3. Variable: FocusControlBehavior

The following section contains a detailed description of the variable FocusControlBehavior.

Variable Overview

Variable Name	Description
FocusControlBehavior	Immediate/Latched mode switch for dynamic focus

Communication Name	FCbehv
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1173
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_IMMEDIATE	
	Value	Name	Description
	0	TX_IMMEDIATE	
	1	TX_LATCHED	

Variable Telegram Syntax

Read Variable:				
`sRN FCbehv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCbehv	String	6	Immediate/Latched mode switch for dynamic focus

Read Variable Response:				
`sRA FCbehv <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCbehv	String	6	Immediate/Latched mode switch for dynamic focus
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FCbehv <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCbehv	String	6	Immediate/Latched mode switch for dynamic focus
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA FCbehv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCbehv	String	6	Immediate/Latched mode switch for dynamic focus

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCbehv[ETX]`
Read Variable Response:	`[STX]sRA FCbehv 0[ETX]`
Write Variable:	`[STX]sWN FCbehv 0[ETX]`
Write Variable Response:	`[STX]sWA FCbehv[ETX]`

2.37.6.4. Variable: FocusControlTimerTime

The following section contains a detailed description of the variable FocusControlTimerTime.

Variable Overview

Variable Name	Description
FocusControlTimerTime	Focus control timer interval if time controlled

Communication Name	FCTmTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1174
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	200..100000
Initialisation	2000
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCTmTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCTmTm	String	6	Focus control timer interval if time controlled

Read Variable Response:

```
sRA FCTmTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCTmTm	String	6	Focus control timer interval if time controlled
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FCTmTm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCTmTm	String	6	Focus control timer interval if time controlled
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA FCTmTm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCTmTm	String	6	Focus control timer interval if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCTmTm[ETX]
Read Variable Response:	[STX]sRA FCTmTm 7D0[ETX]
Write Variable:	[STX]sWN FCTmTm 7D0[ETX]
Write Variable Response:	[STX]sWA FCTmTm[ETX]

2.37.6.5. Variable: FocusControlTimerTrack

The following section contains a detailed description of the variable FocusControlTimerTrack.

Variable Overview

Variable Name	Description
FocusControlTimerTrack	Focus control timer interval if track controlled

Communication Name	FCTmTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1175
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	200..100000
Initialisation	2000
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCTmTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCTmTrk	String	7	Focus control timer interval if track controlled

Read Variable Response:				
`sRA FCTmTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCTmTrk	String	7	Focus control timer interval if track controlled
Variable Data	data	UDInt	4	

Write Variable:				
`sWN FCTmTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCTmTrk	String	7	Focus control timer interval if track controlled
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA FCTmTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCTmTrk	String	7	Focus control timer interval if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCTmTrk[ETX]`
Read Variable Response:	`[STX]sRA FCTmTrk 7D0[ETX]`
Write Variable:	`[STX]sWN FCTmTrk 7D0[ETX]`
Write Variable Response:	`[STX]sWA FCTmTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.6. Variable: FocusControlActive

The following section contains a detailed description of the variable FocusControlActive.

Variable Overview

Variable Name	Description
FocusControlActive	List of dynamic distance configurations

Communication Name	FCAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1176
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN FCAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCAct	String	5	List of dynamic distance configurations

Read Variable Response:

```
sRA FCAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCAct	String	5	List of dynamic distance configurations
Variable Data	data	Array	1	

Write Variable:

```
sWN FCAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCAct	String	5	List of dynamic distance configurations
Variable Data	data	Array	1	

Write Variable Response:

```
sWA FCAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCAct	String	5	List of dynamic distance configurations

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCAct[ETX]`
Read Variable Response:	`[STX]sRA FCAct 1 1 1 1[ETX]`
Write Variable:	`[STX]sWN FCAct 1 1 1 1[ETX]`
Write Variable Response:	`[STX]sWA FCAct[ETX]`

2.37.6.7. Variable: FocusControlDistances

The following section contains a detailed description of the variable FocusControlDistances.

Variable Overview

Variable Name	Description
FocusControlDistances	List of dynamic distance configurations

Communication Name	FCDist
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1177
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
Default Value		{1000,1000,1000,1000}
	UInt	
	Value Range	0..65535
	Initialisation	1000
	Physical Unit	mm
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCDist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCDist	String	6	List of dynamic distance configurations

Read Variable Response:				
`sRA FCDist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCDist	String	6	List of dynamic distance configurations
Variable Data	data	Array	8	

Write Variable:				
`sWN FCDist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCDist	String	6	List of dynamic distance configurations
Variable Data	data	Array	8	

Write Variable Response:				
`sWA FCDist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCDist	String	6	List of dynamic distance configurations

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCDist[ETX]`
Read Variable Response:	`[STX]sRA FCDist 3E8 3E8 3E8 3E8[ETX]`
Write Variable:	`[STX]sWN FCDist 3E8 3E8 3E8 3E8[ETX]`
Write Variable Response:	`[STX]sWA FCDist[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.8. Variable: FocusControlSensorInput

The following section contains a detailed description of the variable FocusControlSensorInput.

Variable Overview

Variable Name	Description
FocusControlSensorInput	sensor inputs for focus control positions, if source is sensor

Communication Name	FCSensIn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1178
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array			
Length		4	
	Enum8		
	Default Value	TX_NONE	
	Value	Name	Description
	0	TX_NONE	
	1	TX_SENS_1	
	2	TX_SENS_2	
	3	TX_EXT_SENS_1	
	4	TX_EXT_SENS_2	

Variable Telegram Syntax

Read Variable:

```
sRN FCSensIn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCSensIn	String	8	sensor inputs for focus control positions, if source is sensor

Read Variable Response:

```
sRA FCSensIn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCSensIn	String	8	sensor inputs for focus control positions, if source is sensor
Variable Data	data	Array	4	

Write Variable:

```
sWN FCSensIn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCSensIn	String	8	sensor inputs for focus control positions, if source is sensor
Variable Data	data	Array	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FCSensIn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCSensIn	String	8	sensor inputs for focus control positions, if source is sensor

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCSensIn[ETX]
Read Variable Response:	[STX]sRA FCSensIn 0 0 0 0[ETX]
Write Variable:	[STX]sWN FCSensIn 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA FCSensIn[ETX]

2.37.6.9. Variable: FocusControlFocusDelayTime

The following section contains a detailed description of the variable FocusControlFocusDelayTime.

Variable Overview

Variable Name	Description
FocusControlFocusDelayTime	Focus delay if time controlled

Communication Name	FCFocusDelayTime
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1179
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..120000
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCFocusDelayTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCFocusDelayTime	String	16	Focus delay if time controlled

Read Variable Response:				
`sRA FCFocusDelayTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCFocusDelayTime	String	16	Focus delay if time controlled
Variable Data	data	UDInt	4	

Write Variable:				
`sWN FCFocusDelayTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCFocusDelayTime	String	16	Focus delay if time controlled
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA FCFocusDelayTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCFocusDelayTime	String	16	Focus delay if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCFocusDelayTime[ETX]`
Read Variable Response:	`[STX]sRA FCFocusDelayTime 0[ETX]`
Write Variable:	`[STX]sWN FCFocusDelayTime 0[ETX]`
Write Variable Response:	`[STX]sWA FCFocusDelayTime[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.10. Variable: FocusControlFocusDelayTrack

The following section contains a detailed description of the variable FocusControlFocusDelayTrack.

Variable Overview

Variable Name	Description
FocusControlFocusDelayTrack	Focus delay if track controlled

Communication Name	FCFocusDelayTrack
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1180
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..120000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCFocusDelayTrack
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCFocusDelayTrack	String	17	Focus delay if track controlled

Read Variable Response:

```
sRA FCFocusDelayTrack <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCFocusDelayTrack	String	17	Focus delay if track controlled
Variable Data	data	DInt	4	

Write Variable:

```
sWN FCFocusDelayTrack <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCFocusDelayTrack	String	17	Focus delay if track controlled
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA FCFocusDelayTrack
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCFocusDelayTrack	String	17	Focus delay if track controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCFocusDelayTrack[ETX]`
Read Variable Response:	`[STX]sRA FCFocusDelayTrack 0[ETX]`
Write Variable:	`[STX]sWN FCFocusDelayTrack 0[ETX]`
Write Variable Response:	`[STX]sWA FCFocusDelayTrack[ETX]`

2.37.6.11. Variable: FocusControlPreExpansionTime

The following section contains a detailed description of the variable FocusControlPreExpansionTime.

Variable Overview

Variable Name	Description
FocusControlPreExpansionTime	Focus control pre-expansion if time controlled

Communication Name	FCPreExpTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1181
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..120000
Initialisation	30
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCPreExpTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCPreExpTm	String	10	Focus control pre-expansion if time controlled

Read Variable Response:

```
sRA FCPreExpTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCPreExpTm	String	10	Focus control pre-expansion if time controlled
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FCPreExpTm <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCPreExpTm	String	10	Focus control pre-expansion if time controlled
Variable Data	data	UDInt	4	

Write Variable Response:				
sWA FCPreExpTm				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCPreExpTm	String	10	Focus control pre-expansion if time controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCPreExpTm[ETX]
Read Variable Response:	[STX]sRA FCPreExpTm 1E[ETX]
Write Variable:	[STX]sWN FCPreExpTm 1E[ETX]
Write Variable Response:	[STX]sWA FCPreExpTm[ETX]

2.37.6.12. Variable: FocusControlPreExpansionTrack

The following section contains a detailed description of the variable FocusControlPreExpansionTrack.

Variable Overview

Variable Name	Description
FocusControlPreExpansionTrack	Focus control pre-expansion if track controlled

Communication Name	FCPreExpTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1182
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

DInt	
Value Range	0..120000
Initialisation	30
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCPreExpTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCPreExpTrk	String	11	Focus control pre-expansion if track controlled

Read Variable Response:				
`sRA FCPreExpTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCPreExpTrk	String	11	Focus control pre-expansion if track controlled
Variable Data	data	DInt	4	

Write Variable:				
`sWN FCPreExpTrk <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCPreExpTrk	String	11	Focus control pre-expansion if track controlled
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA FCPreExpTrk`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCPreExpTrk	String	11	Focus control pre-expansion if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCPreExpTrk[ETX]`
Read Variable Response:	`[STX]sRA FCPreExpTrk 1E[ETX]`
Write Variable:	`[STX]sWN FCPreExpTrk 1E[ETX]`
Write Variable Response:	`[STX]sWA FCPreExpTrk[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.13. Variable: FocusControlPostExpansionTime

The following section contains a detailed description of the variable FocusControlPostExpansionTime.

Variable Overview

Variable Name	Description
FocusControlPostExpansionTime	Focus control post-expansion if time controlled

Communication Name	FCPostExpTm
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1183
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	0..120000
Initialisation	30
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCPostExpTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCPostExpTm	String	11	Focus control post-expansion if time controlled

Read Variable Response:

```
sRA FCPostExpTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCPostExpTm	String	11	Focus control post-expansion if time controlled
Variable Data	data	UDInt	4	

Write Variable:

```
sWN FCPostExpTm <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCPostExpTm	String	11	Focus control post-expansion if time controlled
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA FCPostExpTm
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCPostExpTm	String	11	Focus control post-expansion if time controlled

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCPostExpTm[ETX]`
Read Variable Response:	`[STX]sRA FCPostExpTm 1E[ETX]`
Write Variable:	`[STX]sWN FCPostExpTm 1E[ETX]`
Write Variable Response:	`[STX]sWA FCPostExpTm[ETX]`

2.37.6.14. Variable: FocusControlPostExpansionTrack

The following section contains a detailed description of the variable FocusControlPostExpansionTrack.

Variable Overview

Variable Name	Description
FocusControlPostExpansionTrack	Focus control post-expansion if track controlled

Communication Name	FCPostExpTrk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1184
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

DInt	
Value Range	0..120000
Initialisation	30
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN FCPostExpTrk`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCPostExpTrk	String	12	Focus control post-expansion if track controlled

Read Variable Response:

`sRA FCPostExpTrk <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCPostExpTrk	String	12	Focus control post-expansion if track controlled
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FCPostExpTrk <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCPostExpTrk	String	12	Focus control post-expansion if track controlled
Variable Data	data	DInt	4	

Write Variable Response:				
sWA FCPostExpTrk				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCPostExpTrk	String	12	Focus control post-expansion if track controlled

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCPostExpTrk[ETX]
Read Variable Response:	[STX]sRA FCPostExpTrk 1E[ETX]
Write Variable:	[STX]sWN FCPostExpTrk 1E[ETX]
Write Variable Response:	[STX]sWA FCPostExpTrk[ETX]

2.37.6.15. Variable: FocusControlMLGZDistDeviceBeamLow

The following section contains a detailed description of the variable FocusControlMLGZDistDeviceBeamLow.

Variable Overview

Variable Name	Description
FocusControlMLGZDistDeviceBeamLow	Height of Device above lowest Beam

Communication Name	FCMLGZDistDeviceBeamLow
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1186
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..100000
Initialisation	1500
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCMLGZDistDeviceBeamLow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCMLGZDistDeviceBeamLow	String	23	Height of Device above lowest Beam

Read Variable Response:				
`sRA FCMLGZDistDeviceBeamLow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCMLGZDistDeviceBeamLow	String	23	Height of Device above lowest Beam
Variable Data	data	DInt	4	

Write Variable:				
`sWN FCMLGZDistDeviceBeamLow <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCMLGZDistDeviceBeamLow	String	23	Height of Device above lowest Beam
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA FCMLGZDistDeviceBeamLow`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCMLGZDistDeviceBeamLow	String	23	Height of Device above lowest Beam

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCMLGZDistDeviceBeamLow[ETX]`
Read Variable Response:	`[STX]sRA FCMLGZDistDeviceBeamLow 5DC[ETX]`
Write Variable:	`[STX]sWN FCMLGZDistDeviceBeamLow 5DC[ETX]`
Write Variable Response:	`[STX]sWA FCMLGZDistDeviceBeamLow[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.16. Variable: FocusControlMLGZDistBeams

The following section contains a detailed description of the variable FocusControlMLGZDistBeams.

Variable Overview

Variable Name	Description
FocusControlMLGZDistBeams	Z-Distance between MLG Beams

Communication Name	FCMLGZDistBeams
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1187
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		TX_20	
	Value	Name	Description
	10	TX_10	
	20	TX_20	
	50	TX_50	

Variable Telegram Syntax

Read Variable:				
`sRN FCMLGZDistBeams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCMLGZDistBeams	String	15	Z-Distance between MLG Beams

Read Variable Response:				
`sRA FCMLGZDistBeams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCMLGZDistBeams	String	15	Z-Distance between MLG Beams
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FCMLGZDistBeams <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCMLGZDistBeams	String	15	Z-Distance between MLG Beams
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA FCMLGZDistBeams`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FCMLGZDistBeams				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	FCMLGZDistBeams	String	15	Z-Distance between MLG Beams

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCMLGZDistBeams[ETX]
Read Variable Response:	[STX]sRA FCMLGZDistBeams 14[ETX]
Write Variable:	[STX]sWN FCMLGZDistBeams 14[ETX]
Write Variable Response:	[STX]sWA FCMLGZDistBeams[ETX]

2.37.6.17. Variable: FocusControlMLGIsMLGMaster

The following section contains a detailed description of the variable FocusControlMLGIsMLGMaster.

Variable Overview

Variable Name	Description
FocusControlMLGIsMLGMaster	Device is master over MLG

Communication Name	FCMLGIsMLGMaster
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1188
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCMLGIsMLGMaster`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCMLGIsMLGMaster	String	16	Device is master over MLG

Read Variable Response:				
`sRA FCMLGIsMLGMaster <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCMLGIsMLGMaster	String	16	Device is master over MLG
Variable Data	data	Bool	1	

Write Variable:				
`sWN FCMLGIsMLGMaster <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCMLGIsMLGMaster	String	16	Device is master over MLG
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA FCMLGIsMLGMaster`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCMLGIsMLGMaster	String	16	Device is master over MLG

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCMLGIsMLGMaster[ETX]`
Read Variable Response:	`[STX]sRA FCMLGIsMLGMaster 0[ETX]`
Write Variable:	`[STX]sWN FCMLGIsMLGMaster 0[ETX]`
Write Variable Response:	`[STX]sWA FCMLGIsMLGMaster[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.18. Variable: FocusControlMLGNodeID

The following section contains a detailed description of the variable FocusControlMLGNodeID.

Variable Overview

Variable Name	Description
FocusControlMLGNodeID	CAN-NodeId of MLG

Communication Name	FCMLGNodeID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1189
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

USInt	
Value Range	1..63
Initialisation	63
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCMLGNodeID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCMLGNodeID	String	11	CAN-NodeId of MLG

Read Variable Response:

```
sRA FCMLGNodeID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCMLGNodeID	String	11	CAN-NodeId of MLG
Variable Data	data	USInt	1	

Write Variable:

```
sWN FCMLGNodeID <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCMLGNodeID	String	11	CAN-NodeId of MLG
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA FCMLGNodeID
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCMLGNodeID	String	11	CAN-NodeId of MLG

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCMLGNodeID[ETX]`
Read Variable Response:	`[STX]sRA FCMLGNodeID 3F[ETX]`
Write Variable:	`[STX]sWN FCMLGNodeID 3F[ETX]`
Write Variable Response:	`[STX]sWA FCMLGNodeID[ETX]`

2.37.6.19. Variable: FocusControlMLGIsUpsideDown

The following section contains a detailed description of the variable FocusControlMLGIsUpsideDown.

Variable Overview

Variable Name	Description
FocusControlMLGIsUpsideDown	Is MLG upsidedown

Communication Name	FCMLGIsUpsideDown
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1190
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

`sRN FCMLGIsUpsideDown`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCMLGIsUpsideDown	String	17	Is MLG upsidedown

Read Variable Response:

`sRA FCMLGIsUpsideDown <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCMLGIsUpsideDown	String	17	Is MLG upsidedown
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FCMLGIsUpsideDown <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCMLGIsUpsideDown	String	17	Is MLG upsidedown
Variable Data	data	Bool	1	

Write Variable Response:				
sWA FCMLGIsUpsideDown				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCMLGIsUpsideDown	String	17	Is MLG upsidedown

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCMLGIsUpsideDown[ETX]
Read Variable Response:	[STX]sRA FCMLGIsUpsideDown 0[ETX]
Write Variable:	[STX]sWN FCMLGIsUpsideDown 0[ETX]
Write Variable Response:	[STX]sWA FCMLGIsUpsideDown[ETX]

2.37.6.20. Variable: FocusControlLTRNodeID

The following section contains a detailed description of the variable FocusControlLTRNodeID.

Variable Overview

Variable Name	Description
FocusControlLTRNodeID	CAN-NodeId of LTR

Communication Name	FCLTRNodeID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1212
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

USInt	
Value Range	1..63
Initialisation	32
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCLTRNodeID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCLTRNodeID	String	11	CAN-NodeId of LTR

Read Variable Response:				
`sRA FCLTRNodeID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCLTRNodeID	String	11	CAN-NodeId of LTR
Variable Data	data	USInt	1	

Write Variable:				
`sWN FCLTRNodeID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCLTRNodeID	String	11	CAN-NodeId of LTR
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA FCLTRNodeID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCLTRNodeID	String	11	CAN-NodeId of LTR

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCLTRNodeID[ETX]`
Read Variable Response:	`[STX]sRA FCLTRNodeID 20[ETX]`
Write Variable:	`[STX]sWN FCLTRNodeID 20[ETX]`
Write Variable Response:	`[STX]sWA FCLTRNodeID[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.21. Variable: FocusControlLTRHysteresis

The following section contains a detailed description of the variable FocusControlLTRHysteresis.

Variable Overview

Variable Name	Description
FocusControlLTRHysteresis	Focus Hysterese for LTR

Communication Name	FCLTRHyst
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1213
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..1000
Initialisation	5
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCLTRHyst
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCLTRHyst	String	9	Focus Hysterese for LTR

Read Variable Response:

```
sRA FCLTRHyst <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCLTRHyst	String	9	Focus Hysterese for LTR
Variable Data	data	UInt	2	

Write Variable:

```
sWN FCLTRHyst <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCLTRHyst	String	9	Focus Hysterese for LTR
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA FCLTRHyst
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCLTRHyst	String	9	Focus Hysterese for LTR

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCLTRHyst[ETX]`
Read Variable Response:	`[STX]sRA FCLTRHyst 5[ETX]`
Write Variable:	`[STX]sWN FCLTRHyst 5[ETX]`
Write Variable Response:	`[STX]sWA FCLTRHyst[ETX]`

2.37.6.22. Variable: FocusControlLTRXOffset

The following section contains a detailed description of the variable FocusControlLTRXOffset.

Variable Overview

Variable Name	Description
FocusControlLTRXOffset	Focus Hysterese for LTR

Communication Name	FCLTRXOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1214
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Int	
Value Range	-5000..5000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FCLTRXOffset
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCLTRXOffset	String	12	Focus Hysterese for LTR

Read Variable Response:

```
sRA FCLTRXOffset <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCLTRXOffset	String	12	Focus Hysterese for LTR
Variable Data	data	Int	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN FCLTRXOffset <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCLTRXOffset	String	12	Focus Hysterese for LTR
Variable Data	data	Int	2	

Write Variable Response:				
sWA FCLTRXOffset				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCLTRXOffset	String	12	Focus Hysterese for LTR

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FCLTRXOffset[ETX]
Read Variable Response:	[STX]sRA FCLTRXOffset 0[ETX]
Write Variable:	[STX]sWN FCLTRXOffset 0[ETX]
Write Variable Response:	[STX]sWA FCLTRXOffset[ETX]

2.37.6.23. Variable: FocusControlLTRPostExpation

The following section contains a detailed description of the variable FocusControlLTRPostExpation.

Variable Overview

Variable Name	Description
FocusControlLTRPostExpation	Postexpation of focus data

Communication Name	FCLTRPostExpation
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1215
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Int	
Value Range	-5000..5000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FCLTRPostExpation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCLTRPostExpation	String	17	Postexpation of focus data

Read Variable Response:				
`sRA FCLTRPostExpation <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCLTRPostExpation	String	17	Postexpation of focus data
Variable Data	data	Int	2	

Write Variable:				
`sWN FCLTRPostExpation <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCLTRPostExpation	String	17	Postexpation of focus data
Variable Data	data	Int	2	

Write Variable Response:				
`sWA FCLTRPostExpation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCLTRPostExpation	String	17	Postexpation of focus data

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCLTRPostExpation[ETX]`
Read Variable Response:	`[STX]sRA FCLTRPostExpation 0[ETX]`
Write Variable:	`[STX]sWN FCLTRPostExpation 0[ETX]`
Write Variable Response:	`[STX]sWA FCLTRPostExpation[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.24. Variable: FocusControlLTRManualOffset

The following section contains a detailed description of the variable FocusControlLTRManualOffset.

Variable Overview

Variable Name	Description
FocusControlLTRManualOffset	Use Manual focus offset / expanstion

Communication Name	FCLTRManOff
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1216
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN FCLTRManOff
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCLTRManOff	String	11	Use Manual focus offset / expanstion

Read Variable Response:

```
sRA FCLTRManOff <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCLTRManOff	String	11	Use Manual focus offset / expanstion
Variable Data	data	Bool	1	

Write Variable:

```
sWN FCLTRManOff <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCLTRManOff	String	11	Use Manual focus offset / expanstion
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA FCLTRManOff
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCLTRManOff	String	11	Use Manual focus offset / expanstion

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCLTRManOff[ETX]`
Read Variable Response:	`[STX]sRA FCLTRManOff 0[ETX]`
Write Variable:	`[STX]sWN FCLTRManOff 0[ETX]`
Write Variable Response:	`[STX]sWA FCLTRManOff[ETX]`

2.37.6.25. Variable: FocusControlLTRUsFrontRearFocus

The following section contains a detailed description of the variable FocusControlLTRUsFrontRearFocus.

Variable Overview

Variable Name	Description
FocusControlLTRUsFrontRearFocus	Ignore far focus

Communication Name	FCLTRUsFrontRearFocus
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1217
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN FCLTRUsFrontRearFocus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FCLTRUsFrontRearFocus	String	21	Ignore far focus

Read Variable Response:				
`sRA FCLTRUsFrontRearFocus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FCLTRUsFrontRearFocus	String	21	Ignore far focus
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN FCLTRUsFrontRearFocus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FCLTRUsFrontRearFocus	String	21	Ignore far focus
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA FCLTRUsFrontRearFocus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FCLTRUsFrontRearFocus	String	21	Ignore far focus

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FCLTRUsFrontRearFocus[ETX]`
Read Variable Response:	`[STX]sRA FCLTRUsFrontRearFocus 0[ETX]`
Write Variable:	`[STX]sWN FCLTRUsFrontRearFocus 0[ETX]`
Write Variable Response:	`[STX]sWA FCLTRUsFrontRearFocus[ETX]`

2.37.6.26. Method: SwitchDynRdCfgTableIndex

The following section contains a detailed description of the method SwitchDynRdCfgTableIndex.

Method Overview

Method Name	Description
SwitchDynRdCfgTableIndex	Switches the dynamic reading cfg. table (2AA1-8)

Communication Name	mRCSwDynTblIdx
Sopas Index	118
Invocation Access	Always

Parameters	
Index	
USInt	
Value Range	0..255
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN mRCSwDynTblIdx <Index>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mRCSwDynTblIdx	String	14	Switches the dynamic reading cfg. table (2AA1-8)
Parameter 1	Index	USInt	1	

Method Return Value:				
`sAN mRCSwDynTblIdx <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mRCSwDynTblIdx	String	14	Switches the dynamic reading cfg. table (2AA1-8)
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mRCSwDynTblIdx 1[ETX]`
Method Return Value:	`[STX]sAN mRCSwDynTblIdx 0[ETX]`

2.37.6.27. Method: SwitchDynRdCfgDistance

The following section contains a detailed description of the method SwitchDynRdCfgDistance.

Method Overview

Method Name	Description
SwitchDynRdCfgDistance	Switches the dynamic reading cfg.

Communication Name	mRCSwDynDistance
Sopas Index	119
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Parameters	
Distance	
UInt	
Value Range	0..65535
Initialisation	1000
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mRCSwDynDistance <Distance>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mRCSwDynDistance	String	16	Switches the dynamic reading cfg.
Parameter 1	Distance	UInt	2	

Method Return Value:

```
sAN mRCSwDynDistance <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mRCSwDynDistance	String	16	Switches the dynamic reading cfg.
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mRCSwDynDistance 3E8[ETX]`
Method Return Value:	`[STX]sAN mRCSwDynDistance 0[ETX]`

© SICK AG - Germany - All rights reserved

2.37.6.28. Method: MLGTeachIn

The following section contains a detailed description of the method MLGTeachIn.

Method Overview

Method Name	Description
MLGTeachIn	Starts Teachin via MLG

Communication Name	mMLGTeachIn
Sopas Index	120
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mMLGTeachIn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mMLGTeachIn	String	11	Starts Teachin via MLG

Method Return Value:				
`sAN mMLGTeachIn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mMLGTeachIn	String	11	Starts Teachin via MLG

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mMLGTeachIn[ETX]`
Method Return Value:	`[STX]sAN mMLGTeachIn[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7. Group: CodeImageSegmentation

2.37.7.1. Variable: SharpnessMeasuring

The following section contains a detailed description of the variable SharpnessMeasuring.

Variable Overview

Variable Name	Description
SharpnessMeasuring	Enable to measure image sharpness and give a visual feedback in the image output

Communication Name	CISShrpMeas
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1220
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CISShrpMeas
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CISShrpMeas	String	11	Enable to measure image sharpness and give a visual feedback in the image output

Read Variable Response:

```
sRA CISShrpMeas <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CISShrpMeas	String	11	Enable to measure image sharpness and give a visual feedback in the image output
Variable Data	data	Bool	1	

Write Variable:

```
sWN CISShrpMeas <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CISShrpMeas	String	11	Enable to measure image sharpness and give a visual feedback in the image output
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CISShrpMeas				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CISShrpMeas	String	11	Enable to measure image sharpness and give a visual feedback in the image output

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CISShrpMeas[ETX]
Read Variable Response:	[STX]sRA CISShrpMeas 0[ETX]
Write Variable:	[STX]sWN CISShrpMeas 0[ETX]
Write Variable Response:	[STX]sWA CISShrpMeas[ETX]

2.37.7.2. Variable: ContrastSpreading

The following section contains a detailed description of the variable ContrastSpreading.

Variable Overview

Variable Name
ContrastSpreading

Communication Name	CISContrSprd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1221
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CISContrSprd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CISContrSprd	String	12	

Read Variable Response:				
`sRA CISContrSprd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CISContrSprd	String	12	
Variable Data	data	Bool	1	

Write Variable:				
`sWN CISContrSprd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CISContrSprd	String	12	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CISContrSprd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CISContrSprd	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CISContrSprd[ETX]`
Read Variable Response:	`[STX]sRA CISContrSprd 0[ETX]`
Write Variable:	`[STX]sWN CISContrSprd 0[ETX]`
Write Variable Response:	`[STX]sWA CISContrSprd[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7.3. Variable: ScanDensity1D

The following section contains a detailed description of the variable ScanDensity1D.

Variable Overview

Variable Name	Description
ScanDensity1D	Defines how many samples will be taken in a 1D code region

Communication Name	CISScanDens1D
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1228
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	1..100
Initialisation	10
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN CISScanDens1D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CISScanDens1D	String	13	Defines how many samples will be taken in a 1D code region

Read Variable Response:				
`sRA CISScanDens1D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CISScanDens1D	String	13	Defines how many samples will be taken in a 1D code region
Variable Data	data	UInt	2	

Write Variable:				
`sWN CISScanDens1D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CISScanDens1D	String	13	Defines how many samples will be taken in a 1D code region
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CISScanDens1D				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CISScanDens1D	String	13	Defines how many samples will be taken in a 1D code region

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CISScanDens1D[ETX]
Read Variable Response:	[STX]sRA CISScanDens1D A[ETX]
Write Variable:	[STX]sWN CISScanDens1D A[ETX]
Write Variable Response:	[STX]sWA CISScanDens1D[ETX]

2.37.7.4. Variable: MaxCodesPerRegion1D

The following section contains a detailed description of the variable MaxCodesPerRegion1D.

Variable Overview

Variable Name	Description
MaxCodesPerRegion1D	Defines up to how many 1D barcodes are allowed in one code region in the image

Communication Name	CIMxCdReg1D
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1229
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UDInt	
Value Range	1..99
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CIMxCdReg1D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMxCdReg1D	String	11	Defines up to how many 1D barcodes are allowed in one code region in the image

Read Variable Response:				
`sRA CIMxCdReg1D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMxCdReg1D	String	11	Defines up to how many 1D barcodes are allowed in one code region in the image
Variable Data	data	UDInt	4	

Write Variable:				
`sWN CIMxCdReg1D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMxCdReg1D	String	11	Defines up to how many 1D barcodes are allowed in one code region in the image
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA CIMxCdReg1D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMxCdReg1D	String	11	Defines up to how many 1D barcodes are allowed in one code region in the image

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMxCdReg1D[ETX]`
Read Variable Response:	`[STX]sRA CIMxCdReg1D 1[ETX]`
Write Variable:	`[STX]sWN CIMxCdReg1D 1[ETX]`
Write Variable Response:	`[STX]sWA CIMxCdReg1D[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7.5. Variable: NORCAVerification

The following section contains a detailed description of the variable NORCAVerification.

Variable Overview

Variable Name
NORCAVerification

Communication Name	CINORCA
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1232
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CINORCA`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CINORCA	String	7	

Read Variable Response:				
`sRA CINORCA <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CINORCA	String	7	
Variable Data	data	Bool	1	

Write Variable:				
`sWN CINORCA <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CINORCA	String	7	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CINORCA`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CINORCA	String	7	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CINORCA[ETX]`
Read Variable Response:	`[STX]sRA CINORCA 0[ETX]`
Write Variable:	`[STX]sWN CINORCA 0[ETX]`
Write Variable Response:	`[STX]sWA CINORCA[ETX]`

2.37.7.6. Variable: DottedPostalCodes

The following section contains a detailed description of the variable DottedPostalCodes.

Variable Overview

Variable Name
DottedPostalCodes

Communication Name	CIDottPostal
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1233
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CIDottPostal`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIDottPostal	String	12	

Read Variable Response:				
`sRA CIDottPostal <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIDottPostal	String	12	
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CIDottPostal <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIDottPostal	String	12	
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CIDottPostal				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIDottPostal	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CIDottPostal[ETX]
Read Variable Response:	[STX]sRA CIDottPostal 0[ETX]
Write Variable:	[STX]sWN CIDottPostal 0[ETX]
Write Variable Response:	[STX]sWA CIDottPostal[ETX]

2.37.7.7. Variable: CodeTrackingDirection

The following section contains a detailed description of the variable CodeTrackingDirection.

Variable Overview

Variable Name
CodeTrackingDirection

Communication Name	CITrackDir
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1234
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TRACKING_DIRECTION_RIGHTLEFT	
	Value	Name	Description
	0	TRACKING_DIRECTION_RIGHTLEFT	
	1	TRACKING_DIRECTION_LEFTRIGHT	
	2	TRACKING_DIRECTION_TOPDOWN	
	3	TRACKING_DIRECTION_DOWNTOP	
	4	TRACKING_DIRECTION_STANDSTILL	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CITrackDir`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CITrackDir	String	10	

Read Variable Response:				
`sRA CITrackDir <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CITrackDir	String	10	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CITrackDir <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CITrackDir	String	10	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CITrackDir`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CITrackDir	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CITrackDir[ETX]`
Read Variable Response:	`[STX]sRA CITrackDir 0[ETX]`
Write Variable:	`[STX]sWN CITrackDir 0[ETX]`
Write Variable Response:	`[STX]sWA CITrackDir[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7.8. Variable: OptimizeTireReading

The following section contains a detailed description of the variable OptimizeTireReading.

Variable Overview

Variable Name	Description
OptimizeTireReading	Optimize for reading 1D codes on tires that may have shortened bars

Communication Name	CIOptTire
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1235
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CIOptTire
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIOptTire	String	9	Optimize for reading 1D codes on tires that may have shortened bars

Read Variable Response:

```
sRA CIOptTire <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIOptTire	String	9	Optimize for reading 1D codes on tires that may have shortened bars
Variable Data	data	Bool	1	

Write Variable:

```
sWN CIOptTire <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIOptTire	String	9	Optimize for reading 1D codes on tires that may have shortened bars
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CIOptTire
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CIOptTire				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	CIOptTire	String	9	Optimize for reading 1D codes on tires that may have shortened bars

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CIOptTire[ETX]
Read Variable Response:	[STX]sRA CIOptTire 0[ETX]
Write Variable:	[STX]sWN CIOptTire 0[ETX]
Write Variable Response:	[STX]sWA CIOptTire[ETX]

2.37.7.9. Variable: ShortBarHeight

The following section contains a detailed description of the variable ShortBarHeight.

Variable Overview

Variable Name	Description
ShortBarHeight	Special segmentation for barcodes with a low code height. Typical used if height less than 30 pixel

Communication Name	CIShortBarHeight
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1236
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN CIShortBarHeight				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIShortBarHeight	String	16	Special segmentation for barcodes with a low code height. Typical used if height less than 30 pixel

Read Variable Response:				
sRA CIShortBarHeight <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIShortBarHeight	String	16	Special segmentation for barcodes with a low code height. Typical used if height less than 30 pixel
Variable Data	data	Bool	1	

Write Variable:				
sWN CIShortBarHeight <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIShortBarHeight	String	16	Special segmentation for barcodes with a low code height. Typical used if height less than 30 pixel
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CIShortBarHeight				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIShortBarHeight	String	16	Special segmentation for barcodes with a low code height. Typical used if height less than 30 pixel

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CIShortBarHeight[ETX]
Read Variable Response:	[STX]sRA CIShortBarHeight 0[ETX]
Write Variable:	[STX]sWN CIShortBarHeight 0[ETX]
Write Variable Response:	[STX]sWA CIShortBarHeight[ETX]

© SICK AG - Germany - All rights reserved

2.37.7.10. Variable: MaxNum1DCodesEnabled

The following section contains a detailed description of the variable MaxNum1DCodesEnabled.

Variable Overview

Variable Name
MaxNum1DCodesEnabled

Communication Name	CIMax1DCodesEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1237
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Any	
	Value	Name	Description
	0	Any	
	1	Fixed	

Variable Telegram Syntax

Read Variable:				
`sRN CIMax1DCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMax1DCodesEna	String	15	

Read Variable Response:				
`sRA CIMax1DCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMax1DCodesEna	String	15	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CIMax1DCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMax1DCodesEna	String	15	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CIMax1DCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMax1DCodesEna	String	15	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMax1DCodesEna[ETX]`
Read Variable Response:	`[STX]sRA CIMax1DCodesEna 0[ETX]`
Write Variable:	`[STX]sWN CIMax1DCodesEna 0[ETX]`
Write Variable Response:	`[STX]sWA CIMax1DCodesEna[ETX]`

2.37.7.11. Variable: MaxNum1DCodes

The following section contains a detailed description of the variable MaxNum1DCodes.

Variable Overview

Variable Name
MaxNum1DCodes

Communication Name	CIMax1DCodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1238
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN CIMax1DCodes`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMax1DCodes	String	12	

Read Variable Response:

`sRA CIMax1DCodes <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMax1DCodes	String	12	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CIMax1DCodes <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMax1DCodes	String	12	
Variable Data	data	UInt	2	

Write Variable Response:				
sWA CIMax1DCodes				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMax1DCodes	String	12	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CIMax1DCodes[ETX]
Read Variable Response:	[STX]sRA CIMax1DCodes 1[ETX]
Write Variable:	[STX]sWN CIMax1DCodes 1[ETX]
Write Variable Response:	[STX]sWA CIMax1DCodes[ETX]

2.37.7.12. Variable: MaxNumDMxCodes

The following section contains a detailed description of the variable MaxNumDMxCodes.

Variable Overview

Variable Name
MaxNumDMxCodes

Communication Name	CIMaxDMxCodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1242
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CIMaxDMxCodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMaxDMxCodes	String	13	

Read Variable Response:				
`sRA CIMaxDMxCodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMaxDMxCodes	String	13	
Variable Data	data	UInt	2	

Write Variable:				
`sWN CIMaxDMxCodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMaxDMxCodes	String	13	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CIMaxDMxCodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMaxDMxCodes	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMaxDMxCodes[ETX]`
Read Variable Response:	`[STX]sRA CIMaxDMxCodes 1[ETX]`
Write Variable:	`[STX]sWN CIMaxDMxCodes 1[ETX]`
Write Variable Response:	`[STX]sWA CIMaxDMxCodes[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7.13. Variable: MaxNumQRCodes

The following section contains a detailed description of the variable MaxNumQRCodes.

Variable Overview

Variable Name
MaxNumQRCodes

Communication Name	CIMaxQRCodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1244
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN CIMaxQRCodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMaxQRCodes	String	12	

Read Variable Response:				
`sRA CIMaxQRCodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMaxQRCodes	String	12	
Variable Data	data	UInt	2	

Write Variable:				
`sWN CIMaxQRCodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMaxQRCodes	String	12	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CIMaxQRCodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMaxQRCodes	String	12	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMaxQRCodes[ETX]`
Read Variable Response:	`[STX]sRA CIMaxQRCodes 1[ETX]`
Write Variable:	`[STX]sWN CIMaxQRCodes 1[ETX]`
Write Variable Response:	`[STX]sWA CIMaxQRCodes[ETX]`

2.37.7.14. Variable: MaxNumMaxiCodesEnabled

The following section contains a detailed description of the variable MaxNumMaxiCodesEnabled.

Variable Overview

Variable Name
MaxNumMaxiCodesEnabled

Communication Name	CIMaxMaxiCodesEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1245
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Any	
	Value	Name	Description
	0	Any	
	1	Fixed	

Variable Telegram Syntax

Read Variable:				
`sRN CIMaxMaxiCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMaxMaxiCodesEna	String	17	

Read Variable Response:				
`sRA CIMaxMaxiCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMaxMaxiCodesEna	String	17	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CIMaxMaxiCodesEna <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMaxMaxiCodesEna	String	17	
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA CIMaxMaxiCodesEna				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMaxMaxiCodesEna	String	17	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CIMaxMaxiCodesEna[ETX]
Read Variable Response:	[STX]sRA CIMaxMaxiCodesEna 0[ETX]
Write Variable:	[STX]sWN CIMaxMaxiCodesEna 0[ETX]
Write Variable Response:	[STX]sWA CIMaxMaxiCodesEna[ETX]

2.37.7.15. Variable: MaxNumMaxiCodes

The following section contains a detailed description of the variable MaxNumMaxiCodes.

Variable Overview

Variable Name
MaxNumMaxiCodes

Communication Name	CIMaxMaxiCodes
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1246
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CIMaxMaxiCodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMaxMaxiCodes	String	14	

Read Variable Response:				
`sRA CIMaxMaxiCodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMaxMaxiCodes	String	14	
Variable Data	data	UInt	2	

Write Variable:				
`sWN CIMaxMaxiCodes <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMaxMaxiCodes	String	14	
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA CIMaxMaxiCodes`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMaxMaxiCodes	String	14	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMaxMaxiCodes[ETX]`
Read Variable Response:	`[STX]sRA CIMaxMaxiCodes 1[ETX]`
Write Variable:	`[STX]sWN CIMaxMaxiCodes 1[ETX]`
Write Variable Response:	`[STX]sWA CIMaxMaxiCodes[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7.16. Variable: WoodTexture

The following section contains a detailed description of the variable WoodTexture.

Variable Overview

Variable Name
WoodTexture

Communication Name	CIWdTex
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1247
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CIWdTex`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIWdTex	String	7	

Read Variable Response:				
`sRA CIWdTex <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIWdTex	String	7	
Variable Data	data	Bool	1	

Write Variable:				
`sWN CIWdTex <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIWdTex	String	7	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CIWdTex`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIWdTex	String	7	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIWdTex[ETX]`
Read Variable Response:	`[STX]sRA CIWdTex 0[ETX]`
Write Variable:	`[STX]sWN CIWdTex 0[ETX]`
Write Variable Response:	`[STX]sWA CIWdTex[ETX]`

2.37.7.17. Variable: LogisticsFalsePositiveFilter

The following section contains a detailed description of the variable LogisticsFalsePositiveFilter.

Variable Overview

Variable Name	Description
LogisticsFalsePositiveFilter	Enable the DD-1451 heuristic against code-like patterns on fancy packaging (logistics only)

Communication Name	CILogiFalsPosF
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1248
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN CILogiFalsPosF`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CILogiFalsPosF	String	14	Enable the DD-1451 heuristic against code-like patterns on fancy packaging (logistics only)

Read Variable Response:				
`sRA CILogiFalsPosF <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CILogiFalsPosF	String	14	Enable the DD-1451 heuristic against code-like patterns on fancy packaging (logistics only)
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CILogiFalsPosF <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CILogiFalsPosF	String	14	Enable the DD-1451 heuristic against code-like patterns on fancy packaging (logistics only)
Variable Data	data	Bool	1	

Write Variable Response:				
sWA CILogiFalsPosF				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CILogiFalsPosF	String	14	Enable the DD-1451 heuristic against code-like patterns on fancy packaging (logistics only)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CILogiFalsPosF[ETX]
Read Variable Response:	[STX]sRA CILogiFalsPosF 0[ETX]
Write Variable:	[STX]sWN CILogiFalsPosF 0[ETX]
Write Variable Response:	[STX]sWA CILogiFalsPosF[ETX]

2.37.7.18. Variable: MaxNumQRCodesEnabled

The following section contains a detailed description of the variable MaxNumQRCodesEnabled.

Variable Overview

Variable Name
MaxNumQRCodesEnabled

Communication Name	CIMaxQRCodesEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1243
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Fixed	
	Value	Name	Description
	0	Any	
	1	Fixed	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CIMaxQRCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMaxQRCodesEna	String	15	

Read Variable Response:				
`sRA CIMaxQRCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMaxQRCodesEna	String	15	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CIMaxQRCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMaxQRCodesEna	String	15	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CIMaxQRCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMaxQRCodesEna	String	15	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMaxQRCodesEna[ETX]`
Read Variable Response:	`[STX]sRA CIMaxQRCodesEna 1[ETX]`
Write Variable:	`[STX]sWN CIMaxQRCodesEna 1[ETX]`
Write Variable Response:	`[STX]sWA CIMaxQRCodesEna[ETX]`

© SICK AG - Germany - All rights reserved

2.37.7.19. Variable: MaxNumDMxCodesEnabled

The following section contains a detailed description of the variable MaxNumDMxCodesEnabled.

Variable Overview

Variable Name
MaxNumDMxCodesEnabled

Communication Name	CIMaxDMxCodesEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1241
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Fixed	
	Value	Name	Description
	0	Any	
	1	Fixed	

Variable Telegram Syntax

Read Variable:				
`sRN CIMaxDMxCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CIMaxDMxCodesEna	String	16	

Read Variable Response:				
`sRA CIMaxDMxCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CIMaxDMxCodesEna	String	16	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN CIMaxDMxCodesEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CIMaxDMxCodesEna	String	16	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CIMaxDMxCodesEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CIMaxDMxCodesEna	String	16	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CIMaxDMxCodesEna[ETX]`
Read Variable Response:	`[STX]sRA CIMaxDMxCodesEna 1[ETX]`
Write Variable:	`[STX]sWN CIMaxDMxCodesEna 1[ETX]`
Write Variable Response:	`[STX]sWA CIMaxDMxCodesEna[ETX]`

2.37.7.20. Variable: CodeModuleSize2D

The following section contains a detailed description of the variable CodeModuleSize2D.

Variable Overview

Variable Name
CodeModuleSize2D

Communication Name	CISModSz2D
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1231
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_HUGE	
	Value	Name	Description
	1	TX_MIDDLE	
	3	TX_HUGE	

Variable Telegram Syntax

Read Variable:				
`sRN CISModSz2D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CISModSz2D	String	10	

Read Variable Response:				
`sRA CISModSz2D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CISModSz2D	String	10	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN CISModSz2D <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CISModSz2D	String	10	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA CISModSz2D`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CISModSz2D	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CISModSz2D[ETX]`
Read Variable Response:	`[STX]sRA CISModSz2D 3[ETX]`
Write Variable:	`[STX]sWN CISModSz2D 3[ETX]`
Write Variable Response:	`[STX]sWA CISModSz2D[ETX]`

© SICK AG - Germany - All rights reserved

2.37.8. Group: Digimarc

2.37.8.1. Variable: DigimarcActive

The following section contains a detailed description of the variable DigimarcActive.

Variable Overview

Variable Name	Description
DigimarcActive	Activates Digimarc decoder

Communication Name	DDigAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1251
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DDigAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigAct	String	7	Activates Digimarc decoder

Read Variable Response:

```
sRA DDigAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigAct	String	7	Activates Digimarc decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DDigAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigAct	String	7	Activates Digimarc decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DDigAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDigAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DDigAct	String	7	Activates Digimarc decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDigAct[ETX]
Read Variable Response:	[STX]sRA DDigAct 0[ETX]
Write Variable:	[STX]sWN DDigAct 0[ETX]
Write Variable Response:	[STX]sWA DDigAct[ETX]

2.37.8.2. Variable: DigimarcExpectedModuleSize

The following section contains a detailed description of the variable DigimarcExpectedModuleSize.

Variable Overview

Variable Name	Description
DigimarcExpectedModuleSize	Control the downsampling in Digimarc

Communication Name	DDigExMoSz
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1252
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_MIDDLE	
	Value	Name	Description
	0	TX_SMALL	
	1	TX_MIDDLE	
	2	TX_BIG	
	3	TX_HUGE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDigExMoSz`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigExMoSz	String	10	Control the downsampling in Digimarc

Read Variable Response:				
`sRA DDigExMoSz <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigExMoSz	String	10	Control the downsampling in Digimarc
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DDigExMoSz <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigExMoSz	String	10	Control the downsampling in Digimarc
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DDigExMoSz`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigExMoSz	String	10	Control the downsampling in Digimarc

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDigExMoSz[ETX]`
Read Variable Response:	`[STX]sRA DDigExMoSz 1[ETX]`
Write Variable:	`[STX]sWN DDigExMoSz 1[ETX]`
Write Variable Response:	`[STX]sWA DDigExMoSz[ETX]`

© SICK AG - Germany - All rights reserved

2.37.8.3. Variable: DigimarcBlockSpacing

The following section contains a detailed description of the variable DigimarcBlockSpacing.

Variable Overview

Variable Name	Description
DigimarcBlockSpacing	Spacing of search blocks in pixels.

Communication Name	DDigBlkSpc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1253
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	200..500
Initialisation	260
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DDigBlkSpc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigBlkSpc	String	10	Spacing of search blocks in pixels.

Read Variable Response:

```
sRA DDigBlkSpc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigBlkSpc	String	10	Spacing of search blocks in pixels.
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DDigBlkSpc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigBlkSpc	String	10	Spacing of search blocks in pixels.
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DDigBlkSpc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigBlkSpc	String	10	Spacing of search blocks in pixels.

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDigBlkSpc[ETX]`
Read Variable Response:	`[STX]sRA DDigBlkSpc 104[ETX]`
Write Variable:	`[STX]sWN DDigBlkSpc 104[ETX]`
Write Variable Response:	`[STX]sWA DDigBlkSpc[ETX]`

2.37.8.4. Variable: DigimarcPerspectiveCorrection

The following section contains a detailed description of the variable DigimarcPerspectiveCorrection.

Variable Overview

Variable Name	Description
DigimarcPerspectiveCorrection	Enable perspective correction with tilt and bearing angle

Communication Name	DDigPerCor
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1254
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DDigPerCor
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigPerCor	String	10	Enable perspective correction with tilt and bearing angle

Read Variable Response:

```
sRA DDigPerCor <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigPerCor	String	10	Enable perspective correction with tilt and bearing angle
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DDigPerCor <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigPerCor	String	10	Enable perspective correction with tilt and bearing angle
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DDigPerCor				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigPerCor	String	10	Enable perspective correction with tilt and bearing angle

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDigPerCor[ETX]
Read Variable Response:	[STX]sRA DDigPerCor 0[ETX]
Write Variable:	[STX]sWN DDigPerCor 0[ETX]
Write Variable Response:	[STX]sWA DDigPerCor[ETX]

2.37.8.5. Variable: DigimarcTilt

The following section contains a detailed description of the variable DigimarcTilt.

Variable Overview

Variable Name	Description
DigimarcTilt	Tilt of the target in degrees.

Communication Name	DDigTilt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1255
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..359
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDigTilt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigTilt	String	8	Tilt of the target in degrees.

Read Variable Response:				
`sRA DDigTilt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigTilt	String	8	Tilt of the target in degrees.
Variable Data	data	UInt	2	

Write Variable:				
`sWN DDigTilt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigTilt	String	8	Tilt of the target in degrees.
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA DDigTilt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigTilt	String	8	Tilt of the target in degrees.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDigTilt[ETX]`
Read Variable Response:	`[STX]sRA DDigTilt 0[ETX]`
Write Variable:	`[STX]sWN DDigTilt 0[ETX]`
Write Variable Response:	`[STX]sWA DDigTilt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.8.6. Variable: DigimarcBearing

The following section contains a detailed description of the variable DigimarcBearing.

Variable Overview

Variable Name	Description
DigimarcBearing	Bearing at which the sensor looks at the target, in degrees.

Communication Name	DDigBea
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1256
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..359
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN DDigBea`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigBea	String	7	Bearing at which the sensor looks at the target, in degrees.

Read Variable Response:				
`sRA DDigBea <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigBea	String	7	Bearing at which the sensor looks at the target, in degrees.
Variable Data	data	UInt	2	

Write Variable:				
`sWN DDigBea <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigBea	String	7	Bearing at which the sensor looks at the target, in degrees.
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DDigBea				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigBea	String	7	Bearing at which the sensor looks at the target, in degrees.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DDigBea[ETX]
Read Variable Response:	[STX]sRA DDigBea 0[ETX]
Write Variable:	[STX]sWN DDigBea 0[ETX]
Write Variable Response:	[STX]sWA DDigBea[ETX]

2.37.8.7. Variable: DigimarcMaxBlocksToReadActive

The following section contains a detailed description of the variable DigimarcMaxBlocksToReadActive.

Variable Overview

Variable Name	Description
DigimarcMaxBlocksToReadActive	If selected use DigimarcMaxBlocksToRead parameter.

Communication Name	DDigMaxBlkAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1257
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DDigMaxBlkAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigMaxBlkAct	String	13	If selected use DigimarcMaxBlocksToRead parameter.

Read Variable Response:				
`sRA DDigMaxBlkAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigMaxBlkAct	String	13	If selected use DigimarcMaxBlocksToRead parameter.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DDigMaxBlkAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigMaxBlkAct	String	13	If selected use DigimarcMaxBlocksToRead parameter.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DDigMaxBlkAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigMaxBlkAct	String	13	If selected use DigimarcMaxBlocksToRead parameter.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDigMaxBlkAct[ETX]`
Read Variable Response:	`[STX]sRA DDigMaxBlkAct 0[ETX]`
Write Variable:	`[STX]sWN DDigMaxBlkAct 0[ETX]`
Write Variable Response:	`[STX]sWA DDigMaxBlkAct[ETX]`

© SICK AG - Germany - All rights reserved

2.37.8.8. Variable: DigimarcMaxBlocksToRead

The following section contains a detailed description of the variable DigimarcMaxBlocksToRead.

Variable Overview

Variable Name	Description
DigimarcMaxBlocksToRead	limits how many blocks Digimarc checks.

Communication Name	DDigMaxBlk
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1258
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..10
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DDigMaxBlk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigMaxBlk	String	10	limits how many blocks Digimarc checks.

Read Variable Response:

```
sRA DDigMaxBlk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigMaxBlk	String	10	limits how many blocks Digimarc checks.
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DDigMaxBlk <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigMaxBlk	String	10	limits how many blocks Digimarc checks.
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA DDigMaxBlk
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigMaxBlk	String	10	limits how many blocks Digimarc checks.

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDigMaxBlk[ETX]`
Read Variable Response:	`[STX]sRA DDigMaxBlk 1[ETX]`
Write Variable:	`[STX]sWN DDigMaxBlk 1[ETX]`
Write Variable Response:	`[STX]sWA DDigMaxBlk[ETX]`

2.37.8.9. Variable: DigimarcGiftCard

The following section contains a detailed description of the variable DigimarcGiftCard.

Variable Overview

Variable Name	Description
DigimarcGiftCard	Forward user specific digimarc-gift-card licence key

Communication Name	DDigGftCr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1259
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..128
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN DDigGftCr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DDigGftCr	String	9	Forward user specific digimarc-gift-card licence key

Read Variable Response:

```
sRA DDigGftCr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DDigGftCr	String	9	Forward user specific digimarc-gift-card licence key
Variable Data	data	FlexString	128	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DDigGftCr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DDigGftCr	String	9	Forward user specific digimarc-gift-card licence key
Variable Data	data	FlexString	128	

Write Variable Response:				
`sWA DDigGftCr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DDigGftCr	String	9	Forward user specific digimarc-gift-card licence key

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DDigGftCr[ETX]`
Read Variable Response:	`[STX]sRA DDigGftCr 0[ETX]`
Write Variable:	`[STX]sWN DDigGftCr 0[ETX]`
Write Variable Response:	`[STX]sWA DDigGftCr[ETX]`

© SICK AG - Germany - All rights reserved

2.37.9. Group: OpticsInterchangeableLens

2.37.9.1. Variable: InterchangeableLensfNumber

The following section contains a detailed description of the variable InterchangeableLensfNumber.

Variable Overview

Variable Name	Description
InterchangeableLensfNumber	f-Number

Communication Name	OILensfNumber
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1261
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..64.0
Initialisation	8.0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN OILensfNumber
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OILensfNumber	String	13	f-Number

Read Variable Response:

```
sRA OILensfNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OILensfNumber	String	13	f-Number
Variable Data	data	Real	4	

Write Variable:

```
sWN OILensfNumber <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OILensfNumber	String	13	f-Number
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OILensfNumber				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OILensfNumber	String	13	f-Number

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OILensfNumber[ETX]
Read Variable Response:	[STX]sRA OILensfNumber 41000000[ETX]
Write Variable:	[STX]sWN OILensfNumber 41000000[ETX]
Write Variable Response:	[STX]sWA OILensfNumber[ETX]

2.37.9.2. Variable: InterchangeableLensfStr

The following section contains a detailed description of the variable InterchangeableLensfStr.

Variable Overview

Variable Name	Description
InterchangeableLensfStr	focal length

Communication Name	OILensfStr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1262
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..1000.0
Initialisation	54.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OILensfStr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OILensfStr	String	10	focal length

Read Variable Response:				
`sRA OILensfStr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OILensfStr	String	10	focal length
Variable Data	data	Real	4	

Write Variable:				
`sWN OILensfStr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OILensfStr	String	10	focal length
Variable Data	data	Real	4	

Write Variable Response:				
`sWA OILensfStr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OILensfStr	String	10	focal length

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OILensfStr[ETX]`
Read Variable Response:	`[STX]sRA OILensfStr 42580000[ETX]`
Write Variable:	`[STX]sWN OILensfStr 42580000[ETX]`
Write Variable Response:	`[STX]sWA OILensfStr[ETX]`

© SICK AG - Germany - All rights reserved

2.37.9.3. Variable: InterchangeableLensType

The following section contains a detailed description of the variable InterchangeableLensType.

Variable Overview

Variable Name	Description
InterchangeableLensType	Type of the interchangeable lens

Communication Name	OILensType
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1263
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_INTERCHANGEABLE_LENS_TYPE_UNKNOWN	
	Value	Name	Description
	0	TX_INTERCHANGEABLE_LENS_TYPE_UNKNOWN	Unknown lens type
	1	TX_INTERCHANGEABLE_LENS_TYPE_USERDEFINED	User-defined lens

Variable Telegram Syntax

Read Variable:

```
sRN OILensType
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OILensType	String	10	Type of the interchangeable lens

Read Variable Response:

```
sRA OILensType <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OILensType	String	10	Type of the interchangeable lens
Variable Data	data	Enum8	1	

Write Variable:

```
sWN OILensType <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OILensType	String	10	Type of the interchangeable lens
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA OILensType				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OILensType	String	10	Type of the interchangeable lens

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN OILensType[ETX]
Read Variable Response:	[STX]sRA OILensType 0[ETX]
Write Variable:	[STX]sWN OILensType 0[ETX]
Write Variable Response:	[STX]sWA OILensType[ETX]

2.37.9.4. Variable: InterchangeableLensTransmission

The following section contains a detailed description of the variable InterchangeableLensTransmission.

Variable Overview

Variable Name	Description
InterchangeableLensTransmission	transmission of lens

Communication Name	OILensTrans
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1264
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..1.0
Initialisation	0.9
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN OILensTrans`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	OILensTrans	String	11	transmission of lens

Read Variable Response:				
`sRA OILensTrans <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	OILensTrans	String	11	transmission of lens
Variable Data	data	Real	4	

Write Variable:				
`sWN OILensTrans <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	OILensTrans	String	11	transmission of lens
Variable Data	data	Real	4	

Write Variable Response:				
`sWA OILensTrans`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	OILensTrans	String	11	transmission of lens

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN OILensTrans[ETX]`
Read Variable Response:	`[STX]sRA OILensTrans 3F666666[ETX]`
Write Variable:	`[STX]sWN OILensTrans 3F666666[ETX]`
Write Variable Response:	`[STX]sWA OILensTrans[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10. Group: ImageDiagnosis

2.37.10.1. Variable: ImgDiagStoreCondition

The following section contains a detailed description of the variable ImgDiagStoreCondition.

Variable Overview

Variable Name	Description
ImgDiagStoreCondition	Condition when to store images

Communication Name	DIAGStoreCnd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1265
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		2	
	Value	Name	Description
	0	TX_GOOD_READ	
	1	TX_NO_READ	
	2	TX_ALL	
	3	TX_CONTROLLED_BY_MASTER	
	4	TX_CONT_IMAGES	

Variable Telegram Syntax

Read Variable:

```
sRN DIAGStoreCnd
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGStoreCnd	String	12	Condition when to store images

Read Variable Response:

```
sRA DIAGStoreCnd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGStoreCnd	String	12	Condition when to store images
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DIAGStoreCnd <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGStoreCnd	String	12	Condition when to store images
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGStoreCnd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGStoreCnd	String	12	Condition when to store images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGStoreCnd[ETX]
Read Variable Response:	[STX]sRA DIAGStoreCnd 2[ETX]
Write Variable:	[STX]sWN DIAGStoreCnd 2[ETX]
Write Variable Response:	[STX]sWA DIAGStoreCnd[ETX]

2.37.10.2. Variable: ImgDiagStoreConditionExt

The following section contains a detailed description of the variable ImgDiagStoreConditionExt.

Variable Overview

Variable Name	Description
ImgDiagStoreConditionExt	Extension of store condition

Communication Name	DIAGStoreCndExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1266
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGStoreCndExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGStoreCndExt	String	15	Extension of store condition

Read Variable Response:				
`sRA DIAGStoreCndExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGStoreCndExt	String	15	Extension of store condition
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN DIAGStoreCndExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGStoreCndExt	String	15	Extension of store condition
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA DIAGStoreCndExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGStoreCndExt	String	15	Extension of store condition

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGStoreCndExt[ETX]`
Read Variable Response:	`[STX]sRA DIAGStoreCndExt 0 0[ETX]`
Write Variable:	`[STX]sWN DIAGStoreCndExt 0 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGStoreCndExt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.3. Variable: ImgDiagImageSelection

The following section contains a detailed description of the variable ImgDiagImageSelection.

Variable Overview

Variable Name	Description
ImgDiagImageSelection	Determines which images to store, if the store condition is complied with.

Communication Name	DIAGImgSelection
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1267
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
	Value	Name	Description
	0	LastGoodRead_LastImage	
	1	FirstImage	
	2	ImageSequence	

Variable Telegram Syntax

Read Variable:				
`sRN DIAGImgSelection`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGImgSelection	String	16	Determines which images to store, if the store condition is complied with.

Read Variable Response:				
`sRA DIAGImgSelection <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGImgSelection	String	16	Determines which images to store, if the store condition is complied with.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DIAGImgSelection <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGImgSelection	String	16	Determines which images to store, if the store condition is complied with.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGImgSelection				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGImgSelection	String	16	Determines which images to store, if the store condition is complied with.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGImgSelection[ETX]
Read Variable Response:	[STX]sRA DIAGImgSelection 0[ETX]
Write Variable:	[STX]sWN DIAGImgSelection 0[ETX]
Write Variable Response:	[STX]sWA DIAGImgSelection[ETX]

2.37.10.4. Variable: ImgDiagPathDevice

The following section contains a detailed description of the variable ImgDiagPathDevice.

Variable Overview

Variable Name	Description
ImgDiagPathDevice	Eiter the serial number of the device or a user defined device name has to be included in the image storage path.

Communication Name	DIAGPathDevice
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1268
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	SerialNumber	
	1	DeviceName	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGPathDevice`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGPathDevice	String	14	Eiter the serial number of the device or a user defined device name has to be included in the image storage path.

Read Variable Response:				
`sRA DIAGPathDevice <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGPathDevice	String	14	Eiter the serial number of the device or a user defined device name has to be included in the image storage path.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DIAGPathDevice <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGPathDevice	String	14	Eiter the serial number of the device or a user defined device name has to be included in the image storage path.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DIAGPathDevice`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGPathDevice	String	14	Eiter the serial number of the device or a user defined device name has to be included in the image storage path.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGPathDevice[ETX]`
Read Variable Response:	`[STX]sRA DIAGPathDevice 0[ETX]`
Write Variable:	`[STX]sWN DIAGPathDevice 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGPathDevice[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.5. Variable: ImgDiagPathDeviceName

The following section contains a detailed description of the variable ImgDiagPathDeviceName.

Variable Overview

Variable Name	Description
ImgDiagPathDeviceName	User defined device name for the image store path.

Communication Name	DIAGDeviceName
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1269
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..62
Initialisation	LECTOR6xx

Variable Telegram Syntax

Read Variable:

```
sRN DIAGDeviceName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGDeviceName	String	14	User defined device name for the image store path.

Read Variable Response:

```
sRA DIAGDeviceName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGDeviceName	String	14	User defined device name for the image store path.
Variable Data	data	FlexString	62	

Write Variable:

```
sWN DIAGDeviceName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGDeviceName	String	14	User defined device name for the image store path.
Variable Data	data	FlexString	62	

Write Variable Response:

```
sWA DIAGDeviceName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGDeviceName	String	14	User defined device name for the image store path.

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGDeviceName[ETX]`
Read Variable Response:	`[STX]sRA DIAGDeviceName 9 LECTOR6xx[ETX]`
Write Variable:	`[STX]sWN DIAGDeviceName 9 LECTOR6xx[ETX]`
Write Variable Response:	`[STX]sWA DIAGDeviceName[ETX]`

2.37.10.6. Variable: ImgDiagPathDate

The following section contains a detailed description of the variable ImgDiagPathDate.

Variable Overview

Variable Name	Description
ImgDiagPathDate	Use the current date as subfolder for image storage.

Communication Name	DIAGDate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1270
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN DIAGDate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGDate	String	8	Use the current date as subfolder for image storage.

Read Variable Response:				
`sRA DIAGDate <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGDate	String	8	Use the current date as subfolder for image storage.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN DIAGDate <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGDate	String	8	Use the current date as subfolder for image storage.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGDate`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGDate	String	8	Use the current date as subfolder for image storage.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGDate[ETX]`
Read Variable Response:	`[STX]sRA DIAGDate 0[ETX]`
Write Variable:	`[STX]sWN DIAGDate 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGDate[ETX]`

2.37.10.7. Variable: ImgDiagPathHour

The following section contains a detailed description of the variable ImgDiagPathHour.

Variable Overview

Variable Name	Description
ImgDiagPathHour	Use the current hour as subfolder for image storage.

Communication Name	DIAGHour
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1271
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGHour`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGHour	String	8	Use the current hour as subfolder for image storage.

Read Variable Response:				
`sRA DIAGHour <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGHour	String	8	Use the current hour as subfolder for image storage.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGHour <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGHour	String	8	Use the current hour as subfolder for image storage.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGHour`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGHour	String	8	Use the current hour as subfolder for image storage.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGHour[ETX]`
Read Variable Response:	`[STX]sRA DIAGHour 0[ETX]`
Write Variable:	`[STX]sWN DIAGHour 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGHour[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.8. Variable: ImgDiagPathGoodReadNoRead

The following section contains a detailed description of the variable ImgDiagPathGoodReadNoRead.

Variable Overview

Variable Name	Description
ImgDiagPathGoodReadNoRead	Store images in subfolders 'GoodRead' or 'NoRead'.

Communication Name	DIAGPathGRNR
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1272
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGPathGRNR
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGPathGRNR	String	12	Store images in subfolders 'GoodRead' or 'NoRead'.

Read Variable Response:

```
sRA DIAGPathGRNR <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGPathGRNR	String	12	Store images in subfolders 'GoodRead' or 'NoRead'.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGPathGRNR <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGPathGRNR	String	12	Store images in subfolders 'GoodRead' or 'NoRead'.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGPathGRNR
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGPathGRNR				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DIAGPathGRNR	String	12	Store images in subfolders 'GoodRead' or 'NoRead'.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGPathGRNR[ETX]
Read Variable Response:	[STX]sRA DIAGPathGRNR 0[ETX]
Write Variable:	[STX]sWN DIAGPathGRNR 0[ETX]
Write Variable Response:	[STX]sWA DIAGPathGRNR[ETX]

2.37.10.9. Variable: ImgDiagFileGoodReadNoRead

The following section contains a detailed description of the variable ImgDiagFileGoodReadNoRead.

Variable Overview

Variable Name	Description
ImgDiagFileGoodReadNoRead	Add prefix 'GoodRead' or 'NoRead' to image file names.

Communication Name	DIAGFileGRNR
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1273
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGFileGRNR`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGFileGRNR	String	12	Add prefix 'GoodRead' or 'NoRead' to image file names.

Read Variable Response:				
`sRA DIAGFileGRNR <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGFileGRNR	String	12	Add prefix 'GoodRead' or 'NoRead' to image file names.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGFileGRNR <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGFileGRNR	String	12	Add prefix 'GoodRead' or 'NoRead' to image file names.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGFileGRNR`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGFileGRNR	String	12	Add prefix 'GoodRead' or 'NoRead' to image file names.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGFileGRNR[ETX]`
Read Variable Response:	`[STX]sRA DIAGFileGRNR 0[ETX]`
Write Variable:	`[STX]sWN DIAGFileGRNR 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGFileGRNR[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.10. Variable: ImgDiagFileName

The following section contains a detailed description of the variable ImgDiagFileName.

Variable Overview

Variable Name	Description
ImgDiagFileName	Name for all image files that are stored

Communication Name	DIAGImgFileName
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1274
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	img

Variable Telegram Syntax

Read Variable:

```
sRN DIAGImgFileName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGImgFileName	String	15	Name for all image files that are stored

Read Variable Response:

```
sRA DIAGImgFileName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGImgFileName	String	15	Name for all image files that are stored
Variable Data	data	FlexString	32	

Write Variable:

```
sWN DIAGImgFileName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGImgFileName	String	15	Name for all image files that are stored
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA DIAGImgFileName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGImgFileName	String	15	Name for all image files that are stored

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGImgFileName[ETX]`
Read Variable Response:	`[STX]sRA DIAGImgFileName 3 img[ETX]`
Write Variable:	`[STX]sWN DIAGImgFileName 3 img[ETX]`
Write Variable Response:	`[STX]sWA DIAGImgFileName[ETX]`

2.37.10.11. Variable: ImgDiagFileSystemInfo

The following section contains a detailed description of the variable ImgDiagFileSystemInfo.

Variable Overview

Variable Name	Description
ImgDiagFileSystemInfo	Add postfix SystemInfo to image file names.

Communication Name	DIAGFileSysInfo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1275
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGFileSysInfo
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGFileSysInfo	String	15	Add postfix SystemInfo to image file names.

Read Variable Response:

```
sRA DIAGFileSysInfo <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGFileSysInfo	String	15	Add postfix SystemInfo to image file names.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DIAGFileSysInfo <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGFileSysInfo	String	15	Add postfix SystemInfo to image file names.
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DIAGFileSysInfo				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGFileSysInfo	String	15	Add postfix SystemInfo to image file names.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGFileSysInfo[ETX]
Read Variable Response:	[STX]sRA DIAGFileSysInfo 0[ETX]
Write Variable:	[STX]sWN DIAGFileSysInfo 0[ETX]
Write Variable Response:	[STX]sWA DIAGFileSysInfo[ETX]

2.37.10.12. Variable: ImgDiagFileTimestamp

The following section contains a detailed description of the variable ImgDiagFileTimestamp.

Variable Overview

Variable Name	Description
ImgDiagFileTimestamp	Add timestamp to image file names

Communication Name	DIAGFileTmStamp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1276
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGFileTmStamp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGFileTmStamp	String	15	Add timestamp to image file names

Read Variable Response:				
`sRA DIAGFileTmStamp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGFileTmStamp	String	15	Add timestamp to image file names
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGFileTmStamp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGFileTmStamp	String	15	Add timestamp to image file names
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGFileTmStamp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGFileTmStamp	String	15	Add timestamp to image file names

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGFileTmStamp[ETX]`
Read Variable Response:	`[STX]sRA DIAGFileTmStamp 0[ETX]`
Write Variable:	`[STX]sWN DIAGFileTmStamp 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGFileTmStamp[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.13. Variable: ImgDiagSDCardFileCycleMethod

The following section contains a detailed description of the variable ImgDiagSDCardFileCycleMethod.

Variable Overview

Variable Name	Description
ImgDiagSDCardFileCycleMethod	Selects the method to number the image files on the SD card. It's either by trigger number or by fixed cyclic numbers.

Communication Name	DIAGSDCardImgFileCycleMethod
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1279
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	Trigger_No	
	1	Cycle_No	

Variable Telegram Syntax

Read Variable:

```
sRN DIAGSDCardImgFileCycleMethod
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSDCardImgFileCycleMethod	String	28	Selects the method to number the image files on the SD card. It's either by trigger number or by fixed cyclic numbers.

Read Variable Response:

```
sRA DIAGSDCardImgFileCycleMethod <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSDCardImgFileCycleMethod	String	28	Selects the method to number the image files on the SD card. It's either by trigger number or by fixed cyclic numbers.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DIAGSDCardImgFileCycleMethod <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSDCardImgFileCycleMethod	String	28	Selects the method to number the image files on the SD card. It's either by trigger number or by fixed cyclic numbers.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGSDCardImgFileCycleMethod				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSDCardImgFileCycleMethod	String	28	Selects the method to number the image files on the SD card. It's either by trigger number or by fixed cyclic numbers.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSDCardImgFileCycleMethod[ETX]
Read Variable Response:	[STX]sRA DIAGSDCardImgFileCycleMethod 1[ETX]
Write Variable:	[STX]sWN DIAGSDCardImgFileCycleMethod 1[ETX]
Write Variable Response:	[STX]sWA DIAGSDCardImgFileCycleMethod[ETX]

2.37.10.14. Variable: ImgDiagSDCardFileCycleModulo

The following section contains a detailed description of the variable ImgDiagSDCardFileCycleModulo.

Variable Overview

Variable Name	Description
ImgDiagSDCardFileCycleModulo	Modulo for cyclic image file numbering mode on the SD card.

Communication Name	DIAGSDCardImgFileCountModulo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1280
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..4294967295
Initialisation	30
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGSDCardImgFileCountModulo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSDCardImgFileCountModulo	String	28	Modulo for cyclic image file numbering mode on the SD card.

Read Variable Response:				
`sRA DIAGSDCardImgFileCountModulo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSDCardImgFileCountModulo	String	28	Modulo for cyclic image file numbering mode on the SD card.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DIAGSDCardImgFileCountModulo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSDCardImgFileCountModulo	String	28	Modulo for cyclic image file numbering mode on the SD card.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DIAGSDCardImgFileCountModulo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSDCardImgFileCountModulo	String	28	Modulo for cyclic image file numbering mode on the SD card.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGSDCardImgFileCountModulo[ETX]`
Read Variable Response:	`[STX]sRA DIAGSDCardImgFileCountModulo 1E[ETX]`
Write Variable:	`[STX]sWN DIAGSDCardImgFileCountModulo 1E[ETX]`
Write Variable Response:	`[STX]sWA DIAGSDCardImgFileCountModulo[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.15. Variable: ImgDiagSopasFileCycleMethod

The following section contains a detailed description of the variable ImgDiagSopasFileCycleMethod.

Variable Overview

Variable Name	Description
ImgDiagSopasFileCycleMethod	Selects the method to number the image files on the PC when sent to Sopas. It's either by trigger number or by fixed cyclic numbers.

Communication Name	DIAGSopasImgFileCycleMethod
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1281
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	Trigger_No	
	1	Cycle_No	

Variable Telegram Syntax

Read Variable:				
`sRN DIAGSopasImgFileCycleMethod`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSopasImgFileCycleMethod	String	27	Selects the method to number the image files on the PC when sent to Sopas. It's either by trigger number or by fixed cyclic numbers.

Read Variable Response:				
`sRA DIAGSopasImgFileCycleMethod <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSopasImgFileCycleMethod	String	27	Selects the method to number the image files on the PC when sent to Sopas. It's either by trigger number or by fixed cyclic numbers.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DIAGSopasImgFileCycleMethod <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSopasImgFileCycleMethod	String	27	Selects the method to number the image files on the PC when sent to Sopas. It's either by trigger number or by fixed cyclic numbers.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGSopasImgFileCycleMethod				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSopasImgFileCycleMethod	String	27	Selects the method to number the image files on the PC when sent to Sopas. It's either by trigger number or by fixed cyclic numbers.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSopasImgFileCycleMethod[ETX]
Read Variable Response:	[STX]sRA DIAGSopasImgFileCycleMethod 1[ETX]
Write Variable:	[STX]sWN DIAGSopasImgFileCycleMethod 1[ETX]
Write Variable Response:	[STX]sWA DIAGSopasImgFileCycleMethod[ETX]

2.37.10.16. Variable: ImgDiagSopasFileCycleModulo

The following section contains a detailed description of the variable ImgDiagSopasFileCycleModulo.

Variable Overview

Variable Name	Description
ImgDiagSopasFileCycleModulo	Modulo for cyclic image file numbering mode on the Sopas PC.

Communication Name	DIAGSopasImgFileCountModulo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1282
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..4294967295
Initialisation	30
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGSopasImgFileCountModulo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSopasImgFileCountModulo	String	27	Modulo for cyclic image file numbering mode on the Sopas PC.

Read Variable Response:				
`sRA DIAGSopasImgFileCountModulo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSopasImgFileCountModulo	String	27	Modulo for cyclic image file numbering mode on the Sopas PC.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DIAGSopasImgFileCountModulo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSopasImgFileCountModulo	String	27	Modulo for cyclic image file numbering mode on the Sopas PC.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DIAGSopasImgFileCountModulo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSopasImgFileCountModulo	String	27	Modulo for cyclic image file numbering mode on the Sopas PC.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGSopasImgFileCountModulo[ETX]`
Read Variable Response:	`[STX]sRA DIAGSopasImgFileCountModulo 1E[ETX]`
Write Variable:	`[STX]sWN DIAGSopasImgFileCountModulo 1E[ETX]`
Write Variable Response:	`[STX]sWA DIAGSopasImgFileCountModulo[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.17. Variable: ImgDiagFTPFileCycleMethod

The following section contains a detailed description of the variable ImgDiagFTPFileCycleMethod.

Variable Overview

Variable Name	Description
ImgDiagFTPFileCycleMethod	Selects the method to number the image files when sent to the FTP server. It's either by trigger number or by fixed cyclic numbers.

Communication Name	DIAGFTPImgFileCycleMethod
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1283
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		1	
	Value	Name	Description
	0	Trigger_No	
	1	Cycle_No	

Variable Telegram Syntax

Read Variable:				
`sRN DIAGFTPImgFileCycleMethod`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGFTPImgFileCycleMethod	String	25	Selects the method to number the image files when sent to the FTP server. It's either by trigger number or by fixed cyclic numbers.

Read Variable Response:				
`sRA DIAGFTPImgFileCycleMethod <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGFTPImgFileCycleMethod	String	25	Selects the method to number the image files when sent to the FTP server. It's either by trigger number or by fixed cyclic numbers.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DIAGFTPImgFileCycleMethod <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGFTPImgFileCycleMethod	String	25	Selects the method to number the image files when sent to the FTP server. It's either by trigger number or by fixed cyclic numbers.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGFTPImgFileCycleMethod				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGFTPImgFileCycleMethod	String	25	Selects the method to number the image files when sent to the FTP server. It's either by trigger number or by fixed cyclic numbers.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGFTPImgFileCycleMethod[ETX]
Read Variable Response:	[STX]sRA DIAGFTPImgFileCycleMethod 1[ETX]
Write Variable:	[STX]sWN DIAGFTPImgFileCycleMethod 1[ETX]
Write Variable Response:	[STX]sWA DIAGFTPImgFileCycleMethod[ETX]

2.37.10.18. Variable: ImgDiagFTPFileCycleModulo

The following section contains a detailed description of the variable ImgDiagFTPFileCycleModulo.

Variable Overview

Variable Name	Description
ImgDiagFTPFileCycleModulo	Modulo for cyclic image file numbering mode on the FTP server.

Communication Name	DIAGFTPImgFileCountModulo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1284
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..4294967295
Initialisation	30
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGFTPImgFileCountModulo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGFTPImgFileCountModulo	String	25	Modulo for cyclic image file numbering mode on the FTP server.

Read Variable Response:				
`sRA DIAGFTPImgFileCountModulo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGFTPImgFileCountModulo	String	25	Modulo for cyclic image file numbering mode on the FTP server.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DIAGFTPImgFileCountModulo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGFTPImgFileCountModulo	String	25	Modulo for cyclic image file numbering mode on the FTP server.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DIAGFTPImgFileCountModulo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGFTPImgFileCountModulo	String	25	Modulo for cyclic image file numbering mode on the FTP server.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGFTPImgFileCountModulo[ETX]`
Read Variable Response:	`[STX]sRA DIAGFTPImgFileCountModulo 1E[ETX]`
Write Variable:	`[STX]sWN DIAGFTPImgFileCountModulo 1E[ETX]`
Write Variable Response:	`[STX]sWA DIAGFTPImgFileCountModulo[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.19. Variable: ImgDiagSaveToSDCard

The following section contains a detailed description of the variable ImgDiagSaveToSDCard.

Variable Overview

Variable Name	Description
ImgDiagSaveToSDCard	Images are stored on the micro SD card if primary condition is fulfilled.

Communication Name	DIAGSaveToSD
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1287
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGSaveToSD
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSaveToSD	String	12	Images are stored on the micro SD card if primary condition is fulfilled.

Read Variable Response:

```
sRA DIAGSaveToSD <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSaveToSD	String	12	Images are stored on the micro SD card if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGSaveToSD <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSaveToSD	String	12	Images are stored on the micro SD card if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGSaveToSD
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGSaveToSD				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DIAGSaveToSD	String	12	Images are stored on the micro SD card if primary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSaveToSD[ETX]
Read Variable Response:	[STX]sRA DIAGSaveToSD 0[ETX]
Write Variable:	[STX]sWN DIAGSaveToSD 0[ETX]
Write Variable Response:	[STX]sWA DIAGSaveToSD[ETX]

2.37.10.20. Variable: ImgDiagSaveToSDCard2

The following section contains a detailed description of the variable ImgDiagSaveToSDCard2.

Variable Overview

Variable Name	Description
ImgDiagSaveToSDCard2	Images are stored on the micro SD card if secondary condition is fulfilled.

Communication Name	DIAGSaveToSD2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1288
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN DIAGSaveToSD2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSaveToSD2	String	13	Images are stored on the micro SD card if secondary condition is fulfilled.

Read Variable Response:				
sRA DIAGSaveToSD2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSaveToSD2	String	13	Images are stored on the micro SD card if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:				
sWN DIAGSaveToSD2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSaveToSD2	String	13	Images are stored on the micro SD card if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DIAGSaveToSD2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSaveToSD2	String	13	Images are stored on the micro SD card if secondary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSaveToSD2[ETX]
Read Variable Response:	[STX]sRA DIAGSaveToSD2 0[ETX]
Write Variable:	[STX]sWN DIAGSaveToSD2 0[ETX]
Write Variable Response:	[STX]sWA DIAGSaveToSD2[ETX]

© SICK AG - Germany - All rights reserved

2.37.10.21. Variable: ImgDiagSendFTP

The following section contains a detailed description of the variable ImgDiagSendFTP.

Variable Overview

Variable Name	Description
ImgDiagSendFTP	Images are sent to the specified FTP server if primary condition is fulfilled.

Communication Name	DIAGSendToFTP
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1289
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGSendToFTP
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSendToFTP	String	13	Images are sent to the specified FTP server if primary condition is fulfilled.

Read Variable Response:

```
sRA DIAGSendToFTP <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSendToFTP	String	13	Images are sent to the specified FTP server if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGSendToFTP <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSendToFTP	String	13	Images are sent to the specified FTP server if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGSendToFTP
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGSendToFTP				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DIAGSendToFTP	String	13	Images are sent to the specified FTP server if primary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSendToFTP[ETX]
Read Variable Response:	[STX]sRA DIAGSendToFTP 0[ETX]
Write Variable:	[STX]sWN DIAGSendToFTP 0[ETX]
Write Variable Response:	[STX]sWA DIAGSendToFTP[ETX]

2.37.10.22. Variable: ImgDiagSendFTPLegacyStyle

The following section contains a detailed description of the variable ImgDiagSendFTPLegacyStyle.

Variable Overview

Variable Name	Description
ImgDiagSendFTPLegacyStyle	Images are sent to the specified FTP server with legacy client, not with libcurl.

Communication Name	DIAGSendToFtpLs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1290
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGSendToFtpLs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSendToFtpLs	String	15	Images are sent to the specified FTP server with legacy client, not with libcurl.

Read Variable Response:				
`sRA DIAGSendToFtpLs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSendToFtpLs	String	15	Images are sent to the specified FTP server with legacy client, not with libcurl.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGSendToFtpLs <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSendToFtpLs	String	15	Images are sent to the specified FTP server with legacy client, not with libcurl.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGSendToFtpLs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSendToFtpLs	String	15	Images are sent to the specified FTP server with legacy client, not with libcurl.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGSendToFtpLs[ETX]`
Read Variable Response:	`[STX]sRA DIAGSendToFtpLs 0[ETX]`
Write Variable:	`[STX]sWN DIAGSendToFtpLs 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGSendToFtpLs[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.23. Variable: ImgDiagSendFTP2

The following section contains a detailed description of the variable ImgDiagSendFTP2.

Variable Overview

Variable Name	Description
ImgDiagSendFTP2	Images are sent to the specified FTP server if secondary condition is fulfilled.

Communication Name	DIAGSendToFTP2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1291
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGSendToFTP2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSendToFTP2	String	14	Images are sent to the specified FTP server if secondary condition is fulfilled.

Read Variable Response:

```
sRA DIAGSendToFTP2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSendToFTP2	String	14	Images are sent to the specified FTP server if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGSendToFTP2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSendToFTP2	String	14	Images are sent to the specified FTP server if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGSendToFTP2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGSendToFTP2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DIAGSendToFTP2	String	14	Images are sent to the specified FTP server if secondary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSendToFTP2[ETX]
Read Variable Response:	[STX]sRA DIAGSendToFTP2 0[ETX]
Write Variable:	[STX]sWN DIAGSendToFTP2 0[ETX]
Write Variable Response:	[STX]sWA DIAGSendToFTP2[ETX]

2.37.10.24. Variable: ImgDiagFTPArchiv

The following section contains a detailed description of the variable ImgDiagFTPArchiv.

Variable Overview

Variable Name	Description
ImgDiagFTPArchiv	Images are stored on the internal FTP server if primary condition is fulfilled.

Communication Name	DIAGToFTPArchiv
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1292
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGToFTPArchiv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGToFTPArchiv	String	15	Images are stored on the internal FTP server if primary condition is fulfilled.

Read Variable Response:				
`sRA DIAGToFTPArchiv <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGToFTPArchiv	String	15	Images are stored on the internal FTP server if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGToFTPArchiv <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGToFTPArchiv	String	15	Images are stored on the internal FTP server if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGToFTPArchiv`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGToFTPArchiv	String	15	Images are stored on the internal FTP server if primary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGToFTPArchiv[ETX]`
Read Variable Response:	`[STX]sRA DIAGToFTPArchiv 0[ETX]`
Write Variable:	`[STX]sWN DIAGToFTPArchiv 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGToFTPArchiv[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.25. Variable: ImgDiagFTPArchiv2

The following section contains a detailed description of the variable ImgDiagFTPArchiv2.

Variable Overview

Variable Name	Description
ImgDiagFTPArchiv2	Images are stored on the internal FTP server if secondary condition is fulfilled.

Communication Name	DIAGToFTPArchiv2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1293
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGToFTPArchiv2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGToFTPArchiv2	String	16	Images are stored on the internal FTP server if secondary condition is fulfilled.

Read Variable Response:

```
sRA DIAGToFTPArchiv2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGToFTPArchiv2	String	16	Images are stored on the internal FTP server if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGToFTPArchiv2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGToFTPArchiv2	String	16	Images are stored on the internal FTP server if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGToFTPArchiv2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGToFTPArchiv2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DIAGToFTPArchiv2	String	16	Images are stored on the internal FTP server if secondary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGToFTPArchiv2[ETX]
Read Variable Response:	[STX]sRA DIAGToFTPArchiv2 0[ETX]
Write Variable:	[STX]sWN DIAGToFTPArchiv2 0[ETX]
Write Variable Response:	[STX]sWA DIAGToFTPArchiv2[ETX]

2.37.10.26. Variable: ImgDiagSendSopas

The following section contains a detailed description of the variable ImgDiagSendSopas.

Variable Overview

Variable Name	Description
ImgDiagSendSopas	Images are sent to SOPAS PC if primary condition is fulfilled.

Communication Name	DIAGSendToSopas
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1294
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGSendToSopas`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSendToSopas	String	15	Images are sent to SOPAS PC if primary condition is fulfilled.

Read Variable Response:				
`sRA DIAGSendToSopas <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSendToSopas	String	15	Images are sent to SOPAS PC if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGSendToSopas <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSendToSopas	String	15	Images are sent to SOPAS PC if primary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGSendToSopas`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGSendToSopas	String	15	Images are sent to SOPAS PC if primary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGSendToSopas[ETX]`
Read Variable Response:	`[STX]sRA DIAGSendToSopas 1[ETX]`
Write Variable:	`[STX]sWN DIAGSendToSopas 1[ETX]`
Write Variable Response:	`[STX]sWA DIAGSendToSopas[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.27. Variable: ImgDiagSendSopas2

The following section contains a detailed description of the variable ImgDiagSendSopas2.

Variable Overview

Variable Name	Description
ImgDiagSendSopas2	Images are sent to SOPAS PC if secondary condition is fulfilled.

Communication Name	DIAGSendToSopas2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1295
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN DIAGSendToSopas2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGSendToSopas2	String	16	Images are sent to SOPAS PC if secondary condition is fulfilled.

Read Variable Response:

```
sRA DIAGSendToSopas2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGSendToSopas2	String	16	Images are sent to SOPAS PC if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGSendToSopas2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGSendToSopas2	String	16	Images are sent to SOPAS PC if secondary condition is fulfilled.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGSendToSopas2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGSendToSopas2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DIAGSendToSopas2	String	16	Images are sent to SOPAS PC if secondary condition is fulfilled.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGSendToSopas2[ETX]
Read Variable Response:	[STX]sRA DIAGSendToSopas2 1[ETX]
Write Variable:	[STX]sWN DIAGSendToSopas2 1[ETX]
Write Variable Response:	[STX]sWA DIAGSendToSopas2[ETX]

2.37.10.28. Method: GetImagesFromSD

The following section contains a detailed description of the method GetImagesFromSD.

Method Overview

Method Name
GetImagesFromSD

Communication Name	mDIAGGetImagesFromSD
Sopas Index	121
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
sMN mDIAGGetImagesFromSD				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIAGGetImagesFromSD	String	20	

Method Return Value:				
sAN mDIAGGetImagesFromSD				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIAGGetImagesFromSD	String	20	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIAGGetImagesFromSD[ETX]`
Method Return Value:	`[STX]sAN mDIAGGetImagesFromSD[ETX]`

2.37.10.29. Method: GetImagesFromRam

The following section contains a detailed description of the method GetImagesFromRam.

Method Overview

Method Name
GetImagesFromRam

Communication Name	mDIAGGetImagesFromRam
Sopas Index	122
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

`sMN mDIAGGetImagesFromRam`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIAGGetImagesFromRam	String	21	

Method Return Value:

`sAN mDIAGGetImagesFromRam`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIAGGetImagesFromRam	String	21	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIAGGetImagesFromRam[ETX]`
Method Return Value:	`[STX]sAN mDIAGGetImagesFromRam[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.30. Method: CancelImageUpload

The following section contains a detailed description of the method CancelImageUpload.

Method Overview

Method Name
CancelImageUpload

Communication Name	mDIAGCancelImgUpload
Sopas Index	123
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mDIAGCancelImgUpload`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIAGCancelImgUpload	String	20	

Method Return Value:				
`sAN mDIAGCancelImgUpload`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIAGCancelImgUpload	String	20	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIAGCancelImgUpload[ETX]`
Method Return Value:	`[STX]sAN mDIAGCancelImgUpload[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.31. Method: DeleteImagesFromSD

The following section contains a detailed description of the method DeleteImagesFromSD.

Method Overview

Method Name
DeleteImagesFromSD

Communication Name	mDIAGDelImagesFromSD
Sopas Index	124
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mDIAGDelImagesFromSD`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIAGDelImagesFromSD	String	20	

Method Return Value:				
`sAN mDIAGDelImagesFromSD`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIAGDelImagesFromSD	String	20	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIAGDelImagesFromSD[ETX]`
Method Return Value:	`[STX]sAN mDIAGDelImagesFromSD[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.32. Method: DeleteImagesFromRam

The following section contains a detailed description of the method DeleteImagesFromRam.

Method Overview

Method Name
DeleteImagesFromRam

Communication Name	mDIAGDelImagesFromRam
Sopas Index	125
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

```
sMN mDIAGDelImagesFromRam
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIAGDelImagesFromRam	String	21	

Method Return Value:

```
sAN mDIAGDelImagesFromRam
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIAGDelImagesFromRam	String	21	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mDIAGDelImagesFromRam[ETX]`
Method Return Value:	`[STX]sAN mDIAGDelImagesFromRam[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.33. Method: CancelImageDeletion

The following section contains a detailed description of the method CancelImageDeletion.

Method Overview

Method Name
CancelImageDeletion

Communication Name	mDIAGCancelDel
Sopas Index	126
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

```
sMN mDIAGCancelDel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIAGCancelDel	String	14	

Method Return Value:

```
sAN mDIAGCancelDel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIAGCancelDel	String	14	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mDIAGCancelDel[ETX]`
Method Return Value:	`[STX]sAN mDIAGCancelDel[ETX]`

© SICK AG - Germany - All rights reserved

2.37.10.34. Event: ImgBlobTransfer

The following section contains a detailed description of the event ImgBlobTransfer.

Event Overview

Event Name
ImgBlobTransfer

Sopas Index	416
Queue Length	1

Parameters		
Last		
	Bool	
	Value Range	False, True
	Initialisation	False
Index		
	UDInt	
	Value Range	0..4294967295
Data		
	FlexString	
	Length	0..8008

2.37.10.35. Event: ImageUploadStatus

The following section contains a detailed description of the event ImageUploadStatus.

Event Overview

Event Name
ImageUploadStatus

Sopas Index	417
Queue Length	1

© SICK AG - Germany - All rights reserved

Parameters			
Message			
	Enum8		
	Value	Name	Description
	0	UPLOAD_CANCELED	
	2	BUSY	
	3	IDLE	
	4	DIR_NOT_EXIST	
	5	NO_IMAGES	
	6	MEDIUM_NOT_READY	
	7	INTERNAL_ERROR	
	8	COMMUNICATION_ERROR	

2.37.10.36. Event: ImageDeleteStatus

The following section contains a detailed description of the event ImageDeleteStatus.

Event Overview

Event Name
ImageDeleteStatus

Sopas Index	418
Queue Length	1

Parameters			
Message			
	Enum8		
	Value	Name	Description
	0	BUSY	
	1	DIR_NOT_EXIST	
	2	MEDIUM_NOT_READY	
	3	INTERNAL_ERROR	
	4	ERASE_FINISHED	
	5	ERASE_CANCELED	

© SICK AG - Germany - All rights reserved

2.37.11. Group: ImageDiagnosis65x

2.37.11.1. Variable: ImgDiagStoreCondition2

The following section contains a detailed description of the variable ImgDiagStoreCondition2.

Variable Overview

Variable Name	Description
ImgDiagStoreCondition2	Condition when to store images

Communication Name	DIAGStoreCnd2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1296
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NONE	
	Value	Name	Description
	0	TX_NONE	
	1	TX_GOOD_READ	
	2	TX_NO_READ	
	3	TX_ALL	

Variable Telegram Syntax

Read Variable:

```
sRN DIAGStoreCnd2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGStoreCnd2	String	13	Condition when to store images

Read Variable Response:

```
sRA DIAGStoreCnd2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGStoreCnd2	String	13	Condition when to store images
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DIAGStoreCnd2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGStoreCnd2	String	13	Condition when to store images
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGStoreCnd2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGStoreCnd2	String	13	Condition when to store images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGStoreCnd2[ETX]
Read Variable Response:	[STX]sRA DIAGStoreCnd2 0[ETX]
Write Variable:	[STX]sWN DIAGStoreCnd2 0[ETX]
Write Variable Response:	[STX]sWA DIAGStoreCnd2[ETX]

2.37.11.2. Variable: ImgDiagStoreConditionExt2

The following section contains a detailed description of the variable ImgDiagStoreConditionExt2.

Variable Overview

Variable Name	Description
ImgDiagStoreConditionExt2	Extension of store condition

Communication Name	DIAGStoreCndExt2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1297
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGStoreCndExt2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGStoreCndExt2	String	16	Extension of store condition

Read Variable Response:				
`sRA DIAGStoreCndExt2 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGStoreCndExt2	String	16	Extension of store condition
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN DIAGStoreCndExt2 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGStoreCndExt2	String	16	Extension of store condition
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA DIAGStoreCndExt2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGStoreCndExt2	String	16	Extension of store condition

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGStoreCndExt2[ETX]`
Read Variable Response:	`[STX]sRA DIAGStoreCndExt2 0 0[ETX]`
Write Variable:	`[STX]sWN DIAGStoreCndExt2 0 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGStoreCndExt2[ETX]`

© SICK AG - Germany - All rights reserved

2.37.11.3. Variable: ImgDiagImageSelection2

The following section contains a detailed description of the variable ImgDiagImageSelection2.

Variable Overview

Variable Name	Description
ImgDiagImageSelection2	Determines which images to store, if the store condition is complied with.

Communication Name	DIAGImgSelection2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1298
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
	Value	Name	Description
	0	LastGoodRead_LastImage	
	1	FirstImage	
	2	ImageSequence	

Variable Telegram Syntax

Read Variable:				
`sRN DIAGImgSelection2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGImgSelection2	String	17	Determines which images to store, if the store condition is complied with.

Read Variable Response:				
`sRA DIAGImgSelection2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGImgSelection2	String	17	Determines which images to store, if the store condition is complied with.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DIAGImgSelection2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGImgSelection2	String	17	Determines which images to store, if the store condition is complied with.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGImgSelection2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGImgSelection2	String	17	Determines which images to store, if the store condition is complied with.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGImgSelection2[ETX]
Read Variable Response:	[STX]sRA DIAGImgSelection2 0[ETX]
Write Variable:	[STX]sWN DIAGImgSelection2 0[ETX]
Write Variable Response:	[STX]sWA DIAGImgSelection2[ETX]

2.37.11.4. Variable: ImgDiagJpegCompressionEnabled

The following section contains a detailed description of the variable ImgDiagJpegCompressionEnabled.

Variable Overview

Variable Name	Description
ImgDiagJpegCompressionEnabled	If enabled, images will be stored in jpeg format. Otherwise, uncompressed bitmaps will be stored.

Communication Name	DIAGJpgComprEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1299
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGJpgComprEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGJpgComprEna	String	15	If enabled, images will be stored in jpeg format. Otherwise, uncompressed bitmaps will be stored.

Read Variable Response:				
`sRA DIAGJpgComprEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGJpgComprEna	String	15	If enabled, images will be stored in jpeg format. Otherwise, uncompressed bitmaps will be stored.
Variable Data	data	Bool	1	

Write Variable:				
`sWN DIAGJpgComprEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGJpgComprEna	String	15	If enabled, images will be stored in jpeg format. Otherwise, uncompressed bitmaps will be stored.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DIAGJpgComprEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGJpgComprEna	String	15	If enabled, images will be stored in jpeg format. Otherwise, uncompressed bitmaps will be stored.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGJpgComprEna[ETX]`
Read Variable Response:	`[STX]sRA DIAGJpgComprEna 1[ETX]`
Write Variable:	`[STX]sWN DIAGJpgComprEna 1[ETX]`
Write Variable Response:	`[STX]sWA DIAGJpgComprEna[ETX]`

© SICK AG - Germany - All rights reserved

2.37.11.5. Variable: VisualDecoProfiling

The following section contains a detailed description of the variable VisualDecoProfiling.

Variable Overview

Variable Name	Description
VisualDecoProfiling	Visual the decoder profiling in the image output

Communication Name	DIAGDecoProf
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1300
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DIAGDecoProf
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGDecoProf	String	12	Visual the decoder profiling in the image output

Read Variable Response:

```
sRA DIAGDecoProf <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGDecoProf	String	12	Visual the decoder profiling in the image output
Variable Data	data	Bool	1	

Write Variable:

```
sWN DIAGDecoProf <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGDecoProf	String	12	Visual the decoder profiling in the image output
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DIAGDecoProf
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGDecoProf	String	12	Visual the decoder profiling in the image output

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGDecoProf[ETX]`
Read Variable Response:	`[STX]sRA DIAGDecoProf 0[ETX]`
Write Variable:	`[STX]sWN DIAGDecoProf 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGDecoProf[ETX]`

2.37.11.6. Variable: ImgDiagJpegCompressionQuality

The following section contains a detailed description of the variable ImgDiagJpegCompressionQuality.

Variable Overview

Variable Name	Description
ImgDiagJpegCompressionQuality	Quality level of jpeg in percent

Communication Name	DIAGJpgComprQual
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1301
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	25..90
Initialisation	80
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN DIAGJpgComprQual`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGJpgComprQual	String	16	Quality level of jpeg in percent

Read Variable Response:

`sRA DIAGJpgComprQual <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGJpgComprQual	String	16	Quality level of jpeg in percent
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DIAGJpgComprQual <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGJpgComprQual	String	16	Quality level of jpeg in percent
Variable Data	data	UInt	2	

Write Variable Response:				
sWA DIAGJpgComprQual				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGJpgComprQual	String	16	Quality level of jpeg in percent

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGJpgComprQual[ETX]
Read Variable Response:	[STX]sRA DIAGJpgComprQual 50[ETX]
Write Variable:	[STX]sWN DIAGJpgComprQual 50[ETX]
Write Variable Response:	[STX]sWA DIAGJpgComprQual[ETX]

2.37.11.7. Variable: ImgDiagImageOutReduction

The following section contains a detailed description of the variable ImgDiagImageOutReduction.

Variable Overview

Variable Name	Description
ImgDiagImageOutReduction	Selects image output reduction mode

Communication Name	DIAGImgReduction
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1302
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_MODULO	
	2	TX_MIN_MOVED_DIST	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGImgReduction`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGImgReduction	String	16	Selects image output reduction mode

Read Variable Response:				
`sRA DIAGImgReduction <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGImgReduction	String	16	Selects image output reduction mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DIAGImgReduction <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGImgReduction	String	16	Selects image output reduction mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DIAGImgReduction`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGImgReduction	String	16	Selects image output reduction mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGImgReduction[ETX]`
Read Variable Response:	`[STX]sRA DIAGImgReduction 0[ETX]`
Write Variable:	`[STX]sWN DIAGImgReduction 0[ETX]`
Write Variable Response:	`[STX]sWA DIAGImgReduction[ETX]`

© SICK AG - Germany - All rights reserved

2.37.11.8. Variable: ImgDiagMinConveyingPathMM

The following section contains a detailed description of the variable ImgDiagMinConveyingPathMM.

Variable Overview

Variable Name	Description
ImgDiagMinConveyingPathMM	Image output is suppressed until conveyor has moved at least this distance

Communication Name	DIAGMinConveyorPathMM
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1303
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	10..10000
Initialisation	200
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DIAGMinConveyorPathMM
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGMinConveyorPathMM	String	21	Image output is suppressed until conveyor has moved at least this distance

Read Variable Response:

```
sRA DIAGMinConveyorPathMM <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGMinConveyorPathMM	String	21	Image output is suppressed until conveyor has moved at least this distance
Variable Data	data	UDInt	4	

Write Variable:

```
sWN DIAGMinConveyorPathMM <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGMinConveyorPathMM	String	21	Image output is suppressed until conveyor has moved at least this distance
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIAGMinConveyorPathMM				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGMinConveyorPathMM	String	21	Image output is suppressed until conveyor has moved at least this distance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIAGMinConveyorPathMM[ETX]
Read Variable Response:	[STX]sRA DIAGMinConveyorPathMM C8[ETX]
Write Variable:	[STX]sWN DIAGMinConveyorPathMM C8[ETX]
Write Variable Response:	[STX]sWA DIAGMinConveyorPathMM[ETX]

2.37.11.9. Variable: ImgDiagContinuousModCnt

The following section contains a detailed description of the variable ImgDiagContinuousModCnt.

Variable Overview

Variable Name	Description
ImgDiagContinuousModCnt	Images are suppressed if the modulo condition does not match

Communication Name	DIAGContModCnt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1304
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..10000
Initialisation	10
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DIAGContModCnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGContModCnt	String	14	Images are suppressed if the modulo condition does not match

Read Variable Response:				
`sRA DIAGContModCnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGContModCnt	String	14	Images are suppressed if the modulo condition does not match
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DIAGContModCnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGContModCnt	String	14	Images are suppressed if the modulo condition does not match
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DIAGContModCnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGContModCnt	String	14	Images are suppressed if the modulo condition does not match

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGContModCnt[ETX]`
Read Variable Response:	`[STX]sRA DIAGContModCnt A[ETX]`
Write Variable:	`[STX]sWN DIAGContModCnt A[ETX]`
Write Variable Response:	`[STX]sWA DIAGContModCnt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.11.10. Variable: ImgDiagNameTemplateString

The following section contains a detailed description of the variable ImgDiagNameTemplateString.

Variable Overview

Variable Name	Description
ImgDiagNameTemplateString	Template string defintion for file name over FTP

Communication Name	DIAGtplstr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1305
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..1024
Initialisation	[$TSYR][$0002TSMO][$0002TSDA]_[$0002TSHO][$0002TSMI][$0002TSSE]_[$DEVN]_[$000aOI]_[$0004ON]

Variable Telegram Syntax

Read Variable:

```
sRN DIAGtplstr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIAGtplstr	String	10	Template string defintion for file name over FTP

Read Variable Response:

```
sRA DIAGtplstr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIAGtplstr	String	10	Template string defintion for file name over FTP
Variable Data	data	FlexString	1024	

Write Variable:

```
sWN DIAGtplstr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIAGtplstr	String	10	Template string defintion for file name over FTP
Variable Data	data	FlexString	1024	

Write Variable Response:

```
sWA DIAGtplstr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIAGtplstr	String	10	Template string defintion for file name over FTP

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DIAGtplstr[ETX]`
Read Variable Response:	`[STX]sRA DIAGtplstr 5B [$TSYR][$0002TSMO][$0002TSDA]_[$0002TSHO][$0002TSMI][$0002TSSE]_[$DEVN] _[$000aOI]_[$0004ON][ETX]`
Write Variable:	`[STX]sWN DIAGtplstr 5B [$TSYR][$0002TSMO][$0002TSDA]_[$0002TSHO][$0002TSMI][$0002TSSE]_[$DEVN] _[$000aOI]_[$0004ON][ETX]`
Write Variable Response:	`[STX]sWA DIAGtplstr[ETX]`

© SICK AG - Germany - All rights reserved

2.37.12. Group: LogfileDiagnosis

2.37.12.1. Variable: LogfCtrlSourceSerialHostActive

The following section contains a detailed description of the variable LogfCtrlSourceSerialHostActive.

Variable Overview

Variable Name	Description
LogfCtrlSourceSerialHostActive	If active, the output format data sent over this interface will also be written into a file.

Communication Name	LOGFDIAGSourceSerialHostActive
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1309
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGSourceSerialHostActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGSourceSerialHostActive	String	30	If active, the output format data sent over this interface will also be written into a file.

Read Variable Response:

```
sRA LOGFDIAGSourceSerialHostActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGSourceSerialHostActive	String	30	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable:

```
sWN LOGFDIAGSourceSerialHostActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGSourceSerialHostActive	String	30	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LOGFDIAGSourceSerialHostActive				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGSourceSerialHostActive	String	30	If active, the output format data sent over this interface will also be written into a file.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LOGFDIAGSourceSerialHostActive[ETX]
Read Variable Response:	[STX]sRA LOGFDIAGSourceSerialHostActive 0[ETX]
Write Variable:	[STX]sWN LOGFDIAGSourceSerialHostActive 0[ETX]
Write Variable Response:	[STX]sWA LOGFDIAGSourceSerialHostActive[ETX]

2.37.12.2. Variable: LogfCtrlSourceSerialAuxActive

The following section contains a detailed description of the variable LogfCtrlSourceSerialAuxActive.

Variable Overview

Variable Name	Description
LogfCtrlSourceSerialAuxActive	If active, the output format data sent over this interface will also be written into a file.

Communication Name	LOGFDIAGSourceSerialAuxActive
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1310
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN LOGFDIAGSourceSerialAuxActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGSourceSerialAuxActive	String	29	If active, the output format data sent over this interface will also be written into a file.

Read Variable Response:				
`sRA LOGFDIAGSourceSerialAuxActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGSourceSerialAuxActive	String	29	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable:				
`sWN LOGFDIAGSourceSerialAuxActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGSourceSerialAuxActive	String	29	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA LOGFDIAGSourceSerialAuxActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGSourceSerialAuxActive	String	29	If active, the output format data sent over this interface will also be written into a file.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGSourceSerialAuxActive[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGSourceSerialAuxActive 0[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGSourceSerialAuxActive 0[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGSourceSerialAuxActive[ETX]`

© SICK AG - Germany - All rights reserved

2.37.12.3. Variable: LogfCtrlSourceEthernetHostActive

The following section contains a detailed description of the variable LogfCtrlSourceEthernetHostActive.

Variable Overview

Variable Name	Description
LogfCtrlSourceEthernetHostActive	If active, the output format data sent over this interface will also be written into a file.

Communication Name	LOGFDIAGSourceEthernetHostActive
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1311
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGSourceEthernetHostActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGSourceEthernetHostActive	String	32	If active, the output format data sent over this interface will also be written into a file.

Read Variable Response:

```
sRA LOGFDIAGSourceEthernetHostActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGSourceEthernetHostActive	String	32	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable:

```
sWN LOGFDIAGSourceEthernetHostActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGSourceEthernetHostActive	String	32	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA LOGFDIAGSourceEthernetHostActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LOGFDIAGSourceEthernetHostActive				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	LOGFDIAGSourceEthernetHostActive	String	32	If active, the output format data sent over this interface will also be written into a file.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LOGFDIAGSourceEthernetHostActive[ETX]
Read Variable Response:	[STX]sRA LOGFDIAGSourceEthernetHostActive 0[ETX]
Write Variable:	[STX]sWN LOGFDIAGSourceEthernetHostActive 0[ETX]
Write Variable Response:	[STX]sWA LOGFDIAGSourceEthernetHostActive[ETX]

2.37.12.4. Variable: LogfCtrlSourceEthernetAuxActive

The following section contains a detailed description of the variable LogfCtrlSourceEthernetAuxActive.

Variable Overview

Variable Name	Description
LogfCtrlSourceEthernetAuxActive	If active, the output format data sent over this interface will also be written into a file.

Communication Name	LOGFDIAGSourceEthernetAuxActive
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1312
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN LOGFDIAGSourceEthernetAuxActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGSourceEthernetAuxActive	String	31	If active, the output format data sent over this interface will also be written into a file.

Read Variable Response:				
`sRA LOGFDIAGSourceEthernetAuxActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGSourceEthernetAuxActive	String	31	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable:				
`sWN LOGFDIAGSourceEthernetAuxActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGSourceEthernetAuxActive	String	31	If active, the output format data sent over this interface will also be written into a file.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA LOGFDIAGSourceEthernetAuxActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGSourceEthernetAuxActive	String	31	If active, the output format data sent over this interface will also be written into a file.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGSourceEthernetAuxActive[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGSourceEthernetAuxActive 0[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGSourceEthernetAuxActive 0[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGSourceEthernetAuxActive[ETX]`

© SICK AG - Germany - All rights reserved

2.37.12.5. Variable: LogfCtrlRamMaxStorageSpaceMB

The following section contains a detailed description of the variable LogfCtrlRamMaxStorageSpaceMB.

Variable Overview

Variable Name	Description
LogfCtrlRamMaxStorageSpaceMB	Maximum storage space for logfile on internal memory (non-persistent) in megabytes.

Communication Name	LOGFDIAGRamMaxStorageSpaceMB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1314
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..10
Initialisation	5
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGRamMaxStorageSpaceMB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGRamMaxStorageSpaceMB	String	28	Maximum storage space for logfile on internal memory (non-persistent) in megabytes.

Read Variable Response:

```
sRA LOGFDIAGRamMaxStorageSpaceMB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGRamMaxStorageSpaceMB	String	28	Maximum storage space for logfile on internal memory (non-persistent) in megabytes.
Variable Data	data	UDInt	4	

Write Variable:

```
sWN LOGFDIAGRamMaxStorageSpaceMB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGRamMaxStorageSpaceMB	String	28	Maximum storage space for logfile on internal memory (non-persistent) in megabytes.
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LOGFDIAGRamMaxStorageSpaceMB				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGRamMaxStorageSpaceMB	String	28	Maximum storage space for logfile on internal memory (non-persistent) in megabytes.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LOGFDIAGRamMaxStorageSpaceMB[ETX]
Read Variable Response:	[STX]sRA LOGFDIAGRamMaxStorageSpaceMB 5[ETX]
Write Variable:	[STX]sWN LOGFDIAGRamMaxStorageSpaceMB 5[ETX]
Write Variable Response:	[STX]sWA LOGFDIAGRamMaxStorageSpaceMB[ETX]

2.37.12.6. Variable: LogfCtrlDestinationSDCardActive

The following section contains a detailed description of the variable LogfCtrlDestinationSDCardActive.

Variable Overview

Variable Name	Description
LogfCtrlDestinationSDCardActive	Logfiles are stored on the SD card.

Communication Name	LOGFDIAGDestinationSDCardActive
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1315
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN LOGFDIAGDestinationSDCardActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGDestinationSDCardActive	String	31	Logfiles are stored on the SD card.

Read Variable Response:				
`sRA LOGFDIAGDestinationSDCardActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGDestinationSDCardActive	String	31	Logfiles are stored on the SD card.
Variable Data	data	Bool	1	

Write Variable:				
`sWN LOGFDIAGDestinationSDCardActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGDestinationSDCardActive	String	31	Logfiles are stored on the SD card.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA LOGFDIAGDestinationSDCardActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGDestinationSDCardActive	String	31	Logfiles are stored on the SD card.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGDestinationSDCardActive[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGDestinationSDCardActive 0[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGDestinationSDCardActive 0[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGDestinationSDCardActive[ETX]`

© SICK AG - Germany - All rights reserved

2.37.12.7. Variable: LogfCtrlSDCardMaxStorageSpaceMB

The following section contains a detailed description of the variable LogfCtrlSDCardMaxStorageSpaceMB.

Variable Overview

Variable Name	Description
LogfCtrlSDCardMaxStorageSpaceMB	Maximum storage space for logfile on SD card in megabytes.

Communication Name	LOGFDIAGSDCardMaxStorageSpaceMB
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1316
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	1..10
Initialisation	5
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGSDCardMaxStorageSpaceMB
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGSDCardMaxStorageSpaceMB	String	31	Maximum storage space for logfile on SD card in megabytes.

Read Variable Response:

```
sRA LOGFDIAGSDCardMaxStorageSpaceMB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGSDCardMaxStorageSpaceMB	String	31	Maximum storage space for logfile on SD card in megabytes.
Variable Data	data	UDInt	4	

Write Variable:

```
sWN LOGFDIAGSDCardMaxStorageSpaceMB <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGSDCardMaxStorageSpaceMB	String	31	Maximum storage space for logfile on SD card in megabytes.
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LOGFDIAGSDCardMaxStorageSpaceMB				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGSDCardMaxStorageSpaceMB	String	31	Maximum storage space for logfile on SD card in megabytes.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LOGFDIAGSDCardMaxStorageSpaceMB[ETX]
Read Variable Response:	[STX]sRA LOGFDIAGSDCardMaxStorageSpaceMB 5[ETX]
Write Variable:	[STX]sWN LOGFDIAGSDCardMaxStorageSpaceMB 5[ETX]
Write Variable Response:	[STX]sWA LOGFDIAGSDCardMaxStorageSpaceMB[ETX]

2.37.12.8. Variable: LogfCtrlDiagPathDevice

The following section contains a detailed description of the variable LogfCtrlDiagPathDevice.

Variable Overview

Variable Name	Description
LogfCtrlDiagPathDevice	Eiter the serial number of the device or a user defined device name has to be included in the logfile storage path.

Communication Name	LOGFDIAGPathDevice
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1317
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	SerialNumber	
	1	DeviceName	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN LOGFDIAGPathDevice`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGPathDevice	String	18	Eiter the serial number of the device or a user defined device name has to be included in the logfile storage path.

Read Variable Response:				
`sRA LOGFDIAGPathDevice <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGPathDevice	String	18	Eiter the serial number of the device or a user defined device name has to be included in the logfile storage path.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN LOGFDIAGPathDevice <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGPathDevice	String	18	Eiter the serial number of the device or a user defined device name has to be included in the logfile storage path.
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA LOGFDIAGPathDevice`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGPathDevice	String	18	Eiter the serial number of the device or a user defined device name has to be included in the logfile storage path.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGPathDevice[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGPathDevice 0[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGPathDevice 0[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGPathDevice[ETX]`

© SICK AG - Germany - All rights reserved

2.37.12.9. Variable: LogfCtrlDiagPathDeviceName

The following section contains a detailed description of the variable LogfCtrlDiagPathDeviceName.

Variable Overview

Variable Name	Description
LogfCtrlDiagPathDeviceName	User defined device name for the logfile store path.

Communication Name	LOGFDIAGDeviceName
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1318
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..62
Initialisation	LECTOR6xx

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGDeviceName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGDeviceName	String	18	User defined device name for the logfile store path.

Read Variable Response:

```
sRA LOGFDIAGDeviceName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGDeviceName	String	18	User defined device name for the logfile store path.
Variable Data	data	FlexString	62	

Write Variable:

```
sWN LOGFDIAGDeviceName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGDeviceName	String	18	User defined device name for the logfile store path.
Variable Data	data	FlexString	62	

Write Variable Response:

```
sWA LOGFDIAGDeviceName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGDeviceName	String	18	User defined device name for the logfile store path.

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGDeviceName[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGDeviceName 9 LECTOR6xx[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGDeviceName 9 LECTOR6xx[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGDeviceName[ETX]`

2.37.12.10. Variable: LogfCtrlDiagPathDate

The following section contains a detailed description of the variable LogfCtrlDiagPathDate.

Variable Overview

Variable Name	Description
LogfCtrlDiagPathDate	Use the current date as subfolder for logfile storage.

Communication Name	LOGFDIAGDate
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1319
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGDate
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGDate	String	12	Use the current date as subfolder for logfile storage.

Read Variable Response:

```
sRA LOGFDIAGDate <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGDate	String	12	Use the current date as subfolder for logfile storage.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN LOGFDIAGDate <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGDate	String	12	Use the current date as subfolder for logfile storage.
Variable Data	data	Bool	1	

Write Variable Response:				
sWA LOGFDIAGDate				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGDate	String	12	Use the current date as subfolder for logfile storage.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LOGFDIAGDate[ETX]
Read Variable Response:	[STX]sRA LOGFDIAGDate 0[ETX]
Write Variable:	[STX]sWN LOGFDIAGDate 0[ETX]
Write Variable Response:	[STX]sWA LOGFDIAGDate[ETX]

2.37.12.11. Variable: LogfCtrlDiagPathHour

The following section contains a detailed description of the variable LogfCtrlDiagPathHour.

Variable Overview

Variable Name	Description
LogfCtrlDiagPathHour	Use the current hour as subfolder for logfile storage.

Communication Name	LOGFDIAGHour
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1320
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN LOGFDIAGHour`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGHour	String	12	Use the current hour as subfolder for logfile storage.

Read Variable Response:				
`sRA LOGFDIAGHour <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGHour	String	12	Use the current hour as subfolder for logfile storage.
Variable Data	data	Bool	1	

Write Variable:				
`sWN LOGFDIAGHour <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGHour	String	12	Use the current hour as subfolder for logfile storage.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA LOGFDIAGHour`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGHour	String	12	Use the current hour as subfolder for logfile storage.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGHour[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGHour 0[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGHour 0[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGHour[ETX]`

© SICK AG - Germany - All rights reserved

2.37.12.12. Variable: LogfCtrlDiagFileName

The following section contains a detailed description of the variable LogfCtrlDiagFileName.

Variable Overview

Variable Name	Description
LogfCtrlDiagFileName	Name for all logfiles that are stored

Communication Name	LOGFDIAGLogFileName
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1321
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	log

Variable Telegram Syntax

Read Variable:

```
sRN LOGFDIAGLogFileName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGLogFileName	String	19	Name for all logfiles that are stored

Read Variable Response:

```
sRA LOGFDIAGLogFileName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGLogFileName	String	19	Name for all logfiles that are stored
Variable Data	data	FlexString	32	

Write Variable:

```
sWN LOGFDIAGLogFileName <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGLogFileName	String	19	Name for all logfiles that are stored
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA LOGFDIAGLogFileName
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGLogFileName	String	19	Name for all logfiles that are stored

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGLogFileName[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGLogFileName 3 log[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGLogFileName 3 log[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGLogFileName[ETX]`

2.37.12.13. Variable: LogfCtrlDiagFormatTimestamp

The following section contains a detailed description of the variable LogfCtrlDiagFormatTimestamp.

Variable Overview

Variable Name	Description
LogfCtrlDiagFormatTimestamp	Print timestamp at beginning of each logged line.

Communication Name	LOGFDIAGFrmtTmStamp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1322
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN LOGFDIAGFrmtTmStamp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LOGFDIAGFrmtTmStamp	String	19	Print timestamp at beginning of each logged line.

Read Variable Response:				
`sRA LOGFDIAGFrmtTmStamp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LOGFDIAGFrmtTmStamp	String	19	Print timestamp at beginning of each logged line.
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN LOGFDIAGFrmtTmStamp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LOGFDIAGFrmtTmStamp	String	19	Print timestamp at beginning of each logged line.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA LOGFDIAGFrmtTmStamp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LOGFDIAGFrmtTmStamp	String	19	Print timestamp at beginning of each logged line.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LOGFDIAGFrmtTmStamp[ETX]`
Read Variable Response:	`[STX]sRA LOGFDIAGFrmtTmStamp 1[ETX]`
Write Variable:	`[STX]sWN LOGFDIAGFrmtTmStamp 1[ETX]`
Write Variable Response:	`[STX]sWA LOGFDIAGFrmtTmStamp[ETX]`

2.37.12.14. Method: LogfCtrlStartLogging

The following section contains a detailed description of the method LogfCtrlStartLogging.

Method Overview

Method Name
LogfCtrlStartLogging

Communication Name	mLOGFDIAGStartLogging
Sopas Index	127
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mLOGFDIAGStartLogging				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mLOGFDIAGStartLogging	String	21	

Method Return Value:				
sAN mLOGFDIAGStartLogging				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mLOGFDIAGStartLogging	String	21	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mLOGFDIAGStartLogging[ETX]
Method Return Value:	[STX]sAN mLOGFDIAGStartLogging[ETX]

2.37.12.15. Method: LogfCtrlStopLogging

The following section contains a detailed description of the method LogfCtrlStopLogging.

Method Overview

Method Name
LogfCtrlStopLogging

Communication Name	mLOGFDIAGStopLogging
Sopas Index	128
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mLOGFDIAGStopLogging`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mLOGFDIAGStopLogging	String	20	

Method Return Value:				
`sAN mLOGFDIAGStopLogging`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mLOGFDIAGStopLogging	String	20	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mLOGFDIAGStopLogging[ETX]`
Method Return Value:	`[STX]sAN mLOGFDIAGStopLogging[ETX]`

© SICK AG - Germany - All rights reserved

2.37.13. Group: Position

2.37.13.1. Variable: ScannerPosBeta

The following section contains a detailed description of the variable ScannerPosBeta.

Variable Overview

Variable Name	Description
ScannerPosBeta	Angle Beta of scanner position

Communication Name	PObeta
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1324
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..360
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN PObeta
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PObeta	String	6	Angle Beta of scanner position

Read Variable Response:

```
sRA PObeta <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PObeta	String	6	Angle Beta of scanner position
Variable Data	data	DInt	4	

Write Variable:

```
sWN PObeta <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PObeta	String	6	Angle Beta of scanner position
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PObeta				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PObeta	String	6	Angle Beta of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PObeta[ETX]
Read Variable Response:	[STX]sRA PObeta 0[ETX]
Write Variable:	[STX]sWN PObeta 0[ETX]
Write Variable Response:	[STX]sWA PObeta[ETX]

2.37.13.2. Variable: ScannerPosGamma

The following section contains a detailed description of the variable ScannerPosGamma.

Variable Overview

Variable Name	Description
ScannerPosGamma	Angle Gamma of scanner position

Communication Name	POgamma
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1325
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..360
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN POgamma`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POgamma	String	7	Angle Gamma of scanner position

Read Variable Response:				
`sRA POgamma <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POgamma	String	7	Angle Gamma of scanner position
Variable Data	data	DInt	4	

Write Variable:				
`sWN POgamma <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POgamma	String	7	Angle Gamma of scanner position
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA POgamma`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POgamma	String	7	Angle Gamma of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POgamma[ETX]`
Read Variable Response:	`[STX]sRA POgamma 0[ETX]`
Write Variable:	`[STX]sWN POgamma 0[ETX]`
Write Variable Response:	`[STX]sWA POgamma[ETX]`

© SICK AG - Germany - All rights reserved

2.37.13.3. Variable: ScannerPosXCoord

The following section contains a detailed description of the variable ScannerPosXCoord.

Variable Overview

Variable Name	Description
ScannerPosXCoord	X-coordinate of scanner position

Communication Name	POcoordX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1326
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-10000..10000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN POcoordX
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POcoordX	String	8	X-coordinate of scanner position

Read Variable Response:

```
sRA POcoordX <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POcoordX	String	8	X-coordinate of scanner position
Variable Data	data	DInt	4	

Write Variable:

```
sWN POcoordX <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POcoordX	String	8	X-coordinate of scanner position
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA POcoordX
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POcoordX	String	8	X-coordinate of scanner position

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POcoordX[ETX]`
Read Variable Response:	`[STX]sRA POcoordX 0[ETX]`
Write Variable:	`[STX]sWN POcoordX 0[ETX]`
Write Variable Response:	`[STX]sWA POcoordX[ETX]`

2.37.13.4. Variable: ScannerPosYCoord

The following section contains a detailed description of the variable ScannerPosYCoord.

Variable Overview

Variable Name	Description
ScannerPosYCoord	Y-coordinate of scanner position

Communication Name	POcoordY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1327
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN POcoordY`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POcoordY	String	8	Y-coordinate of scanner position

Read Variable Response:

`sRA POcoordY <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POcoordY	String	8	Y-coordinate of scanner position
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN POcoordY <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POcoordY	String	8	Y-coordinate of scanner position
Variable Data	data	DInt	4	

Write Variable Response:				
sWA POcoordY				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POcoordY	String	8	Y-coordinate of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN POcoordY[ETX]
Read Variable Response:	[STX]sRA POcoordY 0[ETX]
Write Variable:	[STX]sWN POcoordY 0[ETX]
Write Variable Response:	[STX]sWA POcoordY[ETX]

2.37.13.5. Variable: ScannerHRPosBeta

The following section contains a detailed description of the variable ScannerHRPosBeta.

Variable Overview

Variable Name	Description
ScannerHRPosBeta	High Resolution Angle Beta of scanner position

Communication Name	POHRbeta
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1330
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN POHRbeta`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POHRbeta	String	8	High Resolution Angle Beta of scanner position

Read Variable Response:				
`sRA POHRbeta <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POHRbeta	String	8	High Resolution Angle Beta of scanner position
Variable Data	data	Real	4	

Write Variable:				
`sWN POHRbeta <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POHRbeta	String	8	High Resolution Angle Beta of scanner position
Variable Data	data	Real	4	

Write Variable Response:				
`sWA POHRbeta`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POHRbeta	String	8	High Resolution Angle Beta of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POHRbeta[ETX]`
Read Variable Response:	`[STX]sRA POHRbeta 00000000[ETX]`
Write Variable:	`[STX]sWN POHRbeta 00000000[ETX]`
Write Variable Response:	`[STX]sWA POHRbeta[ETX]`

© SICK AG - Germany - All rights reserved

2.37.13.6. Variable: ScannerHRPosGamma

The following section contains a detailed description of the variable ScannerHRPosGamma.

Variable Overview

Variable Name	Description
ScannerHRPosGamma	High Resolution Angle Gamma of scanner position

Communication Name	POHRgamma
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1331
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN POHRgamma
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POHRgamma	String	9	High Resolution Angle Gamma of scanner position

Read Variable Response:

```
sRA POHRgamma <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POHRgamma	String	9	High Resolution Angle Gamma of scanner position
Variable Data	data	Real	4	

Write Variable:

```
sWN POHRgamma <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POHRgamma	String	9	High Resolution Angle Gamma of scanner position
Variable Data	data	Real	4	

Write Variable Response:

```
sWA POHRgamma
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POHRgamma	String	9	High Resolution Angle Gamma of scanner position

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POHRgamma[ETX]`
Read Variable Response:	`[STX]sRA POHRgamma 00000000[ETX]`
Write Variable:	`[STX]sWN POHRgamma 00000000[ETX]`
Write Variable Response:	`[STX]sWA POHRgamma[ETX]`

2.37.13.7. Variable: ScannerHRPosXCoord

The following section contains a detailed description of the variable ScannerHRPosXCoord.

Variable Overview

Variable Name	Description
ScannerHRPosXCoord	High Resolution X-coordinate of scanner position

Communication Name	POHRcoordX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1332
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -1000.0..10000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN POHRcoordX`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POHRcoordX	String	10	High Resolution X-coordinate of scanner position

Read Variable Response:

`sRA POHRcoordX <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POHRcoordX	String	10	High Resolution X-coordinate of scanner position
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN POHRcoordX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POHRcoordX	String	10	High Resolution X-coordinate of scanner position
Variable Data	data	Real	4	

Write Variable Response:				
`sWA POHRcoordX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POHRcoordX	String	10	High Resolution X-coordinate of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POHRcoordX[ETX]`
Read Variable Response:	`[STX]sRA POHRcoordX 00000000[ETX]`
Write Variable:	`[STX]sWN POHRcoordX 00000000[ETX]`
Write Variable Response:	`[STX]sWA POHRcoordX[ETX]`

2.37.13.8. Variable: ScannerHRPosYCoord

The following section contains a detailed description of the variable ScannerHRPosYCoord.

Variable Overview

Variable Name	Description
ScannerHRPosYCoord	High Resolution Y-coordinate of scanner position

Communication Name	POHRcoordY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1333
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3000.0..3000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN POHRcoordY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POHRcoordY	String	10	High Resolution Y-coordinate of scanner position

Read Variable Response:				
`sRA POHRcoordY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POHRcoordY	String	10	High Resolution Y-coordinate of scanner position
Variable Data	data	Real	4	

Write Variable:				
`sWN POHRcoordY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POHRcoordY	String	10	High Resolution Y-coordinate of scanner position
Variable Data	data	Real	4	

Write Variable Response:				
`sWA POHRcoordY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POHRcoordY	String	10	High Resolution Y-coordinate of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POHRcoordY[ETX]`
Read Variable Response:	`[STX]sRA POHRcoordY 00000000[ETX]`
Write Variable:	`[STX]sWN POHRcoordY 00000000[ETX]`
Write Variable Response:	`[STX]sWA POHRcoordY[ETX]`

© SICK AG - Germany - All rights reserved

2.37.13.9. Variable: PositionDeshadingActive

The following section contains a detailed description of the variable PositionDeshadingActive.

Variable Overview

Variable Name	Description
PositionDeshadingActive	Activates the position depending deshading

Communication Name	EnaPosDependingDeshading
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1335
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EnaPosDependingDeshading
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EnaPosDependingDeshading	String	24	Activates the position depending deshading

Read Variable Response:

```
sRA EnaPosDependingDeshading <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EnaPosDependingDeshading	String	24	Activates the position depending deshading
Variable Data	data	Bool	1	

Write Variable:

```
sWN EnaPosDependingDeshading <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EnaPosDependingDeshading	String	24	Activates the position depending deshading
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EnaPosDependingDeshading
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EnaPosDependingDeshading	String	24	Activates the position depending deshading

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EnaPosDependingDeshading[ETX]`
Read Variable Response:	`[STX]sRA EnaPosDependingDeshading 0[ETX]`
Write Variable:	`[STX]sWN EnaPosDependingDeshading 0[ETX]`
Write Variable Response:	`[STX]sWA EnaPosDependingDeshading[ETX]`

2.37.13.10. Variable: PositionXOffset

The following section contains a detailed description of the variable PositionXOffset.

Variable Overview

Variable Name	Description
PositionXOffset	X-position offset

Communication Name	POoffsX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1336
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN POoffsX
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POoffsX	String	7	X-position offset

Read Variable Response:

```
sRA POoffsX <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POoffsX	String	7	X-position offset
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN POoffsX <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POoffsX	String	7	X-position offset
Variable Data	data	DInt	4	

Write Variable Response:				
sWA POoffsX				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POoffsX	String	7	X-position offset

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN POoffsX[ETX]
Read Variable Response:	[STX]sRA POoffsX 0[ETX]
Write Variable:	[STX]sWN POoffsX 0[ETX]
Write Variable Response:	[STX]sWA POoffsX[ETX]

2.37.13.11. Variable: PositionYOffset

The following section contains a detailed description of the variable PositionYOffset.

Variable Overview

Variable Name	Description
PositionYOffset	Z-position offset

Communication Name	POoffsY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1337
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2000..2000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN POoffsY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POoffsY	String	7	Z-position offset

Read Variable Response:				
`sRA POoffsY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POoffsY	String	7	Z-position offset
Variable Data	data	DInt	4	

Write Variable:				
`sWN POoffsY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POoffsY	String	7	Z-position offset
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA POoffsY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POoffsY	String	7	Z-position offset

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POoffsY[ETX]`
Read Variable Response:	`[STX]sRA POoffsY 0[ETX]`
Write Variable:	`[STX]sWN POoffsY 0[ETX]`
Write Variable Response:	`[STX]sWA POoffsY[ETX]`

© SICK AG - Germany - All rights reserved

2.37.13.12. Variable: PositionZOffset

The following section contains a detailed description of the variable PositionZOffset.

Variable Overview

Variable Name	Description
PositionZOffset	Z-position offset

Communication Name	POoffsZ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1338
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2000..2000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN POoffsZ
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POoffsZ	String	7	Z-position offset

Read Variable Response:

```
sRA POoffsZ <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POoffsZ	String	7	Z-position offset
Variable Data	data	DInt	4	

Write Variable:

```
sWN POoffsZ <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POoffsZ	String	7	Z-position offset
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA POoffsZ
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POoffsZ	String	7	Z-position offset

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POoffsZ[ETX]`
Read Variable Response:	`[STX]sRA POoffsZ 0[ETX]`
Write Variable:	`[STX]sWN POoffsZ 0[ETX]`
Write Variable Response:	`[STX]sWA POoffsZ[ETX]`

2.37.13.13. Variable: ScannerHRPosZCoord

The following section contains a detailed description of the variable ScannerHRPosZCoord.

Variable Overview

Variable Name	Description
ScannerHRPosZCoord	High Resolution Z-coordinate of scanner position

Communication Name	POHRcoordZ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1334
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3500.0..3500.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN POHRcoordZ`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POHRcoordZ	String	10	High Resolution Z-coordinate of scanner position

Read Variable Response:

`sRA POHRcoordZ <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POHRcoordZ	String	10	High Resolution Z-coordinate of scanner position
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN POHRcoordZ <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POHRcoordZ	String	10	High Resolution Z-coordinate of scanner position
Variable Data	data	Real	4	

Write Variable Response:				
sWA POHRcoordZ				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POHRcoordZ	String	10	High Resolution Z-coordinate of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN POHRcoordZ[ETX]
Read Variable Response:	[STX]sRA POHRcoordZ 00000000[ETX]
Write Variable:	[STX]sWN POHRcoordZ 00000000[ETX]
Write Variable Response:	[STX]sWA POHRcoordZ[ETX]

2.37.13.14. Variable: ScannerPosZCoord

The following section contains a detailed description of the variable ScannerPosZCoord.

Variable Overview

Variable Name	Description
ScannerPosZCoord	Z-coordinate of scanner position

Communication Name	POcoordZ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1328
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3500..3500
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN POcoordZ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POcoordZ	String	8	Z-coordinate of scanner position

Read Variable Response:				
`sRA POcoordZ <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POcoordZ	String	8	Z-coordinate of scanner position
Variable Data	data	DInt	4	

Write Variable:				
`sWN POcoordZ <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POcoordZ	String	8	Z-coordinate of scanner position
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA POcoordZ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POcoordZ	String	8	Z-coordinate of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POcoordZ[ETX]`
Read Variable Response:	`[STX]sRA POcoordZ 0[ETX]`
Write Variable:	`[STX]sWN POcoordZ 0[ETX]`
Write Variable Response:	`[STX]sWA POcoordZ[ETX]`

© SICK AG - Germany - All rights reserved

2.37.13.15. Variable: ScannerHRPosAlpha

The following section contains a detailed description of the variable ScannerHRPosAlpha.

Variable Overview

Variable Name	Description
ScannerHRPosAlpha	High Resolution Angle Alpha of scanner position

Communication Name	POHRalpha
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1329
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN POHRalpha
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POHRalpha	String	9	High Resolution Angle Alpha of scanner position

Read Variable Response:

```
sRA POHRalpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POHRalpha	String	9	High Resolution Angle Alpha of scanner position
Variable Data	data	Real	4	

Write Variable:

```
sWN POHRalpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POHRalpha	String	9	High Resolution Angle Alpha of scanner position
Variable Data	data	Real	4	

Write Variable Response:

```
sWA POHRalpha
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POHRalpha	String	9	High Resolution Angle Alpha of scanner position

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POHRalpha[ETX]`
Read Variable Response:	`[STX]sRA POHRalpha 00000000[ETX]`
Write Variable:	`[STX]sWN POHRalpha 00000000[ETX]`
Write Variable Response:	`[STX]sWA POHRalpha[ETX]`

2.37.13.16. Variable: ScannerPosAlpha

The following section contains a detailed description of the variable ScannerPosAlpha.

Variable Overview

Variable Name	Description
ScannerPosAlpha	Angle Alpha of scanner position

Communication Name	POalpha
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1323
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..360
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN POalpha`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	POalpha	String	7	Angle Alpha of scanner position

Read Variable Response:				
`sRA POalpha <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	POalpha	String	7	Angle Alpha of scanner position
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN POalpha <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	POalpha	String	7	Angle Alpha of scanner position
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA POalpha`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	POalpha	String	7	Angle Alpha of scanner position

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN POalpha[ETX]`
Read Variable Response:	`[STX]sRA POalpha 0[ETX]`
Write Variable:	`[STX]sWN POalpha 0[ETX]`
Write Variable Response:	`[STX]sWA POalpha[ETX]`

© SICK AG - Germany - All rights reserved

2.37.14. Group: ExpanderPositionLector65x

2.37.14.1. Variable: ExpanderScannerPosAlpha

The following section contains a detailed description of the variable ExpanderScannerPosAlpha.

Variable Overview

Variable Name	Description
ExpanderScannerPosAlpha	Additional Alpha Angle of scanner position for expander

Communication Name	ExpPosAlpha
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1340
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..360
Initialisation	90
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ExpPosAlpha
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpPosAlpha	String	11	Additional Alpha Angle of scanner position for expander

Read Variable Response:

```
sRA ExpPosAlpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpPosAlpha	String	11	Additional Alpha Angle of scanner position for expander
Variable Data	data	DInt	4	

Write Variable:

```
sWN ExpPosAlpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpPosAlpha	String	11	Additional Alpha Angle of scanner position for expander
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExpPosAlpha				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpPosAlpha	String	11	Additional Alpha Angle of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpPosAlpha[ETX]
Read Variable Response:	[STX]sRA ExpPosAlpha 5A[ETX]
Write Variable:	[STX]sWN ExpPosAlpha 5A[ETX]
Write Variable Response:	[STX]sWA ExpPosAlpha[ETX]

2.37.14.2. Variable: ExpanderScannerPosBeta

The following section contains a detailed description of the variable ExpanderScannerPosBeta.

Variable Overview

Variable Name	Description
ExpanderScannerPosBeta	Additional Beta Angle of scanner position for expander

Communication Name	ExpPosBeta
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1341
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..360
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ExpPosBeta`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpPosBeta	String	10	Additional Beta Angle of scanner position for expander

Read Variable Response:				
`sRA ExpPosBeta <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpPosBeta	String	10	Additional Beta Angle of scanner position for expander
Variable Data	data	DInt	4	

Write Variable:				
`sWN ExpPosBeta <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpPosBeta	String	10	Additional Beta Angle of scanner position for expander
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA ExpPosBeta`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpPosBeta	String	10	Additional Beta Angle of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExpPosBeta[ETX]`
Read Variable Response:	`[STX]sRA ExpPosBeta 0[ETX]`
Write Variable:	`[STX]sWN ExpPosBeta 0[ETX]`
Write Variable Response:	`[STX]sWA ExpPosBeta[ETX]`

© SICK AG - Germany - All rights reserved

2.37.14.3. Variable: ExpanderScannerPosGamma

The following section contains a detailed description of the variable ExpanderScannerPosGamma.

Variable Overview

Variable Name	Description
ExpanderScannerPosGamma	Additional Gamma Angle of scanner position for expander

Communication Name	ExpPosGamma
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1342
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	0..360
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN ExpPosGamma`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpPosGamma	String	11	Additional Gamma Angle of scanner position for expander

Read Variable Response:				
`sRA ExpPosGamma <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpPosGamma	String	11	Additional Gamma Angle of scanner position for expander
Variable Data	data	DInt	4	

Write Variable:				
`sWN ExpPosGamma <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpPosGamma	String	11	Additional Gamma Angle of scanner position for expander
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExpPosGamma				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpPosGamma	String	11	Additional Gamma Angle of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpPosGamma[ETX]
Read Variable Response:	[STX]sRA ExpPosGamma 0[ETX]
Write Variable:	[STX]sWN ExpPosGamma 0[ETX]
Write Variable Response:	[STX]sWA ExpPosGamma[ETX]

2.37.14.4. Variable: ExpanderScannerPosXCoord

The following section contains a detailed description of the variable ExpanderScannerPosXCoord.

Variable Overview

Variable Name	Description
ExpanderScannerPosXCoord	Additional X-coordinate of scanner position for expander

Communication Name	ExpPosCoordX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1343
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-10000..10000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ExpPosCoordX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpPosCoordX	String	12	Additional X-coordinate of scanner position for expander

Read Variable Response:				
`sRA ExpPosCoordX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpPosCoordX	String	12	Additional X-coordinate of scanner position for expander
Variable Data	data	DInt	4	

Write Variable:				
`sWN ExpPosCoordX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpPosCoordX	String	12	Additional X-coordinate of scanner position for expander
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA ExpPosCoordX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpPosCoordX	String	12	Additional X-coordinate of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExpPosCoordX[ETX]`
Read Variable Response:	`[STX]sRA ExpPosCoordX 0[ETX]`
Write Variable:	`[STX]sWN ExpPosCoordX 0[ETX]`
Write Variable Response:	`[STX]sWA ExpPosCoordX[ETX]`

© SICK AG - Germany - All rights reserved

2.37.14.5. Variable: ExpanderScannerPosYCoord

The following section contains a detailed description of the variable ExpanderScannerPosYCoord.

Variable Overview

Variable Name	Description
ExpanderScannerPosYCoord	Additional Y-coordinate of scanner position for expander

Communication Name	ExpPosCoordY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1344
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ExpPosCoordY
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpPosCoordY	String	12	Additional Y-coordinate of scanner position for expander

Read Variable Response:

```
sRA ExpPosCoordY <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpPosCoordY	String	12	Additional Y-coordinate of scanner position for expander
Variable Data	data	DInt	4	

Write Variable:

```
sWN ExpPosCoordY <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpPosCoordY	String	12	Additional Y-coordinate of scanner position for expander
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExpPosCoordY				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpPosCoordY	String	12	Additional Y-coordinate of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpPosCoordY[ETX]
Read Variable Response:	[STX]sRA ExpPosCoordY 0[ETX]
Write Variable:	[STX]sWN ExpPosCoordY 0[ETX]
Write Variable Response:	[STX]sWA ExpPosCoordY[ETX]

2.37.14.6. Variable: ExpanderScannerPosZCoord

The following section contains a detailed description of the variable ExpanderScannerPosZCoord.

Variable Overview

Variable Name	Description
ExpanderScannerPosZCoord	Additional Z-coordinate of scanner position for expander

Communication Name	ExpPosCoordZ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1345
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3500..3500
Initialisation	165
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN ExpPosCoordZ				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpPosCoordZ	String	12	Additional Z-coordinate of scanner position for expander

Read Variable Response:				
sRA ExpPosCoordZ <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpPosCoordZ	String	12	Additional Z-coordinate of scanner position for expander
Variable Data	data	DInt	4	

Write Variable:				
sWN ExpPosCoordZ <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpPosCoordZ	String	12	Additional Z-coordinate of scanner position for expander
Variable Data	data	DInt	4	

Write Variable Response:				
sWA ExpPosCoordZ				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpPosCoordZ	String	12	Additional Z-coordinate of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpPosCoordZ[ETX]
Read Variable Response:	[STX]sRA ExpPosCoordZ A5[ETX]
Write Variable:	[STX]sWN ExpPosCoordZ A5[ETX]
Write Variable Response:	[STX]sWA ExpPosCoordZ[ETX]

© SICK AG - Germany - All rights reserved

2.37.14.7. Variable: ExpanderScannerHRPosAlpha

The following section contains a detailed description of the variable ExpanderScannerHRPosAlpha.

Variable Overview

Variable Name	Description
ExpanderScannerHRPosAlpha	Additional High Resolution Alpha Angle of scanner position for expander

Communication Name	ExpHRPosAlpha
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1346
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	90.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ExpHRPosAlpha
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpHRPosAlpha	String	13	Additional High Resolution Alpha Angle of scanner position for expander

Read Variable Response:

```
sRA ExpHRPosAlpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpHRPosAlpha	String	13	Additional High Resolution Alpha Angle of scanner position for expander
Variable Data	data	Real	4	

Write Variable:

```
sWN ExpHRPosAlpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpHRPosAlpha	String	13	Additional High Resolution Alpha Angle of scanner position for expander
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExpHRPosAlpha				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpHRPosAlpha	String	13	Additional High Resolution Alpha Angle of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpHRPosAlpha[ETX]
Read Variable Response:	[STX]sRA ExpHRPosAlpha 42B40000[ETX]
Write Variable:	[STX]sWN ExpHRPosAlpha 42B40000[ETX]
Write Variable Response:	[STX]sWA ExpHRPosAlpha[ETX]

2.37.14.8. Variable: ExpanderScannerHRPosBeta

The following section contains a detailed description of the variable ExpanderScannerHRPosBeta.

Variable Overview

Variable Name	Description
ExpanderScannerHRPosBeta	Additional High Resolution Beta Angle of scanner position for expander

Communication Name	ExpHRPosBeta
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1347
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ExpHRPosBeta`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpHRPosBeta	String	12	Additional High Resolution Beta Angle of scanner position for expander

Read Variable Response:				
`sRA ExpHRPosBeta <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpHRPosBeta	String	12	Additional High Resolution Beta Angle of scanner position for expander
Variable Data	data	Real	4	

Write Variable:				
`sWN ExpHRPosBeta <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpHRPosBeta	String	12	Additional High Resolution Beta Angle of scanner position for expander
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ExpHRPosBeta`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpHRPosBeta	String	12	Additional High Resolution Beta Angle of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExpHRPosBeta[ETX]`
Read Variable Response:	`[STX]sRA ExpHRPosBeta 00000000[ETX]`
Write Variable:	`[STX]sWN ExpHRPosBeta 00000000[ETX]`
Write Variable Response:	`[STX]sWA ExpHRPosBeta[ETX]`

© SICK AG - Germany - All rights reserved

2.37.14.9. Variable: ExpanderScannerHRPosGamma

The following section contains a detailed description of the variable ExpanderScannerHRPosGamma.

Variable Overview

Variable Name	Description
ExpanderScannerHRPosGamma	Additional High Resolution Gamma Angle of scanner position for expander

Communication Name	ExpHRPosGamma
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1348
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ExpHRPosGamma
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpHRPosGamma	String	13	Additional High Resolution Gamma Angle of scanner position for expander

Read Variable Response:

```
sRA ExpHRPosGamma <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpHRPosGamma	String	13	Additional High Resolution Gamma Angle of scanner position for expander
Variable Data	data	Real	4	

Write Variable:

```
sWN ExpHRPosGamma <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpHRPosGamma	String	13	Additional High Resolution Gamma Angle of scanner position for expander
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExpHRPosGamma				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpHRPosGamma	String	13	Additional High Resolution Gamma Angle of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpHRPosGamma[ETX]
Read Variable Response:	[STX]sRA ExpHRPosGamma 00000000[ETX]
Write Variable:	[STX]sWN ExpHRPosGamma 00000000[ETX]
Write Variable Response:	[STX]sWA ExpHRPosGamma[ETX]

2.37.14.10. Variable: ExpanderScannerHRPosXCoord

The following section contains a detailed description of the variable ExpanderScannerHRPosXCoord.

Variable Overview

Variable Name	Description
ExpanderScannerHRPosXCoord	Additional High Resolution X-coordinate of scanner position for expander

Communication Name	ExpHRPosCoordX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1349
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -10000.0..10000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ExpHRPosCoordX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpHRPosCoordX	String	14	Additional High Resolution X-coordinate of scanner position for expander

Read Variable Response:				
`sRA ExpHRPosCoordX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpHRPosCoordX	String	14	Additional High Resolution X-coordinate of scanner position for expander
Variable Data	data	Real	4	

Write Variable:				
`sWN ExpHRPosCoordX <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpHRPosCoordX	String	14	Additional High Resolution X-coordinate of scanner position for expander
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ExpHRPosCoordX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpHRPosCoordX	String	14	Additional High Resolution X-coordinate of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExpHRPosCoordX[ETX]`
Read Variable Response:	`[STX]sRA ExpHRPosCoordX 00000000[ETX]`
Write Variable:	`[STX]sWN ExpHRPosCoordX 00000000[ETX]`
Write Variable Response:	`[STX]sWA ExpHRPosCoordX[ETX]`

© SICK AG - Germany - All rights reserved

2.37.14.11. Variable: ExpanderScannerHRPosYCoord

The following section contains a detailed description of the variable ExpanderScannerHRPosYCoord.

Variable Overview

Variable Name	Description
ExpanderScannerHRPosYCoord	Additional High Resolution Y-coordinate of scanner position for expander

Communication Name	ExpHRPosCoordY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1350
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3000.0..3000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ExpHRPosCoordY
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpHRPosCoordY	String	14	Additional High Resolution Y-coordinate of scanner position for expander

Read Variable Response:

```
sRA ExpHRPosCoordY <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpHRPosCoordY	String	14	Additional High Resolution Y-coordinate of scanner position for expander
Variable Data	data	Real	4	

Write Variable:

```
sWN ExpHRPosCoordY <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpHRPosCoordY	String	14	Additional High Resolution Y-coordinate of scanner position for expander
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ExpHRPosCoordY				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpHRPosCoordY	String	14	Additional High Resolution Y-coordinate of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ExpHRPosCoordY[ETX]
Read Variable Response:	[STX]sRA ExpHRPosCoordY 00000000[ETX]
Write Variable:	[STX]sWN ExpHRPosCoordY 00000000[ETX]
Write Variable Response:	[STX]sWA ExpHRPosCoordY[ETX]

2.37.14.12. Variable: ExpanderScannerHRPosZCoord

The following section contains a detailed description of the variable ExpanderScannerHRPosZCoord.

Variable Overview

Variable Name	Description
ExpanderScannerHRPosZCoord	Additional High Resolution Z-coordinate of scanner position for expander

Communication Name	ExpHRPosCoordZ
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1351
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3500.0..3500.0
Initialisation	165.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ExpHRPosCoordZ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpHRPosCoordZ	String	14	Additional High Resolution Z-coordinate of scanner position for expander

Read Variable Response:				
`sRA ExpHRPosCoordZ <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpHRPosCoordZ	String	14	Additional High Resolution Z-coordinate of scanner position for expander
Variable Data	data	Real	4	

Write Variable:				
`sWN ExpHRPosCoordZ <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpHRPosCoordZ	String	14	Additional High Resolution Z-coordinate of scanner position for expander
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ExpHRPosCoordZ`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpHRPosCoordZ	String	14	Additional High Resolution Z-coordinate of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExpHRPosCoordZ[ETX]`
Read Variable Response:	`[STX]sRA ExpHRPosCoordZ 43250000[ETX]`
Write Variable:	`[STX]sWN ExpHRPosCoordZ 43250000[ETX]`
Write Variable Response:	`[STX]sWA ExpHRPosCoordZ[ETX]`

© SICK AG - Germany - All rights reserved

2.37.15. Group: Reading

2.37.15.1. Variable: RCReadingAreaLimY1

The following section contains a detailed description of the variable RCReadingAreaLimY1.

Variable Overview

Variable Name	Description
RCReadingAreaLimY1	Y1 reading area. Right edge of conveyor

Communication Name	RCRdArlimY1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1352
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN RCRdArlimY1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCRdArlimY1	String	11	Y1 reading area. Right edge of conveyor

Read Variable Response:

```
sRA RCRdArlimY1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCRdArlimY1	String	11	Y1 reading area. Right edge of conveyor
Variable Data	data	DInt	4	

Write Variable:

```
sWN RCRdArlimY1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCRdArlimY1	String	11	Y1 reading area. Right edge of conveyor
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RCRdArlimY1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCRdArlimY1	String	11	Y1 reading area. Right edge of conveyor

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RCRdArlimY1[ETX]
Read Variable Response:	[STX]sRA RCRdArlimY1 0[ETX]
Write Variable:	[STX]sWN RCRdArlimY1 0[ETX]
Write Variable Response:	[STX]sWA RCRdArlimY1[ETX]

2.37.15.2. Variable: RCReadingAreaLimY2

The following section contains a detailed description of the variable RCReadingAreaLimY2.

Variable Overview

Variable Name	Description
RCReadingAreaLimY2	Y2 reading area. Left edge of conveyor

Communication Name	RCRdArlimY2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1353
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	1200
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RCRdArlimY2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCRdArlimY2	String	11	Y2 reading area. Left edge of conveyor

Read Variable Response:				
`sRA RCRdArlimY2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCRdArlimY2	String	11	Y2 reading area. Left edge of conveyor
Variable Data	data	DInt	4	

Write Variable:				
`sWN RCRdArlimY2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCRdArlimY2	String	11	Y2 reading area. Left edge of conveyor
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA RCRdArlimY2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCRdArlimY2	String	11	Y2 reading area. Left edge of conveyor

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCRdArlimY2[ETX]`
Read Variable Response:	`[STX]sRA RCRdArlimY2 4B0[ETX]`
Write Variable:	`[STX]sWN RCRdArlimY2 4B0[ETX]`
Write Variable Response:	`[STX]sWA RCRdArlimY2[ETX]`

© SICK AG - Germany - All rights reserved

2.37.15.3. Variable: RCReadingAreaLimZ1

The following section contains a detailed description of the variable RCReadingAreaLimZ1.

Variable Overview

Variable Name	Description
RCReadingAreaLimZ1	Z1 reading area. Level of conveyor

Communication Name	RCRdArlimZ1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1354
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN RCRdArlimZ1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCRdArlimZ1	String	11	Z1 reading area. Level of conveyor

Read Variable Response:

```
sRA RCRdArlimZ1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCRdArlimZ1	String	11	Z1 reading area. Level of conveyor
Variable Data	data	DInt	4	

Write Variable:

```
sWN RCRdArlimZ1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCRdArlimZ1	String	11	Z1 reading area. Level of conveyor
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA RCRdArlimZ1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCRdArlimZ1	String	11	Z1 reading area. Level of conveyor

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCRdArlimZ1[ETX]`
Read Variable Response:	`[STX]sRA RCRdArlimZ1 0[ETX]`
Write Variable:	`[STX]sWN RCRdArlimZ1 0[ETX]`
Write Variable Response:	`[STX]sWA RCRdArlimZ1[ETX]`

2.37.15.4. Variable: RCReadingAreaLimZ2

The following section contains a detailed description of the variable RCReadingAreaLimZ2.

Variable Overview

Variable Name	Description
RCReadingAreaLimZ2	Z2 reading area. Maximum scanning height

Communication Name	RCRdArlimZ2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1355
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	1600
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN RCRdArlimZ2`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCRdArlimZ2	String	11	Z2 reading area. Maximum scanning height

Read Variable Response:

`sRA RCRdArlimZ2 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCRdArlimZ2	String	11	Z2 reading area. Maximum scanning height
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN RCRdArlimZ2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCRdArlimZ2	String	11	Z2 reading area. Maximum scanning height
Variable Data	data	DInt	4	

Write Variable Response:				
sWA RCRdArlimZ2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCRdArlimZ2	String	11	Z2 reading area. Maximum scanning height

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RCRdArlimZ2[ETX]
Read Variable Response:	[STX]sRA RCRdArlimZ2 640[ETX]
Write Variable:	[STX]sWN RCRdArlimZ2 640[ETX]
Write Variable Response:	[STX]sWA RCRdArlimZ2[ETX]

2.37.15.5. Method: DoMatchCodeTeachIn

The following section contains a detailed description of the method DoMatchCodeTeachIn.

Method Overview

Method Name	Description
DoMatchCodeTeachIn	executes a match code teach in

Communication Name	mRCMaCdTeach
Sopas Index	129
Invocation Access	Always

Return Values		
Success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mRCMaCdTeach`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mRCMaCdTeach	String	12	executes a match code teach in

Method Return Value:				
`sAN mRCMaCdTeach <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mRCMaCdTeach	String	12	executes a match code teach in
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mRCMaCdTeach[ETX]`
Method Return Value:	`[STX]sAN mRCMaCdTeach 0[ETX]`

© SICK AG - Germany - All rights reserved

2.37.16. Group: Reading65x

2.37.16.1. Variable: CalcTriggerPreExpand

The following section contains a detailed description of the variable CalcTriggerPreExpand.

Variable Overview

Variable Name	Description
CalcTriggerPreExpand	calculated value pre expation of the trigger

Communication Name	RCCalcTriggerPreExpand
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1356
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN RCCalcTriggerPreExpand
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCCalcTriggerPreExpand	String	22	calculated value pre expation of the trigger

Read Variable Response:

```
sRA RCCalcTriggerPreExpand <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCCalcTriggerPreExpand	String	22	calculated value pre expation of the trigger
Variable Data	data	DInt	4	

Write Variable:

```
sWN RCCalcTriggerPreExpand <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCCalcTriggerPreExpand	String	22	calculated value pre expation of the trigger
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA RCCalcTriggerPreExpand				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCCalcTriggerPreExpand	String	22	calculated value pre expation of the trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN RCCalcTriggerPreExpand[ETX]
Read Variable Response:	[STX]sRA RCCalcTriggerPreExpand 0[ETX]
Write Variable:	[STX]sWN RCCalcTriggerPreExpand 0[ETX]
Write Variable Response:	[STX]sWA RCCalcTriggerPreExpand[ETX]

2.37.16.2. Variable: CalcTriggerPostExpand

The following section contains a detailed description of the variable CalcTriggerPostExpand.

Variable Overview

Variable Name	Description
CalcTriggerPostExpand	calculated value of the post expation he trigger

Communication Name	RCCalcTriggerPostExpand
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1357
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN RCCalcTriggerPostExpand`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	RCCalcTriggerPostExpand	String	23	calculated value of the post expation he trigger

Read Variable Response:				
`sRA RCCalcTriggerPostExpand <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	RCCalcTriggerPostExpand	String	23	calculated value of the post expation he trigger
Variable Data	data	DInt	4	

Write Variable:				
`sWN RCCalcTriggerPostExpand <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	RCCalcTriggerPostExpand	String	23	calculated value of the post expation he trigger
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA RCCalcTriggerPostExpand`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	RCCalcTriggerPostExpand	String	23	calculated value of the post expation he trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN RCCalcTriggerPostExpand[ETX]`
Read Variable Response:	`[STX]sRA RCCalcTriggerPostExpand 0[ETX]`
Write Variable:	`[STX]sWN RCCalcTriggerPostExpand 0[ETX]`
Write Variable Response:	`[STX]sWA RCCalcTriggerPostExpand[ETX]`

© SICK AG - Germany - All rights reserved

2.37.17. Group: AutoSetup

2.37.17.1. Variable: ASParameter

The following section contains a detailed description of the variable ASParameter.

Variable Overview

Variable Name	Description
ASParameter	Parameters for AutoSetup. This variable has to be set before StartAutoSetup is called.

Communication Name	ASParam
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1358
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
ParamMode			
	Enum8		
	Default Value	TX_AUTOSETUP_STANDARD	
	Value	Name	Description
	0	TX_AUTOSETUP_STANDARD	
	1	TX_AUTOSETUP_ADVANCED	
Focus			
	Bool		
	Value Range	False, True	
	Initialisation	True	
Image			
	Bool		
	Value Range	False, True	
	Initialisation	True	
Code			
	Bool		
	Value Range	False, True	
	Initialisation	True	
CodeSettingsMode			
	Enum8		
	Default Value	TX_Replace	
	Value	Name	Description
	0	TX_Replace	
	1	TX_Add	
ChangeCodeBackground			
	Bool		
	Value Range	False, True	
	Initialisation	True	

© SICK AG - Germany - All rights reserved

Struct	
ChangeCodeContrast	
Bool	
Value Range	False, True
Initialisation	True
ChangeCodeSize	
Bool	
Value Range	False, True
Initialisation	True
ChangeCodeDefects	
Bool	
Value Range	False, True
Initialisation	False
OptimizeCodePerformance	
Bool	
Value Range	False, True
Initialisation	True
OptimizeErosionDilation	
Bool	
Value Range	False, True
Initialisation	False
ImageRegion	
Int	
Value Range	-1..8
Initialisation	-1
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ASParam
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASParam	String	7	Parameters for AutoSetup. This variable has to be set before StartAutoSetup is called.

Read Variable Response:

```
sRA ASParam <ParamMode> <Focus> <Image> <Code> <CodeSettingsMode> <ChangeCodeBackground>
<ChangeCodeContrast> <ChangeCodeSize> <ChangeCodeDefects> <OptimizeCodePerformance>
<OptimizeErosionDilation> <ImageRegion>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASParam	String	7	Parameters for AutoSetup. This variable has to be set before StartAutoSetup is called.
Variable Data 1	ParamMode	Enum8	1	
Variable Data 2	Focus	Bool	1	
Variable Data 3	Image	Bool	1	
Variable Data 4	Code	Bool	1	
Variable Data 5	CodeSettingsMode	Enum8	1	
Variable Data 6	ChangeCodeBackground	Bool	1	

© SICK AG - Germany - All rights reserved

Read Variable Response:				
sRA ASParam <ParamMode> <Focus> <Image> <Code> <CodeSettingsMode> <ChangeCodeBackground> <ChangeCodeContrast> <ChangeCodeSize> <ChangeCodeDefects> <OptimizeCodePerformance> <OptimizeErosionDilation> <ImageRegion>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 7	ChangeCodeContrast	Bool	1	
Variable Data 8	ChangeCodeSize	Bool	1	
Variable Data 9	ChangeCodeDefects	Bool	1	
Variable Data 10	OptimizeCodePerformance	Bool	1	
Variable Data 11	OptimizeErosionDilation	Bool	1	
Variable Data 12	ImageRegion	Int	2	

Write Variable:				
sWN ASParam <ParamMode> <Focus> <Image> <Code> <CodeSettingsMode> <ChangeCodeBackground> <ChangeCodeContrast> <ChangeCodeSize> <ChangeCodeDefects> <OptimizeCodePerformance> <OptimizeErosionDilation> <ImageRegion>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASParam	String	7	Parameters for AutoSetup. This variable has to be set before StartAutoSetup is called.
Variable Data 1	ParamMode	Enum8	1	
Variable Data 2	Focus	Bool	1	
Variable Data 3	Image	Bool	1	
Variable Data 4	Code	Bool	1	
Variable Data 5	CodeSettingsMode	Enum8	1	
Variable Data 6	ChangeCodeBackground	Bool	1	
Variable Data 7	ChangeCodeContrast	Bool	1	
Variable Data 8	ChangeCodeSize	Bool	1	
Variable Data 9	ChangeCodeDefects	Bool	1	
Variable Data 10	OptimizeCodePerformance	Bool	1	
Variable Data 11	OptimizeErosionDilation	Bool	1	
Variable Data 12	ImageRegion	Int	2	

Write Variable Response:				
sWA ASParam				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASParam	String	7	Parameters for AutoSetup. This variable has to be set before StartAutoSetup is called.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ASParam[ETX]
Read Variable Response:	[STX]sRA ASParam 0 1 1 1 0 1 1 1 0 1 0 FFFF[ETX]
Write Variable:	[STX]sWN ASParam 0 1 1 1 0 1 1 1 0 1 0 FFFF[ETX]
Write Variable Response:	[STX]sWA ASParam[ETX]

© SICK AG - Germany - All rights reserved

2.37.17.2. Variable: ASCodeRegion

The following section contains a detailed description of the variable ASCodeRegion.

Variable Overview

Variable Name	Description
ASCodeRegion	Code region for auto setup. This variable has to be set before StartAutoSetup is called.

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1359
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
x		
	Int	
	Value Range	-32768..32767
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0
y		
	Int	
	Value Range	-32768..32767
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0
width		
	Int	
	Value Range	-32768..32767
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0
height		
	Int	
	Value Range	-32768..32767
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ASCodeRegion`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASCodeRegion	String	12	Code region for auto setup. This variable has to be set before StartAutoSetup is called.

Read Variable Response:				
`sRA ASCodeRegion <x> <y> <width> <height>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASCodeRegion	String	12	Code region for auto setup. This variable has to be set before StartAutoSetup is called.
Variable Data 1	x	Int	2	
Variable Data 2	y	Int	2	
Variable Data 3	width	Int	2	
Variable Data 4	height	Int	2	

Write Variable:				
`sWN ASCodeRegion <x> <y> <width> <height>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASCodeRegion	String	12	Code region for auto setup. This variable has to be set before StartAutoSetup is called.
Variable Data 1	x	Int	2	
Variable Data 2	y	Int	2	
Variable Data 3	width	Int	2	
Variable Data 4	height	Int	2	

Write Variable Response:				
`sWA ASCodeRegion`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASCodeRegion	String	12	Code region for auto setup. This variable has to be set before StartAutoSetup is called.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ASCodeRegion[ETX]`
Read Variable Response:	`[STX]sRA ASCodeRegion 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN ASCodeRegion 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA ASCodeRegion[ETX]`

© SICK AG - Germany - All rights reserved

2.37.17.3. Variable: ASManualCodeRegion

The following section contains a detailed description of the variable ASManualCodeRegion.

Variable Overview

Variable Name	Description
ASManualCodeRegion	Code region for auto setup. This variable has to be set before AutoSetup is stopped.

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1360
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Always

Struct	
x	
Int	
Value Range	-32768..32767
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
y	
Int	
Value Range	-32768..32767
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
width	
Int	
Value Range	-32768..32767
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0
height	
Int	
Value Range	-32768..32767
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ASManualCodeRegion`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASManualCodeRegion	String	18	Code region for auto setup. This variable has to be set before AutoSetup is stopped.

Read Variable Response:				
`sRA ASManualCodeRegion <x> <y> <width> <height>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASManualCodeRegion	String	18	Code region for auto setup. This variable has to be set before AutoSetup is stopped.
Variable Data 1	x	Int	2	
Variable Data 2	y	Int	2	
Variable Data 3	width	Int	2	
Variable Data 4	height	Int	2	

Write Variable:				
`sWN ASManualCodeRegion <x> <y> <width> <height>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASManualCodeRegion	String	18	Code region for auto setup. This variable has to be set before AutoSetup is stopped.
Variable Data 1	x	Int	2	
Variable Data 2	y	Int	2	
Variable Data 3	width	Int	2	
Variable Data 4	height	Int	2	

Write Variable Response:				
`sWA ASManualCodeRegion`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASManualCodeRegion	String	18	Code region for auto setup. This variable has to be set before AutoSetup is stopped.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ASManualCodeRegion[ETX]`
Read Variable Response:	`[STX]sRA ASManualCodeRegion 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN ASManualCodeRegion 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA ASManualCodeRegion[ETX]`

© SICK AG - Germany - All rights reserved

2.37.17.4. Variable: ASDatamatrixPrio

The following section contains a detailed description of the variable ASDatamatrixPrio.

Variable Overview

Variable Name	Description
ASDatamatrixPrio	Prefer normal or DPM datamatrix codes during auto setup.

Communication Name	ASDmxPrio
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1362
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Standard	
	Value	Name	Description
	0	Standard	
	1	DPM	

Variable Telegram Syntax

Read Variable:				
`sRN ASDmxPrio`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASDmxPrio	String	9	Prefer normal or DPM datamatrix codes during auto setup.

Read Variable Response:				
`sRA ASDmxPrio <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASDmxPrio	String	9	Prefer normal or DPM datamatrix codes during auto setup.
Variable Data	data	Enum8	1	

Write Variable:				
`sWN ASDmxPrio <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASDmxPrio	String	9	Prefer normal or DPM datamatrix codes during auto setup.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ASDmxPrio				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASDmxPrio	String	9	Prefer normal or DPM datamatrix codes during auto setup.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ASDmxPrio[ETX]
Read Variable Response:	[STX]sRA ASDmxPrio 0[ETX]
Write Variable:	[STX]sWN ASDmxPrio 0[ETX]
Write Variable Response:	[STX]sWA ASDmxPrio[ETX]

2.37.17.5. Variable: ASAllowTeachPixToMM

The following section contains a detailed description of the variable ASAllowTeachPixToMM.

Variable Overview

Variable Name
ASAllowTeachPixToMM

Communication Name	ASAllTchPixMM
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1363
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ASAllTchPixMM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASAllTchPixMM	String	13	

Read Variable Response:				
`sRA ASAllTchPixMM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASAllTchPixMM	String	13	
Variable Data	data	Bool	1	

Write Variable:				
`sWN ASAllTchPixMM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASAllTchPixMM	String	13	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA ASAllTchPixMM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASAllTchPixMM	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ASAllTchPixMM[ETX]`
Read Variable Response:	`[STX]sRA ASAllTchPixMM 0[ETX]`
Write Variable:	`[STX]sWN ASAllTchPixMM 0[ETX]`
Write Variable Response:	`[STX]sWA ASAllTchPixMM[ETX]`

© SICK AG - Germany - All rights reserved

2.37.17.6. Variable: ASUseDPMRoi

The following section contains a detailed description of the variable ASUseDPMRoi.

Variable Overview

Variable Name	Description
ASUseDPMRoi	Decides whether the ROI computed by DPM Decoder AutoSetup shall be used or not (provided the configuration is saved to a parameter set).

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1364
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN ASUseDPMRoi
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASUseDPMRoi	String	11	Decides whether the ROI computed by DPM Decoder AutoSetup shall be used or not (provided the configuration is saved to a parameter set).

Read Variable Response:

```
sRA ASUseDPMRoi <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASUseDPMRoi	String	11	Decides whether the ROI computed by DPM Decoder AutoSetup shall be used or not (provided the configuration is saved to a parameter set).
Variable Data	data	Bool	1	

Write Variable:

```
sWN ASUseDPMRoi <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASUseDPMRoi	String	11	Decides whether the ROI computed by DPM Decoder AutoSetup shall be used or not (provided the configuration is saved to a parameter set).
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA ASUseDPMRoi
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ASUseDPMRoi				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	ASUseDPMRoi	String	11	Decides whether the ROI computed by DPM Decoder AutoSetup shall be used or not (provided the configuration is saved to a parameter set).

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ASUseDPMRoi[ETX]
Read Variable Response:	[STX]sRA ASUseDPMRoi 0[ETX]
Write Variable:	[STX]sWN ASUseDPMRoi 0[ETX]
Write Variable Response:	[STX]sWA ASUseDPMRoi[ETX]

2.37.17.7. Variable: ASUserDefinedDPMRoi

The following section contains a detailed description of the variable ASUserDefinedDPMRoi.

Variable Overview

Variable Name	Description
ASUserDefinedDPMRoi	Decides whether the ROI computed by DPM Decoder will be set manually again after AS.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1365
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ASUserDefinedDPMRoi`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASUserDefinedDPMRoi	String	19	Decides whether the ROI computed by DPM Decoder will be set manually again after AS.

Read Variable Response:				
`sRA ASUserDefinedDPMRoi <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASUserDefinedDPMRoi	String	19	Decides whether the ROI computed by DPM Decoder will be set manually again after AS.
Variable Data	data	Bool	1	

Write Variable:				
`sWN ASUserDefinedDPMRoi <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASUserDefinedDPMRoi	String	19	Decides whether the ROI computed by DPM Decoder will be set manually again after AS.
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA ASUserDefinedDPMRoi`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASUserDefinedDPMRoi	String	19	Decides whether the ROI computed by DPM Decoder will be set manually again after AS.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ASUserDefinedDPMRoi[ETX]`
Read Variable Response:	`[STX]sRA ASUserDefinedDPMRoi 0[ETX]`
Write Variable:	`[STX]sWN ASUserDefinedDPMRoi 0[ETX]`
Write Variable Response:	`[STX]sWA ASUserDefinedDPMRoi[ETX]`

© SICK AG - Germany - All rights reserved

2.37.17.8. Variable: ASWriteTarget

The following section contains a detailed description of the variable ASWriteTarget.

Variable Overview

Variable Name	Description
ASWriteTarget	Decides where to write the result of the AutoSetup. If a parameter bank is chosen the firmware is supposed to activate APS.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1370
Read-Access	Always
Write-Access	Always

Enum8			
	Value	Name	Description
	0	MAIN_REPOSITORY	
	1	PARAMETER_BANK1	
	2	PARAMETER_BANK2	
	3	PARAMETER_BANK3	
	4	PARAMETER_BANK4	
	5	PARAMETER_BANK5	
	6	PARAMETER_BANK6	
	7	PARAMETER_BANK7	
	8	PARAMETER_BANK8	

Variable Telegram Syntax

Read Variable:

```
sRN ASWriteTarget
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASWriteTarget	String	13	Decides where to write the result of the AutoSetup. If a parameter bank is chosen the firmware is supposed to activate APS.

Read Variable Response:

```
sRA ASWriteTarget <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASWriteTarget	String	13	Decides where to write the result of the AutoSetup. If a parameter bank is chosen the firmware is supposed to activate APS.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN ASWriteTarget <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN ASWriteTarget <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	ASWriteTarget	String	13	Decides where to write the result of the AutoSetup. If a parameter bank is chosen the firmware is supposed to activate APS.
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA ASWriteTarget				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASWriteTarget	String	13	Decides where to write the result of the AutoSetup. If a parameter bank is chosen the firmware is supposed to activate APS.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ASWriteTarget[ETX]
Read Variable Response:	[STX]sRA ASWriteTarget 0[ETX]
Write Variable:	[STX]sWN ASWriteTarget 0[ETX]
Write Variable Response:	[STX]sWA ASWriteTarget[ETX]

2.37.17.9. Variable: ASConveyorSpeed

The following section contains a detailed description of the variable ASConveyorSpeed.

Variable Overview

Variable Name	Description
ASConveyorSpeed	The conveyor speed used in AutoSetup for calculating the shutter time.

Communication Name	ASConvSpeed
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1371
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 Min Value: 0.0
Initialisation	0
Physical Unit	m/s
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ASConvSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASConvSpeed	String	11	The conveyor speed used in AutoSetup for calculating the shutter time.

Read Variable Response:				
`sRA ASConvSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASConvSpeed	String	11	The conveyor speed used in AutoSetup for calculating the shutter time.
Variable Data	data	Real	4	

Write Variable:				
`sWN ASConvSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASConvSpeed	String	11	The conveyor speed used in AutoSetup for calculating the shutter time.
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ASConvSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ASConvSpeed	String	11	The conveyor speed used in AutoSetup for calculating the shutter time.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ASConvSpeed[ETX]`
Read Variable Response:	`[STX]sRA ASConvSpeed 00000000[ETX]`
Write Variable:	`[STX]sWN ASConvSpeed 00000000[ETX]`
Write Variable Response:	`[STX]sWA ASConvSpeed[ETX]`

© SICK AG - Germany - All rights reserved

2.37.17.10. Variable: ASCellSize

The following section contains a detailed description of the variable ASCellSize.

Variable Overview

Variable Name	Description
ASCellSize	The cell size used in AutoSetup for calculating the shutter time.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1372
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 Min Value: 0.0
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ASCellSize
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ASCellSize	String	10	The cell size used in AutoSetup for calculating the shutter time.

Read Variable Response:

```
sRA ASCellSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ASCellSize	String	10	The cell size used in AutoSetup for calculating the shutter time.
Variable Data	data	Real	4	

Write Variable:

```
sWN ASCellSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ASCellSize	String	10	The cell size used in AutoSetup for calculating the shutter time.
Variable Data	data	Real	4	

Write Variable Response:

```
sWA ASCellSize
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ASCellSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	ASCellSize	String	10	The cell size used in AutoSetup for calculating the shutter time.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ASCellSize[ETX]
Read Variable Response:	[STX]sRA ASCellSize 00000000[ETX]
Write Variable:	[STX]sWN ASCellSize 00000000[ETX]
Write Variable Response:	[STX]sWA ASCellSize[ETX]

2.37.17.11. Method: StartAutoSetup

The following section contains a detailed description of the method StartAutoSetup.

Method Overview

Method Name	Description
StartAutoSetup	executes auto setup

Communication Name	mASStart
Sopas Index	130
Invocation Access	Always

Return Values		
Started		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mASStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASStart	String	8	executes auto setup

Method Return Value:				
`sAN mASStart <Started>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASStart	String	8	executes auto setup
Return Value 1	Started	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mASStart[ETX]`
Method Return Value:	`[STX]sAN mASStart 0[ETX]`

2.37.17.12. Method: CancelAutoSetup

The following section contains a detailed description of the method CancelAutoSetup.

Method Overview

Method Name	Description
CancelAutoSetup	cancel autosetup and restore all parameters to their previous state.

Communication Name	mASCancel
Sopas Index	131
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mASCancel				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASCancel	String	9	cancel autosetup and restore all parameters to their previous state.

Method Return Value:				
sAN mASCancel				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASCancel	String	9	cancel autosetup and restore all parameters to their previous state.

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mASCancel[ETX]
Method Return Value:	[STX]sAN mASCancel[ETX]

2.37.17.13. Method: FinishAutoSetup

The following section contains a detailed description of the method FinishAutoSetup.

Method Overview

Method Name	Description
FinishAutoSetup	Save the results of autosetup temporarily on the device.

Communication Name	mASFinish
Sopas Index	132
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mASFinish				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASFinish	String	9	Save the results of autosetup temporarily on the device.

Method Return Value:				
sAN mASFinish				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASFinish	String	9	Save the results of autosetup temporarily on the device.

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mASFinish[ETX]
Method Return Value:	[STX]sAN mASFinish[ETX]

2.37.17.14. Method: ASCalculateShutterTime

The following section contains a detailed description of the method ASCalculateShutterTime.

Method Overview

Method Name	Description
ASCalculateShutterTime	Determines a best fitting shutter time using conveyor speed and celle size.

Communication Name	mASCalcShutTime
Sopas Index	133
Invocation Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mASCalcShutTime				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASCalcShutTime	String	15	Determines a best fitting shutter time using conveyor speed and celle size.

Method Return Value:				
sAN mASCalcShutTime				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASCalcShutTime	String	15	Determines a best fitting shutter time using conveyor speed and celle size.

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mASCalcShutTime[ETX]
Method Return Value:	[STX]sAN mASCalcShutTime[ETX]

2.37.17.15. Event: ASAllOperationsFinished

The following section contains a detailed description of the event ASAllOperationsFinished.

Event Overview

Event Name	Description
ASAllOperationsFinished	Indicator for SOPAS to perform an upload of all variables, to receive the Auto-Setup results

Sopas Index	456
Queue Length	1

© SICK AG - Germany - All rights reserved

2.37.18. Group: AutoSetupLector65x

2.37.18.1. Variable: PoseEstimationXOrigin

The following section contains a detailed description of the variable PoseEstimationXOrigin.

Variable Overview

Variable Name	Description
PoseEstimationXOrigin	x Origin of the chessboard target

Communication Name	ALSPosEstiXOrigin
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1373
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSPosEstiXOrigin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiXOrigin	String	17	x Origin of the chessboard target

Read Variable Response:

```
sRA ALSPosEstiXOrigin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiXOrigin	String	17	x Origin of the chessboard target
Variable Data	data	DInt	4	

Write Variable:

```
sWN ALSPosEstiXOrigin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiXOrigin	String	17	x Origin of the chessboard target
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ALSPosEstiXOrigin				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiXOrigin	String	17	x Origin of the chessboard target

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSPosEstiXOrigin[ETX]
Read Variable Response:	[STX]sRA ALSPosEstiXOrigin 0[ETX]
Write Variable:	[STX]sWN ALSPosEstiXOrigin 0[ETX]
Write Variable Response:	[STX]sWA ALSPosEstiXOrigin[ETX]

2.37.18.2. Variable: PoseEstimationYOrigin

The following section contains a detailed description of the variable PoseEstimationYOrigin.

Variable Overview

Variable Name	Description
PoseEstimationYOrigin	y Origin of the chessboard target

Communication Name	ALSPosEstiYOrigin
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1374
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ALSPosEstiYOrigin`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiYOrigin	String	17	y Origin of the chessboard target

Read Variable Response:				
`sRA ALSPosEstiYOrigin <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiYOrigin	String	17	y Origin of the chessboard target
Variable Data	data	DInt	4	

Write Variable:				
`sWN ALSPosEstiYOrigin <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiYOrigin	String	17	y Origin of the chessboard target
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA ALSPosEstiYOrigin`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiYOrigin	String	17	y Origin of the chessboard target

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSPosEstiYOrigin[ETX]`
Read Variable Response:	`[STX]sRA ALSPosEstiYOrigin 0[ETX]`
Write Variable:	`[STX]sWN ALSPosEstiYOrigin 0[ETX]`
Write Variable Response:	`[STX]sWA ALSPosEstiYOrigin[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.3. Variable: PoseEstimationZOrigin

The following section contains a detailed description of the variable PoseEstimationZOrigin.

Variable Overview

Variable Name	Description
PoseEstimationZOrigin	z Origin of the chessboard target

Communication Name	ALSPosEstiZOrigin
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1375
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSPosEstiZOrigin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiZOrigin	String	17	z Origin of the chessboard target

Read Variable Response:

```
sRA ALSPosEstiZOrigin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiZOrigin	String	17	z Origin of the chessboard target
Variable Data	data	DInt	4	

Write Variable:

```
sWN ALSPosEstiZOrigin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiZOrigin	String	17	z Origin of the chessboard target
Variable Data	data	DInt	4	

Write Variable Response:

```
sWA ALSPosEstiZOrigin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiZOrigin	String	17	z Origin of the chessboard target

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSPosEstiZOrigin[ETX]`
Read Variable Response:	`[STX]sRA ALSPosEstiZOrigin 0[ETX]`
Write Variable:	`[STX]sWN ALSPosEstiZOrigin 0[ETX]`
Write Variable Response:	`[STX]sWA ALSPosEstiZOrigin[ETX]`

2.37.18.4. Variable: PoseEstimationTargetOrientation

The following section contains a detailed description of the variable PoseEstimationTargetOrientation.

Variable Overview

Variable Name	Description
PoseEstimationTargetOrientation	Orientation of the chessboard target

Communication Name	ALSPosEstiTargetOrientation
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1376
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_TOP	
	1	TX_LEFT	
	2	TX_RIGHT	

Variable Telegram Syntax

Read Variable:				
`sRN ALSPosEstiTargetOrientation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiTargetOrientation	String	27	Orientation of the chessboard target

Read Variable Response:				
`sRA ALSPosEstiTargetOrientation <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiTargetOrientation	String	27	Orientation of the chessboard target
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN ALSPosEstiTargetOrientation <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiTargetOrientation	String	27	Orientation of the chessboard target
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA ALSPosEstiTargetOrientation				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiTargetOrientation	String	27	Orientation of the chessboard target

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSPosEstiTargetOrientation[ETX]
Read Variable Response:	[STX]sRA ALSPosEstiTargetOrientation 0[ETX]
Write Variable:	[STX]sWN ALSPosEstiTargetOrientation 0[ETX]
Write Variable Response:	[STX]sWA ALSPosEstiTargetOrientation[ETX]

2.37.18.5. Variable: PoseEstimationFeedback

The following section contains a detailed description of the variable PoseEstimationFeedback.

Variable Overview

Variable Name	Description
PoseEstimationFeedback	Feeadback structure of PoseEstimation

Communication Name	ALSPosEstiFeedBack
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1377
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct				
State				
	Enum8			
	Default Value		Idle	
		Value	Name	Description
		0	Idle	
		1	Active	
		2	Finished	
		3	Failed	

© SICK AG - Germany - All rights reserved

Struct	
Alpha	
UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0
Beta	
UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0
Gamma	
UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	°
Physical Unit Factor	0.0
X_Pos	
DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0
Y_Pos	
DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0
Z_Pos	
DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN ALSPosEstiFeedBack				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiFeedBack	String	18	Feeadback structure of PoseEstimation

Read Variable Response:				
sRA ALSPosEstiFeedBack <State> <Alpha> <Beta> <Gamma> <X_Pos> <Y_Pos> <Z_Pos>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiFeedBack	String	18	Feeadback structure of PoseEstimation
Variable Data 1	State	Enum8	1	
Variable Data 2	Alpha	UDInt	4	
Variable Data 3	Beta	UDInt	4	
Variable Data 4	Gamma	UDInt	4	
Variable Data 5	X_Pos	DInt	4	
Variable Data 6	Y_Pos	DInt	4	
Variable Data 7	Z_Pos	DInt	4	

Write Variable:				
sWN ALSPosEstiFeedBack <State> <Alpha> <Beta> <Gamma> <X_Pos> <Y_Pos> <Z_Pos>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiFeedBack	String	18	Feeadback structure of PoseEstimation
Variable Data 1	State	Enum8	1	
Variable Data 2	Alpha	UDInt	4	
Variable Data 3	Beta	UDInt	4	
Variable Data 4	Gamma	UDInt	4	
Variable Data 5	X_Pos	DInt	4	
Variable Data 6	Y_Pos	DInt	4	
Variable Data 7	Z_Pos	DInt	4	

Write Variable Response:				
sWA ALSPosEstiFeedBack				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiFeedBack	String	18	Feeadback structure of PoseEstimation

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSPosEstiFeedBack[ETX]`
Read Variable Response:	`[STX]sRA ALSPosEstiFeedBack 0 0 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN ALSPosEstiFeedBack 0 0 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA ALSPosEstiFeedBack[ETX]`

2.37.18.6. Variable: PoseEstimationProcessFeedback

The following section contains a detailed description of the variable PoseEstimationProcessFeedback.

Variable Overview

Variable Name	Description
PoseEstimationProcessFeedback	Feeadback structure of PoseEstimation process

Communication Name	ALSPosEstiProcFeedBack
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1378
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
State			
	Enum8		
	Default Value	Idle	
	Value	Name	Description
	0	Idle	
	1	Active	
	2	Finished	
	3	Failed	
Progress			
	Int		
	Value Range	-32768..32767	
	Initialisation	0	
	Physical Unit		
	Physical Unit Factor	0.0	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ALSPosEstiProcFeedBack`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiProcFeedBack	String	22	Feeadback structure of PoseEstimation process

Read Variable Response:				
`sRA ALSPosEstiProcFeedBack <State> <Progress>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiProcFeedBack	String	22	Feeadback structure of PoseEstimation process
Variable Data 1	State	Enum8	1	
Variable Data 2	Progress	Int	2	

Write Variable:				
`sWN ALSPosEstiProcFeedBack <State> <Progress>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiProcFeedBack	String	22	Feeadback structure of PoseEstimation process
Variable Data 1	State	Enum8	1	
Variable Data 2	Progress	Int	2	

Write Variable Response:				
`sWA ALSPosEstiProcFeedBack`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiProcFeedBack	String	22	Feeadback structure of PoseEstimation process

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSPosEstiProcFeedBack[ETX]`
Read Variable Response:	`[STX]sRA ALSPosEstiProcFeedBack 0 0[ETX]`
Write Variable:	`[STX]sWN ALSPosEstiProcFeedBack 0 0[ETX]`
Write Variable Response:	`[STX]sWA ALSPosEstiProcFeedBack[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.7. Variable: PoseEstimationFinish

The following section contains a detailed description of the variable PoseEstimationFinish.

Variable Overview

Variable Name	Description
PoseEstimationFinish	Pose Estimation has finished

Communication Name	ALSPosEstiFin
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1379
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN ALSPosEstiFin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSPosEstiFin	String	13	Pose Estimation has finished

Read Variable Response:

```
sRA ALSPosEstiFin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSPosEstiFin	String	13	Pose Estimation has finished
Variable Data	data	Bool	1	

Write Variable:

```
sWN ALSPosEstiFin <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSPosEstiFin	String	13	Pose Estimation has finished
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA ALSPosEstiFin
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSPosEstiFin	String	13	Pose Estimation has finished

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSPosEstiFin[ETX]`
Read Variable Response:	`[STX]sRA ALSPosEstiFin 0[ETX]`
Write Variable:	`[STX]sWN ALSPosEstiFin 0[ETX]`
Write Variable Response:	`[STX]sWA ALSPosEstiFin[ETX]`

2.37.18.8. Variable: NodalPoseAlphaOpti

The following section contains a detailed description of the variable NodalPoseAlphaOpti.

Variable Overview

Variable Name	Description
NodalPoseAlphaOpti	Pose Estimation Angle Alpha of scanner position optimal

Communication Name	ALSNodalPoseAlphaOpti
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1380
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -7.0..7.0
Initialisation	0.0
Physical Unit	rad
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN ALSNodalPoseAlphaOpti`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSNodalPoseAlphaOpti	String	21	Pose Estimation Angle Alpha of scanner position optimal

Read Variable Response:

`sRA ALSNodalPoseAlphaOpti <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSNodalPoseAlphaOpti	String	21	Pose Estimation Angle Alpha of scanner position optimal
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN ALSNodalPoseAlphaOpti <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSNodalPoseAlphaOpti	String	21	Pose Estimation Angle Alpha of scanner position optimal
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ALSNodalPoseAlphaOpti`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSNodalPoseAlphaOpti	String	21	Pose Estimation Angle Alpha of scanner position optimal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSNodalPoseAlphaOpti[ETX]`
Read Variable Response:	`[STX]sRA ALSNodalPoseAlphaOpti 00000000[ETX]`
Write Variable:	`[STX]sWN ALSNodalPoseAlphaOpti 00000000[ETX]`
Write Variable Response:	`[STX]sWA ALSNodalPoseAlphaOpti[ETX]`

2.37.18.9. Variable: NodalPoseBetaOpti

The following section contains a detailed description of the variable NodalPoseBetaOpti.

Variable Overview

Variable Name	Description
NodalPoseBetaOpti	Pose Estimation Angle Beta of scanner position optimal

Communication Name	ALSNodalPoseBetaOpti
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1381
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -7.0..7.0
Initialisation	0.0
Physical Unit	rad
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN ALSNodalPoseBetaOpti				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSNodalPoseBetaOpti	String	20	Pose Estimation Angle Beta of scanner position optimal

Read Variable Response:				
sRA ALSNodalPoseBetaOpti <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSNodalPoseBetaOpti	String	20	Pose Estimation Angle Beta of scanner position optimal
Variable Data	data	Real	4	

Write Variable:				
sWN ALSNodalPoseBetaOpti <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSNodalPoseBetaOpti	String	20	Pose Estimation Angle Beta of scanner position optimal
Variable Data	data	Real	4	

Write Variable Response:				
sWA ALSNodalPoseBetaOpti				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSNodalPoseBetaOpti	String	20	Pose Estimation Angle Beta of scanner position optimal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSNodalPoseBetaOpti[ETX]
Read Variable Response:	[STX]sRA ALSNodalPoseBetaOpti 00000000[ETX]
Write Variable:	[STX]sWN ALSNodalPoseBetaOpti 00000000[ETX]
Write Variable Response:	[STX]sWA ALSNodalPoseBetaOpti[ETX]

© SICK AG - Germany - All rights reserved

2.37.18.10. Variable: NodalPoseGammaOpti

The following section contains a detailed description of the variable NodalPoseGammaOpti.

Variable Overview

Variable Name	Description
NodalPoseGammaOpti	Pose Estimation Angle Gamma of scanner position optimal

Communication Name	ALSNodalPoseGammaOpti
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1382
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -7.0..7.0
Initialisation	0.0
Physical Unit	rad
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSNodalPoseGammaOpti
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSNodalPoseGammaOpti	String	21	Pose Estimation Angle Gamma of scanner position optimal

Read Variable Response:

```
sRA ALSNodalPoseGammaOpti <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSNodalPoseGammaOpti	String	21	Pose Estimation Angle Gamma of scanner position optimal
Variable Data	data	Real	4	

Write Variable:

```
sWN ALSNodalPoseGammaOpti <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSNodalPoseGammaOpti	String	21	Pose Estimation Angle Gamma of scanner position optimal
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ALSNodalPoseGammaOpti				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSNodalPoseGammaOpti	String	21	Pose Estimation Angle Gamma of scanner position optimal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSNodalPoseGammaOpti[ETX]
Read Variable Response:	[STX]sRA ALSNodalPoseGammaOpti 00000000[ETX]
Write Variable:	[STX]sWN ALSNodalPoseGammaOpti 00000000[ETX]
Write Variable Response:	[STX]sWA ALSNodalPoseGammaOpti[ETX]

2.37.18.11. Variable: NodalPoseXCoordOffset

The following section contains a detailed description of the variable NodalPoseXCoordOffset.

Variable Overview

Variable Name	Description
NodalPoseXCoordOffset	Pose Estimation X-coordinate of scanner position optimal

Communication Name	ALSNodalPoseXCoordOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1383
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -1000.0..10000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ALSNodalPoseXCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal

Read Variable Response:				
`sRA ALSNodalPoseXCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal
Variable Data	data	Real	4	

Write Variable:				
`sWN ALSNodalPoseXCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ALSNodalPoseXCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSNodalPoseXCoordOffset[ETX]`
Read Variable Response:	`[STX]sRA ALSNodalPoseXCoordOffset 00000000[ETX]`
Write Variable:	`[STX]sWN ALSNodalPoseXCoordOffset 00000000[ETX]`
Write Variable Response:	`[STX]sWA ALSNodalPoseXCoordOffset[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.12. Variable: NodalPoseYCoordOffset

The following section contains a detailed description of the variable NodalPoseYCoordOffset.

Variable Overview

Variable Name	Description
NodalPoseYCoordOffset	Pose Estimation Y-coordinate of scanner position optimal

Communication Name	ALSNodalPoseYCoordOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1384
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3000.0..3000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSNodalPoseYCoordOffset
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSNodalPoseYCoordOffset	String	24	Pose Estimation Y-coordinate of scanner position optimal

Read Variable Response:

```
sRA ALSNodalPoseYCoordOffset <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSNodalPoseYCoordOffset	String	24	Pose Estimation Y-coordinate of scanner position optimal
Variable Data	data	Real	4	

Write Variable:

```
sWN ALSNodalPoseYCoordOffset <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSNodalPoseYCoordOffset	String	24	Pose Estimation Y-coordinate of scanner position optimal
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ALSNodalPoseYCoordOffset				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSNodalPoseYCoordOffset	String	24	Pose Estimation Y-coordinate of scanner position optimal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSNodalPoseYCoordOffset[ETX]
Read Variable Response:	[STX]sRA ALSNodalPoseYCoordOffset 00000000[ETX]
Write Variable:	[STX]sWN ALSNodalPoseYCoordOffset 00000000[ETX]
Write Variable Response:	[STX]sWA ALSNodalPoseYCoordOffset[ETX]

2.37.18.13. Variable: NodalPoseZCoordOffset

The following section contains a detailed description of the variable NodalPoseZCoordOffset.

Variable Overview

Variable Name	Description
NodalPoseZCoordOffset	Pose Estimation Z-coordinate of scanner position optimal

Communication Name	ALSNodalPoseZCoordOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1385
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3500.0..3500.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ALSNodalPoseZCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSNodalPoseZCoordOffset	String	24	Pose Estimation Z-coordinate of scanner position optimal

Read Variable Response:				
`sRA ALSNodalPoseZCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSNodalPoseZCoordOffset	String	24	Pose Estimation Z-coordinate of scanner position optimal
Variable Data	data	Real	4	

Write Variable:				
`sWN ALSNodalPoseZCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSNodalPoseZCoordOffset	String	24	Pose Estimation Z-coordinate of scanner position optimal
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ALSNodalPoseZCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSNodalPoseZCoordOffset	String	24	Pose Estimation Z-coordinate of scanner position optimal

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSNodalPoseZCoordOffset[ETX]`
Read Variable Response:	`[STX]sRA ALSNodalPoseZCoordOffset 00000000[ETX]`
Write Variable:	`[STX]sWN ALSNodalPoseZCoordOffset 00000000[ETX]`
Write Variable Response:	`[STX]sWA ALSNodalPoseZCoordOffset[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.14. Variable: ExpNodalPoseAlphaOpti

The following section contains a detailed description of the variable ExpNodalPoseAlphaOpti.

Variable Overview

Variable Name	Description
ExpNodalPoseAlphaOpti	Pose Estimation Angle Alpha of scanner position optimal for expander

Communication Name	ALSExpNodalPoseAlphaOpti
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1386
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -7.0..7.0
Initialisation	0.0
Physical Unit	rad
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSExpNodalPoseAlphaOpti
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSExpNodalPoseAlphaOpti	String	24	Pose Estimation Angle Alpha of scanner position optimal for expander

Read Variable Response:

```
sRA ALSExpNodalPoseAlphaOpti <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSExpNodalPoseAlphaOpti	String	24	Pose Estimation Angle Alpha of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable:

```
sWN ALSExpNodalPoseAlphaOpti <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSExpNodalPoseAlphaOpti	String	24	Pose Estimation Angle Alpha of scanner position optimal for expander
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ALSExpNodalPoseAlphaOpti				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSExpNodalPoseAlphaOpti	String	24	Pose Estimation Angle Alpha of scanner position optimal for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSExpNodalPoseAlphaOpti[ETX]
Read Variable Response:	[STX]sRA ALSExpNodalPoseAlphaOpti 00000000[ETX]
Write Variable:	[STX]sWN ALSExpNodalPoseAlphaOpti 00000000[ETX]
Write Variable Response:	[STX]sWA ALSExpNodalPoseAlphaOpti[ETX]

2.37.18.15. Variable: ExpNodalPoseBetaOpti

The following section contains a detailed description of the variable ExpNodalPoseBetaOpti.

Variable Overview

Variable Name	Description
ExpNodalPoseBetaOpti	Pose Estimation Angle Beta of scanner position for expander

Communication Name	ALSExpNodalPoseBetaOpti
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1387
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -7.0..7.0
Initialisation	0.0
Physical Unit	rad
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ALSExpNodalPoseBetaOpti`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSExpNodalPoseBetaOpti	String	23	Pose Estimation Angle Beta of scanner position for expander

Read Variable Response:				
`sRA ALSExpNodalPoseBetaOpti <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSExpNodalPoseBetaOpti	String	23	Pose Estimation Angle Beta of scanner position for expander
Variable Data	data	Real	4	

Write Variable:				
`sWN ALSExpNodalPoseBetaOpti <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSExpNodalPoseBetaOpti	String	23	Pose Estimation Angle Beta of scanner position for expander
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ALSExpNodalPoseBetaOpti`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSExpNodalPoseBetaOpti	String	23	Pose Estimation Angle Beta of scanner position for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSExpNodalPoseBetaOpti[ETX]`
Read Variable Response:	`[STX]sRA ALSExpNodalPoseBetaOpti 00000000[ETX]`
Write Variable:	`[STX]sWN ALSExpNodalPoseBetaOpti 00000000[ETX]`
Write Variable Response:	`[STX]sWA ALSExpNodalPoseBetaOpti[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.16. Variable: ExpNodalPoseGammaOpti

The following section contains a detailed description of the variable ExpNodalPoseGammaOpti.

Variable Overview

Variable Name	Description
ExpNodalPoseGammaOpti	Pose Estimation Angle Gamma of scanner position optimal for expander

Communication Name	ALSExpNodalPoseGammaOpti
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1388
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -7.0..7.0
Initialisation	0.0
Physical Unit	rad
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSExpNodalPoseGammaOpti
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSExpNodalPoseGammaOpti	String	24	Pose Estimation Angle Gamma of scanner position optimal for expander

Read Variable Response:

```
sRA ALSExpNodalPoseGammaOpti <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSExpNodalPoseGammaOpti	String	24	Pose Estimation Angle Gamma of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable:

```
sWN ALSExpNodalPoseGammaOpti <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSExpNodalPoseGammaOpti	String	24	Pose Estimation Angle Gamma of scanner position optimal for expander
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ALSExpNodalPoseGammaOpti				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSExpNodalPoseGammaOpti	String	24	Pose Estimation Angle Gamma of scanner position optimal for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSExpNodalPoseGammaOpti[ETX]
Read Variable Response:	[STX]sRA ALSExpNodalPoseGammaOpti 00000000[ETX]
Write Variable:	[STX]sWN ALSExpNodalPoseGammaOpti 00000000[ETX]
Write Variable Response:	[STX]sWA ALSExpNodalPoseGammaOpti[ETX]

2.37.18.17. Variable: ExpNodalPoseXCoordOffset

The following section contains a detailed description of the variable ExpNodalPoseXCoordOffset.

Variable Overview

Variable Name	Description
ExpNodalPoseXCoordOffset	Pose Estimation X-coordinate of scanner position optimal for expander

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1389
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -1000.0..10000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ExpNodalPoseXCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ExpNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal for expander

Read Variable Response:				
`sRA ExpNodalPoseXCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ExpNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable:				
`sWN ExpNodalPoseXCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ExpNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ExpNodalPoseXCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ExpNodalPoseXCoordOffset	String	24	Pose Estimation X-coordinate of scanner position optimal for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ExpNodalPoseXCoordOffset[ETX]`
Read Variable Response:	`[STX]sRA ExpNodalPoseXCoordOffset 00000000[ETX]`
Write Variable:	`[STX]sWN ExpNodalPoseXCoordOffset 00000000[ETX]`
Write Variable Response:	`[STX]sWA ExpNodalPoseXCoordOffset[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.18. Variable: ExpNodalPoseYCoordOffset

The following section contains a detailed description of the variable ExpNodalPoseYCoordOffset.

Variable Overview

Variable Name	Description
ExpNodalPoseYCoordOffset	Pose Estimation Y-coordinate of scanner position optimal for expander

Communication Name	ALSExpNodalPoseYCoordOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1390
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3000.0..3000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ALSExpNodalPoseYCoordOffset
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSExpNodalPoseYCoordOffset	String	27	Pose Estimation Y-coordinate of scanner position optimal for expander

Read Variable Response:

```
sRA ALSExpNodalPoseYCoordOffset <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSExpNodalPoseYCoordOffset	String	27	Pose Estimation Y-coordinate of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable:

```
sWN ALSExpNodalPoseYCoordOffset <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSExpNodalPoseYCoordOffset	String	27	Pose Estimation Y-coordinate of scanner position optimal for expander
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ALSExpNodalPoseYCoordOffset				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSExpNodalPoseYCoordOffset	String	27	Pose Estimation Y-coordinate of scanner position optimal for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ALSExpNodalPoseYCoordOffset[ETX]
Read Variable Response:	[STX]sRA ALSExpNodalPoseYCoordOffset 00000000[ETX]
Write Variable:	[STX]sWN ALSExpNodalPoseYCoordOffset 00000000[ETX]
Write Variable Response:	[STX]sWA ALSExpNodalPoseYCoordOffset[ETX]

2.37.18.19. Variable: ExpNodalPoseZCoordOffset

The following section contains a detailed description of the variable ExpNodalPoseZCoordOffset.

Variable Overview

Variable Name	Description
ExpNodalPoseZCoordOffset	Pose Estimation Z-coordinate of scanner position optimal for expander

Communication Name	ALSExpNodalPoseZCoordOffset
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1391
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3500.0..3500.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ALSExpNodalPoseZCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ALSExpNodalPoseZCoordOffset	String	27	Pose Estimation Z-coordinate of scanner position optimal for expander

Read Variable Response:				
`sRA ALSExpNodalPoseZCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ALSExpNodalPoseZCoordOffset	String	27	Pose Estimation Z-coordinate of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable:				
`sWN ALSExpNodalPoseZCoordOffset <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ALSExpNodalPoseZCoordOffset	String	27	Pose Estimation Z-coordinate of scanner position optimal for expander
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ALSExpNodalPoseZCoordOffset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ALSExpNodalPoseZCoordOffset	String	27	Pose Estimation Z-coordinate of scanner position optimal for expander

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ALSExpNodalPoseZCoordOffset[ETX]`
Read Variable Response:	`[STX]sRA ALSExpNodalPoseZCoordOffset 00000000[ETX]`
Write Variable:	`[STX]sWN ALSExpNodalPoseZCoordOffset 00000000[ETX]`
Write Variable Response:	`[STX]sWA ALSExpNodalPoseZCoordOffset[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.20. Method: StartPoseEstimation

The following section contains a detailed description of the method StartPoseEstimation.

Method Overview

Method Name	Description
StartPoseEstimation	Begin pose estimation

Communication Name	mASLStartPoseEstimation
Sopas Index	134
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mASLStartPoseEstimation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASLStartPoseEstimation	String	23	Begin pose estimation

Method Return Value:				
`sAN mASLStartPoseEstimation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASLStartPoseEstimation	String	23	Begin pose estimation

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mASLStartPoseEstimation[ETX]`
Method Return Value:	`[STX]sAN mASLStartPoseEstimation[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.21. Method: StartPoseEstimationPanoramaHood1of2

The following section contains a detailed description of the method StartPoseEstimationPanoramaHood1of2.

Method Overview

Method Name	Description
StartPoseEstimationPanoramaHood1of2	Begin pose estimation for panorama Hood step 1

Communication Name	mASLStartPoseEstimationPanorama1of2
Sopas Index	135
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mASLStartPoseEstimationPanorama1of2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASLStartPoseEstimationPanorama1of2	String	35	Begin pose estimation for panorama Hood step 1

Method Return Value:				
`sAN mASLStartPoseEstimationPanorama1of2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASLStartPoseEstimationPanorama1of2	String	35	Begin pose estimation for panorama Hood step 1

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mASLStartPoseEstimationPanorama1of2[ETX]`
Method Return Value:	`[STX]sAN mASLStartPoseEstimationPanorama1of2[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.22. Method: StartPoseEstimationPanoramaHood2of2

The following section contains a detailed description of the method StartPoseEstimationPanoramaHood2of2.

Method Overview

Method Name	Description
StartPoseEstimationPanoramaHood2of2	Begin pose estimation for panorama Hood step 2

Communication Name	mASLStartPoseEstimationPanorama2of2
Sopas Index	136
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mASLStartPoseEstimationPanorama2of2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASLStartPoseEstimationPanorama2of2	String	35	Begin pose estimation for panorama Hood step 2

Method Return Value:				
`sAN mASLStartPoseEstimationPanorama2of2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASLStartPoseEstimationPanorama2of2	String	35	Begin pose estimation for panorama Hood step 2

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mASLStartPoseEstimationPanorama2of2[ETX]`
Method Return Value:	`[STX]sAN mASLStartPoseEstimationPanorama2of2[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.23. Method: CancelPoseEstimation

The following section contains a detailed description of the method CancelPoseEstimation.

Method Overview

Method Name	Description
CancelPoseEstimation	Cancel pose estimation and reset values to previous state

Communication Name	mASLCancelPoseEstimation
Sopas Index	137
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mASLCancelPoseEstimation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASLCancelPoseEstimation	String	24	Cancel pose estimation and reset values to previous state

Method Return Value:				
`sAN mASLCancelPoseEstimation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASLCancelPoseEstimation	String	24	Cancel pose estimation and reset values to previous state

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mASLCancelPoseEstimation[ETX]`
Method Return Value:	`[STX]sAN mASLCancelPoseEstimation[ETX]`

© SICK AG - Germany - All rights reserved

2.37.18.24. Method: FinishPoseEstimation

The following section contains a detailed description of the method FinishPoseEstimation.

Method Overview

Method Name	Description
FinishPoseEstimation	Save the results of pose estimation

Communication Name	mASLCFinishPoseEstimation
Sopas Index	138
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mASLCFinishPoseEstimation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mASLCFinishPoseEstimation	String	25	Save the results of pose estimation

Method Return Value:				
`sAN mASLCFinishPoseEstimation`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mASLCFinishPoseEstimation	String	25	Save the results of pose estimation

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mASLCFinishPoseEstimation[ETX]`
Method Return Value:	`[STX]sAN mASLCFinishPoseEstimation[ETX]`

© SICK AG - Germany - All rights reserved

2.37.19. Group: DemoMode

2.37.19.1. Variable: DemoModeROI

The following section contains a detailed description of the variable DemoModeROI.

Variable Overview

Variable Name	Description
DemoModeROI	Region of interest for the demo mode. Range values are given in pixels.

Communication Name	DMRoi
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1392
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
MinX		
	UInt	
	Value Range	0..2048
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0
MaxX		
	UInt	
	Value Range	0..2048
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0
MinY		
	UInt	
	Value Range	0..2048
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0
MaxY		
	UInt	
	Value Range	0..2048
	Initialisation	0
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DMRoi`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DMRoi	String	5	Region of interest for the demo mode. Range values are given in pixels.

Read Variable Response:				
`sRA DMRoi <MinX> <MaxX> <MinY> <MaxY>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DMRoi	String	5	Region of interest for the demo mode. Range values are given in pixels.
Variable Data 1	MinX	UInt	2	
Variable Data 2	MaxX	UInt	2	
Variable Data 3	MinY	UInt	2	
Variable Data 4	MaxY	UInt	2	

Write Variable:				
`sWN DMRoi <MinX> <MaxX> <MinY> <MaxY>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DMRoi	String	5	Region of interest for the demo mode. Range values are given in pixels.
Variable Data 1	MinX	UInt	2	
Variable Data 2	MaxX	UInt	2	
Variable Data 3	MinY	UInt	2	
Variable Data 4	MaxY	UInt	2	

Write Variable Response:				
`sWA DMRoi`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DMRoi	String	5	Region of interest for the demo mode. Range values are given in pixels.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DMRoi[ETX]`
Read Variable Response:	`[STX]sRA DMRoi 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DMRoi 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DMRoi[ETX]`

© SICK AG - Germany - All rights reserved

2.37.19.2. Variable: DemoModePDF417

The following section contains a detailed description of the variable DemoModePDF417.

Variable Overview

Variable Name	Description
DemoModePDF417	Enables PDF417 decoding in demo mode

Communication Name	DMPDF417
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1393
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DMPDF417
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DMPDF417	String	8	Enables PDF417 decoding in demo mode

Read Variable Response:

```
sRA DMPDF417 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DMPDF417	String	8	Enables PDF417 decoding in demo mode
Variable Data	data	Bool	1	

Write Variable:

```
sWN DMPDF417 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DMPDF417	String	8	Enables PDF417 decoding in demo mode
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DMPDF417
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DMPDF417	String	8	Enables PDF417 decoding in demo mode

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DMPDF417[ETX]`
Read Variable Response:	`[STX]sRA DMPDF417 0[ETX]`
Write Variable:	`[STX]sWN DMPDF417 0[ETX]`
Write Variable Response:	`[STX]sWA DMPDF417[ETX]`

2.37.19.3. Variable: DemoModeMaxiCode

The following section contains a detailed description of the variable DemoModeMaxiCode.

Variable Overview

Variable Name	Description
DemoModeMaxiCode	Enables Maxi Code decoding in demo mode

Communication Name	DMMaxi
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1394
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DMMaxi
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DMMaxi	String	6	Enables Maxi Code decoding in demo mode

Read Variable Response:

```
sRA DMMaxi <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DMMaxi	String	6	Enables Maxi Code decoding in demo mode
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DMMaxi <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DMMaxi	String	6	Enables Maxi Code decoding in demo mode
Variable Data	data	Bool	1	

Write Variable Response:				
sWA DMMaxi				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DMMaxi	String	6	Enables Maxi Code decoding in demo mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DMMaxi[ETX]
Read Variable Response:	[STX]sRA DMMaxi 0[ETX]
Write Variable:	[STX]sWN DMMaxi 0[ETX]
Write Variable Response:	[STX]sWA DMMaxi[ETX]

2.37.19.4. Variable: DemoModeDPMDataMatrix

The following section contains a detailed description of the variable DemoModeDPMDataMatrix.

Variable Overview

Variable Name	Description
DemoModeDPMDataMatrix	Enables DPM Data Matrix decoding in demo mode

Communication Name	DMDPMDmx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1395
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DMDPMDmx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DMDPMDmx	String	8	Enables DPM Data Matrix decoding in demo mode

Read Variable Response:				
`sRA DMDPMDmx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DMDPMDmx	String	8	Enables DPM Data Matrix decoding in demo mode
Variable Data	data	Bool	1	

Write Variable:				
`sWN DMDPMDmx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DMDPMDmx	String	8	Enables DPM Data Matrix decoding in demo mode
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DMDPMDmx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DMDPMDmx	String	8	Enables DPM Data Matrix decoding in demo mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DMDPMDmx[ETX]`
Read Variable Response:	`[STX]sRA DMDPMDmx 1[ETX]`
Write Variable:	`[STX]sWN DMDPMDmx 1[ETX]`
Write Variable Response:	`[STX]sWA DMDPMDmx[ETX]`

© SICK AG - Germany - All rights reserved

2.37.19.5. Method: StartDemoMode

The following section contains a detailed description of the method StartDemoMode.

Method Overview

Method Name
StartDemoMode

Communication Name	mDMStart
Sopas Index	139
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mDMStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDMStart	String	8	

Method Return Value:				
`sAN mDMStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDMStart	String	8	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDMStart[ETX]`
Method Return Value:	`[STX]sAN mDMStart[ETX]`

© SICK AG - Germany - All rights reserved

2.37.19.6. Method: CancelDemoMode

The following section contains a detailed description of the method CancelDemoMode.

Method Overview

Method Name
CancelDemoMode

Communication Name	mDMCancel
Sopas Index	140
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mDMCancel`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDMCancel	String	9	

Method Return Value:				
`sAN mDMCancel`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDMCancel	String	9	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDMCancel[ETX]`
Method Return Value:	`[STX]sAN mDMCancel[ETX]`

© SICK AG - Germany - All rights reserved

2.37.19.7. Method: FinishDemoMode

The following section contains a detailed description of the method FinishDemoMode.

Method Overview

Method Name
FinishDemoMode

Communication Name	mDMFinish
Sopas Index	141
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mDMFinish`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDMFinish	String	9	

Method Return Value:				
`sAN mDMFinish`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDMFinish	String	9	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDMFinish[ETX]`
Method Return Value:	`[STX]sAN mDMFinish[ETX]`

© SICK AG - Germany - All rights reserved

2.37.20. Group: Increment

2.37.20.1. Variable: IncrSource

The following section contains a detailed description of the variable IncrSource.

Variable Overview

Variable Name	Description
IncrSource	Source of system increment

Communication Name	ICsrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1397
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_SOPAS_CMD	
	Value	Name	Description
	0	TX_FIX_VELOCITY	
	1	TX_SENSOR1	
	2	TX_SENSOR2	
	3	TX_CAN_1	
	4	TX_SOPAS_CMD	

Variable Telegram Syntax

Read Variable:

```
sRN ICsrc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ICsrc	String	5	Source of system increment

Read Variable Response:

```
sRA ICsrc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ICsrc	String	5	Source of system increment
Variable Data	data	Enum8	1	

Write Variable:

```
sWN ICsrc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ICsrc	String	5	Source of system increment
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ICsrc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ICsrc	String	5	Source of system increment

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ICsrc[ETX]
Read Variable Response:	[STX]sRA ICsrc 4[ETX]
Write Variable:	[STX]sWN ICsrc 4[ETX]
Write Variable Response:	[STX]sWA ICsrc[ETX]

2.37.20.2. Variable: IncrDistance

The following section contains a detailed description of the variable IncrDistance.

Variable Overview

Variable Name	Description
IncrDistance	Distance per system increment

Communication Name	ICdist
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1398
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.01..100.0
Initialisation	10.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ICdist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ICdist	String	6	Distance per system increment

Read Variable Response:				
`sRA ICdist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ICdist	String	6	Distance per system increment
Variable Data	data	Real	4	

Write Variable:				
`sWN ICdist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ICdist	String	6	Distance per system increment
Variable Data	data	Real	4	

Write Variable Response:				
`sWA ICdist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ICdist	String	6	Distance per system increment

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ICdist[ETX]`
Read Variable Response:	`[STX]sRA ICdist 41200000[ETX]`
Write Variable:	`[STX]sWN ICdist 41200000[ETX]`
Write Variable Response:	`[STX]sWA ICdist[ETX]`

© SICK AG - Germany - All rights reserved

2.37.20.3. Variable: IncrFixVelocity

The following section contains a detailed description of the variable IncrFixVelocity.

Variable Overview

Variable Name	Description
IncrFixVelocity	If fix velocity is selected

Communication Name	ICFixVel
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1399
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..10.0
Initialisation	0.0
Physical Unit	m/s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ICFixVel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ICFixVel	String	8	If fix velocity is selected

Read Variable Response:

```
sRA ICFixVel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ICFixVel	String	8	If fix velocity is selected
Variable Data	data	Real	4	

Write Variable:

```
sWN ICFixVel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ICFixVel	String	8	If fix velocity is selected
Variable Data	data	Real	4	

Write Variable Response:

```
sWA ICFixVel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ICFixVel	String	8	If fix velocity is selected

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ICFixVel[ETX]`
Read Variable Response:	`[STX]sRA ICFixVel 00000000[ETX]`
Write Variable:	`[STX]sWN ICFixVel 00000000[ETX]`
Write Variable Response:	`[STX]sWA ICFixVel[ETX]`

2.37.20.4. Variable: IncrDistribute

The following section contains a detailed description of the variable IncrDistribute.

Variable Overview

Variable Name	Description
IncrDistribute	Increment distribution on CAN-Bus

Communication Name	ICincdist
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1400
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DISABLED	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_CAN_1	

Variable Telegram Syntax

Read Variable:				
`sRN ICincdist`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ICincdist	String	9	Increment distribution on CAN-Bus

Read Variable Response:				
`sRA ICincdist <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ICincdist	String	9	Increment distribution on CAN-Bus
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN ICincdist <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ICincdist	String	9	Increment distribution on CAN-Bus
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA ICincdist				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ICincdist	String	9	Increment distribution on CAN-Bus

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ICincdist[ETX]
Read Variable Response:	[STX]sRA ICincdist 0[ETX]
Write Variable:	[STX]sWN ICincdist 0[ETX]
Write Variable Response:	[STX]sWA ICincdist[ETX]

2.37.20.5. Method: SetIncrement

The following section contains a detailed description of the method SetIncrement.

Method Overview

Method Name	Description
SetIncrement	Sets the increment if a value larger than 0 is given, or increments it by 1 if 0 is given.

Communication Name	mSetInc
Sopas Index	142
Invocation Access	Always

Parameters	
IncVal	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN mSetInc <IncVal>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mSetInc	String	7	Sets the increment if a value larger than 0 is given, or increments it by 1 if 0 is given.
Parameter 1	IncVal	UDInt	4	

Method Return Value:				
`sAN mSetInc <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mSetInc	String	7	Sets the increment if a value larger than 0 is given, or increments it by 1 if 0 is given.
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mSetInc 0[ETX]`
Method Return Value:	`[STX]sAN mSetInc 0[ETX]`

2.37.20.6. Method: GetIncrement

The following section contains a detailed description of the method GetIncrement.

Method Overview

Method Name	Description
GetIncrement	Gets the current increment.

Communication Name	mGetInc
Sopas Index	143
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Return Values	
IncVal	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mGetInc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mGetInc	String	7	Gets the current increment.

Method Return Value:				
`sAN mGetInc <IncVal>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mGetInc	String	7	Gets the current increment.
Return Value 1	IncVal	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mGetInc[ETX]`
Method Return Value:	`[STX]sAN mGetInc 0[ETX]`

2.37.20.7. Method: GetIncrementMM

The following section contains a detailed description of the method GetIncrementMM.

Method Overview

Method Name	Description
GetIncrementMM	Gets the current increment in millimeter

Communication Name	mGetIncMM
Sopas Index	144
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Return Values	
IncValMM	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mGetIncMM
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mGetIncMM	String	9	Gets the current increment in millimeter

Method Return Value:

```
sAN mGetIncMM <IncValMM>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mGetIncMM	String	9	Gets the current increment in millimeter
Return Value 1	IncValMM	UDInt	4	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mGetIncMM[ETX]`
Method Return Value:	`[STX]sAN mGetIncMM 0[ETX]`

© SICK AG - Germany - All rights reserved

2.37.21. Group: TriggerControl

2.37.21.1. Variable: TrigStopCondition1Ext

The following section contains a detailed description of the variable TrigStopCondition1Ext.

Variable Overview

Variable Name	Description
TrigStopCondition1Ext	Stop condition 1 of trigger Evcnd extension

Communication Name	TCStopCond1Ext
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1405
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN TCStopCond1Ext
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopCond1Ext	String	14	Stop condition 1 of trigger Evcnd extension

Read Variable Response:

```
sRA TCStopCond1Ext <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopCond1Ext	String	14	Stop condition 1 of trigger Evcnd extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN TCStopCond1Ext <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopCond1Ext	String	14	Stop condition 1 of trigger Evcnd extension

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN TCStopCond1Ext <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA TCStopCond1Ext				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopCond1Ext	String	14	Stop condition 1 of trigger Evcnd extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCStopCond1Ext[ETX]
Read Variable Response:	[STX]sRA TCStopCond1Ext 0 0[ETX]
Write Variable:	[STX]sWN TCStopCond1Ext 0 0[ETX]
Write Variable Response:	[STX]sWA TCStopCond1Ext[ETX]

2.37.21.2. Variable: TrigStopCondition2Ext

The following section contains a detailed description of the variable TrigStopCondition2Ext.

Variable Overview

Variable Name	Description
TrigStopCondition2Ext	Stop condition 2 of trigger Evcnd extension

Communication Name	TCStopCond2Ext
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1406
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..18
	Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCStopCond2Ext`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopCond2Ext	String	14	Stop condition 2 of trigger Evcnd extension

Read Variable Response:				
`sRA TCStopCond2Ext <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopCond2Ext	String	14	Stop condition 2 of trigger Evcnd extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN TCStopCond2Ext <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopCond2Ext	String	14	Stop condition 2 of trigger Evcnd extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA TCStopCond2Ext`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopCond2Ext	String	14	Stop condition 2 of trigger Evcnd extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStopCond2Ext[ETX]`
Read Variable Response:	`[STX]sRA TCStopCond2Ext 0 0[ETX]`
Write Variable:	`[STX]sWN TCStopCond2Ext 0 0[ETX]`
Write Variable Response:	`[STX]sWA TCStopCond2Ext[ETX]`

© SICK AG - Germany - All rights reserved

2.37.21.3. Variable: TrigStopCondition3Ext

The following section contains a detailed description of the variable TrigStopCondition3Ext.

Variable Overview

Variable Name	Description
TrigStopCondition3Ext	Stop condition 3 of trigger Evcnd extension

Communication Name	TCStopCond3Ext
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1407
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN TCStopCond3Ext
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopCond3Ext	String	14	Stop condition 3 of trigger Evcnd extension

Read Variable Response:

```
sRA TCStopCond3Ext <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopCond3Ext	String	14	Stop condition 3 of trigger Evcnd extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN TCStopCond3Ext <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopCond3Ext	String	14	Stop condition 3 of trigger Evcnd extension
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TCStopCond3Ext				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopCond3Ext	String	14	Stop condition 3 of trigger Evcnd extension

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCStopCond3Ext[ETX]
Read Variable Response:	[STX]sRA TCStopCond3Ext 0 0[ETX]
Write Variable:	[STX]sWN TCStopCond3Ext 0 0[ETX]
Write Variable Response:	[STX]sWA TCStopCond3Ext[ETX]

2.37.21.4. Variable: TriggerEcho

The following section contains a detailed description of the variable TriggerEcho.

Variable Overview

Variable Name	Description
TriggerEcho	Echo on/off for 21/22 triggers and user def. trigger cmd

Communication Name	SnglChrTrgEcho
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1408
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SnglChrTrgEcho`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SnglChrTrgEcho	String	14	Echo on/off for 21/22 triggers and user def. trigger cmd

Read Variable Response:				
`sRA SnglChrTrgEcho <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SnglChrTrgEcho	String	14	Echo on/off for 21/22 triggers and user def. trigger cmd
Variable Data	data	Bool	1	

Write Variable:				
`sWN SnglChrTrgEcho <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SnglChrTrgEcho	String	14	Echo on/off for 21/22 triggers and user def. trigger cmd
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA SnglChrTrgEcho`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SnglChrTrgEcho	String	14	Echo on/off for 21/22 triggers and user def. trigger cmd

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SnglChrTrgEcho[ETX]`
Read Variable Response:	`[STX]sRA SnglChrTrgEcho 0[ETX]`
Write Variable:	`[STX]sWN SnglChrTrgEcho 0[ETX]`
Write Variable Response:	`[STX]sWA SnglChrTrgEcho[ETX]`

© SICK AG - Germany - All rights reserved

2.37.21.5. Variable: UserDefTriggerStartCmd

The following section contains a detailed description of the variable UserDefTriggerStartCmd.

Variable Overview

Variable Name	Description
UserDefTriggerStartCmd	User defined trigger start command string

Communication Name	UsrDfCmdTrgStart
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1409
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..26
Initialisation	\x0221\x03

Variable Telegram Syntax

Read Variable:

```
sRN UsrDfCmdTrgStart
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	UsrDfCmdTrgStart	String	16	User defined trigger start command string

Read Variable Response:

```
sRA UsrDfCmdTrgStart <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	UsrDfCmdTrgStart	String	16	User defined trigger start command string
Variable Data	data	FlexString	26	

Write Variable:

```
sWN UsrDfCmdTrgStart <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	UsrDfCmdTrgStart	String	16	User defined trigger start command string
Variable Data	data	FlexString	26	

Write Variable Response:

```
sWA UsrDfCmdTrgStart
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	UsrDfCmdTrgStart	String	16	User defined trigger start command string

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN UsrDfCmdTrgStart[ETX]`
Read Variable Response:	`[STX]sRA UsrDfCmdTrgStart A \x0221\x03[ETX]`
Write Variable:	`[STX]sWN UsrDfCmdTrgStart A \x0221\x03[ETX]`
Write Variable Response:	`[STX]sWA UsrDfCmdTrgStart[ETX]`

2.37.21.6. Variable: UserDefTriggerStopCmd

The following section contains a detailed description of the variable UserDefTriggerStopCmd.

Variable Overview

Variable Name	Description
UserDefTriggerStopCmd	User defined trigger stop command string

Communication Name	UsrDfCmdTrgStop
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1410
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..26
Initialisation	\x0222\x03

Variable Telegram Syntax

Read Variable:				
`sRN UsrDfCmdTrgStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	UsrDfCmdTrgStop	String	15	User defined trigger stop command string

Read Variable Response:				
`sRA UsrDfCmdTrgStop <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	UsrDfCmdTrgStop	String	15	User defined trigger stop command string
Variable Data	data	FlexString	26	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN UsrDfCmdTrgStop <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	UsrDfCmdTrgStop	String	15	User defined trigger stop command string
Variable Data	data	FlexString	26	

Write Variable Response:				
sWA UsrDfCmdTrgStop				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	UsrDfCmdTrgStop	String	15	User defined trigger stop command string

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN UsrDfCmdTrgStop[ETX]
Read Variable Response:	[STX]sRA UsrDfCmdTrgStop A \x0222\x03[ETX]
Write Variable:	[STX]sWN UsrDfCmdTrgStop A \x0222\x03[ETX]
Write Variable Response:	[STX]sWA UsrDfCmdTrgStop[ETX]

2.37.21.7. Variable: TrigStartCondition

The following section contains a detailed description of the variable TrigStartCondition.

Variable Overview

Variable Name	Description
TrigStartCondition	Start condition of object trigger

Communication Name	TCStartCond
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1401
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_FREE_RUNNING	
	Value	Name	Description
	4	TX_COMMAND	
	8	TX_FIELDBUS	
	9	TX_FREE_RUNNING	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCStartCond`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStartCond	String	11	Start condition of object trigger

Read Variable Response:				
`sRA TCStartCond <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStartCond	String	11	Start condition of object trigger
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TCStartCond <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStartCond	String	11	Start condition of object trigger
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA TCStartCond`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStartCond	String	11	Start condition of object trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStartCond[ETX]`
Read Variable Response:	`[STX]sRA TCStartCond 9[ETX]`
Write Variable:	`[STX]sWN TCStartCond 9[ETX]`
Write Variable Response:	`[STX]sWA TCStartCond[ETX]`

© SICK AG - Germany - All rights reserved

2.37.21.8. Variable: TrigStopCondition2

The following section contains a detailed description of the variable TrigStopCondition2.

Variable Overview

Variable Name	Description
TrigStopCondition2	Stop condition 1 of object trigger

Communication Name	TCStopCond2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1403
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NOT_DEFINED	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_REL_2_START	
	6	TX_COMMAND	
	8	TX_GOOD_READ	

Variable Telegram Syntax

Read Variable:

```
sRN TCStopCond2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopCond2	String	11	Stop condition 1 of object trigger

Read Variable Response:

```
sRA TCStopCond2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopCond2	String	11	Stop condition 1 of object trigger
Variable Data	data	Enum8	1	

Write Variable:

```
sWN TCStopCond2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopCond2	String	11	Stop condition 1 of object trigger
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TCStopCond2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopCond2	String	11	Stop condition 1 of object trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCStopCond2[ETX]
Read Variable Response:	[STX]sRA TCStopCond2 0[ETX]
Write Variable:	[STX]sWN TCStopCond2 0[ETX]
Write Variable Response:	[STX]sWA TCStopCond2[ETX]

2.37.21.9. Variable: TrigStopCondition1

The following section contains a detailed description of the variable TrigStopCondition1.

Variable Overview

Variable Name	Description
TrigStopCondition1	Stop condition 1 of object trigger

Communication Name	TCStopCond1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1402
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_REL_2_START	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_REL_2_START	
	6	TX_COMMAND	
	8	TX_GOOD_READ	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN TCStopCond1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopCond1	String	11	Stop condition 1 of object trigger

Read Variable Response:				
`sRA TCStopCond1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopCond1	String	11	Stop condition 1 of object trigger
Variable Data	data	Enum8	1	

Write Variable:				
`sWN TCStopCond1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopCond1	String	11	Stop condition 1 of object trigger
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA TCStopCond1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopCond1	String	11	Stop condition 1 of object trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN TCStopCond1[ETX]`
Read Variable Response:	`[STX]sRA TCStopCond1 1[ETX]`
Write Variable:	`[STX]sWN TCStopCond1 1[ETX]`
Write Variable Response:	`[STX]sWA TCStopCond1[ETX]`

© SICK AG - Germany - All rights reserved

2.37.21.10. Variable: TrigStopCondition3

The following section contains a detailed description of the variable TrigStopCondition3.

Variable Overview

Variable Name	Description
TrigStopCondition3	Stop condition 1 of object trigger

Communication Name	TCStopCond3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1404
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NOT_DEFINED	
	Value	Name	Description
	0	TX_NOT_DEFINED	
	1	TX_REL_2_START	
	6	TX_COMMAND	
	8	TX_GOOD_READ	

Variable Telegram Syntax

Read Variable:

```
sRN TCStopCond3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	TCStopCond3	String	11	Stop condition 1 of object trigger

Read Variable Response:

```
sRA TCStopCond3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	TCStopCond3	String	11	Stop condition 1 of object trigger
Variable Data	data	Enum8	1	

Write Variable:

```
sWN TCStopCond3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	TCStopCond3	String	11	Stop condition 1 of object trigger
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA TCStopCond3				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	TCStopCond3	String	11	Stop condition 1 of object trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN TCStopCond3[ETX]
Read Variable Response:	[STX]sRA TCStopCond3 0[ETX]
Write Variable:	[STX]sWN TCStopCond3 0[ETX]
Write Variable Response:	[STX]sWA TCStopCond3[ETX]

2.37.21.11. Method: DoReadingGateDiag

The following section contains a detailed description of the method DoReadingGateDiag.

Method Overview

Method Name	Description
DoReadingGateDiag	executes a reading gate for the given number of scans and evaluates the result afterwards (comparable to obsolete command 2TT)

Communication Name	mTCdogatediag
Sopas Index	145
Invocation Access	Always

Parameters		
NbrScans		
	UDInt	
	Value Range	1..100000
	Initialisation	100
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCdogatediag <NbrScans>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCdogatediag	String	13	executes a reading gate for the given number of scans and evaluates the result afterwards (comparable to obsolete command 2TT)
Parameter 1	NbrScans	UDInt	4	

Method Return Value:				
sAN mTCdogatediag				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCdogatediag	String	13	executes a reading gate for the given number of scans and evaluates the result afterwards (comparable to obsolete command 2TT)

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCdogatediag 64[ETX]
Method Return Value:	[STX]sAN mTCdogatediag[ETX]

2.37.21.12. Method: SetDeviceIdle

The following section contains a detailed description of the method SetDeviceIdle.

Method Overview

Method Name	Description
SetDeviceIdle	sets the device idle if parameter is TRUE

Communication Name	mTCsetidle
Sopas Index	146
Invocation Access	Always

Parameters	
GoIdle	
Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mTCsetidle <GoIdle>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCsetidle	String	10	sets the device idle if parameter is TRUE
Parameter 1	GoIdle	Bool	1	

Method Return Value:				
`sAN mTCsetidle`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCsetidle	String	10	sets the device idle if parameter is TRUE

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mTCsetidle 0[ETX]`
Method Return Value:	`[STX]sAN mTCsetidle[ETX]`

2.37.21.13. Method: StartPercentageEvaluation

The following section contains a detailed description of the method StartPercentageEvaluation.

Method Overview

Method Name	Description
StartPercentageEvaluation	starts the percentage evaluation

Communication Name	mTCstrtperc
Sopas Index	147
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCstrtperc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCstrtperc	String	11	starts the percentage evaluation

Method Return Value:				
sAN mTCstrtperc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCstrtperc	String	11	starts the percentage evaluation

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCstrtperc[ETX]
Method Return Value:	[STX]sAN mTCstrtperc[ETX]

2.37.21.14. Method: StopPercentageEvaluation

The following section contains a detailed description of the method StopPercentageEvaluation.

Method Overview

Method Name	Description
StopPercentageEvaluation	stops the percentage evaluation

Communication Name	mTCstpperc
Sopas Index	148
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mTCstpperc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTCstpperc	String	10	stops the percentage evaluation

Method Return Value:				
sAN mTCstpperc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTCstpperc	String	10	stops the percentage evaluation

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mTCstpperc[ETX]
Method Return Value:	[STX]sAN mTCstpperc[ETX]

© SICK AG - Germany - All rights reserved

2.37.22. Group: DecodingGeneral

2.37.22.1. Variable: DecodingTimeOutput

The following section contains a detailed description of the variable DecodingTimeOutput.

Variable Overview

Variable Name	Description
DecodingTimeOutput	Flag to let the decoders print their decoding time to the diagnosis xml

Communication Name	DCTimeOutput
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1418
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCTimeOutput
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCTimeOutput	String	12	Flag to let the decoders print their decoding time to the diagnosis xml

Read Variable Response:

```
sRA DCTimeOutput <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCTimeOutput	String	12	Flag to let the decoders print their decoding time to the diagnosis xml
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCTimeOutput <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCTimeOutput	String	12	Flag to let the decoders print their decoding time to the diagnosis xml
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCTimeOutput				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCTimeOutput	String	12	Flag to let the decoders print their decoding time to the diagnosis xml

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCTimeOutput[ETX]
Read Variable Response:	[STX]sRA DCTimeOutput 0[ETX]
Write Variable:	[STX]sWN DCTimeOutput 0[ETX]
Write Variable Response:	[STX]sWA DCTimeOutput[ETX]

2.37.22.2. Variable: EnableNciiForEveryNoReadImage

The following section contains a detailed description of the variable EnableNciiForEveryNoReadImage.

Variable Overview

Variable Name	Description
EnableNciiForEveryNoReadImage	Always generate a NCII code when no other code was found in an image (for Freerunning)

Communication Name	DCEnNoreadCo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1439
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCEnNoreadCo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCEnNoreadCo	String	12	Always generate a NCII code when no other code was found in an image (for Freerunning)

Read Variable Response:				
`sRA DCEnNoreadCo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCEnNoreadCo	String	12	Always generate a NCII code when no other code was found in an image (for Freerunning)
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCEnNoreadCo <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCEnNoreadCo	String	12	Always generate a NCII code when no other code was found in an image (for Freerunning)
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCEnNoreadCo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCEnNoreadCo	String	12	Always generate a NCII code when no other code was found in an image (for Freerunning)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCEnNoreadCo[ETX]`
Read Variable Response:	`[STX]sRA DCEnNoreadCo 0[ETX]`
Write Variable:	`[STX]sWN DCEnNoreadCo 0[ETX]`
Write Variable Response:	`[STX]sWA DCEnNoreadCo[ETX]`

© SICK AG - Germany - All rights reserved

2.37.22.3. Variable: CodeDirection

The following section contains a detailed description of the variable CodeDirection.

Variable Overview

Variable Name	Description
CodeDirection	'Direction' means mirrored or non-mirrored here

Communication Name	DCGDirection
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1416
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_FORWARDS	
	Value	Name	Description
	0	TX_FORWARDS	
	1	TX_REVERSE	
	2	TX_BOTH	

Variable Telegram Syntax

Read Variable:

```
sRN DCGDirection
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGDirection	String	12	'Direction' means mirrored or non-mirrored here

Read Variable Response:

```
sRA DCGDirection <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGDirection	String	12	'Direction' means mirrored or non-mirrored here
Variable Data	data	Enum8	1	

Write Variable:

```
sWN DCGDirection <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGDirection	String	12	'Direction' means mirrored or non-mirrored here
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA DCGDirection
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCGDirection				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCGDirection	String	12	'Direction' means mirrored or non-mirrored here

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCGDirection[ETX]
Read Variable Response:	[STX]sRA DCGDirection 0[ETX]
Write Variable:	[STX]sWN DCGDirection 0[ETX]
Write Variable Response:	[STX]sWA DCGDirection[ETX]

© SICK AG - Germany - All rights reserved

2.37.23. Group: Decoding1DExtensions

2.37.23.1. Variable: EnableLineFeedMode

The following section contains a detailed description of the variable EnableLineFeedMode.

Variable Overview

Variable Name
EnableLineFeedMode

Communication Name	D1DEXEnaLineFeedMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1443
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN D1DEXEnaLineFeedMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXEnaLineFeedMode	String	20	

Read Variable Response:

```
sRA D1DEXEnaLineFeedMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXEnaLineFeedMode	String	20	
Variable Data	data	Bool	1	

Write Variable:

```
sWN D1DEXEnaLineFeedMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXEnaLineFeedMode	String	20	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA D1DEXEnaLineFeedMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA D1DEXEnaLineFeedMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	D1DEXEnaLineFeedMode	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN D1DEXEnaLineFeedMode[ETX]
Read Variable Response:	[STX]sRA D1DEXEnaLineFeedMode 0[ETX]
Write Variable:	[STX]sWN D1DEXEnaLineFeedMode 0[ETX]
Write Variable Response:	[STX]sWA D1DEXEnaLineFeedMode[ETX]

2.37.23.2. Variable: LineFeedModeHorizontalScans

The following section contains a detailed description of the variable LineFeedModeHorizontalScans.

Variable Overview

Variable Name
LineFeedModeHorizontalScans

Communication Name	D1DEXLineFeedModeHorizontalScans
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1444
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN D1DEXLineFeedModeHorizontalScans`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXLineFeedModeHorizontal Scans	String	32	

Read Variable Response:				
`sRA D1DEXLineFeedModeHorizontalScans <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXLineFeedModeHorizontal Scans	String	32	
Variable Data	data	Bool	1	

Write Variable:				
`sWN D1DEXLineFeedModeHorizontalScans <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXLineFeedModeHorizontal Scans	String	32	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA D1DEXLineFeedModeHorizontalScans`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXLineFeedModeHorizontal Scans	String	32	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D1DEXLineFeedModeHorizontalScans[ETX]`
Read Variable Response:	`[STX]sRA D1DEXLineFeedModeHorizontalScans 1[ETX]`
Write Variable:	`[STX]sWN D1DEXLineFeedModeHorizontalScans 1[ETX]`
Write Variable Response:	`[STX]sWA D1DEXLineFeedModeHorizontalScans[ETX]`

© SICK AG - Germany - All rights reserved

2.37.23.3. Variable: LineFeedModeNumScansInImage

The following section contains a detailed description of the variable LineFeedModeNumScansInImage.

Variable Overview

Variable Name
LineFeedModeNumScansInImage

Communication Name	D1DEXLineFeedModeNumScansInImg
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1445
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..100
Initialisation	10
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN D1DEXLineFeedModeNumScansInImg
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXLineFeedModeNumScansInImg	String	30	

Read Variable Response:

```
sRA D1DEXLineFeedModeNumScansInImg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXLineFeedModeNumScansInImg	String	30	
Variable Data	data	UInt	2	

Write Variable:

```
sWN D1DEXLineFeedModeNumScansInImg <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXLineFeedModeNumScansInImg	String	30	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA D1DEXLineFeedModeNumScansInImg				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXLineFeedModeNumScansInImg	String	30	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN D1DEXLineFeedModeNumScansInImg[ETX]
Read Variable Response:	[STX]sRA D1DEXLineFeedModeNumScansInImg A[ETX]
Write Variable:	[STX]sWN D1DEXLineFeedModeNumScansInImg A[ETX]
Write Variable Response:	[STX]sWA D1DEXLineFeedModeNumScansInImg[ETX]

2.37.23.4. Variable: OptimizeBad1DDecoding

The following section contains a detailed description of the variable OptimizeBad1DDecoding.

Variable Overview

Variable Name
OptimizeBad1DDecoding

Communication Name	D1DEXBadDec
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1447
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN D1DEXBadDec`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXBadDec	String	11	

Read Variable Response:				
`sRA D1DEXBadDec <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXBadDec	String	11	
Variable Data	data	Bool	1	

Write Variable:				
`sWN D1DEXBadDec <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXBadDec	String	11	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA D1DEXBadDec`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXBadDec	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D1DEXBadDec[ETX]`
Read Variable Response:	`[STX]sRA D1DEXBadDec 0[ETX]`
Write Variable:	`[STX]sWN D1DEXBadDec 0[ETX]`
Write Variable Response:	`[STX]sWA D1DEXBadDec[ETX]`

© SICK AG - Germany - All rights reserved

2.37.23.5. Variable: Emphasize1D

The following section contains a detailed description of the variable Emphasize1D.

Variable Overview

Variable Name
Emphasize1D

Communication Name	D1DEXEmph
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1450
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN D1DEXEmph
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXEmph	String	9	

Read Variable Response:

```
sRA D1DEXEmph <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXEmph	String	9	
Variable Data	data	Bool	1	

Write Variable:

```
sWN D1DEXEmph <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXEmph	String	9	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA D1DEXEmph
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXEmph	String	9	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D1DEXEmph[ETX]`
Read Variable Response:	`[STX]sRA D1DEXEmph 0[ETX]`
Write Variable:	`[STX]sWN D1DEXEmph 0[ETX]`
Write Variable Response:	`[STX]sWA D1DEXEmph[ETX]`

2.37.23.6. Variable: Scanning1DRegionMode

The following section contains a detailed description of the variable Scanning1DRegionMode.

Variable Overview

Variable Name
Scanning1DRegionMode

Communication Name	D1DEXScnMd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1454
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Intelligent	
	Value	Name	Description
	0	Full	
	1	Partial	
	2	Intelligent	

Variable Telegram Syntax

Read Variable:				
`sRN D1DEXScnMd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXScnMd	String	10	

Read Variable Response:				
`sRA D1DEXScnMd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXScnMd	String	10	
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN D1DEXScnMd <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXScnMd	String	10	
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA D1DEXScnMd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXScnMd	String	10	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN D1DEXScnMd[ETX]
Read Variable Response:	[STX]sRA D1DEXScnMd 2[ETX]
Write Variable:	[STX]sWN D1DEXScnMd 2[ETX]
Write Variable Response:	[STX]sWA D1DEXScnMd[ETX]

2.37.23.7. Variable: SizeFilter1DCodes

The following section contains a detailed description of the variable SizeFilter1DCodes.

Variable Overview

Variable Name	Description
SizeFilter1DCodes	Defines valid width and height ranges for 1D codes in pixels.

Communication Name	D1DEXSzFlt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1455
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct		
Enabled		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Struct		
RangeX		
	Array	
	Length	2
	Default Value	{0,500}
		UDInt
		Value Range: 0..999
		Initialisation:
		Physical Unit: Px
		Physical Unit Factor: 0.0
RangeY		
	Array	
	Length	2
	Default Value	{0,120}
		UDInt
		Value Range: 0..999
		Initialisation:
		Physical Unit: Px
		Physical Unit Factor: 0.0

Variable Telegram Syntax

Read Variable:

```
sRN D1DEXSzFlt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXSzFlt	String	10	Defines valid width and height ranges for 1D codes in pixels.

Read Variable Response:

```
sRA D1DEXSzFlt <Enabled> <RangeX> <RangeY>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXSzFlt	String	10	Defines valid width and height ranges for 1D codes in pixels.
Variable Data 1	Enabled	Bool	1	
Variable Data 2	RangeX	Array	8	
Variable Data 3	RangeY	Array	8	

Write Variable:

```
sWN D1DEXSzFlt <Enabled> <RangeX> <RangeY>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXSzFlt	String	10	Defines valid width and height ranges for 1D codes in pixels.
Variable Data 1	Enabled	Bool	1	
Variable Data 2	RangeX	Array	8	
Variable Data 3	RangeY	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA D1DEXSzFlt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXSzFlt	String	10	Defines valid width and height ranges for 1D codes in pixels.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN D1DEXSzFlt[ETX]
Read Variable Response:	[STX]sRA D1DEXSzFlt 0 0 1F4 0 78[ETX]
Write Variable:	[STX]sWN D1DEXSzFlt 0 0 1F4 0 78[ETX]
Write Variable Response:	[STX]sWA D1DEXSzFlt[ETX]

2.37.23.8. Variable: CodeAtBorder1D

The following section contains a detailed description of the variable CodeAtBorder1D.

Variable Overview

Variable Name
CodeAtBorder1D

Communication Name	D1DAtBrd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1456
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN D1DAtBrd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DAtBrd	String	8	

Read Variable Response:				
`sRA D1DAtBrd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DAtBrd	String	8	
Variable Data	data	Bool	1	

Write Variable:				
`sWN D1DAtBrd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DAtBrd	String	8	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA D1DAtBrd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DAtBrd	String	8	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D1DAtBrd[ETX]`
Read Variable Response:	`[STX]sRA D1DAtBrd 0[ETX]`
Write Variable:	`[STX]sWN D1DAtBrd 0[ETX]`
Write Variable Response:	`[STX]sWA D1DAtBrd[ETX]`

© SICK AG - Germany - All rights reserved

2.37.23.9. Variable: SuperResolutionActive

The following section contains a detailed description of the variable SuperResolutionActive.

Variable Overview

Variable Name	Description
SuperResolutionActive	Actives Super Resolution

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1457
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Off	
	Value	Name	Description
	0	Off	
	1	On	
	2	Auto	

Variable Telegram Syntax

Read Variable:				
`sRN SuperResolutionActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SuperResolutionActive	String	21	Actives Super Resolution

Read Variable Response:				
`sRA SuperResolutionActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SuperResolutionActive	String	21	Actives Super Resolution
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SuperResolutionActive <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SuperResolutionActive	String	21	Actives Super Resolution
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SuperResolutionActive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SuperResolutionActive	String	21	Actives Super Resolution

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SuperResolutionActive[ETX]`
Read Variable Response:	`[STX]sRA SuperResolutionActive 0[ETX]`
Write Variable:	`[STX]sWN SuperResolutionActive 0[ETX]`
Write Variable Response:	`[STX]sWA SuperResolutionActive[ETX]`

2.37.23.10. Variable: UPCEANAddonMatchingStrategy

The following section contains a detailed description of the variable UPCEANAddonMatchingStrategy.

Variable Overview

Variable Name	Description
UPCEANAddonMatchingStrategy	Heuristic for matching Addons to EAN codes

Communication Name	UPCEANMatStrat
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1458
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		STRICT_ANGLE_MATCH	
	Value	Name	Description
	0	STRICT_ANGLE_MATCH	
	1	AGGRESSIVE	

Variable Telegram Syntax

Read Variable:				
`sRN UPCEANMatStrat`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	UPCEANMatStrat	String	14	Heuristic for matching Addons to EAN codes

Read Variable Response:				
`sRA UPCEANMatStrat <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	UPCEANMatStrat	String	14	Heuristic for matching Addons to EAN codes
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN UPCEANMatStrat <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	UPCEANMatStrat	String	14	Heuristic for matching Addons to EAN codes
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA UPCEANMatStrat				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	UPCEANMatStrat	String	14	Heuristic for matching Addons to EAN codes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN UPCEANMatStrat[ETX]
Read Variable Response:	[STX]sRA UPCEANMatStrat 0[ETX]
Write Variable:	[STX]sWN UPCEANMatStrat 0[ETX]
Write Variable Response:	[STX]sWA UPCEANMatStrat[ETX]

2.37.23.11. Variable: Decoding1DLevel

The following section contains a detailed description of the variable Decoding1DLevel.

Variable Overview

Variable Name	Description
Decoding1DLevel	Main level switch of 1D decoding performance

Communication Name	D1DEXLev
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1446
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Aggressive	
	Value	Name	Description
	0	Fast	
	1	Balanced	
	2	Aggressive	
	3	AggressiveTiny	
	4	UserDefined	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN D1DEXLev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D1DEXLev	String	8	Main level switch of 1D decoding performance

Read Variable Response:				
`sRA D1DEXLev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D1DEXLev	String	8	Main level switch of 1D decoding performance
Variable Data	data	Enum8	1	

Write Variable:				
`sWN D1DEXLev <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D1DEXLev	String	8	Main level switch of 1D decoding performance
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA D1DEXLev`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D1DEXLev	String	8	Main level switch of 1D decoding performance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D1DEXLev[ETX]`
Read Variable Response:	`[STX]sRA D1DEXLev 2[ETX]`
Write Variable:	`[STX]sWN D1DEXLev 2[ETX]`
Write Variable Response:	`[STX]sWA D1DEXLev[ETX]`

© SICK AG - Germany - All rights reserved

2.37.24. Group: Decoding2DExtensions

2.37.24.1. Variable: GlsCodeSelection

The following section contains a detailed description of the variable GlsCodeSelection.

Variable Overview

Variable Name	Description
GlsCodeSelection	Select if multicode or codetape label should be computed.

Communication Name	GlsCodeSel
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1463
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Multicode	
	Value	Name	Description
	0	Multicode	
	1	Codetape	
	2	Codetape_GLS1	

Variable Telegram Syntax

Read Variable:

```
sRN GlsCodeSel
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GlsCodeSel	String	10	Select if multicode or codetape label should be computed.

Read Variable Response:

```
sRA GlsCodeSel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GlsCodeSel	String	10	Select if multicode or codetape label should be computed.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN GlsCodeSel <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GlsCodeSel	String	10	Select if multicode or codetape label should be computed.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA GlsCodeSel				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GlsCodeSel	String	10	Select if multicode or codetape label should be computed.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GlsCodeSel[ETX]
Read Variable Response:	[STX]sRA GlsCodeSel 0[ETX]
Write Variable:	[STX]sWN GlsCodeSel 0[ETX]
Write Variable Response:	[STX]sWA GlsCodeSel[ETX]

2.37.24.2. Variable: MultiCodeGridModuleSize

The following section contains a detailed description of the variable MultiCodeGridModuleSize.

Variable Overview

Variable Name	Description
MultiCodeGridModuleSize	Distance between single codes within the Multi Code Grid

Communication Name	D2MCGridModSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1464
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	9
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN D2MCGridModSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D2MCGridModSize	String	15	Distance between single codes within the Multi Code Grid

Read Variable Response:				
`sRA D2MCGridModSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D2MCGridModSize	String	15	Distance between single codes within the Multi Code Grid
Variable Data	data	UInt	2	

Write Variable:				
`sWN D2MCGridModSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D2MCGridModSize	String	15	Distance between single codes within the Multi Code Grid
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA D2MCGridModSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D2MCGridModSize	String	15	Distance between single codes within the Multi Code Grid

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN D2MCGridModSize[ETX]`
Read Variable Response:	`[STX]sRA D2MCGridModSize 9[ETX]`
Write Variable:	`[STX]sWN D2MCGridModSize 9[ETX]`
Write Variable Response:	`[STX]sWA D2MCGridModSize[ETX]`

© SICK AG - Germany - All rights reserved

2.37.24.3. Variable: MCMountingAngleAlphaCompensationActive

The following section contains a detailed description of the variable MCMountingAngleAlphaCompensationActive.

Variable Overview

Variable Name	Description
MCMountingAngleAlphaCompensationActive	If active, mounting angle alpha is considered withing the calculation of XMCL und YMCL.

Communication Name	D2MCMAACompAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1465
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		FromAGV_CompensationInactive	
	Value	Name	Description
	0	FromAGV_CompensationInactive	
	1	FromImager_CompensationActive	

Variable Telegram Syntax

Read Variable:

```
sRN D2MCMAACompAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D2MCMAACompAct	String	14	If active, mounting angle alpha is considered withing the calculation of XMCL und YMCL.

Read Variable Response:

```
sRA D2MCMAACompAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D2MCMAACompAct	String	14	If active, mounting angle alpha is considered withing the calculation of XMCL und YMCL.
Variable Data	data	Enum8	1	

Write Variable:

```
sWN D2MCMAACompAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D2MCMAACompAct	String	14	If active, mounting angle alpha is considered withing the calculation of XMCL und YMCL.
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA D2MCMAACompAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	D2MCMAACompAct	String	14	If active, mounting angle alpha is considered withing the calculation of XMCL und YMCL.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN D2MCMAACompAct[ETX]
Read Variable Response:	[STX]sRA D2MCMAACompAct 0[ETX]
Write Variable:	[STX]sWN D2MCMAACompAct 0[ETX]
Write Variable Response:	[STX]sWA D2MCMAACompAct[ETX]

2.37.24.4. Variable: GLSIncreaseAngleStability

The following section contains a detailed description of the variable GLSIncreaseAngleStability.

Variable Overview

Variable Name	Description
GLSIncreaseAngleStability	Enable optimization that gives better Tilt Angle for square codes at 90deg like in GLS, and noreads for other codes, so beware

Communication Name	DCGLSAngSt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1466
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCGLSAngSt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCGLSAngSt	String	10	Enable optimization that gives better Tilt Angle for square codes at 90deg like in GLS, and noreads for other codes, so beware

Read Variable Response:				
`sRA DCGLSAngSt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCGLSAngSt	String	10	Enable optimization that gives better Tilt Angle for square codes at 90deg like in GLS, and noreads for other codes, so beware
Variable Data	data	Bool	1	

Write Variable:				
`sWN DCGLSAngSt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCGLSAngSt	String	10	Enable optimization that gives better Tilt Angle for square codes at 90deg like in GLS, and noreads for other codes, so beware
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA DCGLSAngSt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCGLSAngSt	String	10	Enable optimization that gives better Tilt Angle for square codes at 90deg like in GLS, and noreads for other codes, so beware

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCGLSAngSt[ETX]`
Read Variable Response:	`[STX]sRA DCGLSAngSt 0[ETX]`
Write Variable:	`[STX]sWN DCGLSAngSt 0[ETX]`
Write Variable Response:	`[STX]sWA DCGLSAngSt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.24.5. Variable: MultiCodeCenterOffsetEnabled

The following section contains a detailed description of the variable MultiCodeCenterOffsetEnabled.

Variable Overview

Variable Name	Description
MultiCodeCenterOffsetEnabled	If enabled, distances from multi code labels' center to the image center are computed.

Communication Name	D2MCCOffEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1462
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN D2MCCOffEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	D2MCCOffEna	String	11	If enabled, distances from multi code labels' center to the image center are computed.

Read Variable Response:

```
sRA D2MCCOffEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	D2MCCOffEna	String	11	If enabled, distances from multi code labels' center to the image center are computed.
Variable Data	data	Bool	1	

Write Variable:

```
sWN D2MCCOffEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	D2MCCOffEna	String	11	If enabled, distances from multi code labels' center to the image center are computed.
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA D2MCCOffEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA D2MCCOffEna				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	D2MCCOffEna	String	11	If enabled, distances from multi code labels' center to the image center are computed.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN D2MCCOffEna[ETX]
Read Variable Response:	[STX]sRA D2MCCOffEna 1[ETX]
Write Variable:	[STX]sWN D2MCCOffEna 1[ETX]
Write Variable Response:	[STX]sWA D2MCCOffEna[ETX]

© SICK AG - Germany - All rights reserved

2.37.25. Group: DecodingAztec

2.37.25.1. Variable: AztecActive

The following section contains a detailed description of the variable AztecActive.

Variable Overview

Variable Name	Description
AztecActive	Activates Aztec Decoder

Communication Name	DCAZAct
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1467
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DCAZAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCAZAct	String	7	Activates Aztec Decoder

Read Variable Response:

```
sRA DCAZAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCAZAct	String	7	Activates Aztec Decoder
Variable Data	data	Bool	1	

Write Variable:

```
sWN DCAZAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCAZAct	String	7	Activates Aztec Decoder
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA DCAZAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCAZAct				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCAZAct	String	7	Activates Aztec Decoder

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCAZAct[ETX]
Read Variable Response:	[STX]sRA DCAZAct 0[ETX]
Write Variable:	[STX]sWN DCAZAct 0[ETX]
Write Variable Response:	[STX]sWA DCAZAct[ETX]

2.37.25.2. Variable: AztecLengthMode

The following section contains a detailed description of the variable AztecLengthMode.

Variable Overview

Variable Name	Description
AztecLengthMode	Codelength mode of Aztec Code

Communication Name	DCAZLenMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1468
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		Free	
	Value	Name	Description
	0	Free	
	1	Fix	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCAZLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCAZLenMode	String	11	Codelength mode of Aztec Code

Read Variable Response:				
`sRA DCAZLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCAZLenMode	String	11	Codelength mode of Aztec Code
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DCAZLenMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCAZLenMode	String	11	Codelength mode of Aztec Code
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA DCAZLenMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCAZLenMode	String	11	Codelength mode of Aztec Code

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCAZLenMode[ETX]`
Read Variable Response:	`[STX]sRA DCAZLenMode 0[ETX]`
Write Variable:	`[STX]sWN DCAZLenMode 0[ETX]`
Write Variable Response:	`[STX]sWA DCAZLenMode[ETX]`

© SICK AG - Germany - All rights reserved

2.37.25.3. Variable: AztecFixLenList

The following section contains a detailed description of the variable AztecFixLenList.

Variable Overview

Variable Name	Description
AztecFixLenList	List of symbol sizes

Communication Name	DCAZFixLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1469
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

© SICK AG - Germany - All rights reserved

Array				
Length			5	
	Enum8			
		Value	Name	Description
		0	NONE	
		1	15_15	
		2	19_19	
		3	23_23	
		4	27_27	
		5	31_31	
		6	37_37	
		7	41_41	
		8	45_45	
		9	49_49	
		10	53_53	
		11	57_57	
		12	61_61	
		13	67_67	
		14	71_71	
		15	75_75	
		16	79_79	
		17	83_83	
		18	87_87	
		19	91_91	
		20	95_95	
		21	101_101	
		22	105_105	
		23	109_109	
		24	113_113	
		25	117_117	
		26	121_121	
		27	125_125	
		28	131_131	
		29	135_135	
		30	139_139	
		31	143_143	
		32	147_147	
		33	151_151	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DCAZFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCAZFixLen	String	10	List of symbol sizes

Read Variable Response:				
`sRA DCAZFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCAZFixLen	String	10	List of symbol sizes
Variable Data	data	Array	5	

Write Variable:				
`sWN DCAZFixLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCAZFixLen	String	10	List of symbol sizes
Variable Data	data	Array	5	

Write Variable Response:				
`sWA DCAZFixLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DCAZFixLen	String	10	List of symbol sizes

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DCAZFixLen[ETX]`
Read Variable Response:	`[STX]sRA DCAZFixLen 0 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DCAZFixLen 0 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DCAZFixLen[ETX]`

© SICK AG - Germany - All rights reserved

2.37.25.4. Variable: AztecMode

The following section contains a detailed description of the variable AztecMode.

Variable Overview

Variable Name	Description
AztecMode	Aztec code mode

Communication Name	DCAZMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1470
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		COMPACT_FULLSIZE	
	Value	Name	Description
	0	COMPACT_FULLSIZE	
	1	COMPACT_ONLY	
	2	FULLSIZE_ONLY	

Variable Telegram Syntax

Read Variable:
`sRN DCAZMode`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DCAZMode	String	8	Aztec code mode

Read Variable Response:
`sRA DCAZMode <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DCAZMode	String	8	Aztec code mode
Variable Data	data	Enum8	1	

Write Variable:
`sWN DCAZMode <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DCAZMode	String	8	Aztec code mode
Variable Data	data	Enum8	1	

Write Variable Response:
`sWA DCAZMode`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DCAZMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	DCAZMode	String	8	Aztec code mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DCAZMode[ETX]
Read Variable Response:	[STX]sRA DCAZMode 0[ETX]
Write Variable:	[STX]sWN DCAZMode 0[ETX]
Write Variable Response:	[STX]sWA DCAZMode[ETX]

© SICK AG - Germany - All rights reserved

2.37.26. Group: MatchTeachIn

2.37.26.1. Variable: MTIGeneralSettings

The following section contains a detailed description of the variable MTIGeneralSettings.

Variable Overview

Variable Name	Description
MTIGeneralSettings	General settings for both teach-in channels

Communication Name	MTIGnrlStt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1475
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
codeMode			
	Enum8		
	Default Value	1	
	Value	Name	Description
	0	TX_ALL_CODES	
	1	TX_SELECTED_CODES	
	2	TX_ONLY_PHARMA_CODE	
codeConfigHandling			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_DONT_CHANGE_CODE_CONFIG	
	1	TX_CHANGE_CODE_CONFIG_TO_LAST_TEACHED_CODE	
	2	TX_WIDEN_CODE_CONFIG_ON_LAST_TEACHED_CODE	
savePermanent			
	Bool		
	Value Range	False, True	
	Initialisation	False	
triggerType			
	Enum8		
	Default Value	0	
	Value	Name	Description
	0	TX_EXTRA_TEACH_TRIGGER	
	1	TX_STD_TRIGGER_NEEDED	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN MTIGnrlStt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIGnrlStt	String	10	General settings for both teach-in channels

Read Variable Response:				
`sRA MTIGnrlStt <codeMode> <codeConfigHandling> <savePermanent> <triggerType>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIGnrlStt	String	10	General settings for both teach-in channels
Variable Data 1	codeMode	Enum8	1	
Variable Data 2	codeConfigHandling	Enum8	1	
Variable Data 3	savePermanent	Bool	1	
Variable Data 4	triggerType	Enum8	1	

Write Variable:				
`sWN MTIGnrlStt <codeMode> <codeConfigHandling> <savePermanent> <triggerType>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIGnrlStt	String	10	General settings for both teach-in channels
Variable Data 1	codeMode	Enum8	1	
Variable Data 2	codeConfigHandling	Enum8	1	
Variable Data 3	savePermanent	Bool	1	
Variable Data 4	triggerType	Enum8	1	

Write Variable Response:				
`sWA MTIGnrlStt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MTIGnrlStt	String	10	General settings for both teach-in channels

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN MTIGnrlStt[ETX]`
Read Variable Response:	`[STX]sRA MTIGnrlStt 1 0 0 0[ETX]`
Write Variable:	`[STX]sWN MTIGnrlStt 1 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA MTIGnrlStt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.26.2. Variable: MTIChannelSettings1

The following section contains a detailed description of the variable MTIChannelSettings1.

Variable Overview

Variable Name	Description
MTIChannelSettings1	Config for channel1

Communication Name	MTIChnl1Stt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1476
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
triggerSrc			
	Enum8		
	Default Value	TX_INACTIVE	
	Value	Name	Description
	0	TX_INACTIVE	
	1	TX_SENS1	
	2	TX_SENS2	
	3	TX_EXT_SENS1	
	4	TX_EXT_SENS2	
	5	TX_COMMAND	
	6	TX_CDF600_FIELDBUS	
teachContent			
	Bool		
	Value Range	False, True	
	Initialisation	True	
teachID			
	Bool		
	Value Range	False, True	
	Initialisation	True	
teachLength			
	Bool		
	Value Range	False, True	
	Initialisation	True	
negativeMatch			
	Bool		
	Value Range	False, True	
	Initialisation	False	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN MTIChnl1Stt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIChnl1Stt	String	11	Config for channel1

Read Variable Response:				
`sRA MTIChnl1Stt <triggerSrc> <teachContent> <teachID> <teachLength> <negativeMatch>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIChnl1Stt	String	11	Config for channel1
Variable Data 1	triggerSrc	Enum8	1	
Variable Data 2	teachContent	Bool	1	
Variable Data 3	teachID	Bool	1	
Variable Data 4	teachLength	Bool	1	
Variable Data 5	negativeMatch	Bool	1	

Write Variable:				
`sWN MTIChnl1Stt <triggerSrc> <teachContent> <teachID> <teachLength> <negativeMatch>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIChnl1Stt	String	11	Config for channel1
Variable Data 1	triggerSrc	Enum8	1	
Variable Data 2	teachContent	Bool	1	
Variable Data 3	teachID	Bool	1	
Variable Data 4	teachLength	Bool	1	
Variable Data 5	negativeMatch	Bool	1	

Write Variable Response:				
`sWA MTIChnl1Stt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MTIChnl1Stt	String	11	Config for channel1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN MTIChnl1Stt[ETX]`
Read Variable Response:	`[STX]sRA MTIChnl1Stt 0 1 1 1 0[ETX]`
Write Variable:	`[STX]sWN MTIChnl1Stt 0 1 1 1 0[ETX]`
Write Variable Response:	`[STX]sWA MTIChnl1Stt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.26.3. Variable: MTIChannelStopSettings1

The following section contains a detailed description of the variable MTIChannelStopSettings1.

Variable Overview

Variable Name	Description
MTIChannelStopSettings1	Stopping settings for dyn. teach-in

Communication Name	MTIChnl1Stp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1477
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_STOPPED_BY_TRIGGER_SRC	
	Value	Name	Description
	0	TX_STOPPED_BY_TRIGGER_SRC	
	1	TX_STOPPED_BY_OBJ_TRIG	
	2	TX_STOPPED_BY_VALID_TEACHED_CODE	

Variable Telegram Syntax

Read Variable:

```
sRN MTIChnl1Stp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIChnl1Stp	String	11	Stopping settings for dyn. teach-in

Read Variable Response:

```
sRA MTIChnl1Stp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIChnl1Stp	String	11	Stopping settings for dyn. teach-in
Variable Data	data	Enum8	1	

Write Variable:

```
sWN MTIChnl1Stp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIChnl1Stp	String	11	Stopping settings for dyn. teach-in
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA MTIChnl1Stp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA MTIChnl1Stp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	MTIChnl1Stp	String	11	Stopping settings for dyn. teach-in

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN MTIChnl1Stp[ETX]
Read Variable Response:	[STX]sRA MTIChnl1Stp 0[ETX]
Write Variable:	[STX]sWN MTIChnl1Stp 0[ETX]
Write Variable Response:	[STX]sWA MTIChnl1Stp[ETX]

2.37.26.4. Variable: MTIChannel1Condition

The following section contains a detailed description of the variable MTIChannel1Condition.

Variable Overview

Variable Name	Description
MTIChannel1Condition	Dest. condition for teach-in 1

Communication Name	MTIChnl1Cnd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1478
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..18
Initialisation	TeachIn1

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN MTIChnl1Cnd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIChnl1Cnd	String	11	Dest. condition for teach-in 1

Read Variable Response:				
`sRA MTIChnl1Cnd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIChnl1Cnd	String	11	Dest. condition for teach-in 1
Variable Data	data	FlexString	18	

Write Variable:				
`sWN MTIChnl1Cnd <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIChnl1Cnd	String	11	Dest. condition for teach-in 1
Variable Data	data	FlexString	18	

Write Variable Response:				
`sWA MTIChnl1Cnd`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MTIChnl1Cnd	String	11	Dest. condition for teach-in 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN MTIChnl1Cnd[ETX]`
Read Variable Response:	`[STX]sRA MTIChnl1Cnd 8 TeachIn1[ETX]`
Write Variable:	`[STX]sWN MTIChnl1Cnd 8 TeachIn1[ETX]`
Write Variable Response:	`[STX]sWA MTIChnl1Cnd[ETX]`

© SICK AG - Germany - All rights reserved

2.37.26.5. Variable: MTIChannelSettings2

The following section contains a detailed description of the variable MTIChannelSettings2.

Variable Overview

Variable Name	Description
MTIChannelSettings2	Config for channel2

Communication Name	MTIChnl2Stt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1479
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct			
triggerSrc			
	Enum8		
	Default Value	TX_INACTIVE	
	Value	Name	Description
	0	TX_INACTIVE	
	1	TX_SENS1	
	2	TX_SENS2	
	3	TX_EXT_SENS1	
	4	TX_EXT_SENS2	
	5	TX_CDF600_FIELDBUS	
teachContent			
	Bool		
	Value Range	False, True	
	Initialisation	True	
teachID			
	Bool		
	Value Range	False, True	
	Initialisation	True	
teachLength			
	Bool		
	Value Range	False, True	
	Initialisation	True	
negativeMatch			
	Bool		
	Value Range	False, True	
	Initialisation	False	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN MTIChnl2Stt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIChnl2Stt	String	11	Config for channel2

Read Variable Response:				
`sRA MTIChnl2Stt <triggerSrc> <teachContent> <teachID> <teachLength> <negativeMatch>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIChnl2Stt	String	11	Config for channel2
Variable Data 1	triggerSrc	Enum8	1	
Variable Data 2	teachContent	Bool	1	
Variable Data 3	teachID	Bool	1	
Variable Data 4	teachLength	Bool	1	
Variable Data 5	negativeMatch	Bool	1	

Write Variable:				
`sWN MTIChnl2Stt <triggerSrc> <teachContent> <teachID> <teachLength> <negativeMatch>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIChnl2Stt	String	11	Config for channel2
Variable Data 1	triggerSrc	Enum8	1	
Variable Data 2	teachContent	Bool	1	
Variable Data 3	teachID	Bool	1	
Variable Data 4	teachLength	Bool	1	
Variable Data 5	negativeMatch	Bool	1	

Write Variable Response:				
`sWA MTIChnl2Stt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MTIChnl2Stt	String	11	Config for channel2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN MTIChnl2Stt[ETX]`
Read Variable Response:	`[STX]sRA MTIChnl2Stt 0 1 1 1 0[ETX]`
Write Variable:	`[STX]sWN MTIChnl2Stt 0 1 1 1 0[ETX]`
Write Variable Response:	`[STX]sWA MTIChnl2Stt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.26.6. Variable: MTIChannelStopSettings2

The following section contains a detailed description of the variable MTIChannelStopSettings2.

Variable Overview

Variable Name	Description
MTIChannelStopSettings2	Stopping settings for dyn. teach-in

Communication Name	MTIChnl2Stp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1480
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_STOPPED_BY_TRIGGER_SRC	
	Value	Name	Description
	0	TX_STOPPED_BY_TRIGGER_SRC	
	1	TX_STOPPED_BY_OBJ_TRIG	

Variable Telegram Syntax

Read Variable:

```
sRN MTIChnl2Stp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIChnl2Stp	String	11	Stopping settings for dyn. teach-in

Read Variable Response:

```
sRA MTIChnl2Stp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIChnl2Stp	String	11	Stopping settings for dyn. teach-in
Variable Data	data	Enum8	1	

Write Variable:

```
sWN MTIChnl2Stp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIChnl2Stp	String	11	Stopping settings for dyn. teach-in
Variable Data	data	Enum8	1	

Write Variable Response:

```
sWA MTIChnl2Stp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MTIChnl2Stp	String	11	Stopping settings for dyn. teach-in

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN MTIChnl2Stp[ETX]`
Read Variable Response:	`[STX]sRA MTIChnl2Stp 0[ETX]`
Write Variable:	`[STX]sWN MTIChnl2Stp 0[ETX]`
Write Variable Response:	`[STX]sWA MTIChnl2Stp[ETX]`

2.37.26.7. Variable: MTIChannel2Condition

The following section contains a detailed description of the variable MTIChannel2Condition.

Variable Overview

Variable Name	Description
MTIChannel2Condition	Dest. condition for teach-in 2

Communication Name	MTIChnl2Cnd
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1481
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..18
Initialisation	TeachIn2

Variable Telegram Syntax

Read Variable:

`sRN MTIChnl2Cnd`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	MTIChnl2Cnd	String	11	Dest. condition for teach-in 2

Read Variable Response:

`sRA MTIChnl2Cnd <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	MTIChnl2Cnd	String	11	Dest. condition for teach-in 2
Variable Data	data	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN MTIChnl2Cnd <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	MTIChnl2Cnd	String	11	Dest. condition for teach-in 2
Variable Data	data	FlexString	18	

Write Variable Response:				
sWA MTIChnl2Cnd				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	MTIChnl2Cnd	String	11	Dest. condition for teach-in 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN MTIChnl2Cnd[ETX]
Read Variable Response:	[STX]sRA MTIChnl2Cnd 8 TeachIn2[ETX]
Write Variable:	[STX]sWN MTIChnl2Cnd 8 TeachIn2[ETX]
Write Variable Response:	[STX]sWA MTIChnl2Cnd[ETX]

© SICK AG - Germany - All rights reserved

2.37.27. Group: HMI

2.37.27.1. Variable: HMIAllowMatchCodeTeachIn

The following section contains a detailed description of the variable HMIAllowMatchCodeTeachIn.

Variable Overview

Variable Name	Description
HMIAllowMatchCodeTeachIn	To lock the TeachIn command in the HMI menu

Communication Name	HMIAllowTeachIn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1483
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN HMIAllowTeachIn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	HMIAllowTeachIn	String	15	To lock the TeachIn command in the HMI menu

Read Variable Response:

```
sRA HMIAllowTeachIn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	HMIAllowTeachIn	String	15	To lock the TeachIn command in the HMI menu
Variable Data	data	Bool	1	

Write Variable:

```
sWN HMIAllowTeachIn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	HMIAllowTeachIn	String	15	To lock the TeachIn command in the HMI menu
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA HMIAllowTeachIn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA HMIAllowTeachIn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	HMIAllowTeachIn	String	15	To lock the TeachIn command in the HMI menu

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN HMIAllowTeachIn[ETX]
Read Variable Response:	[STX]sRA HMIAllowTeachIn 1[ETX]
Write Variable:	[STX]sWN HMIAllowTeachIn 1[ETX]
Write Variable Response:	[STX]sWA HMIAllowTeachIn[ETX]

2.37.27.2. Variable: HMIAutoSetupChangeFocus

The following section contains a detailed description of the variable HMIAutoSetupChangeFocus.

Variable Overview

Variable Name	Description
HMIAutoSetupChangeFocus	If true, the focus position will be adjusted during auto setup

Communication Name	HMIASChangeFocus
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1484
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN HMIASChangeFocus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	HMIASChangeFocus	String	16	If true, the focus position will be adjusted during auto setup

Read Variable Response:				
`sRA HMIASChangeFocus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	HMIASChangeFocus	String	16	If true, the focus position will be adjusted during auto setup
Variable Data	data	Bool	1	

Write Variable:				
`sWN HMIASChangeFocus <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	HMIASChangeFocus	String	16	If true, the focus position will be adjusted during auto setup
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA HMIASChangeFocus`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	HMIASChangeFocus	String	16	If true, the focus position will be adjusted during auto setup

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN HMIASChangeFocus[ETX]`
Read Variable Response:	`[STX]sRA HMIASChangeFocus 1[ETX]`
Write Variable:	`[STX]sWN HMIASChangeFocus 1[ETX]`
Write Variable Response:	`[STX]sWA HMIASChangeFocus[ETX]`

© SICK AG - Germany - All rights reserved

2.37.27.3. Variable: HMIAutoSetupChangeImage

The following section contains a detailed description of the variable HMIAutoSetupChangeImage.

Variable Overview

Variable Name	Description
HMIAutoSetupChangeImage	If true auto setup may adjust image parameters, e.g. brightness

Communication Name	HMIASChangeImage
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1485
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN HMIASChangeImage
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	HMIASChangeImage	String	16	If true auto setup may adjust image parameters, e.g. brightness

Read Variable Response:

```
sRA HMIASChangeImage <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	HMIASChangeImage	String	16	If true auto setup may adjust image parameters, e.g. brightness
Variable Data	data	Bool	1	

Write Variable:

```
sWN HMIASChangeImage <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	HMIASChangeImage	String	16	If true auto setup may adjust image parameters, e.g. brightness
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA HMIASChangeImage
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA HMIASChangeImage				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	HMIASChangeImage	String	16	If true auto setup may adjust image parameters, e.g. brightness

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN HMIASChangeImage[ETX]
Read Variable Response:	[STX]sRA HMIASChangeImage 1[ETX]
Write Variable:	[STX]sWN HMIASChangeImage 1[ETX]
Write Variable Response:	[STX]sWA HMIASChangeImage[ETX]

2.37.27.4. Variable: HMIAutoSetupChangeCode

The following section contains a detailed description of the variable HMIAutoSetupChangeCode.

Variable Overview

Variable Name	Description
HMIAutoSetupChangeCode	If true auto setup may adjust code parameters, e.g. background color

Communication Name	HMIASChangeCode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1486
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN HMIASChangeCode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	HMIASChangeCode	String	15	If true auto setup may adjust code parameters, e.g. background color

Read Variable Response:				
`sRA HMIASChangeCode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	HMIASChangeCode	String	15	If true auto setup may adjust code parameters, e.g. background color
Variable Data	data	Bool	1	

Write Variable:				
`sWN HMIASChangeCode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	HMIASChangeCode	String	15	If true auto setup may adjust code parameters, e.g. background color
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA HMIASChangeCode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	HMIASChangeCode	String	15	If true auto setup may adjust code parameters, e.g. background color

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN HMIASChangeCode[ETX]`
Read Variable Response:	`[STX]sRA HMIASChangeCode 1[ETX]`
Write Variable:	`[STX]sWN HMIASChangeCode 1[ETX]`
Write Variable Response:	`[STX]sWA HMIASChangeCode[ETX]`

© SICK AG - Germany - All rights reserved

2.37.27.5. Variable: HMIButtonMode

The following section contains a detailed description of the variable HMIButtonMode.

Variable Overview

Variable Name	Description
HMIButtonMode	Depending on the mode, the HMI buttons are enabled or can be used for different actions

Communication Name	HMIBtnsMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1482
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_TRIGGER_AND_AIMINGLASER	
	2	TX_OPMODE_SAVE_PERMANENTLY	
	3	TX_OPMODE_SAVE_TEMPORARILY	
	4	TX_QUICK_AUTOSETUP	

Variable Telegram Syntax

Read Variable:

```
sRN HMIBtnsMode
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	HMIBtnsMode	String	11	Depending on the mode, the HMI buttons are enabled or can be used for different actions

Read Variable Response:

```
sRA HMIBtnsMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	HMIBtnsMode	String	11	Depending on the mode, the HMI buttons are enabled or can be used for different actions
Variable Data	data	Enum8	1	

Write Variable:

```
sWN HMIBtnsMode <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	HMIBtnsMode	String	11	Depending on the mode, the HMI buttons are enabled or can be used for different actions
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA HMIBtnsMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	HMIBtnsMode	String	11	Depending on the mode, the HMI buttons are enabled or can be used for different actions

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN HMIBtnsMode[ETX]
Read Variable Response:	[STX]sRA HMIBtnsMode 0[ETX]
Write Variable:	[STX]sWN HMIBtnsMode 0[ETX]
Write Variable Response:	[STX]sWA HMIBtnsMode[ETX]

© SICK AG - Germany - All rights reserved

2.37.28. Group: Beeper

2.37.28.1. Variable: BeeperFuncExt

The following section contains a detailed description of the variable BeeperFuncExt.

Variable Overview

Variable Name	Description
BeeperFuncExt	Extension of beeper func for evalcond

Communication Name	BPFuncExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1489
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN BPFuncExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BPFuncExt	String	9	Extension of beeper func for evalcond

Read Variable Response:

```
sRA BPFuncExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BPFuncExt	String	9	Extension of beeper func for evalcond
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:

```
sWN BPFuncExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BPFuncExt	String	9	Extension of beeper func for evalcond

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN BPFuncExt <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA BPFuncExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BPFuncExt	String	9	Extension of beeper func for evalcond

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BPFuncExt[ETX]
Read Variable Response:	[STX]sRA BPFuncExt 0 0[ETX]
Write Variable:	[STX]sWN BPFuncExt 0 0[ETX]
Write Variable Response:	[STX]sWA BPFuncExt[ETX]

2.37.28.2. Variable: BeeperLoudness

The following section contains a detailed description of the variable BeeperLoudness.

Variable Overview

Variable Name	Description
BeeperLoudness	Defines the loudness of the beeper

Communication Name	BPLoudness
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1487
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_OFF	
	Value	Name	Description
	0	TX_OFF	
	1	TX_SOFT	
	2	TX_LOUD	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BPLoudness`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BPLoudness	String	10	Defines the loudness of the beeper

Read Variable Response:				
`sRA BPLoudness <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BPLoudness	String	10	Defines the loudness of the beeper
Variable Data	data	Enum8	1	

Write Variable:				
`sWN BPLoudness <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BPLoudness	String	10	Defines the loudness of the beeper
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA BPLoudness`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BPLoudness	String	10	Defines the loudness of the beeper

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BPLoudness[ETX]`
Read Variable Response:	`[STX]sRA BPLoudness 0[ETX]`
Write Variable:	`[STX]sWN BPLoudness 0[ETX]`
Write Variable Response:	`[STX]sWA BPLoudness[ETX]`

© SICK AG - Germany - All rights reserved

2.37.28.3. Variable: BeeperFunc

The following section contains a detailed description of the variable BeeperFunc.

Variable Overview

Variable Name	Description
BeeperFunc	Function of Beeper

Communication Name	BPFunc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1488
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_GOOD_READ	
	Value	Name	Description
	0	TX_GOOD_READ	
	1	TX_NO_READ	
	6	TX_PM_FEEDBACK	
	7	TX_MODE_DIGIO_CONDITION1	

Variable Telegram Syntax

Read Variable:				
`sRN BPFunc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BPFunc	String	6	Function of Beeper

Read Variable Response:				
`sRA BPFunc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BPFunc	String	6	Function of Beeper
Variable Data	data	Enum8	1	

Write Variable:				
`sWN BPFunc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BPFunc	String	6	Function of Beeper
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BPFunc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BPFunc	String	6	Function of Beeper

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BPFunc[ETX]
Read Variable Response:	[STX]sRA BPFunc 0[ETX]
Write Variable:	[STX]sWN BPFunc 0[ETX]
Write Variable Response:	[STX]sWA BPFunc[ETX]

© SICK AG - Germany - All rights reserved

2.37.29. Group: GoodReadLed

2.37.29.1. Variable: GoodReadLedFuncExt

The following section contains a detailed description of the variable GoodReadLedFuncExt.

Variable Overview

Variable Name	Description
GoodReadLedFuncExt	Extension of green GoodRead LED func for evalcond

Communication Name	GRLEDFuncExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1492
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN GRLEDFuncExt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GRLEDFuncExt	String	12	Extension of green GoodRead LED func for evalcond

Read Variable Response:

```
sRA GRLEDFuncExt <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GRLEDFuncExt	String	12	Extension of green GoodRead LED func for evalcond
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN GRLEDFuncExt <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GRLEDFuncExt	String	12	Extension of green GoodRead LED func for evalcond
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA GRLEDFuncExt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GRLEDFuncExt	String	12	Extension of green GoodRead LED func for evalcond

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN GRLEDFuncExt[ETX]
Read Variable Response:	[STX]sRA GRLEDFuncExt 0 0[ETX]
Write Variable:	[STX]sWN GRLEDFuncExt 0 0[ETX]
Write Variable Response:	[STX]sWA GRLEDFuncExt[ETX]

2.37.29.2. Variable: GoodReadLedDuration

The following section contains a detailed description of the variable GoodReadLedDuration.

Variable Overview

Variable Name	Description
GoodReadLedDuration	Time duration in milliseconds the green GoodRead LED is switched on

Communication Name	GRLEDDuration
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1493
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	100..10000
Initialisation	500
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GRLEDDuration`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GRLEDDuration	String	13	Time duration in milliseconds the green GoodRead LED is switched on

Read Variable Response:				
`sRA GRLEDDuration <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GRLEDDuration	String	13	Time duration in milliseconds the green GoodRead LED is switched on
Variable Data	data	UDInt	4	

Write Variable:				
`sWN GRLEDDuration <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GRLEDDuration	String	13	Time duration in milliseconds the green GoodRead LED is switched on
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA GRLEDDuration`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GRLEDDuration	String	13	Time duration in milliseconds the green GoodRead LED is switched on

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GRLEDDuration[ETX]`
Read Variable Response:	`[STX]sRA GRLEDDuration 1F4[ETX]`
Write Variable:	`[STX]sWN GRLEDDuration 1F4[ETX]`
Write Variable Response:	`[STX]sWA GRLEDDuration[ETX]`

© SICK AG - Germany - All rights reserved

2.37.29.3. Variable: IlluminationForFeedback

The following section contains a detailed description of the variable IlluminationForFeedback.

Variable Overview

Variable Name	Description
IlluminationForFeedback	LED and aiming laser can be disabled for Feedback

Communication Name	IlluFeedback
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1494
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_FEEDBACK_ILLU_AIMINGLASER_ON	
	Value	Name	Description
	0	TX_FEEDBACK_ILLU_AIMINGLASER_ON	
	1	TX_FEEDBACK_ILLU_OFF	
	2	TX_FEEDBACK_AIMINGLASER_OFF	
	3	TX_FEEDBACK_ILLU_AIMINGLASER_OFF	

Variable Telegram Syntax

Read Variable:

```
sRN IlluFeedback
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	IlluFeedback	String	12	LED and aiming laser can be disabled for Feedback

Read Variable Response:

```
sRA IlluFeedback <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	IlluFeedback	String	12	LED and aiming laser can be disabled for Feedback
Variable Data	data	Enum8	1	

Write Variable:

```
sWN IlluFeedback <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	IlluFeedback	String	12	LED and aiming laser can be disabled for Feedback
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA IlluFeedback				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	IlluFeedback	String	12	LED and aiming laser can be disabled for Feedback

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN IlluFeedback[ETX]
Read Variable Response:	[STX]sRA IlluFeedback 0[ETX]
Write Variable:	[STX]sWN IlluFeedback 0[ETX]
Write Variable Response:	[STX]sWA IlluFeedback[ETX]

2.37.29.4. Variable: GoodReadLedFunc

The following section contains a detailed description of the variable GoodReadLedFunc.

Variable Overview

Variable Name	Description
GoodReadLedFunc	Function of green GoodRead LED

Communication Name	GRLEDFunc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1491
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_FUNCTION	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_GOOD_READ	
	7	TX_PM_FEEDBACK	
	8	TX_MODE_DIGIO_CONDITION1	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN GRLEDFunc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GRLEDFunc	String	9	Function of green GoodRead LED

Read Variable Response:				
`sRA GRLEDFunc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GRLEDFunc	String	9	Function of green GoodRead LED
Variable Data	data	Enum8	1	

Write Variable:				
`sWN GRLEDFunc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GRLEDFunc	String	9	Function of green GoodRead LED
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA GRLEDFunc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GRLEDFunc	String	9	Function of green GoodRead LED

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GRLEDFunc[ETX]`
Read Variable Response:	`[STX]sRA GRLEDFunc 0[ETX]`
Write Variable:	`[STX]sWN GRLEDFunc 0[ETX]`
Write Variable Response:	`[STX]sWA GRLEDFunc[ETX]`

© SICK AG - Germany - All rights reserved

2.37.30. Group: FeedbackLedRed

2.37.30.1. Variable: FeedbackLedRedFunc

The following section contains a detailed description of the variable FeedbackLedRedFunc.

Variable Overview

Variable Name	Description
FeedbackLedRedFunc	Function of red feedback LED

Communication Name	FBLEDRedFunc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1495
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_FUNCTION	
	Value	Name	Description
	0	TX_NO_FUNCTION	
	1	TX_GOOD_READ	
	2	TX_NO_READ	

Variable Telegram Syntax

Read Variable:				
`sRN FBLEDRedFunc`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FBLEDRedFunc	String	12	Function of red feedback LED

Read Variable Response:				
`sRA FBLEDRedFunc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FBLEDRedFunc	String	12	Function of red feedback LED
Variable Data	data	Enum8	1	

Write Variable:				
`sWN FBLEDRedFunc <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FBLEDRedFunc	String	12	Function of red feedback LED
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FBLEDRedFunc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FBLEDRedFunc	String	12	Function of red feedback LED

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FBLEDRedFunc[ETX]
Read Variable Response:	[STX]sRA FBLEDRedFunc 0[ETX]
Write Variable:	[STX]sWN FBLEDRedFunc 0[ETX]
Write Variable Response:	[STX]sWA FBLEDRedFunc[ETX]

2.37.30.2. Variable: FeedbackLedRedFuncExt

The following section contains a detailed description of the variable FeedbackLedRedFuncExt.

Variable Overview

Variable Name	Description
FeedbackLedRedFuncExt	Extension of red feedback LED func for evalcond

Communication Name	FBLEDRedFuncExt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1496
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN FBLEDRedFuncExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FBLEDRedFuncExt	String	15	Extension of red feedback LED func for evalcond

Read Variable Response:				
`sRA FBLEDRedFuncExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FBLEDRedFuncExt	String	15	Extension of red feedback LED func for evalcond
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN FBLEDRedFuncExt <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FBLEDRedFuncExt	String	15	Extension of red feedback LED func for evalcond
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA FBLEDRedFuncExt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FBLEDRedFuncExt	String	15	Extension of red feedback LED func for evalcond

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN FBLEDRedFuncExt[ETX]`
Read Variable Response:	`[STX]sRA FBLEDRedFuncExt 0 0[ETX]`
Write Variable:	`[STX]sWN FBLEDRedFuncExt 0 0[ETX]`
Write Variable Response:	`[STX]sWA FBLEDRedFuncExt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.30.3. Variable: FeedbackLedRedDuration

The following section contains a detailed description of the variable FeedbackLedRedDuration.

Variable Overview

Variable Name	Description
FeedbackLedRedDuration	Time duration in milliseconds the red feedback LED is switched on

Communication Name	FBLEDRedDuration
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1497
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	100..10000
Initialisation	500
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN FBLEDRedDuration
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FBLEDRedDuration	String	16	Time duration in milliseconds the red feedback LED is switched on

Read Variable Response:

```
sRA FBLEDRedDuration <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FBLEDRedDuration	String	16	Time duration in milliseconds the red feedback LED is switched on
Variable Data	data	UDInt	4	

Write Variable:

```
sWN FBLEDRedDuration <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FBLEDRedDuration	String	16	Time duration in milliseconds the red feedback LED is switched on
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA FBLEDRedDuration				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FBLEDRedDuration	String	16	Time duration in milliseconds the red feedback LED is switched on

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FBLEDRedDuration[ETX]
Read Variable Response:	[STX]sRA FBLEDRedDuration 1F4[ETX]
Write Variable:	[STX]sWN FBLEDRedDuration 1F4[ETX]
Write Variable Response:	[STX]sWA FBLEDRedDuration[ETX]

© SICK AG - Germany - All rights reserved

2.37.31. Group: ApplicationCounters

2.37.31.1. Variable: APCCounterCondition01

The following section contains a detailed description of the variable APCCounterCondition01.

Variable Overview

Variable Name	Description
APCCounterCondition01	Enum of permanent counter 1

Communication Name	APCCC01
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1498
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC01
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC01	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC01 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC01	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC01 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCC01	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC01				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC01	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC01[ETX]
Read Variable Response:	[STX]sRA APCCC01 0[ETX]
Write Variable:	[STX]sWN APCCC01 0[ETX]
Write Variable Response:	[STX]sWA APCCC01[ETX]

2.37.31.2. Variable: APCCounterConditionStruct01

The following section contains a detailed description of the variable APCCounterConditionStruct01.

Variable Overview

Variable Name	Description
APCCounterConditionStruct01	Struct of permanent counter for condition name based observing

Communication Name	APCCCS01
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1499
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS01`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS01	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS01 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS01	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS01 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS01	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS01`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS01	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS01[ETX]`
Read Variable Response:	`[STX]sRA APCCCS01 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS01 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS01[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.3. Variable: APCCounterDBTagStruct01

The following section contains a detailed description of the variable APCCounterDBTagStruct01.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct01	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS01
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1500
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	True
ExtraValue	
FlexString	
Length	0..6
Initialisation	NC

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS01
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS01	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS01 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS01	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS01 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS01	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS01 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS01				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS01	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS01[ETX]
Read Variable Response:	[STX]sRA APCCDTS01 1 2 NC[ETX]
Write Variable:	[STX]sWN APCCDTS01 1 2 NC[ETX]
Write Variable Response:	[STX]sWA APCCDTS01[ETX]

2.37.31.4. Variable: APCIsPermanent01

The following section contains a detailed description of the variable APCIsPermanent01.

Variable Overview

Variable Name	Description
APCIsPermanent01	Defines whether a counter is permanent or not

Communication Name	APCIsPerm01
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1501
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm01`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm01	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm01 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm01	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm01 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm01	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm01`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm01	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm01[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm01 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm01 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm01[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.5. Variable: APCCounterCondition02

The following section contains a detailed description of the variable APCCounterCondition02.

Variable Overview

Variable Name	Description
APCCounterCondition02	Enum of permanent counter 1

Communication Name	APCCC02
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1502
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC02
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC02	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC02 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC02	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC02 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC02 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC02	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC02				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC02	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC02[ETX]
Read Variable Response:	[STX]sRA APCCC02 0[ETX]
Write Variable:	[STX]sWN APCCC02 0[ETX]
Write Variable Response:	[STX]sWA APCCC02[ETX]

2.37.31.6. Variable: APCCounterConditionStruct02

The following section contains a detailed description of the variable APCCounterConditionStruct02.

Variable Overview

Variable Name	Description
APCCounterConditionStruct02	Struct of permanent counter for condition name based observing

Communication Name	APCCCS02
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1503
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS02`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS02	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS02 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS02	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS02 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS02	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS02`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS02	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS02[ETX]`
Read Variable Response:	`[STX]sRA APCCCS02 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS02 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS02[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.7. Variable: APCCounterDBTagStruct02

The following section contains a detailed description of the variable APCCounterDBTagStruct02.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct02	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS02
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1504
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	True
ExtraValue	
FlexString	
Length	0..6
Initialisation	SCGR

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS02
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS02	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS02 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS02	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS02 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS02	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS02 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS02				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS02	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS02[ETX]
Read Variable Response:	[STX]sRA APCCDTS02 1 4 SCGR[ETX]
Write Variable:	[STX]sWN APCCDTS02 1 4 SCGR[ETX]
Write Variable Response:	[STX]sWA APCCDTS02[ETX]

2.37.31.8. Variable: APCIsPermanent02

The following section contains a detailed description of the variable APCIsPermanent02.

Variable Overview

Variable Name	Description
APCIsPermanent02	Defines whether a counter is permanent or not

Communication Name	APCIsPerm02
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1505
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm02`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm02	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm02 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm02	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm02 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm02	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm02`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm02	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm02[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm02 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm02 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm02[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.9. Variable: APCCounterCondition03

The following section contains a detailed description of the variable APCCounterCondition03.

Variable Overview

Variable Name	Description
APCCounterCondition03	Enum of permanent counter 1

Communication Name	APCCC03
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1506
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC03
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC03	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC03 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC03	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC03 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC03 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC03	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC03				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC03	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC03[ETX]
Read Variable Response:	[STX]sRA APCCC03 0[ETX]
Write Variable:	[STX]sWN APCCC03 0[ETX]
Write Variable Response:	[STX]sWA APCCC03[ETX]

2.37.31.10. Variable: APCCounterConditionStruct03

The following section contains a detailed description of the variable APCCounterConditionStruct03.

Variable Overview

Variable Name	Description
APCCounterConditionStruct03	Struct of permanent counter for condition name based observing

Communication Name	APCCCS03
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1507
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS03`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS03	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS03 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS03	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS03 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS03	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS03`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS03	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS03[ETX]`
Read Variable Response:	`[STX]sRA APCCCS03 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS03 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS03[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.11. Variable: APCCounterDBTagStruct03

The following section contains a detailed description of the variable APCCounterDBTagStruct03.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct03	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS03
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1508
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	True
ExtraValue	
FlexString	
Length	0..6
Initialisation	SCNR

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS03
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS03	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS03 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS03	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS03 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS03	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS03 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS03				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS03	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS03[ETX]
Read Variable Response:	[STX]sRA APCCDTS03 1 4 SCNR[ETX]
Write Variable:	[STX]sWN APCCDTS03 1 4 SCNR[ETX]
Write Variable Response:	[STX]sWA APCCDTS03[ETX]

2.37.31.12. Variable: APCIsPermanent03

The following section contains a detailed description of the variable APCIsPermanent03.

Variable Overview

Variable Name	Description
APCIsPermanent03	Defines whether a counter is permanent or not

Communication Name	APCIsPerm03
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1509
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm03`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm03	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm03 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm03	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm03 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm03	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm03`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm03	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm03[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm03 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm03 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm03[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.13. Variable: APCCounterCondition04

The following section contains a detailed description of the variable APCCounterCondition04.

Variable Overview

Variable Name	Description
APCCounterCondition04	Enum of permanent counter 1

Communication Name	APCCC04
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1510
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC04
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC04	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC04 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC04	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC04 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC04 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC04	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC04				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC04	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC04[ETX]
Read Variable Response:	[STX]sRA APCCC04 0[ETX]
Write Variable:	[STX]sWN APCCC04 0[ETX]
Write Variable Response:	[STX]sWA APCCC04[ETX]

2.37.31.14. Variable: APCCounterConditionStruct04

The following section contains a detailed description of the variable APCCounterConditionStruct04.

Variable Overview

Variable Name	Description
APCCounterConditionStruct04	Struct of permanent counter for condition name based observing

Communication Name	APCCCS04
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1511
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	True
ExtraValue	
FlexString	
Length	0..18
Initialisation	Match1

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN APCCCS04				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS04	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
sRA APCCCS04 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS04	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
sWN APCCCS04 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS04	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA APCCCS04				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS04	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCCS04[ETX]
Read Variable Response:	[STX]sRA APCCCS04 1 6 Match1[ETX]
Write Variable:	[STX]sWN APCCCS04 1 6 Match1[ETX]
Write Variable Response:	[STX]sWA APCCCS04[ETX]

© SICK AG - Germany - All rights reserved

2.37.31.15. Variable: APCCounterDBTagStruct04

The following section contains a detailed description of the variable APCCounterDBTagStruct04.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct04	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS04
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1512
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..6
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS04
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS04	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS04 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS04	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS04 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS04	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS04 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS04				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS04	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS04[ETX]
Read Variable Response:	[STX]sRA APCCDTS04 0 0[ETX]
Write Variable:	[STX]sWN APCCDTS04 0 0[ETX]
Write Variable Response:	[STX]sWA APCCDTS04[ETX]

2.37.31.16. Variable: APCIsPermanent04

The following section contains a detailed description of the variable APCIsPermanent04.

Variable Overview

Variable Name	Description
APCIsPermanent04	Defines whether a counter is permanent or not

Communication Name	APCIsPerm04
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1513
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm04`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm04	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm04 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm04	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm04 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm04	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm04`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm04	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm04[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm04 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm04 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm04[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.17. Variable: APCCounterCondition05

The following section contains a detailed description of the variable APCCounterCondition05.

Variable Overview

Variable Name	Description
APCCounterCondition05	Enum of permanent counter 1

Communication Name	APCCC05
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1514
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC05
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC05	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC05 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC05	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC05 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC05 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC05	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC05				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC05	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC05[ETX]
Read Variable Response:	[STX]sRA APCCC05 0[ETX]
Write Variable:	[STX]sWN APCCC05 0[ETX]
Write Variable Response:	[STX]sWA APCCC05[ETX]

2.37.31.18. Variable: APCCounterConditionStruct05

The following section contains a detailed description of the variable APCCounterConditionStruct05.

Variable Overview

Variable Name	Description
APCCounterConditionStruct05	Struct of permanent counter for condition name based observing

Communication Name	APCCCS05
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1515
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	True
ExtraValue	
FlexString	
Length	0..18
Initialisation	TeachIn1

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS05`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS05	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS05 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS05	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS05 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS05	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS05`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS05	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS05[ETX]`
Read Variable Response:	`[STX]sRA APCCCS05 1 8 TeachIn1[ETX]`
Write Variable:	`[STX]sWN APCCCS05 1 8 TeachIn1[ETX]`
Write Variable Response:	`[STX]sWA APCCCS05[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.19. Variable: APCCounterDBTagStruct05

The following section contains a detailed description of the variable APCCounterDBTagStruct05.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct05	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS05
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1516
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..6
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS05
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS05	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS05 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS05	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS05 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS05	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS05 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS05				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS05	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS05[ETX]
Read Variable Response:	[STX]sRA APCCDTS05 0 0[ETX]
Write Variable:	[STX]sWN APCCDTS05 0 0[ETX]
Write Variable Response:	[STX]sWA APCCDTS05[ETX]

2.37.31.20. Variable: APCIsPermanent05

The following section contains a detailed description of the variable APCIsPermanent05.

Variable Overview

Variable Name	Description
APCIsPermanent05	Defines whether a counter is permanent or not

Communication Name	APCIsPerm05
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1517
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm05`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm05	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm05 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm05	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm05 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm05	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm05`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm05	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm05[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm05 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm05 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm05[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.21. Variable: APCCounterCondition06

The following section contains a detailed description of the variable APCCounterCondition06.

Variable Overview

Variable Name	Description
APCCounterCondition06	Enum of permanent counter 1

Communication Name	APCCC06
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1518
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC06
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC06	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC06 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC06	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC06 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC06 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC06	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC06				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC06	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC06[ETX]
Read Variable Response:	[STX]sRA APCCC06 0[ETX]
Write Variable:	[STX]sWN APCCC06 0[ETX]
Write Variable Response:	[STX]sWA APCCC06[ETX]

2.37.31.22. Variable: APCCounterConditionStruct06

The following section contains a detailed description of the variable APCCounterConditionStruct06.

Variable Overview

Variable Name	Description
APCCounterConditionStruct06	Struct of permanent counter for condition name based observing

Communication Name	APCCCS06
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1519
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN APCCCS06				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS06	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
sRA APCCCS06 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS06	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
sWN APCCCS06 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS06	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
sWA APCCCS06				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS06	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCCS06[ETX]
Read Variable Response:	[STX]sRA APCCCS06 0 0[ETX]
Write Variable:	[STX]sWN APCCCS06 0 0[ETX]
Write Variable Response:	[STX]sWA APCCCS06[ETX]

© SICK AG - Germany - All rights reserved

2.37.31.23. Variable: APCCounterDBTagStruct06

The following section contains a detailed description of the variable APCCounterDBTagStruct06.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct06	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS06
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1520
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	True
ExtraValue	
FlexString	
Length	0..6
Initialisation	NY

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS06
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS06	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS06 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS06	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS06 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS06	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS06 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS06				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS06	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS06[ETX]
Read Variable Response:	[STX]sRA APCCDTS06 1 2 NY[ETX]
Write Variable:	[STX]sWN APCCDTS06 1 2 NY[ETX]
Write Variable Response:	[STX]sWA APCCDTS06[ETX]

2.37.31.24. Variable: APCIsPermanent06

The following section contains a detailed description of the variable APCIsPermanent06.

Variable Overview

Variable Name	Description
APCIsPermanent06	Defines whether a counter is permanent or not

Communication Name	APCIsPerm06
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1521
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm06`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm06	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm06 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm06	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm06 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm06	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm06`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm06	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm06[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm06 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm06 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm06[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.25. Variable: APCCounterCondition07

The following section contains a detailed description of the variable APCCounterCondition07.

Variable Overview

Variable Name	Description
APCCounterCondition07	Enum of permanent counter 1

Communication Name	APCCC07
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1522
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC07
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC07	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC07 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC07	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC07 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC07 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC07	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC07				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC07	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC07[ETX]
Read Variable Response:	[STX]sRA APCCC07 0[ETX]
Write Variable:	[STX]sWN APCCC07 0[ETX]
Write Variable Response:	[STX]sWA APCCC07[ETX]

2.37.31.26. Variable: APCCounterConditionStruct07

The following section contains a detailed description of the variable APCCounterConditionStruct07.

Variable Overview

Variable Name	Description
APCCounterConditionStruct07	Struct of permanent counter for condition name based observing

Communication Name	APCCCS07
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1523
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS07`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS07	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS07 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS07	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS07 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS07	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS07`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS07	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS07[ETX]`
Read Variable Response:	`[STX]sRA APCCCS07 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS07 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS07[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.27. Variable: APCCounterDBTagStruct07

The following section contains a detailed description of the variable APCCounterDBTagStruct07.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct07	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS07
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1524
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..6
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS07
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS07	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS07 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS07	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS07 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS07	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS07 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS07				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS07	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS07[ETX]
Read Variable Response:	[STX]sRA APCCDTS07 0 0[ETX]
Write Variable:	[STX]sWN APCCDTS07 0 0[ETX]
Write Variable Response:	[STX]sWA APCCDTS07[ETX]

2.37.31.28. Variable: APCIsPermanent07

The following section contains a detailed description of the variable APCIsPermanent07.

Variable Overview

Variable Name	Description
APCIsPermanent07	Defines whether a counter is permanent or not

Communication Name	APCIsPerm07
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1525
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm07`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm07	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm07 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm07	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm07 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm07	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm07`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm07	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm07[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm07 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm07 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm07[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.29. Variable: APCCounterCondition08

The following section contains a detailed description of the variable APCCounterCondition08.

Variable Overview

Variable Name	Description
APCCounterCondition08	Enum of permanent counter 1

Communication Name	APCCC08
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1526
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC08
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC08	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC08 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC08	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC08 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC08 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC08	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC08				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC08	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC08[ETX]
Read Variable Response:	[STX]sRA APCCC08 0[ETX]
Write Variable:	[STX]sWN APCCC08 0[ETX]
Write Variable Response:	[STX]sWA APCCC08[ETX]

2.37.31.30. Variable: APCCounterConditionStruct08

The following section contains a detailed description of the variable APCCounterConditionStruct08.

Variable Overview

Variable Name	Description
APCCounterConditionStruct08	Struct of permanent counter for condition name based observing

Communication Name	APCCCS08
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1527
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS08`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS08	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS08 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS08	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS08 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS08	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS08`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS08	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS08[ETX]`
Read Variable Response:	`[STX]sRA APCCCS08 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS08 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS08[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.31. Variable: APCCounterDBTagStruct08

The following section contains a detailed description of the variable APCCounterDBTagStruct08.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct08	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS08
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1528
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..6
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS08
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS08	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS08 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS08	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS08 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS08	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS08 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS08				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS08	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS08[ETX]
Read Variable Response:	[STX]sRA APCCDTS08 0 0[ETX]
Write Variable:	[STX]sWN APCCDTS08 0 0[ETX]
Write Variable Response:	[STX]sWA APCCDTS08[ETX]

2.37.31.32. Variable: APCIsPermanent08

The following section contains a detailed description of the variable APCIsPermanent08.

Variable Overview

Variable Name	Description
APCIsPermanent08	Defines whether a counter is permanent or not

Communication Name	APCIsPerm08
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1529
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm08`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm08	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm08 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm08	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm08 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm08	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm08`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm08	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm08[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm08 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm08 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm08[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.33. Variable: APCCounterCondition09

The following section contains a detailed description of the variable APCCounterCondition09.

Variable Overview

Variable Name	Description
APCCounterCondition09	Enum of permanent counter 1

Communication Name	APCCC09
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1530
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC09
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC09	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC09 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC09	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC09 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC09 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC09	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC09				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC09	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC09[ETX]
Read Variable Response:	[STX]sRA APCCC09 0[ETX]
Write Variable:	[STX]sWN APCCC09 0[ETX]
Write Variable Response:	[STX]sWA APCCC09[ETX]

2.37.31.34. Variable: APCCounterConditionStruct09

The following section contains a detailed description of the variable APCCounterConditionStruct09.

Variable Overview

Variable Name	Description
APCCounterConditionStruct09	Struct of permanent counter for condition name based observing

Communication Name	APCCCS09
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1531
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS09`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS09	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS09 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS09	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS09 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS09	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS09`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS09	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS09[ETX]`
Read Variable Response:	`[STX]sRA APCCCS09 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS09 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS09[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.35. Variable: APCCounterDBTagStruct09

The following section contains a detailed description of the variable APCCounterDBTagStruct09.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct09	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS09
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1532
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..6
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS09
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS09	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS09 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS09	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS09 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS09	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS09 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS09				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS09	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS09[ETX]
Read Variable Response:	[STX]sRA APCCDTS09 0 0[ETX]
Write Variable:	[STX]sWN APCCDTS09 0 0[ETX]
Write Variable Response:	[STX]sWA APCCDTS09[ETX]

2.37.31.36. Variable: APCIsPermanent09

The following section contains a detailed description of the variable APCIsPermanent09.

Variable Overview

Variable Name	Description
APCIsPermanent09	Defines whether a counter is permanent or not

Communication Name	APCIsPerm09
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1533
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm09`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm09	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm09 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm09	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm09 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm09	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm09`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm09	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm09[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm09 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm09 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm09[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.37. Variable: APCCounterCondition10

The following section contains a detailed description of the variable APCCounterCondition10.

Variable Overview

Variable Name	Description
APCCounterCondition10	Enum of permanent counter 1

Communication Name	APCCC10
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1534
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DEACTIVATED	
	Value	Name	Description
	0	TX_DEACTIVATED	
	1	TX_INPUT1	
	2	TX_INPUT2	
	3	TX_EXT_IN1	
	4	TX_EXT_IN2	
	5	TX_OUTPUT1	
	6	TX_OUTPUT2	
	7	TX_OUTPUT3	
	8	TX_OUTPUT4	
	9	TX_EXT_OUT1	
	10	TX_EXT_OUT2	

Variable Telegram Syntax

Read Variable:

```
sRN APCCC10
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCC10	String	7	Enum of permanent counter 1

Read Variable Response:

```
sRA APCCC10 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCC10	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable:

```
sWN APCCC10 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCC10 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	APCCC10	String	7	Enum of permanent counter 1
Variable Data	data	Enum8	1	

Write Variable Response:				
sWA APCCC10				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCC10	String	7	Enum of permanent counter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCC10[ETX]
Read Variable Response:	[STX]sRA APCCC10 0[ETX]
Write Variable:	[STX]sWN APCCC10 0[ETX]
Write Variable Response:	[STX]sWA APCCC10[ETX]

2.37.31.38. Variable: APCCounterConditionStruct10

The following section contains a detailed description of the variable APCCounterConditionStruct10.

Variable Overview

Variable Name	Description
APCCounterConditionStruct10	Struct of permanent counter for condition name based observing

Communication Name	APCCCS10
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1535
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCCCS10`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCCS10	String	8	Struct of permanent counter for condition name based observing

Read Variable Response:				
`sRA APCCCS10 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCCS10	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable:				
`sWN APCCCS10 <UseExtraValue> <ExtraValue>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCCS10	String	8	Struct of permanent counter for condition name based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	18	

Write Variable Response:				
`sWA APCCCS10`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCCS10	String	8	Struct of permanent counter for condition name based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCCCS10[ETX]`
Read Variable Response:	`[STX]sRA APCCCS10 0 0[ETX]`
Write Variable:	`[STX]sWN APCCCS10 0 0[ETX]`
Write Variable Response:	`[STX]sWA APCCCS10[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.39. Variable: APCCounterDBTagStruct10

The following section contains a detailed description of the variable APCCounterDBTagStruct10.

Variable Overview

Variable Name	Description
APCCounterDBTagStruct10	Struct of permanent counter for dbtag based observing

Communication Name	APCCDTS10
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1536
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..6
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN APCCDTS10
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCCDTS10	String	9	Struct of permanent counter for dbtag based observing

Read Variable Response:

```
sRA APCCDTS10 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCCDTS10	String	9	Struct of permanent counter for dbtag based observing
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable:

```
sWN APCCDTS10 <UseExtraValue> <ExtraValue>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCCDTS10	String	9	Struct of permanent counter for dbtag based observing

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN APCCDTS10 <UseExtraValue> <ExtraValue>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Variable Data 1	UseExtraValue	Bool	1	
Variable Data 2	ExtraValue	FlexString	6	

Write Variable Response:				
sWA APCCDTS10				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCCDTS10	String	9	Struct of permanent counter for dbtag based observing

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN APCCDTS10[ETX]
Read Variable Response:	[STX]sRA APCCDTS10 0 0[ETX]
Write Variable:	[STX]sWN APCCDTS10 0 0[ETX]
Write Variable Response:	[STX]sWA APCCDTS10[ETX]

2.37.31.40. Variable: APCIsPermanent10

The following section contains a detailed description of the variable APCIsPermanent10.

Variable Overview

Variable Name	Description
APCIsPermanent10	Defines whether a counter is permanent or not

Communication Name	APCIsPerm10
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1537
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN APCIsPerm10`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	APCIsPerm10	String	11	Defines whether a counter is permanent or not

Read Variable Response:				
`sRA APCIsPerm10 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	APCIsPerm10	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable:				
`sWN APCIsPerm10 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	APCIsPerm10	String	11	Defines whether a counter is permanent or not
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA APCIsPerm10`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	APCIsPerm10	String	11	Defines whether a counter is permanent or not

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN APCIsPerm10[ETX]`
Read Variable Response:	`[STX]sRA APCIsPerm10 0[ETX]`
Write Variable:	`[STX]sWN APCIsPerm10 0[ETX]`
Write Variable Response:	`[STX]sWA APCIsPerm10[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.41. Method: ResetAppCounter

The following section contains a detailed description of the method ResetAppCounter.

Method Overview

Method Name	Description
ResetAppCounter	Resets the application counters

Communication Name	mAPCReset
Sopas Index	151
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mAPCReset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mAPCReset	String	9	Resets the application counters

Method Return Value:				
`sAN mAPCReset`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mAPCReset	String	9	Resets the application counters

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mAPCReset[ETX]`
Method Return Value:	`[STX]sAN mAPCReset[ETX]`

© SICK AG - Germany - All rights reserved

2.37.31.42. Method: StoreAppCounter

The following section contains a detailed description of the method StoreAppCounter.

Method Overview

Method Name	Description
StoreAppCounter	Trigeres the permanent storage of the permanent application counters

Communication Name	mAPCStore
Sopas Index	152
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mAPCStore`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mAPCStore	String	9	Trigeres the permanent storage of the permanent application counters

Method Return Value:				
`sAN mAPCStore`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mAPCStore	String	9	Trigeres the permanent storage of the permanent application counters

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mAPCStore[ETX]`
Method Return Value:	`[STX]sAN mAPCStore[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32. Group: ParameterSwitching

2.37.32.1. Variable: ParameterSwitchingMode

The following section contains a detailed description of the variable ParameterSwitchingMode.

Variable Overview

Variable Name	Description
ParameterSwitchingMode	APS or EPS

Communication Name	DPSMode
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1538
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_DISABLED	
	Value	Name	Description
	0	TX_DISABLED	
	1	TX_APS	
	2	TX_EPS	

Variable Telegram Syntax

Read Variable:				
`sRN DPSMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSMode	String	7	APS or EPS

Read Variable Response:				
`sRA DPSMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSMode	String	7	APS or EPS
Variable Data	data	Enum8	1	

Write Variable:				
`sWN DPSMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSMode	String	7	APS or EPS
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DPSMode				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSMode	String	7	APS or EPS

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DPSMode[ETX]
Read Variable Response:	[STX]sRA DPSMode 0[ETX]
Write Variable:	[STX]sWN DPSMode 0[ETX]
Write Variable Response:	[STX]sWA DPSMode[ETX]

2.37.32.2. Variable: APSRetries

The following section contains a detailed description of the variable APSRetries.

Variable Overview

Variable Name	Description
APSRetries	Number of retries until APS switches to the next parameter set

Communication Name	PSAPSRetr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1539
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PSAPSRetr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSAPSRetr	String	9	Number of retries until APS switches to the next parameter set

Read Variable Response:				
`sRA PSAPSRetr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSAPSRetr	String	9	Number of retries until APS switches to the next parameter set
Variable Data	data	UInt	2	

Write Variable:				
`sWN PSAPSRetr <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSAPSRetr	String	9	Number of retries until APS switches to the next parameter set
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA PSAPSRetr`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSAPSRetr	String	9	Number of retries until APS switches to the next parameter set

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSAPSRetr[ETX]`
Read Variable Response:	`[STX]sRA PSAPSRetr 1[ETX]`
Write Variable:	`[STX]sWN PSAPSRetr 1[ETX]`
Write Variable Response:	`[STX]sWA PSAPSRetr[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.3. Variable: EPSSource

The following section contains a detailed description of the variable EPSSource.

Variable Overview

Variable Name	Description
EPSSource	Source event that triggers an EPS switch

Communication Name	PSEPSSrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1540
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_COMMAND	
	Value	Name	Description
	1	TX_SENS1	
	2	TX_SENS2	
	3	TX_EXT_SENS1	
	4	TX_EXT_SENS2	
	5	TX_COMMAND	

Variable Telegram Syntax

Read Variable:

```
sRN PSEPSSrc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSEPSSrc	String	8	Source event that triggers an EPS switch

Read Variable Response:

```
sRA PSEPSSrc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSEPSSrc	String	8	Source event that triggers an EPS switch
Variable Data	data	Enum8	1	

Write Variable:

```
sWN PSEPSSrc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSEPSSrc	String	8	Source event that triggers an EPS switch
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PSEPSSrc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSEPSSrc	String	8	Source event that triggers an EPS switch

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PSEPSSrc[ETX]
Read Variable Response:	[STX]sRA PSEPSSrc 5[ETX]
Write Variable:	[STX]sWN PSEPSSrc 5[ETX]
Write Variable Response:	[STX]sWA PSEPSSrc[ETX]

2.37.32.4. Variable: DpsFocusPositions

The following section contains a detailed description of the variable DpsFocusPositions.

Variable Overview

Variable Name	Description
DpsFocusPositions	This array contains the individual focus positions for each set.

Communication Name	DPSFocPos
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1541
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	UDInt	
	Value Range	670..2000
	Initialisation	1300
	Physical Unit	mm
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DPSFocPos`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSFocPos	String	9	This array contains the individual focus positions for each set.

Read Variable Response:				
`sRA DPSFocPos <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSFocPos	String	9	This array contains the individual focus positions for each set.
Variable Data	data	Array	16	

Write Variable:				
`sWN DPSFocPos <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSFocPos	String	9	This array contains the individual focus positions for each set.
Variable Data	data	Array	16	

Write Variable Response:				
`sWA DPSFocPos`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSFocPos	String	9	This array contains the individual focus positions for each set.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DPSFocPos[ETX]`
Read Variable Response:	`[STX]sRA DPSFocPos 514 514 514 514[ETX]`
Write Variable:	`[STX]sWN DPSFocPos 514 514 514 514[ETX]`
Write Variable Response:	`[STX]sWA DPSFocPos[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.5. Variable: DpsFocusPositionsExt

The following section contains a detailed description of the variable DpsFocusPositionsExt.

Variable Overview

Variable Name	Description
DpsFocusPositionsExt	Extension This array contains the individual focus positions for each set.

Communication Name	DPSFocPosEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1542
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
UDInt	
Value Range	670..2000
Initialisation	1300
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DPSFocPosEx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSFocPosEx	String	11	Extension This array contains the individual focus positions for each set.

Read Variable Response:

```
sRA DPSFocPosEx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSFocPosEx	String	11	Extension This array contains the individual focus positions for each set.
Variable Data	data	Array	16	

Write Variable:

```
sWN DPSFocPosEx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSFocPosEx	String	11	Extension This array contains the individual focus positions for each set.
Variable Data	data	Array	16	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DPSFocPosEx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSFocPosEx	String	11	Extension This array contains the individual focus positions for each set.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DPSFocPosEx[ETX]
Read Variable Response:	[STX]sRA DPSFocPosEx 514 514 514 514[ETX]
Write Variable:	[STX]sWN DPSFocPosEx 514 514 514 514[ETX]
Write Variable Response:	[STX]sWA DPSFocPosEx[ETX]

2.37.32.6. Variable: DpsFocusPostSwitchDelayMs

The following section contains a detailed description of the variable DpsFocusPostSwitchDelayMs.

Variable Overview

Variable Name	Description
DpsFocusPostSwitchDelayMs	Provide a delay which should be paused after DPS changed the focus position.

Communication Name	DPSFocDelay
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1543
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DPSFocDelay`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSFocDelay	String	11	Provide a delay which should be paused after DPS changed the focus position.

Read Variable Response:				
`sRA DPSFocDelay <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSFocDelay	String	11	Provide a delay which should be paused after DPS changed the focus position.
Variable Data	data	UDInt	4	

Write Variable:				
`sWN DPSFocDelay <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSFocDelay	String	11	Provide a delay which should be paused after DPS changed the focus position.
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA DPSFocDelay`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSFocDelay	String	11	Provide a delay which should be paused after DPS changed the focus position.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DPSFocDelay[ETX]`
Read Variable Response:	`[STX]sRA DPSFocDelay 0[ETX]`
Write Variable:	`[STX]sWN DPSFocDelay 0[ETX]`
Write Variable Response:	`[STX]sWA DPSFocDelay[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.7. Variable: ParameterSets

The following section contains a detailed description of the variable ParameterSets.

Variable Overview

Variable Name	Description
ParameterSets	Array of parameter sets for each APS/EPS slot

Communication Name	DPSSets
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1544
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
UserType	
DPSSet	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN DPSSets`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSSets	String	7	Array of parameter sets for each APS/EPS slot

Read Variable Response:				
`sRA DPSSets <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSSets	String	7	Array of parameter sets for each APS/EPS slot
Variable Data	data	Array	48	

Write Variable:				
`sWN DPSSets <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSSets	String	7	Array of parameter sets for each APS/EPS slot
Variable Data	data	Array	48	

Write Variable Response:				
`sWA DPSSets`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSSets	String	7	Array of parameter sets for each APS/EPS slot

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DPSSets[ETX]`
Read Variable Response:	`[STX]sRA DPSSets C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0[ETX]`
Write Variable:	`[STX]sWN DPSSets C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0[ETX]`
Write Variable Response:	`[STX]sWA DPSSets[ETX]`

2.37.32.8. Variable: ParameterSetsExt

The following section contains a detailed description of the variable ParameterSetsExt.

Variable Overview

Variable Name	Description
ParameterSetsExt	Array of parameter sets for each APS/EPS slot

Communication Name	DPSSetsEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1545
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	UserType	
	DPSSet	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN DPSSetsEx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSSetsEx	String	9	Array of parameter sets for each APS/EPS slot

Read Variable Response:				
`sRA DPSSetsEx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSSetsEx	String	9	Array of parameter sets for each APS/EPS slot
Variable Data	data	Array	48	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN DPSSetsEx <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSSetsEx	String	9	Array of parameter sets for each APS/EPS slot
Variable Data	data	Array	48	

Write Variable Response:				
sWA DPSSetsEx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSSetsEx	String	9	Array of parameter sets for each APS/EPS slot

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DPSSetsEx[ETX]
Read Variable Response:	[STX]sRA DPSSetsEx C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0[ETX]
Write Variable:	[STX]sWN DPSSetsEx C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0 C8 32 A 0 1 0[ETX]
Write Variable Response:	[STX]sWA DPSSetsEx[ETX]

2.37.32.9. Variable: ParameterSetsIlluminationColor

The following section contains a detailed description of the variable ParameterSetsIlluminationColor.

Variable Overview

Variable Name	Description
ParameterSetsIlluminationColor	Internal illumination color

Communication Name	PSIlluColor
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1546
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
UserType	
DPSColorType	See the chapter "User Types" for details.

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PSIlluColor`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSIlluColor	String	11	Internal illumination color

Read Variable Response:				
`sRA PSIlluColor <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSIlluColor	String	11	Internal illumination color
Variable Data	data	Array	0	

Write Variable:				
`sWN PSIlluColor <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSIlluColor	String	11	Internal illumination color
Variable Data	data	Array	0	

Write Variable Response:				
`sWA PSIlluColor`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSIlluColor	String	11	Internal illumination color

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSIlluColor[ETX]`
Read Variable Response:	`[STX]sRA PSIlluColor[ETX]`
Write Variable:	`[STX]sWN PSIlluColor[ETX]`
Write Variable Response:	`[STX]sWA PSIlluColor[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.10. Variable: ParameterSetsIlluminationColorExt

The following section contains a detailed description of the variable ParameterSetsIlluminationColorExt.

Variable Overview

Variable Name	Description
ParameterSetsIlluminationColorExt	Internal illumination color

Communication Name	PSIlluColorEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1547
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
UserType	
DPSColorType	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN PSIlluColorEx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSIlluColorEx	String	13	Internal illumination color

Read Variable Response:

```
sRA PSIlluColorEx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSIlluColorEx	String	13	Internal illumination color
Variable Data	data	Array	0	

Write Variable:

```
sWN PSIlluColorEx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSIlluColorEx	String	13	Internal illumination color
Variable Data	data	Array	0	

Write Variable Response:

```
sWA PSIlluColorEx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSIlluColorEx	String	13	Internal illumination color

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSIlluColorEx[ETX]`
Read Variable Response:	`[STX]sRA PSIlluColorEx[ETX]`
Write Variable:	`[STX]sWN PSIlluColorEx[ETX]`
Write Variable Response:	`[STX]sWA PSIlluColorEx[ETX]`

2.37.32.11. Variable: ParameterSetsDPMDMXString

The following section contains a detailed description of the variable ParameterSetsDPMDMXString.

Variable Overview

Variable Name	Description
ParameterSetsDPMDMXString	This string contains DPM DMX Settings acquired during AutoSetup.

Communication Name	PSDPMDMXString
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1548
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	FlexString	
	Length	0..1024
	Initialisation	---

Variable Telegram Syntax

Read Variable:				
`sRN PSDPMDMXString`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSDPMDMXString	String	14	This string contains DPM DMX Settings acquired during AutoSetup.

Read Variable Response:				
`sRA PSDPMDMXString <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSDPMDMXString	String	14	This string contains DPM DMX Settings acquired during AutoSetup.
Variable Data	data	Array	4096	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN PSDPMDMXString <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSDPMDMXString	String	14	This string contains DPM DMX Settings acquired during AutoSetup.
Variable Data	data	Array	4096	

Write Variable Response:				
sWA PSDPMDMXString				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSDPMDMXString	String	14	This string contains DPM DMX Settings acquired during AutoSetup.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PSDPMDMXString[ETX]
Read Variable Response:	[STX]sRA PSDPMDMXString 3 --- 3 --- 3 --- 3 ---[ETX]
Write Variable:	[STX]sWN PSDPMDMXString 3 --- 3 --- 3 --- 3 ---[ETX]
Write Variable Response:	[STX]sWA PSDPMDMXString[ETX]

2.37.32.12. Variable: ParameterSetsDPMDMXStringExt

The following section contains a detailed description of the variable ParameterSetsDPMDMXStringExt.

Variable Overview

Variable Name	Description
ParameterSetsDPMDMXStringExt	This string contains DPM DMX Settings acquired during AutoSetup.

Communication Name	PSDPMDMXStringEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1549
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	FlexString	
	Length	0..1024
	Initialisation	---

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PSDPMDMXStringEx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSDPMDMXStringEx	String	16	This string contains DPM DMX Settings acquired during AutoSetup.

Read Variable Response:				
`sRA PSDPMDMXStringEx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSDPMDMXStringEx	String	16	This string contains DPM DMX Settings acquired during AutoSetup.
Variable Data	data	Array	4096	

Write Variable:				
`sWN PSDPMDMXStringEx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSDPMDMXStringEx	String	16	This string contains DPM DMX Settings acquired during AutoSetup.
Variable Data	data	Array	4096	

Write Variable Response:				
`sWA PSDPMDMXStringEx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSDPMDMXStringEx	String	16	This string contains DPM DMX Settings acquired during AutoSetup.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSDPMDMXStringEx[ETX]`
Read Variable Response:	`[STX]sRA PSDPMDMXStringEx 3 --- 3 --- 3 --- 3 ---[ETX]`
Write Variable:	`[STX]sWN PSDPMDMXStringEx 3 --- 3 --- 3 --- 3 ---[ETX]`
Write Variable Response:	`[STX]sWA PSDPMDMXStringEx[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.13. Variable: ParameterSetsDPMDMXPrettyString

The following section contains a detailed description of the variable ParameterSetsDPMDMXPrettyString.

Variable Overview

Variable Name	Description
ParameterSetsDPMDMXPrettyString	A beautified, human readable version of the DPMDMXString above

Communication Name	PSDPMDMXPrettyString
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1550
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
FlexString	
Length	0..100
Initialisation	---

Variable Telegram Syntax

Read Variable:

```
sRN PSDPMDMXPrettyString
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSDPMDMXPrettyString	String	20	A beautified, human readable version of the DPMDMXString above

Read Variable Response:

```
sRA PSDPMDMXPrettyString <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSDPMDMXPrettyString	String	20	A beautified, human readable version of the DPMDMXString above
Variable Data	data	Array	400	

Write Variable:

```
sWN PSDPMDMXPrettyString <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSDPMDMXPrettyString	String	20	A beautified, human readable version of the DPMDMXString above
Variable Data	data	Array	400	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PSDPMDMXPrettyString				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSDPMDMXPrettyString	String	20	A beautified, human readable version of the DPMDMXString above

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PSDPMDMXPrettyString[ETX]
Read Variable Response:	[STX]sRA PSDPMDMXPrettyString 3 --- 3 --- 3 --- 3 ---[ETX]
Write Variable:	[STX]sWN PSDPMDMXPrettyString 3 --- 3 --- 3 --- 3 ---[ETX]
Write Variable Response:	[STX]sWA PSDPMDMXPrettyString[ETX]

2.37.32.14. Variable: ParameterSetsDPMDMXPrettyStringExt

The following section contains a detailed description of the variable ParameterSetsDPMDMXPrettyStringExt.

Variable Overview

Variable Name	Description
ParameterSetsDPMDMXPrettyStringExt	A beautified, human readable version of the DPMDMXString above

Communication Name	PSDPMDMXPrettyStringEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1551
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	FlexString	
	Length	0..100
	Initialisation	---

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PSDPMDMXPrettyStringEx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSDPMDMXPrettyStringEx	String	22	A beautified, human readable version of the DPMDMXString above

Read Variable Response:				
`sRA PSDPMDMXPrettyStringEx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSDPMDMXPrettyStringEx	String	22	A beautified, human readable version of the DPMDMXString above
Variable Data	data	Array	400	

Write Variable:				
`sWN PSDPMDMXPrettyStringEx <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSDPMDMXPrettyStringEx	String	22	A beautified, human readable version of the DPMDMXString above
Variable Data	data	Array	400	

Write Variable Response:				
`sWA PSDPMDMXPrettyStringEx`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSDPMDMXPrettyStringEx	String	22	A beautified, human readable version of the DPMDMXString above

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSDPMDMXPrettyStringEx[ETX]`
Read Variable Response:	`[STX]sRA PSDPMDMXPrettyStringEx 3 --- 3 --- 3 --- 3 ---[ETX]`
Write Variable:	`[STX]sWN PSDPMDMXPrettyStringEx 3 --- 3 --- 3 --- 3 ---[ETX]`
Write Variable Response:	`[STX]sWA PSDPMDMXPrettyStringEx[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.15. Variable: ParameterSetsL61xIlluminationLEDStates1

The following section contains a detailed description of the variable ParameterSetsL61xIlluminationLEDStates1.

Variable Overview

Variable Name	Description
ParameterSetsL61xIlluminationLEDStates1	LED states of Group A,B,C, and D.

Communication Name	PSL61xIlluLEDStat1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1552
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
UserType	
DPSIllu61xLedStates	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

```
sRN PSL61xIlluLEDStat1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSL61xIlluLEDStat1	String	18	LED states of Group A,B,C, and D.

Read Variable Response:

```
sRA PSL61xIlluLEDStat1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSL61xIlluLEDStat1	String	18	LED states of Group A,B,C, and D.
Variable Data	data	Array	2	

Write Variable:

```
sWN PSL61xIlluLEDStat1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSL61xIlluLEDStat1	String	18	LED states of Group A,B,C, and D.
Variable Data	data	Array	2	

Write Variable Response:

```
sWA PSL61xIlluLEDStat1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSL61xIlluLEDStat1	String	18	LED states of Group A,B,C, and D.

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSL61xIlluLEDStat1[ETX]`
Read Variable Response:	`[STX]sRA PSL61xIlluLEDStat1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1[ETX]`
Write Variable:	`[STX]sWN PSL61xIlluLEDStat1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1[ETX]`
Write Variable Response:	`[STX]sWA PSL61xIlluLEDStat1[ETX]`

2.37.32.16. Variable: ParameterSetsL61xIlluminationLEDStates1Ext

The following section contains a detailed description of the variable ParameterSetsL61xIlluminationLEDStates1Ext.

Variable Overview

Variable Name	Description
ParameterSetsL61xIlluminationLEDStates1Ext	LED states of Group A,B,C, and D.

Communication Name	PSL61xIlluLEDStat1Ex
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1553
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
UserType	
DPSIllu61xLedStates	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:

`sRN PSL61xIlluLEDStat1Ex`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSL61xIlluLEDStat1Ex	String	20	LED states of Group A,B,C, and D.

Read Variable Response:

`sRA PSL61xIlluLEDStat1Ex <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSL61xIlluLEDStat1Ex	String	20	LED states of Group A,B,C, and D.
Variable Data	data	Array	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN PSL61xIlluLEDStat1Ex <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSL61xIlluLEDStat1Ex	String	20	LED states of Group A,B,C, and D.
Variable Data	data	Array	2	

Write Variable Response:				
sWA PSL61xIlluLEDStat1Ex				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSL61xIlluLEDStat1Ex	String	20	LED states of Group A,B,C, and D.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PSL61xIlluLEDStat1Ex[ETX]
Read Variable Response:	[STX]sRA PSL61xIlluLEDStat1Ex 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1[ETX]
Write Variable:	[STX]sWN PSL61xIlluLEDStat1Ex 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1[ETX]
Write Variable Response:	[STX]sWA PSL61xIlluLEDStat1Ex[ETX]

2.37.32.17. Variable: ParameterSetsL61xIlluminationIntensity

The following section contains a detailed description of the variable ParameterSetsL61xIlluminationIntensity.

Variable Overview

Variable Name
ParameterSetsL61xIlluminationIntensity

Communication Name	PSL61xIlluInt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1554
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	UInt	
	Value Range	0..100
	Initialisation	70
	Physical Unit	%
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PSL61xIlluInt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSL61xIlluInt	String	13	

Read Variable Response:				
`sRA PSL61xIlluInt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSL61xIlluInt	String	13	
Variable Data	data	Array	8	

Write Variable:				
`sWN PSL61xIlluInt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSL61xIlluInt	String	13	
Variable Data	data	Array	8	

Write Variable Response:				
`sWA PSL61xIlluInt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSL61xIlluInt	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PSL61xIlluInt[ETX]`
Read Variable Response:	`[STX]sRA PSL61xIlluInt 46 46 46 46[ETX]`
Write Variable:	`[STX]sWN PSL61xIlluInt 46 46 46 46[ETX]`
Write Variable Response:	`[STX]sWA PSL61xIlluInt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.18. Variable: ParameterSetsL61xIlluminationIntensityExt

The following section contains a detailed description of the variable ParameterSetsL61xIlluminationIntensityExt.

Variable Overview

Variable Name
ParameterSetsL61xIlluminationIntensityExt

Communication Name	PSL61xIlluIntEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1555
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	UInt	
	Value Range	0..100
	Initialisation	70
	Physical Unit	%
	Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:
`sRN PSL61xIlluIntEx`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PSL61xIlluIntEx	String	15	

Read Variable Response:
`sRA PSL61xIlluIntEx <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PSL61xIlluIntEx	String	15	
Variable Data	data	Array	8	

Write Variable:
`sWN PSL61xIlluIntEx <data>`

Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PSL61xIlluIntEx	String	15	
Variable Data	data	Array	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PSL61xIlluIntEx				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PSL61xIlluIntEx	String	15	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PSL61xIlluIntEx[ETX]
Read Variable Response:	[STX]sRA PSL61xIlluIntEx 46 46 46 46[ETX]
Write Variable:	[STX]sWN PSL61xIlluIntEx 46 46 46 46[ETX]
Write Variable Response:	[STX]sWA PSL61xIlluIntEx[ETX]

2.37.32.19. Variable: ParameterSetEnabled

The following section contains a detailed description of the variable ParameterSetEnabled.

Variable Overview

Variable Name	Description
ParameterSetEnabled	Enable switch for each DPS/EPS slot

Communication Name	DPSEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1556
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array		
Length		4
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN DPSEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSEna	String	6	Enable switch for each DPS/EPS slot

Read Variable Response:				
`sRA DPSEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSEna	String	6	Enable switch for each DPS/EPS slot
Variable Data	data	Array	1	

Write Variable:				
`sWN DPSEna <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSEna	String	6	Enable switch for each DPS/EPS slot
Variable Data	data	Array	1	

Write Variable Response:				
`sWA DPSEna`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSEna	String	6	Enable switch for each DPS/EPS slot

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DPSEna[ETX]`
Read Variable Response:	`[STX]sRA DPSEna 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DPSEna 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DPSEna[ETX]`

© SICK AG - Germany - All rights reserved

2.37.32.20. Variable: ParameterSetEnabledExt

The following section contains a detailed description of the variable ParameterSetEnabledExt.

Variable Overview

Variable Name	Description
ParameterSetEnabledExt	Enable switch for each DPS/EPS slot

Communication Name	DPSEnaEx
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1557
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Array	
Length	4
Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN DPSEnaEx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DPSEnaEx	String	8	Enable switch for each DPS/EPS slot

Read Variable Response:

```
sRA DPSEnaEx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DPSEnaEx	String	8	Enable switch for each DPS/EPS slot
Variable Data	data	Array	1	

Write Variable:

```
sWN DPSEnaEx <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DPSEnaEx	String	8	Enable switch for each DPS/EPS slot
Variable Data	data	Array	1	

Write Variable Response:

```
sWA DPSEnaEx
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DPSEnaEx	String	8	Enable switch for each DPS/EPS slot

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN DPSEnaEx[ETX]`
Read Variable Response:	`[STX]sRA DPSEnaEx 0 0 0 0[ETX]`
Write Variable:	`[STX]sWN DPSEnaEx 0 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA DPSEnaEx[ETX]`

2.37.32.21. Method: ActivateEPSSet

The following section contains a detailed description of the method ActivateEPSSet.

Method Overview

Method Name	**Description**
ActivateEPSSet	Trigger method to switch between the four available EPS parameter sets

Communication Name	mEPSActSet
Sopas Index	153
Invocation Access	Always

Parameters			
SetIndex			
	Enum8		
	Default Value	Set1	
	Value	Name	Description
	1	Set1	
	2	Set2	
	3	Set3	
	4	Set4	
	5	Set5	
	6	Set6	
	7	Set7	
	8	Set8	

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mEPSActSet <SetIndex>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mEPSActSet	String	10	Trigger method to switch between the four available EPS parameter sets
Parameter 1	SetIndex	Enum8	1	

Method Return Value:				
`sAN mEPSActSet`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mEPSActSet	String	10	Trigger method to switch between the four available EPS parameter sets

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mEPSActSet 1[ETX]`
Method Return Value:	`[STX]sAN mEPSActSet[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33. Group: CollectionOfData

2.37.33.1. Variable: LabelPosTolerance

The following section contains a detailed description of the variable LabelPosTolerance.

Variable Overview

Variable Name	Description
LabelPosTolerance	Label assignment position tolerance

Communication Name	LblPosTlrc
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1558
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..1000
Initialisation	400
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN LblPosTlrc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LblPosTlrc	String	10	Label assignment position tolerance

Read Variable Response:

```
sRA LblPosTlrc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LblPosTlrc	String	10	Label assignment position tolerance
Variable Data	data	UInt	2	

Write Variable:

```
sWN LblPosTlrc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LblPosTlrc	String	10	Label assignment position tolerance
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LblPosTlrc				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LblPosTlrc	String	10	Label assignment position tolerance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LblPosTlrc[ETX]
Read Variable Response:	[STX]sRA LblPosTlrc 190[ETX]
Write Variable:	[STX]sWN LblPosTlrc 190[ETX]
Write Variable Response:	[STX]sWA LblPosTlrc[ETX]

2.37.33.2. Variable: ImageQueueTimeoutMM

The following section contains a detailed description of the variable ImageQueueTimeoutMM.

Variable Overview

Variable Name	Description
ImageQueueTimeoutMM	Image queue timeout distance

Communication Name	ImgQueueTimeoutMM
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1559
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..10000
Initialisation	400
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ImgQueueTimeoutMM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ImgQueueTimeoutMM	String	17	Image queue timeout distance

Read Variable Response:				
`sRA ImgQueueTimeoutMM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ImgQueueTimeoutMM	String	17	Image queue timeout distance
Variable Data	data	UInt	2	

Write Variable:				
`sWN ImgQueueTimeoutMM <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ImgQueueTimeoutMM	String	17	Image queue timeout distance
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA ImgQueueTimeoutMM`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ImgQueueTimeoutMM	String	17	Image queue timeout distance

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ImgQueueTimeoutMM[ETX]`
Read Variable Response:	`[STX]sRA ImgQueueTimeoutMM 190[ETX]`
Write Variable:	`[STX]sWN ImgQueueTimeoutMM 190[ETX]`
Write Variable Response:	`[STX]sWA ImgQueueTimeoutMM[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.3. Variable: ImageQueueTimeoutMS

The following section contains a detailed description of the variable ImageQueueTimeoutMS.

Variable Overview

Variable Name	Description
ImageQueueTimeoutMS	Image queue timeout time

Communication Name	ImgQueueTimeoutMS
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1560
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..10000
Initialisation	400
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ImgQueueTimeoutMS
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ImgQueueTimeoutMS	String	17	Image queue timeout time

Read Variable Response:

```
sRA ImgQueueTimeoutMS <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ImgQueueTimeoutMS	String	17	Image queue timeout time
Variable Data	data	UInt	2	

Write Variable:

```
sWN ImgQueueTimeoutMS <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ImgQueueTimeoutMS	String	17	Image queue timeout time
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA ImgQueueTimeoutMS
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ImgQueueTimeoutMS	String	17	Image queue timeout time

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ImgQueueTimeoutMS[ETX]`
Read Variable Response:	`[STX]sRA ImgQueueTimeoutMS 190[ETX]`
Write Variable:	`[STX]sWN ImgQueueTimeoutMS 190[ETX]`
Write Variable Response:	`[STX]sWA ImgQueueTimeoutMS[ETX]`

2.37.33.4. Variable: EnableImageQueueTimeout

The following section contains a detailed description of the variable EnableImageQueueTimeout.

Variable Overview

Variable Name	Description
EnableImageQueueTimeout	Enable image queue timeout

Communication Name	EnableImgQueueTimeout
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1561
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:				
`sRN EnableImgQueueTimeout`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EnableImgQueueTimeout	String	21	Enable image queue timeout

Read Variable Response:				
`sRA EnableImgQueueTimeout <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EnableImgQueueTimeout	String	21	Enable image queue timeout
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EnableImgQueueTimeout <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EnableImgQueueTimeout	String	21	Enable image queue timeout
Variable Data	data	Bool	1	

Write Variable Response:				
sWA EnableImgQueueTimeout				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EnableImgQueueTimeout	String	21	Enable image queue timeout

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EnableImgQueueTimeout[ETX]
Read Variable Response:	[STX]sRA EnableImgQueueTimeout 0[ETX]
Write Variable:	[STX]sWN EnableImgQueueTimeout 0[ETX]
Write Variable Response:	[STX]sWA EnableImgQueueTimeout[ETX]

2.37.33.5. Variable: EnableSkipImageByQueueSize

The following section contains a detailed description of the variable EnableSkipImageByQueueSize.

Variable Overview

Variable Name	Description
EnableSkipImageByQueueSize	Enable Skip Image By Queue Size

Communication Name	EnaSkipImgByQueueSize
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1562
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EnaSkipImgByQueueSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EnaSkipImgByQueueSize	String	21	Enable Skip Image By Queue Size

Read Variable Response:				
`sRA EnaSkipImgByQueueSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EnaSkipImgByQueueSize	String	21	Enable Skip Image By Queue Size
Variable Data	data	Bool	1	

Write Variable:				
`sWN EnaSkipImgByQueueSize <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EnaSkipImgByQueueSize	String	21	Enable Skip Image By Queue Size
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EnaSkipImgByQueueSize`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EnaSkipImgByQueueSize	String	21	Enable Skip Image By Queue Size

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EnaSkipImgByQueueSize[ETX]`
Read Variable Response:	`[STX]sRA EnaSkipImgByQueueSize 0[ETX]`
Write Variable:	`[STX]sWN EnaSkipImgByQueueSize 0[ETX]`
Write Variable Response:	`[STX]sWA EnaSkipImgByQueueSize[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.6. Variable: EnableOptimizeObjCap

The following section contains a detailed description of the variable EnableOptimizeObjCap.

Variable Overview

Variable Name	Description
EnableOptimizeObjCap	Optimized Object Capturing

Communication Name	EnaOptObjectCap
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1563
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN EnaOptObjectCap
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EnaOptObjectCap	String	15	Optimized Object Capturing

Read Variable Response:

```
sRA EnaOptObjectCap <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EnaOptObjectCap	String	15	Optimized Object Capturing
Variable Data	data	Bool	1	

Write Variable:

```
sWN EnaOptObjectCap <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EnaOptObjectCap	String	15	Optimized Object Capturing
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA EnaOptObjectCap
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EnaOptObjectCap	String	15	Optimized Object Capturing

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EnaOptObjectCap[ETX]`
Read Variable Response:	`[STX]sRA EnaOptObjectCap 0[ETX]`
Write Variable:	`[STX]sWN EnaOptObjectCap 0[ETX]`
Write Variable Response:	`[STX]sWA EnaOptObjectCap[ETX]`

2.37.33.7. Variable: SkipImgQueueFillLevel1

The following section contains a detailed description of the variable SkipImgQueueFillLevel1.

Variable Overview

Variable Name	Description
SkipImgQueueFillLevel1	Fill Level1 starting skipping Images

Communication Name	SkipImgQuFillLevel1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1564
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	10
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgQuFillLevel1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgQuFillLevel1	String	19	Fill Level1 starting skipping Images

Read Variable Response:				
`sRA SkipImgQuFillLevel1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgQuFillLevel1	String	19	Fill Level1 starting skipping Images
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SkipImgQuFillLevel1 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgQuFillLevel1	String	19	Fill Level1 starting skipping Images
Variable Data	data	UInt	2	

Write Variable Response:				
sWA SkipImgQuFillLevel1				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgQuFillLevel1	String	19	Fill Level1 starting skipping Images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SkipImgQuFillLevel1[ETX]
Read Variable Response:	[STX]sRA SkipImgQuFillLevel1 A[ETX]
Write Variable:	[STX]sWN SkipImgQuFillLevel1 A[ETX]
Write Variable Response:	[STX]sWA SkipImgQuFillLevel1[ETX]

2.37.33.8. Variable: SkipImageByQueueSize1

The following section contains a detailed description of the variable SkipImageByQueueSize1.

Variable Overview

Variable Name	Description
SkipImageByQueueSize1	Number of skiped images at 0 to 19 degree of filling

Communication Name	SkipImgByQuSize1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1565
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgByQuSize1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgByQuSize1	String	16	Number of skiped images at 0 to 19 degree of filling

Read Variable Response:				
`sRA SkipImgByQuSize1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgByQuSize1	String	16	Number of skiped images at 0 to 19 degree of filling
Variable Data	data	UInt	2	

Write Variable:				
`sWN SkipImgByQuSize1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgByQuSize1	String	16	Number of skiped images at 0 to 19 degree of filling
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA SkipImgByQuSize1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgByQuSize1	String	16	Number of skiped images at 0 to 19 degree of filling

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SkipImgByQuSize1[ETX]`
Read Variable Response:	`[STX]sRA SkipImgByQuSize1 1[ETX]`
Write Variable:	`[STX]sWN SkipImgByQuSize1 1[ETX]`
Write Variable Response:	`[STX]sWA SkipImgByQuSize1[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.9. Variable: SkipImgQueueFillLevel2

The following section contains a detailed description of the variable SkipImgQueueFillLevel2.

Variable Overview

Variable Name	Description
SkipImgQueueFillLevel2	Fill Level2 starting skipping Images

Communication Name	SkipImgQuFillLevel2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1566
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	20
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SkipImgQuFillLevel2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgQuFillLevel2	String	19	Fill Level2 starting skipping Images

Read Variable Response:

```
sRA SkipImgQuFillLevel2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgQuFillLevel2	String	19	Fill Level2 starting skipping Images
Variable Data	data	UInt	2	

Write Variable:

```
sWN SkipImgQuFillLevel2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgQuFillLevel2	String	19	Fill Level2 starting skipping Images
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA SkipImgQuFillLevel2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgQuFillLevel2	String	19	Fill Level2 starting skipping Images

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SkipImgQuFillLevel2[ETX]`
Read Variable Response:	`[STX]sRA SkipImgQuFillLevel2 14[ETX]`
Write Variable:	`[STX]sWN SkipImgQuFillLevel2 14[ETX]`
Write Variable Response:	`[STX]sWA SkipImgQuFillLevel2[ETX]`

2.37.33.10. Variable: SkipImageByQueueSize2

The following section contains a detailed description of the variable SkipImageByQueueSize2.

Variable Overview

Variable Name	Description
SkipImageByQueueSize2	Number of skiped images at 20 to 39 degree of filling

Communication Name	SkipImgByQuSize2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1567
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	2
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgByQuSize2`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgByQuSize2	String	16	Number of skiped images at 20 to 39 degree of filling

Read Variable Response:				
`sRA SkipImgByQuSize2 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgByQuSize2	String	16	Number of skiped images at 20 to 39 degree of filling
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SkipImgByQuSize2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgByQuSize2	String	16	Number of skiped images at 20 to 39 degree of filling
Variable Data	data	UInt	2	

Write Variable Response:				
sWA SkipImgByQuSize2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgByQuSize2	String	16	Number of skiped images at 20 to 39 degree of filling

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SkipImgByQuSize2[ETX]
Read Variable Response:	[STX]sRA SkipImgByQuSize2 2[ETX]
Write Variable:	[STX]sWN SkipImgByQuSize2 2[ETX]
Write Variable Response:	[STX]sWA SkipImgByQuSize2[ETX]

2.37.33.11. Variable: SkipImgQueueFillLevel3

The following section contains a detailed description of the variable SkipImgQueueFillLevel3.

Variable Overview

Variable Name	Description
SkipImgQueueFillLevel3	Fill Level3 starting skipping Images

Communication Name	SkipImgQuFillLevel3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1568
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	30
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgQuFillLevel3`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgQuFillLevel3	String	19	Fill Level3 starting skipping Images

Read Variable Response:				
`sRA SkipImgQuFillLevel3 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgQuFillLevel3	String	19	Fill Level3 starting skipping Images
Variable Data	data	UInt	2	

Write Variable:				
`sWN SkipImgQuFillLevel3 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgQuFillLevel3	String	19	Fill Level3 starting skipping Images
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA SkipImgQuFillLevel3`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgQuFillLevel3	String	19	Fill Level3 starting skipping Images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SkipImgQuFillLevel3[ETX]`
Read Variable Response:	`[STX]sRA SkipImgQuFillLevel3 1E[ETX]`
Write Variable:	`[STX]sWN SkipImgQuFillLevel3 1E[ETX]`
Write Variable Response:	`[STX]sWA SkipImgQuFillLevel3[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.12. Variable: SkipImageByQueueSize3

The following section contains a detailed description of the variable SkipImageByQueueSize3.

Variable Overview

Variable Name	Description
SkipImageByQueueSize3	Number of skiped images at 40 to 59 degree of filling

Communication Name	SkipImgByQuSize3
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1569
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	4
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SkipImgByQuSize3
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgByQuSize3	String	16	Number of skiped images at 40 to 59 degree of filling

Read Variable Response:

```
sRA SkipImgByQuSize3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgByQuSize3	String	16	Number of skiped images at 40 to 59 degree of filling
Variable Data	data	UInt	2	

Write Variable:

```
sWN SkipImgByQuSize3 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgByQuSize3	String	16	Number of skiped images at 40 to 59 degree of filling
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SkipImgByQuSize3				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgByQuSize3	String	16	Number of skiped images at 40 to 59 degree of filling

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SkipImgByQuSize3[ETX]
Read Variable Response:	[STX]sRA SkipImgByQuSize3 4[ETX]
Write Variable:	[STX]sWN SkipImgByQuSize3 4[ETX]
Write Variable Response:	[STX]sWA SkipImgByQuSize3[ETX]

2.37.33.13. Variable: SkipImgQueueFillLevel4

The following section contains a detailed description of the variable SkipImgQueueFillLevel4.

Variable Overview

Variable Name	Description
SkipImgQueueFillLevel4	Fill Level4 starting skipping Images

Communication Name	SkipImgQuFillLevel4
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1570
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	40
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgQuFillLevel4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgQuFillLevel4	String	19	Fill Level4 starting skipping Images

Read Variable Response:				
`sRA SkipImgQuFillLevel4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgQuFillLevel4	String	19	Fill Level4 starting skipping Images
Variable Data	data	UInt	2	

Write Variable:				
`sWN SkipImgQuFillLevel4 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgQuFillLevel4	String	19	Fill Level4 starting skipping Images
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA SkipImgQuFillLevel4`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgQuFillLevel4	String	19	Fill Level4 starting skipping Images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SkipImgQuFillLevel4[ETX]`
Read Variable Response:	`[STX]sRA SkipImgQuFillLevel4 28[ETX]`
Write Variable:	`[STX]sWN SkipImgQuFillLevel4 28[ETX]`
Write Variable Response:	`[STX]sWA SkipImgQuFillLevel4[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.14. Variable: SkipImageByQueueSize4

The following section contains a detailed description of the variable SkipImageByQueueSize4.

Variable Overview

Variable Name	Description
SkipImageByQueueSize4	Number of skiped images at 60 to 79 degree of filling

Communication Name	SkipImgByQuSize4
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1571
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	8
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SkipImgByQuSize4
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgByQuSize4	String	16	Number of skiped images at 60 to 79 degree of filling

Read Variable Response:

```
sRA SkipImgByQuSize4 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgByQuSize4	String	16	Number of skiped images at 60 to 79 degree of filling
Variable Data	data	UInt	2	

Write Variable:

```
sWN SkipImgByQuSize4 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgByQuSize4	String	16	Number of skiped images at 60 to 79 degree of filling
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SkipImgByQuSize4				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgByQuSize4	String	16	Number of skiped images at 60 to 79 degree of filling

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SkipImgByQuSize4[ETX]
Read Variable Response:	[STX]sRA SkipImgByQuSize4 8[ETX]
Write Variable:	[STX]sWN SkipImgByQuSize4 8[ETX]
Write Variable Response:	[STX]sWA SkipImgByQuSize4[ETX]

2.37.33.15. Variable: SkipImgQueueFillLevel5

The following section contains a detailed description of the variable SkipImgQueueFillLevel5.

Variable Overview

Variable Name	Description
SkipImgQueueFillLevel5	Fill Level5 starting skipping Images

Communication Name	SkipImgQuFillLevel5
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1572
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	60
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgQuFillLevel5`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgQuFillLevel5	String	19	Fill Level5 starting skipping Images

Read Variable Response:				
`sRA SkipImgQuFillLevel5 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgQuFillLevel5	String	19	Fill Level5 starting skipping Images
Variable Data	data	UInt	2	

Write Variable:				
`sWN SkipImgQuFillLevel5 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgQuFillLevel5	String	19	Fill Level5 starting skipping Images
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA SkipImgQuFillLevel5`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgQuFillLevel5	String	19	Fill Level5 starting skipping Images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SkipImgQuFillLevel5[ETX]`
Read Variable Response:	`[STX]sRA SkipImgQuFillLevel5 3C[ETX]`
Write Variable:	`[STX]sWN SkipImgQuFillLevel5 3C[ETX]`
Write Variable Response:	`[STX]sWA SkipImgQuFillLevel5[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.16. Variable: SkipImageByQueueSize5

The following section contains a detailed description of the variable SkipImageByQueueSize5.

Variable Overview

Variable Name	Description
SkipImageByQueueSize5	Number of skiped images at 60 to 79 degree of filling

Communication Name	SkipImgByQuSize5
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1573
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	16
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN SkipImgByQuSize5
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgByQuSize5	String	16	Number of skiped images at 60 to 79 degree of filling

Read Variable Response:

```
sRA SkipImgByQuSize5 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgByQuSize5	String	16	Number of skiped images at 60 to 79 degree of filling
Variable Data	data	UInt	2	

Write Variable:

```
sWN SkipImgByQuSize5 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgByQuSize5	String	16	Number of skiped images at 60 to 79 degree of filling
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SkipImgByQuSize5				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgByQuSize5	String	16	Number of skiped images at 60 to 79 degree of filling

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SkipImgByQuSize5[ETX]
Read Variable Response:	[STX]sRA SkipImgByQuSize5 10[ETX]
Write Variable:	[STX]sWN SkipImgByQuSize5 10[ETX]
Write Variable Response:	[STX]sWA SkipImgByQuSize5[ETX]

2.37.33.17. Variable: SkipImgQueueFillLevel6

The following section contains a detailed description of the variable SkipImgQueueFillLevel6.

Variable Overview

Variable Name	Description
SkipImgQueueFillLevel6	Fill Level skipping all Images

Communication Name	SkipImgQuFillLevel6
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1574
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

UInt	
Value Range	0..65535
Initialisation	75
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SkipImgQuFillLevel6`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SkipImgQuFillLevel6	String	19	Fill Level skipping all Images

Read Variable Response:				
`sRA SkipImgQuFillLevel6 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SkipImgQuFillLevel6	String	19	Fill Level skipping all Images
Variable Data	data	UInt	2	

Write Variable:				
`sWN SkipImgQuFillLevel6 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SkipImgQuFillLevel6	String	19	Fill Level skipping all Images
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA SkipImgQuFillLevel6`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SkipImgQuFillLevel6	String	19	Fill Level skipping all Images

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SkipImgQuFillLevel6[ETX]`
Read Variable Response:	`[STX]sRA SkipImgQuFillLevel6 4B[ETX]`
Write Variable:	`[STX]sWN SkipImgQuFillLevel6 4B[ETX]`
Write Variable Response:	`[STX]sWA SkipImgQuFillLevel6[ETX]`

© SICK AG - Germany - All rights reserved

2.37.33.18. Variable: CodePositionByImageMultipleEnable

The following section contains a detailed description of the variable CodePositionByImageMultipleEnable.

Variable Overview

Variable Name	Description
CodePositionByImageMultipleEnable	Code Position By Multiple Image Enable

Communication Name	CodePosImgMultiEna
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1575
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN CodePosImgMultiEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CodePosImgMultiEna	String	18	Code Position By Multiple Image Enable

Read Variable Response:

```
sRA CodePosImgMultiEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CodePosImgMultiEna	String	18	Code Position By Multiple Image Enable
Variable Data	data	Bool	1	

Write Variable:

```
sWN CodePosImgMultiEna <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CodePosImgMultiEna	String	18	Code Position By Multiple Image Enable
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA CodePosImgMultiEna
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CodePosImgMultiEna	String	18	Code Position By Multiple Image Enable

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CodePosImgMultiEna[ETX]`
Read Variable Response:	`[STX]sRA CodePosImgMultiEna 0[ETX]`
Write Variable:	`[STX]sWN CodePosImgMultiEna 0[ETX]`
Write Variable Response:	`[STX]sWA CodePosImgMultiEna[ETX]`

2.37.33.19. Variable: CodeMultiImageToleranceFactor

The following section contains a detailed description of the variable CodeMultiImageToleranceFactor.

Variable Overview

Variable Name	Description
CodeMultiImageToleranceFactor	Label assignment position tolerance factor for multi image

Communication Name	CodePosImgMultiFactor
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1576
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Real	
Value Range	See specification IEEE 754 0.0..10.0
Initialisation	1.0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN CodePosImgMultiFactor`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CodePosImgMultiFactor	String	21	Label assignment position tolerance factor for multi image

Read Variable Response:

`sRA CodePosImgMultiFactor <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CodePosImgMultiFactor	String	21	Label assignment position tolerance factor for multi image
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN CodePosImgMultiFactor <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CodePosImgMultiFactor	String	21	Label assignment position tolerance factor for multi image
Variable Data	data	Real	4	

Write Variable Response:				
sWA CodePosImgMultiFactor				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CodePosImgMultiFactor	String	21	Label assignment position tolerance factor for multi image

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CodePosImgMultiFactor[ETX]
Read Variable Response:	[STX]sRA CodePosImgMultiFactor 3F800000[ETX]
Write Variable:	[STX]sWN CodePosImgMultiFactor 3F800000[ETX]
Write Variable Response:	[STX]sWA CodePosImgMultiFactor[ETX]

2.37.33.20. Variable: EnableSystemOptimizingParameter

The following section contains a detailed description of the variable EnableSystemOptimizingParameter.

Variable Overview

Variable Name	Description
EnableSystemOptimizingParameter	Enable the system optimizing paramter

Communication Name	EnableSysOptiParam
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1577
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EnableSysOptiParam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EnableSysOptiParam	String	18	Enable the system optimizing paramter

Read Variable Response:				
`sRA EnableSysOptiParam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EnableSysOptiParam	String	18	Enable the system optimizing paramter
Variable Data	data	Bool	1	

Write Variable:				
`sWN EnableSysOptiParam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EnableSysOptiParam	String	18	Enable the system optimizing paramter
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA EnableSysOptiParam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EnableSysOptiParam	String	18	Enable the system optimizing paramter

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EnableSysOptiParam[ETX]`
Read Variable Response:	`[STX]sRA EnableSysOptiParam 0[ETX]`
Write Variable:	`[STX]sWN EnableSysOptiParam 0[ETX]`
Write Variable Response:	`[STX]sWA EnableSysOptiParam[ETX]`

© SICK AG - Germany - All rights reserved

2.37.34. Group: Profinet

2.37.34.1. Variable: cdpPnioSelectDataFormat

The following section contains a detailed description of the variable cdpPnioSelectDataFormat.

Variable Overview

Variable Name	Description
cdpPnioSelectDataFormat	Format string for user data

Communication Name	cdpPnioSelDataFrmt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1578
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		OUTPUT_FORMAT_1	
	Value	Name	Description
	0	NO_OUTPUT	
	1	OUTPUT_FORMAT_1	
	2	OUTPUT_FORMAT_2	

Variable Telegram Syntax

Read Variable:				
`sRN cdpPnioSelDataFrmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	cdpPnioSelDataFrmt	String	18	Format string for user data

Read Variable Response:				
`sRA cdpPnioSelDataFrmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	cdpPnioSelDataFrmt	String	18	Format string for user data
Variable Data	data	Enum8	1	

Write Variable:				
`sWN cdpPnioSelDataFrmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	cdpPnioSelDataFrmt	String	18	Format string for user data
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA cdpPnioSelDataFrmt				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	cdpPnioSelDataFrmt	String	18	Format string for user data

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN cdpPnioSelDataFrmt[ETX]
Read Variable Response:	[STX]sRA cdpPnioSelDataFrmt 1[ETX]
Write Variable:	[STX]sWN cdpPnioSelDataFrmt 1[ETX]
Write Variable Response:	[STX]sWA cdpPnioSelDataFrmt[ETX]

© SICK AG - Germany - All rights reserved

2.37.35. Group: PresentationMode

2.37.35.1. Variable: PMSensitivityThreshold

The following section contains a detailed description of the variable PMSensitivityThreshold.

Variable Overview

Variable Name	Description
PMSensitivityThreshold	Sets the sensivity of the movement detection.

Communication Name	PMSensThresh
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1579
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..10
Initialisation	5
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN PMSensThresh
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMSensThresh	String	12	Sets the sensivity of the movement detection.

Read Variable Response:

```
sRA PMSensThresh <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMSensThresh	String	12	Sets the sensivity of the movement detection.
Variable Data	data	UInt	2	

Write Variable:

```
sWN PMSensThresh <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMSensThresh	String	12	Sets the sensivity of the movement detection.
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PMSensThresh				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMSensThresh	String	12	Sets the sensivity of the movement detection.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PMSensThresh[ETX]
Read Variable Response:	[STX]sRA PMSensThresh 5[ETX]
Write Variable:	[STX]sWN PMSensThresh 5[ETX]
Write Variable Response:	[STX]sWA PMSensThresh[ETX]

2.37.35.2. Variable: PMReTrigPause

The following section contains a detailed description of the variable PMReTrigPause.

Variable Overview

Variable Name	Description
PMReTrigPause	Delay beteween reading gate end and start of movement detection.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1580
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	800
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PMReTrigPause`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMReTrigPause	String	13	Delay beteween reading gate end and start of movement detection.

Read Variable Response:				
`sRA PMReTrigPause <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMReTrigPause	String	13	Delay beteween reading gate end and start of movement detection.
Variable Data	data	UInt	2	

Write Variable:				
`sWN PMReTrigPause <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMReTrigPause	String	13	Delay beteween reading gate end and start of movement detection.
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA PMReTrigPause`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMReTrigPause	String	13	Delay beteween reading gate end and start of movement detection.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PMReTrigPause[ETX]`
Read Variable Response:	`[STX]sRA PMReTrigPause 320[ETX]`
Write Variable:	`[STX]sWN PMReTrigPause 320[ETX]`
Write Variable Response:	`[STX]sWA PMReTrigPause[ETX]`

© SICK AG - Germany - All rights reserved

2.37.35.3. Variable: PMMovDectTimeout

The following section contains a detailed description of the variable PMMovDectTimeout.

Variable Overview

Variable Name	Description
PMMovDectTimeout	Tolerance in ms, defining the max. distance between movment detections after which gate_off is fired.

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1581
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	200
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN PMMovDectTimeout
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMMovDectTimeout	String	16	Tolerance in ms, defining the max. distance between movment detections after which gate_off is fired.

Read Variable Response:

```
sRA PMMovDectTimeout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMMovDectTimeout	String	16	Tolerance in ms, defining the max. distance between movment detections after which gate_off is fired.
Variable Data	data	UInt	2	

Write Variable:

```
sWN PMMovDectTimeout <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMMovDectTimeout	String	16	Tolerance in ms, defining the max. distance between movment detections after which gate_off is fired.
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PMMovDectTimeout				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMMovDectTimeout	String	16	Tolerance in ms, defining the max. distance between movment detections after which gate_off is fired.

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PMMovDectTimeout[ETX]
Read Variable Response:	[STX]sRA PMMovDectTimeout C8[ETX]
Write Variable:	[STX]sWN PMMovDectTimeout C8[ETX]
Write Variable Response:	[STX]sWA PMMovDectTimeout[ETX]

2.37.35.4. Variable: PMSleepTriggerTime

The following section contains a detailed description of the variable PMSleepTriggerTime.

Variable Overview

Variable Name	Description
PMSleepTriggerTime	Activate sleep after trigger time

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1595
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..10000
Initialisation	600
Physical Unit	s
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PMSleepTriggerTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMSleepTriggerTime	String	18	Activate sleep after trigger time

Read Variable Response:				
`sRA PMSleepTriggerTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMSleepTriggerTime	String	18	Activate sleep after trigger time
Variable Data	data	UInt	2	

Write Variable:				
`sWN PMSleepTriggerTime <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMSleepTriggerTime	String	18	Activate sleep after trigger time
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA PMSleepTriggerTime`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMSleepTriggerTime	String	18	Activate sleep after trigger time

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PMSleepTriggerTime[ETX]`
Read Variable Response:	`[STX]sRA PMSleepTriggerTime 258[ETX]`
Write Variable:	`[STX]sWN PMSleepTriggerTime 258[ETX]`
Write Variable Response:	`[STX]sWA PMSleepTriggerTime[ETX]`

© SICK AG - Germany - All rights reserved

2.37.35.5. Variable: PMRepetitiveContentFilteringEnabled

The following section contains a detailed description of the variable PMRepetitiveContentFilteringEnabled.

Variable Overview

Variable Name	Description
PMRepetitiveContentFilteringEnabled	Enable redundancy score measurement for presentation, LECTOR6XX-2970

Communication Name	PMRepFEn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1605
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN PMRepFEn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMRepFEn	String	8	Enable redundancy score measurement for presentation, LECTOR6XX-2970

Read Variable Response:

```
sRA PMRepFEn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMRepFEn	String	8	Enable redundancy score measurement for presentation, LECTOR6XX-2970
Variable Data	data	Bool	1	

Write Variable:

```
sWN PMRepFEn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMRepFEn	String	8	Enable redundancy score measurement for presentation, LECTOR6XX-2970
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA PMRepFEn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PMRepFEn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	PMRepFEn	String	8	Enable redundancy score measurement for presentation, LECTOR6XX-2970

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PMRepFEn[ETX]
Read Variable Response:	[STX]sRA PMRepFEn 0[ETX]
Write Variable:	[STX]sWN PMRepFEn 0[ETX]
Write Variable Response:	[STX]sWA PMRepFEn[ETX]

2.37.35.6. Variable: PMRepetitiveContentFilteringNumObjects

The following section contains a detailed description of the variable PMRepetitiveContentFilteringNumObjects.

Variable Overview

Variable Name	Description
PMRepetitiveContentFilteringNumObjects	Number of past Objects to include in redundancy score computation

Communication Name	PMRepFNumOb
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1606
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..50
Initialisation	3
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PMRepFNumOb`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMRepFNumOb	String	11	Number of past Objects to include in redundancy score computation

Read Variable Response:				
`sRA PMRepFNumOb <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMRepFNumOb	String	11	Number of past Objects to include in redundancy score computation
Variable Data	data	UInt	2	

Write Variable:				
`sWN PMRepFNumOb <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMRepFNumOb	String	11	Number of past Objects to include in redundancy score computation
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA PMRepFNumOb`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMRepFNumOb	String	11	Number of past Objects to include in redundancy score computation

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PMRepFNumOb[ETX]`
Read Variable Response:	`[STX]sRA PMRepFNumOb 3[ETX]`
Write Variable:	`[STX]sWN PMRepFNumOb 3[ETX]`
Write Variable Response:	`[STX]sWA PMRepFNumOb[ETX]`

© SICK AG - Germany - All rights reserved

2.37.35.7. Variable: PMRepetitiveContentFilteringMaxAge

The following section contains a detailed description of the variable PMRepetitiveContentFilteringMaxAge.

Variable Overview

Variable Name	Description
PMRepetitiveContentFilteringMaxAge	Maximum age of past Objects to participate in redundancy score computation

Communication Name	PMRepFAge
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1607
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1..36000
Initialisation	60
Physical Unit	s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN PMRepFAge`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMRepFAge	String	9	Maximum age of past Objects to participate in redundancy score computation

Read Variable Response:				
`sRA PMRepFAge <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMRepFAge	String	9	Maximum age of past Objects to participate in redundancy score computation
Variable Data	data	UInt	2	

Write Variable:				
`sWN PMRepFAge <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMRepFAge	String	9	Maximum age of past Objects to participate in redundancy score computation
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PMRepFAge				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMRepFAge	String	9	Maximum age of past Objects to participate in redundancy score computation

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PMRepFAge[ETX]
Read Variable Response:	[STX]sRA PMRepFAge 3C[ETX]
Write Variable:	[STX]sWN PMRepFAge 3C[ETX]
Write Variable Response:	[STX]sWA PMRepFAge[ETX]

2.37.35.8. Variable: PMSleepModeEnabled

The following section contains a detailed description of the variable PMSleepModeEnabled.

Variable Overview

Variable Name	Description
PMSleepModeEnabled	Enable sleep mode

Communication Name	PMSleepModeEnbld
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1594
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN PMSleepModeEnbld`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMSleepModeEnbld	String	16	Enable sleep mode

Read Variable Response:				
`sRA PMSleepModeEnbld <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMSleepModeEnbld	String	16	Enable sleep mode
Variable Data	data	Bool	1	

Write Variable:				
`sWN PMSleepModeEnbld <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMSleepModeEnbld	String	16	Enable sleep mode
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA PMSleepModeEnbld`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMSleepModeEnbld	String	16	Enable sleep mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN PMSleepModeEnbld[ETX]`
Read Variable Response:	`[STX]sRA PMSleepModeEnbld 0[ETX]`
Write Variable:	`[STX]sWN PMSleepModeEnbld 0[ETX]`
Write Variable Response:	`[STX]sWA PMSleepModeEnbld[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36. Group: ExternalDataInputHandling

2.37.36.1. Variable: SerHostInputHandling

The following section contains a detailed description of the variable SerHostInputHandling.

Variable Overview

Variable Name	Description
SerHostInputHandling	Handling method for Input data on Serial Host interface

Communication Name	SIHstInp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1608
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_INPUT_DATA	
	Value	Name	Description
	0	TX_NO_INPUT_DATA	
	1	TX_INPUT_DATA_FORWARDING	
	2	TX_INPUT_DATA_AUXRESULT	
	3	TX_INPUT_DATA_STRING_FOR_OUTFORMAT	

Variable Telegram Syntax

Read Variable:

```
sRN SIHstInp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIHstInp	String	8	Handling method for Input data on Serial Host interface

Read Variable Response:

```
sRA SIHstInp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIHstInp	String	8	Handling method for Input data on Serial Host interface
Variable Data	data	Enum8	1	

Write Variable:

```
sWN SIHstInp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIHstInp	String	8	Handling method for Input data on Serial Host interface
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SIHstInp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIHstInp	String	8	Handling method for Input data on Serial Host interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SIHstInp[ETX]
Read Variable Response:	[STX]sRA SIHstInp 0[ETX]
Write Variable:	[STX]sWN SIHstInp 0[ETX]
Write Variable Response:	[STX]sWA SIHstInp[ETX]

2.37.36.2. Variable: SerAuxInputHandling

The following section contains a detailed description of the variable SerAuxInputHandling.

Variable Overview

Variable Name	Description
SerAuxInputHandling	Handling method for Input data on serial aux interface

Communication Name	SIAuxtInp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1609
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_INPUT_DATA	
	Value	Name	Description
	0	TX_NO_INPUT_DATA	
	1	TX_INPUT_DATA_FORWARDING	
	2	TX_INPUT_DATA_AUXRESULT	
	3	TX_INPUT_DATA_STRING_FOR_OUTFORMAT	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SIAuxtInp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SIAuxtInp	String	9	Handling method for Input data on serial aux interface

Read Variable Response:				
`sRA SIAuxtInp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SIAuxtInp	String	9	Handling method for Input data on serial aux interface
Variable Data	data	Enum8	1	

Write Variable:				
`sWN SIAuxtInp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SIAuxtInp	String	9	Handling method for Input data on serial aux interface
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA SIAuxtInp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SIAuxtInp	String	9	Handling method for Input data on serial aux interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SIAuxtInp[ETX]`
Read Variable Response:	`[STX]sRA SIAuxtInp 0[ETX]`
Write Variable:	`[STX]sWN SIAuxtInp 0[ETX]`
Write Variable Response:	`[STX]sWA SIAuxtInp[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36.3. Variable: EtherHostInputHandling

The following section contains a detailed description of the variable EtherHostInputHandling.

Variable Overview

Variable Name	Description
EtherHostInputHandling	Handling method for Input data on ethernet host interface

Communication Name	EIHstInp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1610
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_INPUT_DATA	
	Value	Name	Description
	0	TX_NO_INPUT_DATA	
	1	TX_INPUT_DATA_FORWARDING	
	2	TX_INPUT_DATA_AUXRESULT	
	3	TX_INPUT_DATA_STRING_FOR_OUTFORMAT	

Variable Telegram Syntax

Read Variable:

```
sRN EIHstInp
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIHstInp	String	8	Handling method for Input data on ethernet host interface

Read Variable Response:

```
sRA EIHstInp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIHstInp	String	8	Handling method for Input data on ethernet host interface
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EIHstInp <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIHstInp	String	8	Handling method for Input data on ethernet host interface
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIHstInp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIHstInp	String	8	Handling method for Input data on ethernet host interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIHstInp[ETX]
Read Variable Response:	[STX]sRA EIHstInp 0[ETX]
Write Variable:	[STX]sWN EIHstInp 0[ETX]
Write Variable Response:	[STX]sWA EIHstInp[ETX]

2.37.36.4. Variable: EtherAuxInputHandling

The following section contains a detailed description of the variable EtherAuxInputHandling.

Variable Overview

Variable Name	Description
EtherAuxInputHandling	Handling method for Input data on Ethernet Aux interface

Communication Name	EIAuxInp
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1611
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_NO_INPUT_DATA	
	Value	Name	Description
	0	TX_NO_INPUT_DATA	
	1	TX_INPUT_DATA_FORWARDING	
	2	TX_INPUT_DATA_AUXRESULT	
	3	TX_INPUT_DATA_STRING_FOR_OUTFORMAT	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EIAuxInp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIAuxInp	String	8	Handling method for Input data on Ethernet Aux interface

Read Variable Response:				
`sRA EIAuxInp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIAuxInp	String	8	Handling method for Input data on Ethernet Aux interface
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EIAuxInp <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIAuxInp	String	8	Handling method for Input data on Ethernet Aux interface
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EIAuxInp`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIAuxInp	String	8	Handling method for Input data on Ethernet Aux interface

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EIAuxInp[ETX]`
Read Variable Response:	`[STX]sRA EIAuxInp 0[ETX]`
Write Variable:	`[STX]sWN EIAuxInp 0[ETX]`
Write Variable Response:	`[STX]sWA EIAuxInp[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36.5. Variable: ED_DataForwardDestination

The following section contains a detailed description of the variable ED_DataForwardDestination.

Variable Overview

Variable Name	Description
ED_DataForwardDestination	Destination interface for data forwareding

Communication Name	EDFwDs
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1612
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_EDI_FWD_DST_SER_AUX	
	Value	Name	Description
	0	TX_EDI_FWD_DST_SER_HOST	
	1	TX_EDI_FWD_DST_SER_AUX	
	2	TX_EDI_FWD_DST_ETH_HOST	
	3	TX_EDI_FWD_DST_ETH_AUX	

Variable Telegram Syntax

Read Variable:

```
sRN EDFwDs
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDFwDs	String	6	Destination interface for data forwareding

Read Variable Response:

```
sRA EDFwDs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDFwDs	String	6	Destination interface for data forwareding
Variable Data	data	Enum8	1	

Write Variable:

```
sWN EDFwDs <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDFwDs	String	6	Destination interface for data forwareding
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EDFwDs				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDFwDs	String	6	Destination interface for data forwareding

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EDFwDs[ETX]
Read Variable Response:	[STX]sRA EDFwDs 1[ETX]
Write Variable:	[STX]sWN EDFwDs 1[ETX]
Write Variable Response:	[STX]sWA EDFwDs[ETX]

2.37.36.6. Variable: ED_DataForwardFrameRxHeader

The following section contains a detailed description of the variable ED_DataForwardFrameRxHeader.

Variable Overview

Variable Name	Description
ED_DataForwardFrameRxHeader	Defines the receive framing start characters for Data Forwarding Commands

Communication Name	EDFwRFH
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1613
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x02/

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EDFwRFH`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDFwRFH	String	7	Defines the receive framing start characters for Data Forwarding Commands

Read Variable Response:				
`sRA EDFwRFH <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDFwRFH	String	7	Defines the receive framing start characters for Data Forwarding Commands
Variable Data	data	FlexString	10	

Write Variable:				
`sWN EDFwRFH <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDFwRFH	String	7	Defines the receive framing start characters for Data Forwarding Commands
Variable Data	data	FlexString	10	

Write Variable Response:				
`sWA EDFwRFH`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDFwRFH	String	7	Defines the receive framing start characters for Data Forwarding Commands

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EDFwRFH[ETX]`
Read Variable Response:	`[STX]sRA EDFwRFH 5 \x02/[ETX]`
Write Variable:	`[STX]sWN EDFwRFH 5 \x02/[ETX]`
Write Variable Response:	`[STX]sWA EDFwRFH[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36.7. Variable: ED_DataForwardFrameRxTerminator

The following section contains a detailed description of the variable ED_DataForwardFrameRxTerminator.

Variable Overview

Variable Name	Description
ED_DataForwardFrameRxTerminator	Defines the receive framing stop characters for Data Forwarding Commands

Communication Name	EDFwRFT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1614
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x03

Variable Telegram Syntax

Read Variable:

```
sRN EDFwRFT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDFwRFT	String	7	Defines the receive framing stop characters for Data Forwarding Commands

Read Variable Response:

```
sRA EDFwRFT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDFwRFT	String	7	Defines the receive framing stop characters for Data Forwarding Commands
Variable Data	data	FlexString	10	

Write Variable:

```
sWN EDFwRFT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDFwRFT	String	7	Defines the receive framing stop characters for Data Forwarding Commands
Variable Data	data	FlexString	10	

Write Variable Response:

```
sWA EDFwRFT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EDFwRFT				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EDFwRFT	String	7	Defines the receive framing stop characters for Data Forwarding Commands

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EDFwRFT[ETX]
Read Variable Response:	[STX]sRA EDFwRFT 4 \x03[ETX]
Write Variable:	[STX]sWN EDFwRFT 4 \x03[ETX]
Write Variable Response:	[STX]sWA EDFwRFT[ETX]

2.37.36.8. Variable: ED_DataForwardFrameTxHeader

The following section contains a detailed description of the variable ED_DataForwardFrameTxHeader.

Variable Overview

Variable Name	Description
ED_DataForwardFrameTxHeader	Defines the transmit framing start characters for Data Forwarding

Communication Name	EDFwTFH
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1615
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x02/

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EDFwTFH`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDFwTFH	String	7	Defines the transmit framing start characters for Data Forwarding

Read Variable Response:				
`sRA EDFwTFH <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDFwTFH	String	7	Defines the transmit framing start characters for Data Forwarding
Variable Data	data	FlexString	10	

Write Variable:				
`sWN EDFwTFH <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDFwTFH	String	7	Defines the transmit framing start characters for Data Forwarding
Variable Data	data	FlexString	10	

Write Variable Response:				
`sWA EDFwTFH`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDFwTFH	String	7	Defines the transmit framing start characters for Data Forwarding

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EDFwTFH[ETX]`
Read Variable Response:	`[STX]sRA EDFwTFH 5 \x02/[ETX]`
Write Variable:	`[STX]sWN EDFwTFH 5 \x02/[ETX]`
Write Variable Response:	`[STX]sWA EDFwTFH[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36.9. Variable: ED_DataForwardFrameTxTerminator

The following section contains a detailed description of the variable ED_DataForwardFrameTxTerminator.

Variable Overview

Variable Name	Description
ED_DataForwardFrameTxTerminator	Defines the transmit framing stop characters for Data Forwarding

Communication Name	EDFwTFT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1616
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x03

Variable Telegram Syntax

Read Variable:

```
sRN EDFwTFT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDFwTFT	String	7	Defines the transmit framing stop characters for Data Forwarding

Read Variable Response:

```
sRA EDFwTFT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDFwTFT	String	7	Defines the transmit framing stop characters for Data Forwarding
Variable Data	data	FlexString	10	

Write Variable:

```
sWN EDFwTFT <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDFwTFT	String	7	Defines the transmit framing stop characters for Data Forwarding
Variable Data	data	FlexString	10	

Write Variable Response:

```
sWA EDFwTFT
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EDFwTFT				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EDFwTFT	String	7	Defines the transmit framing stop characters for Data Forwarding

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EDFwTFT[ETX]
Read Variable Response:	[STX]sRA EDFwTFT 4 \x03[ETX]
Write Variable:	[STX]sWN EDFwTFT 4 \x03[ETX]
Write Variable Response:	[STX]sWA EDFwTFT[ETX]

2.37.36.10. Variable: ED_AuxReadResultBarcodeType

The following section contains a detailed description of the variable ED_AuxReadResultBarcodeType.

Variable Overview

Variable Name	Description
ED_AuxReadResultBarcodeType	Defines ihow to determine the code type for the auxiliary read result: Use fixed code type or set to undefined to use the first input character as barcode type identifier

Communication Name	EDArsTy
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1617
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		TX_EDI_RS_TYPE_C39	
	Value	Name	Description
	0	TX_EDI_RS_TYPE_BY_IDENTIFIER	
	1	TX_EDI_RS_TYPE_CODABAR	
	2	TX_EDI_RS_TYPE_C39	
	3	TX_EDI_RS_TYPE_EAN	
	4	TX_EDI_RS_TYPE_UPC	
	5	TX_EDI_RS_TYPE_25IL	
	6	TX_EDI_RS_TYPE_C93	
	7	TX_EDI_RS_TYPE_C128	
	8	TX_EDI_RS_TYPE_GS1DATABAR	
	9	TX_EDI_RS_TYPE_PHARMA	
	10	TX_EDI_RS_TYPE_DATAMATRIX	
	11	TX_EDI_RS_TYPE_QRCODE	
	12	TX_EDI_RS_TYPE_MAXICODE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EDArsTy`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDArsTy	String	7	Defines ihow to determine the code type for the auxiliary read result: Use fixed code type or set to undefined to use the first input character as barcode type identifier

Read Variable Response:				
`sRA EDArsTy <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDArsTy	String	7	Defines ihow to determine the code type for the auxiliary read result: Use fixed code type or set to undefined to use the first input character as barcode type identifier
Variable Data	data	Enum8	1	

Write Variable:				
`sWN EDArsTy <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDArsTy	String	7	Defines ihow to determine the code type for the auxiliary read result: Use fixed code type or set to undefined to use the first input character as barcode type identifier
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA EDArsTy`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDArsTy	String	7	Defines ihow to determine the code type for the auxiliary read result: Use fixed code type or set to undefined to use the first input character as barcode type identifier

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EDArsTy[ETX]`
Read Variable Response:	`[STX]sRA EDArsTy 2[ETX]`
Write Variable:	`[STX]sWN EDArsTy 2[ETX]`
Write Variable Response:	`[STX]sWA EDArsTy[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36.11. Variable: ED_AuxReadResultFrameRxHeader

The following section contains a detailed description of the variable ED_AuxReadResultFrameRxHeader.

Variable Overview

Variable Name	Description
ED_AuxReadResultFrameRxHeader	Defines the receive framing start characters for Data Aux read result Commands

Communication Name	EDArsRFH
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1618
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x02>

Variable Telegram Syntax

Read Variable:

```
sRN EDArsRFH
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDArsRFH	String	8	Defines the receive framing start characters for Data Aux read result Commands

Read Variable Response:

```
sRA EDArsRFH <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDArsRFH	String	8	Defines the receive framing start characters for Data Aux read result Commands
Variable Data	data	FlexString	10	

Write Variable:

```
sWN EDArsRFH <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDArsRFH	String	8	Defines the receive framing start characters for Data Aux read result Commands
Variable Data	data	FlexString	10	

Write Variable Response:

```
sWA EDArsRFH
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EDArsRFH				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	EDArsRFH	String	8	Defines the receive framing start characters for Data Aux read result Commands

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EDArsRFH[ETX]
Read Variable Response:	[STX]sRA EDArsRFH 5 \x02>[ETX]
Write Variable:	[STX]sWN EDArsRFH 5 \x02>[ETX]
Write Variable Response:	[STX]sWA EDArsRFH[ETX]

2.37.36.12. Variable: ED_AuxReadResultFrameRxTerminator

The following section contains a detailed description of the variable ED_AuxReadResultFrameRxTerminator.

Variable Overview

Variable Name	Description
ED_AuxReadResultFrameRxTerminator	Defines the receive framing stop characters for Aux read result Commands

Communication Name	EDArsRFT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1619
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x03

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EDArsRFT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDArsRFT	String	8	Defines the receive framing stop characters for Aux read result Commands

Read Variable Response:				
`sRA EDArsRFT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDArsRFT	String	8	Defines the receive framing stop characters for Aux read result Commands
Variable Data	data	FlexString	10	

Write Variable:				
`sWN EDArsRFT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDArsRFT	String	8	Defines the receive framing stop characters for Aux read result Commands
Variable Data	data	FlexString	10	

Write Variable Response:				
`sWA EDArsRFT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDArsRFT	String	8	Defines the receive framing stop characters for Aux read result Commands

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EDArsRFT[ETX]`
Read Variable Response:	`[STX]sRA EDArsRFT 4 \x03[ETX]`
Write Variable:	`[STX]sWN EDArsRFT 4 \x03[ETX]`
Write Variable Response:	`[STX]sWA EDArsRFT[ETX]`

© SICK AG - Germany - All rights reserved

2.37.36.13. Variable: ED_DataStringAcqDefault

The following section contains a detailed description of the variable ED_DataStringAcqDefault.

Variable Overview

Variable Name	Description
ED_DataStringAcqDefault	default value for string acqusition

Communication Name	EDAcqDf
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1620
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..50
Initialisation	NoDataReceived

Variable Telegram Syntax

Read Variable:

```
sRN EDAcqDf
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDAcqDf	String	7	default value for string acqusition

Read Variable Response:

```
sRA EDAcqDf <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDAcqDf	String	7	default value for string acqusition
Variable Data	data	FlexString	50	

Write Variable:

```
sWN EDAcqDf <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDAcqDf	String	7	default value for string acqusition
Variable Data	data	FlexString	50	

Write Variable Response:

```
sWA EDAcqDf
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDAcqDf	String	7	default value for string acqusition

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EDAcqDf[ETX]`
Read Variable Response:	`[STX]sRA EDAcqDf E NoDataReceived[ETX]`
Write Variable:	`[STX]sWN EDAcqDf E NoDataReceived[ETX]`
Write Variable Response:	`[STX]sWA EDAcqDf[ETX]`

2.37.36.14. Variable: ED_DataStringAcqFrameRxHeader

The following section contains a detailed description of the variable ED_DataStringAcqFrameRxHeader.

Variable Overview

Variable Name	Description
ED_DataStringAcqFrameRxHeader	Defines the receive framing start characters for Data string acquisition Commands

Communication Name	EDAcqRFH
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1621
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x02&

Variable Telegram Syntax

Read Variable:				
`sRN EDAcqRFH`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDAcqRFH	String	8	Defines the receive framing start characters for Data string acquisition Commands

Read Variable Response:				
`sRA EDAcqRFH <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDAcqRFH	String	8	Defines the receive framing start characters for Data string acquisition Commands
Variable Data	data	FlexString	10	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN EDAcqRFH <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDAcqRFH	String	8	Defines the receive framing start characters for Data string acquisition Commands
Variable Data	data	FlexString	10	

Write Variable Response:				
sWA EDAcqRFH				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDAcqRFH	String	8	Defines the receive framing start characters for Data string acquisition Commands

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EDAcqRFH[ETX]
Read Variable Response:	[STX]sRA EDAcqRFH 5 \x02&[ETX]
Write Variable:	[STX]sWN EDAcqRFH 5 \x02&[ETX]
Write Variable Response:	[STX]sWA EDAcqRFH[ETX]

2.37.36.15. Variable: ED_DataStringAcqFrameRxTerminator

The following section contains a detailed description of the variable ED_DataStringAcqFrameRxTerminator.

Variable Overview

Variable Name	Description
ED_DataStringAcqFrameRxTerminator	Defines the receive framing stop characters for Data string acquisition Commands

Communication Name	EDAcqRFT
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1622
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..10
Initialisation	\x03

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN EDAcqRFT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EDAcqRFT	String	8	Defines the receive framing stop characters for Data string acquisition Commands

Read Variable Response:				
`sRA EDAcqRFT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EDAcqRFT	String	8	Defines the receive framing stop characters for Data string acquisition Commands
Variable Data	data	FlexString	10	

Write Variable:				
`sWN EDAcqRFT <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EDAcqRFT	String	8	Defines the receive framing stop characters for Data string acquisition Commands
Variable Data	data	FlexString	10	

Write Variable Response:				
`sWA EDAcqRFT`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EDAcqRFT	String	8	Defines the receive framing stop characters for Data string acquisition Commands

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN EDAcqRFT[ETX]`
Read Variable Response:	`[STX]sRA EDAcqRFT 4 \x03[ETX]`
Write Variable:	`[STX]sWN EDAcqRFT 4 \x03[ETX]`
Write Variable Response:	`[STX]sWA EDAcqRFT[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37. Group: ScriptParameters

2.37.37.1. Variable: ScriptParam01

The following section contains a detailed description of the variable ScriptParam01.

Variable Overview

Variable Name	Description
ScriptParam01	Script parameter 1

Communication Name	SP01
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1624
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP01
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP01	String	4	Script parameter 1

Read Variable Response:

```
sRA SP01 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP01	String	4	Script parameter 1
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP01 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP01	String	4	Script parameter 1
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP01
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA SP01				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	SP01	String	4	Script parameter 1

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SP01[ETX]
Read Variable Response:	[STX]sRA SP01 0[ETX]
Write Variable:	[STX]sWN SP01 0[ETX]
Write Variable Response:	[STX]sWA SP01[ETX]

2.37.37.2. Variable: ScriptParam02

The following section contains a detailed description of the variable ScriptParam02.

Variable Overview

Variable Name	Description
ScriptParam02	Script parameter 2

Communication Name	SP02
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1626
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP02`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP02	String	4	Script parameter 2

Read Variable Response:				
`sRA SP02 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP02	String	4	Script parameter 2
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP02 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP02	String	4	Script parameter 2
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP02`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP02	String	4	Script parameter 2

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP02[ETX]`
Read Variable Response:	`[STX]sRA SP02 0[ETX]`
Write Variable:	`[STX]sWN SP02 0[ETX]`
Write Variable Response:	`[STX]sWA SP02[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37.3. Variable: ScriptParam03

The following section contains a detailed description of the variable ScriptParam03.

Variable Overview

Variable Name	Description
ScriptParam03	Script parameter 3

Communication Name	SP03
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1628
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP03
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP03	String	4	Script parameter 3

Read Variable Response:

```
sRA SP03 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP03	String	4	Script parameter 3
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP03 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP03	String	4	Script parameter 3
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP03
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP03	String	4	Script parameter 3

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP03[ETX]`
Read Variable Response:	`[STX]sRA SP03 0[ETX]`
Write Variable:	`[STX]sWN SP03 0[ETX]`
Write Variable Response:	`[STX]sWA SP03[ETX]`

2.37.37.4. Variable: ScriptParam04

The following section contains a detailed description of the variable ScriptParam04.

Variable Overview

Variable Name	Description
ScriptParam04	Script parameter 4

Communication Name	SP04
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1630
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP04
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP04	String	4	Script parameter 4

Read Variable Response:

```
sRA SP04 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP04	String	4	Script parameter 4
Variable Data	data	FlexString	32	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SP04 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP04	String	4	Script parameter 4
Variable Data	data	FlexString	32	

Write Variable Response:				
sWA SP04				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP04	String	4	Script parameter 4

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SP04[ETX]
Read Variable Response:	[STX]sRA SP04 0[ETX]
Write Variable:	[STX]sWN SP04 0[ETX]
Write Variable Response:	[STX]sWA SP04[ETX]

2.37.37.5. Variable: ScriptParam05

The following section contains a detailed description of the variable ScriptParam05.

Variable Overview

Variable Name	Description
ScriptParam05	Script parameter 5

Communication Name	SP05
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1632
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP05`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP05	String	4	Script parameter 5

Read Variable Response:				
`sRA SP05 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP05	String	4	Script parameter 5
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP05 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP05	String	4	Script parameter 5
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP05`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP05	String	4	Script parameter 5

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP05[ETX]`
Read Variable Response:	`[STX]sRA SP05 0[ETX]`
Write Variable:	`[STX]sWN SP05 0[ETX]`
Write Variable Response:	`[STX]sWA SP05[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37.6. Variable: ScriptParam06

The following section contains a detailed description of the variable ScriptParam06.

Variable Overview

Variable Name	Description
ScriptParam06	Script parameter 6

Communication Name	SP06
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1634
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP06
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP06	String	4	Script parameter 6

Read Variable Response:

```
sRA SP06 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP06	String	4	Script parameter 6
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP06 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP06	String	4	Script parameter 6
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP06
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP06	String	4	Script parameter 6

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP06[ETX]`
Read Variable Response:	`[STX]sRA SP06 0[ETX]`
Write Variable:	`[STX]sWN SP06 0[ETX]`
Write Variable Response:	`[STX]sWA SP06[ETX]`

2.37.37.7. Variable: ScriptParam07

The following section contains a detailed description of the variable ScriptParam07.

Variable Overview

Variable Name	Description
ScriptParam07	Script parameter 7

Communication Name	SP07
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1636
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:				
`sRN SP07`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP07	String	4	Script parameter 7

Read Variable Response:				
`sRA SP07 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP07	String	4	Script parameter 7
Variable Data	data	FlexString	32	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN SP07 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP07	String	4	Script parameter 7
Variable Data	data	FlexString	32	

Write Variable Response:				
sWA SP07				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP07	String	4	Script parameter 7

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN SP07[ETX]
Read Variable Response:	[STX]sRA SP07 0[ETX]
Write Variable:	[STX]sWN SP07 0[ETX]
Write Variable Response:	[STX]sWA SP07[ETX]

2.37.37.8. Variable: ScriptParam08

The following section contains a detailed description of the variable ScriptParam08.

Variable Overview

Variable Name	Description
ScriptParam08	Script parameter 8

Communication Name	SP08
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1638
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP08`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP08	String	4	Script parameter 8

Read Variable Response:				
`sRA SP08 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP08	String	4	Script parameter 8
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP08 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP08	String	4	Script parameter 8
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP08`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP08	String	4	Script parameter 8

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP08[ETX]`
Read Variable Response:	`[STX]sRA SP08 0[ETX]`
Write Variable:	`[STX]sWN SP08 0[ETX]`
Write Variable Response:	`[STX]sWA SP08[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37.9. Variable: ScriptParam09

The following section contains a detailed description of the variable ScriptParam09.

Variable Overview

Variable Name	Description
ScriptParam09	Script parameter 9

Communication Name	SP09
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1640
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP09
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP09	String	4	Script parameter 9

Read Variable Response:

```
sRA SP09 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP09	String	4	Script parameter 9
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP09 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP09	String	4	Script parameter 9
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP09
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP09	String	4	Script parameter 9

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP09[ETX]`
Read Variable Response:	`[STX]sRA SP09 0[ETX]`
Write Variable:	`[STX]sWN SP09 0[ETX]`
Write Variable Response:	`[STX]sWA SP09[ETX]`

2.37.37.10. Variable: ScriptParam10

The following section contains a detailed description of the variable ScriptParam10.

Variable Overview

Variable Name	Description
ScriptParam10	Script parameter 10

Communication Name	SP10
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1642
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:				
`sRN SP10`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP10	String	4	Script parameter 10

Read Variable Response:				
`sRA SP10 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP10	String	4	Script parameter 10
Variable Data	data	FlexString	32	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN SP10 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP10	String	4	Script parameter 10
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP10`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP10	String	4	Script parameter 10

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP10[ETX]`
Read Variable Response:	`[STX]sRA SP10 0[ETX]`
Write Variable:	`[STX]sWN SP10 0[ETX]`
Write Variable Response:	`[STX]sWA SP10[ETX]`

2.37.37.11. Variable: ScriptParam11

The following section contains a detailed description of the variable ScriptParam11.

Variable Overview

Variable Name	Description
ScriptParam11	Script parameter 11

Communication Name	SP11
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1644
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP11`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP11	String	4	Script parameter 11

Read Variable Response:				
`sRA SP11 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP11	String	4	Script parameter 11
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP11 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP11	String	4	Script parameter 11
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP11`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP11	String	4	Script parameter 11

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP11[ETX]`
Read Variable Response:	`[STX]sRA SP11 0[ETX]`
Write Variable:	`[STX]sWN SP11 0[ETX]`
Write Variable Response:	`[STX]sWA SP11[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37.12. Variable: ScriptParam12

The following section contains a detailed description of the variable ScriptParam12.

Variable Overview

Variable Name	Description
ScriptParam12	Script parameter 12

Communication Name	SP12
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1646
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP12
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP12	String	4	Script parameter 12

Read Variable Response:

```
sRA SP12 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP12	String	4	Script parameter 12
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP12 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP12	String	4	Script parameter 12
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP12
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP12	String	4	Script parameter 12

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP12[ETX]`
Read Variable Response:	`[STX]sRA SP12 0[ETX]`
Write Variable:	`[STX]sWN SP12 0[ETX]`
Write Variable Response:	`[STX]sWA SP12[ETX]`

2.37.37.13. Variable: ScriptParam13

The following section contains a detailed description of the variable ScriptParam13.

Variable Overview

Variable Name	Description
ScriptParam13	Script parameter 13

Communication Name	SP13
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1648
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

`sRN SP13`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP13	String	4	Script parameter 13

Read Variable Response:

`sRA SP13 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP13	String	4	Script parameter 13
Variable Data	data	FlexString	32	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN SP13 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP13	String	4	Script parameter 13
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP13`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP13	String	4	Script parameter 13

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP13[ETX]`
Read Variable Response:	`[STX]sRA SP13 0[ETX]`
Write Variable:	`[STX]sWN SP13 0[ETX]`
Write Variable Response:	`[STX]sWA SP13[ETX]`

2.37.37.14. Variable: ScriptParam14

The following section contains a detailed description of the variable ScriptParam14.

Variable Overview

Variable Name	Description
ScriptParam14	Script parameter 14

Communication Name	SP14
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1650
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP14`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP14	String	4	Script parameter 14

Read Variable Response:				
`sRA SP14 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP14	String	4	Script parameter 14
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP14 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP14	String	4	Script parameter 14
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP14`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP14	String	4	Script parameter 14

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP14[ETX]`
Read Variable Response:	`[STX]sRA SP14 0[ETX]`
Write Variable:	`[STX]sWN SP14 0[ETX]`
Write Variable Response:	`[STX]sWA SP14[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37.15. Variable: ScriptParam15

The following section contains a detailed description of the variable ScriptParam15.

Variable Overview

Variable Name	Description
ScriptParam15	Script parameter 15

Communication Name	SP15
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1652
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP15
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP15	String	4	Script parameter 15

Read Variable Response:

```
sRA SP15 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP15	String	4	Script parameter 15
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP15 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP15	String	4	Script parameter 15
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP15
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP15	String	4	Script parameter 15

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP15[ETX]`
Read Variable Response:	`[STX]sRA SP15 0[ETX]`
Write Variable:	`[STX]sWN SP15 0[ETX]`
Write Variable Response:	`[STX]sWA SP15[ETX]`

2.37.37.16. Variable: ScriptParam16

The following section contains a detailed description of the variable ScriptParam16.

Variable Overview

Variable Name	Description
ScriptParam16	Script parameter 16

Communication Name	SP16
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1654
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

`sRN SP16`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP16	String	4	Script parameter 16

Read Variable Response:

`sRA SP16 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP16	String	4	Script parameter 16
Variable Data	data	FlexString	32	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN SP16 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP16	String	4	Script parameter 16
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP16`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP16	String	4	Script parameter 16

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP16[ETX]`
Read Variable Response:	`[STX]sRA SP16 0[ETX]`
Write Variable:	`[STX]sWN SP16 0[ETX]`
Write Variable Response:	`[STX]sWA SP16[ETX]`

2.37.37.17. Variable: ScriptParam17

The following section contains a detailed description of the variable ScriptParam17.

Variable Overview

Variable Name	Description
ScriptParam17	Script parameter 17

Communication Name	SP17
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1656
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP17`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP17	String	4	Script parameter 17

Read Variable Response:				
`sRA SP17 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP17	String	4	Script parameter 17
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP17 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP17	String	4	Script parameter 17
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP17`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP17	String	4	Script parameter 17

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP17[ETX]`
Read Variable Response:	`[STX]sRA SP17 0[ETX]`
Write Variable:	`[STX]sWN SP17 0[ETX]`
Write Variable Response:	`[STX]sWA SP17[ETX]`

© SICK AG - Germany - All rights reserved

2.37.37.18. Variable: ScriptParam18

The following section contains a detailed description of the variable ScriptParam18.

Variable Overview

Variable Name	Description
ScriptParam18	Script parameter 18

Communication Name	SP18
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1658
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN SP18
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP18	String	4	Script parameter 18

Read Variable Response:

```
sRA SP18 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP18	String	4	Script parameter 18
Variable Data	data	FlexString	32	

Write Variable:

```
sWN SP18 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP18	String	4	Script parameter 18
Variable Data	data	FlexString	32	

Write Variable Response:

```
sWA SP18
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP18	String	4	Script parameter 18

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP18[ETX]`
Read Variable Response:	`[STX]sRA SP18 0[ETX]`
Write Variable:	`[STX]sWN SP18 0[ETX]`
Write Variable Response:	`[STX]sWA SP18[ETX]`

2.37.37.19. Variable: ScriptParam19

The following section contains a detailed description of the variable ScriptParam19.

Variable Overview

Variable Name	Description
ScriptParam19	Script parameter 19

Communication Name	SP19
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1660
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

Variable Telegram Syntax

Read Variable:				
`sRN SP19`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP19	String	4	Script parameter 19

Read Variable Response:				
`sRA SP19 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP19	String	4	Script parameter 19
Variable Data	data	FlexString	32	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN SP19 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP19	String	4	Script parameter 19
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP19`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP19	String	4	Script parameter 19

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP19[ETX]`
Read Variable Response:	`[STX]sRA SP19 0[ETX]`
Write Variable:	`[STX]sWN SP19 0[ETX]`
Write Variable Response:	`[STX]sWA SP19[ETX]`

2.37.37.20. Variable: ScriptParam20

The following section contains a detailed description of the variable ScriptParam20.

Variable Overview

Variable Name	Description
ScriptParam20	Script parameter 20

Communication Name	SP20
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1662
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..32
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN SP20`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	SP20	String	4	Script parameter 20

Read Variable Response:				
`sRA SP20 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	SP20	String	4	Script parameter 20
Variable Data	data	FlexString	32	

Write Variable:				
`sWN SP20 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	SP20	String	4	Script parameter 20
Variable Data	data	FlexString	32	

Write Variable Response:				
`sWA SP20`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	SP20	String	4	Script parameter 20

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN SP20[ETX]`
Read Variable Response:	`[STX]sRA SP20 0[ETX]`
Write Variable:	`[STX]sWN SP20 0[ETX]`
Write Variable Response:	`[STX]sWA SP20[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38. Group: BackwardMode

2.37.38.1. Variable: BWDEnableMode

The following section contains a detailed description of the variable BWDEnableMode.

Variable Overview

Variable Name	Description
BWDEnableMode	Enables the backward mode for backward mode

Communication Name	BWDEnaMod
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1663
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN BWDEnaMod
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDEnaMod	String	9	Enables the backward mode for backward mode

Read Variable Response:

```
sRA BWDEnaMod <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDEnaMod	String	9	Enables the backward mode for backward mode
Variable Data	data	Bool	1	

Write Variable:

```
sWN BWDEnaMod <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDEnaMod	String	9	Enables the backward mode for backward mode
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA BWDEnaMod
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDEnaMod				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	BWDEnaMod	String	9	Enables the backward mode for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDEnaMod[ETX]
Read Variable Response:	[STX]sRA BWDEnaMod 0[ETX]
Write Variable:	[STX]sWN BWDEnaMod 0[ETX]
Write Variable Response:	[STX]sWA BWDEnaMod[ETX]

2.37.38.2. Variable: BWDDistanceBwdTrigger

The following section contains a detailed description of the variable BWDDistanceBwdTrigger.

Variable Overview

Variable Name	Description
BWDDistanceBwdTrigger	Distance between trigger and backward trigger

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1664
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..50000
Initialisation	3000
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDDistanceBwdTrigger`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDDistanceBwdTrigger	String	21	Distance between trigger and backward trigger

Read Variable Response:				
`sRA BWDDistanceBwdTrigger <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDDistanceBwdTrigger	String	21	Distance between trigger and backward trigger
Variable Data	data	UDInt	4	

Write Variable:				
`sWN BWDDistanceBwdTrigger <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDDistanceBwdTrigger	String	21	Distance between trigger and backward trigger
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA BWDDistanceBwdTrigger`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDDistanceBwdTrigger	String	21	Distance between trigger and backward trigger

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDDistanceBwdTrigger[ETX]`
Read Variable Response:	`[STX]sRA BWDDistanceBwdTrigger BB8[ETX]`
Write Variable:	`[STX]sWN BWDDistanceBwdTrigger BB8[ETX]`
Write Variable Response:	`[STX]sWA BWDDistanceBwdTrigger[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.3. Variable: BWDBeltWidth

The following section contains a detailed description of the variable BWDBeltWidth.

Variable Overview

Variable Name	Description
BWDBeltWidth	Belt width

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1665
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..5000
Initialisation	1200
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDBeltWidth
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDBeltWidth	String	12	Belt width

Read Variable Response:

```
sRA BWDBeltWidth <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDBeltWidth	String	12	Belt width
Variable Data	data	UDInt	4	

Write Variable:

```
sWN BWDBeltWidth <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDBeltWidth	String	12	Belt width
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA BWDBeltWidth
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDBeltWidth	String	12	Belt width

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDBeltWidth[ETX]`
Read Variable Response:	`[STX]sRA BWDBeltWidth 4B0[ETX]`
Write Variable:	`[STX]sWN BWDBeltWidth 4B0[ETX]`
Write Variable Response:	`[STX]sWA BWDBeltWidth[ETX]`

2.37.38.4. Variable: BWDCalcTriggerPreExpand

The following section contains a detailed description of the variable BWDCalcTriggerPreExpand.

Variable Overview

Variable Name	Description
BWDCalcTriggerPreExpand	calculated value pre expation of the trigger or backward mode

Communication Name	BWDRCCalcTriggerPreExpand
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1666
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN BWDRCCalcTriggerPreExpand`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDRCCalcTriggerPreExpand	String	25	calculated value pre expation of the trigger or backward mode

Read Variable Response:

`sRA BWDRCCalcTriggerPreExpand <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDRCCalcTriggerPreExpand	String	25	calculated value pre expation of the trigger or backward mode
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN BWDRCCalcTriggerPreExpand <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDRCCalcTriggerPreExpand	String	25	calculated value pre expation of the trigger or backward mode
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA BWDRCCalcTriggerPreExpand`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDRCCalcTriggerPreExpand	String	25	calculated value pre expation of the trigger or backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDRCCalcTriggerPreExpand[ETX]`
Read Variable Response:	`[STX]sRA BWDRCCalcTriggerPreExpand 0[ETX]`
Write Variable:	`[STX]sWN BWDRCCalcTriggerPreExpand 0[ETX]`
Write Variable Response:	`[STX]sWA BWDRCCalcTriggerPreExpand[ETX]`

2.37.38.5. Variable: BWDCalcTriggerPostExpand

The following section contains a detailed description of the variable BWDCalcTriggerPostExpand.

Variable Overview

Variable Name	Description
BWDCalcTriggerPostExpand	calculated value of the post expation he trigger or backward mode

Communication Name	BWDRCCalcTriggerPostExpand
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1667
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-2147483648..2147483647
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDRCCalcTriggerPostExpand`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDRCCalcTriggerPostExpand	String	26	calculated value of the post expation he trigger or backward mode

Read Variable Response:				
`sRA BWDRCCalcTriggerPostExpand <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDRCCalcTriggerPostExpand	String	26	calculated value of the post expation he trigger or backward mode
Variable Data	data	DInt	4	

Write Variable:				
`sWN BWDRCCalcTriggerPostExpand <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDRCCalcTriggerPostExpand	String	26	calculated value of the post expation he trigger or backward mode
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA BWDRCCalcTriggerPostExpand`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDRCCalcTriggerPostExpand	String	26	calculated value of the post expation he trigger or backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDRCCalcTriggerPostExpand[ETX]`
Read Variable Response:	`[STX]sRA BWDRCCalcTriggerPostExpand 0[ETX]`
Write Variable:	`[STX]sWN BWDRCCalcTriggerPostExpand 0[ETX]`
Write Variable Response:	`[STX]sWA BWDRCCalcTriggerPostExpand[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.6. Variable: BWDFocusPosition

The following section contains a detailed description of the variable BWDFocusPosition.

Variable Overview

Variable Name	Description
BWDFocusPosition	Focus position i.e. distance from camera to object in mm. for backward mode

Communication Name	BWDFocPos
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1668
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	1300
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDFocPos
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDFocPos	String	9	Focus position i.e. distance from camera to object in mm. for backward mode

Read Variable Response:

```
sRA BWDFocPos <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDFocPos	String	9	Focus position i.e. distance from camera to object in mm. for backward mode
Variable Data	data	UDInt	4	

Write Variable:

```
sWN BWDFocPos <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDFocPos	String	9	Focus position i.e. distance from camera to object in mm. for backward mode
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDFocPos				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDFocPos	String	9	Focus position i.e. distance from camera to object in mm. for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDFocPos[ETX]
Read Variable Response:	[STX]sRA BWDFocPos 514[ETX]
Write Variable:	[STX]sWN BWDFocPos 514[ETX]
Write Variable Response:	[STX]sWA BWDFocPos[ETX]

2.37.38.7. Variable: BWDRCReadingAreaLimY1

The following section contains a detailed description of the variable BWDRCReadingAreaLimY1.

Variable Overview

Variable Name	Description
BWDRCReadingAreaLimY1	Y1 reading area. Right edge of conveyor for backward mode

Communication Name	BWDRCRdArlimY1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1669
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDRCRdArlimY1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDRCRdArlimY1	String	14	Y1 reading area. Right edge of conveyor for backward mode

Read Variable Response:				
`sRA BWDRCRdArlimY1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDRCRdArlimY1	String	14	Y1 reading area. Right edge of conveyor for backward mode
Variable Data	data	DInt	4	

Write Variable:				
`sWN BWDRCRdArlimY1 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDRCRdArlimY1	String	14	Y1 reading area. Right edge of conveyor for backward mode
Variable Data	data	DInt	4	

Write Variable Response:				
`sWA BWDRCRdArlimY1`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDRCRdArlimY1	String	14	Y1 reading area. Right edge of conveyor for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDRCRdArlimY1[ETX]`
Read Variable Response:	`[STX]sRA BWDRCRdArlimY1 0[ETX]`
Write Variable:	`[STX]sWN BWDRCRdArlimY1 0[ETX]`
Write Variable Response:	`[STX]sWA BWDRCRdArlimY1[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.8. Variable: BWDRCReadingAreaLimY2

The following section contains a detailed description of the variable BWDRCReadingAreaLimY2.

Variable Overview

Variable Name	Description
BWDRCReadingAreaLimY2	Y2 reading area. Left edge of conveyor for backward mode

Communication Name	BWDRCRdArlimY2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1671
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

DInt	
Value Range	-3000..3000
Initialisation	1200
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDRCRdArlimY2
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDRCRdArlimY2	String	14	Y2 reading area. Left edge of conveyor for backward mode

Read Variable Response:

```
sRA BWDRCRdArlimY2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDRCRdArlimY2	String	14	Y2 reading area. Left edge of conveyor for backward mode
Variable Data	data	DInt	4	

Write Variable:

```
sWN BWDRCRdArlimY2 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDRCRdArlimY2	String	14	Y2 reading area. Left edge of conveyor for backward mode
Variable Data	data	DInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDRCRdArlimY2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDRCRdArlimY2	String	14	Y2 reading area. Left edge of conveyor for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDRCRdArlimY2[ETX]
Read Variable Response:	[STX]sRA BWDRCRdArlimY2 4B0[ETX]
Write Variable:	[STX]sWN BWDRCRdArlimY2 4B0[ETX]
Write Variable Response:	[STX]sWA BWDRCRdArlimY2[ETX]

2.37.38.9. Variable: BWDDistMeasSourceVMSNodeID

The following section contains a detailed description of the variable BWDDistMeasSourceVMSNodeID.

Variable Overview

Variable Name	Description
BWDDistMeasSourceVMSNodeID	CAN Node ID of distance measurement source VDS/MSC for backward mode

Communication Name	BWDDMsrcVMSnodeID
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1673
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

USInt	
Value Range	1..63
Initialisation	32
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDDMsrcVMSnodeID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDDMsrcVMSnodeID	String	17	CAN Node ID of distance measurement source VDS/MSC for backward mode

Read Variable Response:				
`sRA BWDDMsrcVMSnodeID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDDMsrcVMSnodeID	String	17	CAN Node ID of distance measurement source VDS/MSC for backward mode
Variable Data	data	USInt	1	

Write Variable:				
`sWN BWDDMsrcVMSnodeID <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDDMsrcVMSnodeID	String	17	CAN Node ID of distance measurement source VDS/MSC for backward mode
Variable Data	data	USInt	1	

Write Variable Response:				
`sWA BWDDMsrcVMSnodeID`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDDMsrcVMSnodeID	String	17	CAN Node ID of distance measurement source VDS/MSC for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDDMsrcVMSnodeID[ETX]`
Read Variable Response:	`[STX]sRA BWDDMsrcVMSnodeID 20[ETX]`
Write Variable:	`[STX]sWN BWDDMsrcVMSnodeID 20[ETX]`
Write Variable Response:	`[STX]sWA BWDDMsrcVMSnodeID[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.10. Variable: BWDScannerPosAlpha

The following section contains a detailed description of the variable BWDScannerPosAlpha.

Variable Overview

Variable Name	Description
BWDScannerPosAlpha	Angle Alpha of scanner position for backward mode

Communication Name	BWDPOalpha
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1674
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	90.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDPOalpha
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOalpha	String	10	Angle Alpha of scanner position for backward mode

Read Variable Response:

```
sRA BWDPOalpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOalpha	String	10	Angle Alpha of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable:

```
sWN BWDPOalpha <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOalpha	String	10	Angle Alpha of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable Response:

```
sWA BWDPOalpha
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOalpha	String	10	Angle Alpha of scanner position for backward mode

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDPOalpha[ETX]`
Read Variable Response:	`[STX]sRA BWDPOalpha 42B40000[ETX]`
Write Variable:	`[STX]sWN BWDPOalpha 42B40000[ETX]`
Write Variable Response:	`[STX]sWA BWDPOalpha[ETX]`

2.37.38.11. Variable: BWDScannerPosBeta

The following section contains a detailed description of the variable BWDScannerPosBeta.

Variable Overview

Variable Name	Description
BWDScannerPosBeta	Angle Beta of scanner position for backward mode

Communication Name	BWDPObeta
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1676
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	15.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN BWDPObeta`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPObeta	String	9	Angle Beta of scanner position for backward mode

Read Variable Response:

`sRA BWDPObeta <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPObeta	String	9	Angle Beta of scanner position for backward mode
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN BWDPObeta <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPObeta	String	9	Angle Beta of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable Response:				
sWA BWDPObeta				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPObeta	String	9	Angle Beta of scanner position for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDPObeta[ETX]
Read Variable Response:	[STX]sRA BWDPObeta 41700000[ETX]
Write Variable:	[STX]sWN BWDPObeta 41700000[ETX]
Write Variable Response:	[STX]sWA BWDPObeta[ETX]

2.37.38.12. Variable: BWDScannerPosGamma

The following section contains a detailed description of the variable BWDScannerPosGamma.

Variable Overview

Variable Name	Description
BWDScannerPosGamma	Angle Gamma of scanner position for backward mode

Communication Name	BWDPOgamma
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1678
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDPOgamma`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOgamma	String	10	Angle Gamma of scanner position for backward mode

Read Variable Response:				
`sRA BWDPOgamma <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOgamma	String	10	Angle Gamma of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable:				
`sWN BWDPOgamma <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOgamma	String	10	Angle Gamma of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable Response:				
`sWA BWDPOgamma`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOgamma	String	10	Angle Gamma of scanner position for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDPOgamma[ETX]`
Read Variable Response:	`[STX]sRA BWDPOgamma 00000000[ETX]`
Write Variable:	`[STX]sWN BWDPOgamma 00000000[ETX]`
Write Variable Response:	`[STX]sWA BWDPOgamma[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.13. Variable: BWDScannerPosXCoord

The following section contains a detailed description of the variable BWDScannerPosXCoord.

Variable Overview

Variable Name	Description
BWDScannerPosXCoord	X-coordinate of scanner position for backward mode

Communication Name	BWDPOcoordX
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1680
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -10000.0..50000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDPOcoordX
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOcoordX	String	11	X-coordinate of scanner position for backward mode

Read Variable Response:

```
sRA BWDPOcoordX <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOcoordX	String	11	X-coordinate of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable:

```
sWN BWDPOcoordX <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOcoordX	String	11	X-coordinate of scanner position for backward mode
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDPOcoordX				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOcoordX	String	11	X-coordinate of scanner position for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDPOcoordX[ETX]
Read Variable Response:	[STX]sRA BWDPOcoordX 00000000[ETX]
Write Variable:	[STX]sWN BWDPOcoordX 00000000[ETX]
Write Variable Response:	[STX]sWA BWDPOcoordX[ETX]

2.37.38.14. Variable: BWDScannerPosYCoord

The following section contains a detailed description of the variable BWDScannerPosYCoord.

Variable Overview

Variable Name	Description
BWDScannerPosYCoord	Y-coordinate of scanner position for backward mode

Communication Name	BWDPOcoordY
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1682
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3000.0..3000.0
Initialisation	600.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDPOcoordY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOcoordY	String	11	Y-coordinate of scanner position for backward mode

Read Variable Response:				
`sRA BWDPOcoordY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOcoordY	String	11	Y-coordinate of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable:				
`sWN BWDPOcoordY <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOcoordY	String	11	Y-coordinate of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable Response:				
`sWA BWDPOcoordY`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOcoordY	String	11	Y-coordinate of scanner position for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDPOcoordY[ETX]`
Read Variable Response:	`[STX]sRA BWDPOcoordY 44160000[ETX]`
Write Variable:	`[STX]sWN BWDPOcoordY 44160000[ETX]`
Write Variable Response:	`[STX]sWA BWDPOcoordY[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.15. Variable: BWDScannerPosAlphaPanorama

The following section contains a detailed description of the variable BWDScannerPosAlphaPanorama.

Variable Overview

Variable Name	Description
BWDScannerPosAlphaPanorama	Angle Alpha of scanner position for backward mode Panorama

Communication Name	BWDPOalphaPano
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1684
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	90.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDPOalphaPano
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOalphaPano	String	14	Angle Alpha of scanner position for backward mode Panorama

Read Variable Response:

```
sRA BWDPOalphaPano <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOalphaPano	String	14	Angle Alpha of scanner position for backward mode Panorama
Variable Data	data	Real	4	

Write Variable:

```
sWN BWDPOalphaPano <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOalphaPano	String	14	Angle Alpha of scanner position for backward mode Panorama
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDPOalphaPano				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOalphaPano	String	14	Angle Alpha of scanner position for backward mode Panorama

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDPOalphaPano[ETX]`
Read Variable Response:	`[STX]sRA BWDPOalphaPano 42B40000[ETX]`
Write Variable:	`[STX]sWN BWDPOalphaPano 42B40000[ETX]`
Write Variable Response:	`[STX]sWA BWDPOalphaPano[ETX]`

2.37.38.16. Variable: BWDScannerPosBetaPanorama

The following section contains a detailed description of the variable BWDScannerPosBetaPanorama.

Variable Overview

Variable Name	Description
BWDScannerPosBetaPanorama	Angle Beta of scanner position for backward mode Panorama

Communication Name	BWDPObetaPano
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1686
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	15.0
Physical Unit	°
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDPObetaPano`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPObetaPano	String	13	Angle Beta of scanner position for backward mode Panorama

Read Variable Response:				
`sRA BWDPObetaPano <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPObetaPano	String	13	Angle Beta of scanner position for backward mode Panorama
Variable Data	data	Real	4	

Write Variable:				
`sWN BWDPObetaPano <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPObetaPano	String	13	Angle Beta of scanner position for backward mode Panorama
Variable Data	data	Real	4	

Write Variable Response:				
`sWA BWDPObetaPano`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPObetaPano	String	13	Angle Beta of scanner position for backward mode Panorama

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDPObetaPano[ETX]`
Read Variable Response:	`[STX]sRA BWDPObetaPano 41700000[ETX]`
Write Variable:	`[STX]sWN BWDPObetaPano 41700000[ETX]`
Write Variable Response:	`[STX]sWA BWDPObetaPano[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.17. Variable: BWDScannerPosGammaPanorama

The following section contains a detailed description of the variable BWDScannerPosGammaPanorama.

Variable Overview

Variable Name	Description
BWDScannerPosGammaPanorama	Angle Gamma of scanner position for backward mode Panorama

Communication Name	BWDPOgammaPano
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1688
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 0.0..360.0
Initialisation	0.0
Physical Unit	°
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDPOgammaPano
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOgammaPano	String	14	Angle Gamma of scanner position for backward mode Panorama

Read Variable Response:

```
sRA BWDPOgammaPano <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOgammaPano	String	14	Angle Gamma of scanner position for backward mode Panorama
Variable Data	data	Real	4	

Write Variable:

```
sWN BWDPOgammaPano <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOgammaPano	String	14	Angle Gamma of scanner position for backward mode Panorama
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDPOgammaPano				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOgammaPano	String	14	Angle Gamma of scanner position for backward mode Panorama

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDPOgammaPano[ETX]
Read Variable Response:	[STX]sRA BWDPOgammaPano 00000000[ETX]
Write Variable:	[STX]sWN BWDPOgammaPano 00000000[ETX]
Write Variable Response:	[STX]sWA BWDPOgammaPano[ETX]

2.37.38.18. Variable: BWDScannerPosXCoordPanorama

The following section contains a detailed description of the variable BWDScannerPosXCoordPanorama.

Variable Overview

Variable Name	Description
BWDScannerPosXCoordPanorama	X-coordinate of scanner position for backward mode Panorama

Communication Name	BWDPOcoordXPano
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1690
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -10000.0..50000.0
Initialisation	0.0
Physical Unit	mm
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN BWDPOcoordXPano`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOcoordXPano	String	15	X-coordinate of scanner position for backward mode Panorama

Read Variable Response:				
`sRA BWDPOcoordXPano <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOcoordXPano	String	15	X-coordinate of scanner position for backward mode Panorama
Variable Data	data	Real	4	

Write Variable:				
`sWN BWDPOcoordXPano <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOcoordXPano	String	15	X-coordinate of scanner position for backward mode Panorama
Variable Data	data	Real	4	

Write Variable Response:				
`sWA BWDPOcoordXPano`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOcoordXPano	String	15	X-coordinate of scanner position for backward mode Panorama

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN BWDPOcoordXPano[ETX]`
Read Variable Response:	`[STX]sRA BWDPOcoordXPano 00000000[ETX]`
Write Variable:	`[STX]sWN BWDPOcoordXPano 00000000[ETX]`
Write Variable Response:	`[STX]sWA BWDPOcoordXPano[ETX]`

© SICK AG - Germany - All rights reserved

2.37.38.19. Variable: BWDScannerPosYCoordPanorama

The following section contains a detailed description of the variable BWDScannerPosYCoordPanorama.

Variable Overview

Variable Name	Description
BWDScannerPosYCoordPanorama	Y-coordinate of scanner position for backward mode

Communication Name	BWDPOcoordYPano
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1692
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Real	
Value Range	See specification IEEE 754 -3000.0..3000.0
Initialisation	600.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BWDPOcoordYPano
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BWDPOcoordYPano	String	15	Y-coordinate of scanner position for backward mode

Read Variable Response:

```
sRA BWDPOcoordYPano <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BWDPOcoordYPano	String	15	Y-coordinate of scanner position for backward mode
Variable Data	data	Real	4	

Write Variable:

```
sWN BWDPOcoordYPano <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BWDPOcoordYPano	String	15	Y-coordinate of scanner position for backward mode
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BWDPOcoordYPano				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BWDPOcoordYPano	String	15	Y-coordinate of scanner position for backward mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BWDPOcoordYPano[ETX]
Read Variable Response:	[STX]sRA BWDPOcoordYPano 44160000[ETX]
Write Variable:	[STX]sWN BWDPOcoordYPano 44160000[ETX]
Write Variable Response:	[STX]sWA BWDPOcoordYPano[ETX]

2.37.38.20. Method: BWDCopyParam

The following section contains a detailed description of the method BWDCopyParam.

Method Overview

Method Name
BWDCopyParam

Communication Name	mBWDCopyParam
Sopas Index	154
Invocation Access	AuthorizedClient, Service

Method Telegram Syntax

Method Invocation:				
sMN mBWDCopyParam				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mBWDCopyParam	String	13	

Method Return Value:				
sAN mBWDCopyParam				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mBWDCopyParam	String	13	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mBWDCopyParam[ETX]`
Method Return Value:	`[STX]sAN mBWDCopyParam[ETX]`

© SICK AG - Germany - All rights reserved

2.37.39. Group: ProfileCodes

2.37.39.1. Variable: ProfileCodesSharedKey

The following section contains a detailed description of the variable ProfileCodesSharedKey.

Variable Overview

Variable Name	Description
ProfileCodesSharedKey	Additional security to avoid manipulation of the Lector

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1694
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

FlexString	
Length	0..20
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN ProfileCodesSharedKey
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ProfileCodesSharedKey	String	21	Additional security to avoid manipulation of the Lector

Read Variable Response:

```
sRA ProfileCodesSharedKey <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ProfileCodesSharedKey	String	21	Additional security to avoid manipulation of the Lector
Variable Data	data	FlexString	20	

Write Variable:

```
sWN ProfileCodesSharedKey <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ProfileCodesSharedKey	String	21	Additional security to avoid manipulation of the Lector
Variable Data	data	FlexString	20	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ProfileCodesSharedKey				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ProfileCodesSharedKey	String	21	Additional security to avoid manipulation of the Lector

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ProfileCodesSharedKey[ETX]
Read Variable Response:	[STX]sRA ProfileCodesSharedKey 0[ETX]
Write Variable:	[STX]sWN ProfileCodesSharedKey 0[ETX]
Write Variable Response:	[STX]sWA ProfileCodesSharedKey[ETX]

2.37.39.2. Variable: ProfileCodesForwardingEnabled

The following section contains a detailed description of the variable ProfileCodesForwardingEnabled.

Variable Overview

Variable Name	Description
ProfileCodesForwardingEnabled	Forward profile codes to registered receivers

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1695
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ProfileCodesForwardingEnabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ProfileCodesForwardingEnabled	String	29	Forward profile codes to registered receivers

Read Variable Response:				
`sRA ProfileCodesForwardingEnabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ProfileCodesForwardingEnabled	String	29	Forward profile codes to registered receivers
Variable Data	data	Bool	1	

Write Variable:				
`sWN ProfileCodesForwardingEnabled <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ProfileCodesForwardingEnabled	String	29	Forward profile codes to registered receivers
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA ProfileCodesForwardingEnabled`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ProfileCodesForwardingEnabled	String	29	Forward profile codes to registered receivers

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ProfileCodesForwardingEnabled[ETX]`
Read Variable Response:	`[STX]sRA ProfileCodesForwardingEnabled 0[ETX]`
Write Variable:	`[STX]sWN ProfileCodesForwardingEnabled 0[ETX]`
Write Variable Response:	`[STX]sWA ProfileCodesForwardingEnabled[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40. Group: HostImageProcessing

2.37.40.1. Variable: PMShippEnabled

The following section contains a detailed description of the variable PMShippEnabled.

Variable Overview

Variable Name	Description
PMShippEnabled	Wait for Host to evaluate each read result, starting Prep Mode on request

Communication Name	PMShippEn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1697
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN PMShippEn
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PMShippEn	String	9	Wait for Host to evaluate each read result, starting Prep Mode on request

Read Variable Response:

```
sRA PMShippEn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PMShippEn	String	9	Wait for Host to evaluate each read result, starting Prep Mode on request
Variable Data	data	Bool	1	

Write Variable:

```
sWN PMShippEn <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PMShippEn	String	9	Wait for Host to evaluate each read result, starting Prep Mode on request
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PMShippEn				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PMShippEn	String	9	Wait for Host to evaluate each read result, starting Prep Mode on request

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PMShippEn[ETX]
Read Variable Response:	[STX]sRA PMShippEn 0[ETX]
Write Variable:	[STX]sWN PMShippEn 0[ETX]
Write Variable Response:	[STX]sWA PMShippEn[ETX]

2.37.40.2. Variable: ShippSnapPreDelayMs

The following section contains a detailed description of the variable ShippSnapPreDelayMs.

Variable Overview

Variable Name	Description
ShippSnapPreDelayMs	How long Shipp Snap mode waits initially before triggering the image

Communication Name	ShSnPre
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1698
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	10
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ShSnPre`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShSnPre	String	7	How long Shipp Snap mode waits initially before triggering the image

Read Variable Response:				
`sRA ShSnPre <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShSnPre	String	7	How long Shipp Snap mode waits initially before triggering the image
Variable Data	data	UDInt	4	

Write Variable:				
`sWN ShSnPre <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShSnPre	String	7	How long Shipp Snap mode waits initially before triggering the image
Variable Data	data	UDInt	4	

Write Variable Response:				
`sWA ShSnPre`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShSnPre	String	7	How long Shipp Snap mode waits initially before triggering the image

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShSnPre[ETX]`
Read Variable Response:	`[STX]sRA ShSnPre A[ETX]`
Write Variable:	`[STX]sWN ShSnPre A[ETX]`
Write Variable Response:	`[STX]sWA ShSnPre[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.3. Variable: ShippSnapHostTimeoutMs

The following section contains a detailed description of the variable ShippSnapHostTimeoutMs.

Variable Overview

Variable Name	Description
ShippSnapHostTimeoutMs	How long Shipp Snap mode waits for response from host

Communication Name	ShSnHostTO
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1699
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	2000
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ShSnHostTO
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShSnHostTO	String	10	How long Shipp Snap mode waits for response from host

Read Variable Response:

```
sRA ShSnHostTO <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShSnHostTO	String	10	How long Shipp Snap mode waits for response from host
Variable Data	data	UDInt	4	

Write Variable:

```
sWN ShSnHostTO <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShSnHostTO	String	10	How long Shipp Snap mode waits for response from host
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ShSnHostTO				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShSnHostTO	String	10	How long Shipp Snap mode waits for response from host

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ShSnHostTO[ETX]
Read Variable Response:	[STX]sRA ShSnHostTO 7D0[ETX]
Write Variable:	[STX]sWN ShSnHostTO 7D0[ETX]
Write Variable Response:	[STX]sWA ShSnHostTO[ETX]

2.37.40.4. Variable: ShippSnapBurstLength

The following section contains a detailed description of the variable ShippSnapBurstLength.

Variable Overview

Variable Name	Description
ShippSnapBurstLength	How many images to capture

Communication Name	ShSnBurstLen
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1700
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ShSnBurstLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShSnBurstLen	String	12	How many images to capture

Read Variable Response:				
`sRA ShSnBurstLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShSnBurstLen	String	12	How many images to capture
Variable Data	data	UInt	2	

Write Variable:				
`sWN ShSnBurstLen <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShSnBurstLen	String	12	How many images to capture
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA ShSnBurstLen`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShSnBurstLen	String	12	How many images to capture

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShSnBurstLen[ETX]`
Read Variable Response:	`[STX]sRA ShSnBurstLen 1[ETX]`
Write Variable:	`[STX]sWN ShSnBurstLen 1[ETX]`
Write Variable Response:	`[STX]sWA ShSnBurstLen[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.5. Variable: ShippPrepSteadyTimeMs

The following section contains a detailed description of the variable ShippPrepSteadyTimeMs.

Variable Overview

Variable Name	Description
ShippPrepSteadyTimeMs	How long the code must be steady before triggering Snap

Communication Name	ShPrSteTo
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1701
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	1000
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ShPrSteTo
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShPrSteTo	String	9	How long the code must be steady before triggering Snap

Read Variable Response:

```
sRA ShPrSteTo <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShPrSteTo	String	9	How long the code must be steady before triggering Snap
Variable Data	data	UDInt	4	

Write Variable:

```
sWN ShPrSteTo <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShPrSteTo	String	9	How long the code must be steady before triggering Snap
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ShPrSteTo				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShPrSteTo	String	9	How long the code must be steady before triggering Snap

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ShPrSteTo[ETX]
Read Variable Response:	[STX]sRA ShPrSteTo 3E8[ETX]
Write Variable:	[STX]sWN ShPrSteTo 3E8[ETX]
Write Variable Response:	[STX]sWA ShPrSteTo[ETX]

2.37.40.6. Variable: ShippPrepSteadyCount

The following section contains a detailed description of the variable ShippPrepSteadyCount.

Variable Overview

Variable Name	Description
ShippPrepSteadyCount	How many successive decoded images the code must be steady before triggering Snap

Communication Name	ShPrSteCnt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1702
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	5
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ShPrSteCnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShPrSteCnt	String	10	How many successive decoded images the code must be steady before triggering Snap

Read Variable Response:				
`sRA ShPrSteCnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShPrSteCnt	String	10	How many successive decoded images the code must be steady before triggering Snap
Variable Data	data	UInt	2	

Write Variable:				
`sWN ShPrSteCnt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShPrSteCnt	String	10	How many successive decoded images the code must be steady before triggering Snap
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA ShPrSteCnt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShPrSteCnt	String	10	How many successive decoded images the code must be steady before triggering Snap

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShPrSteCnt[ETX]`
Read Variable Response:	`[STX]sRA ShPrSteCnt 5[ETX]`
Write Variable:	`[STX]sWN ShPrSteCnt 5[ETX]`
Write Variable Response:	`[STX]sWA ShPrSteCnt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.7. Variable: ShippPrepPostWaitMs

The following section contains a detailed description of the variable ShippPrepPostWaitMs.

Variable Overview

Variable Name	Description
ShippPrepPostWaitMs	How long to wait before returning to Presentation

Communication Name	ShPrPostW
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1703
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	500
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ShPrPostW
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShPrPostW	String	9	How long to wait before returning to Presentation

Read Variable Response:

```
sRA ShPrPostW <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShPrPostW	String	9	How long to wait before returning to Presentation
Variable Data	data	UDInt	4	

Write Variable:

```
sWN ShPrPostW <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShPrPostW	String	9	How long to wait before returning to Presentation
Variable Data	data	UDInt	4	

Write Variable Response:

```
sWA ShPrPostW
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShPrPostW	String	9	How long to wait before returning to Presentation

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShPrPostW[ETX]`
Read Variable Response:	`[STX]sRA ShPrPostW 1F4[ETX]`
Write Variable:	`[STX]sWN ShPrPostW 1F4[ETX]`
Write Variable Response:	`[STX]sWA ShPrPostW[ETX]`

2.37.40.8. Variable: ShippPrepModeActive

The following section contains a detailed description of the variable ShippPrepModeActive.

Variable Overview

Variable Name
ShippPrepModeActive

Communication Name	ShPrAct
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1704
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN ShPrAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShPrAct	String	7	

Read Variable Response:

```
sRA ShPrAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShPrAct	String	7	
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable:				
`sWN ShPrAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShPrAct	String	7	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA ShPrAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShPrAct	String	7	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShPrAct[ETX]`
Read Variable Response:	`[STX]sRA ShPrAct 0[ETX]`
Write Variable:	`[STX]sWN ShPrAct 0[ETX]`
Write Variable Response:	`[STX]sWA ShPrAct[ETX]`

2.37.40.9. Variable: ShippSnapModeActive

The following section contains a detailed description of the variable ShippSnapModeActive.

Variable Overview

Variable Name
ShippSnapModeActive

Communication Name	ShSnAct
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1705
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ShSnAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShSnAct	String	7	

Read Variable Response:				
`sRA ShSnAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShSnAct	String	7	
Variable Data	data	Bool	1	

Write Variable:				
`sWN ShSnAct <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShSnAct	String	7	
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA ShSnAct`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShSnAct	String	7	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShSnAct[ETX]`
Read Variable Response:	`[STX]sRA ShSnAct 0[ETX]`
Write Variable:	`[STX]sWN ShSnAct 0[ETX]`
Write Variable Response:	`[STX]sWA ShSnAct[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.10. Variable: ShippInhibitLoggingInPresentation

The following section contains a detailed description of the variable ShippInhibitLoggingInPresentation.

Variable Overview

Variable Name	Description
ShippInhibitLoggingInPresentation	In Post-flavored Presentation Mode, Inhibit image logging during Presentation Mode

Communication Name	ShInhImLog
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1706
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:

```
sRN ShInhImLog
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShInhImLog	String	10	In Post-flavored Presentation Mode, Inhibit image logging during Presentation Mode

Read Variable Response:

```
sRA ShInhImLog <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShInhImLog	String	10	In Post-flavored Presentation Mode, Inhibit image logging during Presentation Mode
Variable Data	data	Bool	1	

Write Variable:

```
sWN ShInhImLog <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShInhImLog	String	10	In Post-flavored Presentation Mode, Inhibit image logging during Presentation Mode
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA ShInhImLog
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ShInhImLog				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	ShInhImLog	String	10	In Post-flavored Presentation Mode, Inhibit image logging during Presentation Mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ShInhImLog[ETX]
Read Variable Response:	[STX]sRA ShInhImLog 1[ETX]
Write Variable:	[STX]sWN ShInhImLog 1[ETX]
Write Variable Response:	[STX]sWA ShInhImLog[ETX]

2.37.40.11. Variable: ShippForceResultOutput

The following section contains a detailed description of the variable ShippForceResultOutput.

Variable Overview

Variable Name	Description
ShippForceResultOutput	In Post-flavored Presentation, force OF1 and OF2 output to ETH gates, regardless of ETH output format setting

Communication Name	ShResOutF
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1707
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ShResOutF`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShResOutF	String	9	In Post-flavored Presentation, force OF1 and OF2 output to ETH gates, regardless of ETH output format setting

Read Variable Response:				
`sRA ShResOutF <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShResOutF	String	9	In Post-flavored Presentation, force OF1 and OF2 output to ETH gates, regardless of ETH output format setting
Variable Data	data	Bool	1	

Write Variable:				
`sWN ShResOutF <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShResOutF	String	9	In Post-flavored Presentation, force OF1 and OF2 output to ETH gates, regardless of ETH output format setting
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA ShResOutF`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShResOutF	String	9	In Post-flavored Presentation, force OF1 and OF2 output to ETH gates, regardless of ETH output format setting

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShResOutF[ETX]`
Read Variable Response:	`[STX]sRA ShResOutF 1[ETX]`
Write Variable:	`[STX]sWN ShResOutF 1[ETX]`
Write Variable Response:	`[STX]sWA ShResOutF[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.12. Variable: ShippBeepDurationShort

The following section contains a detailed description of the variable ShippBeepDurationShort.

Variable Overview

Variable Name	Description
ShippBeepDurationShort	Duration of short external beep

Communication Name	ShBeDur1
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1708
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	100
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ShBeDur1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShBeDur1	String	8	Duration of short external beep

Read Variable Response:

```
sRA ShBeDur1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShBeDur1	String	8	Duration of short external beep
Variable Data	data	UInt	2	

Write Variable:

```
sWN ShBeDur1 <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShBeDur1	String	8	Duration of short external beep
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA ShBeDur1
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShBeDur1	String	8	Duration of short external beep

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShBeDur1[ETX]`
Read Variable Response:	`[STX]sRA ShBeDur1 64[ETX]`
Write Variable:	`[STX]sWN ShBeDur1 64[ETX]`
Write Variable Response:	`[STX]sWA ShBeDur1[ETX]`

2.37.40.13. Variable: ShippBeepDurationLong

The following section contains a detailed description of the variable ShippBeepDurationLong.

Variable Overview

Variable Name	Description
ShippBeepDurationLong	Duration of long external beep

Communication Name	ShBeDur2
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1709
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	300
Physical Unit	ms
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

`sRN ShBeDur2`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShBeDur2	String	8	Duration of long external beep

Read Variable Response:

`sRA ShBeDur2 <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShBeDur2	String	8	Duration of long external beep
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN ShBeDur2 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShBeDur2	String	8	Duration of long external beep
Variable Data	data	UInt	2	

Write Variable Response:				
sWA ShBeDur2				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShBeDur2	String	8	Duration of long external beep

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ShBeDur2[ETX]
Read Variable Response:	[STX]sRA ShBeDur2 12C[ETX]
Write Variable:	[STX]sWN ShBeDur2 12C[ETX]
Write Variable Response:	[STX]sWA ShBeDur2[ETX]

2.37.40.14. Variable: ShippPrepTimeout

The following section contains a detailed description of the variable ShippPrepTimeout.

Variable Overview

Variable Name	Description
ShippPrepTimeout	Duration of long to stay in PrepMode without host feedback

Communication Name	ShPrTmt
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1710
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	0..65535
Initialisation	60000
Physical Unit	ms
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ShPrTmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ShPrTmt	String	7	Duration of long to stay in PrepMode without host feedback

Read Variable Response:				
`sRA ShPrTmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ShPrTmt	String	7	Duration of long to stay in PrepMode without host feedback
Variable Data	data	UInt	2	

Write Variable:				
`sWN ShPrTmt <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ShPrTmt	String	7	Duration of long to stay in PrepMode without host feedback
Variable Data	data	UInt	2	

Write Variable Response:				
`sWA ShPrTmt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ShPrTmt	String	7	Duration of long to stay in PrepMode without host feedback

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ShPrTmt[ETX]`
Read Variable Response:	`[STX]sRA ShPrTmt EA60[ETX]`
Write Variable:	`[STX]sWN ShPrTmt EA60[ETX]`
Write Variable Response:	`[STX]sWA ShPrTmt[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.15. Method: ShippSnapStart

The following section contains a detailed description of the method ShippSnapStart.

Method Overview

Method Name	Description
ShippSnapStart	Start a Snap episode (send image to host, wait for verdict)

Communication Name	ShSnapStart
Sopas Index	155
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN ShSnapStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ShSnapStart	String	11	Start a Snap episode (send image to host, wait for verdict)

Method Return Value:				
`sAN ShSnapStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ShSnapStart	String	11	Start a Snap episode (send image to host, wait for verdict)

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ShSnapStart[ETX]`
Method Return Value:	`[STX]sAN ShSnapStart[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.16. Method: ShippSnapPositiveFeedback

The following section contains a detailed description of the method ShippSnapPositiveFeedback.

Method Overview

Method Name
ShippSnapPositiveFeedback

Communication Name	ShFeedbackPositive
Sopas Index	156
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN ShFeedbackPositive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ShFeedbackPositive	String	18	

Method Return Value:				
`sAN ShFeedbackPositive`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ShFeedbackPositive	String	18	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ShFeedbackPositive[ETX]`
Method Return Value:	`[STX]sAN ShFeedbackPositive[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.17. Method: ShippSnapNegativeFeedback

The following section contains a detailed description of the method ShippSnapNegativeFeedback.

Method Overview

Method Name
ShippSnapNegativeFeedback

Communication Name	ShFeedbackNegative
Sopas Index	157
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN ShFeedbackNegative`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ShFeedbackNegative	String	18	

Method Return Value:				
`sAN ShFeedbackNegative`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ShFeedbackNegative	String	18	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ShFeedbackNegative[ETX]`
Method Return Value:	`[STX]sAN ShFeedbackNegative[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.18. Method: ShippPrepStart

The following section contains a detailed description of the method ShippPrepStart.

Method Overview

Method Name
ShippPrepStart

Communication Name	ShPrepStart
Sopas Index	158
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN ShPrepStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ShPrepStart	String	11	

Method Return Value:				
`sAN ShPrepStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ShPrepStart	String	11	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ShPrepStart[ETX]`
Method Return Value:	`[STX]sAN ShPrepStart[ETX]`

© SICK AG - Germany - All rights reserved

2.37.40.19. Method: ShippPrepStop

The following section contains a detailed description of the method ShippPrepStop.

Method Overview

Method Name
ShippPrepStop

Communication Name	ShPrepStop
Sopas Index	159
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

```
sMN ShPrepStop
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ShPrepStop	String	10	

Method Return Value:

```
sAN ShPrepStop
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ShPrepStop	String	10	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN ShPrepStop[ETX]`
Method Return Value:	`[STX]sAN ShPrepStop[ETX]`

© SICK AG - Germany - All rights reserved

2.37.41. Group: CodeMotionTracker

2.37.41.1. Variable: CodeMotionSteadyThreshold

The following section contains a detailed description of the variable CodeMotionSteadyThreshold.

Variable Overview

Variable Name	Description
CodeMotionSteadyThreshold	Maximum velocity of a Code considered 'steady', in pixels per second

Communication Name	CMTSteThr
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1711
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UDInt	
Value Range	0..4294967295
Initialisation	250
Physical Unit	pix/s
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN CMTSteThr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CMTSteThr	String	9	Maximum velocity of a Code considered 'steady', in pixels per second

Read Variable Response:

```
sRA CMTSteThr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CMTSteThr	String	9	Maximum velocity of a Code considered 'steady', in pixels per second
Variable Data	data	UDInt	4	

Write Variable:

```
sWN CMTSteThr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CMTSteThr	String	9	Maximum velocity of a Code considered 'steady', in pixels per second
Variable Data	data	UDInt	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA CMTSteThr				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CMTSteThr	String	9	Maximum velocity of a Code considered 'steady', in pixels per second

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN CMTSteThr[ETX]
Read Variable Response:	[STX]sRA CMTSteThr FA[ETX]
Write Variable:	[STX]sWN CMTSteThr FA[ETX]
Write Variable Response:	[STX]sWA CMTSteThr[ETX]

2.37.41.2. Variable: CodeMotionTrackingEnabled

The following section contains a detailed description of the variable CodeMotionTrackingEnabled.

Variable Overview

Variable Name	Description
CodeMotionTrackingEnabled	Enable code-motion tracking explicitly -- for interactive tuning. (Devicemodes can also enable this internally, which makes more sense)

Communication Name	CMTEn
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1713
Read-Access	Always
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN CMTEn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	CMTEn	String	5	Enable code-motion tracking explicitly -- for interactive tuning. (Devicemodes can also enable this internally, which makes more sense)

Read Variable Response:				
`sRA CMTEn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	CMTEn	String	5	Enable code-motion tracking explicitly -- for interactive tuning. (Devicemodes can also enable this internally, which makes more sense)
Variable Data	data	Bool	1	

Write Variable:				
`sWN CMTEn <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	CMTEn	String	5	Enable code-motion tracking explicitly -- for interactive tuning. (Devicemodes can also enable this internally, which makes more sense)
Variable Data	data	Bool	1	

Write Variable Response:				
`sWA CMTEn`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	CMTEn	String	5	Enable code-motion tracking explicitly -- for interactive tuning. (Devicemodes can also enable this internally, which makes more sense)

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN CMTEn[ETX]`
Read Variable Response:	`[STX]sRA CMTEn 0[ETX]`
Write Variable:	`[STX]sWN CMTEn 0[ETX]`
Write Variable Response:	`[STX]sWA CMTEn[ETX]`

© SICK AG - Germany - All rights reserved

2.37.42. Group: StandbyMode

2.37.42.1. Variable: StandbyModeActive

The following section contains a detailed description of the variable StandbyModeActive.

Variable Overview

Variable Name
StandbyModeActive

Communication Name	StdbyMdAct
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1714
Read-Access	Always
Write-Access	Always

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN StdbyMdAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	StdbyMdAct	String	10	

Read Variable Response:

```
sRA StdbyMdAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	StdbyMdAct	String	10	
Variable Data	data	Bool	1	

Write Variable:

```
sWN StdbyMdAct <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	StdbyMdAct	String	10	
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA StdbyMdAct
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	StdbyMdAct	String	10	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN StdbyMdAct[ETX]`
Read Variable Response:	`[STX]sRA StdbyMdAct 0[ETX]`
Write Variable:	`[STX]sWN StdbyMdAct 0[ETX]`
Write Variable Response:	`[STX]sWA StdbyMdAct[ETX]`

© SICK AG - Germany - All rights reserved

2.37.43. Group: LaetusGroup

2.37.43.1. Variable: LaetusSerialNumber

The following section contains a detailed description of the variable LaetusSerialNumber.

Variable Overview

Variable Name	Description
LaetusSerialNumber	Laetus serial number set by customer on servicelevel

Communication Name	LaeSerNum
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1715
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

String	
Length	8
Initialisation	00000000

Variable Telegram Syntax

Read Variable:

```
sRN LaeSerNum
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LaeSerNum	String	9	Laetus serial number set by customer on servicelevel

Read Variable Response:

```
sRA LaeSerNum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LaeSerNum	String	9	Laetus serial number set by customer on servicelevel
Variable Data	data	String	8	

Write Variable:

```
sWN LaeSerNum <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LaeSerNum	String	9	Laetus serial number set by customer on servicelevel
Variable Data	data	String	8	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA LaeSerNum				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LaeSerNum	String	9	Laetus serial number set by customer on servicelevel

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN LaeSerNum[ETX]
Read Variable Response:	[STX]sRA LaeSerNum 00000000[ETX]
Write Variable:	[STX]sWN LaeSerNum 00000000[ETX]
Write Variable Response:	[STX]sWA LaeSerNum[ETX]

2.37.43.2. Variable: LaetusDeviceName

The following section contains a detailed description of the variable LaetusDeviceName.

Variable Overview

Variable Name	Description
LaetusDeviceName	Laetus name for Lector6xx-xxxx

Communication Name	LaeDevName
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1716
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	Service

FlexString	
Length	0..14
Initialisation	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN LaeDevName`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	LaeDevName	String	10	Laetus name for Lector6xx-xxxx

Read Variable Response:				
`sRA LaeDevName <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	LaeDevName	String	10	Laetus name for Lector6xx-xxxx
Variable Data	data	FlexString	14	

Write Variable:				
`sWN LaeDevName <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	LaeDevName	String	10	Laetus name for Lector6xx-xxxx
Variable Data	data	FlexString	14	

Write Variable Response:				
`sWA LaeDevName`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	LaeDevName	String	10	Laetus name for Lector6xx-xxxx

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN LaeDevName[ETX]`
Read Variable Response:	`[STX]sRA LaeDevName 0[ETX]`
Write Variable:	`[STX]sWN LaeDevName 0[ETX]`
Write Variable Response:	`[STX]sWA LaeDevName[ETX]`

© SICK AG - Germany - All rights reserved

2.38. Interface Block: Diag

2.38.1. Group: DeviceInformation

2.38.1.1. Variable: HasFieldbusConfigChanged

The following section contains a detailed description of the variable HasFieldbusConfigChanged.

Variable Overview

Variable Name	Description
HasFieldbusConfigChanged	True if device (CDF) fieldbus parameter (Ethernet) has changed by Sopas

Communication Name	DIHasFbConfigChanged
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1753
Read-Access	Always
Write-Access	Always

USInt	
Value Range	0..255
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN DIHasFbConfigChanged
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	DIHasFbConfigChanged	String	20	True if device (CDF) fieldbus parameter (Ethernet) has changed by Sopas

Read Variable Response:

```
sRA DIHasFbConfigChanged <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	DIHasFbConfigChanged	String	20	True if device (CDF) fieldbus parameter (Ethernet) has changed by Sopas
Variable Data	data	USInt	1	

Write Variable:

```
sWN DIHasFbConfigChanged <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	DIHasFbConfigChanged	String	20	True if device (CDF) fieldbus parameter (Ethernet) has changed by Sopas
Variable Data	data	USInt	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA DIHasFbConfigChanged				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	DIHasFbConfigChanged	String	20	True if device (CDF) fieldbus parameter (Ethernet) has changed by Sopas

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN DIHasFbConfigChanged[ETX]
Read Variable Response:	[STX]sRA DIHasFbConfigChanged 0[ETX]
Write Variable:	[STX]sWN DIHasFbConfigChanged 0[ETX]
Write Variable Response:	[STX]sWA DIHasFbConfigChanged[ETX]

2.38.1.2. Method: GetEffectiveImageSize

The following section contains a detailed description of the method GetEffectiveImageSize.

Method Overview

Method Name	Description
GetEffectiveImageSize	Get the dimensions of future images in pixels, respecting ROI and Binning

Communication Name	mDIGetEffImgSize
Sopas Index	160
Invocation Access	Always

Return Values		
width		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
height		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mDIGetEffImgSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIGetEffImgSize	String	16	Get the dimensions of future images in pixels, respecting ROI and Binning

Method Return Value:				
sAN mDIGetEffImgSize <width> <height>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIGetEffImgSize	String	16	Get the dimensions of future images in pixels, respecting ROI and Binning
Return Value 1	width	UDInt	4	
Return Value 2	height	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mDIGetEffImgSize[ETX]
Method Return Value:	[STX]sAN mDIGetEffImgSize 0 0[ETX]

2.38.1.3. Method: BootupCDF

The following section contains a detailed description of the method BootupCDF.

Method Overview

Method Name	Description
BootupCDF	Called as bootup message of CDF600

Communication Name	mDIBootCdf
Sopas Index	161
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mDIBootCdf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDIBootCdf	String	10	Called as bootup message of CDF600

Method Return Value:				
`sAN mDIBootCdf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDIBootCdf	String	10	Called as bootup message of CDF600

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDIBootCdf[ETX]`
Method Return Value:	`[STX]sAN mDIBootCdf[ETX]`

© SICK AG - Germany - All rights reserved

2.38.2. Group: FirmwareInformation

2.38.2.1. Variable: OSDescription

The following section contains a detailed description of the variable OSDescription.

Variable Overview

Variable Name	Description
OSDescription	Operating system description

Communication Name	FIOSDesc
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1789
Read-Access	Service
Write-Access	Always

FlexString	
Length	0..254
Initialisation	

Variable Telegram Syntax

Read Variable:

```
sRN FIOSDesc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	FIOSDesc	String	8	Operating system description

Read Variable Response:

```
sRA FIOSDesc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	FIOSDesc	String	8	Operating system description
Variable Data	data	FlexString	254	

Write Variable:

```
sWN FIOSDesc <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	FIOSDesc	String	8	Operating system description
Variable Data	data	FlexString	254	

Write Variable Response:

```
sWA FIOSDesc
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	FIOSDesc	String	8	Operating system description

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN FIOSDesc[ETX]
Read Variable Response:	[STX]sRA FIOSDesc 0[ETX]
Write Variable:	[STX]sWN FIOSDesc 0[ETX]
Write Variable Response:	[STX]sWA FIOSDesc[ETX]

© SICK AG - Germany - All rights reserved

2.38.3. Group: AnalogEvents

2.38.3.1. Variable: eConveyorSpeed

The following section contains a detailed description of the variable eConveyorSpeed.

Variable Overview

Variable Name
eConveyorSpeed

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1794
Read-Access	Service
Write-Access	Always

UserType	
SETEM_Analog	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN eConveyorSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	eConveyorSpeed	String	14	

Read Variable Response:				
`sRA eConveyorSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	eConveyorSpeed	String	14	
Variable Data	data	SETEM_Analog	12	

Write Variable:				
`sWN eConveyorSpeed <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	eConveyorSpeed	String	14	
Variable Data	data	SETEM_Analog	12	

Write Variable Response:				
`sWA eConveyorSpeed`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	eConveyorSpeed	String	14	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN eConveyorSpeed[ETX]`
Read Variable Response:	`[STX]sRA eConveyorSpeed 0 0 0[ETX]`
Write Variable:	`[STX]sWN eConveyorSpeed 0 0 0[ETX]`
Write Variable Response:	`[STX]sWA eConveyorSpeed[ETX]`

© SICK AG - Germany - All rights reserved

2.38.4. Group: Visualisation

2.38.4.1. Variable: BarcodeState

The following section contains a detailed description of the variable BarcodeState.

Variable Overview

Variable Name	Description
BarcodeState	switch to select the barcode state which should be putted in into barcod result

Communication Name	VIbcsource
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1795
Read-Access	Always
Write-Access	Service

Enum8			
Default Value		0	
	Value	Name	Description
	0	TX_OUTPUT	
	1	TX_FILTERED	
	2	TX_RAWCODE	

Variable Telegram Syntax

Read Variable:

```
sRN VIbcsource
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	VIbcsource	String	10	switch to select the barcode state which should be putted in into barcod result

Read Variable Response:

```
sRA VIbcsource <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	VIbcsource	String	10	switch to select the barcode state which should be putted in into barcod result
Variable Data	data	Enum8	1	

Write Variable:

```
sWN VIbcsource <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	VIbcsource	String	10	switch to select the barcode state which should be putted in into barcod result
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA VIbcsource				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	VIbcsource	String	10	switch to select the barcode state which should be putted in into barcod result

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN VIbcsource[ETX]
Read Variable Response:	[STX]sRA VIbcsource 0[ETX]
Write Variable:	[STX]sWN VIbcsource 0[ETX]
Write Variable Response:	[STX]sWA VIbcsource[ETX]

2.38.4.2. Method: ResetStatisticDisplay

The following section contains a detailed description of the method ResetStatisticDisplay.

Method Overview

Method Name	Description
ResetStatisticDisplay	Resets all values of the Statistic Display to 0.

Communication Name	mVIResetStatDisp
Sopas Index	170
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
sMN mVIResetStatDisp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mVIResetStatDisp	String	16	Resets all values of the Statistic Display to 0.

Method Return Value:				
sAN mVIResetStatDisp				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mVIResetStatDisp	String	16	Resets all values of the Statistic Display to 0.

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mVIResetStatDisp[ETX]`
Method Return Value:	`[STX]sAN mVIResetStatDisp[ETX]`

© SICK AG - Germany - All rights reserved

2.38.5. Group: CodeDiag

2.38.5.1. Method: mTestCode

The following section contains a detailed description of the method mTestCode.

Method Overview

Method Name
mTestCode

Sopas Index	171
Invocation Access	Always

Parameters		
CodeDef		
	FlexString	
	Length	0..512
	Initialisation	

Return Values		
Success		
	Bool	
	Value Range	False, True
	Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mTestCode <CodeDef>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mTestCode	String	9	
Parameter 1	CodeDef	FlexString	512	

Method Return Value:

```
sAN mTestCode <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mTestCode	String	9	
Return Value 1	Success	Bool	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mTestCode 0[ETX]`
Method Return Value:	`[STX]sAN mTestCode 0[ETX]`

© SICK AG - Germany - All rights reserved

2.38.6. Group: DevModeDiag

2.38.6.1. Method: mGetDevModsRunning

The following section contains a detailed description of the method mGetDevModsRunning.

Method Overview

Method Name
mGetDevModsRunning

Sopas Index	172
Invocation Access	Always

Return Values	
RunDevMods	Running device modes comma seperated
FlexString	
Length	0..512
Initialisation	

Method Telegram Syntax

Method Invocation:				
`sMN mGetDevModsRunning`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mGetDevModsRunning	String	18	

Method Return Value:				
`sAN mGetDevModsRunning <RunDevMods>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mGetDevModsRunning	String	18	
Return Value 1	RunDevMods	FlexString	512	Running device modes comma seperated

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mGetDevModsRunning[ETX]`
Method Return Value:	`[STX]sAN mGetDevModsRunning 0[ETX]`

© SICK AG - Germany - All rights reserved

2.38.6.2. Method: mGetDevModsPending

The following section contains a detailed description of the method mGetDevModsPending.

Method Overview

Method Name
mGetDevModsPending

Sopas Index	173
Invocation Access	Always

Return Values		
PendDevMods		Pending device modes comma seperated
	FlexString	
	Length	0..512
	Initialisation	

Method Telegram Syntax

Method Invocation:				
`sMN mGetDevModsPending`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mGetDevModsPending	String	18	

Method Return Value:				
`sAN mGetDevModsPending <PendDevMods>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mGetDevModsPending	String	18	
Return Value 1	PendDevMods	FlexString	512	Pending device modes comma seperated

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mGetDevModsPending[ETX]`
Method Return Value:	`[STX]sAN mGetDevModsPending 0[ETX]`

© SICK AG - Germany - All rights reserved

2.38.7. Group: LiveImage

2.38.7.1. Method: StartLiveImageMode

The following section contains a detailed description of the method StartLiveImageMode.

Method Overview

Method Name
StartLiveImageMode

Communication Name	mLIStart
Sopas Index	174
Invocation Access	Always

Parameters	
ForAutoSetup	
Bool	
Value Range	False, True
Initialisation	False

Return Values			
Result			
Enum8			
	Value	Name	Description
	0	Success	
	1	NoConnection	
	2	SlowConnection	
	3	DeviceNotReady	

Method Telegram Syntax

Method Invocation:				
`sMN mLIStart <ForAutoSetup>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mLIStart	String	8	
Parameter 1	ForAutoSetup	Bool	1	

Method Return Value:				
`sAN mLIStart <Result>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mLIStart	String	8	
Return Value 1	Result	Enum8	1	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mLIStart 0[ETX]`
Method Return Value:	`[STX]sAN mLIStart 0[ETX]`

2.38.7.2. Method: StopLiveImageMode

The following section contains a detailed description of the method StopLiveImageMode.

Method Overview

Method Name
StopLiveImageMode

Communication Name	mLIStop
Sopas Index	175
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mLIStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mLIStop	String	7	

Method Return Value:				
`sAN mLIStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mLIStop	String	7	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mLIStop[ETX]`
Method Return Value:	`[STX]sAN mLIStop[ETX]`

© SICK AG - Germany - All rights reserved

2.38.8. Group: StaticImageCtrl

2.38.8.1. Variable: StaticImageSource

The following section contains a detailed description of the variable StaticImageSource.

Variable Overview

Variable Name	Description
StaticImageSource	Control variable for 'static image' device mode that allows to set the image source

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1801
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		LIVE_IMAGES	
	Value	Name	Description
	0	LIVE_IMAGES	
	1	TRIGGER_IMAGES	

Variable Telegram Syntax

Read Variable:

```
sRN StaticImageSource
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	StaticImageSource	String	17	Control variable for 'static image' device mode that allows to set the image source

Read Variable Response:

```
sRA StaticImageSource <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	StaticImageSource	String	17	Control variable for 'static image' device mode that allows to set the image source
Variable Data	data	Enum8	1	

Write Variable:

```
sWN StaticImageSource <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	StaticImageSource	String	17	Control variable for 'static image' device mode that allows to set the image source
Variable Data	data	Enum8	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA StaticImageSource				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	StaticImageSource	String	17	Control variable for 'static image' device mode that allows to set the image source

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN StaticImageSource[ETX]
Read Variable Response:	[STX]sRA StaticImageSource 0[ETX]
Write Variable:	[STX]sWN StaticImageSource 0[ETX]
Write Variable Response:	[STX]sWA StaticImageSource[ETX]

2.38.8.2. Variable: StaticImageMode

The following section contains a detailed description of the variable StaticImageMode.

Variable Overview

Variable Name	Description
StaticImageMode	Control variable for 'static image' device mode that allows to set the acquisition mode

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1802
Read-Access	Always
Write-Access	AuthorizedClient, Service

Enum8			
Default Value		CONTINUOUS	
	Value	Name	Description
	0	CONTINUOUS	
	1	SINGLE	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN StaticImageMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	StaticImageMode	String	15	Control variable for 'static image' device mode that allows to set the acquisition mode

Read Variable Response:				
`sRA StaticImageMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	StaticImageMode	String	15	Control variable for 'static image' device mode that allows to set the acquisition mode
Variable Data	data	Enum8	1	

Write Variable:				
`sWN StaticImageMode <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	StaticImageMode	String	15	Control variable for 'static image' device mode that allows to set the acquisition mode
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA StaticImageMode`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	StaticImageMode	String	15	Control variable for 'static image' device mode that allows to set the acquisition mode

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN StaticImageMode[ETX]`
Read Variable Response:	`[STX]sRA StaticImageMode 0[ETX]`
Write Variable:	`[STX]sWN StaticImageMode 0[ETX]`
Write Variable Response:	`[STX]sWA StaticImageMode[ETX]`

© SICK AG - Germany - All rights reserved

2.38.8.3. Variable: StaticImagePaused

The following section contains a detailed description of the variable StaticImagePaused.

Variable Overview

Variable Name	Description
StaticImagePaused	Control variable for 'static image' device mode that tells if image acquisition is paused or not

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1803
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN StaticImagePaused
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	StaticImagePaused	String	17	Control variable for 'static image' device mode that tells if image acquisition is paused or not

Read Variable Response:

```
sRA StaticImagePaused <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	StaticImagePaused	String	17	Control variable for 'static image' device mode that tells if image acquisition is paused or not
Variable Data	data	Bool	1	

Write Variable:

```
sWN StaticImagePaused <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	StaticImagePaused	String	17	Control variable for 'static image' device mode that tells if image acquisition is paused or not
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA StaticImagePaused
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	StaticImagePaused	String	17	Control variable for 'static image' device mode that tells if image acquisition is paused or not

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN StaticImagePaused[ETX]`
Read Variable Response:	`[STX]sRA StaticImagePaused 0[ETX]`
Write Variable:	`[STX]sWN StaticImagePaused 0[ETX]`
Write Variable Response:	`[STX]sWA StaticImagePaused[ETX]`

2.38.8.4. Method: StaticImageStart

The following section contains a detailed description of the method StaticImageStart.

Method Overview

Method Name
StaticImageStart

Sopas Index	176
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN StaticImageStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	StaticImageStart	String	16	

Method Return Value:				
`sAN StaticImageStart`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	StaticImageStart	String	16	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN StaticImageStart[ETX]`
Method Return Value:	`[STX]sAN StaticImageStart[ETX]`

© SICK AG - Germany - All rights reserved

2.38.8.5. Method: StaticImageStop

The following section contains a detailed description of the method StaticImageStop.

Method Overview

Method Name
StaticImageStop

Sopas Index	177
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN StaticImageStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	StaticImageStop	String	15	

Method Return Value:				
`sAN StaticImageStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	StaticImageStop	String	15	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN StaticImageStop[ETX]`
Method Return Value:	`[STX]sAN StaticImageStop[ETX]`

© SICK AG - Germany - All rights reserved

2.38.8.6. Method: StaticImageAcquire

The following section contains a detailed description of the method StaticImageAcquire.

Method Overview

Method Name
StaticImageAcquire

Sopas Index	178
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN StaticImageAcquire`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	StaticImageAcquire	String	18	

Method Return Value:				
`sAN StaticImageAcquire`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	StaticImageAcquire	String	18	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN StaticImageAcquire[ETX]`
Method Return Value:	`[STX]sAN StaticImageAcquire[ETX]`

© SICK AG - Germany - All rights reserved

2.38.8.7. Method: StaticImageProcess

The following section contains a detailed description of the method StaticImageProcess.

Method Overview

Method Name
StaticImageProcess

Sopas Index	179
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN StaticImageProcess`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	StaticImageProcess	String	18	

Method Return Value:				
`sAN StaticImageProcess`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	StaticImageProcess	String	18	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN StaticImageProcess[ETX]`
Method Return Value:	`[STX]sAN StaticImageProcess[ETX]`

© SICK AG - Germany - All rights reserved

2.39. Interface Block: EventMonitor

2.39.1. Group: EventMonitor

2.39.1.1. Variable: EVCheckEvtAct

The following section contains a detailed description of the variable EVCheckEvtAct.

Variable Overview

Variable Name	Description
EVCheckEvtAct	Switch Event Monitoring On/Off

Communication Name	EVMonCheck
Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1886
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:				
`sRN EVMonCheck`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EVMonCheck	String	10	Switch Event Monitoring On/Off

Read Variable Response:				
`sRA EVMonCheck <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EVMonCheck	String	10	Switch Event Monitoring On/Off
Variable Data	data	Bool	1	

Write Variable:				
`sWN EVMonCheck <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EVMonCheck	String	10	Switch Event Monitoring On/Off
Variable Data	data	Bool	1	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EVMonCheck				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EVMonCheck	String	10	Switch Event Monitoring On/Off

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EVMonCheck[ETX]
Read Variable Response:	[STX]sRA EVMonCheck 1[ETX]
Write Variable:	[STX]sWN EVMonCheck 1[ETX]
Write Variable Response:	[STX]sWA EVMonCheck[ETX]

© SICK AG - Germany - All rights reserved

2.40. Interface Block: Fieldbus

2.40.1. Group: Fieldbus

2.40.1.1. Variable: ControlBitsPlcOut

The following section contains a detailed description of the variable ControlBitsPlcOut.

Variable Overview

Variable Name	Description
ControlBitsPlcOut	Command Word received by sensor from Profibus

Communication Name	PBCMCtrlOut
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1888
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN PBCMCtrlOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	PBCMCtrlOut	String	11	Command Word received by sensor from Profibus

Read Variable Response:

```
sRA PBCMCtrlOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	PBCMCtrlOut	String	11	Command Word received by sensor from Profibus
Variable Data	data	UInt	2	

Write Variable:

```
sWN PBCMCtrlOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	PBCMCtrlOut	String	11	Command Word received by sensor from Profibus
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA PBCMCtrlOut				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	PBCMCtrlOut	String	11	Command Word received by sensor from Profibus

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN PBCMCtrlOut[ETX]
Read Variable Response:	[STX]sRA PBCMCtrlOut 0[ETX]
Write Variable:	[STX]sWN PBCMCtrlOut 0[ETX]
Write Variable Response:	[STX]sWA PBCMCtrlOut[ETX]

© SICK AG - Germany - All rights reserved

2.40.2. Group: EthernetIPResult

2.40.2.1. Variable: EIPControlBitsPlcOut

The following section contains a detailed description of the variable EIPControlBitsPlcOut.

Variable Overview

Variable Name	Description
EIPControlBitsPlcOut	Command Word received by sensor from EthernetIP

Communication Name	EIPCMCtrlOut
Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1891
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN EIPCMCtrlOut
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	EIPCMCtrlOut	String	12	Command Word received by sensor from EthernetIP

Read Variable Response:

```
sRA EIPCMCtrlOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	EIPCMCtrlOut	String	12	Command Word received by sensor from EthernetIP
Variable Data	data	UInt	2	

Write Variable:

```
sWN EIPCMCtrlOut <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	EIPCMCtrlOut	String	12	Command Word received by sensor from EthernetIP
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA EIPCMCtrlOut				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	EIPCMCtrlOut	String	12	Command Word received by sensor from EthernetIP

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN EIPCMCtrlOut[ETX]
Read Variable Response:	[STX]sRA EIPCMCtrlOut 0[ETX]
Write Variable:	[STX]sWN EIPCMCtrlOut 0[ETX]
Write Variable Response:	[STX]sWA EIPCMCtrlOut[ETX]

© SICK AG - Germany - All rights reserved

2.40.3. Group: ProfibusCommand

2.40.3.1. Variable: vPBSizeFilter1DCodes

The following section contains a detailed description of the variable vPBSizeFilter1DCodes.

Variable Overview

Variable Name
vPBSizeFilter1DCodes

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1896
Read-Access	Always
Write-Access	AuthorizedClient, Service

Struct	
CodeSizeFilterEnabled	
Bool	
Value Range	False, True
Initialisation	False
reserved	
Bool	
Value Range	False, True
Initialisation	False
MinWidth	
UInt	
Value Range	1..500
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0
MaxWidth	
UInt	
Value Range	1..500
Initialisation	500
Physical Unit	
Physical Unit Factor	0.0
MinHeight	
UInt	
Value Range	1..120
Initialisation	1
Physical Unit	
Physical Unit Factor	0.0
MaxHeight	
UInt	
Value Range	1..120
Initialisation	120
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
sRN vPBSizeFilter1DCodes				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBSizeFilter1DCodes	String	20	

Read Variable Response:				
sRA vPBSizeFilter1DCodes <CodeSizeFilterEnabled> <reserved> <MinWidth> <MaxWidth> <MinHeight> <MaxHeight>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBSizeFilter1DCodes	String	20	
Variable Data 1	CodeSizeFilterEnabled	Bool	1	
Variable Data 2	reserved	Bool	1	
Variable Data 3	MinWidth	UInt	2	
Variable Data 4	MaxWidth	UInt	2	
Variable Data 5	MinHeight	UInt	2	
Variable Data 6	MaxHeight	UInt	2	

Write Variable:				
sWN vPBSizeFilter1DCodes <CodeSizeFilterEnabled> <reserved> <MinWidth> <MaxWidth> <MinHeight> <MaxHeight>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBSizeFilter1DCodes	String	20	
Variable Data 1	CodeSizeFilterEnabled	Bool	1	
Variable Data 2	reserved	Bool	1	
Variable Data 3	MinWidth	UInt	2	
Variable Data 4	MaxWidth	UInt	2	
Variable Data 5	MinHeight	UInt	2	
Variable Data 6	MaxHeight	UInt	2	

Write Variable Response:				
sWA vPBSizeFilter1DCodes				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBSizeFilter1DCodes	String	20	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN vPBSizeFilter1DCodes[ETX]
Read Variable Response:	[STX]sRA vPBSizeFilter1DCodes 0 0 1 1F4 1 78[ETX]
Write Variable:	[STX]sWN vPBSizeFilter1DCodes 0 0 1 1F4 1 78[ETX]
Write Variable Response:	[STX]sWA vPBSizeFilter1DCodes[ETX]

© SICK AG - Germany - All rights reserved

2.40.3.2. Variable: vPBSuperResolutionActive

The following section contains a detailed description of the variable vPBSuperResolutionActive.

Variable Overview

Variable Name	Description
vPBSuperResolutionActive	Virtual Profibus variable Super Resolution Active

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1897
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN vPBSuperResolutionActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBSuperResolutionActive	String	24	Virtual Profibus variable Super Resolution Active

Read Variable Response:

```
sRA vPBSuperResolutionActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBSuperResolutionActive	String	24	Virtual Profibus variable Super Resolution Active
Variable Data	data	Bool	1	

Write Variable:

```
sWN vPBSuperResolutionActive <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBSuperResolutionActive	String	24	Virtual Profibus variable Super Resolution Active
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA vPBSuperResolutionActive
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBSuperResolutionActive	String	24	Virtual Profibus variable Super Resolution Active

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN vPBSuperResolutionActive[ETX]`
Read Variable Response:	`[STX]sRA vPBSuperResolutionActive 0[ETX]`
Write Variable:	`[STX]sWN vPBSuperResolutionActive 0[ETX]`
Write Variable Response:	`[STX]sWA vPBSuperResolutionActive[ETX]`

2.40.3.3. Variable: vPBGeneral2dCodeSettingRealValue

The following section contains a detailed description of the variable vPBGeneral2dCodeSettingRealValue.

Variable Overview

Variable Name
vPBGeneral2dCodeSettingRealValue

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1900
Read-Access	Always
Write-Access	Always

Struct		
MinModuleSize2DMM		
	UInt	
	Value Range	0..65535
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
MaxModuleSize2DMM		
	UInt	
	Value Range	0..65535
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN vPBGeneral2dCodeSettingRealValue`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBGeneral2dCodeSettingRealValue	String	32	

Read Variable Response:				
`sRA vPBGeneral2dCodeSettingRealValue <MinModuleSize2DMM> <MaxModuleSize2DMM>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBGeneral2dCodeSettingRealValue	String	32	
Variable Data 1	MinModuleSize2DMM	UInt	2	
Variable Data 2	MaxModuleSize2DMM	UInt	2	

Write Variable:				
`sWN vPBGeneral2dCodeSettingRealValue <MinModuleSize2DMM> <MaxModuleSize2DMM>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBGeneral2dCodeSettingRealValue	String	32	
Variable Data 1	MinModuleSize2DMM	UInt	2	
Variable Data 2	MaxModuleSize2DMM	UInt	2	

Write Variable Response:				
`sWA vPBGeneral2dCodeSettingRealValue`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBGeneral2dCodeSettingRealValue	String	32	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN vPBGeneral2dCodeSettingRealValue[ETX]`
Read Variable Response:	`[STX]sRA vPBGeneral2dCodeSettingRealValue 0 0[ETX]`
Write Variable:	`[STX]sWN vPBGeneral2dCodeSettingRealValue 0 0[ETX]`
Write Variable Response:	`[STX]sWA vPBGeneral2dCodeSettingRealValue[ETX]`

© SICK AG - Germany - All rights reserved

2.40.3.4. Variable: vPBIllumAndAcquisitionSettings

The following section contains a detailed description of the variable vPBIllumAndAcquisitionSettings.

Variable Overview

Variable Name
vPBIllumAndAcquisitionSettings

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1907
Read-Access	Always
Write-Access	Always

© SICK AG - Germany - All rights reserved

XByte			
Bit Length		36	
ImageROIXmin			
0.0	**UInt8**		
...	Value Range	0..255	
0.7	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	
ImageROIXmax			
1.0	**UInt8**		
...	Value Range	0..255	
1.7	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	
ImageROIYmin			
2.0	**UInt8**		
...	Value Range	0..255	
2.7	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	
ImageROIYmax			
3.0	**UInt8**		
...	Value Range	0..255	
3.7	Initialisation		
	Physical Unit		
	Physical Unit Factor	0.0	
FlickerFreeMode			
4.0	**Bool**		
	Value Range	False, True	
	Initialisation	True	
FlickerFreeFrequency			
4.1	**Enum1**		
	Default Value	Level1	
	Value	Name	Description
	0	Level1	
	1	Level2	
ImageMirroring			
4.2	**Bool**		
	Value Range	False, True	
	Initialisation	True	
PixelBinning			
4.3	**Enum1**		
	Default Value	0	
	Value	Name	Description
	0	TX_IMG_BINN_NONE	
	1	TX_IMG_BINN_2X2	

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN vPBIllumAndAcquisitionSettings`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBIllumAndAcquisitionSettings	String	30	

Read Variable Response:				
`sRA vPBIllumAndAcquisitionSettings <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBIllumAndAcquisitionSettings	String	30	
Variable Data	data	XByte	5	

Write Variable:				
`sWN vPBIllumAndAcquisitionSettings <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBIllumAndAcquisitionSettings	String	30	
Variable Data	data	XByte	5	

Write Variable Response:				
`sWA vPBIllumAndAcquisitionSettings`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBIllumAndAcquisitionSettings	String	30	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN vPBIllumAndAcquisitionSettings[ETX]`
Read Variable Response:	`[STX]sRA vPBIllumAndAcquisitionSettings 00 00 00 00 00[ETX]`
Write Variable:	`[STX]sWN vPBIllumAndAcquisitionSettings 00 00 00 00 00[ETX]`
Write Variable Response:	`[STX]sWA vPBIllumAndAcquisitionSettings[ETX]`

© SICK AG - Germany - All rights reserved

2.40.3.5. Variable: vPBEndOfParam

The following section contains a detailed description of the variable vPBEndOfParam.

Variable Overview

Variable Name
vPBEndOfParam

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1927
Read-Access	Always
Write-Access	Always

Enum8			
Default Value		1	
	Value	Name	Description
	0	TX_DO_NOT_SAVE	
	1	TX_DO_SAVE	

Variable Telegram Syntax

Read Variable:				
`sRN vPBEndOfParam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBEndOfParam	String	13	

Read Variable Response:				
`sRA vPBEndOfParam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBEndOfParam	String	13	
Variable Data	data	Enum8	1	

Write Variable:				
`sWN vPBEndOfParam <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBEndOfParam	String	13	
Variable Data	data	Enum8	1	

Write Variable Response:				
`sWA vPBEndOfParam`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBEndOfParam	String	13	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN vPBEndOfParam[ETX]`
Read Variable Response:	`[STX]sRA vPBEndOfParam 1[ETX]`
Write Variable:	`[STX]sWN vPBEndOfParam 1[ETX]`
Write Variable Response:	`[STX]sWA vPBEndOfParam[ETX]`

2.40.3.6. Variable: vPBCommandX20

The following section contains a detailed description of the variable vPBCommandX20.

Variable Overview

Variable Name
vPBCommandX20

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1928
Read-Access	Always
Write-Access	Always

Array		
Length		20
Default Value		{{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0},{0}}
	UserType	
	Asci127_t	See the chapter "User Types" for details.

Variable Telegram Syntax

Read Variable:				
`sRN vPBCommandX20`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBCommandX20	String	13	

Read Variable Response:				
`sRA vPBCommandX20 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBCommandX20	String	13	
Variable Data	data	Array	20	

© SICK AG - Germany - All rights reserved

Write Variable:				
sWN vPBCommandX20 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBCommandX20	String	13	
Variable Data	data	Array	20	

Write Variable Response:				
sWA vPBCommandX20				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBCommandX20	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN vPBCommandX20[ETX]
Read Variable Response:	[STX]sRA vPBCommandX20 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0[ETX]
Write Variable:	[STX]sWN vPBCommandX20 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0[ETX]
Write Variable Response:	[STX]sWA vPBCommandX20[ETX]

2.40.3.7. Variable: vPBCommandX30

The following section contains a detailed description of the variable vPBCommandX30.

Variable Overview

Variable Name
vPBCommandX30

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1929
Read-Access	Always
Write-Access	Always

Array		
Length		30
Default Value		{{0},{0},{0},

Variable Telegram Syntax

Read Variable:				
`sRN vPBCommandX30`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	vPBCommandX30	String	13	

Read Variable Response:				
`sRA vPBCommandX30 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	vPBCommandX30	String	13	
Variable Data	data	Array	30	

Write Variable:				
`sWN vPBCommandX30 <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBCommandX30	String	13	
Variable Data	data	Array	30	

Write Variable Response:				
`sWA vPBCommandX30`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBCommandX30	String	13	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN vPBCommandX30[ETX]`
Read Variable Response:	`[STX]sRA vPBCommandX30 0 0 0

2.40.3.8. Variable: vPBCommandX50

The following section contains a detailed description of the variable vPBCommandX50.

Variable Overview

Variable Name
vPBCommandX50

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1930
Read-Access	Always
Write-Access	Always

Array		
Length		50
Default Value		{{0},{0},{0},

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN vPBCommandX50[ETX]
Read Variable Response:	[STX]sRA vPBCommandX50 0 0 0

Write Variable:				
sWN vPBCommandX100 <data>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	vPBCommandX100	String	14	
Variable Data	data	Array	100	

Write Variable Response:				
sWA vPBCommandX100				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	vPBCommandX100	String	14	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN vPBCommandX100[ETX]
Read Variable Response:	[STX]sRA vPBCommandX100 0 0 0

Array		
Length		200
Default Value		{{0},{0},{0},

Write Variable:	[STX]sWN vPBCommandX200 0 0 0

Method Telegram Syntax

Method Invocation:				
`sMN mPBCMexecCmd <CmdString>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mPBCMexecCmd	String	12	Execute a command received via PB
Parameter 1	CmdString	Array	2080	

Method Return Value:				
`sAN mPBCMexecCmd <RespString>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mPBCMexecCmd	String	12	Execute a command received via PB
Return Value 1	RespString	Array	4094	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mPBCMexecCmd 0[ETX]`
Method Return Value:	`[STX]sAN mPBCMexecCmd 0[ETX]`

2.40.3.12. Method: vCdfUpDatePnConfig

The following section contains a detailed description of the method vCdfUpDatePnConfig.

Method Overview

Method Name
vCdfUpDatePnConfig

Sopas Index	183
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN vCdfUpDatePnConfig				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	vCdfUpDatePnConfig	String	18	

Method Return Value:				
sAN vCdfUpDatePnConfig				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	vCdfUpDatePnConfig	String	18	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN vCdfUpDatePnConfig[ETX]
Method Return Value:	[STX]sAN vCdfUpDatePnConfig[ETX]

© SICK AG - Germany - All rights reserved

2.40.4. Group: VirtualModbus

2.40.4.1. Variable: ModbusCommandWord

The following section contains a detailed description of the variable ModbusCommandWord.

Variable Overview

Variable Name
ModbusCommandWord

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1934
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ModbusCommandWord
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ModbusCommandWord	String	17	

Read Variable Response:

```
sRA ModbusCommandWord <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ModbusCommandWord	String	17	
Variable Data	data	UInt	2	

Write Variable:

```
sWN ModbusCommandWord <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ModbusCommandWord	String	17	
Variable Data	data	UInt	2	

Write Variable Response:

```
sWA ModbusCommandWord
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ModbusCommandWord				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command	ModbusCommandWord	String	17	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ModbusCommandWord[ETX]
Read Variable Response:	[STX]sRA ModbusCommandWord 0[ETX]
Write Variable:	[STX]sWN ModbusCommandWord 0[ETX]
Write Variable Response:	[STX]sWA ModbusCommandWord[ETX]

2.40.4.2. Variable: ModbusResultBuf

The following section contains a detailed description of the variable ModbusResultBuf.

Variable Overview

Variable Name	Description
ModbusResultBuf	Result buffer for reading results

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1935
Read-Access	Always
Write-Access	Always

Array		
Length		50
	USInt	
	Value Range	0..255
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Variable Telegram Syntax

Read Variable:				
`sRN ModbusResultBuf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ModbusResultBuf	String	15	Result buffer for reading results

Read Variable Response:				
`sRA ModbusResultBuf <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ModbusResultBuf	String	15	Result buffer for reading results
Variable Data	data	Array	50	

Write Variable:				
`sWN ModbusResultBuf <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ModbusResultBuf	String	15	Result buffer for reading results
Variable Data	data	Array	50	

Write Variable Response:				
`sWA ModbusResultBuf`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ModbusResultBuf	String	15	Result buffer for reading results

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ModbusResultBuf[ETX]`
Read Variable Response:	`[STX]sRA ModbusResultBuf 0 0 0

2.40.4.3. Variable: ModbusResultChangeCtr

The following section contains a detailed description of the variable ModbusResultChangeCtr.

Variable Overview

Variable Name	Description
ModbusResultChangeCtr	Will be incremented for each reading result

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1936
Read-Access	Always
Write-Access	Always

USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN ModbusResultChangeCtr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ModbusResultChangeCtr	String	21	Will be incremented for each reading result

Read Variable Response:

```
sRA ModbusResultChangeCtr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ModbusResultChangeCtr	String	21	Will be incremented for each reading result
Variable Data	data	USInt	1	

Write Variable:

```
sWN ModbusResultChangeCtr <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ModbusResultChangeCtr	String	21	Will be incremented for each reading result
Variable Data	data	USInt	1	

Write Variable Response:

```
sWA ModbusResultChangeCtr
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ModbusResultChangeCtr	String	21	Will be incremented for each reading result

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ModbusResultChangeCtr[ETX]`
Read Variable Response:	`[STX]sRA ModbusResultChangeCtr 0[ETX]`
Write Variable:	`[STX]sWN ModbusResultChangeCtr 0[ETX]`
Write Variable Response:	`[STX]sWA ModbusResultChangeCtr[ETX]`

© SICK AG - Germany - All rights reserved

2.40.5. Group: DummyGroupForVirtualMemRef_FBParamEEprom

2.40.5.1. Variable: Dummy_FBParamEEprom_Type

The following section contains a detailed description of the variable Dummy_FBParamEEprom_Type.

Variable Overview

Variable Name
Dummy_FBParamEEprom_Type

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1937
Storage	Variable is stored in FBParamEEprom
Read-Access	Always
Write-Access	Always

UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN Dummy_FBParamEEprom_Type
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	Dummy_FBParamEEprom_Type	String	24	

Read Variable Response:

```
sRA Dummy_FBParamEEprom_Type <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	Dummy_FBParamEEprom_Type	String	24	
Variable Data	data	UInt	2	

Write Variable:

```
sWN Dummy_FBParamEEprom_Type <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	Dummy_FBParamEEprom_Type	String	24	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA Dummy_FBParamEEprom_Type				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	Dummy_FBParamEEprom_Type	String	24	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN Dummy_FBParamEEprom_Type[ETX]
Read Variable Response:	[STX]sRA Dummy_FBParamEEprom_Type 0[ETX]
Write Variable:	[STX]sWN Dummy_FBParamEEprom_Type 0[ETX]
Write Variable Response:	[STX]sWA Dummy_FBParamEEprom_Type[ETX]

© SICK AG - Germany - All rights reserved

2.41. Interface Block: BlobTransfer

2.41.1. Group: CommonBlobConfig

2.41.1.1. Variable: BlobFragmentSize

The following section contains a detailed description of the variable BlobFragmentSize.

Variable Overview

Variable Name
BlobFragmentSize

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1939
Read-Access	Always
Write-Access	Service

UInt	
Value Range	1..1024
Initialisation	1024
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BlobFragmentSize
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BlobFragmentSize	String	16	

Read Variable Response:

```
sRA BlobFragmentSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BlobFragmentSize	String	16	
Variable Data	data	UInt	2	

Write Variable:

```
sWN BlobFragmentSize <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BlobFragmentSize	String	16	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BlobFragmentSize				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BlobFragmentSize	String	16	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BlobFragmentSize[ETX]
Read Variable Response:	[STX]sRA BlobFragmentSize 400[ETX]
Write Variable:	[STX]sWN BlobFragmentSize 400[ETX]
Write Variable Response:	[STX]sWA BlobFragmentSize[ETX]

2.41.1.2. Method: BlobServerGetStatistics

The following section contains a detailed description of the method BlobServerGetStatistics.

Method Overview

Method Name
BlobServerGetStatistics

Sopas Index	184
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Return Values	
Levels	
Array	
Length	2
Struct	
Decoding	
Struct	
NumImages	
UDInt	Return Values[Levels].Array.Struct[Decoding].Struct[NumImages].UDInt
NumErrors	
UDInt	Return Values[Levels].Array.Struct[Decoding].Struct[NumErrors].UDInt
Sending	
Struct	
NumImages	
UDInt	Return Values[Levels].Array.Struct[Sending].Struct[NumImages].UDInt
NumErrors	
UDInt	Return Values[Levels].Array.Struct[Sending].Struct[NumErrors].UDInt
NumInactive	
UDInt	Return Values[Levels].Array.Struct[Sending].Struct[NumInactive].UDInt
ScalingTime	
Struct	
MinTime_ms	
Real	Return Values[Levels].Array.Struct[ScalingTime].Struct[MinTime_ms].Real
AvgTime_ms	
Real	Return Values[Levels].Array.Struct[ScalingTime].Struct[AvgTime_ms].Real
MaxTime_ms	
Real	Return Values[Levels].Array.Struct[ScalingTime].Struct[MaxTime_ms].Real
SendingTime	
Struct	
MinTime_ms	
Real	Return Values[Levels].Array.Struct[SendingTime].Struct[MinTime_ms].Real
AvgTime_ms	
Real	Return Values[Levels].Array.Struct[SendingTime].Struct[AvgTime_ms].Real
MaxTime_ms	
Real	Return Values[Levels].Array.Struct[SendingTime].Struct[MaxTime_ms].Real

UDInt	Return Values[Levels].Array.Struct[Decoding].Struct[NumImages].UDInt
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

UDInt	Return Values[Levels].Array.Struct[Decoding].Struct[NumErrors].UDInt
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

UDInt	Return Values[Levels].Array.Struct[Sending].Struct[NumImages].UDInt
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

UDInt	Return Values[Levels].Array.Struct[Sending].Struct[NumErrors].UDInt
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

UDInt	Return Values[Levels].Array.Struct[Sending].Struct[NumInactive].UDInt
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Real	Return Values[Levels].Array.Struct[ScalingTime].Struct[MinTime_ms].Real
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Real	Return Values[Levels].Array.Struct[ScalingTime].Struct[AvgTime_ms].Real
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Real	Return Values[Levels].Array.Struct[ScalingTime].Struct[MaxTime_ms].Real
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Real	Return Values[Levels].Array.Struct[SendingTime].Struct[MinTime_ms].Real
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Real	Return Values[Levels].Array.Struct[SendingTime].Struct[AvgTime_ms].Real
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Real	Return Values[Levels].Array.Struct[SendingTime].Struct[MaxTime_ms].Real
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN BlobServerGetStatistics`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	BlobServerGetStatistics	String	23	

Method Return Value:				
`sAN BlobServerGetStatistics <Levels>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	BlobServerGetStatistics	String	23	
Return Value 1	Levels	Array	88	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN BlobServerGetStatistics[ETX]`
Method Return Value:	`[STX]sAN BlobServerGetStatistics 0 0 0 0 0 00000000 00000000 00000000 00000000 00000000 00000000 0 0 0 0 0 00000000 00000000 00000000 00000000 00000000 00000000[ETX]`

2.41.1.3. Method: BlobServerResetLocalStatistics

The following section contains a detailed description of the method BlobServerResetLocalStatistics.

Method Overview

Method Name
BlobServerResetLocalStatistics

Sopas Index	185
Invocation Access	Always

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN BlobServerResetLocalStatistics				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	BlobServerResetLocalStatistics	String	30	

Method Return Value:				
sAN BlobServerResetLocalStatistics				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	BlobServerResetLocalStatistics	String	30	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN BlobServerResetLocalStatistics[ETX]
Method Return Value:	[STX]sAN BlobServerResetLocalStatistics[ETX]

© SICK AG - Germany - All rights reserved

2.41.2. Group: BlobClientConfig

2.41.2.1. Variable: BlobTcpPort

The following section contains a detailed description of the variable BlobTcpPort.

Variable Overview

Variable Name
BlobTcpPort

Sopas Synchronisation	Variable is relevant for synchronisation with SOPAS ET.
Sopas Index	1940
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

UInt	
Value Range	1025..65535
Initialisation	2113
Physical Unit	
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:

```
sRN BlobTcpPort
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	BlobTcpPort	String	11	

Read Variable Response:

```
sRA BlobTcpPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	BlobTcpPort	String	11	
Variable Data	data	UInt	2	

Write Variable:

```
sWN BlobTcpPort <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	BlobTcpPort	String	11	
Variable Data	data	UInt	2	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA BlobTcpPort				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	BlobTcpPort	String	11	

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN BlobTcpPort[ETX]
Read Variable Response:	[STX]sRA BlobTcpPort 841[ETX]
Write Variable:	[STX]sWN BlobTcpPort 841[ETX]
Write Variable Response:	[STX]sWA BlobTcpPort[ETX]

2.41.2.2. Method: GetBlobClientConfig

The following section contains a detailed description of the method GetBlobClientConfig.

Method Overview

Method Name
GetBlobClientConfig

Sopas Index	186
Invocation Access	Always

Return Values		
TransportProtocol		
	FlexString	
	Length	0..20
	Initialisation	TCP
DeviceIpAddress		
	FlexString	
	Length	0..15
	Initialisation	
MulticastIpAddress		
	FlexString	
	Length	0..15
	Initialisation	
TcpPort		
	UInt	
	Value Range	0..65535
	Initialisation	2113
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
UdpPeerPort	
UInt	
Value Range	0..65535
Initialisation	2122
Physical Unit	
Physical Unit Factor	0.0
UdpLocalPort	
UInt	
Value Range	0..65535
Initialisation	2121
Physical Unit	
Physical Unit Factor	0.0
Active	
Bool	
Value Range	False, True
Initialisation	False
FragmentSize	
UInt	
Value Range	0..65535
Initialisation	1024
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN GetBlobClientConfig
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	GetBlobClientConfig	String	19	

Method Return Value:

```
sAN GetBlobClientConfig <TransportProtocol> <DeviceIpAddress> <MulticastIpAddress> <TcpPort>
<UdpPeerPort> <UdpLocalPort> <Active> <FragmentSize>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	GetBlobClientConfig	String	19	
Return Value 1	TransportProtocol	FlexString	20	
Return Value 2	DeviceIpAddress	FlexString	15	
Return Value 3	MulticastIpAddress	FlexString	15	
Return Value 4	TcpPort	UInt	2	
Return Value 5	UdpPeerPort	UInt	2	
Return Value 6	UdpLocalPort	UInt	2	
Return Value 7	Active	Bool	1	
Return Value 8	FragmentSize	UInt	2	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN GetBlobClientConfig[ETX]`
Method Return Value:	`[STX]sAN GetBlobClientConfig 3 TCP 0 0 841 84A 849 0 400[ETX]`

© SICK AG - Germany - All rights reserved

2.42. Interface Block: Lector6xxHardware

2.42.1. Group: Optics

2.42.1.1. Variable: ESys

The following section contains a detailed description of the variable ESys.

Variable Overview

Variable Name	Description
ESys	ESys

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	1953
Storage	Variable is stored in CalibEEpromEKAnalog
Read-Access	Always
Write-Access	Always

Real	
Value Range	See specification IEEE 754 -1000000.0..1000000.0
Initialisation	1.0
Physical Unit	mm
Physical Unit Factor	0.0

Variable Telegram Syntax

Read Variable:				
`sRN ESys`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ESys	String	4	ESys

Read Variable Response:				
`sRA ESys <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ESys	String	4	ESys
Variable Data	data	Real	4	

Write Variable:				
`sWN ESys <data>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ESys	String	4	ESys
Variable Data	data	Real	4	

© SICK AG - Germany - All rights reserved

Write Variable Response:				
sWA ESys				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ESys	String	4	ESys

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	[STX]sRN ESys[ETX]
Read Variable Response:	[STX]sRA ESys 3F800000[ETX]
Write Variable:	[STX]sWN ESys 3F800000[ETX]
Write Variable Response:	[STX]sWA ESys[ETX]

© SICK AG - Germany - All rights reserved

2.42.2. Group: FocusCtrl6xx

2.42.2.1. Method: GetFocusPositionIs

The following section contains a detailed description of the method GetFocusPositionIs.

Method Overview

Method Name	Description
GetFocusPositionIs	Retrieves the current focus position in mm

Communication Name	mGetFocPosIs
Sopas Index	190
Invocation Access	Always

Return Values	
focPos	
Real	
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	mm
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mGetFocPosIs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mGetFocPosIs	String	12	Retrieves the current focus position in mm

Method Return Value:				
`sAN mGetFocPosIs <focPos>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mGetFocPosIs	String	12	Retrieves the current focus position in mm
Return Value 1	focPos	Real	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mGetFocPosIs[ETX]`
Method Return Value:	`[STX]sAN mGetFocPosIs 00000000[ETX]`

© SICK AG - Germany - All rights reserved

2.42.2.2. Method: GetMotorPosMinMax

The following section contains a detailed description of the method GetMotorPosMinMax.

Method Overview

Method Name
GetMotorPosMinMax

Communication Name	mOPGetMotorMinMax
Sopas Index	191
Invocation Access	Always

Return Values		
Min		
	UInt	
	Value Range	0..65535
	Initialisation	
	Physical Unit	HS
	Physical Unit Factor	0.0
Max		
	UInt	
	Value Range	0..65535
	Initialisation	
	Physical Unit	HS
	Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mOPGetMotorMinMax`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mOPGetMotorMinMax	String	17	

Method Return Value:				
`sAN mOPGetMotorMinMax <Min> <Max>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mOPGetMotorMinMax	String	17	
Return Value 1	Min	UInt	2	
Return Value 2	Max	UInt	2	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mOPGetMotorMinMax[ETX]`
Method Return Value:	`[STX]sAN mOPGetMotorMinMax 0 0[ETX]`

2.42.2.3. Method: SetMotorPosAbsolute

The following section contains a detailed description of the method SetMotorPosAbsolute.

Method Overview

Method Name
SetMotorPosAbsolute

Communication Name	mFCSetMotorPosAbs
Sopas Index	192
Invocation Access	Always

Parameters	
pos	
Int	
Value Range	-32768..32767
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFCSetMotorPosAbs <pos>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFCSetMotorPosAbs	String	17	
Parameter 1	pos	Int	2	

Method Return Value:				
`sAN mFCSetMotorPosAbs`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFCSetMotorPosAbs	String	17	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFCSetMotorPosAbs 0[ETX]`
Method Return Value:	`[STX]sAN mFCSetMotorPosAbs[ETX]`

2.42.2.4. Method: SetMotorPosRelative

The following section contains a detailed description of the method SetMotorPosRelative.

Method Overview

Method Name
SetMotorPosRelative

Communication Name	mFCSetMotorPosRelative
Sopas Index	193
Invocation Access	Always

Parameters	
delta	
Int	
Value Range	-32768..32767
Initialisation	0
Physical Unit	
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFCSetMotorPosRelative <delta>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFCSetMotorPosRelative	String	22	
Parameter 1	delta	Int	2	

Method Return Value:				
`sAN mFCSetMotorPosRelative`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFCSetMotorPosRelative	String	22	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFCSetMotorPosRelative 0[ETX]`
Method Return Value:	`[STX]sAN mFCSetMotorPosRelative[ETX]`

2.42.2.5. Method: GetMotorRotationAngle

The following section contains a detailed description of the method GetMotorRotationAngle.

Method Overview

Method Name
GetMotorRotationAngle

Communication Name	mFCGetMotorRotationAngle
Sopas Index	194
Invocation Access	Always

Return Values		
Steps		
	UInt	
	Value Range	0..4095
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
TooLow		
	Bool	
	Value Range	False, True
	Initialisation	False
TooHigh		
	Bool	
	Value Range	False, True
	Initialisation	False
CommError		
	Bool	
	Value Range	False, True
	Initialisation	False
ParityError		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mFCGetMotorRotationAngle				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFCGetMotorRotationAngle	String	24	

Method Return Value:				
sAN mFCGetMotorRotationAngle <Steps> <TooLow> <TooHigh> <CommError> <ParityError>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFCGetMotorRotationAngle	String	24	
Return Value 1	Steps	UInt	2	
Return Value 2	TooLow	Bool	1	
Return Value 3	TooHigh	Bool	1	
Return Value 4	CommError	Bool	1	
Return Value 5	ParityError	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mFCGetMotorRotationAngle[ETX]
Method Return Value:	[STX]sAN mFCGetMotorRotationAngle 0 0 0 0 0[ETX]

2.42.2.6. Method: GetMMPerPixel

The following section contains a detailed description of the method GetMMPerPixel.

Method Overview

Method Name	Description
GetMMPerPixel	Run the Pixel-to-Millimeter computation at a given assumed focus distance

Communication Name	mFCGetPixelPerMM
Sopas Index	195
Invocation Access	Always

Parameters	
FocusDistanceMM	
Real	
Value Range	See specification IEEE 754
Initialisation	0.0
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
PixelWidth	
Real	
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	mm/Pix
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:

```
sMN mFCGetPixelPerMM <FocusDistanceMM>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFCGetPixelPerMM	String	16	Run the Pixel-to-Millimeter computation at a given assumed focus distance
Parameter 1	FocusDistanceMM	Real	4	

Method Return Value:

```
sAN mFCGetPixelPerMM <PixelWidth>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFCGetPixelPerMM	String	16	Run the Pixel-to-Millimeter computation at a given assumed focus distance
Return Value 1	PixelWidth	Real	4	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mFCGetPixelPerMM 00000000[ETX]`
Method Return Value:	`[STX]sAN mFCGetPixelPerMM 00000000[ETX]`

© SICK AG - Germany - All rights reserved

2.42.2.7. Method: GetMotorPos

The following section contains a detailed description of the method GetMotorPos.

Method Overview

Method Name
GetMotorPos

Communication Name	mFCGetMotorPos
Sopas Index	196
Invocation Access	Always

Return Values	
Pos	
UInt	
Value Range	0..65535
Initialisation	
Physical Unit	HS
Physical Unit Factor	0.0

Method Telegram Syntax

Method Invocation:				
`sMN mFCGetMotorPos`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFCGetMotorPos	String	14	

Method Return Value:				
`sAN mFCGetMotorPos <Pos>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFCGetMotorPos	String	14	
Return Value 1	Pos	UInt	2	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFCGetMotorPos[ETX]`
Method Return Value:	`[STX]sAN mFCGetMotorPos 0[ETX]`

© SICK AG - Germany - All rights reserved

2.42.2.8. Method: DisableLiquidLensOutput

The following section contains a detailed description of the method DisableLiquidLensOutput.

Method Overview

Method Name
DisableLiquidLensOutput

Communication Name	mFCDisableLiquidLensOutput
Sopas Index	197
Invocation Access	Always

Return Values		
Disable		
	Bool	
	Value Range	False, True
	Initialisation	False

Method Telegram Syntax

Method Invocation:				
`sMN mFCDisableLiquidLensOutput`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mFCDisableLiquidLensOutput	String	26	

Method Return Value:				
`sAN mFCDisableLiquidLensOutput <Disable>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mFCDisableLiquidLensOutput	String	26	
Return Value 1	Disable	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mFCDisableLiquidLensOutput[ETX]`
Method Return Value:	`[STX]sAN mFCDisableLiquidLensOutput 0[ETX]`

© SICK AG - Germany - All rights reserved

2.42.3. Group: FPGA

2.42.3.1. Method: DumpIOMUX

The following section contains a detailed description of the method DumpIOMUX.

Method Overview

Method Name
DumpIOMUX

Communication Name	mDumpIOMUX
Sopas Index	227
Invocation Access	Always

Return Values	
Dump	
FlexString	
Length	0..6000
Initialisation	0

Method Telegram Syntax

Method Invocation:				
`sMN mDumpIOMUX`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDumpIOMUX	String	10	

Method Return Value:				
`sAN mDumpIOMUX <Dump>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDumpIOMUX	String	10	
Return Value 1	Dump	FlexString	6000	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDumpIOMUX[ETX]`
Method Return Value:	`[STX]sAN mDumpIOMUX 1 0[ETX]`

© SICK AG - Germany - All rights reserved

2.42.3.2. Method: ExecFpgaDeveloperCommand

The following section contains a detailed description of the method ExecFpgaDeveloperCommand.

Method Overview

Method Name
ExecFpgaDeveloperCommand

Communication Name	mExecFpgaDevCmd
Sopas Index	228
Invocation Access	Always

Parameters	
Request	
FlexString	
Length	0..1000
Initialisation	

Return Values	
Response	
FlexString	
Length	0..1000
Initialisation	0

Method Telegram Syntax

Method Invocation:

```
sMN mExecFpgaDevCmd <Request>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mExecFpgaDevCmd	String	15	
Parameter 1	Request	FlexString	1000	

Method Return Value:

```
sAN mExecFpgaDevCmd <Response>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mExecFpgaDevCmd	String	15	
Return Value 1	Response	FlexString	1000	

© SICK AG - Germany - All rights reserved

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mExecFpgaDevCmd 0[ETX]`
Method Return Value:	`[STX]sAN mExecFpgaDevCmd 1 0[ETX]`

© SICK AG - Germany - All rights reserved

2.42.4. Group: DebugMisc

2.42.4.1. Method: TracingStop

The following section contains a detailed description of the method TracingStop.

Method Overview

Method Name
TracingStop

Communication Name	mDBGMTraceStop
Sopas Index	230
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mDBGMTraceStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mDBGMTraceStop	String	14	

Method Return Value:				
`sAN mDBGMTraceStop`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mDBGMTraceStop	String	14	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mDBGMTraceStop[ETX]`
Method Return Value:	`[STX]sAN mDBGMTraceStop[ETX]`

© SICK AG - Germany - All rights reserved

2.42.5. Group: Imager

2.42.5.1. Variable: GeneralImgOutActive

The following section contains a detailed description of the variable GeneralImgOutActive.

Variable Overview

Variable Name
GeneralImgOutActive

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	2179
Read-Access	Service
Write-Access	Service

Bool	
Value Range	False, True
Initialisation	True

Variable Telegram Syntax

Read Variable:
`sRN GeneralImgOutActive`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	GeneralImgOutActive	String	19	

Read Variable Response:
`sRA GeneralImgOutActive <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	GeneralImgOutActive	String	19	
Variable Data	data	Bool	1	

Write Variable:
`sWN GeneralImgOutActive <data>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	GeneralImgOutActive	String	19	
Variable Data	data	Bool	1	

Write Variable Response:
`sWA GeneralImgOutActive`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	GeneralImgOutActive	String	19	

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN GeneralImgOutActive[ETX]`
Read Variable Response:	`[STX]sRA GeneralImgOutActive 1[ETX]`
Write Variable:	`[STX]sWN GeneralImgOutActive 1[ETX]`
Write Variable Response:	`[STX]sWA GeneralImgOutActive[ETX]`

2.42.5.2. Method: RequestFrameStatistics

The following section contains a detailed description of the method RequestFrameStatistics.

Method Overview

Method Name
RequestFrameStatistics

Sopas Index	238
Invocation Access	Always

Return Values		
AcquiredFramesReadingGate		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
LostFramesReadingGate		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
DecodedFramesReadingGate		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0
FramesInDecoQueueReadingGate		
	UDInt	
	Value Range	0..4294967295
	Initialisation	
	Physical Unit	
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
FrameCounterFPGA	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
FlashTime	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
FrameRate	
Real	
Value Range	See specification IEEE 754
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
TotalFrameTime	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	µs
Physical Unit Factor	0.0
ProperFramesTotal	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
SpillFramesTotal	
UDInt	
Value Range	0..4294967295
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:
`sMN RequestFrameStatistics`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	RequestFrameStatistics	String	22	

Method Return Value:
`sAN RequestFrameStatistics <AcquiredFramesReadingGate> <LostFramesReadingGate> <DecodedFramesReadingGate> <FramesInDecoQueueReadingGate> <FrameCounterFPGA> <FlashTime> <FrameRate> <TotalFrameTime> <ProperFramesTotal> <SpillFramesTotal>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	RequestFrameStatistics	String	22	
Return Value 1	AcquiredFramesReadingGate	UDInt	4	
Return Value 2	LostFramesReadingGate	UDInt	4	
Return Value 3	DecodedFramesReadingGate	UDInt	4	
Return Value 4	FramesInDecoQueueReadingGate	UDInt	4	
Return Value 5	FrameCounterFPGA	UDInt	4	
Return Value 6	FlashTime	UDInt	4	
Return Value 7	FrameRate	Real	4	
Return Value 8	TotalFrameTime	UDInt	4	
Return Value 9	ProperFramesTotal	UDInt	4	
Return Value 10	SpillFramesTotal	UDInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN RequestFrameStatistics[ETX]`
Method Return Value:	`[STX]sAN RequestFrameStatistics 0 0 0 0 0 0 00000000 0 0 0[ETX]`

© SICK AG - Germany - All rights reserved

2.42.5.3. Method: CuckooImageLoad

The following section contains a detailed description of the method CuckooImageLoad.

Method Overview

Method Name
CuckooImageLoad

Communication Name	mLoadCuckoo
Sopas Index	242
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mLoadCuckoo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mLoadCuckoo	String	11	

Method Return Value:				
`sAN mLoadCuckoo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mLoadCuckoo	String	11	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mLoadCuckoo[ETX]`
Method Return Value:	`[STX]sAN mLoadCuckoo[ETX]`

© SICK AG - Germany - All rights reserved

2.42.5.4. Method: CuckooImageClear

The following section contains a detailed description of the method CuckooImageClear.

Method Overview

Method Name
CuckooImageClear

Communication Name	mClearCuckoo
Sopas Index	243
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN mClearCuckoo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mClearCuckoo	String	12	

Method Return Value:				
`sAN mClearCuckoo`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mClearCuckoo	String	12	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mClearCuckoo[ETX]`
Method Return Value:	`[STX]sAN mClearCuckoo[ETX]`

© SICK AG - Germany - All rights reserved

2.42.6. Group: OutputHardware2

2.42.6.1. Method: MAX14820ReadRegisters

The following section contains a detailed description of the method MAX14820ReadRegisters.

Method Overview

Method Name	Description
MAX14820ReadRegisters	Read-out all MAX14820 registers

Sopas Index	245
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN MAX14820ReadRegisters`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	MAX14820ReadRegisters	String	21	Read-out all MAX14820 registers

Method Return Value:				
`sAN MAX14820ReadRegisters`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	MAX14820ReadRegisters	String	21	Read-out all MAX14820 registers

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN MAX14820ReadRegisters[ETX]`
Method Return Value:	`[STX]sAN MAX14820ReadRegisters[ETX]`

© SICK AG - Germany - All rights reserved

2.42.6.2. Method: MAX14820WriteRegisters

The following section contains a detailed description of the method MAX14820WriteRegisters.

Method Overview

Method Name	Description
MAX14820WriteRegisters	Write all MAX14820 registers

Sopas Index	246
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN MAX14820WriteRegisters`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	MAX14820WriteRegisters	String	22	Write all MAX14820 registers

Method Return Value:				
`sAN MAX14820WriteRegisters`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	MAX14820WriteRegisters	String	22	Write all MAX14820 registers

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN MAX14820WriteRegisters[ETX]`
Method Return Value:	`[STX]sAN MAX14820WriteRegisters[ETX]`

© SICK AG - Germany - All rights reserved

2.42.7. Group: Temperature

2.42.7.1. Method: TemperatureGetValues

The following section contains a detailed description of the method TemperatureGetValues.

Method Overview

Method Name
TemperatureGetValues

Sopas Index	247
Invocation Access	Always

Return Values		
EKLed		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	
	Physical Unit	°C
	Physical Unit Factor	0.0
EKAnalog		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	
	Physical Unit	°C
	Physical Unit Factor	0.0
EKImager		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	
	Physical Unit	°C
	Physical Unit Factor	0.0
EKInterface		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	
	Physical Unit	°C
	Physical Unit Factor	0.0
EKDigitalFPGA		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	
	Physical Unit	°C
	Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Return Values	
EKDigitalQorIQ	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	°C
Physical Unit Factor	0.0
EKDigitalPowerSupply	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	°C
Physical Unit Factor	0.0
EKDigitalEdge	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	°C
Physical Unit Factor	0.0
EKLM95214	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	°C
Physical Unit Factor	0.0
EKAccSensor	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	°C
Physical Unit Factor	0.0
EKLiquidLens	
DInt	
Value Range	-2147483648..2147483647
Initialisation	
Physical Unit	°C
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:
`sMN TemperatureGetValues`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	TemperatureGetValues	String	20	

Method Return Value:
`sAN TemperatureGetValues <EKLed> <EKAnalog> <EKImager> <EKInterface> <EKDigitalFPGA> <EKDigitalQorIQ> <EKDigitalPowerSupply> <EKDigitalEdge> <EKLM95214> <EKAccSensor> <EKLiquidLens>`

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	TemperatureGetValues	String	20	
Return Value 1	EKLed	DInt	4	
Return Value 2	EKAnalog	DInt	4	
Return Value 3	EKImager	DInt	4	
Return Value 4	EKInterface	DInt	4	
Return Value 5	EKDigitalFPGA	DInt	4	
Return Value 6	EKDigitalQorIQ	DInt	4	
Return Value 7	EKDigitalPowerSupply	DInt	4	
Return Value 8	EKDigitalEdge	DInt	4	
Return Value 9	EKLM95214	DInt	4	
Return Value 10	EKAccSensor	DInt	4	
Return Value 11	EKLiquidLens	DInt	4	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN TemperatureGetValues[ETX]`
Method Return Value:	`[STX]sAN TemperatureGetValues 0 0 0 0 0 0 0 0 0 0 0[ETX]`

© SICK AG - Germany - All rights reserved

2.42.8. Group: ToFSensorMeasurement

2.42.8.1. Variable: ToFDisabledForCompliance

The following section contains a detailed description of the variable ToFDisabledForCompliance.

Variable Overview

Variable Name	Description
ToFDisabledForCompliance	customer can enable or disable ToF functionality

Sopas Synchronisation	Variable is not relevant for synchronisation with SOPAS ET.
Sopas Index	2283
Storage	Variable is stored in ParamEEprom
Read-Access	Always
Write-Access	AuthorizedClient, Service

Bool	
Value Range	False, True
Initialisation	False

Variable Telegram Syntax

Read Variable:

```
sRN ToFDisabledForCompliance
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRN	String	3	Read SOPAS Variable by Name
Command	ToFDisabledForCompliance	String	24	customer can enable or disable ToF functionality

Read Variable Response:

```
sRA ToFDisabledForCompliance <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sRA	String	3	SOPAS Variable Read Acknowledge
Command	ToFDisabledForCompliance	String	24	customer can enable or disable ToF functionality
Variable Data	data	Bool	1	

Write Variable:

```
sWN ToFDisabledForCompliance <data>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWN	String	3	Write SOPAS Variable by Name
Command	ToFDisabledForCompliance	String	24	customer can enable or disable ToF functionality
Variable Data	data	Bool	1	

Write Variable Response:

```
sWA ToFDisabledForCompliance
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sWA	String	3	SOPAS Variable Write Acknowledge
Command	ToFDisabledForCompliance	String	24	customer can enable or disable ToF functionality

© SICK AG - Germany - All rights reserved

Variable Telegram Examples

Example: Default Values	
Variable telegram examples with data set to default values.	
Read Variable:	`[STX]sRN ToFDisabledForCompliance[ETX]`
Read Variable Response:	`[STX]sRA ToFDisabledForCompliance 0[ETX]`
Write Variable:	`[STX]sWN ToFDisabledForCompliance 0[ETX]`
Write Variable Response:	`[STX]sWA ToFDisabledForCompliance[ETX]`

2.42.8.2. Method: ToFSingleshotStart

The following section contains a detailed description of the method ToFSingleshotStart.

Method Overview

Method Name
ToFSingleshotStart

Communication Name	ToFSnglshtStrt
Sopas Index	257
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN ToFSnglshtStrt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ToFSnglshtStrt	String	14	

Method Return Value:				
`sAN ToFSnglshtStrt`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ToFSnglshtStrt	String	14	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ToFSnglshtStrt[ETX]`
Method Return Value:	`[STX]sAN ToFSnglshtStrt[ETX]`

© SICK AG - Germany - All rights reserved

2.42.8.3. Method: ToFContinuousMeasurementStart

The following section contains a detailed description of the method ToFContinuousMeasurementStart.

Method Overview

Method Name
ToFContinuousMeasurementStart

Communication Name	ToFCntnsMsrmntStrt
Sopas Index	258
Invocation Access	Always

Method Telegram Syntax

Method Invocation:

```
sMN ToFCntnsMsrmntStrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ToFCntnsMsrmntStrt	String	18	

Method Return Value:

```
sAN ToFCntnsMsrmntStrt
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ToFCntnsMsrmntStrt	String	18	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN ToFCntnsMsrmntStrt[ETX]`
Method Return Value:	`[STX]sAN ToFCntnsMsrmntStrt[ETX]`

© SICK AG - Germany - All rights reserved

2.42.8.4. Method: ToFStopAllMeasurements

The following section contains a detailed description of the method ToFStopAllMeasurements.

Method Overview

Method Name
ToFStopAllMeasurements

Communication Name	ToFStpMsrmnts
Sopas Index	259
Invocation Access	Always

Method Telegram Syntax

Method Invocation:				
`sMN ToFStpMsrmnts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	ToFStpMsrmnts	String	13	

Method Return Value:				
`sAN ToFStpMsrmnts`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	ToFStpMsrmnts	String	13	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN ToFStpMsrmnts[ETX]`
Method Return Value:	`[STX]sAN ToFStpMsrmnts[ETX]`

© SICK AG - Germany - All rights reserved

2.43. Interface Block: CDF600_Types

2.43.1. Group: _CDF_SystemPublic

2.43.1.1. Method: CDF_ReadParameterSetSegment

The following section contains a detailed description of the method CDF_ReadParameterSetSegment.

Method Overview

Method Name	Description
CDF_ReadParameterSetSegment	reads a number of bytes of the parameter set

Communication Name	mCDF_RdParamSeg
Sopas Index	262
Invocation Access	Service

Parameters	
SegmentStartAddr	
UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0
SegmentLen	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
SegmentData	
FlexString	
Length	0..128
Initialisation	
SegmentStartAddr	
UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
sMN mCDF_RdParamSeg <SegmentStartAddr> <SegmentLen>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mCDF_RdParamSeg	String	15	reads a number of bytes of the parameter set
Parameter 1	SegmentStartAddr	UInt	2	
Parameter 2	SegmentLen	USInt	1	

Method Return Value:				
sAN mCDF_RdParamSeg <SegmentData> <SegmentStartAddr>				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mCDF_RdParamSeg	String	15	reads a number of bytes of the parameter set
Return Value 1	SegmentData	FlexString	128	
Return Value 2	SegmentStartAddr	UInt	2	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	[STX]sMN mCDF_RdParamSeg 0 0[ETX]
Method Return Value:	[STX]sAN mCDF_RdParamSeg 0 0[ETX]

2.43.1.2. Method: CDF_WriteParameterSetSegment

The following section contains a detailed description of the method CDF_WriteParameterSetSegment.

Method Overview

Method Name	Description
CDF_WriteParameterSetSegment	writes a number of bytes of the parameter set

Communication Name	mCDF_WrParamSeg
Sopas Index	263
Invocation Access	Service

Parameters	
SegmentStartAddr	
UInt	
Value Range	0..65535
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

© SICK AG - Germany - All rights reserved

Parameters	
SegmentData	
FlexString	
Length	0..128
Initialisation	

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

Method Telegram Syntax

Method Invocation:

```
sMN mCDF_WrParamSeg <SegmentStartAddr> <SegmentData>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mCDF_WrParamSeg	String	15	writes a number of bytes of the parameter set
Parameter 1	SegmentStartAddr	UInt	2	
Parameter 2	SegmentData	FlexString	128	

Method Return Value:

```
sAN mCDF_WrParamSeg <Success>
```

Telegram Part	Telegram	Type	Length [Byte]	Description
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mCDF_WrParamSeg	String	15	writes a number of bytes of the parameter set
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values

Method telegram examples with parameter data and return value data set to default values.

Method Invocation:	`[STX]sMN mCDF_WrParamSeg 0 0[ETX]`
Method Return Value:	`[STX]sAN mCDF_WrParamSeg 0[ETX]`

© SICK AG - Germany - All rights reserved

2.43.1.3. Method: CDF_FlashParameterFile

The following section contains a detailed description of the method CDF_FlashParameterFile.

Method Overview

Method Name	Description
CDF_FlashParameterFile	Flashes parameterfile which was Written segment by segment before

Communication Name	mCDF_FlashParamFile
Sopas Index	264
Invocation Access	Service

Parameters	
ParamSetDeviceType	
FlexString	
Length	0..20
Initialisation	
ParamSetDevFirmware	
FlexString	
Length	0..20
Initialisation	
FileBCC	
USInt	
Value Range	0..255
Initialisation	
Physical Unit	
Physical Unit Factor	0.0

Return Values	
Success	
Bool	
Value Range	False, True
Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mCDF_FlashParamFile <ParamSetDeviceType> <ParamSetDevFirmware> <FileBCC>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mCDF_FlashParamFile	String	19	Flashes parameterfile which was Written segment by segment before
Parameter 1	ParamSetDeviceType	FlexString	20	
Parameter 2	ParamSetDevFirmware	FlexString	20	
Parameter 3	FileBCC	USInt	1	

Method Return Value:				
`sAN mCDF_FlashParamFile <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mCDF_FlashParamFile	String	19	Flashes parameterfile which was Written segment by segment before
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mCDF_FlashParamFile 0 0 0[ETX]`
Method Return Value:	`[STX]sAN mCDF_FlashParamFile 0[ETX]`

2.43.1.4. Method: CDF_EraseParameterFile

The following section contains a detailed description of the method CDF_EraseParameterFile.

Method Overview

Method Name	Description
CDF_EraseParameterFile	Erases parameterfile

Communication Name	mCDF_EraseParamFile
Sopas Index	265
Invocation Access	Service

Return Values		
Success		
	Bool	
	Value Range	False, True
	Initialisation	False

© SICK AG - Germany - All rights reserved

Method Telegram Syntax

Method Invocation:				
`sMN mCDF_EraseParamFile`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sMN	String	3	Request (SOPAS Method by Name)
Command	mCDF_EraseParamFile	String	19	Erases parameterfile

Method Return Value:				
`sAN mCDF_EraseParamFile <Success>`				
Telegram Part	**Telegram**	**Type**	**Length [Byte]**	**Description**
Command Type	sAN	String	3	Result (SOPAS Method Result)
Command	mCDF_EraseParamFile	String	19	Erases parameterfile
Return Value 1	Success	Bool	1	

Method Telegram Examples

Example: Default Values	
Method telegram examples with parameter data and return value data set to default values.	
Method Invocation:	`[STX]sMN mCDF_EraseParamFile[ETX]`
Method Return Value:	`[STX]sAN mCDF_EraseParamFile 0[ETX]`

© SICK AG - Germany - All rights reserved

3. User Types

3.1. Type: CidVersion

The following section contains a detailed description of the user type CidVersion.

Type
CidVersion

Struct			
MajorVersion			
	UInt		
	Value Range	0..65535	
	Initialisation	4	
MinorVersion			
	UInt		
	Value Range	0..65535	
	Initialisation	14	
PatchVersion			
	UInt		
	Value Range	0..65535	
	Initialisation	0	
BuildNumber			
	UDInt		
	Value Range	0..4294967295	
	Initialisation	21	
VersionClassifier			
	Enum8		
	Default Value	R	
	Value	Name	Description
	0	C	Release Candidate
	1	A	Alpha
	2	B	Beta
	3	R	Release
	4	S	Special

© SICK AG - Germany - All rights reserved

3.2. Type: OCRRegionPrimitive

The following section contains a detailed description of the user type OCRRegionPrimitive.

Type
OCRRegionPrimitive

Struct			
Type			
	Enum8		
	Default Value	RECTANGLE	
	Value	Name	Description
	0	RECTANGLE	
	1	ELLIPSE	
PosX			
	DInt		
	Value Range	-2147483648..2147483647	
	Initialisation	0	
PosY			
	DInt		
	Value Range	-2147483648..2147483647	
	Initialisation	0	
SizeX			
	DInt		
	Value Range	-2147483648..2147483647	
	Initialisation	0	
SizeY			
	DInt		
	Value Range	-2147483648..2147483647	
	Initialisation	0	
Angle			
	DInt		
	Value Range	-2147483648..2147483647	
	Initialisation	0	

© SICK AG - Germany - All rights reserved

3.3. Type: ErrTimeType

The following section contains a detailed description of the user type ErrTimeType.

Type	Description
ErrTimeType	TODO

Struct	
PwrOnCnt	
UInt	
Value Range	0..65535
Initialisation	0
OpSecs	
UDInt	
Value Range	0..4294967295
Initialisation	0
TimeOccur	
UDInt	
Value Range	0..4294967295
Initialisation	0

3.4. Type: ErrStructType

The following section contains a detailed description of the user type ErrStructType.

Type	Description
ErrStructType	TODO

Struct	
ErrorId	
UDInt	
Value Range	0..4294967295
ErrorState	
UDInt	
Value Range	0..4294967295
FirstTime	
UserType	
ErrTimeType	See the chapter "User Types" for details.
LastTime	
UserType	
ErrTimeType	See the chapter "User Types" for details.
NumberOccurance	
UInt	
Value Range	0..65535
Initialisation	0

© SICK AG - Germany - All rights reserved

Struct	
ErrReserved	
UInt	
Value Range	0..65535
Initialisation	0
ExtInfo	
FlexString	
Length	0..50

3.5. Type: SETEM_Binary

The following section contains a detailed description of the user type SETEM_Binary.

Type	Description
SETEM_Binary	Mandatory struct for use in MonitorableEvents.BinaryEvents, containing three BasicTypes: DInt Timestamp, DInt Increment, Bool Value

Struct	
Timestamp	
DInt	
Value Range	0..2147483647
Initialisation	0
Increment	
DInt	
Value Range	0..2147483647
Initialisation	0
Value	
Bool	
Value Range	False, True
Initialisation	False

3.6. Type: SETEM_Analog

The following section contains a detailed description of the user type SETEM_Analog.

Type	Description
SETEM_Analog	Mandatory struct for use in MonitorableEvents.AnalogEvents, containing three BasicTypes: DInt Timestamp, DInt Increment, DIntl Value

Struct	
Timestamp	
DInt	
Value Range	0..2147483647
Initialisation	0

© SICK AG - Germany - All rights reserved

Struct	
Increment	
DInt	
Value Range	0..2147483647
Initialisation	0
Value	
DInt	
Value Range	-10000..10000
Initialisation	0

3.7. Type: SETEM_String

The following section contains a detailed description of the user type SETEM_String.

Type	Description
SETEM_String	Mandatory struct for use in MonitorableEvents.StringEvents, containing three BasicTypes: DInt Timestamp, DInt Increment, String Value

Struct	
Timestamp	
DInt	
Value Range	0..2147483647
Initialisation	0
Increment	
DInt	
Value Range	0..2147483647
Initialisation	0
Value	
FlexString	
Length	0..100
Initialisation	Dummy

3.8. Type: SETEditExtendibleEnum

The following section contains a detailed description of the user type SETEditExtendibleEnum.

Type	Description
SETEditExtendibleEnum	Mandatory struct for use in ETEditStringExtendibleEnum

Struct	
UseExtraValue	
Bool	
Value Range	False, True
Initialisation	False
ExtraValue	
FlexString	
Length	0..18

© SICK AG - Germany - All rights reserved

3.9. Type: SETEditExtendibleEnumSize6

The following section contains a detailed description of the user type SETEditExtendibleEnumSize6.

Type	Description
SETEditExtendibleEnumSize6	Mandatory struct for use in ETEditStringExtendibleEnum

Struct		
UseExtraValue		
	Bool	
	Value Range	False, True
	Initialisation	False
ExtraValue		
	FlexString	
	Length	0..6

3.10. Type: eUsePredConnSetType

The following section contains a detailed description of the user type eUsePredConnSetType.

Type
eUsePredConnSetType

Struct			
eUsePredConnSet		Defines use of predefined Connection set of CANopen. (use of bool is not possible within grids)	
	Enum8		
	Default Value	USE_PredConnSet	
	Value	Name	Description
	0	NoUSE_PredConnSet	
	1	USE_PredConnSet	

3.11. Type: ProfinetFixed

The following section contains a detailed description of the user type ProfinetFixed.

Type	Description
ProfinetFixed	Software revision of Profinet-Stack.

© SICK AG - Germany - All rights reserved

Struct		
swRevision		Software revision, format is {prefix}{function}.{bugfix}.{change}, e.g. V0.1.2
	Struct	
	prefix	Version number prefix, 'V', 'R', 'P', 'U', 'T'...
		String
		Length: 1
		Initialisation: V
	function	
		USInt
		Value Range: 0..255
		Initialisation: 2
	bugfix	
		USInt
		Value Range: 0..255
		Initialisation: 0
	change	
		USInt
		Value Range: 0..255
		Initialisation: 0

3.12. Type: Asci127_t

The following section contains a detailed description of the user type Asci127_t.

Type
Asci127_t

© SICK AG - Germany - All rights reserved

Struct	
eAscii127	
Enum8	

© SICK AG - Germany - All rights reserved

Struct			
Default Value		0	
	Value	Name	Description
	0	TX_NUL_00	
	1	TX_SOH_01	
	2	TX_STX_02	
	3	TX_ETX_03	
	4	TX_EOT_04	
	5	TX_ENQ_05	
	6	TX_ACK_06	
	7	TX_BEL_07	
	8	TX_BS_08	
	9	TX_TAB_09	
	10	TX_LF_0A	
	11	TX_VT_0B	
	12	TX_FF_0C	
	13	TX_CR_0D	
	14	TX_SO_0E	
	15	TX_SI_0F	
	16	TX_DLE_10	
	17	TX_DC1_11	
	18	TX_DC2_12	
	19	TX_DC3_13	
	20	TX_DC4_14	
	21	TX_NAK_15	
	22	TX_SYN_16	
	23	TX_ETB_17	
	24	TX_CAN_18	
	25	TX_EM_19	
	26	TX_SUB_1A	
	27	TX_ESC_1B	
	28	TX_FS_1C	
	29	TX_GS_1D	
	30	TX_RS_1E	
	31	TX_US_1F	
	32	TX_SPACE_20	
	33	TX_EXCLAMATION_21	
	34	TX_DOUBLE_QUOTE_22	
	35	TX_HASH_23	
	36	TX_DOLLAR_24	
	37	TX_PERCENT_25	
	38	TX_AMP_26	
	39	TX_SIGNLE_QUOT_27	
	40	TX_OPEN_BRACKET_28	
	41	TX_CLOSE_BRACKET_29	
	42	TX_ASTERISK_2A	
	43	TX_PLUS_2B	
	44	TX_KOMMA_2C	
	45	TX_MINUS_2D	
	46	TX_DOT_2E	
	47	TX_SLASH_2F	
	48	TX_0_30	
	49	TX_1_31	
	50	TX_2_32	
	51	TX_3_33	

© SICK AG - Germany - All rights reserved

Struct				
		52	TX_4_34	
		53	TX_5_35	
		54	TX_6_36	
		55	TX_7_37	
		56	TX_8_38	
		57	TX_9_39	
		58	TX_COLON_3A	
		59	TX_SEMICOLON_3B	
		60	TX_LT_3C	
		61	TX_EQUAL_3D	
		62	TX_GT_3E	
		63	TX_INTERROGATION_3F	
		64	TX_AT_40	
		65	TX_A_41	
		66	TX_B_42	
		67	TX_C_43	
		68	TX_D_44	
		69	TX_E_45	
		70	TX_F_46	
		71	TX_G_47	
		72	TX_H_48	
		73	TX_I_49	
		74	TX_J_4A	
		75	TX_K_4B	
		76	TX_L_4C	
		77	TX_M_4D	
		78	TX_N_4E	
		79	TX_O_4F	
		80	TX_P_50	
		81	TX_Q_51	
		82	TX_R_52	
		83	TX_S_53	
		84	TX_T_54	
		85	TX_U_55	
		86	TX_V_56	
		87	TX_W_57	
		88	TX_X_58	
		89	TX_Y_59	
		90	TX_Z_5A	
		91	TX_OPEN_SQUARED_BRACKET_5B	
		92	TX_BACK_SLASH_5C	
		93	TX_CLOSE_SQUARED_BRACKET_5D	
		94	TX_ACCENT_CIRC_5E	
		95	TX_UNDERSCORE_5F	
		96	TX_ACCENT_LEFT_60	
		97	TX_a_61	
		98	TX_b_62	
		99	TX_c_63	
		100	TX_d_64	
		101	TX_e_65	
		102	TX_f_66	
		103	TX_g_67	
		104	TX_h_68	
		105	TX_i_69	

© SICK AG - Germany - All rights reserved

Struct				
		106	TX_j_6A	
		107	TX_k_6B	
		108	TX_l_6C	
		109	TX_m_6D	
		110	TX_n_6E	
		111	TX_o_6F	
		112	TX_p_70	
		113	TX_q_71	
		114	TX_r_72	
		115	TX_s_73	
		116	TX_t_74	
		117	TX_u_75	
		118	TX_v_76	
		119	TX_w_77	
		120	TX_x_78	
		121	TX_y_79	
		122	TX_z_7A	
		123	TX_OPEN_CURLY_BRACKET_7B	
		124	TX_BAR_7C	
		125	TX_CLOSE_CURLY_BRACKET_7D	
		126	TX_TILDE_7E	

3.13. Type: Asci127AndObject_t

The following section contains a detailed description of the user type Asci127AndObject_t.

Type
Asci127AndObject_t

© SICK AG - Germany - All rights reserved

Struct	
eAscii127	
Enum8	

© SICK AG - Germany - All rights reserved

Struct			
Default Value	0		
	Value	Name	Description
	0	TX_NUL_00	
	1	TX_SOH_01	
	2	TX_STX_02	
	3	TX_ETX_03	
	4	TX_EOT_04	
	5	TX_ENQ_05	
	6	TX_ACK_06	
	7	TX_BEL_07	
	8	TX_BS_08	
	9	TX_TAB_09	
	10	TX_LF_0A	
	11	TX_VT_0B	
	12	TX_FF_0C	
	13	TX_CR_0D	
	14	TX_SO_0E	
	15	TX_SI_0F	
	16	TX_DLE_10	
	17	TX_DC1_11	
	18	TX_DC2_12	
	19	TX_DC3_13	
	20	TX_DC4_14	
	21	TX_NAK_15	
	22	TX_SYN_16	
	23	TX_ETB_17	
	24	TX_CAN_18	
	25	TX_EM_19	
	26	TX_SUB_1A	
	27	TX_ESC_1B	
	28	TX_FS_1C	
	29	TX_GS_1D	
	30	TX_RS_1E	
	31	TX_US_1F	
	32	TX_SPACE_20	
	33	TX_EXCLAMATION_21	
	34	TX_DOUBLE_QUOTE_22	
	35	TX_HASH_23	
	36	TX_DOLLAR_24	
	37	TX_PERCENT_25	
	38	TX_AMP_26	
	39	TX_SIGNLE_QUOT_27	
	40	TX_OPEN_BRACKET_28	
	41	TX_CLOSE_BRACKET_29	
	42	TX_ASTERISK_2A	
	43	TX_PLUS_2B	
	44	TX_KOMMA_2C	
	45	TX_MINUS_2D	
	46	TX_DOT_2E	
	47	TX_SLASH_2F	
	48	TX_0_30	
	49	TX_1_31	
	50	TX_2_32	
	51	TX_3_33	

© SICK AG - Germany - All rights reserved

Struct				
		52	TX_4_34	
		53	TX_5_35	
		54	TX_6_36	
		55	TX_7_37	
		56	TX_8_38	
		57	TX_9_39	
		58	TX_COLON_3A	
		59	TX_SEMICOLON_3B	
		60	TX_LT_3C	
		61	TX_EQUAL_3D	
		62	TX_GT_3E	
		63	TX_INTERROGATION_3F	
		64	TX_AT_40	
		65	TX_A_41	
		66	TX_B_42	
		67	TX_C_43	
		68	TX_D_44	
		69	TX_E_45	
		70	TX_F_46	
		71	TX_G_47	
		72	TX_H_48	
		73	TX_I_49	
		74	TX_J_4A	
		75	TX_K_4B	
		76	TX_L_4C	
		77	TX_M_4D	
		78	TX_N_4E	
		79	TX_O_4F	
		80	TX_P_50	
		81	TX_Q_51	
		82	TX_R_52	
		83	TX_S_53	
		84	TX_T_54	
		85	TX_U_55	
		86	TX_V_56	
		87	TX_W_57	
		88	TX_X_58	
		89	TX_Y_59	
		90	TX_Z_5A	
		91	TX_OPEN_SQUARED_BRACKET_5B	
		92	TX_BACK_SLASH_5C	
		93	TX_CLOSE_SQUARED_BRACKET_5D	
		94	TX_ACCENT_CIRC_5E	
		95	TX_UNDERSCORE_5F	
		96	TX_ACCENT_LEFT_60	
		97	TX_a_61	
		98	TX_b_62	
		99	TX_c_63	
		100	TX_d_64	
		101	TX_e_65	
		102	TX_f_66	
		103	TX_g_67	
		104	TX_h_68	
		105	TX_i_69	

© SICK AG - Germany - All rights reserved

Struct				
		106	TX_j_6A	
		107	TX_k_6B	
		108	TX_l_6C	
		109	TX_m_6D	
		110	TX_n_6E	
		111	TX_o_6F	
		112	TX_p_70	
		113	TX_q_71	
		114	TX_r_72	
		115	TX_s_73	
		116	TX_t_74	
		117	TX_u_75	
		118	TX_v_76	
		119	TX_w_77	
		120	TX_x_78	
		121	TX_y_79	
		122	TX_z_7A	
		123	TX_OPEN_CURLY_BRACKET_7B	
		124	TX_BAR_7C	
		125	TX_CLOSE_CURLY_BRACKET_7D	
		126	TX_TILDE_7E	
		127	TX_OBJ_TT	
		128	TX_OBJ_CC	
		129	TX_OBJ_VCC	
		130	TX_OBJ_DID	
		131	TX_OBJ_COUNTER_TRIGER	
		132	TX_OBJ_COUNTER_MATCH	
		133	TX_OBJ_COUNTER_GoodRead	
		134	TX_OBJ_BETA	
		135	TX_OBJ_GAMM	

3.14. Type: Asci127AndCode_t

The following section contains a detailed description of the user type Asci127AndCode_t.

Type
Asci127AndCode_t

© SICK AG - Germany - All rights reserved

Struct	
eAscii127	
Enum8	

© SICK AG - Germany - All rights reserved

Struct			
Default Value		0	
	Value	Name	Description
	0	TX_NUL_00	
	1	TX_SOH_01	
	2	TX_STX_02	
	3	TX_ETX_03	
	4	TX_EOT_04	
	5	TX_ENQ_05	
	6	TX_ACK_06	
	7	TX_BEL_07	
	8	TX_BS_08	
	9	TX_TAB_09	
	10	TX_LF_0A	
	11	TX_VT_0B	
	12	TX_FF_0C	
	13	TX_CR_0D	
	14	TX_SO_0E	
	15	TX_SI_0F	
	16	TX_DLE_10	
	17	TX_DC1_11	
	18	TX_DC2_12	
	19	TX_DC3_13	
	20	TX_DC4_14	
	21	TX_NAK_15	
	22	TX_SYN_16	
	23	TX_ETB_17	
	24	TX_CAN_18	
	25	TX_EM_19	
	26	TX_SUB_1A	
	27	TX_ESC_1B	
	28	TX_FS_1C	
	29	TX_GS_1D	
	30	TX_RS_1E	
	31	TX_US_1F	
	32	TX_SPACE_20	
	33	TX_EXCLAMATION_21	
	34	TX_DOUBLE_QUOTE_22	
	35	TX_HASH_23	
	36	TX_DOLLAR_24	
	37	TX_PERCENT_25	
	38	TX_AMP_26	
	39	TX_SIGNLE_QUOT_27	
	40	TX_OPEN_BRACKET_28	
	41	TX_CLOSE_BRACKET_29	
	42	TX_ASTERISK_2A	
	43	TX_PLUS_2B	
	44	TX_KOMMA_2C	
	45	TX_MINUS_2D	
	46	TX_DOT_2E	
	47	TX_SLASH_2F	
	48	TX_0_30	
	49	TX_1_31	
	50	TX_2_32	
	51	TX_3_33	

© SICK AG - Germany - All rights reserved

Struct				
		52	TX_4_34	
		53	TX_5_35	
		54	TX_6_36	
		55	TX_7_37	
		56	TX_8_38	
		57	TX_9_39	
		58	TX_COLON_3A	
		59	TX_SEMICOLON_3B	
		60	TX_LT_3C	
		61	TX_EQUAL_3D	
		62	TX_GT_3E	
		63	TX_INTERROGATION_3F	
		64	TX_AT_40	
		65	TX_A_41	
		66	TX_B_42	
		67	TX_C_43	
		68	TX_D_44	
		69	TX_E_45	
		70	TX_F_46	
		71	TX_G_47	
		72	TX_H_48	
		73	TX_I_49	
		74	TX_J_4A	
		75	TX_K_4B	
		76	TX_L_4C	
		77	TX_M_4D	
		78	TX_N_4E	
		79	TX_O_4F	
		80	TX_P_50	
		81	TX_Q_51	
		82	TX_R_52	
		83	TX_S_53	
		84	TX_T_54	
		85	TX_U_55	
		86	TX_V_56	
		87	TX_W_57	
		88	TX_X_58	
		89	TX_Y_59	
		90	TX_Z_5A	
		91	TX_OPEN_SQUARED_BRACKET_5B	
		92	TX_BACK_SLASH_5C	
		93	TX_CLOSE_SQUARED_BRACKET_5D	
		94	TX_ACCENT_CIRC_5E	
		95	TX_UNDERSCORE_5F	
		96	TX_ACCENT_LEFT_60	
		97	TX_a_61	
		98	TX_b_62	
		99	TX_c_63	
		100	TX_d_64	
		101	TX_e_65	
		102	TX_f_66	
		103	TX_g_67	
		104	TX_h_68	
		105	TX_i_69	

© SICK AG - Germany - All rights reserved

Struct				
		106	TX_j_6A	
		107	TX_k_6B	
		108	TX_l_6C	
		109	TX_m_6D	
		110	TX_n_6E	
		111	TX_o_6F	
		112	TX_p_70	
		113	TX_q_71	
		114	TX_r_72	
		115	TX_s_73	
		116	TX_t_74	
		117	TX_u_75	
		118	TX_v_76	
		119	TX_w_77	
		120	TX_x_78	
		121	TX_y_79	
		122	TX_z_7A	
		123	TX_OPEN_CURLY_BRACKET_7B	
		124	TX_BAR_7C	
		125	TX_CLOSE_CURLY_BRACKET_7D	
		126	TX_TILDE_7E	
		127	TX_CODE_BC	
		128	TX_CODE_CL	
		129	TX_CODE_ID	
		130	TX_CODE_RSD1DV	
		131	TX_CODE_CTG1	
		132	TX_CODE_AN2	
		133	TX_CODE_CS	
		134	TX_CODE_YPOS	
		135	TX_CODE_XPOS	
		136	TX_CODE_CPX	
		137	TX_CODE_CPY	
		138	TX_CODE_CTG	

3.15. Type: Temperature

The following section contains a detailed description of the user type Temperature.

Type
Temperature

Struct		
Temperature		
	DInt	
	Value Range	-2147483648..2147483647
	Initialisation	0
	Physical Unit	°C

© SICK AG - Germany - All rights reserved

Struct	
OpHours	
UDInt	
Value Range	0..4294967295
Initialisation	0
Physical Unit	h
DailyOpHours	
Real	
Value Range	See specification IEEE 754
Initialisation	0.0
Physical Unit	h

3.16. Type: TempSensArray_t

The following section contains a detailed description of the user type TempSensArray_t.

Type
TempSensArray_t

3.17. Type: DPSSet

The following section contains a detailed description of the user type DPSSet.

Type	Description
DPSSet	One parameter-switching parameter set; initial feature set

Struct	
ShutterTime	
UInt	
Value Range	60..5000
Initialisation	200
Physical Unit	µs
Brightness	
UInt	
Value Range	0..100
Initialisation	50
Contrast	
UInt	
Value Range	0..100
Initialisation	10
Physical Unit	%
MorphologicalFilter	
DInt	
Value Range	-4..4
Initialisation	0

© SICK AG - Germany - All rights reserved

Struct			
InternalIlluminationMode			
	Enum8		
	Default Value	On	
	Value	Name	Description
	0	Off	
	1	On	
ExternalIlluminationMode			
	Enum8		
	Default Value	TX_EXTERNAL_ILLUMINATION_OFF	
	Value	Name	Description
	0	TX_EXTERNAL_ILLUMINATION_OFF	
	1	TX_EXTERNAL_ILLUMINATION_ICL110	
	2	TX_EXTERNAL_ILLUMINATION_ICL170	
	3	TX_EXTERNAL_ILLUMINATION_ICL260	
	4	TX_EXTERNAL_ILLUMINATION_ICL280	
	5	TX_EXTERNAL_ILLUMINATION_ICL280_F202S01	
	6	TX_EXTERNAL_ILLUMINATION_ICL300	
	7	TX_EXTERNAL_ILLUMINATION_ICL300_F202S01	
	8	TX_EXTERNAL_ILLUMINATION_ACTIVE_LOW_CONTINUOUS	
	9	TX_EXTERNAL_ILLUMINATION_ACTIVE_LOW_FLASHING	
	10	TX_EXTERNAL_ILLUMINATION_ACTIVE_HIGH_CONTINUOUS	
	11	TX_EXTERNAL_ILLUMINATION_ACTIVE_HIGH_FLASHING	

3.18. Type: DPSColorType

The following section contains a detailed description of the user type DPSColorType.

Type
DPSColorType

© SICK AG - Germany - All rights reserved

3.19. Type: DPSIllu61xLedStates

The following section contains a detailed description of the user type DPSIllu61xLedStates.

Type	Description
DPSIllu61xLedStates	One parameter-switching parameter set; 611 LED states

Struct	
A1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True
B1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True
C1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True
D1_ENABLED	
Bool	
Value Range	False, True
Initialisation	True

3.20. Type: E_USER_LEVEL_TYPE

The following section contains a detailed description of the user type E_USER_LEVEL_TYPE.

Type
E_USER_LEVEL_TYPE

© SICK AG - Germany - All rights reserved

4. Error Codes

4.1. Error Level

This section shows the defined error levels:

Name	Value	Description
DYNAMIC	0	
DEBUG	1	
INFO	2	
WARNING	3	User have to do any action to switch off this warning, maybe because of wrong paramtrization
ERROR	4	
FATALERROR	5	
RESERVED1	6	
RESERVED2	7	

4.2. LECTOR65x

4.2.1. FOCUS

This section shows the defined error codes of the " FOCUS" sub system.
The defined value of the sub system is: 1

Name	Level	Value	Description
FOCUS_REFERENCE_NEEDED_BOOTUP	WARNING	0x03000100	Focus reference was needed on bootup
FOCUS_MOTOR_STALL	ERROR	0x04000101	Focus motor stall
FOCUS_INFORMATION	INFO	0x02000102	Focus information
FOCUS_REFERENCE_FAILED	WARNING	0x03000103	Focus reference failed
FOCUS_CTRL_LOCKED	ERROR	0x04000104	Focus Ctrl locked
FOCUS_CTRL_BLOCKED	ERROR	0x04000105	Focus is blocked

4.2.2. IMG_SENSOR_ACQ_DRIVER

This section shows the defined error codes of the " IMG_SENSOR_ACQ_DRIVER" sub system.
The defined value of the sub system is: 11

Name	Level	Value	Description
IMG_ACQ_DRIVER_START_FAILED	WARNING	0x03000b00	Start of image sensor acq driver failed
IMG_ACQ_DRIVER_IMG_ENQEUEING_FAILED	WARNING	0x03000b01	Enqeueing of new image to driver img queue failed
IMG_ACQ_DRIVER_FRAME_ALLOC_FAILED	WARNING	0x03000b02	Frame allocation in transfer driver failed

© SICK AG - Germany - All rights reserved

4.2.3. OUTPUTS

This section shows the defined error codes of the " OUTPUTS" sub system.
The defined value of the sub system is: 20

Name	Level	Value	Description
OUTPUT1_ERROR_PWRSPL_LOW	WARNING	0x03001400	Power supply too low on result 1/2
OUTPUT2_ERROR_PWRSPL_LOW	WARNING	0x03001401	Power supply too low on result 3/4
OUTPUT1_INFO_WAKEUPREQ	INFO	0x02001402	Wake Up request for result 1/2
OUTPUT2_INFO_WAKEUPREQ	INFO	0x02001403	Wake Up request for result 3/4
OUTPUT1_ERROR_OVERTEMP_FAULT	WARNING	0x03001404	Over temperature fault on result 1/2
OUTPUT2_ERROR_OVERTEMP_FAULT	WARNING	0x03001405	Over temperature fault on result 3/4
OUTPUT1_ERROR_CQ_OVERLOAD	WARNING	0x03001406	Result 1 overload
OUTPUT2_ERROR_CQ_OVERLOAD	WARNING	0x03001407	Result 3 overload
OUTPUT1_ERROR_IQ_OVERLOAD	WARNING	0x03001408	Result 2 overload
OUTPUT2_ERROR_IQ_OVERLOAD	WARNING	0x03001409	Result 4 overload
OUTPUT1_ERROR_SWITCH_REG_UNDERVOLT_FAULT	WARNING	0x0300140a	Switching Regulator Under-Voltage Fault on result 1/2
OUTPUT2_ERROR_SWITCH_REG_UNDERVOLT_FAULT	WARNING	0x0300140b	Switching Regulator Under-Voltage Fault on result 3/4
OUTPUT1_ERROR_LINEAR_REG_UNDERVOLT_FAULT	WARNING	0x0300140c	Linear Regulator Under-Voltage Fault on output 1/2
OUTPUT2_ERROR_LINEAR_REG_UNDERVOLT_FAULT	WARNING	0x0300140d	Linear Regulator Under-Voltage Fault on output 3/4
OUTPUT1_ERROR_PARITY_CHECK	WARNING	0x0300140e	Parity Check Error on result 1/2
OUTPUT2_ERROR_PARITY_CHECK	WARNING	0x0300140f	Parity Check Error on result 3/4
OUTPUT1_ERROR_PWROUT_LOW	WARNING	0x03001410	Power output too low on result 1/2
OUTPUT2_ERROR_PWROUT_LOW	WARNING	0x03001411	Power output too low on result 3/4
OUTPUT_LOW_ACTIVE_FORBIDDEN	ERROR	0x04001412	Digital Output can not be driven in low side mode.

4.2.4. MAIN

This section shows the defined error codes of the " MAIN" sub system.
The defined value of the sub system is: 50

Name	Level	Value	Description
INCONSISTENT_FIRMWARE	ERROR	0x04003200	Inconsistent firmware
IOCONTROLLER_RESET	ERROR	0x04003201	Triggered IOController Watchdog
REMOTE_CALIB_RESTORE_FAILED	ERROR	0x04003202	Remote calib data restore failed
REMOTE_CALIB_RESTORE_RETRY	WARNING	0x03003203	Remote calib data restore success on retry
REMOTE_CALIB_RESTORE_EK_LED_IMPLAUSIBLE	WARNING	0x03003204	Remote calib data from EK LED have implausible values.
REMOTE_CALIB_RESTORE_EK_ANALOG_IMPLAUSIBLE	WARNING	0x03003205	Remote calib data from EK Analog have implausible values.
FIRMWARE_DOWNGRADE_INCOMPATIBLE_VERSION	ERROR	0x04003206	Downgrade to v2.x needs special spk.
IOCONTROLLER_COMM_TIMEOUT	INFO	0x02003207	IOController communication timeout
IOCONTROLLER_BOOT_TIMEOUT	ERROR	0x04003208	IOController boot problem

© SICK AG - Germany - All rights reserved

4.2.5. IMAGEOUTPUT

This section shows the defined error codes of the " IMAGEOUTPUT" sub system.
The defined value of the sub system is: 60

Name	Level	Value	Description
IMAGEOUTPUT_LOST_IMAGES	WARNING	0x03003c00	Diagnosis images lost for output.

4.2.6. TEMPERATURE_OBSERVER

This section shows the defined error codes of the " TEMPERATURE_OBSERVER" sub system.
The defined value of the sub system is: 70

Name	Level	Value	Description
TEMPERATURE_SENSOR_EK_LED_OUT_OF_RANGE	WARNING	0x03004603	Value of EK LED temperature sensor is out of range.
TEMPERATURE_SENSOR_EK_IF_OUT_OF_RANGE	WARNING	0x03004604	Value of EK Interface temperature sensor is out of range.
TEMPERATURE_SENSOR_EK_ANALOG_OUT_OF_RANGE	WARNING	0x03004605	Value of EK analog temperature sensor is out of range.
TEMPERATURE_SENSOR_EK_LED_NOT_PLAUSIBLE	WARNING	0x03004606	Value of EK LED temperature sensor is not plausible.
TEMPERATURE_SENSOR_EK_IF_NOT_PLAUSIBLE	WARNING	0x03004607	Value of EK Interface temperature sensor is not plausible.
TEMPERATURE_SENSOR_EK_ANALOG_NOT_PLAUSIBLE	WARNING	0x03004608	Value of EK analog temperature sensor is not plausible.

4.2.7. MLG

This section shows the defined error codes of the " MLG" sub system.
The defined value of the sub system is: 90

Name	Level	Value	Description
MLG_DETECTED	INFO	0x02005a00	MLG detected
MLG_NO_DATA	WARNING	0x03005a01	MLG received no data for some time
MLG_INVALID_PROCESS_DATA	WARNING	0x03005a02	MLG invalid process data
MLG_PARAMETRIZATION_MODE	INFO	0x02005a03	MLG parametrization mode
MLG_TEACHIN_ACTIVE	INFO	0x02005a04	MLG teach-in active
MLG_TEACHIN_SUCCESSFUL	INFO	0x02005a05	MLG teach-in successful
MLG_TEACHIN_NOT_SUCCESSFUL	WARNING	0x03005a06	MLG teach-in not successful
MLG_POLLUTION_DETECTED	WARNING	0x03005a07	MLG pollution detected
MLG_HARDWARE_ERROR	WARNING	0x03005a08	MLG hardware error
MLG_LOW_RECEIVED_SIGNAL_LEVEL	WARNING	0x03005a09	MLG low received signal level
MLG_LOW_SIGNAL_FOR_TEACHIN	WARNING	0x03005a0a	MLG received signal level too low for teach-in
MLG_SYNC_ERROR	WARNING	0x03005a0b	MLG synchronisation error
MLG_FOCUSQUEUE_OVERRUN	INFO	0x02005a0c	MLG focus queue overrun

© SICK AG - Germany - All rights reserved

4.3. LECTOR6xx

4.3.1. EXTERNAL_DEVICES

This section shows the defined error codes of the " EXTERNAL_DEVICES" sub system.
The defined value of the sub system is: 7

Name	Level	Value	Description
CMF400_PROFIBUS_DETECTED	INFO	0x02000701	CMF400-Profibus detected
CMF400_PROFI_MISSING	WARNING	0x03000702	Missing CMF400-Profibus device
CMF400_PROFI_ERR_RETURN	WARNING	0x03000703	Warning was returned by CMF400-Profibus
CMF400_PROFI_WRONG_DEVICE_TYPE	WARNING	0x03000704	CMF400 is not Profibus type
CMF400_DEVICENET_DETECTED	INFO	0x02000705	CMF400-DeviceNet detected
CMF400_DEVICENET_MISSING	WARNING	0x03000706	Missing CMF400-DeviceNet device
CMF400_DEVICENET_ERR_RETURN	WARNING	0x03000707	Warning was returned by CMF400-DeviceNet
CMF400_DEVICENET_WRONG_DEVICE_TYPE	WARNING	0x03000708	CMF400 is not DeviceNet type
RESET_CAUSE_DIFFERENT_EXT_PARAMETERS	INFO	0x02000709	Reset cause different external parameters
CDM425_PROFINET_DETECTED	INFO	0x0200070a	CDM425-ProfiNet detected
CDM425_PROFINET_MISSING	WARNING	0x0300070b	Missing CDM425-ProfiNet device
CDM425_PROFINET_ERR_RETURN	WARNING	0x0300070c	Warning was returned by CDM425-ProfiNet
CDM425_PROFINET_WRONG_DEVICE_TYPE	WARNING	0x0300070d	CDM425-ProfiNet is not DeviceNet type
CMC600_DETECTED	INFO	0x0200070e	CMC600 detected
CMC600_WRITE_INHIBIT	WARNING	0x0300070f	CMC600 writeprotection
CMC600_WARNING	WARNING	0x03000710	CMC600 warning
CMC600_ERROR	ERROR	0x04000711	CMC600 error
CDF600_DETECTED	INFO	0x02000715	CDF600 detected
CDF600_WRITE_INHIBIT	WARNING	0x03000716	CDF600 writeprotection
CDF600_WARNING	WARNING	0x03000717	CDF600 warning
CDF600_CONNECTED	INFO	0x02000718	CDF600 connected
CDF600_CONNECTION_LOST	INFO	0x02000719	CDF600 connection lost

4.3.2. IMG_ACQ_CTRL

This section shows the defined error codes of the " IMG_ACQ_CTRL" sub system.
The defined value of the sub system is: 8

Name	Level	Value	Description
IMG_ACQ_DRIVER_FAILED_TO_DELIVER_IMG	ERROR	0x04000800	Img Acq Driver failed to deliver image
IMG_GEOM_PARAM_FAILED_IMG_LOG_RUNNING	WARNING	0x03000801	Img Geometry could not be modified because img output logging process is not finished yet
IMG_ACQ_ALREADY_RUNNING	WARNING	0x03000802	Img Acq Is Already Running On New Trigger
IMG_ACQ_DRIVER_IMG_QUEUE_INIT_FILL_FAILED	WARNING	0x03000803	Img Acq Driver Img Queue Initial Filling failed
IMG_LOGGING_LAST_IMG_LOG_TIMEOUT	WARNING	0x03000804	Img Output Logging: Last img log timeout occurred
NEW_DRIVER_SET	INFO	0x02000805	New Img Acq Driver set on the fly
IMG_ACQ_STALE_IMG_IN_IMG_QUEUE	INFO	0x02000806	Stale image in image queue

© SICK AG - Germany - All rights reserved

Name	Level	Value	Description
IMG_ACQ_DELAYED_FOR_EYE_SAFETY	INFO	0x02000808	Trigger-On delayed to guarantee eye safety
IMG_ACQ_DENIED_FOR_EYE_SAFETY	INFO	0x02000809	Trigger-On rejected to guarantee eye safety
IMG_ACQ_SKIPPED_DUE_TO_SHORT_READING_GATE	INFO	0x0200080a	Image acquisition skipped. Reading gate too short.
IMG_ACQ_SWITCHED_ILLUMINATION_OFF_DUE_TO_TIMEOUT	INFO	0x0200080b	Illumination switched off by Illumination timeout

4.3.3. DEVICE_MODE

This section shows the defined error codes of the " DEVICE_MODE" sub system.

The defined value of the sub system is: 9

Name	Level	Value	Description
START_MATCHCODE_TEACH_FAILED	WARNING	0x03000900	Start of Match Code Teach In failed
START_AUTOSETUP_FAILED	WARNING	0x03000904	Start of Autosetup failed
START_PERCENT_EVAL_FAILED	WARNING	0x03000905	Start of Percent Evaluation failed
START_LIVE_IMAGE_FAILED	WARNING	0x03000906	Start of Live Image failed
SYSTEM_PARAM_FOR_LIVEIMG_FAILED	WARNING	0x03000907	System parameterization for live img process failed
SYSTEM_PARAM_AFTER_LIVEIMG_FAILED	WARNING	0x03000908	System parameterization after live img process failed
SYSTEM_PARAM_FOR_PERCEVAL_FAILED	WARNING	0x03000909	System parameterization for percentage evaluation process failed
SYSTEM_PARAM_AFTER_PERCEVAL_FAILED	WARNING	0x0300090a	System parameterization after percentage evaluation process failed
TERMINATE_LIVE_IMG_FOR_AUTOSETUP	INFO	0x0200090b	Live Image gets terminated for autosetup process start
SYSTEM_PARAM_FOR_AUTOSETUP_FAILED	WARNING	0x0300090c	System parameterization for autosetup process failed
SYSTEM_PARAM_AFTER_AUTOSETUP_FAILED	WARNING	0x0300090d	System parameterization after autosetup process failed
START_PRESENTATION_MODE_FAILED	WARNING	0x0300090e	Start of Presentation Mode failed
START_DIAGREAD_MODE_FAILED	WARNING	0x0300090f	Start of Diag Read failed
START_ADJUST_MODE_FAILED	WARNING	0x03000910	Start of Brightness Adjust failed
START_DPS_MODE_FAILED	WARNING	0x03000911	Start of DPS failed
START_VERIFIER_REPORT_FAILED	WARNING	0x03000912	Start of Verification Report failed
SYSTEM_PARAM_FOR_VERIFIER_REPORT_FAILED	WARNING	0x03000913	System parameterization for verification report process failed
SYSTEM_PARAM_AFTER_VERIFIER_REPORT_FAILED	WARNING	0x03000914	System parameterization after verification report process failed
START_FREERUNNING_FAILED	WARNING	0x03000915	Start of free running mode failed
START_VERIFICATION_WIZARD_FAILED	WARNING	0x03000916	Start of verification wizard failed
START_AIM_DPM_FAILED	WARNING	0x03000917	Start of aim dpm failed
START_MOVEDECT_FAILED	WARNING	0x03000918	Start of movement detection

© SICK AG - Germany - All rights reserved

4.3.4. AUTO_SETUP

This section shows the defined error codes of the " AUTO_SETUP" sub system.
The defined value of the sub system is: 10

Name	Level	Value	Description
AUTOSETUP_PARAMS_CORRECTED	WARNING	0x03000a02	Internal parameters are changed to avoid conflicts if some params are not valid

4.3.5. BLOB_SERVER

This section shows the defined error codes of the " BLOB_SERVER" sub system.
The defined value of the sub system is: 12

Name	Level	Value	Description
BLOB_SERVER_NOT_CONNECTED	ERROR	0x04000c00	Client connection not established or lost
BLOB_SERVER_DATANOTSENT	ERROR	0x04000c01	Data not (completely) sent to the blob client
BLOB_SERVER_INACTIVE_BY_NOTIMERTICK	ERROR	0x04000c02	Blob server has become inactive because of missing external request
BLOB_SERVER_INTERNAL_COMMUNICATION_FAILED	ERROR	0x04000c03	Internal communication fails
BLOB_SERVER_UNKNOWN_ERROR	ERROR	0x04000c04	General error, that is not known yet (for later purposes)

4.3.6. IMAGE_LOGGING_UPLOAD

This section shows the defined error codes of the " IMAGE_LOGGING_UPLOAD" sub system.
The defined value of the sub system is: 13

Name	Level	Value	Description
LOGGING_BLOBSRV_SEND_FAILED	WARNING	0x03000d00	A timeout occurred during waiting for blob server reply
UPLOAD_BLOBSRV_SEND_FAILED	WARNING	0x03000d01	A timeout occurred during waiting for blob server reply
LOGGING_OUTOFMEM_SDCARD	WARNING	0x03000d02	Image logging: no free space on sd card
LOGGING_OUTOFMEM_NAND	WARNING	0x03000d03	Image logging: no free space on internal permanent memory
LOGGING_OUTOFMEM_RAMDISK	WARNING	0x03000d04	Image logging: no free space on internal temporary memory
LOGGING_FTP_SEND_FAILED	WARNING	0x03000d05	An image could not be sent via FTP
LOGGING_SVP_IMG_SEND_FAILED	WARNING	0x03000d06	An image could not be sent to svp
LOGGING_FTP_UPLOAD_KEY_SUCCESSFULL	INFO	0x02000d07	Private key uploaded successful
LOGGING_FTP_KEY_NOT_FOUND	WARNING	0x03000d08	Private key not found
LOGGING_FTP_KEY_INVALID	WARNING	0x03000d09	Private key invalid
LOGGING_FTP_PARAMETER_INVALID	WARNING	0x03000d0a	Image loggging FTP parameter invalid

© SICK AG - Germany - All rights reserved

4.3.7. OS

This section shows the defined error codes of the " OS" sub system.
The defined value of the sub system is: 21

Name	Level	Value	Description
GENERAL_HARDWARE_ERROR	FATALERROR	0x05001500	General Error
GENERAL_HARDWARE_WARNING	WARNING	0x03001501	General Warning
GENERAL_DRIVER_PROBLEM	INFO	0x02001502	Driver Problem

4.3.8. FILESYSTEM_LECTOR

This section shows the defined error codes of the " FILESYSTEM_LECTOR" sub system.
The defined value of the sub system is: 30

Name	Level	Value	Description
FS_PERSIST_PART_NOT_MOUNTED	ERROR	0x04001e00	Persist partition is not mounted
FS_VAR_PART_NOT_MOUNTED	ERROR	0x04001e01	Data partition is not mounted
SDCARD_STORAGE_READ_SUCCESSFUL	INFO	0x02001e02	Reading parameters from SD-Card successful
SDCARD_STORAGE_READ_FAILED	WARNING	0x03001e03	Reading parameters from SD-Card failed
SDCARD_STORAGE_WRITE_SUCCESSFUL	INFO	0x02001e04	Writing parameters to SD-Card successful
SDCARD_STORAGE_WRITE_FAILED	WARNING	0x03001e05	Writing parameters to SD-Card failed

4.3.9. TIME_CONTROL

This section shows the defined error codes of the " TIME_CONTROL" sub system.
The defined value of the sub system is: 31

Name	Level	Value	Description
NTP_SUCCESSFUL	INFO	0x02001f00	Successfully received current time from NTP server
NTP_NOT_SUCCESSFUL	WARNING	0x03001f01	Could not receive time from the NTP server

© SICK AG - Germany - All rights reserved

4.3.10. ETHERNETIP

This section shows the defined error codes of the " ETHERNETIP" sub system.
The defined value of the sub system is: 32

Name	Level	Value	Description
EIP_INITIALIZATION_FAILED	FATALERROR	0x05002000	EtherNet/IP initialization failed
EIP_CONNECTION_ESTABLISHED	INFO	0x02002001	EtherNet/IP connection established
EIP_CONNCETION_TIMEOUT	WARNING	0x03002002	EtherNet/IP connection timeout

4.3.11. SVP

This section shows the defined error codes of the " SVP" sub system.
The defined value of the sub system is: 33

Name	Level	Value	Description
SVP_DATA_LOST	WARNING	0x03002100	SVP Protocol Data Lost

4.3.12. NETINTERFACE_LOGGING_UPLOAD

This section shows the defined error codes of the " NETINTERFACE_LOGGING_UPLOAD" sub system.
The defined value of the sub system is: 34

Name	Level	Value	Description
ITFLOG_EIO_SDCARD	ERROR	0x04002200	Net interface logging: write error on sd card
ITFLOG_EIO_NAND	ERROR	0x04002201	Net interface logging: write error on internal permanent memory
ITFLOG_EIO_RAMDISK	ERROR	0x04002202	Net interface logging: write error on internal temporary memory
ITFLOG_OUTOFMEM_SDCARD	WARNING	0x03002203	Net interface logging: no free space on sd card
ITFLOG_OUTOFMEM_NAND	WARNING	0x03002204	Net interface logging: no free space on internal permanent memory
ITFLOG_OUTOFMEM_RAMDISK	WARNING	0x03002205	Net interface logging: no free space on internal temporary memory

© SICK AG - Germany - All rights reserved

4.3.13. FPGA

This section shows the defined error codes of the " FPGA" sub system.
The defined value of the sub system is: 35

Name	Level	Value	Description
FPGA_NOT_VALID	ERROR	0x04002308	No valid FPGA-Configuration found
FPGA_NOT_INITIALIZED	ERROR	0x04002309	FPGA could not be initialized
FPGA_BAD_FPGA_VERSION	FATALERROR	0x0500230a	FPGA version does not match firmware version
FPGA_DMA_FAIL	FATALERROR	0x0500230b	Cannot initialize DMA subsystem
FPGA_UNINITIALIZED_VARIANT	WARNING	0x0300230c	Cannot load FPGA due to incomplete ATAB
FPGA_DMA_TIMING	INFO	0x0200230d	DMA timing problem detected

4.3.14. PROFINET

This section shows the defined error codes of the " PROFINET" sub system.
The defined value of the sub system is: 36

Name	Level	Value	Description
PN_INITIALIZATION_FAILED	FATALERROR	0x05002400	Profinet initialization failed
PN_CONNECTION_ESTABLISHED	INFO	0x02002401	Profinet connection established
PN_CONNCETION_TIMEOUT	WARNING	0x03002402	Profinet connection timeout
PN_INVALID_DEVICE_NAME	WARNING	0x03002402	Profinet invalid PN device name
PN_INVALID_P_MAC_ADDRESS	ERROR	0x04002408	Profinet invalid port MAC address (contact SICK)

4.4. BASE

4.4.1. GENERAL

This section shows the defined error codes of the " GENERAL" sub system.
The defined value of the sub system is: 0

Name	Level	Value	Description
DEBUG_INFO	DEBUG	0x01000001	Debug Information
DEBUG_WARNING	DEBUG	0x01000002	Debug Warning
DEBUG_ERROR	DEBUG	0x01000003	Debug Error
DEBUG_FATALERROR	DEBUG	0x01000004	Debug Fatal Error
UNDEFINED_ERROR	FATALERROR	0x05000005	Unknown Error
SPEED_ERROR	ERROR	0x0400000a	Error from SPEED
SPEED_WARNING	WARNING	0x0300000b	Warning from SPEED
SPEED_INFO	INFO	0x0200000c	Info from SPEED
RAPID_ERROR	ERROR	0x04000014	Error from RAPID
RAPID_WARNING	WARNING	0x03000015	Warning from RAPID
RAPID_INFO	INFO	0x02000016	Info from RAPID
RESET_BY_POWER_ON	INFO	0x0200001e	Reset by Power On
RESET_BY_ASSERTION	FATALERROR	0x0500001f	Reset by Assertion
RESET_BY_UNHANDLED_INTERRUPT	FATALERROR	0x05000020	Reset by Unhandled Interrupt
RESET_ON_BOOT_ABANDONED	ERROR	0x04000021	Reset on boot abandoned

© SICK AG - Germany - All rights reserved

Name	Level	Value	Description
RESET_BY_CLEAR_APPL_MAGIC	ERROR	0x04000022	Reset by clearing Application Magic
RESET_BY_SOPAS_METHOD_SOFTRESET	ERROR	0x04000023	Reset by Sopas method Softreset
RESET_BY_SOPAS_METHOD_REBOOTDEVICE	ERROR	0x04000024	Reset by Sopas method Reset Device
RESET_BY_ETHERNET_PARAM_CHANGE	ERROR	0x04000025	Reset needed because of Ethernet Parameter change
START_FIRMWARE_UPDATE	ERROR	0x04000026	Performing firmware update

4.4.2. TESTERRORS

This section shows the defined error codes of the " TESTERRORS" sub system.
The defined value of the sub system is: 14

Name	Level	Value	Description
ERROR_TEST_INFO	INFO	0x02000e01	Test error for level INFO
ERROR_TEST_WARNING	WARNING	0x03000e02	Test error for level WARNING
ERROR_TEST_ERROR	ERROR	0x04000e03	Test error for level ERROR
ERROR_TEST_FATALERROR	FATALERROR	0x05000e04	Test error for level FATALERROR

4.4.3. CSAD_CSFD

This section shows the defined error codes of the " CSAD_CSFD" sub system.
The defined value of the sub system is: 19

Name	Level	Value	Description
CSAD_FAILED	WARNING	0x03001301	Error at loading CSAD
CSAD_SUCCEEDED	INFO	0x02001302	Successfully loaded CSAD
CSFD_FAILED	WARNING	0x03001303	Error at loading CSFD
CSFD_SUCCEEDED	INFO	0x02001304	Successfully loaded CSFD

© SICK AG - Germany - All rights reserved

4.5. CAN1

4.5.1. CAN1_GENERAL

This section shows the defined error codes of the " CAN1_GENERAL" sub system.
The defined value of the sub system is: 2

Name	Level	Value	Description
CAN_NO_REC_BUFFER	WARNING	0x03000201	No buffer got for receiving commands
CAN_INIT	WARNING	0x03000202	INIT failed !
CAN_CLIENT_SDO_TIMEOUT	WARNING	0x03000203	Client SDO timeout for server
CAN_CLIENT_UNKNOWN_DATA_TYPE	WARNING	0x03000204	Client unknown data type !
CAN_WRITE_PDO	WARNING	0x03000205	Data lost while sending PDO
CAN_SEND_CMD	WARNING	0x03000206	WRITE_COMMAND could not be executed
CAN_DATA_NOT_CONSISTENT	WARNING	0x03000207	Inconsistent data
CAN_START_SDO_TRANSFER	WARNING	0x03000208	Error on SDO StartTransfer
CAN_CLIENT_SDO_ABORT	WARNING	0x03000209	Client SDO transfer canceled
CAN_CLIENT_SDO_INIT	WARNING	0x0300020a	No memory for SDO request!
CAN_FIFO_OVERFLOW	WARNING	0x0300020b	Buffer Overflow - Server Data lost
CAN_SERVER_LOST_RD_RESULT	WARNING	0x0300020c	Read Result timeout from server
CAN_SERVER_LOST_CMD_RESP	WARNING	0x0300020d	Command Response timeout from server
CAN_SERVER_LOST_DIAG_DATA	WARNING	0x0300020e	Diagnosis timeout from server
CAN_SERVER_LOST_SERALIZED_DATA	WARNING	0x0300020f	Server timeout for transfer of serialized data
CAN_SERVER_UNCONN_LOST_DATA	WARNING	0x03000210	Unconnected data timeout
CAN_SERVER_LOST_UNKNOWN_DATA	WARNING	0x03000211	Data available PDO of invalid type
CAN_SERVER_SEND_SDO_TIMEOUT	WARNING	0x03000212	Timeout on sending server data
CAN_DOMAIN_ID_MISMATCH	WARNING	0x03000213	Received Domain ID and expected value don't match
CAN_CONTROLLER_OVERRUN	WARNING	0x03000214	CAN Controller Overrun
CAN_BUFFER_OVERFLOW	WARNING	0x03000215	CAN buffer overflow
CAN_ERROR_PASSIVE	WARNING	0x03000216	CAN Controller reached state 'error passive'
CAN_BUS_OFF	WARNING	0x03000217	CAN Controller reached state 'bus off'
RESET_BY_CAN_CMD	ERROR	0x04000218	Reset by CAN command
CAN_OTHER_TIME_PRODUCER_DETECTED	WARNING	0x03000219	Another client produces timestamps on the bus

© SICK AG - Germany - All rights reserved

4.6. NETWORK

4.6.1. NETWORK_GENERAL

This section shows the defined error codes of the " NETWORK_GENERAL" sub system.
The defined value of the sub system is: 3

Name	Level	Value	Description
TEST_NETWORK_INFO	INFO	0x02000300	Testinfo Network

4.6.2. NETWORK_MONITOR

This section shows the defined error codes of the " NETWORK_MONITOR" sub system.
The defined value of the sub system is: 4

Name	Level	Value	Description
WARN_REMOTE_DEV_ERR_STAT_SET	WARNING	0x03000400	Remote Device Error state set
WARN_REMOTE_DEV_MISSING	WARNING	0x03000401	Remote Device missing
INFO_NET_MONITORING_OK	INFO	0x02000402	Net monitoring OK
INFO_REMOTE_DEV_CONNECTED	INFO	0x02000403	Remote Device connected
INFO_REMOTE_DEV_CONNECTED_NOT_MONITORED	INFO	0x02000404	Remote Device connected but it is not monitored
WARN_REMOTE_DEV_WARNING_SET	INFO	0x02000405	Remote Device Warning state set
WARN_REMOTE_DEV_ERR_FATAL_SET	WARNING	0x03000406	Remote Device Fatal Error state set

© SICK AG - Germany - All rights reserved

4.7. FILESYSTEM

4.7.1. FILESYSTEM_GENERAL

This section shows the defined error codes of the " FILESYSTEM_GENERAL" sub system.
The defined value of the sub system is: 5

Name	Level	Value	Description
FILE_IO_FAILED	WARNING	0x03000500	File I/O failed
STORAGE_DEV_NOT_FOUND	WARNING	0x03000501	Storage device not found
MMC_DETECTED	INFO	0x0200050a	Memory card detected
MMC_ACCESS_PROBLEM	WARNING	0x0300050b	Problem occured accessing memory card
MMC_FS_DAMAGED	WARNING	0x0300050c	File system on sd card is damaged

4.8. ETHERNET

4.8.1. ETHERNET_GENERAL

This section shows the defined error codes of the " ETHERNET_GENERAL" sub system.
The defined value of the sub system is: 15

Name	Level	Value	Description
CONNECTION_ESTABLISHED	INFO	0x02000f01	Connection established
CONNECTION_LOST	INFO	0x02000f02	Connection lost
TRANSMIT_FAILED	WARNING	0x03000f03	Transmit failed
NO_ETHERNET_CABLE	INFO	0x02000f04	No ethernet cable
CONNECTION_ABORTED	INFO	0x02000f05	Connection aborted
CONNECTION_RESET_BY_PEER	INFO	0x02000f06	Connection closed by peer
CONNECTION_CLOSING	INFO	0x02000f07	Connection closing
CONNECTION_RELEASED	INFO	0x02000f08	Connection released
CONNECTION_TIMED_OUT	WARNING	0x03000f09	Connection timed out
CONNECTION_OPEN_FAILED	INFO	0x02000f0a	Connection open failed
TRANSMIT_FAILED_ERROR_CODE	INFO	0x02000f0b	Tx failed with error code
RECEIVE_FAILED_ERROR_CODE	INFO	0x02000f0c	Rx failed with error code
OPEN_FAILED_ERROR_CODE	INFO	0x02000f0d	Open failed with error code
CLOSE_FAILED_ERROR_CODE	INFO	0x02000f0e	Close failed with error code
LISTEN_FAILED	WARNING	0x03000f0f	Listen failed
BIND_FAILED	WARNING	0x03000f10	Bind failed
ACCEPT_FAILED	WARNING	0x03000f11	Accept failed
MAXIMUM_CLIENT_CONNECTIONS	WARNING	0x03000f12	Reached maximum client connections
SERVER_NOT_REACHABLE	WARNING	0x03000f13	Server not reachable
FTP_OPEN_FAILED	INFO	0x02000f14	FTP open failed
FTP_PASSWD_FAILED	INFO	0x02000f15	FTP password failed
FTP_UNKNOWN_USER	INFO	0x02000f16	FTP unknown user
FTP_CMD_CWD_FAILED	INFO	0x02000f17	FTP command CWD failed
FTP_CMD_STOR_FAILED	INFO	0x02000f18	FTP command STOR failed
FTP_CMD_TYPE_FAILED	INFO	0x02000f19	FTP command TYPE failed
FTP_OPEN_LOCAL_FILE_FAILED	INFO	0x02000f1a	FTP failed to open local file
DHCP_SUCCESSFULL	INFO	0x02000f1b	Successfully assigned IP-Address via DHCP
DHCP_NOT_SUCCESSFULL	WARNING	0x03000f1c	DHCP server reply timed out

© SICK AG - Germany - All rights reserved

Name	Level	Value	Description
IP_ADDRESS_CONFLICT	WARNING	0x03000f1d	IP-Address conflict detected

4.9. ObjAdmin

4.9.1. OBJECT_ADMIN

This section shows the defined error codes of the " OBJECT_ADMIN" sub system.
The defined value of the sub system is: 17

Name	Level	Value	Description
RESET_ON_NOREAD	ERROR	0x04001101	Reset because of to many no read in a row
STRTEMP1_INVALID	ERROR	0x04001102	Output formatter #1 content is invalid
STRTEMP2_INVALID	ERROR	0x04001103	Output formatter #2 content is invalid
EVCND_INVALID	ERROR	0x04001104	Evaluation condition is invalid
EVCND_MISSING	WARNING	0x03001105	Evaluation condition is missing or invalid. See Evaluation C. page.
OUT_OF_SEQUENCE	WARNING	0x03001106	Object output (publish) was out of sequence.
OBJECT_RELEASED	INFO	0x02001107	Object released. Codestat doesn't accept released objects.

4.10. TriggerCtrl

4.10.1. TRIGGER_CTRL

This section shows the defined error codes of the " TRIGGER_CTRL" sub system.
The defined value of the sub system is: 18

Name	Level	Value	Description
NO_TIMER_FOR_TRIGGER_START	WARNING	0x03001201	No timer for Trigger Start
NO_TIMER_FOR_TRIGGER_END	WARNING	0x03001202	No timer for Trigger End
REPLACE_ID_WITH_LAST_VALID_ID	WARNING	0x03001203	Replace Trigger ID with last valid Trigger ID
OBJ_TRIG_ID_MISMATCH	WARNING	0x03001204	Object Trigger ID mismatch
NO_VISIBLE_OBJECT	INFO	0x02001205	No visible Trigger Object
DO_ON_WRONG_STATE	WARNING	0x03001206	Trigger DoOn wrong State
DO_OFF_WRONG_STATE	WARNING	0x03001207	Trigger DoOff wrong State
LEAVE_IDLE_WRONG_STATE	WARNING	0x03001208	Trigger Leave Idle wrong State
NO_SYS_ON_FROM_MASTER	INFO	0x02001209	System Gate On from Master missing
NO_SYS_OFF_FROM_MASTER	INFO	0x0200120a	System Gate Off from Master missing
TRIGGER_ID_ON_SUPPRESSED	WARNING	0x0300120b	Suppressed Trigger ID On
TRIGGER_ID_OFF_SUPPRESSED	WARNING	0x0300120c	Suppressed Trigger ID Off
USER_TRIG_QUEUE_LIMIT_REACHED	WARNING	0x0300120d	Trigger Queue reached limit
USER_TRIG_TO_MANY_DISPATCH_ERRORS	WARNING	0x0300120e	To many Trigger dispatch Errors
USER_TRIG_TO_MANY_END_TRIGGER	WARNING	0x0300120f	Trigger Ratio out of Balance, to many Off
USER_TRIG_TO_MANY_START_TRIGGER	WARNING	0x03001210	Trigger Ratio out of Balance, to many On

© SICK AG - Germany - All rights reserved

Index

A

AbortDownload 64
ActivateEPSSet 2110
AimDpmActive 642
AimDpmCalibratedGain 643
AimDpmCalibratedMaxReflectance 645
AimDpmCalibratedMeanReflectance 646
AimingLaser 1586
ALSExpNodalPoseAlphaOpti 1896
ALSExpNodalPoseBetaOpti 1897
ALSExpNodalPoseGammaOpti 1899
ALSExpNodalPoseYCoordOffset 1902
ALSExpNodalPoseZCoordOffset 1903
ALSNodalPoseAlphaOpti 1887
ALSNodalPoseBetaOpti 1888
ALSNodalPoseGammaOpti 1890
ALSNodalPoseXCoordOffset 1891
ALSNodalPoseYCoordOffset 1893
ALSNodalPoseZCoordOffset 1894
ALSPosEstiFeedBack 1881
ALSPosEstiFin 1886
ALSPosEstiProcFeedBack 1884
ALSPosEstiTargetOrientation 1880
ALSPosEstiXOrigin 1876
ALSPosEstiYOrigin 1877
ALSPosEstiZOrigin 1879
APCCC01 2020
APCCC02 2026
APCCC03 2032
APCCC04 2038
APCCC05 2044
APCCC06 2050
APCCC07 2056
APCCC08 2062
APCCC09 2068
APCCC10 2074
APCCCS01 2021
APCCCS02 2027
APCCCS03 2033
APCCCS04 2039
APCCCS05 2045
APCCCS06 2051
APCCCS07 2057
APCCCS08 2063
APCCCS09 2069
APCCCS10 2075
APCCDTS01 2023
APCCDTS02 2029
APCCDTS03 2035
APCCDTS04 2041
APCCDTS05 2047
APCCDTS06 2053
APCCDTS07 2059
APCCDTS08 2065
APCCDTS09 2071
APCCDTS10 2077
APCCounterCondition01 2020
APCCounterCondition02 2026
APCCounterCondition03 2032
APCCounterCondition04 2038
APCCounterCondition05 2044
APCCounterCondition06 2050
APCCounterCondition07 2056
APCCounterCondition08 2062
APCCounterCondition09 2068
APCCounterCondition10 2074
APCCounterConditionStruct01 2021
APCCounterConditionStruct02 2027
APCCounterConditionStruct03 2033
APCCounterConditionStruct04 2039
APCCounterConditionStruct05 2045
APCCounterConditionStruct06 2051
APCCounterConditionStruct07 2057
APCCounterConditionStruct08 2063
APCCounterConditionStruct09 2069
APCCounterConditionStruct10 2075
APCCounterDBTagStruct01 2023
APCCounterDBTagStruct02 2029
APCCounterDBTagStruct03 2035
APCCounterDBTagStruct04 2041
APCCounterDBTagStruct05 2047
APCCounterDBTagStruct06 2053
APCCounterDBTagStruct07 2059
APCCounterDBTagStruct08 2065
APCCounterDBTagStruct09 2071
APCCounterDBTagStruct10 2077
APCIsPerm01 2024
APCIsPerm02 2030
APCIsPerm03 2036
APCIsPerm04 2042
APCIsPerm05 2048
APCIsPerm06 2054
APCIsPerm07 2060
APCIsPerm08 2066
APCIsPerm09 2072
APCIsPerm10 2078
APCIsPermanent01 2024
APCIsPermanent02 2030
APCIsPermanent03 2036
APCIsPermanent04 2042
APCIsPermanent05 2048
APCIsPermanent06 2054
APCIsPermanent07 2060
APCIsPermanent08 2066
APCIsPermanent09 2072
APCIsPermanent10 2078
APSRetries 2083
ASAllOperationsFinished 1875
ASAllowTeachPixToMM 1862
ASAllTchPixMM 1862
ASAPConditionTimoutTime 818
ASAPConditionTimoutTrack 807
ASAPLabelTimoutTime 819
ASAPLabelTimoutTrack 806
ASCalculateShutterTime 1874
ASCellSize 1870
Asci127_t 2377

© SICK AG - Germany - All rights reserved

Asci127AndCode_t 2385
Asci127AndObject_t 2381
ASCodeRegion 1857
ASConveyorSpeed 1868
ASConvSpeed 1868
AScriptEna 1342
ASDatamatrixPrio 1861
ASDmxPrio 1861
ASManualCodeRegion 1859
ASParam 1854
ASParameter 1854
AssignmentMode 785
ASUseDPMRoi 1864
ASUserDefinedDPMRoi 1865
ASWriteTarget 1867
AUTO_SETUP 2398
AutoAdjustGain 1596
AutoAdjustGainRangeMax 1601
AutoAdjustGainRangeMin 1599
AutoAdjustRegion 1597
AztecActive 1976
AztecFixLenList 1979
AztecLengthMode 1977
AztecMode 1982

B

BarcodeState 2276
BASE 2401
BeeperFunc 2007
BeeperFuncExt 2004
BeeperLoudness 2005
BLOB_SERVER 2398
BlobFragmentSize 2325
BlobServerGetStatistics 2326
BlobServerResetLocalStatistics 2329
BlobTcpPort 2331
BootupCDF 2270
BPFunc 2007
BPFuncExt 2004
BPLoudness 2005
Brightness 1573
BWDBeltWidth 2206
BWDCalcTriggerPostExpand 2208
BWDCalcTriggerPreExpand 2207
BWDCopyParam 2230
BWDDistanceBwdTrigger 2204
BWDDistMeasSourceVMSNodeID 2214
BWDDMsrcVMSnodeID 2214
BWDEnableMode 2203
BWDEnaMod 2203
BWDFocPos 2210
BWDFocusPosition 2210
BWDPOalpha 2216
BWDPOalphaPano 2223
BWDPObeta 2217
BWDPObetaPano 2224
BWDPOcoordX 2220
BWDPOcoordXPano 2227
BWDPOcoordY 2221
BWDPOcoordYPano 2229
BWDPOgamma 2218
BWDPOgammaPano 2226
BWDRCCalcTriggerPostExpand 2208
BWDRCCalcTriggerPreExpand 2207
BWDRCRdArlimY1 2211
BWDRCRdArlimY2 2213
BWDRCReadingAreaLimY1 2211
BWDRCReadingAreaLimY2 2213
BWDScannerPosAlpha 2216
BWDScannerPosAlphaPanorama 2223
BWDScannerPosBeta 2217
BWDScannerPosBetaPanorama 2224
BWDScannerPosGamma 2218
BWDScannerPosGammaPanorama 2226
BWDScannerPosXCoord 2220
BWDScannerPosXCoordPanorama 2227
BWDScannerPosYCoord 2221
BWDScannerPosYCoordPanorama 2229

C

C128Active 389
C128CheckDigitTestL1 325
C128CheckDigitTestL2 327
C128CheckDigitTestL3 328
C128CheckDigitTestL4 330
C128CheckDigitTestL5 331
C128FamiliyActive 390
C128FixLenList 334
C128HexASCIIOutput 337
C128IntLenList 336
C128LengthMode 333
C128MultiRead 324
C128SingleErrorCorrection 341
C128StartCharacterValidation 340
C128StopCharacterValidation 339
C1_CmdRespEna 914
C1_CmdRespTmo 916
C1_DiagEna 911
C1_DiagTmo 913
C1_DiIID 878
C1_DiMsk 879
C1_DoEna 876
C1_DoID 875
C1_EmcyId 917
C1_EmcyIT 919
C1_HbTime 897
C1_PdoET 910
C1_PdoId 906
C1_PdoIT 909
C1_PdoNum 904
C1_PdoTT 907
C1_ResEna 898
C1_ResTmo 901
C1_RP1_ID 969
C1_RP1_MN 964
C1_RP1_MOBJ 965
C1_RP1_PCS 968
C1_RP1_TT 971
C1_RP2_ID 977
C1_RP2_MN 972
C1_RP2_MOBJ 973
C1_RP2_PCS 976
C1_RP2_TT 979
C1_RP3_ID 985

© SICK AG - Germany - All rights reserved

C1_RP3_MN 980
C1_RP3_MOBJ 981
C1_RP3_PCS 984
C1_RP3_TT 987
C1_RP4_ID 993
C1_RP4_MN 988
C1_RP4_MOBJ 989
C1_RP4_PCS 992
C1_RP4_TT 995
C1_RPDO1_CobId 969
C1_RPDO1_MapNum 964
C1_RPDO1_MapObjs 965
C1_RPDO1_PreConnSet 968
C1_RPDO1_TrmType 971
C1_RPDO2_CobId 977
C1_RPDO2_MapNum 972
C1_RPDO2_MapObjs 973
C1_RPDO2_PreConnSet 976
C1_RPDO2_TrmType 979
C1_RPDO3_CobId 985
C1_RPDO3_MapNum 980
C1_RPDO3_MapObjs 981
C1_RPDO3_PreConnSet 984
C1_RPDO3_TrmType 987
C1_RPDO4_CobId 993
C1_RPDO4_MapNum 988
C1_RPDO4_MapObjs 989
C1_RPDO4_PreConnSet 992
C1_RPDO4_TrmType 995
C1_SdoRel 903
C1_SMode 900
C1_TP1_ET 930
C1_TP1_ID 926
C1_TP1_IT 929
C1_TP1_MN 921
C1_TP1_MOBJ 922
C1_TP1_PCS 925
C1_TP1_TT 928
C1_TP2_ET 941
C1_TP2_ID 937
C1_TP2_IT 940
C1_TP2_MN 932
C1_TP2_MOBJ 933
C1_TP2_PCS 936
C1_TP2_TT 938
C1_TP3_ET 952
C1_TP3_ID 948
C1_TP3_IT 950
C1_TP3_MN 942
C1_TP3_MOBJ 944
C1_TP3_PCS 946
C1_TP3_TT 949
C1_TP4_ET 962
C1_TP4_ID 958
C1_TP4_IT 961
C1_TP4_MN 953
C1_TP4_MOBJ 954
C1_TP4_PCS 957
C1_TP4_TT 960
C1_TPDO1_CobId 926
C1_TPDO1_EventTime 930
C1_TPDO1_InhibtTime 929
C1_TPDO1_MapNum 921
C1_TPDO1_MapObjs 922
C1_TPDO1_PreConnSet 925
C1_TPDO1_TrmType 928
C1_TPDO2_CobId 937
C1_TPDO2_EventTime 941
C1_TPDO2_InhibtTime 940
C1_TPDO2_MapNum 932
C1_TPDO2_MapObjs 933
C1_TPDO2_PreConnSet 936
C1_TPDO2_TrmType 938
C1_TPDO3_CobId 948
C1_TPDO3_EventTime 952
C1_TPDO3_InhibtTime 950
C1_TPDO3_MapNum 942
C1_TPDO3_MapObjs 944
C1_TPDO3_PreConnSet 946
C1_TPDO3_TrmType 949
C1_TPDO4_CobId 958
C1_TPDO4_EventTime 962
C1_TPDO4_InhibtTime 961
C1_TPDO4_MapNum 953
C1_TPDO4_MapObjs 954
C1_TPDO4_PreConnSet 957
C1_TPDO4_TrmType 960
C1HBEna 881
C1HBInt 882
C1RetrHB 883
C1TSMode 892
C1TSPeriod 893
C1UInpByNum 888
C1UInpID 886
C1UIOEna 885
C1UOutpByNum 890
C1UOutpID 889
C25ILActive 378
C25ILCheckDigitTestL1 297
C25ILCheckDigitTestL2 298
C25ILCheckDigitTestL3 300
C25ILCheckDigitTestL4 301
C25ILCheckDigitTestL5 303
C25ILClassRestriction 309
C25ILFixLenList 306
C25ILIntLenList 307
C25ILLengthMode 304
C25ILMultiReadL1 290
C25ILMultiReadL2 291
C25ILMultiReadL3 293
C25ILMultiReadL4 294
C25ILMultiReadL5 295
C25ILQuietZoneVerification 315
C25ILSingleErrorCorrection 314
C25ILStartCharacterValidation 313
C25ILStopCharacterValidation 311
C25ILTransmitCheckDigit 310
C39Active 380
C39CheckDigitTest 269
C39ClassRestriction 278
C39Code32Conversion 275
C39FixLenList 272
C39FullASCII 266
C39HexASCIIOutput 268
C39IntLenList 273
C39LengthMode 270

© SICK AG - Germany - All rights reserved

C39MultiRead 264
C39StaStoTransmit 265
C39TransmitCheckDigit 276
C93Active 384
C93FixLenList 319
C93HexASCIIOutput 322
C93IntLenList 321
C93LengthMode 318
C93MultiRead 317
CalcTriggerPostExpand 1852
CalcTriggerPreExpand 1851
CalibratedMmPerPix 1623
CAMAcqMode 1567
CAMAimingLaser 1586
CAMAutAdjReg 1597
CAMAutGain 1596
CAMAutGainMax 1601
CAMAutGainMin 1599
CAMBrightness 1573
CAMBurstImgNum 1569
CAMCalMMPix 1623
CAMCCDMtx 1621
CAMContrast 1574
CAMDutyCycViol 1626
CAMExternalIllum 1582
CAMExtLightConnMode 1584
CAMFlashContrEna 1625
CAMFlashContrLev 1612
CAMFocPos 1606
CAMFrameRate 1608
CAMGammaTurningPoint10bit 1575
CAMIlluOffDelayEnable 1619
CAMIlluOffDelayTime 1620
CAMImageRoi 1589
CAMImgResolution 1591
CAMInternalIllum 1579
CAMInternalIllumColor 1581
CAMLedTimeout 1587
CAMLedTimeoutEnabled 1603
CAMMirroring 1593
CAMNoiseRedFilter 1577
CAMNumFramesQueue 1571
CAMPanoImgOverlap 1615
CAMReadDistInput 1605
CAMRMorphFilter 1578
CAMShutterTime 1609
CAMUseCCDToWrldTrnsfMtrx 1595
CAMUseFrameRate 1566
CAMUseNumFramesQueue 1570
CAMVerticalFlip 1592
CAN1 2403
CAN1_CmdResponseTimeout 916
CAN1_DiagDataTimeout 913
CAN1_GENERAL 2403
CAN1_ReadResultTimeout 901
CAN1AutoSdoRelease 903
CAN1Baudrate 872
CAN1CmdRespEnable 914
CAN1DiagEnable 911
CAN1DigInputMask 879
CAN1DigInputPdoId 878
CAN1DigOutputPdoEna 876
CAN1DigOutputPdoId 875
CAN1EmcyID 917
CAN1EmcyInhibitTime 919
CAN1Format 873
CAN1HBEna 881
CAN1HBInterval 882
CAN1Mode 895
CAN1PdoEventTime 910
CAN1PdoID 906
CAN1PdoInhibitTime 909
CAN1PdoNum 904
CAN1PdoTrmType 907
CAN1ProdHbTime 897
CAN1ReadResultEnable 898
CAN1RetrHB 883
CAN1SendMode 900
CAN1TimeStampMode 892
CAN1TimeStampPeriod 893
CAN1UserInpByteNum 888
CAN1UserInpPdoId 886
CAN1UserOutpByteNum 890
CAN1UserOutpPdoId 889
CAN1UsrIOEna 885
CancelAimDpmCalib 649
CancelAutoSetup 1872
CancelDemoMode 1917
CancelImageDeletion 1765
CancelImageUpload 1762
CancelPoseEstimation 1908
CBARActive 386
CBARCheckDigitTest 256
CBARFixLenList 259
CBARIntLenList 261
CBARLengthMode 258
CBARMultiRead 252
CBARStaStoIdent 253
CBARStaStoTransmit 255
CBARTransmitCheckDigit 262
CCDToWorldTransformMatrix 1621
CDF_EraseParameterFile 2369
CDF_FlashParameterFile 2368
CDF_FramingHeaderInputSelect_1 1164
CDF_FramingHeaderInputSelect_2 1165
CDF_PhysInDebounceTime_1 1170
CDF_PhysInDebounceTime_2 1171
CDF_PhysOutputSelect_1 1167
CDF_PhysOutputSelect_2 1168
CDF_PlcLogicalInputState_FH 1173
CDF_PlcLogicalInputState_Map 1174
CDF_ReadParameterSetSegment 2365
CDF_SensorPhysicalOutputState 1176
CDF_WriteParameterSetSegment 2366
CdfCanMpxOutEnable 1301
CdfCanMultiplexSend 1301
CdfCm_CDF600HS 1179
CdfEcatCmMode 1309
CdfEthMac 118
CdfEthMacP1 119
CdfEthMacP2 121
CdfIsDevFam 125
CdfIsDeviceFamily 125
CdfLis 1173
CdfOrderIdDevice 124
CdfOrderIdFamily 122

© SICK AG - Germany - All rights reserved

CdfOrdIdDev 124
CdfOrdIdFam 122
CdfPhysInDeb_1 1170
CdfPhysInDeb_2 1171
CdfPhysOutSel_1 1167
CdfPhysOutSel_2 1168
CdfPlcFhInSel_1 1164
CdfPlcFhInSel_2 1165
CdfPlcLisMap 1174
CdfPnApplyButton 140
CdfPnBusStatus 127
CdfPncfgApply 135
CdfPncfgChanged 136
CdfPnDeviceId 109
CdfPnDeviceType 110
CdfPnDevId 109
CdfPnDevTyp 110
CdfPnEeWrInt 106
CdfPnErrCode 128
CdfPnHwRev 113
CdfPnHwRevision 113
CdfPnImDate 151
CdfPnImDsc 152
CdfPnImFun 148
CdfPnImGw 146
CdfPnImLoc 149
CdfPnImSign 154
CdfPnIpAddr 143
CdfPnIpMask 145
CdfPnIpRemanent 133
CdfPnMasterAvailable 130
CdfPnPdev 159
CdfPnPdevCrc 157
CdfPnPdevMagic 156
CdfPnPdevRawData 159
CdfPnProfId 115
CdfPnProfileId 115
CdfPnProfileSpecificType 116
CdfPnProfSpTyp 116
CdfPnResetFactory 107
CdfPnS7CompMode 138
CdfPnStationName 142
CdfPnStationNameRemanent 131
CdfPnSwRev 112
CdfPnSwRevision 112
CdfProfiCmMode 1298
CdfProfinetApplyButton 140
CdfProfinetBusStatus 127
CdfProfinetConfigApply 135
CdfProfinetConfigChanged 136
CdfProfinetEeWriteOnlyIntern 106
CdfProfinetImDate 151
CdfProfinetImDescriptor 152
CdfProfinetImFunction 148
CdfProfinetImLocation 149
CdfProfinetImSignature 154
CdfProfinetIpAddress 143
CdfProfinetIpGateway 146
CdfProfinetIpMask 145
CdfProfinetIpSettingsStoringRemanent 133
CdfProfinetMasterAvailable 130
CdfProfinetResetToFactory 107
CdfProfinetS7CompatibilityMode 138
CdfProfinetStackErrorCode 128
CdfProfinetStationName 142
CdfProfinetStationNameStoringRemanent 131
CdfSelDataFrmt 1299
CdfSelectDataFormat 1299
CdfSensPos 1176
CdfStatNameSync 1178
CdfSyncStationNameToLocationName 1178
CdfUpDatePnConfig 1181
cdpApiErrorEvent 1366
cdpApiRequestTracepointInfo 1370
cdpApiRstToFactorySettingsEvent 1367
cdpApiStoreParams 1368
cdpApiTracerCommProc 1358
cdpApiTracerCycleThresholdLowerUs 1364
cdpApiTracerCycleThresholdUpperUs 1362
cdpApiTracerEnabled 1360
cdpApiTracerMaxRecords 1361
cdpApiTracerMode 1357
cdpApiTracerSetTPProp 1372
cdpApiUpDateDiagExt 1369
cdpApiWarningEvent 1366
cdpCmConfig 1547
cdpCmCtrlBitsIn 1541
cdpCmCtrlBitsOut 1543
cdpCmdReg 1352
cdpCmInFrameLength 1548
cdpCmInMsgLength 1553
cdpCmInternalDataIn 1557
cdpCmInternalDataOut 1559
cdpCmOutFrameLength 1550
cdpCmOutMsg 1555
cdpCmProtocolVariant 1551
cdpCmStatus 1545
cdpDigIoReg0 1561
cdpEndianCheck 1355
cdpFbCommStatusReg 1351
cdpPnioAlarmsSupported 1400
cdpPnioDHCP_Status 1386
cdpPnioDHCP_Support 1385
cdpPnioEpMAnnotation 1398
cdpPnioEpMOrderID 1399
cdpPnioGateWayAddr 1380
cdpPnioIMDate 1394
cdpPnioIMDescriptor 1395
cdpPnioIMSignature 1396
cdpPnioIMTagFunction 1392
cdpPnioIMTagLocation 1391
cdpPnioIpAddress 1377
cdpPnioIpAddressType 1375
cdpPnioLedStateBF 1406
cdpPnioLedStateSF 1408
cdpPnioMib1_ifInDiscards 1426
cdpPnioMib1_ifInErrors 1427
cdpPnioMib1_ifInNUcastPkts 1425
cdpPnioMib1_ifInOctets 1422
cdpPnioMib1_ifInUcastPkts 1423
cdpPnioMib1_ifLastChange 1421
cdpPnioMib1_ifNumber 1415
cdpPnioMib1_ifOperStatus 1419
cdpPnioMib1_ifOutDiscards 1433
cdpPnioMib1_ifOutErrors 1434
cdpPnioMib1_ifOutNUcastPkts 1431

© SICK AG - Germany - All rights reserved

cdpPnioMib1_ifOutOctets 1429
cdpPnioMib1_ifOutUcastPkts 1430
cdpPnioMib1_ifPhysAddress 1418
cdpPnioMib1_ifSpeed 1416
cdpPnioMib1_ipInAddrErrors 1439
cdpPnioMib1_ipInDiscards 1440
cdpPnioMib1_ipInHdrErrors 1437
cdpPnioMib1_ipInReceives 1436
cdpPnioMib1_ipOutDiscards 1443
cdpPnioMib1_ipOutRequests 1441
cdpPnioMib1_tcpInErrs 1453
cdpPnioMib1_tcpInSegs 1449
cdpPnioMib1_tcpOutRsts 1455
cdpPnioMib1_tcpOutSegs 1451
cdpPnioMib1_tcpRetransSegs 1452
cdpPnioMib1_udpInDatagrams 1444
cdpPnioMib1_udpInErrors 1447
cdpPnioMib1_udpNoPorts 1445
cdpPnioMib1_udpOutDatagrams 1448
cdpPnioMib2_ifInDiscards 1468
cdpPnioMib2_ifInErrors 1469
cdpPnioMib2_ifInNUcastPkts 1467
cdpPnioMib2_ifInOctets 1464
cdpPnioMib2_ifInUcastPkts 1465
cdpPnioMib2_ifLastChange 1463
cdpPnioMib2_ifNumber 1457
cdpPnioMib2_ifOperStatus 1461
cdpPnioMib2_ifOutDiscards 1475
cdpPnioMib2_ifOutErrors 1476
cdpPnioMib2_ifOutNUcastPkts 1473
cdpPnioMib2_ifOutOctets 1471
cdpPnioMib2_ifOutUcastPkts 1472
cdpPnioMib2_ifPhysAddress 1460
cdpPnioMib2_ifSpeed 1458
cdpPnioMib2_ipInAddrErrors 1481
cdpPnioMib2_ipInDiscards 1482
cdpPnioMib2_ipInHdrErrors 1479
cdpPnioMib2_ipInReceives 1478
cdpPnioMib2_ipOutDiscards 1485
cdpPnioMib2_ipOutRequests 1483
cdpPnioMib2_tcpInErrs 1495
cdpPnioMib2_tcpInSegs 1491
cdpPnioMib2_tcpOutRsts 1497
cdpPnioMib2_tcpOutSegs 1493
cdpPnioMib2_tcpRetransSegs 1494
cdpPnioMib2_udpInDatagrams 1486
cdpPnioMib2_udpInErrors 1489
cdpPnioMib2_udpNoPorts 1487
cdpPnioMib2_udpOutDatagrams 1490
cdpPnioMib3_ifInDiscards 1510
cdpPnioMib3_ifInErrors 1511
cdpPnioMib3_ifInNUcastPkts 1509
cdpPnioMib3_ifInOctets 1506
cdpPnioMib3_ifInUcastPkts 1507
cdpPnioMib3_ifLastChange 1505
cdpPnioMib3_ifNumber 1499
cdpPnioMib3_ifOperStatus 1503
cdpPnioMib3_ifOutDiscards 1517
cdpPnioMib3_ifOutErrors 1518
cdpPnioMib3_ifOutNUcastPkts 1515
cdpPnioMib3_ifOutOctets 1513
cdpPnioMib3_ifOutUcastPkts 1514
cdpPnioMib3_ifPhysAddress 1502
cdpPnioMib3_ifSpeed 1500
cdpPnioMib3_ipInAddrErrors 1523
cdpPnioMib3_ipInDiscards 1524
cdpPnioMib3_ipInHdrErrors 1521
cdpPnioMib3_ipInReceives 1520
cdpPnioMib3_ipOutDiscards 1527
cdpPnioMib3_ipOutRequests 1525
cdpPnioMib3_tcpInErrs 1537
cdpPnioMib3_tcpInSegs 1533
cdpPnioMib3_tcpOutRsts 1539
cdpPnioMib3_tcpOutSegs 1535
cdpPnioMib3_tcpRetransSegs 1536
cdpPnioMib3_udpInDatagrams 1528
cdpPnioMib3_udpInErrors 1531
cdpPnioMib3_udpNoPorts 1529
cdpPnioMib3_udpOutDatagrams 1532
cdpPnioMibSysContact 1413
cdpPnioMibSysDesc 1410
cdpPnioMibSysUpTime 1412
cdpPnioPLCSetAddrRemanent 1383
cdpPnioPLCSetNameRemanent 1381
cdpPnioSelDataFrmt 2140
cdpPnioSelectDataFormat 2140
cdpPnioStateApplication 1402
cdpPnioStateCommunication 1403
cdpPnioStateCommunicationFSM 1409
cdpPnioStateDeviceSummaryDiagnosis 1405
cdpPnioStationName 1374
cdpPnioStatNameSync 1388
cdpPnioSubNetMaskAddr 1378
cdpPnioSyncStationNameToLocationName 1388
cdpPnioUpDatePnConfig 1389
cdpResStatusReg 1354
ChangePassword 13
CheckPassword 16
CheckSdCard 1195
CIbaud 872
CIDottPostal 1681
CidVersion 2371
CIHstFrm 873
CILogiFalsPosF 1696
CIMax1DCodes 1688
CIMax1DCodesEna 1687
CIMaxDMxCodes 1689
CIMaxDMxCodesEna 1699
CIMaxMaxiCodes 1693
CIMaxMaxiCodesEna 1692
CIMaxQRCodes 1691
CIMaxQRCodesEna 1697
CImode 895
CIMxCdReg1D 1678
CinCOCDIFt 766
CinOCChSt 773
CINORCA 1680
CIOptTire 1684
CISContrSprd 1675
CIShortBarHeight 1685
CISModSz2D 1700
CISScanDens1D 1677
CISShrpMeas 1674
CITrackDir 1682
CIWdTex 1695
CloseFile 19

© SICK AG - Germany - All rights reserved

CMTEn 2261
CMTSteThr 2260
Code1DVerISO15416 536
CodeAtBorder1D 1962
CodeBackground1D 250
CodeBackground2D 541
CodeContrast1D 249
CodeContrast2D 538
CodeDirection 1950
CodeFilterDepth 809
CodeModuleSize2D 1700
CodeMotionSteadyThreshold 2260
CodeMotionTrackingEnabled 2261
CodeMultiImageToleranceFactor 2137
CodePosImgMultiEna 2136
CodePosImgMultiFactor 2137
CodePositionByImageMultipleEnable 2136
CodeTrackingDirection 1682
ConnectTimeServer 1191
Contrast 1574
ContrastSpreading 1675
ControlBitsPlcOut 2295
CPCodeDistance 866
CPComp 865
CPCompareDeviceID 868
CPCompDID 868
CPDist 866
CPUseComparison 865
CSAD_CSFD 2402
CuckooImageClear 2355
CuckooImageLoad 2354

D

D1DAtBrd 1962
D1DEXBadDec 1956
D1DEXEmph 1958
D1DEXEnaLineFeedMode 1952
D1DEXLev 1966
D1DEXLineFeedModeHorizontalScans 1953
D1DEXLineFeedModeNumScansInImg 1955
D1DEXScnMd 1959
D1DEXSzFlt 1960
D1DExtSeg 374
D2MCCOffEna 1974
D2MCGridModSize 1969
D2MCMAACompAct 1971
DataMatrixActive 602
DataMatrixAggressivityLevel 607
DataMatrixAllowRect 608
DataMatrixCheckSimpleLPatterns 560
DataMatrixConstructiveGrid 587
DataMatrixDefectCorrection 584
DataMatrixDilateErodeWith2ndValue 548
DataMatrixDilateFilterSize 545
DataMatrixDotActive 591
DataMatrixDotBlobSensitivity 595
DataMatrixDotDiameter 598
DataMatrixDotFilterBlobSearch 596
DataMatrixDotIntegralBlobSearch 594
DataMatrixDotPolarity 592
DataMatrixDotSymbolGeometry 599
DataMatrixEnableNewSeg 567
DataMatrixEnablePCBSpeedUp 563
DataMatrixEnableSpeedOptimization 559
DataMatrixEnableTextSpeedUp 564
DataMatrixErodeFilterSize 547
DataMatrixErrorCorr 544
DataMatrixExcludeCodeAreas 590
DataMatrixFilterSamplePoints 588
DataMatrixFixLenList 603
DataMatrixFormatMode 573
DataMatrixFPGASpeedup 570
DataMatrixFullRescan 582
DataMatrixGeoEstimation 586
DataMatrixGS1AIMarking 578
DataMatrixGS1FirstCharReplacement 575
DataMatrixGS1SeparatorCharReplacement 576
DataMatrixLengthMode 600
DataMatrixMinModuleSize100 572
DataMatrixNegativeDifferenceAllowed 552
DataMatrixNewSegAllowSingleTiles 569
DataMatrixNumWeakBitErrorBitsAllowed 554
DataMatrixPositiveDifferenceAllowed 551
DataMatrixRedundantCodes 566
DataMatrixRescanTPattern 583
DataMatrixTolerateErrorsInLPattern 556
DataMatrixTolerateErrorsInTimingPattern 558
DataMatrixTolerateLPatternDeformation 562
DataMatrixVerISO15415 580
DataMatrixVerISO16022 579
DataMatrixWeakBitsEnabled 550
DataMatrixWeakBitTreshhold 555
DC1DBackground 250
DC1DContrast 249
DC1DVerISO15416 536
DC2DBackground 541
DC2DContrast 538
DC2DMaxModSize 542
DC2DMinModSize 539
DCAddOnLength 282
DCAddOnMode 280
DCAZAct 1976
DCAZFixLen 1979
DCAZLenMode 1977
DCAZMode 1982
DCC128Act 389
DCC128CdTstL1 325
DCC128CdTstL2 327
DCC128CdTstL3 328
DCC128CdTstL4 330
DCC128CdTstL5 331
DCC128FixLen 334
DCC128HxAOut 337
DCC128IntLen 336
DCC128LenMode 333
DCC128Mr 324
DCC128SingErrCorr 341
DCC128StartCharVal 340
DCC128StopCharVal 339
DCC25ILAct 378
DCC25ILCdTstL1 297
DCC25ILCdTstL2 298
DCC25ILCdTstL3 300
DCC25ILCdTstL4 301
DCC25ILCdTstL5 303

© SICK AG - Germany - All rights reserved

DCC25ILClRs 309
DCC25ILFixLen 306
DCC25ILIntLen 307
DCC25ILLenMode 304
DCC25ILMrL1 290
DCC25ILMrL2 291
DCC25ILMrL3 293
DCC25ILMrL4 294
DCC25ILMrL5 295
DCC25ILQuietZnVer 315
DCC25ILSingErrCorr 314
DCC25ILStartCharVal 313
DCC25ILStopCharVal 311
DCC25ILTrCd 310
DCC39Act 380
DCC39C32Conv 275
DCC39CdTst 269
DCC39ClRs 278
DCC39FixLen 272
DCC39FullA 266
DCC39HxAOut 268
DCC39IntLen 273
DCC39LenMode 270
DCC39Mr 264
DCC39StTx 265
DCC39TrCd 276
DCC93Act 384
DCC93FixLen 319
DCC93HxAOut 322
DCC93IntLen 321
DCC93LenMode 318
DCC93Mr 317
DCCBARAct 386
DCCBARCdTst 256
DCCBARFixLen 259
DCCBARIntLen 261
DCCBARLenMode 258
DCCBARMr 252
DCCBARStId 253
DCCBARStTx 255
DCCBARTrCd 262
DCDMAct 602
DCDMAggrLvl 607
DCDMChckSmplL 560
DCDMConstGrd 587
DCDMDefCorr 584
DCDMDilatlFltSize 545
DCDMDotAct 591
DCDMDotBlbSens 595
DCDMDotDiam 598
DCDMDotFilterBlob 596
DCDMDotIntBlob 594
DCDMDotPol 592
DCDMDotSym 599
DCDMEroslFltSize 547
DCDMErrCor 544
DCDMExCdArs 590
DCDMFilterSmplPnts 588
DCDMFixLenX 603
DCDMFlt2ndVal 548
DCDMFormatMode 573
DCDMFPGASpdUp 570
DCDMFullRescn 582
DCDMGeoEst 586
DCDMGS1AIMark 578
DCDMGS1FirstCharReplace 575
DCDMGS1SepCharReplace 576
DCDMLenMode 600
DCDMMinModSize100 572
DCDMNegDiffAllwd 552
DCDMNewSegMthd 567
DCDMNewSegSingTil 569
DCDMPCBSpdUp 563
DCDMPosDiffAllwd 551
DCDMRctFld 608
DCDMRedundantCodes 566
DCDMRescnTPat 583
DCDMSpeedOpt 559
DCDMTolErrLPat 556
DCDMTolErrTPat 558
DCDMTolLDef 562
DCDMTxtSpdUp 564
DCDMVerISO15415 580
DCDMVerISO16022 579
DCDMWeakBitAllwd 554
DCDMWeakBitEna 550
DCDMWeakBitThr 555
DCDS1FixLen 526
DCEAN1281stFc1 343
DCEAN128Act 377
DCEAN128InsFc1 344
DCEAN13Act 388
DCEAN8Act 381
DCEANUPCTrCd 285
DCEnaSMART 373
DCEnNoreadCo 1948
DCFam128Act 390
DCGDirection 1950
DCGLSAngSt 1972
DCGS114Enabled 515
DCGS12DCompMode 522
DCGS1Act 514
DCGS1EmuEnabled 525
DCGS1ExpEnabled 517
DCGS1HxAOut 523
DCGS1IntLen 528
DCGS1LimEnabled 518
DCGS1Min3AdjSegm 529
DCGS1ModWidthTol 531
DCGS1Mr 521
DCGS1OutVrfr 532
DCGS1StackedAct 519
DCGS1UndecSymbls 534
DCMCAct 615
DCMCMd2Act 619
DCMCMd3Act 624
DCMCMd4Act 622
DCMCMd5Act 623
DCMCMd6Act 620
DCMCMdPM 616
DCMCVeriEna 618
DCMSIPlesseyAct 493
DCMSIPlesseyCdTst 496
DCMSIPlesseyFixLen 500
DCMSIPlesseyIntLen 501
DCMSIPlesseyLenMode 498

© SICK AG - Germany - All rights reserved

DCMSIPlesseyMr 494
DCMSIPlesseyTrCd 497
DCPCAct 392
DCPCDepSym 393
DCPCOrint 396
DCPCPAstrlFixLen 432
DCPCPAstrlIntLen 434
DCPCPAstrlLenMode 431
DCPCPAstrlZrFCC 435
DCPCPcDpi 395
DCPCPJpnFixLen 428
DCPCPJpnIntLen 429
DCPCPJpnLenMode 426
DCPCPKixFixLen 399
DCPCPKixIntLen 401
DCPCPKixLenMode 398
DCPCPRMInfmlAct 414
DCPCPRMInfmlFixLen 417
DCPCPRMInfmlIntLen 419
DCPCPRMInfmlLenMode 416
DCPCPRMMailmarkAct 402
DCPCPRMMailmarkFixLen 405
DCPCPRMMailmarkIntLen 407
DCPCPRMMailmarkLenMode 404
DCPCPRMPSAct 420
DCPCPRMPSFixLen 423
DCPCPRMPSIntLen 425
DCPCPRMPSLenMode 422
DCPCPRMRM4SCCAct 408
DCPCPRMRM4SCCFixLen 411
DCPCPRMRM4SCCIntLen 413
DCPCPRMRM4SCCLenMode 410
DCPCPSwdnFixLen 459
DCPCPSwdnIntLen 460
DCPCPSwdnLenMode 457
DCPCRaw2StatAct 462
DCPCRaw2StatFixLen 465
DCPCRaw2StatIntLen 466
DCPCRaw2StatLenMode 463
DCPCRaw4StatAct 468
DCPCRaw4StatFixLen 471
DCPCRaw4StatIntLen 472
DCPCRaw4StatLenMode 469
DCPCSwftPRMInfmlAct 477
DCPCSwftPRMMailmarkAct 474
DCPCSwftPRMRM4SCCAct 475
DCPCSwftUSPPLAct 479
DCPCSwftUSPPNAct 478
DCPCSwftUSPUPUAct 481
DCPCSwftUSPUsps4SAct 482
DCPCUSPFixLen 442
DCPCUSPIntLen 444
DCPCUSPLenMode 441
DCPCUSPPLAct 439
DCPCUSPPNAct 437
DCPCUSPPNBnBFld 438
DCPCUSPUPUAct 445
DCPCUSPUPUFixLen 448
DCPCUSPUPUIntLen 450
DCPCUSPUPULenMode 447
DCPCUSPUsps4SAct 451
DCPCUSPUsps4SFixLen 454
DCPCUSPUsps4SIntLen 456
DCPCUSPUsps4SLenMode 453
DCPDF417Act 610
DCPDF417Lvl 613
DCPDF417Tru 611
DCPhrm2Digits 364
DCPhrmAct 346
DCPhrmAddQZFact 367
DCPhrmBGAct 355
DCPhrmBSmax 358
DCPhrmBSmin 357
DCPhrmDecOut 371
DCPhrmGSmax 361
DCPhrmGSmin 360
DCPhrmLen 353
DCPhrmLenMode 351
DCPhrmLimTol 363
DCPhrmMdWdMd 348
DCPhrmMdWdUs 350
DCPhrmMr 347
DCPhrmPercQZScans 370
DCPhrmQZChck 366
DCPhrmQZDens 368
DCPhrmRev 354
DCPlesseyAct 484
DCPlesseyFixLen 489
DCPlesseyIntLen 491
DCPlesseyLenMode 488
DCPlesseyMr 485
DCPlesseyTrCd 487
DCQRAct 626
DCQRFixLen 630
DCQRFormatMode 636
DCQRGS1AIMark 640
DCQRGS1FirstCharReplace 637
DCQRGS1SepCharReplace 638
DCQRLenMode 629
DCQRLvl 634
DCQRMode 627
DCQRVerISO18004 633
DCTAct 697
DCTBlrWin 704
DCTClseDg 709
DCTClseX 710
DCTClseY 712
DCTDevLenX 713
DCTDevLenY 714
DCTDia 700
DCTelepenAct 503
DCTelepenFixLen 510
DCTelepenIntLen 512
DCTelepenLenMode 509
DCTelepenMode 506
DCTelepenMr 504
DCTelepenTrCd 507
DCTHeight 702
DCTimeOutput 1947
DCTOrient 698
DCTSauvK 706
DCTSauvR 708
DCTSauvWin 705
DCTWidth 701
DCUPCAAct 376
DCUPCEAct 385

© SICK AG - Germany - All rights reserved

DCUPCEANAct 382
DCUPCEANMr 279
DCUPCEANStartCharVal 289
DCUPCEANStopCharVal 287
DCUPCExt 283
DCUPCNumSys 286
DDigAct 1702
DDigBea 1709
DDigBlkSpc 1705
DDigExMoSz 1703
DDigGftCr 1713
DDigMaxBlk 1712
DDigMaxBlkAct 1710
DDigPerCor 1706
DDigTilt 1707
DDMAct 653
DDMAggr 654
DDMAllwRect 670
DDMBackground 676
DDMContrast 675
DDMCtrstTol 688
DDMDirection 673
DDMFndPtTol 686
DDMFxNmCds 658
DDMGeoDis 672
DDMMaxCell 661
DDMMaxCol 668
DDMMaxGapCol 685
DDMMaxGapRow 682
DDMMaxRow 664
DDMMaxSkw 679
DDMMinCell 660
DDMMinCol 666
DDMMinGapCol 683
DDMMinGapRow 680
DDMMinRow 662
DDMNmCds 657
DDMSmlCell 678
DDMTmout 656
DEBUG 2393
Decoding1DLevel 1966
DecodingTimeOutput 1947
DeleteImagesFromRam 1764
DeleteImagesFromSD 1763
DemoModeDPMDataMatrix 1914
DemoModeMaxiCode 1913
DemoModePDF417 1912
DemoModeROI 1910
DeShadingActive 1631
DeShadingIlluminationNonUniformity 1632
DEVICE_MODE 2397
DI1Control 96
DI1DebTim 94
DI1DebTrk 95
DI1Logic 92
DI1Sens 91
DI2Control 103
DI2DebTim 100
DI2DebTrk 102
DI2Logic 99
DI2Sens 98
DIAGContModCnt 1779
DIAGDate 1728
DIAGDecoProf 1774
DIAGDeviceName 1727
DIAGFileGRNR 1732
DIAGFileSysInfo 1735
DIAGFileTmStamp 1736
DIAGFTPImgFileCountModulo 1745
DIAGFTPImgFileCycleMethod 1744
DIAGHour 1729
DIAGImgFileName 1734
DIAGImgReduction 1776
DIAGImgSelection 1724
DIAGImgSelection2 1771
DIAGJpgComprEna 1772
DIAGJpgComprQual 1775
DIAGMinConveyorPathMM 1778
DIAGPathDevice 1725
DIAGPathGRNR 1731
DIAGSaveToSD 1747
DIAGSaveToSD2 1748
DIAGSDCardImgFileCountModulo 1739
DIAGSDCardImgFileCycleMethod 1738
DIAGSendToFTP 1750
DIAGSendToFTP2 1753
DIAGSendToFtpLs 1751
DIAGSendToSopas 1757
DIAGSendToSopas2 1759
DIAGSopasImgFileCountModulo 1742
DIAGSopasImgFileCycleMethod 1741
DIAGStoreCnd 1721
DIAGStoreCnd2 1768
DIAGStoreCndExt 1722
DIAGStoreCndExt2 1769
DIAGToFTPArchiv 1754
DIAGToFTPArchiv2 1756
DIAGtplstr 1781
DigimarcActive 1702
DigimarcBearing 1709
DigimarcBlockSpacing 1705
DigimarcExpectedModuleSize 1703
DigimarcGiftCard 1713
DigimarcMaxBlocksToRead 1712
DigimarcMaxBlocksToReadActive 1710
DigimarcPerspectiveCorrection 1706
DigimarcTilt 1707
DIHasFbConfigChanged 2268
DIlstmt 46
DInxtmt 47
DisableLiquidLensOutput 2345
DMDPMDmx 1914
DMMaxi 1913
DMPDF417 1912
DMRoi 1910
DO1Control 74
DO1DurTm 72
Do1DurTrk 73
DO1Fnc 87
DO1FncEvExt 66
DO1FncTIMCE 1219
DO1Logic 70
DO1Mode 185
DO1OffFnc 67
DO1OffFncEvExt 69
DO1Sc 190

© SICK AG - Germany - All rights reserved

DO1ScD 191
DO2Control 84
DO2DurTm 82
DO2DurTrk 83
DO2Fnc 86
DO2FncEvExt 76
DO2FncTIMCE 1221
DO2Logic 80
DO2Mode 186
DO2OffFnc 77
DO2OffFncEvExt 79
DO2Sc 193
DO2ScD 194
DO3Control 173
DO3DurTm 171
Do3DurTrk 172
DO3Fnc 198
DO3FncEvExt 165
DO3FncTIMCE 1222
DO3Logic 169
DO3Mode 187
DO3OffFnc 166
DO3OffFncEvExt 168
DO4Control 183
DO4DurTm 181
DO4DurTrk 182
DO4Fnc 197
DO4FncEvExt 175
DO4FncTIMCE 1224
DO4Logic 179
DO4Mode 189
DO4OffFnc 176
DO4OffFncEvExt 178
DoDiagReading 1125
DOExt1FncTIMCE 1226
DOExt2FncTIMCE 1227
DoMatchCodeTeachIn 1849
DoReadingGateDiag 1942
DOResOutTrig 195
DotCodeTobaccoActive 697
DotCodeTobaccoBlurWindow 704
DotCodeTobaccoCloseDiagonal 709
DotCodeTobaccoCloseX 710
DotCodeTobaccoCloseY 712
DotCodeTobaccoDeviationLengthX 713
DotCodeTobaccoDeviationLengthY 714
DotCodeTobaccoDotDiameter 700
DotCodeTobaccoHeight 702
DotCodeTobaccoOrientation 698
DotCodeTobaccoSauvolaK 706
DotCodeTobaccoSauvolaR 708
DotCodeTobaccoSauvolaWindow 705
DotCodeTobaccoWidth 701
DottedPostalCodes 1681
DPMCodeTypeChoice 651
DPMDataMatrixActive 653
DPMDataMatrixAllowRectangular 670
DPMDataMatrixCodeBackground 676
DPMDataMatrixCodeContrast 675
DPMDataMatrixCodeDirection 673
DPMDataMatrixContrastTolerance 688
DPMDataMatrixDecodingLevel 654
DPMDataMatrixFinderPatternTolerance 686
DPMDataMatrixFixedNumCodes 658
DPMDataMatrixGeometricDistortion 672
DPMDataMatrixMaxCellSize 661
DPMDataMatrixMaxGapCol 685
DPMDataMatrixMaxGapRow 682
DPMDataMatrixMaxNumCols 668
DPMDataMatrixMaxNumRows 664
DPMDataMatrixMaxSkew 679
DPMDataMatrixMinCellSize 660
DPMDataMatrixMinGapCol 683
DPMDataMatrixMinGapRow 680
DPMDataMatrixMinNumCols 666
DPMDataMatrixMinNumRows 662
DPMDataMatrixNumCodes 657
DPMDataMatrixSmallCells 678
DPMDataMatrixTimeout 656
DPMDecoderChoice 651
DPMQRModelType 690
DPMQRVersionMax 694
DPMQRVersionMin 691
DPSColorType 2391
DPSEna 2107
DPSEnaEx 2109
DPSFocDelay 2089
DPSFocPos 2086
DPSFocPosEx 2088
DpsFocusPositions 2086
DpsFocusPositionsExt 2088
DpsFocusPostSwitchDelayMs 2089
DPSIllu61xLedStates 2392
DPSMode 2082
DPSSet 2390
DPSSets 2091
DPSSetsEx 2092
DQRModelType 690
DQRVersionMax 694
DQRVersionMin 691
Dummy_FBParamEEprom_Type 2323
DumpIOMUX 2346
DYNAMIC 2393

E

E_USER_LEVEL_TYPE 2392
EAN128Active 377
EAN128FirstFC1Val 343
EAN128InsideFC1Val 344
EAN13Active 388
EAN8Active 381
EANUPCTransmitCheckDigit 285
eConveyorSpeed 2274
ED_AuxReadResultBarcodeType 2167
ED_AuxReadResultFrameRxHeader 2169
ED_AuxReadResultFrameRxTerminator 2170
ED_DataForwardDestination 2160
ED_DataForwardFrameRxHeader 2161
ED_DataForwardFrameRxTerminator 2163
ED_DataForwardFrameTxHeader 2164
ED_DataForwardFrameTxTerminator 2166
ED_DataStringAcqDefault 2172
ED_DataStringAcqFrameRxHeader 2173
ED_DataStringAcqFrameRxTerminator 2174
EDAcqDf 2172

© SICK AG - Germany - All rights reserved

EDAcqRFH 2173
EDAcqRFT 2174
EDArsRFH 2169
EDArsRFT 2170
EDArsTy 2167
EDFwDs 2160
EDFwRFH 2161
EDFwRFT 2163
EDFwTFH 2164
EDFwTFT 2166
EI1AddrMode 1089
EI1AuxInp 1338
EI1AuxPort 1092
EI1AuxProt 1090
EI1Control 239
EI1DebTim 236
EI1DebTrk 237
EI1DHCPFallback 1088
EI1gate 1083
EI1IpAddr 1082
EI1Logic 234
EI1mask 1085
EI1Sens 233
EI1SpdDpx 1086
EI2Control 246
EI2DebTim 243
EI2DebTrk 244
EI2Logic 242
EI2Sens 240
EIAddrMode 1065
EIAuxInp 2158
EIAuxPort 1047
EIAuxProt 1046
EIDHCPFallback 1067
EIEnaEth1 1335
EIgate 1023
EIHstCola 1040
EIHstEnHB 1042
EIHstFTPClntPasWd 1032
EIHstFTPClntUpPath 1033
EIHstFTPClntUsrNm 1031
EIHstFTPProt 1029
EIHstHBInt 1043
EIHstInp 2157
EIHstMux 1035
EIHstPort 1037
EIHstProt 1028
EIHstRetrHB 1044
EIHstSrvAddr 1039
EIHstSrvClnt 1036
EIIpAddr 1022
EImask 1025
EImonCAN1 1062
EImonCAN2 1064
EImonou1 1054
EImonou2 1056
EImonseraux 1057
EImonseraux2 1060
EImonserhost 1058
EImonserhost2 1061
EIPAct 1311
EIPAssemblySizeInput 1323
EIPAssemblySizeOutput 1321
EIPAsSizeIn 1323
EIPAsSizeOut 1321
EIPCMCtrlOut 2297
EIPCMCtrlOutMask 1316
EIPControlBitsPlcOut 2297
EIPControlBitsPlcOutMask 1316
EIPDataFormat 1315
EIPHBEna 1317
EIPHBInt 1319
EIPHBInterval 1319
EIPInterf 1336
EIPInterface 1336
EIPMode 1312
EIPMultiplex 1313
EIPRetrHB 1320
EIPTxBufferSize 1324
EIPTxBufSize 1324
EIRDTID 1050
EIRDTPort 1051
EIRDTSrvAddr 1053
EIRDTSrvClnt 1049
EISpdDpx 1026
EIUDPCola 1071
EIUDPPort 1069
EIUpdtNdd 1068
Emphasize1D 1958
EnableActiveScript 1342
EnableImageQueueTimeout 2116
EnableImgQueueTimeout 2116
EnableLineFeedMode 1952
EnableNciiForEveryNoReadImage 1948
EnableOptimizeObjCap 2119
EnableSkipImageByQueueSize 2117
EnableSMARTDecoder 373
EnableSysOptiParam 2138
EnableSystemOptimizingParameter 2138
EnaOptObjectCap 2119
EnaPosDependingDeshading 1815
EnaSkipImgByQueueSize 2117
EndDiagReading 1128
EO1Control 218
EO1DurTm 215
EO1DurTrk 216
EO1Fnc 208
EO1FncEvExt 209
EO1Logic 214
EO1OffFnc 211
EO1OffFncEvExt 212
EO2Control 229
EO2DurTm 227
EO2DurTrk 228
EO2Fnc 219
EO2FncEvExt 221
EO2Logic 225
EO2OffFnc 222
EO2OffFncEvExt 224
EParUse 1333
EPSSource 2085
ERROR 2393
ErrStructType 2373
ErrTimeType 2373
ESys 2335
Ether1AddressingMode 1089

© SICK AG - Germany - All rights reserved

Ether1AuxInputHandling 1338
Ether1AuxIPPort 1092
Ether1AuxProtocol 1090
Ether1DHCPFallback 1088
Ether1Enable 1335
Ether1IPAddress 1082
Ether1IPGateAddress 1083
Ether1IPMask 1085
Ether1IPSpeedDuplex 1086
EtherAddressingMode 1065
EtherAuxInputHandling 2158
EtherAuxIPPort 1047
EtherAuxProtocol 1046
EtherDHCPFallback 1067
EtherHostCoLaDialect 1040
EtherHostCustomProtNb 1232
EtherHostEnHB 1042
EtherHostFTPPassword 1032
EtherHostFTPProtocol 1029
EtherHostFTPUploadPath 1033
EtherHostFTPUsername 1031
EtherHostHBInterval 1043
EtherHostInputHandling 2157
EtherHostIPPort 1037
EtherHostIPServerAddress 1039
EtherHostMultiplex 1035
EtherHostProtocol 1028
EtherHostRetrHB 1044
EtherHostServerClient 1036
EtherIPAddress 1022
EtherIPGateAddress 1023
EtherIPMask 1025
EtherIPSpeedDuplex 1026
EtherMonCAN1 1062
EtherMonCAN2 1064
EtherMonOutputFormat1 1054
EtherMonOutputFormat2 1056
EtherMonSerAux 1057
EtherMonSerAux2 1060
EtherMonSerHost 1058
EtherMonSerHost2 1061
ETHERNET 2405
ETHERNET_GENERAL 2405
ETHERNETIP 2400
EthernetPing 1072
EthernetUpdate 1073
EtherRDT_ID 1050
EtherRDTIPPort 1051
EtherRDTIPServerAddress 1053
EtherRDTServerClient 1049
EtherUDPCoLaDialect 1071
EtherUDPIPPort 1069
EtherUpdateNeeded 1068
ETHstCstProtNb 1232
eUsePredConnSetType 2376
EVCheckEvtAct 2293
EVCheckMaxNbr 849
EVCheckMinNbr 846
EVchkmax 849
EVchkmin 846
EVcndnames 859
EVcond 857
EVCondtionDiag 852
EVCondtionNames 859
EVCondtions 857
EVdiag 852
Event: ASAllOperationsFinished 1875
Event: cdpApiErrorEvent 1366
Event: cdpApiRstToFactorySettingsEvent 1367
Event: cdpApiWarningEvent 1366
Event: FlashDutyCycleViolation 1626
Event: ImageDeleteStatus 1767
Event: ImageUploadStatus 1766
Event: ImgBlobTransfer 1766
Event: OCR3CharStatistics 773
EVMainGoodReadStruct 843
EVmaxcodes 847
EVMaxNbrCodes 847
EVmincodes 844
EVMinNbrCodes 844
EVMonCheck 2293
EVrebnoread 854
EVrebnoreadcnt 855
EVRebootOnNoreadCntr 855
EVRebootOnNoreadEnable 854
EVSetMatchCode 860
EVstrgoodr 843
EVuserdefcndnames 850
EVUserDefCondtionNames 850
ExecFpgaDeveloperCommand 2347
ExecuteDownload 60
ExecutePBCmd 2315
ExpanderScannerHRPosAlpha 1835
ExpanderScannerHRPosBeta 1836
ExpanderScannerHRPosGamma 1838
ExpanderScannerHRPosXCoord 1839
ExpanderScannerHRPosYCoord 1841
ExpanderScannerHRPosZCoord 1842
ExpanderScannerPosAlpha 1826
ExpanderScannerPosBeta 1827
ExpanderScannerPosGamma 1829
ExpanderScannerPosXCoord 1830
ExpanderScannerPosYCoord 1832
ExpanderScannerPosZCoord 1833
ExpHRPosAlpha 1835
ExpHRPosBeta 1836
ExpHRPosCoordX 1839
ExpHRPosCoordY 1841
ExpHRPosCoordZ 1842
ExpHRPosGamma 1838
ExpNodalPoseAlphaOpti 1896
ExpNodalPoseBetaOpti 1897
ExpNodalPoseGammaOpti 1899
ExpNodalPoseXCoordOffset 1900
ExpNodalPoseYCoordOffset 1902
ExpNodalPoseZCoordOffset 1903
ExpPosAlpha 1826
ExpPosBeta 1827
ExpPosCoordX 1830
ExpPosCoordY 1832
ExpPosCoordZ 1833
ExpPosGamma 1829
ExtDataStringDefault 870
ExtDatStrDflt 870
ExtDevEEwrite 163
ExtDevFacDflt 161

© SICK AG - Germany - All rights reserved

ExtDeviceLoadFactoryDefaults 161
ExtDeviceWriteEeprom 163
ExtendedSegmentation 374
EXTERNAL_DEVICES 2396
ExternalIlluminationMode 1582
ExternalLightConnectorMode 1584
ExtOut1Control 218
ExtOut1DurTime 215
ExtOut1DurTrack 216
ExtOut1Func 208
ExtOut1FuncEvCndExt 209
ExtOut1FuncTeachInMatchCodeEnh 1226
ExtOut1Logic 214
ExtOut1OffFunc 211
ExtOut1OffFuncEvCndExt 212
ExtOut2Control 229
ExtOut2DurTime 227
ExtOut2DurTrack 228
ExtOut2Func 219
ExtOut2FuncEvCndExt 221
ExtOut2FuncTeachInMatchCodeEnh 1227
ExtOut2Logic 225
ExtOut2OffFunc 222
ExtOut2OffFuncEvCndExt 224
ExtSensor1Control 239
ExtSensor1DebounceTime 236
ExtSensor1DebounceTrack 237
ExtSensor1Logic 234
ExtSensor1Sensitivity 233
ExtSensor2Control 246
ExtSensor2DebounceTime 243
ExtSensor2DebounceTrack 244
ExtSensor2Logic 242
ExtSensor2Sensitivity 240

F

FATALERROR 2393
FBLEDRedDuration 2018
FBLEDRedFunc 2015
FBLEDRedFuncExt 2016
FCAct 1643
FCbehv 1639
FCctrlmd 1636
FCDist 1644
FCFocusDelayTime 1647
FCFocusDelayTrack 1649
FCLTRHyst 1664
FCLTRManOff 1668
FCLTRNodeID 1662
FCLTRPostExpation 1666
FCLTRUsFrontRearFocus 1669
FCLTRXOffset 1665
FCMLGIsMLGMaster 1658
FCMLGIsUpsideDown 1661
FCMLGNodeID 1660
FCMLGZDistBeams 1657
FCMLGZDistDeviceBeamLow 1655
FCPostExpTm 1653
FCPostExpTrk 1654
FCPreExpTm 1650
FCPreExpTrk 1651
FCSensIn 1646
FCSrc 1637
FCTmTm 1640
FCTmTrk 1641
FeedbackLedRedDuration 2018
FeedbackLedRedFunc 2015
FeedbackLedRedFuncExt 2016
FILESYSTEM 2405
FILESYSTEM_GENERAL 2405
FILESYSTEM_LECTOR 2399
FileSystemAccess 1129
FinishAimDpmCalib 650
FinishAutoSetup 1873
FinishDemoMode 1918
FinishDownload 63
FinishPoseEstimation 1909
FIOSDesc 2272
FlashDutyCycleViolation 1626
FlashFrequencyControlEnable 1625
FlashFrequencyControlLevel 1612
FOCUS 2393
FocusControlActive 1643
FocusControlBehavior 1639
FocusControlDistances 1644
FocusControlFocusDelayTime 1647
FocusControlFocusDelayTrack 1649
FocusControlLTRHysteresis 1664
FocusControlLTRManualOffset 1668
FocusControlLTRNodeID 1662
FocusControlLTRPostExpation 1666
FocusControlLTRUsFrontRearFocus 1669
FocusControlLTRXOffset 1665
FocusControlMLGIsMLGMaster 1658
FocusControlMLGIsUpsideDown 1661
FocusControlMLGNodeID 1660
FocusControlMLGZDistBeams 1657
FocusControlMLGZDistDeviceBeamLow 1655
FocusControlMode 1636
FocusControlPostExpansionTime 1653
FocusControlPostExpansionTrack 1654
FocusControlPreExpansionTime 1650
FocusControlPreExpansionTrack 1651
FocusControlSensorInput 1646
FocusControlSource 1637
FocusControlTimerTime 1640
FocusControlTimerTrack 1641
FocusPosition 1606
FPGA 2401
FrameRate 1608
FTAClientTimeout 1258
FTALocalFileTimeout 1259
FTAMaxClients 1256
FTAMaxObj 1260
FTAPasWd 1252
FTASendBufSize 1255
FTASvrPrt 1254
FTAUsrNm 1251
FTAuthMet 1242
FTClntAct 1234
FTClntDevUpPath 1249
FTClntPasWd 1245
FTClntUpPath 1247
FTClntUsrNm 1243
FTEthIf 1239

© SICK AG - Germany - All rights reserved

FTHstNm 1238
FTPArchibPassword 1252
FTPArchiveClientTimeout 1258
FTPArchiveIPPort 1254
FTPArchiveMaxClients 1256
FTPArchiveMaxNumObjects 1260
FTPArchiveSendBufferSize 1255
FTPArchiveSLocalFileTimeout 1259
FTPArchivUsername 1251
FTPAuthenticationMethod 1242
FTPClientActive 1234
FTPDevUpload 1249
FTPEthIface 1239
FTPHostname 1238
FTPPassword 1245
FTPPathPrivateKey 1246
FTPProtocol 1241
FTPrivKey 1246
FTPRootPath 1080
FTProt 1241
FTPSEnable 1075
FTPServerIPAddress 1235
FTPServerIPPort 1237
FTPSPort 1079
FTPSRootPath 1080
FTPSrvEnabled 1075
FTPSrvPort 1079
FTPSrvUsrName 1078
FTPSrvUsrPassword 1076
FTPSUsrNm 1078
FTPSUsrPasWd 1076
FTPUploadPath 1247
FTPUsername 1243
FTSvrAdr 1235
FTSvrPrt 1237

G

GammaCorrectionTurningPoint10bit 1575
GatewayDNAddress 1288
GatewayDNBaudrate 1293
GatewayDNDevIDIsDNAdress 1290
GatewayDNInputDataLength 1294
GatewayDNOpMode 1291
GatewayDNOutputDataLength 1296
GatewayPBAddress 1285
GatewayPBDevIDIsPBAdress 1284
GatewayPBOpMode 1287
GatewaySerAux 1281
GatewaySerHost 1282
GenCloseFile 19
GENERAL 2401
GeneralImgOutActive 2350
GenOpenFile 18
GenReadFile 20
GenWriteFile 22
GetAccessMode 6
GetBlobClientConfig 2332
GetChallenge 11
GetCurrentFrameRate 1611
GetDescription 8
GetEffectiveImageSize 2269
GetFileSize 25
GetFileSyncValue 24
GetFocusPositionIs 2337
GetImagesFromRam 1761
GetImagesFromSD 1760
GetIncrement 1925
GetIncrementMM 1926
GetMMPerPixel 2342
GetMotorPos 2344
GetMotorPosMinMax 2338
GetMotorRotationAngle 2341
GetTime 1189
GlsCodeSel 1968
GlsCodeSelection 1968
GLSIncreaseAngleStability 1972
GoodReadLedDuration 2010
GoodReadLedFunc 2013
GoodReadLedFuncExt 2009
GRLEDDuration 2010
GRLEDFunc 2013
GRLEDFuncExt 2009
GS114Enabled 515
GS12DComponentMode 522
GS1DataBarActive 514
GS1DataBarStackedCodesActive 519
GS1EmulationEnabled 525
GS1ExpandedEnabled 517
GS1FixLenList 526
GS1HexASCIIOutput 523
GS1IntLenList 528
GS1LimitedEnabled 518
GS1Min3AdjacentSegments 529
GS1ModuleWidthTolerance 531
GS1MultiRead 521
GS1NorcaIssueUndecodableSymbols 534
GS1NorcaOutputVerifier 532
GWDNAddr 1288
GWDNBdRt 1293
GWDNdevIDDNAdr 1290
GWDNInDtL 1294
GWDNOpMd 1291
GWDNOutDtL 1296
GWPBAddr 1285
GWPBdevIDPBAdr 1284
GWPBOpMd 1287
GWSerAuxMd 1281
GWSerHstMd 1282

H

HasFieldbusConfigChanged 2268
HeartbeatString 823
HMIAllowMatchCodeTeachIn 1996
HMIAllowTeachIn 1996
HMIASChangeCode 2000
HMIASChangeFocus 1997
HMIASChangeImage 1999
HMIAutoSetupChangeCode 2000
HMIAutoSetupChangeFocus 1997
HMIAutoSetupChangeImage 1999
HMIBtnsMode 2002
HMIButtonMode 2002
HTWebserverEnabled 1279
HTWSAct 1279

© SICK AG - Germany - All rights reserved

I

ICdist 1920
ICFixVel 1922
ICincdist 1923
ICsrc 1919
IlluFeedback 2012
IlluminationForFeedback 2012
IlluOffDelayEnable 1619
IlluOffDelayTime 1620
IlluSyncDevDelayMs 1617
IlluSyncEnable 1616
IMAGE_LOGGING_UPLOAD 2398
ImageAcqROI 1589
ImageBinningMode 1602
ImageDeleteStatus 1767
ImageMirroring 1593
IMAGEOUTPUT 2395
ImageQueueTimeoutMM 2113
ImageQueueTimeoutMS 2115
ImageResolution 1591
ImageUploadStatus 1766
ImageVerticalFlip 1592
IMG_ACQ_CTRL 2396
IMG_SENSOR_ACQ_DRIVER 2393
ImgAcqBurstModeNumImages 1569
ImgAcqMode 1567
ImgBlobTransfer 1766
ImgDiagContinuousModCnt 1779
ImgDiagFileGoodReadNoRead 1732
ImgDiagFileName 1734
ImgDiagFileSystemInfo 1735
ImgDiagFileTimestamp 1736
ImgDiagFTPArchiv 1754
ImgDiagFTPArchiv2 1756
ImgDiagFTPFileCycleMethod 1744
ImgDiagFTPFileCycleModulo 1745
ImgDiagImageOutReduction 1776
ImgDiagImageSelection 1724
ImgDiagImageSelection2 1771
ImgDiagJpegCompressionEnabled 1772
ImgDiagJpegCompressionQuality 1775
ImgDiagMinConveyingPathMM 1778
ImgDiagNameTemplateString 1781
ImgDiagPathDate 1728
ImgDiagPathDevice 1725
ImgDiagPathDeviceName 1727
ImgDiagPathGoodReadNoRead 1731
ImgDiagPathHour 1729
ImgDiagSaveToSDCard 1747
ImgDiagSaveToSDCard2 1748
ImgDiagSDCardFileCycleMethod 1738
ImgDiagSDCardFileCycleModulo 1739
ImgDiagSendFTP 1750
ImgDiagSendFTP2 1753
ImgDiagSendFTPLegacyStyle 1751
ImgDiagSendSopas 1757
ImgDiagSendSopas2 1759
ImgDiagSopasFileCycleMethod 1741
ImgDiagSopasFileCycleModulo 1742
ImgDiagStoreCondition 1721
ImgDiagStoreCondition2 1768
ImgDiagStoreConditionExt 1722
ImgDiagStoreConditionExt2 1769
ImgQueueTimeoutMM 2113
ImgQueueTimeoutMS 2115
IncrDistance 1920
IncrDistribute 1923
IncrFixVelocity 1922
IncrSource 1919
INFO 2393
InterchangeableLensfNumber 1715
InterchangeableLensfStr 1716
InterchangeableLensTransmission 1719
InterchangeableLensType 1718
InternalIlluminationColor 1581
InternalIlluminationMode 1579
InvalidIndex 1120
IpAddressChoiceForImageTransmission 1345

L

L61xIlluInt 1629
L61xIlluLEDStat1 1627
L61xIlluminationIntensity 1629
L61xIlluminationLEDStates1 1627
LabelAssFix 783
LabelAssMax 782
LabelAssTol 781
LabelPosTolerance 2112
LabelTimoutTime 811
LabelTimoutTimeActive 810
LabelTimoutTrack 813
LaeDevName 2266
LaeSerNum 2265
LaetusDeviceName 2266
LaetusSerialNumber 2265
LastMaintenance 46
LblPosTlrc 2112
LECTOR65x 2393
LECTOR6xx 2396
LedTimeout 1587
LedTimeoutEnabled 1603
LineFeedModeHorizontalScans 1953
LineFeedModeNumScansInImage 1955
LoadApplicationDefaults 36
LoadApplicationDefaultsSystemSlave 1340
LoadFactoryDefaults 35
LocationName 3
LogEnd 41
LogErase 43
LogfCtrlDestinationSDCardActive 1790
LogfCtrlDiagFileName 1799
LogfCtrlDiagFormatTimestamp 1800
LogfCtrlDiagPathDate 1796
LogfCtrlDiagPathDevice 1793
LogfCtrlDiagPathDeviceName 1795
LogfCtrlDiagPathHour 1797
LogfCtrlRamMaxStorageSpaceMB 1789
LogfCtrlSDCardMaxStorageSpaceMB 1792
LogfCtrlSourceEthernetAuxActive 1787
LogfCtrlSourceEthernetHostActive 1786
LogfCtrlSourceSerialAuxActive 1784
LogfCtrlSourceSerialHostActive 1783
LogfCtrlStartLogging 1801
LogfCtrlStopLogging 1802

© SICK AG - Germany - All rights reserved

LOGFDIAGDate 1796
LOGFDIAGDestinationSDCardActive 1790
LOGFDIAGDeviceName 1795
LOGFDIAGFrmtTmStamp 1800
LOGFDIAGHour 1797
LOGFDIAGLogFileName 1799
LOGFDIAGPathDevice 1793
LOGFDIAGRamMaxStorageSpaceMB 1789
LOGFDIAGSDCardMaxStorageSpaceMB 1792
LOGFDIAGSourceEthernetAuxActive 1787
LOGFDIAGSourceEthernetHostActive 1786
LOGFDIAGSourceSerialAuxActive 1784
LOGFDIAGSourceSerialHostActive 1783
LogInfo 42
LogisticsFalsePositiveFilter 1696
LogWrite 40

M

MAIN 2394
ManualBlobIpAddress 1348
ManualBlobTcpPort 1349
mAPCReset 2080
mAPCStore 2081
mASCalcShutTime 1874
mASCancel 1872
mASFinish 1873
mASLCancelPoseEstimation 1908
mASLCFinishPoseEstimation 1909
mASLStartPoseEstimation 1905
mASLStartPoseEstimationPanorama1of2 1906
mASLStartPoseEstimationPanorama2of2 1907
mASStart 1871
MAX14820ReadRegisters 2356
MAX14820WriteRegisters 2357
MaxCodesPerRegion1D 1678
MaxiCodeActive 615
MaxiCodeMode2Active 619
MaxiCodeMode3Active 624
MaxiCodeMode4Active 622
MaxiCodeMode5Active 623
MaxiCodeMode6Active 620
MaxiCodePrimaryMessage 616
MaxiCodeVerifierEnable 618
MaxIndexValue 1119
MaxModuleSize2DMM 542
MaxNum1DCodes 1688
MaxNum1DCodesEnabled 1687
MaxNumDMxCodes 1689
MaxNumDMxCodesEnabled 1699
MaxNumMaxiCodes 1693
MaxNumMaxiCodesEnabled 1692
MaxNumQRCodes 1691
MaxNumQRCodesEnabled 1697
MaxTolerance3D 787
mBWDCopyParam 2230
mCAMGetCurrFrameRate 1611
mCDF_EraseParamFile 2369
mCDF_FlashParamFile 2368
mCDF_RdParamSeg 2365
mCDF_WrParamSeg 2366
mcdpApiUpDateDiagExt 1369
mcdpPnioUpdPnConfig 1389
mClearCuckoo 2355
MCMountingAngleAlphaCompensationActive 1971
mDBGMTraceStop 2349
mDIAGCancelDel 1765
mDIAGCancelImgUpload 1762
mDIAGDelImagesFromRam 1764
mDIAGDelImagesFromSD 1763
mDIAGGetImagesFromRam 1761
mDIAGGetImagesFromSD 1760
mDIBootCdf 2270
mDIGetEffImgSize 2269
mDIReadInput 104
mDIsetlast 49
mDMCancel 1917
mDMFinish 1918
mDMStart 1916
mDOSetOutput 89
mDumpIOMUX 2346
mEEreadall 27
mEEwriteall 28
mEIReadInput 247
mEOSetOutput 231
mEPSActSet 2110
Method: AbortDownload 64
Method: ActivateEPSSet 2110
Method: ASCalculateShutterTime 1874
Method: BlobServerGetStatistics 2326
Method: BlobServerResetLocalStatistics 2329
Method: BootupCDF 2270
Method: BWDCopyParam 2230
Method: CancelAimDpmCalib 649
Method: CancelAutoSetup 1872
Method: CancelDemoMode 1917
Method: CancelImageDeletion 1765
Method: CancelImageUpload 1762
Method: CancelPoseEstimation 1908
Method: CDF_EraseParameterFile 2369
Method: CDF_FlashParameterFile 2368
Method: CDF_ReadParameterSetSegment 2365
Method: CDF_WriteParameterSetSegment 2366
Method: CdfProfinetApplyButton 140
Method: CdfProfinetEeWriteOnlyIntern 106
Method: CdfProfinetResetToFactory 107
Method: CdfUpDatePnConfig 1181
Method: cdpApiRequestTracepointInfo 1370
Method: cdpApiStoreParams 1368
Method: cdpApiTracerSetTPProp 1372
Method: cdpApiUpDateDiagExt 1369
Method: cdpPnioUpDatePnConfig 1389
Method: ChangePassword 13
Method: CheckPassword 16
Method: CheckSdCard 1195
Method: ConnectTimeServer 1191
Method: CuckooImageClear 2355
Method: CuckooImageLoad 2354
Method: DeleteImagesFromRam 1764
Method: DeleteImagesFromSD 1763
Method: DisableLiquidLensOutput 2345
Method: DoDiagReading 1125
Method: DoMatchCodeTeachIn 1849
Method: DoReadingGateDiag 1942
Method: DumpIOMUX 2346
Method: EndDiagReading 1128

© SICK AG - Germany - All rights reserved

Method: EthernetPing 1072
Method: EthernetUpdate 1073
Method: EVSetMatchCode 860
Method: ExecFpgaDeveloperCommand 2347
Method: ExecuteDownload 60
Method: ExecutePBCmd 2315
Method: FileSystemAccess 1129
Method: FinishAimDpmCalib 650
Method: FinishAutoSetup 1873
Method: FinishDemoMode 1918
Method: FinishDownload 63
Method: FinishPoseEstimation 1909
Method: GenCloseFile 19
Method: GenOpenFile 18
Method: GenReadFile 20
Method: GenWriteFile 22
Method: GetAccessMode 6
Method: GetBlobClientConfig 2332
Method: GetChallenge 11
Method: GetCurrentFrameRate 1611
Method: GetDescription 8
Method: GetEffectiveImageSize 2269
Method: GetFileSize 25
Method: GetFileSyncValue 24
Method: GetFocusPositionIs 2337
Method: GetImagesFromRam 1761
Method: GetImagesFromSD 1760
Method: GetIncrement 1925
Method: GetIncrementMM 1926
Method: GetMMPerPixel 2342
Method: GetMotorPos 2344
Method: GetMotorPosMinMax 2338
Method: GetMotorRotationAngle 2341
Method: GetTime 1189
Method: LoadApplicationDefaults 36
Method: LoadApplicationDefaultsSystemSlave 1340
Method: LoadFactoryDefaults 35
Method: LogEnd 41
Method: LogErase 43
Method: LogfCtrlStartLogging 1801
Method: LogfCtrlStopLogging 1802
Method: LogInfo 42
Method: LogWrite 40
Method: MAX14820ReadRegisters 2356
Method: MAX14820WriteRegisters 2357
Method: Method_4 1341
Method: mGetDevModsPending 2282
Method: mGetDevModsRunning 2281
Method: mGetMatch 863
Method: MLGTeachIn 1673
Method: mSetMatch 861
Method: mTestCode 2279
Method: NotifyMode 5
Method: OCR3DeleteChar 771
Method: OCR3DeleteFont 766
Method: OCR3GetCharInfo 769
Method: OCR3OCVInput 768
Method: OCR3ResetCharStatistics 772
Method: OCR3SetFielding 767
Method: OCRPopParams 731
Method: OCRPushParams 730
Method: ProgramConfigData 56
Method: ProgramData 58
Method: ReadEeprom 27
Method: ReadExtInput 247
Method: ReadingGateOff 1122
Method: ReadingGateOffDiag 1124
Method: ReadingGateOn 1121
Method: ReadingGateOnDiag 1123
Method: ReadInput 104
Method: RebootDevice 34
Method: RepairSdCard 1196
Method: RequestFrameStatistics 2351
Method: RequestOCRInformation 732
Method: ResetAppCounter 2080
Method: ResetStatisticDisplay 2277
Method: RSClearStat 1215
Method: Run 7
Method: ScriptCommand 1343
Method: SelfTest 38
Method: SetAccessMode 4
Method: SetDeviceIdle 1943
Method: SetExtOutput 231
Method: SetIncrement 1924
Method: SetLastUser 49
Method: SetMotorPosAbsolute 2339
Method: SetMotorPosRelative 2340
Method: SetOutput 89
Method: SetPassword 15
Method: SetPasswordDefaults 37
Method: SetTestErrorError 53
Method: SetTestErrorFatalError 54
Method: SetTestErrorInfo 51
Method: SetTestErrorWarning 52
Method: SetTime 1190
Method: SetUserLevel 12
Method: ShippPrepStart 2258
Method: ShippPrepStop 2259
Method: ShippSnapNegativeFeedback 2257
Method: ShippSnapPositiveFeedback 2256
Method: ShippSnapStart 2255
Method: SoftReset 33
Method: Start2ndStageLoader 39
Method: StartAimDpmCalib 648
Method: StartAutoSetup 1871
Method: StartContinuousHallSensorMeasurement 1197
Method: StartDemoMode 1916
Method: StartDiagReading 1127
Method: StartHallSensorSingleshotMeasurement 1199
Method: StartLiveImageMode 2283
Method: StartMemCardUpdate 45
Method: StartModeDigIoCondition1 200
Method: StartModeDigIoCondition2 202
Method: StartModeDigIoCondition3 204
Method: StartModeDigIoCondition4 206
Method: StartPercentageEvaluation 1944
Method: StartPoseEstimation 1905
Method: StartPoseEstimationPanoramaHood1of2 1906
Method: StartPoseEstimationPanoramaHood2of2 1907
Method: StaticImageAcquire 2291
Method: StaticImageProcess 2292
Method: StaticImageStart 2289
Method: StaticImageStop 2290
Method: StatusDownload 61
Method: StopHallSensorMeasurements 1198
Method: StopLiveImageMode 2284

© SICK AG - Germany - All rights reserved

Method: StopModeDigIoCondition1 201
Method: StopModeDigIoCondition2 203
Method: StopModeDigIoCondition3 205
Method: StopModeDigIoCondition4 207
Method: StopPercentageEvaluation 1945
Method: StoreAppCounter 2081
Method: SwitchDynRdCfgDistance 1671
Method: SwitchDynRdCfgTableIndex 1670
Method: SystemConfigData 55
Method: TemperatureGetValues 2358
Method: ToFContinuousMeasurementStart 2363
Method: ToFSingleshotStart 2362
Method: ToFStopAllMeasurements 2364
Method: TracingStop 2349
Method: UmountSdCard 1194
Method: vCdfUpDatePnConfig 2316
Method: WriteEeprom 28
Method_4 1341
mEthPing 1072
mEthUpdt 1073
mEVSetMatchCode 860
mExecFpgaDevCmd 2347
mFCDisableLiquidLensOutput 2345
mFCGetMotorPos 2344
mFCGetMotorRotationAngle 2341
mFCGetPixelPerMM 2342
mFCSetMotorPosAbs 2339
mFCSetMotorPosRelative 2340
mFDabrtdwnld 64
mFDexedwnld 60
mFDfindwnld 63
mFDlogend 41
mFDlogerase 43
mFDloginfo 42
mFDlogwrite 40
mFDprgcfgdata 56
mFDprgdata 58
mFDsrt2ndstgldr 39
mFDstadwnld 61
mFDstrMCupdt 45
mFDsyscfgdata 55
mFSAcc 1129
mGetDevModsPending 2282
mGetDevModsRunning 2281
mGetFocPosIs 2337
mGetInc 1925
mGetIncMM 1926
mGetMatch 863
MinModuleSize2DMM 539
MinTolerance3D 786
MLG 2395
MLGTeachIn 1673
mLIStart 2283
mLIStop 2284
mLoadCuckoo 2354
mLOGFDIAGStartLogging 1801
mLOGFDIAGStopLogging 1802
mMLGTeachIn 1673
mOCVInput 768
ModbusAddress 1327
ModbusCommandWord 2318
ModbusResultBuf 2319
ModbusResultChangeCtr 2321
ModbusTcpMode 1326
mOPGetMotorMinMax 2338
MorphologicalFilter 1578
MoTcpAddr 1327
MoTcpMode 1326
mPBCMexecCmd 2315
mRCMaCdTeach 1849
mRCSwDynDistance 1671
mRCSwDynTblIdx 1670
mRSClearStat 1215
mSCCdfUpDatePnConfig 1181
mSCloadappdef 36
mSCloadappdefsysslave 1340
mSCloadfacdef 35
mSCreboot 34
mScrptCmd 1343
mSCselftest 38
mSCsetpwdef 37
mSCsoftreset 33
mSDCheck 1195
mSDRepair 1196
mSDUmount 1194
mSetFielding 767
mSetInc 1924
mSetMatch 861
MSIPlesseyActive 493
MSIPlesseyCheckDigitTest 496
MSIPlesseyFixLenList 500
MSIPlesseyIntLenList 501
MSIPlesseyLengthMode 498
MSIPlesseyMultiRead 494
MSIPlesseyTransmitCheckDigit 497
mStartContinuousHallSensorMeasurement 1197
mStartHallSensorSingleshotMeasurement 1199
mStartModeDigIoCondition1 200
mStartModeDigIoCondition2 202
mStartModeDigIoCondition3 204
mStartModeDigIoCondition4 206
mStopHallSensorMeasurements 1198
mStopModeDigIoCondition1 201
mStopModeDigIoCondition2 203
mStopModeDigIoCondition3 205
mStopModeDigIoCondition4 207
mTCdodiagread 1125
mTCdogatediag 1942
mTCenddiagread 1128
mTCgateoff 1122
mTCgateoffdiag 1124
mTCgateon 1121
mTCgateondiag 1123
mTCsetidle 1943
mTCstartdiagread 1127
mTCstpperc 1945
mTCstrtperc 1944
mTestCode 2279
MTIChannel1Condition 1989
MTIChannel2Condition 1994
MTIChannelSettings1 1986
MTIChannelSettings2 1991
MTIChannelStopSettings1 1988
MTIChannelStopSettings2 1993
MTIChnl1Cnd 1989
MTIChnl1Stp 1988

© SICK AG - Germany - All rights reserved

MTIChnl1Stt 1986
MTIChnl2Cnd 1994
MTIChnl2Stp 1993
MTIChnl2Stt 1991
mTIConnectSrv 1191
MTIGeneralSettings 1984
MTIGnrlStt 1984
mTSetErrErr 53
mTSetErrFatal 54
mTSetErrInfo 51
mTSetErrWarn 52
MultiCodeCenterOffsetEnabled 1974
MultiCodeGridModuleSize 1969
mVDPMCancelCal 649
mVDPMFinishCal 650
mVDPMStartCal 648
mVIResetStatDisp 2277

N

NetDeviceID 1131
NETINTERFACE_LOGGING_UPLOAD 2400
NetMasterSlave 1132
NetMonAssignment1 1139
NetMonAssignment2 1142
NetMonDevList1 1141
NetMonDevList2 1143
NetMonTimeout 1145
NetMultiplexerAssignment 1137
NetServerList 1138
NetSlaveList 1135
NETWORK 2404
NETWORK_GENERAL 2404
NETWORK_MONITOR 2404
NetworkAssignment 1134
NextMaintenance 47
NodalPoseAlphaOpti 1887
NodalPoseBetaOpti 1888
NodalPoseGammaOpti 1890
NodalPoseXCoordOffset 1891
NodalPoseYCoordOffset 1893
NodalPoseZCoordOffset 1894
NoiseReductionFilter 1577
NORCAVerification 1680
NotifyMode 5
NumFramesInQueue 1571
NWDevID 1131
NWmonasgn1 1139
NWmonasgn2 1142
NWmondevlst1 1141
NWmondevlst2 1143
NWmontimeout 1145
NWMstSlv 1132
NWMuxAsgn 1137
NWNtwAsgn 1134
NWslvlst 1135
NWsrvlst 1138

O

ObjAdmin 2406
OBJECT_ADMIN 2406
ObjectReleasePoint 777
ObjTrigSource 1117
OCR3AbortTime_ms 734
OCR3Abtms 734
OCR3CharStatistics 773
OCR3ChInf 769
OCR3Classifier 746
OCR3Clss 746
OCR3DeleteChar 771
OCR3DeleteFont 766
OCR3DlCh 771
OCR3DoDeslant 742
OCR3DontUseHW 741
OCR3DoRowFind 737
OCR3DoRwFnd 737
OCR3DoTraining 739
OCR3DoTrn 739
OCR3EdgeWidth 755
OCR3EdWd 755
OCR3FieldingMode 745
OCR3FMd 745
OCR3FullRd 735
OCR3GetCharInfo 769
OCR3GldChIdx 752
OCR3IdealCharacterIndices 752
OCR3NBlcks 757
OCR3NoUseHW 741
OCR3NRw 738
OCR3NumBlocks 757
OCR3NumRows 738
OCR3OCVInput 768
OCR3ResetCharStatistics 772
OCR3RowConfigArray 753
OCR3RowConfigExArray 761
OCR3RwCfg 753
OCR3RwCfgEx 761
OCR3SbstCh 749
OCR3sChSt 772
OCR3SetFielding 767
OCR3SlantAngle 744
OCR3SlantAngleInDegrees 744
OCR3SubstituteCharacter 749
OCR3ThGn 758
OCR3ThOf 760
OCR3ThresholdGain 758
OCR3ThresholdOffset 760
OCR3UseAlternateScore 748
OCR3UseAltSc 748
OCR3UseFullReader 735
OCR3UseIdCh 750
OCR3UseIdealCharacter 750
OCRAct 716
OCRActive 716
OCRDiagLevel 729
OCRDiagLvl 729
OCRPopParams 731
OCRPopPrm 731
OCRPreMode 724
OCRPreprocessMode 724
OCRPshPrm 730
OCRPushParams 730
OCRRefCodeReg 720
OCRReferenceCodeRegion 720
OCRReferencePatternExclusionRegions 723

© SICK AG - Germany - All rights reserved

OCRReferencePatternRegion 722
OCRRefPatExRegs 723
OCRRefPatReg 722
OCRReg 719
OCRRegDoTrain 726
OCRRegion 719
OCRRegionFinderDoTraining 726
OCRRegionPrimitive 2372
OCRRegionReferenceMode 717
OCRRegRefMode 717
OCRShowScores 727
OCRShwSc 727
OFembmode 824
OFEmbodimentMode 824
OFHBString 823
OFrdtenaerrors 1158
OFrdtsendcommtraces 1156
OFrdtsendtraces 1155
OFrdtvmsenaerrors 1162
OFrdtvmssendcommtraces 1161
OFrdtvmssendtraces 1159
OFTemplateString1 832
OFTemplateString1Maximized 826
OFTemplateString2 834
OFTemplateString2Maximized 827
OFTemplateStringFixString1 828
OFTemplateStringFixString2 830
OFTemplateStringFixString3 831
OFtplstr1 832
OFtplstr1max 826
OFtplstr2 834
OFtplstr2max 827
OFtplstrFix1 828
OFtplstrFix2 830
OFtplstrFix3 831
OFUsageMode2 836
OFusmd2 836
OILensfNumber 1715
OILensfStr 1716
OILensTrans 1719
OILensType 1718
OPCondASAPenum 794
OPCondASAPstruct 795
OpenFile 18
OPSendPointNonTracking 817
OPSendPointTracking 792
OptimizeBad1DDecoding 1956
OptimizeTireReading 1684
OS 2399
OSDescription 2272
OTASAPCondTimoTm 818
OTASAPLabTimoTm 819
OTCondASAPenum 794
OTCondASAPstruct 795
OTControl 791
OTDelayTk 802
OTDelayTm 801
OTLabTimoAct 810
OTLabTimoTm 811
OTOutMode 821
OTSlvTimoTk 815
OTSlvTimoTm 814
OTSndPntDst 798
OTSndPntNoTr 817
OTSndPntRef 797
OTSndPntTime 799
OTSndPntTr 792
OTTimoTk 805
OTTimoTm 803
Out1Control 74
Out1DurTime 72
Out1DurTrack 73
Out1Func 87
Out1FuncEvCndExt 66
Out1FuncTeachInMatchCodeEnh 1219
Out1Logic 70
Out1Mode 185
Out1OffFunc 67
Out1OffFuncEvCndExt 69
Out1ScopingEnabled 190
Out1ScopingExtraDelay 191
Out2Control 84
Out2DurTime 82
Out2DurTrack 83
Out2Func 86
Out2FuncEvCndExt 76
Out2FuncTeachInMatchCodeEnh 1221
Out2Logic 80
Out2Mode 186
Out2OffFunc 77
Out2OffFuncEvCndExt 79
Out2ScopingEnabled 193
Out2ScopingExtraDelay 194
Out3Control 173
Out3DurTime 171
Out3DurTrack 172
Out3Func 198
Out3FuncEvCndExt 165
Out3FuncTeachInMatchCodeEnh 1222
Out3Logic 169
Out3Mode 187
Out3OffFunc 166
Out3OffFuncEvCndExt 168
Out4Control 183
Out4DurTime 181
Out4DurTrack 182
Out4Func 197
Out4FuncEvCndExt 175
Out4FuncTeachInMatchCodeEnh 1224
Out4Logic 179
Out4Mode 189
Out4OffFunc 176
Out4OffFuncEvCndExt 178
OutputDelayTime 801
OutputDelayTrack 802
OutputOutputMode 821
OUTPUTS 2394
OutputSendingPointDistance 798
OutputSendingPointReference 797
OutputSendingPointTime 799
OutputTimingControl 791

P

PanoramaHoodActive 1613
PanoramaHoodImageOverlapping 1615

© SICK AG - Germany - All rights reserved

ParameterSetEnabled 2107
ParameterSetEnabledExt 2109
ParameterSets 2091
ParameterSetsDPMDMXPrettyString 2099
ParameterSetsDPMDMXPrettyStringExt 2100
ParameterSetsDPMDMXString 2096
ParameterSetsDPMDMXStringExt 2097
ParameterSetsExt 2092
ParameterSetsIlluminationColor 2093
ParameterSetsIlluminationColorExt 2095
ParameterSetsL61xIlluminationIntensity 2104
ParameterSetsL61xIlluminationIntensityExt 2106
ParameterSetsL61xIlluminationLEDStates1 2102
ParameterSetsL61xIlluminationLEDStates1Ext 2103
ParameterSwitchingMode 2082
PBCMCtrlOut 2295
PBUsage_CdfFhIn2 1307
PBUsage_CdfFhOut1 1302
PBUsage_CdfFhOut2 1304
PDF417Active 610
PDF417DecodingLevel 613
PDF417Truncated 611
Pharm2DigitsEnable 364
PharmaActive 346
PharmAddQuietZoneFact 367
PharmBarSizeMax 358
PharmBarSizeMin 357
PharmCheckBarGapActive 355
PharmDecimalOutput 371
PharmDensityQuietZone 368
PharmGapSizeMax 361
PharmGapSizeMin 360
PharmLength 353
PharmLengthMode 351
PharmLimitTolSize 363
PharmMinPercUndisturbedQuietZoneScans 370
PharmModuleWidthMode 348
PharmModuleWidthUserDefined 350
PharmMultiRead 347
PharmQuietzoneCheckEnable 366
PharmReverse 354
PlesseyActive 484
PlesseyFixLenList 489
PlesseyIntLenList 491
PlesseyLengthMode 488
PlesseyMultiRead 485
PlesseyTransmitCheckDigit 487
PMMovDectTimeout 2145
PMRepetitiveContentFilteringEnabled 2148
PMRepetitiveContentFilteringMaxAge 2151
PMRepetitiveContentFilteringNumObjects 2149
PMRepFAge 2151
PMRepFEn 2148
PMRepFNumOb 2149
PMReTrigPause 2143
PMSensitivityThreshold 2142
PMSensThresh 2142
PMShippEn 2235
PMShippEnabled 2235
PMSleepModeEnabled 2152
PMSleepModeEnbld 2152
PMSleepTriggerTime 2146
PN1PortActive 1329
PNAutoDetect 1330
PNAutoDetectTO 1331
POalpha 1824
PObeta 1804
POcoordX 1807
POcoordY 1808
POcoordZ 1821
POgamma 1805
POHRalpha 1823
POHRbeta 1809
POHRcoordX 1812
POHRcoordY 1813
POHRcoordZ 1820
POHRgamma 1811
POoffsX 1816
POoffsY 1817
POoffsZ 1819
PoseEstimationFeedback 1881
PoseEstimationFinish 1886
PoseEstimationProcessFeedback 1884
PoseEstimationTargetOrientation 1880
PoseEstimationXOrigin 1876
PoseEstimationYOrigin 1877
PoseEstimationZOrigin 1879
PositionDeshadingActive 1815
PositionXOffset 1816
PositionYOffset 1817
PositionZOffset 1819
PostCodeActive 392
PostCodeDPI 395
PostCodeKixFixLenList 399
PostCodeKixIntLenList 401
PostCodeKixLengthMode 398
PostCodePostAustraliaAllowZeroFCC 435
PostCodePostAustraliaFixLenList 432
PostCodePostAustraliaIntLenList 434
PostCodePostAustraliaLengthMode 431
PostCodePostJapanFixLenList 428
PostCodePostJapanIntLenList 429
PostCodePostJapanLengthMode 426
PostCodePostSwedenFixLenList 459
PostCodePostSwedenIntLenList 460
PostCodePostSwedenLengthMode 457
PostCodeRawBarOutput2StateActive 462
PostCodeRawBarOutput2StateFixLenList 465
PostCodeRawBarOutput2StateIntLenList 466
PostCodeRawBarOutput2StateLengthMode 463
PostCodeRawBarOutput4StateActive 468
PostCodeRawBarOutput4StateFixLenList 471
PostCodeRawBarOutput4StateIntLenList 472
PostCodeRawBarOutput4StateLengthMode 469
PostCodeRMInfomailActive 414
PostCodeRMInfomailFixLenList 417
PostCodeRMInfomailIntLenList 419
PostCodeRMInfomailLengthMode 416
PostCodeRMMailmarkActive 402
PostCodeRMMailmarkFixLenList 405
PostCodeRMMailmarkIntLenList 407
PostCodeRMMailmarkLengthMode 404
PostCodeRMPostSingaporeActive 420
PostCodeRMPostSingaporeFixLenList 423
PostCodeRMPostSingaporeIntLenList 425
PostCodeRMPostSingaporeLengthMode 422

© SICK AG - Germany - All rights reserved

PostCodeRMRM4SCCActive 408
PostCodeRMRM4SCCFixLenList 411
PostCodeRMRM4SCCIntLenList 413
PostCodeRMRM4SCCLengthMode 410
PostCodesDependentSymbology 393
PostCodesOrientation 396
PostCodeUSPFixLenList 442
PostCodeUSPIntLenList 444
PostCodeUSPLengthMode 441
PostCodeUSPPlanetActive 439
PostCodeUSPPostNetActive 437
PostCodeUSPPostNetAllowBnBFields 438
PostCodeUSPUPUActive 445
PostCodeUSPUPUFixLenList 448
PostCodeUSPUPUIntLenList 450
PostCodeUSPUPULengthMode 447
PostCodeUSPUsps4StateActive 451
PostCodeUSPUsps4StateFixLenList 454
PostCodeUSPUsps4StateIntLenList 456
PostCodeUSPUsps4StateLengthMode 453
ProfileCodesForwardingEnabled 2233
ProfileCodesSharedKey 2232
PROFINET 2401
ProfinetFixed 2376
ProgramConfigData 56
ProgramData 58
PSAPSRetr 2083
PSDPMDMXPrettyString 2099
PSDPMDMXPrettyStringEx 2100
PSDPMDMXString 2096
PSDPMDMXStringEx 2097
PSEPSSrc 2085
PSIlluColor 2093
PSIlluColorEx 2095
PSL61xIlluInt 2104
PSL61xIlluIntEx 2106
PSL61xIlluLEDStat1 2102
PSL61xIlluLEDStat1Ex 2103

Q

QRCodeActive 626
QRDecodingLevel 634
QRFixLenList 630
QRFormatMode 636
QRGS1AIMarking 640
QRGS1FirstCharReplacement 637
QRGS1SeparatorCharReplacement 638
QRLengthMode 629
QRMode 627
QRVerISO18004 633

R

RCBrdtctcond1enum 1147
RCBrdtctcond1struct 1148
RCBrdtctcond2enum 1150
RCBrdtctcond2struct 1151
RCBrdtctcond3enum 1152
RCBrdtctcond3struct 1154
RCCalcTriggerPostExpand 1852
RCCalcTriggerPreExpand 1851
RCRdArlimY1 1844
RCRdArlimY2 1845
RCRdArlimZ1 1847
RCRdArlimZ2 1848
RCReadingAreaLimY1 1844
RCReadingAreaLimY2 1845
RCReadingAreaLimZ1 1847
RCReadingAreaLimZ2 1848
RDTCTCond1Enum 1147
RDTCTCond1Struct 1148
RDTCTCond2Enum 1150
RDTCTCond2Struct 1151
RDTCTCond3Enum 1152
RDTCTCond3Struct 1154
RDTEnableErrors 1158
RDTSendCommTraces 1156
RDTSendTraces 1155
RDTVMSEnableErrors 1162
RDTVMSSendCommTraces 1161
RDTVMSSendTraces 1159
ReadEeprom 27
ReadExtInput 247
ReadFile 20
ReadingDistanceInput 1605
ReadingGateOff 1122
ReadingGateOffDiag 1124
ReadingGateOn 1121
ReadingGateOnDiag 1123
ReadingStatEnabled 1200
ReadingStatisticEnabled 1200
ReadInput 104
RebootDevice 34
ReleaseDelayTime 779
RepairSdCard 1196
RequestFrameStatistics 2351
RequestOCRInformation 732
RESERVED1 2393
RESERVED2 2393
ResetAppCounter 2080
ResetOutOnTrigger 195
ResetStatisticDisplay 2277
RotateDeShadingMetric 1634
RSClearStat 1215
RSctcond1enum 1201
RSCTCond1Enum 1201
RSctcond1name 1204
RSCTCond1Name 1204
RSCTCond1Struct 1203
RSctcond1struct 1203
RSctcond2enum 1206
RSCTCond2Enum 1206
RSctcond2name 1209
RSCTCond2Name 1209
RSctcond2struct 1207
RSCTCond2Struct 1207
RSctcond31name 1213
RSCTCond3Enum 1210
RSctcond3enum 1210
RSCTCond3Name 1213
RSctcond3struct 1212
RSCTCond3Struct 1212
RSRefreshRunning 1216
RSRefreshTrigger 1217
Run 7

© SICK AG - Germany - All rights reserved

S

ScanDensity1D 1677
ScannerHRPosAlpha 1823
ScannerHRPosBeta 1809
ScannerHRPosGamma 1811
ScannerHRPosXCoord 1812
ScannerHRPosYCoord 1813
ScannerHRPosZCoord 1820
ScannerPosAlpha 1824
ScannerPosBeta 1804
ScannerPosGamma 1805
ScannerPosXCoord 1807
ScannerPosYCoord 1808
ScannerPosZCoord 1821
Scanning1DRegionMode 1959
ScriptCommand 1343
ScriptParam01 2176
ScriptParam02 2177
ScriptParam03 2179
ScriptParam04 2180
ScriptParam05 2181
ScriptParam06 2183
ScriptParam07 2184
ScriptParam08 2185
ScriptParam09 2187
ScriptParam10 2188
ScriptParam11 2189
ScriptParam12 2191
ScriptParam13 2192
ScriptParam14 2193
ScriptParam15 2195
ScriptParam16 2196
ScriptParam17 2197
ScriptParam18 2199
ScriptParam19 2200
ScriptParam20 2201
SCtimeformat 30
SCTimeFormat 30
SCUIVers 31
SCUserInterfaceVariant 31
SelfTest 38
Sensor1Control 96
Sensor1DebounceTime 94
Sensor1DebounceTrack 95
Sensor1Logic 92
Sensor1Sensitivity 91
Sensor2Control 103
Sensor2DebounceTime 100
Sensor2DebounceTrack 102
Sensor2Logic 99
Sensor2Sensitivity 98
SerAuxBaudrate 1011
SerAuxEnHB 1017
SerAuxHardware 1016
SerAuxHBInterval 1019
SerAuxInputHandling 2155
SerAuxParity 1014
SerAuxProtocol 1010
SerAuxRetrHB 1020
SerAuxStopbits 1013
SerHostBaudrate 1000
SerHostCustomProtNb 1230
SerHostEnHB 1006
SerHostHardware 1004
SerHostHBInterval 1007
SerHostInputHandling 2154
SerHostMultiplex 998
SerHostParity 1003
SerHostProtocol 997
SerHostRetrHB 1008
SerHostStopbits 1001
SetAccessMode 4
SetDeviceIdle 1943
SETEditExtendibleEnum 2375
SETEditExtendibleEnumSize6 2376
SETEM_Analog 2374
SETEM_Binary 2374
SETEM_String 2375
SetExtOutput 231
SetIncrement 1924
SetLastUser 49
SetMotorPosAbsolute 2339
SetMotorPosRelative 2340
SetOutput 89
SetPassword 15
SetPasswordDefaults 37
SetTestErrorError 53
SetTestErrorFatalError 54
SetTestErrorInfo 51
SetTestErrorWarning 52
SetTime 1190
SetUserLevel 12
SFParameter 841
SFprms 841
SFstrct1 838
SFstrct2 839
SFStructure1 838
SFStructure2 839
SharpnessMeasuring 1674
ShBeDur1 2251
ShBeDur2 2252
ShFeedbackNegative 2257
ShFeedbackPositive 2256
ShInhImLog 2248
ShippBeepDurationLong 2252
ShippBeepDurationShort 2251
ShippForceResultOutput 2249
ShippInhibitLoggingInPresentation 2248
ShippPrepModeActive 2245
ShippPrepPostWaitMs 2244
ShippPrepStart 2258
ShippPrepSteadyCount 2242
ShippPrepSteadyTimeMs 2241
ShippPrepStop 2259
ShippPrepTimeout 2253
ShippSnapBurstLength 2239
ShippSnapHostTimeoutMs 2238
ShippSnapModeActive 2246
ShippSnapNegativeFeedback 2257
ShippSnapPositiveFeedback 2256
ShippSnapPreDelayMs 2236
ShippSnapStart 2255
ShortBarHeight 1685
ShPrAct 2245
ShPrepStart 2258

© SICK AG - Germany - All rights reserved

ShPrepStop 2259
ShPrPostW 2244
ShPrSteCnt 2242
ShPrSteTo 2241
ShPrTmt 2253
ShResOutF 2249
ShSnAct 2246
ShSnapStart 2255
ShSnBurstLen 2239
ShSnHostTO 2238
ShSnPre 2236
ShutterTime 1609
SIAuxBaud 1011
SIAuxEnHB 1017
SIAuxHBInt 1019
SIAuxHw 1016
SIAuxPar 1014
SIAuxProt 1010
SIAuxRetrHB 1020
SIAuxStop 1013
SIAuxtInp 2155
SIHstBaud 1000
SIHstCstProtNb 1230
SIHstEnHB 1006
SIHstHBInt 1007
SIHstHw 1004
SIHstInp 2154
SIHstMux 998
SIHstPar 1003
SIHstProt 997
SIHstRetrHB 1008
SIHstStop 1001
SizeFilter1DCodes 1960
SkipImageByQueueSize1 2121
SkipImageByQueueSize2 2124
SkipImageByQueueSize3 2127
SkipImageByQueueSize4 2130
SkipImageByQueueSize5 2133
SkipImgByQuSize1 2121
SkipImgByQuSize2 2124
SkipImgByQuSize3 2127
SkipImgByQuSize4 2130
SkipImgByQuSize5 2133
SkipImgQueueFillLevel1 2120
SkipImgQueueFillLevel2 2123
SkipImgQueueFillLevel3 2125
SkipImgQueueFillLevel4 2128
SkipImgQueueFillLevel5 2131
SkipImgQueueFillLevel6 2134
SkipImgQuFillLevel1 2120
SkipImgQuFillLevel2 2123
SkipImgQuFillLevel3 2125
SkipImgQuFillLevel4 2128
SkipImgQuFillLevel5 2131
SkipImgQuFillLevel6 2134
SlaveTimeoutTime 814
SlaveTimeoutTrack 815
SnglChrTrgEcho 1932
SoftReset 33
SP01 2176
SP02 2177
SP03 2179
SP04 2180
SP05 2181
SP06 2183
SP07 2184
SP08 2185
SP09 2187
SP10 2188
SP11 2189
SP12 2191
SP13 2192
SP14 2193
SP15 2195
SP16 2196
SP17 2197
SP18 2199
SP19 2200
SP20 2201
StandbyModeActive 2263
Start2ndStageLoader 39
StartAimDpmCalib 648
StartAutoSetup 1871
StartContinuousHallSensorMeasurement 1197
StartDemoMode 1916
StartDiagReading 1127
StartHallSensorSingleshotMeasurement 1199
StartLiveImageMode 2283
StartMemCardUpdate 45
StartModeDigIoCondition1 200
StartModeDigIoCondition2 202
StartModeDigIoCondition3 204
StartModeDigIoCondition4 206
StartOfAssignment 789
StartPercentageEvaluation 1944
StartPoseEstimation 1905
StartPoseEstimationPanoramaHood1of2 1906
StartPoseEstimationPanoramaHood2of2 1907
StaticImageAcquire 2291
StaticImageMode 2286
StaticImagePaused 2288
StaticImageProcess 2292
StaticImageSource 2285
StaticImageStart 2289
StaticImageStop 2290
StatusDownload 61
StdbyMdAct 2263
StopHallSensorMeasurements 1198
StopLiveImageMode 2284
StopModeDigIoCondition1 201
StopModeDigIoCondition2 203
StopModeDigIoCondition3 205
StopModeDigIoCondition4 207
StopPercentageEvaluation 1945
StoreAppCounter 2081
SuperResolutionActive 1964
SVP 2400
SVPAct 1262
SVPActive 1262
SVPAppSrvIface 1266
SVPAppSrvIPAddress 1263
SVPAppSrvIPPort 1265
SVPImageTransfer 1267
SVPImg 1267
SVPImgSrvAdr 1269
SVPImgSrvIface 1272

© SICK AG - Germany - All rights reserved

SVPImgSrvIPAddress 1269
SVPImgSrvIPPort 1270
SVPImgSrvPassword 1274
SVPImgSrvPasWd 1274
SVPImgSrvPrt 1270
SVPImgSrvUsername 1273
SVPImgSrvUsrNm 1273
SVPOutFmt 1276
SVPOutputFormat 1276
SVPSendOnlyErrors 1277
SVPSvrAdr 1263
SVPSvrIface 1266
SVPSvrPrt 1265
SwiftPostCodeRMInfomailActive 477
SwiftPostCodeRMMailmarkActive 474
SwiftPostCodeRMRM4SCCActive 475
SwiftPostCodeUSPPlanetActive 479
SwiftPostCodeUSPPostNetActive 478
SwiftPostCodeUSPUPUActive 481
SwiftPostCodeUSPUsps4StateActive 482
SwitchDynRdCfgDistance 1671
SwitchDynRdCfgTableIndex 1670
SYNoQkStrt 1564
SYNoQuickstart 1564
SYParaPasswordGuarded 1563
SYPwGuarded 1563
SystemConfigData 55
SYUImode 1192
SYUIMode 1192

T

TCacPauTm 1105
TCacPauTrk 1108
TCacPlsTm 1103
TCacPlsTrk 1106
TCcantrgsrc 1109
TCControl 1094
TCExpansTm 1112
TCExpansTrk 1113
TCExpPreTm 1115
TCExpPreTrk 1116
TCInvalidIdx 1120
TCMaxIdxVal 1119
TCObjTrigSrc 1117
TcpPortChoiceForImageTransmission 1346
TCStartCond 1936
TCStartDelTm 1095
TCStartDelTrk 1097
TCStopCond1 1939
TCStopCond1Ext 1928
TCStopCond2 1938
TCStopCond2Ext 1929
TCStopCond3 1941
TCStopCond3Ext 1931
TCStopDelTm 1101
TCStopDelTrk 1102
TCStopTimerTm 1098
TCStopTimerTrk 1099
TCtrgdist 1111
TelepenActive 503
TelepenFixLenList 510
TelepenIntLenList 512
TelepenLengthMode 509
TelepenMode 506
TelepenMultiRead 504
TelepenTransmitCheckDigit 507
Temperature 2389
TEMPERATURE_OBSERVER 2395
TemperatureGetValues 2358
TempSensArray_t 2390
TESTERRORS 2402
TIME_CONTROL 2399
TimeoutTime 803
TimeoutTrack 805
TimeServerIface 1186
TimeServerIPAddress 1183
TimeServerIPPort 1185
TimeSource 1182
TimeZoneOffset 1187
TIServerAddr 1183
TIServerIface 1186
TIServerPort 1185
TISrc 1182
TITimeZoneOffset 1187
ToFCntnsMsrmntStrt 2363
ToFContinuousMeasurementStart 2363
ToFDisabledForCompliance 2361
ToFSingleshotStart 2362
ToFSnglshtStrt 2362
ToFStopAllMeasurements 2364
ToFStpMsrmnts 2364
TracingStop 2349
TrackingMode 774
TrackingTimeOut 775
TRASAPCondTimoTk 807
TRASAPLabTimoTk 806
TRAssMode 785
TRCdFltrDpt 809
TrigAutoCyclePauseTime 1105
TrigAutoCyclePauseTrack 1108
TrigAutoCyclePulseTime 1103
TrigAutoCyclePulseTrack 1106
TrigCANSource 1109
TrigControl 1094
TrigDistribute 1111
TrigExpansionTime 1112
TrigExpansionTrack 1113
TRIGGER_CTRL 2406
TriggerCtrl 2406
TriggerEcho 1932
TrigPreExpansionTime 1115
TrigPreExpansionTrack 1116
TrigStartCondition 1936
TrigStartDelayTime 1095
TrigStartDelayTrack 1097
TrigStopCondition1 1939
TrigStopCondition1Ext 1928
TrigStopCondition2 1938
TrigStopCondition2Ext 1929
TrigStopCondition3 1941
TrigStopCondition3Ext 1931
TrigStopDelayTime 1101
TrigStopDelayTrack 1102
TrigStopTimerTime 1098
TrigStopTimerTrack 1099

© SICK AG - Germany - All rights reserved

TRLabAssFix 783
TRLabAssMax 782
TRLabAssTol 781
TRLabTimoTk 813
TRMaxTol3D 787
TRMinTol3D 786
TRObjRel 777
TRReleaseDelayTime 779
TRStartOfAss 789
TRTimeout 775
TRTrMode 774
TRUseReleaseDelayTime 778
Type: Asci127_t 2377
Type: Asci127AndCode_t 2385
Type: Asci127AndObject_t 2381
Type: CidVersion 2371
Type: DPSColorType 2391
Type: DPSIllu61xLedStates 2392
Type: DPSSet 2390
Type: E_USER_LEVEL_TYPE 2392
Type: ErrStructType 2373
Type: ErrTimeType 2373
Type: eUsePredConnSetType 2376
Type: OCRRegionPrimitive 2372
Type: ProfinetFixed 2376
Type: SETEditExtendibleEnum 2375
Type: SETEditExtendibleEnumSize6 2376
Type: SETEM_Analog 2374
Type: SETEM_Binary 2374
Type: SETEM_String 2375
Type: Temperature 2389
Type: TempSensArray_t 2390

U

UmountSdCard 1194
UPCAActive 376
UPCEActive 385
UPCEANActive 382
UPCEANAddOnLength 282
UPCEANAddonMatchingStrategy 1965
UPCEANAddOnMode 280
UPCEANMatStrat 1965
UPCEANMultiRead 279
UPCEANStartCharacterValidation 289
UPCEANStopCharacterValidation 287
UPCEExtended 283
UPCENumSystem 286
Usage_CdfProfibusFhIn1 1305
Usage_CdfProfibusFhIn2 1307
Usage_CdfProfibusFhOut1 1302
Usage_CdfProfibusFhOut2 1304
UseCCDToWorldTransformMatrix 1595
UseExtParams 1333
UseFrameRate 1566
UseNumFramesInQueue 1570
UserDefTriggerStartCmd 1934
UserDefTriggerStopCmd 1935
UseReleaseDelayTime 778
UsrDfCmdTrgStart 1934
UsrDfCmdTrgStop 1935

V

Variable: AimDpmActive 642
Variable: AimDpmCalibratedGain 643
Variable: AimDpmCalibratedMaxReflectance 645
Variable: AimDpmCalibratedMeanReflectance 646
Variable: AimingLaser 1586
Variable: APCCounterCondition01 2020
Variable: APCCounterCondition02 2026
Variable: APCCounterCondition03 2032
Variable: APCCounterCondition04 2038
Variable: APCCounterCondition05 2044
Variable: APCCounterCondition06 2050
Variable: APCCounterCondition07 2056
Variable: APCCounterCondition08 2062
Variable: APCCounterCondition09 2068
Variable: APCCounterCondition10 2074
Variable: APCCounterConditionStruct01 2021
Variable: APCCounterConditionStruct02 2027
Variable: APCCounterConditionStruct03 2033
Variable: APCCounterConditionStruct04 2039
Variable: APCCounterConditionStruct05 2045
Variable: APCCounterConditionStruct06 2051
Variable: APCCounterConditionStruct07 2057
Variable: APCCounterConditionStruct08 2063
Variable: APCCounterConditionStruct09 2069
Variable: APCCounterConditionStruct10 2075
Variable: APCCounterDBTagStruct01 2023
Variable: APCCounterDBTagStruct02 2029
Variable: APCCounterDBTagStruct03 2035
Variable: APCCounterDBTagStruct04 2041
Variable: APCCounterDBTagStruct05 2047
Variable: APCCounterDBTagStruct06 2053
Variable: APCCounterDBTagStruct07 2059
Variable: APCCounterDBTagStruct08 2065
Variable: APCCounterDBTagStruct09 2071
Variable: APCCounterDBTagStruct10 2077
Variable: APCIsPermanent01 2024
Variable: APCIsPermanent02 2030
Variable: APCIsPermanent03 2036
Variable: APCIsPermanent04 2042
Variable: APCIsPermanent05 2048
Variable: APCIsPermanent06 2054
Variable: APCIsPermanent07 2060
Variable: APCIsPermanent08 2066
Variable: APCIsPermanent09 2072
Variable: APCIsPermanent10 2078
Variable: APSRetries 2083
Variable: ASAllowTeachPixToMM 1862
Variable: ASAPConditionTimoutTime 818
Variable: ASAPConditionTimoutTrack 807
Variable: ASAPLabelTimoutTime 819
Variable: ASAPLabelTimoutTrack 806
Variable: ASCellSize 1870
Variable: ASCodeRegion 1857
Variable: ASConveyorSpeed 1868
Variable: ASDatamatrixPrio 1861
Variable: ASManualCodeRegion 1859
Variable: ASParameter 1854
Variable: AssignmentMode 785
Variable: ASUseDPMRoi 1864
Variable: ASUserDefinedDPMRoi 1865
Variable: ASWriteTarget 1867
Variable: AutoAdjustGain 1596
Variable: AutoAdjustGainRangeMax 1601

© SICK AG - Germany - All rights reserved

Variable: AutoAdjustGainRangeMin 1599
Variable: AutoAdjustRegion 1597
Variable: AztecActive 1976
Variable: AztecFixLenList 1979
Variable: AztecLengthMode 1977
Variable: AztecMode 1982
Variable: BarcodeState 2276
Variable: BeeperFunc 2007
Variable: BeeperFuncExt 2004
Variable: BeeperLoudness 2005
Variable: BlobFragmentSize 2325
Variable: BlobTcpPort 2331
Variable: Brightness 1573
Variable: BWDBeltWidth 2206
Variable: BWDCalcTriggerPostExpand 2208
Variable: BWDCalcTriggerPreExpand 2207
Variable: BWDDistanceBwdTrigger 2204
Variable: BWDDistMeasSourceVMSNodeID 2214
Variable: BWDEnableMode 2203
Variable: BWDFocusPosition 2210
Variable: BWDRCReadingAreaLimY1 2211
Variable: BWDRCReadingAreaLimY2 2213
Variable: BWDScannerPosAlpha 2216
Variable: BWDScannerPosAlphaPanorama 2223
Variable: BWDScannerPosBeta 2217
Variable: BWDScannerPosBetaPanorama 2224
Variable: BWDScannerPosGamma 2218
Variable: BWDScannerPosGammaPanorama 2226
Variable: BWDScannerPosXCoord 2220
Variable: BWDScannerPosXCoordPanorama 2227
Variable: BWDScannerPosYCoord 2221
Variable: BWDScannerPosYCoordPanorama 2229
Variable: C128Active 389
Variable: C128CheckDigitTestL1 325
Variable: C128CheckDigitTestL2 327
Variable: C128CheckDigitTestL3 328
Variable: C128CheckDigitTestL4 330
Variable: C128CheckDigitTestL5 331
Variable: C128FamiliyActive 390
Variable: C128FixLenList 334
Variable: C128HexASCIIOutput 337
Variable: C128IntLenList 336
Variable: C128LengthMode 333
Variable: C128MultiRead 324
Variable: C128SingleErrorCorrection 341
Variable: C128StartCharacterValidation 340
Variable: C128StopCharacterValidation 339
Variable: C1_RPDO1_CobId 969
Variable: C1_RPDO1_MapNum 964
Variable: C1_RPDO1_MapObjs 965
Variable: C1_RPDO1_PreConnSet 968
Variable: C1_RPDO1_TrmType 971
Variable: C1_RPDO2_CobId 977
Variable: C1_RPDO2_MapNum 972
Variable: C1_RPDO2_MapObjs 973
Variable: C1_RPDO2_PreConnSet 976
Variable: C1_RPDO2_TrmType 979
Variable: C1_RPDO3_CobId 985
Variable: C1_RPDO3_MapNum 980
Variable: C1_RPDO3_MapObjs 981
Variable: C1_RPDO3_PreConnSet 984
Variable: C1_RPDO3_TrmType 987
Variable: C1_RPDO4_CobId 993
Variable: C1_RPDO4_MapNum 988
Variable: C1_RPDO4_MapObjs 989
Variable: C1_RPDO4_PreConnSet 992
Variable: C1_RPDO4_TrmType 995
Variable: C1_TPDO1_CobId 926
Variable: C1_TPDO1_EventTime 930
Variable: C1_TPDO1_InhibtTime 929
Variable: C1_TPDO1_MapNum 921
Variable: C1_TPDO1_MapObjs 922
Variable: C1_TPDO1_PreConnSet 925
Variable: C1_TPDO1_TrmType 928
Variable: C1_TPDO2_CobId 937
Variable: C1_TPDO2_EventTime 941
Variable: C1_TPDO2_InhibtTime 940
Variable: C1_TPDO2_MapNum 932
Variable: C1_TPDO2_MapObjs 933
Variable: C1_TPDO2_PreConnSet 936
Variable: C1_TPDO2_TrmType 938
Variable: C1_TPDO3_CobId 948
Variable: C1_TPDO3_EventTime 952
Variable: C1_TPDO3_InhibtTime 950
Variable: C1_TPDO3_MapNum 942
Variable: C1_TPDO3_MapObjs 944
Variable: C1_TPDO3_PreConnSet 946
Variable: C1_TPDO3_TrmType 949
Variable: C1_TPDO4_CobId 958
Variable: C1_TPDO4_EventTime 962
Variable: C1_TPDO4_InhibtTime 961
Variable: C1_TPDO4_MapNum 953
Variable: C1_TPDO4_MapObjs 954
Variable: C1_TPDO4_PreConnSet 957
Variable: C1_TPDO4_TrmType 960
Variable: C25ILActive 378
Variable: C25ILCheckDigitTestL1 297
Variable: C25ILCheckDigitTestL2 298
Variable: C25ILCheckDigitTestL3 300
Variable: C25ILCheckDigitTestL4 301
Variable: C25ILCheckDigitTestL5 303
Variable: C25ILClassRestriction 309
Variable: C25ILFixLenList 306
Variable: C25ILIntLenList 307
Variable: C25ILLengthMode 304
Variable: C25ILMultiReadL1 290
Variable: C25ILMultiReadL2 291
Variable: C25ILMultiReadL3 293
Variable: C25ILMultiReadL4 294
Variable: C25ILMultiReadL5 295
Variable: C25ILQuietZoneVerification 315
Variable: C25ILSingleErrorCorrection 314
Variable: C25ILStartCharacterValidation 313
Variable: C25ILStopCharacterValidation 311
Variable: C25ILTransmitCheckDigit 310
Variable: C39Active 380
Variable: C39CheckDigitTest 269
Variable: C39ClassRestriction 278
Variable: C39Code32Conversion 275
Variable: C39FixLenList 272
Variable: C39FullASCII 266
Variable: C39HexASCIIOutput 268
Variable: C39IntLenList 273
Variable: C39LengthMode 270
Variable: C39MultiRead 264
Variable: C39StaStoTransmit 265

© SICK AG - Germany - All rights reserved

Variable: C39TransmitCheckDigit 276
Variable: C93Active 384
Variable: C93FixLenList 319
Variable: C93HexASCIIOutput 322
Variable: C93IntLenList 321
Variable: C93LengthMode 318
Variable: C93MultiRead 317
Variable: CalcTriggerPostExpand 1852
Variable: CalcTriggerPreExpand 1851
Variable: CalibratedMmPerPix 1623
Variable: CAN1_CmdResponseTimeout 916
Variable: CAN1_DiagDataTimeout 913
Variable: CAN1_ReadResultTimeout 901
Variable: CAN1AutoSdoRelease 903
Variable: CAN1Baudrate 872
Variable: CAN1CmdRespEnable 914
Variable: CAN1DiagEnable 911
Variable: CAN1DigInputMask 879
Variable: CAN1DigInputPdoId 878
Variable: CAN1DigOutputPdoEna 876
Variable: CAN1DigOutputPdoId 875
Variable: CAN1EmcyID 917
Variable: CAN1EmcyInhibitTime 919
Variable: CAN1Format 873
Variable: CAN1HBEna 881
Variable: CAN1HBInterval 882
Variable: CAN1Mode 895
Variable: CAN1PdoEventTime 910
Variable: CAN1PdoID 906
Variable: CAN1PdoInhibitTime 909
Variable: CAN1PdoNum 904
Variable: CAN1PdoTrmType 907
Variable: CAN1ProdHbTime 897
Variable: CAN1ReadResultEnable 898
Variable: CAN1RetrHB 883
Variable: CAN1SendMode 900
Variable: CAN1TimeStampMode 892
Variable: CAN1TimeStampPeriod 893
Variable: CAN1UserInpByteNum 888
Variable: CAN1UserInpPdoId 886
Variable: CAN1UserOutpByteNum 890
Variable: CAN1UserOutpPdoId 889
Variable: CAN1UsrIOEna 885
Variable: CBARActive 386
Variable: CBARCheckDigitTest 256
Variable: CBARFixLenList 259
Variable: CBARIntLenList 261
Variable: CBARLengthMode 258
Variable: CBARMultiRead 252
Variable: CBARStaStoIdent 253
Variable: CBARStaStoTransmit 255
Variable: CBARTransmitCheckDigit 262
Variable: CCDToWorldTransformMatrix 1621
Variable: CDF_FramingHeaderInputSelect_1 1164
Variable: CDF_FramingHeaderInputSelect_2 1165
Variable: CDF_PhysInDebounceTime_1 1170
Variable: CDF_PhysInDebounceTime_2 1171
Variable: CDF_PhysOutputSelect_1 1167
Variable: CDF_PhysOutputSelect_2 1168
Variable: CDF_PlcLogicalInputState_FH 1173
Variable: CDF_PlcLogicalInputState_Map 1174
Variable: CDF_SensorPhysicalOutputState 1176
Variable: CdfCanMultiplexSend 1301
Variable: CdfCm_CDF600HS 1179
Variable: CdfEcatCmMode 1309
Variable: CdfEthMac 118
Variable: CdfEthMacP1 119
Variable: CdfEthMacP2 121
Variable: CdfIsDeviceFamily 125
Variable: CdfOrderIdDevice 124
Variable: CdfOrderIdFamily 122
Variable: CdfPnDeviceId 109
Variable: CdfPnDeviceType 110
Variable: CdfPnHwRevision 113
Variable: CdfPnPdevCrc 157
Variable: CdfPnPdevMagic 156
Variable: CdfPnPdevRawData 159
Variable: CdfPnProfileId 115
Variable: CdfPnProfileSpecificType 116
Variable: CdfPnSwRevision 112
Variable: CdfProfiCmMode 1298
Variable: CdfProfinetBusStatus 127
Variable: CdfProfinetConfigApply 135
Variable: CdfProfinetConfigChanged 136
Variable: CdfProfinetImDate 151
Variable: CdfProfinetImDescriptor 152
Variable: CdfProfinetImFunction 148
Variable: CdfProfinetImLocation 149
Variable: CdfProfinetImSignature 154
Variable: CdfProfinetIpAddress 143
Variable: CdfProfinetIpGateway 146
Variable: CdfProfinetIpMask 145
Variable: CdfProfinetIpSettingsStoringRemanent 133
Variable: CdfProfinetMasterAvailable 130
Variable: CdfProfinetS7CompatibilityMode 138
Variable: CdfProfinetStackErrorCode 128
Variable: CdfProfinetStationName 142
Variable: CdfProfinetStationNameStoringRemanent 131
Variable: CdfSelectDataFormat 1299
Variable: CdfSyncStationNameToLocationName 1178
Variable: cdpApiTracerCommProc 1358
Variable: cdpApiTracerCycleThresholdLowerUs 1364
Variable: cdpApiTracerCycleThresholdUpperUs 1362
Variable: cdpApiTracerEnabled 1360
Variable: cdpApiTracerMaxRecords 1361
Variable: cdpApiTracerMode 1357
Variable: cdpCmConfig 1547
Variable: cdpCmCtrlBitsIn 1541
Variable: cdpCmCtrlBitsOut 1543
Variable: cdpCmdReg 1352
Variable: cdpCmInFrameLength 1548
Variable: cdpCmInMsgLength 1553
Variable: cdpCmInternalDataIn 1557
Variable: cdpCmInternalDataOut 1559
Variable: cdpCmOutFrameLength 1550
Variable: cdpCmOutMsg 1555
Variable: cdpCmProtocolVariant 1551
Variable: cdpCmStatus 1545
Variable: cdpDigIoReg0 1561
Variable: cdpEndianCheck 1355
Variable: cdpFbCommStatusReg 1351
Variable: cdpPnioAlarmsSupported 1400
Variable: cdpPnioDHCP_Status 1386
Variable: cdpPnioDHCP_Support 1385
Variable: cdpPnioEpMAnnotation 1398
Variable: cdpPnioEpMOrderID 1399

© SICK AG - Germany - All rights reserved

Variable: cdpPnioGateWayAddr 1380
Variable: cdpPnioIMDate 1394
Variable: cdpPnioIMDescriptor 1395
Variable: cdpPnioIMSignature 1396
Variable: cdpPnioIMTagFunction 1392
Variable: cdpPnioIMTagLocation 1391
Variable: cdpPnioIpAddress 1377
Variable: cdpPnioIpAddressType 1375
Variable: cdpPnioLedStateBF 1406
Variable: cdpPnioLedStateSF 1408
Variable: cdpPnioMib1_ifInDiscards 1426
Variable: cdpPnioMib1_ifInErrors 1427
Variable: cdpPnioMib1_ifInNUcastPkts 1425
Variable: cdpPnioMib1_ifInOctets 1422
Variable: cdpPnioMib1_ifInUcastPkts 1423
Variable: cdpPnioMib1_ifLastChange 1421
Variable: cdpPnioMib1_ifNumber 1415
Variable: cdpPnioMib1_ifOperStatus 1419
Variable: cdpPnioMib1_ifOutDiscards 1433
Variable: cdpPnioMib1_ifOutErrors 1434
Variable: cdpPnioMib1_ifOutNUcastPkts 1431
Variable: cdpPnioMib1_ifOutOctets 1429
Variable: cdpPnioMib1_ifOutUcastPkts 1430
Variable: cdpPnioMib1_ifPhysAddress 1418
Variable: cdpPnioMib1_ifSpeed 1416
Variable: cdpPnioMib1_ipInAddrErrors 1439
Variable: cdpPnioMib1_ipInDiscards 1440
Variable: cdpPnioMib1_ipInHdrErrors 1437
Variable: cdpPnioMib1_ipInReceives 1436
Variable: cdpPnioMib1_ipOutDiscards 1443
Variable: cdpPnioMib1_ipOutRequests 1441
Variable: cdpPnioMib1_tcpInErrs 1453
Variable: cdpPnioMib1_tcpInSegs 1449
Variable: cdpPnioMib1_tcpOutRsts 1455
Variable: cdpPnioMib1_tcpOutSegs 1451
Variable: cdpPnioMib1_tcpRetransSegs 1452
Variable: cdpPnioMib1_udpInDatagrams 1444
Variable: cdpPnioMib1_udpInErrors 1447
Variable: cdpPnioMib1_udpNoPorts 1445
Variable: cdpPnioMib1_udpOutDatagrams 1448
Variable: cdpPnioMib2_ifInDiscards 1468
Variable: cdpPnioMib2_ifInErrors 1469
Variable: cdpPnioMib2_ifInNUcastPkts 1467
Variable: cdpPnioMib2_ifInOctets 1464
Variable: cdpPnioMib2_ifInUcastPkts 1465
Variable: cdpPnioMib2_ifLastChange 1463
Variable: cdpPnioMib2_ifNumber 1457
Variable: cdpPnioMib2_ifOperStatus 1461
Variable: cdpPnioMib2_ifOutDiscards 1475
Variable: cdpPnioMib2_ifOutErrors 1476
Variable: cdpPnioMib2_ifOutNUcastPkts 1473
Variable: cdpPnioMib2_ifOutOctets 1471
Variable: cdpPnioMib2_ifOutUcastPkts 1472
Variable: cdpPnioMib2_ifPhysAddress 1460
Variable: cdpPnioMib2_ifSpeed 1458
Variable: cdpPnioMib2_ipInAddrErrors 1481
Variable: cdpPnioMib2_ipInDiscards 1482
Variable: cdpPnioMib2_ipInHdrErrors 1479
Variable: cdpPnioMib2_ipInReceives 1478
Variable: cdpPnioMib2_ipOutDiscards 1485
Variable: cdpPnioMib2_ipOutRequests 1483
Variable: cdpPnioMib2_tcpInErrs 1495
Variable: cdpPnioMib2_tcpInSegs 1491
Variable: cdpPnioMib2_tcpOutRsts 1497
Variable: cdpPnioMib2_tcpOutSegs 1493
Variable: cdpPnioMib2_tcpRetransSegs 1494
Variable: cdpPnioMib2_udpInDatagrams 1486
Variable: cdpPnioMib2_udpInErrors 1489
Variable: cdpPnioMib2_udpNoPorts 1487
Variable: cdpPnioMib2_udpOutDatagrams 1490
Variable: cdpPnioMib3_ifInDiscards 1510
Variable: cdpPnioMib3_ifInErrors 1511
Variable: cdpPnioMib3_ifInNUcastPkts 1509
Variable: cdpPnioMib3_ifInOctets 1506
Variable: cdpPnioMib3_ifInUcastPkts 1507
Variable: cdpPnioMib3_ifLastChange 1505
Variable: cdpPnioMib3_ifNumber 1499
Variable: cdpPnioMib3_ifOperStatus 1503
Variable: cdpPnioMib3_ifOutDiscards 1517
Variable: cdpPnioMib3_ifOutErrors 1518
Variable: cdpPnioMib3_ifOutNUcastPkts 1515
Variable: cdpPnioMib3_ifOutOctets 1513
Variable: cdpPnioMib3_ifOutUcastPkts 1514
Variable: cdpPnioMib3_ifPhysAddress 1502
Variable: cdpPnioMib3_ifSpeed 1500
Variable: cdpPnioMib3_ipInAddrErrors 1523
Variable: cdpPnioMib3_ipInDiscards 1524
Variable: cdpPnioMib3_ipInHdrErrors 1521
Variable: cdpPnioMib3_ipInReceives 1520
Variable: cdpPnioMib3_ipOutDiscards 1527
Variable: cdpPnioMib3_ipOutRequests 1525
Variable: cdpPnioMib3_tcpInErrs 1537
Variable: cdpPnioMib3_tcpInSegs 1533
Variable: cdpPnioMib3_tcpOutRsts 1539
Variable: cdpPnioMib3_tcpOutSegs 1535
Variable: cdpPnioMib3_tcpRetransSegs 1536
Variable: cdpPnioMib3_udpInDatagrams 1528
Variable: cdpPnioMib3_udpInErrors 1531
Variable: cdpPnioMib3_udpNoPorts 1529
Variable: cdpPnioMib3_udpOutDatagrams 1532
Variable: cdpPnioMibSysContact 1413
Variable: cdpPnioMibSysDesc 1410
Variable: cdpPnioMibSysUpTime 1412
Variable: cdpPnioPLCSetAddrRemanent 1383
Variable: cdpPnioPLCSetNameRemanent 1381
Variable: cdpPnioSelectDataFormat 2140
Variable: cdpPnioStateApplication 1402
Variable: cdpPnioStateCommunication 1403
Variable: cdpPnioStateCommunicationFSM 1409
Variable: cdpPnioStateDeviceSummaryDiagnosis 1405
Variable: cdpPnioStationName 1374
Variable: cdpPnioSubNetMaskAddr 1378
Variable: cdpPnioSyncStationNameToLocationName 1388
Variable: cdpResStatusReg 1354
Variable: Code1DVerISO15416 536
Variable: CodeAtBorder1D 1962
Variable: CodeBackground1D 250
Variable: CodeBackground2D 541
Variable: CodeContrast1D 249
Variable: CodeContrast2D 538
Variable: CodeDirection 1950
Variable: CodeFilterDepth 809
Variable: CodeModuleSize2D 1700
Variable: CodeMotionSteadyThreshold 2260
Variable: CodeMotionTrackingEnabled 2261
Variable: CodeMultiImageToleranceFactor 2137

© SICK AG - Germany - All rights reserved

Variable: CodePositionByImageMultipleEnable 2136
Variable: CodeTrackingDirection 1682
Variable: Contrast 1574
Variable: ContrastSpreading 1675
Variable: ControlBitsPlcOut 2295
Variable: CPCodeDistance 866
Variable: CPCompareDeviceID 868
Variable: CPUseComparison 865
Variable: DataMatrixActive 602
Variable: DataMatrixAggressivityLevel 607
Variable: DataMatrixAllowRect 608
Variable: DataMatrixCheckSimpleLPatterns 560
Variable: DataMatrixConstructiveGrid 587
Variable: DataMatrixDefectCorrection 584
Variable: DataMatrixDilateErodeWith2ndValue 548
Variable: DataMatrixDilateFilterSize 545
Variable: DataMatrixDotActive 591
Variable: DataMatrixDotBlobSensitivity 595
Variable: DataMatrixDotDiameter 598
Variable: DataMatrixDotFilterBlobSearch 596
Variable: DataMatrixDotIntegralBlobSearch 594
Variable: DataMatrixDotPolarity 592
Variable: DataMatrixDotSymbolGeometry 599
Variable: DataMatrixEnableNewSeg 567
Variable: DataMatrixEnablePCBSpeedUp 563
Variable: DataMatrixEnableSpeedOptimization 559
Variable: DataMatrixEnableTextSpeedUp 564
Variable: DataMatrixErodeFilterSize 547
Variable: DataMatrixErrorCorr 544
Variable: DataMatrixExcludeCodeAreas 590
Variable: DataMatrixFilterSamplePoints 588
Variable: DataMatrixFixLenList 603
Variable: DataMatrixFormatMode 573
Variable: DataMatrixFPGASpeedup 570
Variable: DataMatrixFullRescan 582
Variable: DataMatrixGeoEstimation 586
Variable: DataMatrixGS1AIMarking 578
Variable: DataMatrixGS1FirstCharReplacement 575
Variable: DataMatrixGS1SeparatorCharReplacement 576
Variable: DataMatrixLengthMode 600
Variable: DataMatrixMinModuleSize100 572
Variable: DataMatrixNegativeDifferenceAllowed 552
Variable: DataMatrixNewSegAllowSingleTiles 569
Variable: DataMatrixNumWeakBitErrorBitsAllowed 554
Variable: DataMatrixPositiveDifferenceAllowed 551
Variable: DataMatrixRedundantCodes 566
Variable: DataMatrixRescanTPattern 583
Variable: DataMatrixTolerateErrorsInLPattern 556
Variable: DataMatrixTolerateErrorsInTimingPattern 558
Variable: DataMatrixTolerateLPatternDeformation 562
Variable: DataMatrixVerISO15415 580
Variable: DataMatrixVerISO16022 579
Variable: DataMatrixWeakBitsEnabled 550
Variable: DataMatrixWeakBitTreshhold 555
Variable: Decoding1DLevel 1966
Variable: DecodingTimeOutput 1947
Variable: DemoModeDPMDataMatrix 1914
Variable: DemoModeMaxiCode 1913
Variable: DemoModePDF417 1912
Variable: DemoModeROI 1910
Variable: DeShadingActive 1631
Variable: DeShadingIlluminationNonUniformity 1632
Variable: DigimarcActive 1702
Variable: DigimarcBearing 1709
Variable: DigimarcBlockSpacing 1705
Variable: DigimarcExpectedModuleSize 1703
Variable: DigimarcGiftCard 1713
Variable: DigimarcMaxBlocksToRead 1712
Variable: DigimarcMaxBlocksToReadActive 1710
Variable: DigimarcPerspectiveCorrection 1706
Variable: DigimarcTilt 1707
Variable: DotCodeTobaccoActive 697
Variable: DotCodeTobaccoBlurWindow 704
Variable: DotCodeTobaccoCloseDiagonal 709
Variable: DotCodeTobaccoCloseX 710
Variable: DotCodeTobaccoCloseY 712
Variable: DotCodeTobaccoDeviationLengthX 713
Variable: DotCodeTobaccoDeviationLengthY 714
Variable: DotCodeTobaccoDotDiameter 700
Variable: DotCodeTobaccoHeight 702
Variable: DotCodeTobaccoOrientation 698
Variable: DotCodeTobaccoSauvolaK 706
Variable: DotCodeTobaccoSauvolaR 708
Variable: DotCodeTobaccoSauvolaWindow 705
Variable: DotCodeTobaccoWidth 701
Variable: DottedPostalCodes 1681
Variable: DPMCodeTypeChoice 651
Variable: DPMDataMatrixActive 653
Variable: DPMDataMatrixAllowRectangular 670
Variable: DPMDataMatrixCodeBackground 676
Variable: DPMDataMatrixCodeContrast 675
Variable: DPMDataMatrixCodeDirection 673
Variable: DPMDataMatrixContrastTolerance 688
Variable: DPMDataMatrixDecodingLevel 654
Variable: DPMDataMatrixFinderPatternTolerance 686
Variable: DPMDataMatrixFixedNumCodes 658
Variable: DPMDataMatrixGeometricDistortion 672
Variable: DPMDataMatrixMaxCellSize 661
Variable: DPMDataMatrixMaxGapCol 685
Variable: DPMDataMatrixMaxGapRow 682
Variable: DPMDataMatrixMaxNumCols 668
Variable: DPMDataMatrixMaxNumRows 664
Variable: DPMDataMatrixMaxSkew 679
Variable: DPMDataMatrixMinCellSize 660
Variable: DPMDataMatrixMinGapCol 683
Variable: DPMDataMatrixMinGapRow 680
Variable: DPMDataMatrixMinNumCols 666
Variable: DPMDataMatrixMinNumRows 662
Variable: DPMDataMatrixNumCodes 657
Variable: DPMDataMatrixSmallCells 678
Variable: DPMDataMatrixTimeout 656
Variable: DPMQRModelType 690
Variable: DPMQRVersionMax 694
Variable: DPMQRVersionMin 691
Variable: DpsFocusPositions 2086
Variable: DpsFocusPositionsExt 2088
Variable: DpsFocusPostSwitchDelayMs 2089
Variable: Dummy_FBParamEEprom_Type 2323
Variable: EAN128Active 377
Variable: EAN128FirstFC1Val 343
Variable: EAN128InsideFC1Val 344
Variable: EAN13Active 388
Variable: EAN8Active 381
Variable: EANUPCTransmitCheckDigit 285
Variable: eConveyorSpeed 2274
Variable: ED_AuxReadResultBarcodeType 2167

© SICK AG - Germany - All rights reserved

Variable: ED_AuxReadResultFrameRxHeader 2169
Variable: ED_AuxReadResultFrameRxTerminator 2170
Variable: ED_DataForwardDestination 2160
Variable: ED_DataForwardFrameRxHeader 2161
Variable: ED_DataForwardFrameRxTerminator 2163
Variable: ED_DataForwardFrameTxHeader 2164
Variable: ED_DataForwardFrameTxTerminator 2166
Variable: ED_DataStringAcqDefault 2172
Variable: ED_DataStringAcqFrameRxHeader 2173
Variable: ED_DataStringAcqFrameRxTerminator 2174
Variable: EIPAct 1311
Variable: EIPAssemblySizeInput 1323
Variable: EIPAssemblySizeOutput 1321
Variable: EIPControlBitsPlcOut 2297
Variable: EIPControlBitsPlcOutMask 1316
Variable: EIPDataFormat 1315
Variable: EIPHBEna 1317
Variable: EIPHBInterval 1319
Variable: EIPInterface 1336
Variable: EIPMode 1312
Variable: EIPMultiplex 1313
Variable: EIPRetrHB 1320
Variable: EIPTxBufferSize 1324
Variable: Emphasize1D 1958
Variable: EnableActiveScript 1342
Variable: EnableImageQueueTimeout 2116
Variable: EnableLineFeedMode 1952
Variable: EnableNciiForEveryNoReadImage 1948
Variable: EnableOptimizeObjCap 2119
Variable: EnableSkipImageByQueueSize 2117
Variable: EnableSMARTDecoder 373
Variable: EnableSystemOptimizingParameter 2138
Variable: EPSSource 2085
Variable: ESys 2335
Variable: Ether1AddressingMode 1089
Variable: Ether1AuxInputHandling 1338
Variable: Ether1AuxIPPort 1092
Variable: Ether1AuxProtocol 1090
Variable: Ether1DHCPFallback 1088
Variable: Ether1Enable 1335
Variable: Ether1IPAddress 1082
Variable: Ether1IPGateAddress 1083
Variable: Ether1IPMask 1085
Variable: Ether1IPSpeedDuplex 1086
Variable: EtherAddressingMode 1065
Variable: EtherAuxInputHandling 2158
Variable: EtherAuxIPPort 1047
Variable: EtherAuxProtocol 1046
Variable: EtherDHCPFallback 1067
Variable: EtherHostCoLaDialect 1040
Variable: EtherHostCustomProtNb 1232
Variable: EtherHostEnHB 1042
Variable: EtherHostFTPPassword 1032
Variable: EtherHostFTPProtocol 1029
Variable: EtherHostFTPUploadPath 1033
Variable: EtherHostFTPUsername 1031
Variable: EtherHostHBInterval 1043
Variable: EtherHostInputHandling 2157
Variable: EtherHostIPPort 1037
Variable: EtherHostIPServerAddress 1039
Variable: EtherHostMultiplex 1035
Variable: EtherHostProtocol 1028
Variable: EtherHostRetrHB 1044
Variable: EtherHostServerClient 1036
Variable: EtherIPAddress 1022
Variable: EtherIPGateAddress 1023
Variable: EtherIPMask 1025
Variable: EtherIPSpeedDuplex 1026
Variable: EtherMonCAN1 1062
Variable: EtherMonCAN2 1064
Variable: EtherMonOutputFormat1 1054
Variable: EtherMonOutputFormat2 1056
Variable: EtherMonSerAux 1057
Variable: EtherMonSerAux2 1060
Variable: EtherMonSerHost 1058
Variable: EtherMonSerHost2 1061
Variable: EtherRDT_ID 1050
Variable: EtherRDTIPPort 1051
Variable: EtherRDTIPServerAddress 1053
Variable: EtherRDTServerClient 1049
Variable: EtherUDPCoLaDialect 1071
Variable: EtherUDPIPPort 1069
Variable: EtherUpdateNeeded 1068
Variable: EVCheckEvtAct 2293
Variable: EVCheckMaxNbr 849
Variable: EVCheckMinNbr 846
Variable: EVCondtionDiag 852
Variable: EVCondtionNames 859
Variable: EVCondtions 857
Variable: EVMainGoodReadStruct 843
Variable: EVMaxNbrCodes 847
Variable: EVMinNbrCodes 844
Variable: EVRebootOnNoreadCntr 855
Variable: EVRebootOnNoreadEnable 854
Variable: EVUserDefCondtionNames 850
Variable: ExpanderScannerHRPosAlpha 1835
Variable: ExpanderScannerHRPosBeta 1836
Variable: ExpanderScannerHRPosGamma 1838
Variable: ExpanderScannerHRPosXCoord 1839
Variable: ExpanderScannerHRPosYCoord 1841
Variable: ExpanderScannerHRPosZCoord 1842
Variable: ExpanderScannerPosAlpha 1826
Variable: ExpanderScannerPosBeta 1827
Variable: ExpanderScannerPosGamma 1829
Variable: ExpanderScannerPosXCoord 1830
Variable: ExpanderScannerPosYCoord 1832
Variable: ExpanderScannerPosZCoord 1833
Variable: ExpNodalPoseAlphaOpti 1896
Variable: ExpNodalPoseBetaOpti 1897
Variable: ExpNodalPoseGammaOpti 1899
Variable: ExpNodalPoseXCoordOffset 1900
Variable: ExpNodalPoseYCoordOffset 1902
Variable: ExpNodalPoseZCoordOffset 1903
Variable: ExtDataStringDefault 870
Variable: ExtDeviceLoadFactoryDefaults 161
Variable: ExtDeviceWriteEeprom 163
Variable: ExtendedSegmentation 374
Variable: ExternalIlluminationMode 1582
Variable: ExternalLightConnectorMode 1584
Variable: ExtOut1Control 218
Variable: ExtOut1DurTime 215
Variable: ExtOut1DurTrack 216
Variable: ExtOut1Func 208
Variable: ExtOut1FuncEvCndExt 209
Variable: ExtOut1FuncTeachInMatchCodeEnh 1226
Variable: ExtOut1Logic 214

© SICK AG - Germany - All rights reserved

Variable: ExtOut1OffFunc 211
Variable: ExtOut1OffFuncEvCndExt 212
Variable: ExtOut2Control 229
Variable: ExtOut2DurTime 227
Variable: ExtOut2DurTrack 228
Variable: ExtOut2Func 219
Variable: ExtOut2FuncEvCndExt 221
Variable: ExtOut2FuncTeachInMatchCodeEnh 1227
Variable: ExtOut2Logic 225
Variable: ExtOut2OffFunc 222
Variable: ExtOut2OffFuncEvCndExt 224
Variable: ExtSensor1Control 239
Variable: ExtSensor1DebounceTime 236
Variable: ExtSensor1DebounceTrack 237
Variable: ExtSensor1Logic 234
Variable: ExtSensor1Sensitivity 233
Variable: ExtSensor2Control 246
Variable: ExtSensor2DebounceTime 243
Variable: ExtSensor2DebounceTrack 244
Variable: ExtSensor2Logic 242
Variable: ExtSensor2Sensitivity 240
Variable: FeedbackLedRedDuration 2018
Variable: FeedbackLedRedFunc 2015
Variable: FeedbackLedRedFuncExt 2016
Variable: FlashFrequencyControlEnable 1625
Variable: FlashFrequencyControlLevel 1612
Variable: FocusControlActive 1643
Variable: FocusControlBehavior 1639
Variable: FocusControlDistances 1644
Variable: FocusControlFocusDelayTime 1647
Variable: FocusControlFocusDelayTrack 1649
Variable: FocusControlLTRHysteresis 1664
Variable: FocusControlLTRManualOffset 1668
Variable: FocusControlLTRNodeID 1662
Variable: FocusControlLTRPostExpation 1666
Variable: FocusControlLTRUsFrontRearFocus 1669
Variable: FocusControlLTRXOffset 1665
Variable: FocusControlMLGIsMLGMaster 1658
Variable: FocusControlMLGIsUpsideDown 1661
Variable: FocusControlMLGNodeID 1660
Variable: FocusControlMLGZDistBeams 1657
Variable: FocusControlMLGZDistDeviceBeamLow 1655
Variable: FocusControlMode 1636
Variable: FocusControlPostExpansionTime 1653
Variable: FocusControlPostExpansionTrack 1654
Variable: FocusControlPreExpansionTime 1650
Variable: FocusControlPreExpansionTrack 1651
Variable: FocusControlSensorInput 1646
Variable: FocusControlSource 1637
Variable: FocusControlTimerTime 1640
Variable: FocusControlTimerTrack 1641
Variable: FocusPosition 1606
Variable: FrameRate 1608
Variable: FTPArchibPassword 1252
Variable: FTPArchiveClientTimeout 1258
Variable: FTPArchiveIPPort 1254
Variable: FTPArchiveMaxClients 1256
Variable: FTPArchiveMaxNumObjects 1260
Variable: FTPArchiveSendBufferSize 1255
Variable: FTPArchiveSLocalFileTimeout 1259
Variable: FTPArchivUsername 1251
Variable: FTPAuthenticationMethod 1242
Variable: FTPClientActive 1234
Variable: FTPDevUpload 1249
Variable: FTPEthIface 1239
Variable: FTPHostname 1238
Variable: FTPPassword 1245
Variable: FTPPathPrivateKey 1246
Variable: FTPProtocol 1241
Variable: FTPRootPath 1080
Variable: FTPServerIPAddress 1235
Variable: FTPServerIPPort 1237
Variable: FTPSrvEnabled 1075
Variable: FTPSrvPort 1079
Variable: FTPSrvUsrName 1078
Variable: FTPSrvUsrPassword 1076
Variable: FTPUploadPath 1247
Variable: FTPUsername 1243
Variable: GammaCorrectionTurningPoint10bit 1575
Variable: GatewayDNAddress 1288
Variable: GatewayDNBaudrate 1293
Variable: GatewayDNDevIDIsDNAdress 1290
Variable: GatewayDNInputDataLength 1294
Variable: GatewayDNOpMode 1291
Variable: GatewayDNOutputDataLength 1296
Variable: GatewayPBAddress 1285
Variable: GatewayPBDevIDIsPBAdress 1284
Variable: GatewayPBOpMode 1287
Variable: GatewaySerAux 1281
Variable: GatewaySerHost 1282
Variable: GeneralImgOutActive 2350
Variable: GlsCodeSelection 1968
Variable: GLSIncreaseAngleStability 1972
Variable: GoodReadLedDuration 2010
Variable: GoodReadLedFunc 2013
Variable: GoodReadLedFuncExt 2009
Variable: GS114Enabled 515
Variable: GS12DComponentMode 522
Variable: GS1DataBarActive 514
Variable: GS1DataBarStackedCodesActive 519
Variable: GS1EmulationEnabled 525
Variable: GS1ExpandedEnabled 517
Variable: GS1FixLenList 526
Variable: GS1HexASCIIOutput 523
Variable: GS1IntLenList 528
Variable: GS1LimitedEnabled 518
Variable: GS1Min3AdjacentSegments 529
Variable: GS1ModuleWidthTolerance 531
Variable: GS1MultiRead 521
Variable: GS1NorcaIssueUndecodableSymbols 534
Variable: GS1NorcaOutputVerifier 532
Variable: HasFieldbusConfigChanged 2268
Variable: HeartbeatString 823
Variable: HMIAllowMatchCodeTeachIn 1996
Variable: HMIAutoSetupChangeCode 2000
Variable: HMIAutoSetupChangeFocus 1997
Variable: HMIAutoSetupChangeImage 1999
Variable: HMIButtonMode 2002
Variable: HTWebserverEnabled 1279
Variable: IlluminationForFeedback 2012
Variable: IlluOffDelayEnable 1619
Variable: IlluOffDelayTime 1620
Variable: IlluSyncDevDelayMs 1617
Variable: IlluSyncEnable 1616
Variable: ImageAcqROI 1589
Variable: ImageBinningMode 1602

© SICK AG - Germany - All rights reserved

Variable: ImageMirroring 1593
Variable: ImageQueueTimeoutMM 2113
Variable: ImageQueueTimeoutMS 2115
Variable: ImageResolution 1591
Variable: ImageVerticalFlip 1592
Variable: ImgAcqBurstModeNumImages 1569
Variable: ImgAcqMode 1567
Variable: ImgDiagContinuousModCnt 1779
Variable: ImgDiagFileGoodReadNoRead 1732
Variable: ImgDiagFileName 1734
Variable: ImgDiagFileSystemInfo 1735
Variable: ImgDiagFileTimestamp 1736
Variable: ImgDiagFTPArchiv 1754
Variable: ImgDiagFTPArchiv2 1756
Variable: ImgDiagFTPFileCycleMethod 1744
Variable: ImgDiagFTPFileCycleModulo 1745
Variable: ImgDiagImageOutReduction 1776
Variable: ImgDiagImageSelection 1724
Variable: ImgDiagImageSelection2 1771
Variable: ImgDiagJpegCompressionEnabled 1772
Variable: ImgDiagJpegCompressionQuality 1775
Variable: ImgDiagMinConveyingPathMM 1778
Variable: ImgDiagNameTemplateString 1781
Variable: ImgDiagPathDate 1728
Variable: ImgDiagPathDevice 1725
Variable: ImgDiagPathDeviceName 1727
Variable: ImgDiagPathGoodReadNoRead 1731
Variable: ImgDiagPathHour 1729
Variable: ImgDiagSaveToSDCard 1747
Variable: ImgDiagSaveToSDCard2 1748
Variable: ImgDiagSDCardFileCycleMethod 1738
Variable: ImgDiagSDCardFileCycleModulo 1739
Variable: ImgDiagSendFTP 1750
Variable: ImgDiagSendFTP2 1753
Variable: ImgDiagSendFTPLegacyStyle 1751
Variable: ImgDiagSendSopas 1757
Variable: ImgDiagSendSopas2 1759
Variable: ImgDiagSopasFileCycleMethod 1741
Variable: ImgDiagSopasFileCycleModulo 1742
Variable: ImgDiagStoreCondition 1721
Variable: ImgDiagStoreCondition2 1768
Variable: ImgDiagStoreConditionExt 1722
Variable: ImgDiagStoreConditionExt2 1769
Variable: IncrDistance 1920
Variable: IncrDistribute 1923
Variable: IncrFixVelocity 1922
Variable: IncrSource 1919
Variable: InterchangeableLensfNumber 1715
Variable: InterchangeableLensfStr 1716
Variable: InterchangeableLensTransmission 1719
Variable: InterchangeableLensType 1718
Variable: InternalIlluminationColor 1581
Variable: InternalIlluminationMode 1579
Variable: InvalidIndex 1120
Variable: IpAddressChoiceForImageTransmission 1345
Variable: L61xIlluminationIntensity 1629
Variable: L61xIlluminationLEDStates1 1627
Variable: LabelAssFix 783
Variable: LabelAssMax 782
Variable: LabelAssTol 781
Variable: LabelPosTolerance 2112
Variable: LabelTimoutTime 811
Variable: LabelTimoutTimeActive 810
Variable: LabelTimoutTrack 813
Variable: LaetusDeviceName 2266
Variable: LaetusSerialNumber 2265
Variable: LastMaintenance 46
Variable: LedTimeout 1587
Variable: LedTimeoutEnabled 1603
Variable: LineFeedModeHorizontalScans 1953
Variable: LineFeedModeNumScansInImage 1955
Variable: LocationName 3
Variable: LogfCtrlDestinationSDCardActive 1790
Variable: LogfCtrlDiagFileName 1799
Variable: LogfCtrlDiagFormatTimestamp 1800
Variable: LogfCtrlDiagPathDate 1796
Variable: LogfCtrlDiagPathDevice 1793
Variable: LogfCtrlDiagPathDeviceName 1795
Variable: LogfCtrlDiagPathHour 1797
Variable: LogfCtrlRamMaxStorageSpaceMB 1789
Variable: LogfCtrlSDCardMaxStorageSpaceMB 1792
Variable: LogfCtrlSourceEthernetAuxActive 1787
Variable: LogfCtrlSourceEthernetHostActive 1786
Variable: LogfCtrlSourceSerialAuxActive 1784
Variable: LogfCtrlSourceSerialHostActive 1783
Variable: LogisticsFalsePositiveFilter 1696
Variable: ManualBlobIpAddress 1348
Variable: ManualBlobTcpPort 1349
Variable: MaxCodesPerRegion1D 1678
Variable: MaxiCodeActive 615
Variable: MaxiCodeMode2Active 619
Variable: MaxiCodeMode3Active 624
Variable: MaxiCodeMode4Active 622
Variable: MaxiCodeMode5Active 623
Variable: MaxiCodeMode6Active 620
Variable: MaxiCodePrimaryMessage 616
Variable: MaxiCodeVerifierEnable 618
Variable: MaxIndexValue 1119
Variable: MaxModuleSize2DMM 542
Variable: MaxNum1DCodes 1688
Variable: MaxNum1DCodesEnabled 1687
Variable: MaxNumDMxCodes 1689
Variable: MaxNumDMxCodesEnabled 1699
Variable: MaxNumMaxiCodes 1693
Variable: MaxNumMaxiCodesEnabled 1692
Variable: MaxNumQRCodes 1691
Variable: MaxNumQRCodesEnabled 1697
Variable: MaxTolerance3D 787
Variable: MCMountingAngleAlphaCompensationActive 1971
Variable: MinModuleSize2DMM 539
Variable: MinTolerance3D 786
Variable: ModbusAddress 1327
Variable: ModbusCommandWord 2318
Variable: ModbusResultBuf 2319
Variable: ModbusResultChangeCtr 2321
Variable: ModbusTcpMode 1326
Variable: MorphologicalFilter 1578
Variable: MSIPlesseyActive 493
Variable: MSIPlesseyCheckDigitTest 496
Variable: MSIPlesseyFixLenList 500
Variable: MSIPlesseyIntLenList 501
Variable: MSIPlesseyLengthMode 498
Variable: MSIPlesseyMultiRead 494
Variable: MSIPlesseyTransmitCheckDigit 497
Variable: MTIChannel1Condition 1989
Variable: MTIChannel2Condition 1994

© SICK AG - Germany - All rights reserved

Variable: MTIChannelSettings1 1986
Variable: MTIChannelSettings2 1991
Variable: MTIChannelStopSettings1 1988
Variable: MTIChannelStopSettings2 1993
Variable: MTIGeneralSettings 1984
Variable: MultiCodeCenterOffsetEnabled 1974
Variable: MultiCodeGridModuleSize 1969
Variable: NetDeviceID 1131
Variable: NetMasterSlave 1132
Variable: NetMonAssignment1 1139
Variable: NetMonAssignment2 1142
Variable: NetMonDevList1 1141
Variable: NetMonDevList2 1143
Variable: NetMonTimeout 1145
Variable: NetMultiplexerAssignment 1137
Variable: NetServerList 1138
Variable: NetSlaveList 1135
Variable: NetworkAssignment 1134
Variable: NextMaintenance 47
Variable: NodalPoseAlphaOpti 1887
Variable: NodalPoseBetaOpti 1888
Variable: NodalPoseGammaOpti 1890
Variable: NodalPoseXCoordOffset 1891
Variable: NodalPoseYCoordOffset 1893
Variable: NodalPoseZCoordOffset 1894
Variable: NoiseReductionFilter 1577
Variable: NORCAVerification 1680
Variable: NumFramesInQueue 1571
Variable: ObjectReleasePoint 777
Variable: ObjTrigSource 1117
Variable: OCR3AbortTime_ms 734
Variable: OCR3Classifier 746
Variable: OCR3DoDeslant 742
Variable: OCR3DontUseHW 741
Variable: OCR3DoRowFind 737
Variable: OCR3DoTraining 739
Variable: OCR3EdgeWidth 755
Variable: OCR3FieldingMode 745
Variable: OCR3IdealCharacterIndices 752
Variable: OCR3NumBlocks 757
Variable: OCR3NumRows 738
Variable: OCR3RowConfigArray 753
Variable: OCR3RowConfigExArray 761
Variable: OCR3SlantAngleInDegrees 744
Variable: OCR3SubstituteCharacter 749
Variable: OCR3ThresholdGain 758
Variable: OCR3ThresholdOffset 760
Variable: OCR3UseAlternateScore 748
Variable: OCR3UseFullReader 735
Variable: OCR3UseIdealCharacter 750
Variable: OCRActive 716
Variable: OCRDiagLevel 729
Variable: OCRPreprocessMode 724
Variable: OCRReferenceCodeRegion 720
Variable: OCRReferencePatternExclusionRegions 723
Variable: OCRReferencePatternRegion 722
Variable: OCRRegion 719
Variable: OCRRegionFinderDoTraining 726
Variable: OCRRegionReferenceMode 717
Variable: OCRShowScores 727
Variable: OFEmbodimentMode 824
Variable: OFTemplateString1 832
Variable: OFTemplateString1Maximized 826
Variable: OFTemplateString2 834
Variable: OFTemplateString2Maximized 827
Variable: OFTemplateStringFixString1 828
Variable: OFTemplateStringFixString2 830
Variable: OFTemplateStringFixString3 831
Variable: OFUsageMode2 836
Variable: OPCondASAPenum 794
Variable: OPCondASAPstruct 795
Variable: OPSendPointNonTracking 817
Variable: OPSendPointTracking 792
Variable: OptimizeBad1DDecoding 1956
Variable: OptimizeTireReading 1684
Variable: OSDescription 2272
Variable: Out1Control 74
Variable: Out1DurTime 72
Variable: Out1DurTrack 73
Variable: Out1Func 87
Variable: Out1FuncEvCndExt 66
Variable: Out1FuncTeachInMatchCodeEnh 1219
Variable: Out1Logic 70
Variable: Out1Mode 185
Variable: Out1OffFunc 67
Variable: Out1OffFuncEvCndExt 69
Variable: Out1ScopingEnabled 190
Variable: Out1ScopingExtraDelay 191
Variable: Out2Control 84
Variable: Out2DurTime 82
Variable: Out2DurTrack 83
Variable: Out2Func 86
Variable: Out2FuncEvCndExt 76
Variable: Out2FuncTeachInMatchCodeEnh 1221
Variable: Out2Logic 80
Variable: Out2Mode 186
Variable: Out2OffFunc 77
Variable: Out2OffFuncEvCndExt 79
Variable: Out2ScopingEnabled 193
Variable: Out2ScopingExtraDelay 194
Variable: Out3Control 173
Variable: Out3DurTime 171
Variable: Out3DurTrack 172
Variable: Out3Func 198
Variable: Out3FuncEvCndExt 165
Variable: Out3FuncTeachInMatchCodeEnh 1222
Variable: Out3Logic 169
Variable: Out3Mode 187
Variable: Out3OffFunc 166
Variable: Out3OffFuncEvCndExt 168
Variable: Out4Control 183
Variable: Out4DurTime 181
Variable: Out4DurTrack 182
Variable: Out4Func 197
Variable: Out4FuncEvCndExt 175
Variable: Out4FuncTeachInMatchCodeEnh 1224
Variable: Out4Logic 179
Variable: Out4Mode 189
Variable: Out4OffFunc 176
Variable: Out4OffFuncEvCndExt 178
Variable: OutputDelayTime 801
Variable: OutputDelayTrack 802
Variable: OutputOutputMode 821
Variable: OutputSendingPointDistance 798
Variable: OutputSendingPointReference 797
Variable: OutputSendingPointTime 799

© SICK AG - Germany - All rights reserved

Variable: OutputTimingControl 791
Variable: PanoramaHoodActive 1613
Variable: PanoramaHoodImageOverlapping 1615
Variable: ParameterSetEnabled 2107
Variable: ParameterSetEnabledExt 2109
Variable: ParameterSets 2091
Variable: ParameterSetsDPMDMXPrettyString 2099
Variable: ParameterSetsDPMDMXPrettyStringExt 2100
Variable: ParameterSetsDPMDMXString 2096
Variable: ParameterSetsDPMDMXStringExt 2097
Variable: ParameterSetsExt 2092
Variable: ParameterSetsIlluminationColor 2093
Variable: ParameterSetsIlluminationColorExt 2095
Variable: ParameterSetsL61xIlluminationIntensity 2104
Variable: ParameterSetsL61xIlluminationIntensityExt 2106
Variable: ParameterSetsL61xIlluminationLEDStates1 2102
Variable: ParameterSetsL61xIlluminationLEDStates1Ext 2103
Variable: ParameterSwitchingMode 2082
Variable: PDF417Active 610
Variable: PDF417DecodingLevel 613
Variable: PDF417Truncated 611
Variable: Pharm2DigitsEnable 364
Variable: PharmaActive 346
Variable: PharmAddQuietZoneFact 367
Variable: PharmBarSizeMax 358
Variable: PharmBarSizeMin 357
Variable: PharmCheckBarGapActive 355
Variable: PharmDecimalOutput 371
Variable: PharmDensityQuietZone 368
Variable: PharmGapSizeMax 361
Variable: PharmGapSizeMin 360
Variable: PharmLength 353
Variable: PharmLengthMode 351
Variable: PharmLimitTolSize 363
Variable: PharmMinPercUndisturbedQuietZoneScans 370
Variable: PharmModuleWidthMode 348
Variable: PharmModuleWidthUserDefined 350
Variable: PharmMultiRead 347
Variable: PharmQuietzoneCheckEnable 366
Variable: PharmReverse 354
Variable: PlesseyActive 484
Variable: PlesseyFixLenList 489
Variable: PlesseyIntLenList 491
Variable: PlesseyLengthMode 488
Variable: PlesseyMultiRead 485
Variable: PlesseyTransmitCheckDigit 487
Variable: PMMovDectTimeout 2145
Variable: PMRepetitiveContentFilteringEnabled 2148
Variable: PMRepetitiveContentFilteringMaxAge 2151
Variable: PMRepetitiveContentFilteringNumObjects 2149
Variable: PMReTrigPause 2143
Variable: PMSensitivityThreshold 2142
Variable: PMShippEnabled 2235
Variable: PMSleepModeEnabled 2152
Variable: PMSleepTriggerTime 2146
Variable: PN1PortActive 1329
Variable: PNAutoDetect 1330
Variable: PNAutoDetectTO 1331
Variable: PoseEstimationFeedback 1881
Variable: PoseEstimationFinish 1886
Variable: PoseEstimationProcessFeedback 1884
Variable: PoseEstimationTargetOrientation 1880
Variable: PoseEstimationXOrigin 1876
Variable: PoseEstimationYOrigin 1877
Variable: PoseEstimationZOrigin 1879
Variable: PositionDeshadingActive 1815
Variable: PositionXOffset 1816
Variable: PositionYOffset 1817
Variable: PositionZOffset 1819
Variable: PostCodeActive 392
Variable: PostCodeDPI 395
Variable: PostCodeKixFixLenList 399
Variable: PostCodeKixIntLenList 401
Variable: PostCodeKixLengthMode 398
Variable: PostCodePostAustraliaAllowZeroFCC 435
Variable: PostCodePostAustraliaFixLenList 432
Variable: PostCodePostAustraliaIntLenList 434
Variable: PostCodePostAustraliaLengthMode 431
Variable: PostCodePostJapanFixLenList 428
Variable: PostCodePostJapanIntLenList 429
Variable: PostCodePostJapanLengthMode 426
Variable: PostCodePostSwedenFixLenList 459
Variable: PostCodePostSwedenIntLenList 460
Variable: PostCodePostSwedenLengthMode 457
Variable: PostCodeRawBarOutput2StateActive 462
Variable: PostCodeRawBarOutput2StateFixLenList 465
Variable: PostCodeRawBarOutput2StateIntLenList 466
Variable: PostCodeRawBarOutput2StateLengthMode 463
Variable: PostCodeRawBarOutput4StateActive 468
Variable: PostCodeRawBarOutput4StateFixLenList 471
Variable: PostCodeRawBarOutput4StateIntLenList 472
Variable: PostCodeRawBarOutput4StateLengthMode 469
Variable: PostCodeRMInfomailActive 414
Variable: PostCodeRMInfomailFixLenList 417
Variable: PostCodeRMInfomailIntLenList 419
Variable: PostCodeRMInfomailLengthMode 416
Variable: PostCodeRMMailmarkActive 402
Variable: PostCodeRMMailmarkFixLenList 405
Variable: PostCodeRMMailmarkIntLenList 407
Variable: PostCodeRMMailmarkLengthMode 404
Variable: PostCodeRMPostSingaporeActive 420
Variable: PostCodeRMPostSingaporeFixLenList 423
Variable: PostCodeRMPostSingaporeIntLenList 425
Variable: PostCodeRMPostSingaporeLengthMode 422
Variable: PostCodeRMRM4SCCActive 408
Variable: PostCodeRMRM4SCCFixLenList 411
Variable: PostCodeRMRM4SCCIntLenList 413
Variable: PostCodeRMRM4SCCLengthMode 410
Variable: PostCodesDependentSymbology 393
Variable: PostCodesOrientation 396
Variable: PostCodeUSPFixLenList 442
Variable: PostCodeUSPIntLenList 444
Variable: PostCodeUSPLengthMode 441
Variable: PostCodeUSPPlanetActive 439
Variable: PostCodeUSPPostNetActive 437
Variable: PostCodeUSPPostNetAllowBnBFields 438
Variable: PostCodeUSPUPUActive 445
Variable: PostCodeUSPUPUFixLenList 448
Variable: PostCodeUSPUPUIntLenList 450
Variable: PostCodeUSPUPULengthMode 447
Variable: PostCodeUSPUsps4StateActive 451
Variable: PostCodeUSPUsps4StateFixLenList 454
Variable: PostCodeUSPUsps4StateIntLenList 456
Variable: PostCodeUSPUsps4StateLengthMode 453
Variable: ProfileCodesForwardingEnabled 2233
Variable: ProfileCodesSharedKey 2232

© SICK AG - Germany - All rights reserved

Variable: QRCodeActive 626
Variable: QRDecodingLevel 634
Variable: QRFixLenList 630
Variable: QRFormatMode 636
Variable: QRGS1AIMarking 640
Variable: QRGS1FirstCharReplacement 637
Variable: QRGS1SeparatorCharReplacement 638
Variable: QRLengthMode 629
Variable: QRMode 627
Variable: QRVerISO18004 633
Variable: RCReadingAreaLimY1 1844
Variable: RCReadingAreaLimY2 1845
Variable: RCReadingAreaLimZ1 1847
Variable: RCReadingAreaLimZ2 1848
Variable: RDTCTCond1Enum 1147
Variable: RDTCTCond1Struct 1148
Variable: RDTCTCond2Enum 1150
Variable: RDTCTCond2Struct 1151
Variable: RDTCTCond3Enum 1152
Variable: RDTCTCond3Struct 1154
Variable: RDTEnableErrors 1158
Variable: RDTSendCommTraces 1156
Variable: RDTSendTraces 1155
Variable: RDTVMSEnableErrors 1162
Variable: RDTVMSSendCommTraces 1161
Variable: RDTVMSSendTraces 1159
Variable: ReadingDistanceInput 1605
Variable: ReadingStatisticEnabled 1200
Variable: ReleaseDelayTime 779
Variable: ResetOutOnTrigger 195
Variable: RotateDeShadingMetric 1634
Variable: RSCTCond1Enum 1201
Variable: RSCTCond1Name 1204
Variable: RSCTCond1Struct 1203
Variable: RSCTCond2Enum 1206
Variable: RSCTCond2Name 1209
Variable: RSCTCond2Struct 1207
Variable: RSCTCond3Enum 1210
Variable: RSCTCond3Name 1213
Variable: RSCTCond3Struct 1212
Variable: RSRefreshRunning 1216
Variable: RSRefreshTrigger 1217
Variable: ScanDensity1D 1677
Variable: ScannerHRPosAlpha 1823
Variable: ScannerHRPosBeta 1809
Variable: ScannerHRPosGamma 1811
Variable: ScannerHRPosXCoord 1812
Variable: ScannerHRPosYCoord 1813
Variable: ScannerHRPosZCoord 1820
Variable: ScannerPosAlpha 1824
Variable: ScannerPosBeta 1804
Variable: ScannerPosGamma 1805
Variable: ScannerPosXCoord 1807
Variable: ScannerPosYCoord 1808
Variable: ScannerPosZCoord 1821
Variable: Scanning1DRegionMode 1959
Variable: ScriptParam01 2176
Variable: ScriptParam02 2177
Variable: ScriptParam03 2179
Variable: ScriptParam04 2180
Variable: ScriptParam05 2181
Variable: ScriptParam06 2183
Variable: ScriptParam07 2184
Variable: ScriptParam08 2185
Variable: ScriptParam09 2187
Variable: ScriptParam10 2188
Variable: ScriptParam11 2189
Variable: ScriptParam12 2191
Variable: ScriptParam13 2192
Variable: ScriptParam14 2193
Variable: ScriptParam15 2195
Variable: ScriptParam16 2196
Variable: ScriptParam17 2197
Variable: ScriptParam18 2199
Variable: ScriptParam19 2200
Variable: ScriptParam20 2201
Variable: SCTimeFormat 30
Variable: SCUserInterfaceVariant 31
Variable: Sensor1Control 96
Variable: Sensor1DebounceTime 94
Variable: Sensor1DebounceTrack 95
Variable: Sensor1Logic 92
Variable: Sensor1Sensitivity 91
Variable: Sensor2Control 103
Variable: Sensor2DebounceTime 100
Variable: Sensor2DebounceTrack 102
Variable: Sensor2Logic 99
Variable: Sensor2Sensitivity 98
Variable: SerAuxBaudrate 1011
Variable: SerAuxEnHB 1017
Variable: SerAuxHardware 1016
Variable: SerAuxHBInterval 1019
Variable: SerAuxInputHandling 2155
Variable: SerAuxParity 1014
Variable: SerAuxProtocol 1010
Variable: SerAuxRetrHB 1020
Variable: SerAuxStopbits 1013
Variable: SerHostBaudrate 1000
Variable: SerHostCustomProtNb 1230
Variable: SerHostEnHB 1006
Variable: SerHostHardware 1004
Variable: SerHostHBInterval 1007
Variable: SerHostInputHandling 2154
Variable: SerHostMultiplex 998
Variable: SerHostParity 1003
Variable: SerHostProtocol 997
Variable: SerHostRetrHB 1008
Variable: SerHostStopbits 1001
Variable: SFParameter 841
Variable: SFStructure1 838
Variable: SFStructure2 839
Variable: SharpnessMeasuring 1674
Variable: ShippBeepDurationLong 2252
Variable: ShippBeepDurationShort 2251
Variable: ShippForceResultOutput 2249
Variable: ShippInhibitLoggingInPresentation 2248
Variable: ShippPrepModeActive 2245
Variable: ShippPrepPostWaitMs 2244
Variable: ShippPrepSteadyCount 2242
Variable: ShippPrepSteadyTimeMs 2241
Variable: ShippPrepTimeout 2253
Variable: ShippSnapBurstLength 2239
Variable: ShippSnapHostTimeoutMs 2238
Variable: ShippSnapModeActive 2246
Variable: ShippSnapPreDelayMs 2236
Variable: ShortBarHeight 1685

© SICK AG - Germany - All rights reserved

Variable: ShutterTime 1609
Variable: SizeFilter1DCodes 1960
Variable: SkipImageByQueueSize1 2121
Variable: SkipImageByQueueSize2 2124
Variable: SkipImageByQueueSize3 2127
Variable: SkipImageByQueueSize4 2130
Variable: SkipImageByQueueSize5 2133
Variable: SkipImgQueueFillLevel1 2120
Variable: SkipImgQueueFillLevel2 2123
Variable: SkipImgQueueFillLevel3 2125
Variable: SkipImgQueueFillLevel4 2128
Variable: SkipImgQueueFillLevel5 2131
Variable: SkipImgQueueFillLevel6 2134
Variable: SlaveTimeoutTime 814
Variable: SlaveTimeoutTrack 815
Variable: StandbyModeActive 2263
Variable: StartOfAssignment 789
Variable: StaticImageMode 2286
Variable: StaticImagePaused 2288
Variable: StaticImageSource 2285
Variable: SuperResolutionActive 1964
Variable: SVPActive 1262
Variable: SVPAppSrvIface 1266
Variable: SVPAppSrvIPAddress 1263
Variable: SVPAppSrvIPPort 1265
Variable: SVPImageTransfer 1267
Variable: SVPImgSrvIface 1272
Variable: SVPImgSrvIPAddress 1269
Variable: SVPImgSrvIPPort 1270
Variable: SVPImgSrvPassword 1274
Variable: SVPImgSrvUsername 1273
Variable: SVPOutputFormat 1276
Variable: SVPSendOnlyErrors 1277
Variable: SwiftPostCodeRMInfomailActive 477
Variable: SwiftPostCodeRMMailmarkActive 474
Variable: SwiftPostCodeRMRM4SCCActive 475
Variable: SwiftPostCodeUSPPlanetActive 479
Variable: SwiftPostCodeUSPPostNetActive 478
Variable: SwiftPostCodeUSPUPUActive 481
Variable: SwiftPostCodeUSPUsps4StateActive 482
Variable: SYNoQuickstart 1564
Variable: SYParaPasswordGuarded 1563
Variable: SYUIMode 1192
Variable: TcpPortChoiceForImageTransmission 1346
Variable: TelepenActive 503
Variable: TelepenFixLenList 510
Variable: TelepenIntLenList 512
Variable: TelepenLengthMode 509
Variable: TelepenMode 506
Variable: TelepenMultiRead 504
Variable: TelepenTransmitCheckDigit 507
Variable: TimeoutTime 803
Variable: TimeoutTrack 805
Variable: TimeServerIface 1186
Variable: TimeServerIPAddress 1183
Variable: TimeServerIPPort 1185
Variable: TimeSource 1182
Variable: TimeZoneOffset 1187
Variable: ToFDisabledForCompliance 2361
Variable: TrackingMode 774
Variable: TrackingTimeOut 775
Variable: TrigAutoCyclePauseTime 1105
Variable: TrigAutoCyclePauseTrack 1108
Variable: TrigAutoCyclePulseTime 1103
Variable: TrigAutoCyclePulseTrack 1106
Variable: TrigCANSource 1109
Variable: TrigControl 1094
Variable: TrigDistribute 1111
Variable: TrigExpansionTime 1112
Variable: TrigExpansionTrack 1113
Variable: TriggerEcho 1932
Variable: TrigPreExpansionTime 1115
Variable: TrigPreExpansionTrack 1116
Variable: TrigStartCondition 1936
Variable: TrigStartDelayTime 1095
Variable: TrigStartDelayTrack 1097
Variable: TrigStopCondition1 1939
Variable: TrigStopCondition1Ext 1928
Variable: TrigStopCondition2 1938
Variable: TrigStopCondition2Ext 1929
Variable: TrigStopCondition3 1941
Variable: TrigStopCondition3Ext 1931
Variable: TrigStopDelayTime 1101
Variable: TrigStopDelayTrack 1102
Variable: TrigStopTimerTime 1098
Variable: TrigStopTimerTrack 1099
Variable: UPCAActive 376
Variable: UPCEActive 385
Variable: UPCEANActive 382
Variable: UPCEANAddOnLength 282
Variable: UPCEANAddonMatchingStrategy 1965
Variable: UPCEANAddOnMode 280
Variable: UPCEANMultiRead 279
Variable: UPCEANStartCharacterValidation 289
Variable: UPCEANStopCharacterValidation 287
Variable: UPCEExtended 283
Variable: UPCENumSystem 286
Variable: Usage_CdfProfibusFhIn1 1305
Variable: Usage_CdfProfibusFhIn2 1307
Variable: Usage_CdfProfibusFhOut1 1302
Variable: Usage_CdfProfibusFhOut2 1304
Variable: UseCCDToWorldTransformMatrix 1595
Variable: UseExtParams 1333
Variable: UseFrameRate 1566
Variable: UseNumFramesInQueue 1570
Variable: UserDefTriggerStartCmd 1934
Variable: UserDefTriggerStopCmd 1935
Variable: UseReleaseDelayTime 778
Variable: VisualDecoProfiling 1774
Variable: vPBCommandX100 2312
Variable: vPBCommandX20 2308
Variable: vPBCommandX200 2313
Variable: vPBCommandX30 2309
Variable: vPBCommandX50 2311
Variable: vPBEndOfParam 2307
Variable: vPBGeneral2dCodeSettingRealValue 2302
Variable: vPBIllumAndAcquisitionSettings 2304
Variable: vPBSizeFilter1DCodes 2299
Variable: vPBSuperResolutionActive 2301
Variable: WoodTexture 1695
vCdfUpDatePnConfig 2316
VDPMAct 642
VDPMCalGain 643
VDPMCalMaxRefl 645
VDPMCalMeanRefl 646
VIbcsource 2276

© SICK AG - Germany - All rights reserved

VisualDecoProfiling 1774
vPBCommandX100 2312
vPBCommandX20 2308
vPBCommandX200 2313
vPBCommandX30 2309
vPBCommandX50 2311
vPBEndOfParam 2307
vPBGeneral2dCodeSettingRealValue 2302
vPBIllumAndAcquisitionSettings 2304
vPBSizeFilter1DCodes 2299
vPBSuperResolutionActive 2301

W

WARNING 2393
WoodTexture 1695
WriteEeprom 28
WriteFile 22

© SICK AG - Germany - All rights reserved

8031219/0000/2025-09-09/en

Australia
Phone +61 (3) 9457 0600
1800 33 48 02 – tollfree
E-Mail sales@sick.com.au

Austria
Phone +43 (0) 2236 62288-0
E-Mail office@sick.at

Belgium/Luxembourg
Phone +32 (0) 2 466 55 66
E-Mail info@sick.be

Brazil
Phone +55 11 3215-4900
E-Mail comercial@sick.com.br

Canada
Phone +1 905.771.1444
E-Mail cs.canada@sick.com

Czech Republic
Phone +420 234 719 500
E-Mail sick@sick.cz

Chile
Phone +56 (2) 2274 7430
E-Mail chile@sick.com

China
Phone +86 20 2882 3600
E-Mail info.china@sick.net.cn

Denmark
Phone +45 45 82 64 00
E-Mail sick@sick.dk

Finland
Phone +358-9-25 15 800
E-Mail sick@sick.fi

France
Phone +33 1 64 62 35 00
E-Mail info@sick.fr

Germany
Phone +49 (0) 2 11 53 010
E-Mail info@sick.de

Greece
Phone +30 210 6825100
E-Mail office@sick.com.gr

Hong Kong
Phone +852 2153 6300
E-Mail ghk@sick.com.hk

Hungary
Phone +36 1 371 2680
E-Mail ertekesites@sick.hu

India
Phone +91-22-6119 8900
E-Mail info@sick-india.com

Israel
Phone +972 97110 11
E-Mail info@sick-sensors.com

Italy
Phone +39 02 27 43 41
E-Mail info@sick.it

Japan
Phone +81 3 5309 2112
E-Mail support@sick.jp

Malaysia
Phone +603-8080 7425
E-Mail enquiry.my@sick.com

Mexico
Phone +52 (472) 748 9451
E-Mail mexico@sick.com

Netherlands
Phone +31 (0) 30 204 40 00
E-Mail info@sick.nl

New Zealand
Phone +64 9 415 0459
0800 222 278 – tollfree
E-Mail sales@sick.co.nz

Norway
Phone +47 67 81 50 00
E-Mail sick@sick.no

Poland
Phone +48 22 539 41 00
E-Mail info@sick.pl

Romania
Phone +40 356-17 11 20
E-Mail office@sick.ro

Singapore
Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Slovakia
Phone +421 482 901 201
E-Mail mail@sick-sk.sk

Slovenia
Phone +386 591 78849
E-Mail office@sick.si

South Africa
Phone +27 10 060 0550
E-Mail info@sickautomation.co.za

South Korea
Phone +82 2 786 6321/4
E-Mail infokorea@sick.com

Spain
Phone +34 93 480 31 00
E-Mail info@sick.es

Sweden
Phone +46 10 110 10 00
E-Mail info@sick.se

Switzerland
Phone +41 41 619 29 39
E-Mail contact@sick.ch

Taiwan
Phone +886-2-2375-6288
E-Mail sales@sick.com.tw

Thailand
Phone +66 2 645 0009
E-Mail marcom.th@sick.com

Turkey
Phone +90 (216) 528 50 00
E-Mail info@sick.com.tr

United Arab Emirates
Phone +971 (0) 4 88 65 878
E-Mail contact@sick.ae

United Kingdom
Phone +44 (0)17278 31121
E-Mail info@sick.co.uk

USA
Phone +1 800.325.7425
E-Mail info@sick.com

Vietnam
Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Detailed addresses and further locations at **www.sick.com**

SICK AG | Waldkirch | Germany | www.sick.com

SICK
Sensor Intelligence.