Key-Codes ESP32 – CH9350 (Based on old PS/2 Converter)
2022 By Jann Oesch [JOE/TRS]   () = Code not available by US Keyboard

Code	Tastenziffer	Code	Tastenziffer	Code	Tastenziffer	Code	Tastenziffer	Code	Tastenziffer	Code	Tastenziffer	Code	Tastenziffer
00	keine Taste	20	SPACE	40	@	60	`	80	S-SPACE	A0		C0		E0	CTRL-0
01	(Shift)	21	!	41	A	61	a	81	AG-A	A1	CTRL-A	C1	ALT-A	E1	CTRL-1
02	(Caps)	22	"	42	B	62	b	82	AG-B	A2	CTRL-B	C2	ALT-B	E2	CTRL-2
03	(CTRL)	23	#	43	C	63	c	83	AG-C	A3	CTRL-C	C3	ALT-C	E3	CTRL-3
04	(ALT)	24	$	44	D	64	d	84	AG-D	A4	CTRL-D	C4	ALT-D	E4	CTRL-4
05	(NUM)	25	%	45	E	65	e	85	AG-E	A5	CTRL-E	C5	ALT-E	E5	CTRL-5
06	(ALT GR)	26	&	46	F	66	f	86	AG-F	A6	CTRL-F	C6	ALT-F	E6	CTRL-6
07	(Windows)	27	'	47	G	67	g	87	AG-G	A7	CTRL-G	C7	ALT-G	E7	CTRL-7
08	Backspace	28	(	48	H	68	h	88	AG-H	A8	CTRL-H	C8	ALT-H	E8	CTRL-8
09	Tab ->	29	)	49	I	69	i	89	AG-I	A9	CTRL-I	C9	ALT-I	E9	CTRL-9
0A	(Apps/Menu)	2A	*	4A	J	6A	j	8A	GI-J	AA	CTRL-J	CA	ALT-J	EA	AG-5
0B	Tab <-	2B	+	4B	K	6B	k	8B	AH-K	AB	CTRL-K	CB	ALT-K	EB	AG-6
0C		2C	,	4C	L	6C	l	8C	AG-L	AC	CTRL-L	CC	ALT-L	EC	AG-7
0D	Return	2D	-	4D	M	6D	m	8D	AG-M	AD	CTRL-M	CD	ALT-M	ED	AG-8
0E	S-Return	2E	.	4E	N	6E	n	8E	AG-N	AE	CTRL-N	CE	ALT-N	EE	AG-9
0F	CTRL-Return	2F	/	4F	O	6F	o	8F	AG-O	AF	CTRL-O	CF	ALT-O	EF	PrintScr
10	Cursor Up	30	0	50	P	70	p	90	AG-P	B0	CTRL-P	D0	ALT-P	F0	Scroll Lock
11	Cursor Down	31	1	51	Q	71	q	91	AG-Q	B1	CTRL-Q	D1	ALT-Q	F1	F1
12	Cursor Left	32	2	52	R	72	r	92	AG-R	B2	CTRL-R	D2	ALT-R	F2	F2
13	Cursor Right	33	3	53	S	73	s	93	AG-S	B3	CTRL-S	D3	ALT-S	F3	F3
14	Home	34	4	54	T	74	t	94	AG-T	B4	CTRL-T	D4	ALT-T	F4	F4
15	Bild Up	35	5	55	U	75	u	95	AG-U	B5	CTRL-U	D5	ALT-U	F5	F5
16	Bild Down	36	6	56	V	76	v	96	AG-V	B6	CTRL-V	D6	ALT-V	F6	F6
17	Ende	37	7	57	W	77	w	97	AG-W	B7	CTRL-W	D7	ALT-W	F7	F7
18	Insert	38	8	58	X	78	x	98	AG-X	B8	CTRL-X	D8	ALT-X	F8	F8
19	StartZeile	39	9	59	Y	79	y	99	AG-Y	B9	CTRL-Y	D9	ALT-Y	F9	F9
1A	EndeZeile	3A	:	5A	Z	7A	z	9A	AG-Z	BA	CTRL-Z	DA	ALT-Z	FA	F10
1B	ESC	3B	;	5B	[	7B	{	9B	AG-1	BB	ALT-0	DB	ALT-5	FB	F11
1C		3C	<	5C	\	7C	|	9C	AG-2	BC	ALT-1	DC	ALT-6	FC	F12
1D		3D	=	5D	]	7D	}	9D	AG-3	BD	ALT-2	DD	ALT-7	FD	Rollen
1E		3E	>	5E	^	7E	~	9E	AG-4	BE	ALT-3	DE	ALT-8	FE	Pause
1F	PrintScreen	3F	?	5F	_	7F	DEL	9F	AG-5	BF	ALT-4	DF	ALT-9	FF	

AG = Alt Gr = Right ALT Key / S = Shift