

1. Welcome and safety

Thank you for choosing the Aurora T-200 Smart Thermostat. This guide covers installation, setup, everyday use, and troubleshooting.

In the box: the T-200 thermostat, the wall mounting plate, four mounting screws with drywall anchors, two AAA alkaline batteries, a sheet of wire labels, and a quick-start card.

SAFETY. Always switch off power to your heating and cooling equipment at the breaker before removing your old thermostat or wiring the T-200. The T-200 is a low-voltage control only: it must not be connected to a 120 V or 240 V line-voltage system, such as electric baseboard heat. If you are unsure what system you have, stop and consult a licensed HVAC technician. Do not install the thermostat in direct sunlight or above a heat source, as this will bias the temperature reading.

2. Specifications

Primary power: 24 VAC, supplied through the common (C) wire terminal. A C wire is required; the T-200 does not support power stealing.

Backup power: two AAA alkaline batteries, which preserve the clock and settings during a power loss.

Wire terminals: R and Rc (power), C (common), W and W2 (heat stages), Y and Y2 (cool stages), G (fan).

Setpoint range: 40 to 90 degrees Fahrenheit, adjustable in 1-degree steps.

Temperature sensor accuracy: plus or minus 0.5 degrees Fahrenheit.

Wi-Fi: 2.4 GHz 802.11 b/g/n only. The T-200 does not connect to 5 GHz networks.

Dimensions: 3.5 x 3.5 x 1.0 inches.

Operating environment: 32 to 104 degrees Fahrenheit, 5 to 90 percent relative humidity, non-condensing.

3. Installation, part 1: removing the old thermostat

1. Switch off power to the heating and cooling system at the breaker panel. Confirm the old thermostat's display is blank before continuing.
2. Remove the old thermostat's face from its base. Take a photo of the wiring so you have a reference.
3. Using the included labels, label each wire with the letter printed next to the terminal it currently occupies, not the colour of the wire.
4. Loosen the terminal screws, release the wires, and let them rest so they cannot fall back into the wall.
5. Unscrew and remove the old base plate from the wall.

4. Installation, part 2: mounting the T-200

1. Feed the wires through the opening in the new wall plate. Hold the plate against the wall, use the built-in bubble level to set it straight, and mark the screw holes.
2. Drill the marked holes, tap in the supplied anchors, and fasten the plate with the four screws.
3. Insert each labelled wire into the matching lettered terminal. Press the tab, insert the wire until it seats, and release. Tug gently to confirm it is held.
4. Align the thermostat body with the plate and press until it clicks.
5. Restore power at the breaker. The screen should light within ten seconds.

5. First-time setup

When the T-200 powers on for the first time it walks you through setup on screen.

1. Choose a display language.
2. Select your home Wi-Fi network and enter its password. Remember that only a 2.4 GHz network will appear in the list; if you run a combined network, you may need to enable the 2.4 GHz band or use a separate network name for it.
3. Open the Aurora Home app on your phone and either sign in or create an account, then scan the pairing code shown on the thermostat.
4. Confirm your date, time, and location so that schedules and daylight saving adjust automatically.

6. Everyday use

Setting the temperature: turn the outer dial, or tap the on-screen up and down arrows, to change the target temperature. The large number is the current room temperature; the smaller number is the target.

System mode: choose Heat, Cool, Auto, or Off. In Auto the thermostat switches between heating and cooling to keep the room between a low and a high target.

Fan mode: Auto runs the fan only during a heating or cooling call; On runs it continuously; Circulate runs it for a share of each hour to even out temperatures.

Hold: adjusting the target by hand starts a temporary Hold that keeps that setting until the next scheduled period. A permanent Hold ignores the schedule until you cancel it.

7. Schedules

A schedule lets the T-200 change target temperatures automatically through the day. Each day has up to four periods, named Wake, Away, Home, and Sleep, and you set a start time and a heat and cool target for each.

Weekdays and weekends are scheduled separately. After editing one day you can use 'Copy to' to duplicate its periods onto other days rather than re-entering them.

If you make a manual change while a schedule is running, the resulting temporary Hold lasts only until the next period begins, at which point the schedule resumes on its own.

8. Energy-saving features

Eco mode: when enabled, Eco mode widens both the heat and cool targets by 4 degrees from their scheduled values to cut runtime while you are asleep or out.

Adaptive Recovery: the thermostat learns how long your system takes to change the room temperature and starts heating or cooling early, so the room reaches the scheduled target at the scheduled time rather than starting from it.

Away detection: if you allow location access, the Aurora Home app tells the thermostat when everyone's phone has left a geofence around the house so it can drop to an economical setting, and to resume normal targets before you get home.

Energy report: each month the app summarises heating and cooling runtime and compares it with the previous month.

9. Maintenance and troubleshooting

Maintenance: replace the two AAA batteries once a year, or sooner if the low-battery icon appears. Clean the screen with a dry, soft cloth only; do not use liquids or sprays. After changing a furnace filter, reset the reminder under Settings > Maintenance.

Screen is blank: the system has no power. Check that the breaker is on and that a C wire is connected to the C terminal; check the AAA batteries.

Will not join Wi-Fi: confirm you are joining a 2.4 GHz network and that the password is correct; move the router closer or add an extender.

Heat will not start: check the wire in the W terminal; note that a built-in five-minute compressor delay can postpone the start of a call.

System short-cycles: raise the cycle-rate setting so the equipment runs longer per cycle.

Temperature reading looks high: make sure the thermostat is out of direct sun and away from lamps and electronics.

10. Warranty and support

Limited warranty: Aurora warrants the T-200 against defects in materials and workmanship for three years from the date of purchase. The warranty does not cover damage from improper installation, misuse, or connection to a line-voltage system.

FCC: this device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device may not cause harmful interference and must accept any interference received.

Support: reach Aurora support at 1-800-555-0142 or support@example.com, Monday to Friday, 8am to 8pm Eastern.

Factory reset: to erase all settings and Wi-Fi credentials, press and hold the dial for ten seconds until the screen shows RESET, then confirm. The thermostat restarts into first-time setup.