SIEMENS

Installation Instructions
Document ID A6V12344977
(insert for A6V11231622,
A6V10303476, A6V11231620,
A6V10333878, and A6V11231623)

Model FCM2041-U2
Operator Interface

IMPORTANT!

Scan this QR code to access the Manual and other important documentation for the Model FCM2041-U2 (A6V11231622) or go to:
https://www.siemens.com/download?A6V11231622

Scan this QR code to access the Device Compatibility Chart for the Compatible Notification Appliances (A6V10303476) or go to:
https://www.siemens.com/download?A6V10303476

Scan this QR code to access the Desigo Fire Safety Modular IOM Manual (A6V11231620) or go to:
https://www.siemens.com/download?A6V11231620

Scan this QR code to access the Installation Instruction Index for FireFinder-XLS (A6V10333878) or go to:
https://www.siemens.com/download?A6V10333878

Scan this QR code to access the FCM2041-U2 Installation Instruction (A6V11231623) or go to:
https://www.siemens.com/download?A6V11231623

CAUTION:
It is recommended that the printed circuit boards be removed for any procedure that may cause dust, metal shavings, grease or any such matter that may affect the circuit boards and/or parts. There may be several sources of power into the control unit. Each source must be disconnected prior to installing or connecting or disconnecting wiring.

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. Products or company names mentioned herein may be the trademarks of their respective owners. © 2021 Siemens Industry, Inc.

Siemens Industry, Inc.
Smart Infrastructure
8 Fernwood Road
Florham Park, NJ 07932

Siemens Canada, Ltd.
1577 North Service Road East
Oakville, Ontario L6H 0H6 Canada

Your feedback is important to us. If you have comments about this document, please send them to SBT_technical.editor.us.sbt@siemens.com

Document ID A6V12344977_en--_a
P/N A5W00161778

Printed in the USA