

Function	Instruction Template
Note: 1. The command contains <>; 2. IoT cards cannot accept real-name card SMS verification; 3. Telecom cards are not supported; 4. Short	
Upgrade	<HL&P:HOLLOO&1U:HBD200_V402632,47.106.157.21,21,ftp_holloo,ftp_holloo_ *TP_SZ, HBD200 _V402632.BIN,/,>
Query	<HLCK>
Restart the device	<HL&P:HOLLOO&1R:1>
Clear blind spot data	<HL&P:HOLLOO&1P:1,1,1,1>
Modify GPRS parameters	<HL&P:HOLLOO&B:58.61.154.237:7018>
Modify the second GPRS parameter	<HL&P:HOLLOO&E:58.61.154.237:7018>
Set up APN	<HL&P:HOLLOO&A:CMNET>
Change model ID	<HL&P:HOLLOO&D:F1E0,16>
Backhaul interval (small packets)	<HL&P:HOLLOO&1A:5>
Backhaul interval (large packet)	<HL&P:HOLLOO&3Z:30>
Ignition threshold	<HL&P:HOLLOO&1C:132>
Stalling return transmission interval	<HL&P:HOLLOO&3X:30>
Set low electricity alarm threshold	<HL&P:HOLLOO&1B:115>
Set fatigue driving duration	<HL&P:HOLLOO&1D:240>
Set overspeed threshold	<HL&P:HOLLOO&1E:120>
Duration of tachycardia	<HL&P:HOLLOO&1F:3>
Switch OBD	<HL&P:HOLLOO&5A:0>
Initial mileage consumption	<HL&P:HOLLOO&1L:00&1Y:00>

Heartbeat data interval	<HL&P:HOLLOO&1H:60,3600>
WIFI parameter	<HL&P:HOLLOO&1W:1,88888888,11111111>
Provincial ID	<HL&P:HOLLOO&3A:44>
Administrative region of a city ID	<HL&P:HOLLOO&3B:303>
Manufacturer ID	<HL&P:HOLLOO&3C:12345>
Terminal model	<HL&P:HOLLOO&3D:FH-VM010>
VIN code for departmental standard agreement	<HL&P:HOLLOO&3E:XB123456789012345>
Vehicle color	<HL&P:HOLLOO&3F:1>
License plate	<HL&P:HOLLOO&3G:01G12345>
Minimum rest period	<HL&P:HOLLOO&3N:20>
High-speed acceleration level	<HL&P:HOLLOO&5B:1>
Grade of rapid deceleration	<HL&P:HOLLOO&5C:1>
Sharp turn rating	<HL&P:HOLLOO&5D:1>
Collision grade	<HL&P:HOLLOO&5E:1>
Critical time points for emergency resuscitation	<HL&P:HOLLOO&5E:0>
Fuel consumption coefficient	<HL&P:HOLLOO&5S:140>
Mileage coefficient	<HL&P:HOLLOO&5T:140>

Print serial port log	<HL&P:HOLLOO&5P:0>
-----------------------	--------------------

Explain

SMS commands cannot contain spaces.

The command contains two firmware names: the first corresponds to the terminal version, and if identical, no upgrade is performed; the second is the target firmware. Upon successful upgrade, all device parameters are returned.

The firmware update occurs when the vehicle speed is zero; the upgrade process typically takes 3-5 minutes.

No SMS receipt

No SMS receipt

Format: &1P: a, b, c, d

a Vehicle data 1: Clear 0: Not clear

b Alarm data 1: Clear 0: Do not clear

c Alarm description data 1: Clear 0 / Do not clear d Driving behavior data 1: Clear 0 / Do not clear

Replace with the target IP and port. Supports domain name format.

Replace with the target IP and port. Supports domain name format.

Format: &A: apn, user, password

The APN field is mandatory. The User and Password fields are default values and may be omitted.

For example: &A: cmnet, admin, admin

Format: & D: cartype, cc

cartype model ID: for example F001

cc displacement: For example, 16 indicates 1.6 L

Location data packet (unit position information) feedback interval, default 5S

Interval for returning location data packets (including data streams), default: 30S

Format: &1C: volvalue

volvalue voltage threshold, unit 0.1V

12V system, default 13.2V

24 System default. 268

Format: &3X:repsecond repsecond

Return interval time, in seconds

Format: &1B: volvalue

volvalue voltage threshold, unit 0.1V

Format: &1D: minute

minute unit minute

Format: &1E: speed

Speed threshold, unit: Km/h

Format: &1F: spdtim

spdtim Duration of overspeed: in seconds

(0 means off; 1 means on)

Format: &1Y: fuel

Fuel initial oil quantity unit: ml

Format: &1L: mile

mile

Format: &1H: account time, off account time AccoTime device normal operation heartbeat packet interval (in the absence of other communication data) in seconds; AccoTime device sleep wake-up interval in seconds
Format: &1W: state, user, password state Switch state 1 On Wi-Fi 0 Off Wi-Fi userwifi username (default device ID) passwordwifi password (default 12345678) for example: &1W:1,88888888,11111111
Format: &3A:val val provincial ID For example: &3A:44
Format: &3B:val val administrative region of a city ID For example: &3B:303
Format: &3C:val The manufacturer ID of the val device is fixed at 5 bytes. For example: &3C:12345
Format: &3D:val The terminal model identifier is fixed at 8 bytes For example: &3D: FH-VM010
Format: &3E: string The VIN code for a vehicle is fixed at 17 bytes, for example: &3E: XB123456789012345
Format: &3F:val License plate colors: 1 blue, 2 yellow, 3 black, 4 white. For example: &3F:1
Format: &3G: aaXXXXXX aa: The license plate address serial number starts from 00, following the sequence: Beijing, Zhejiang, Tianjin, Anhui, Shanghai, Fujian, Chongqing, Guangdong, Shandong, Macau, Henan, Inner Mongolia, Hubei, Xinjiang, Hunan, Ningxia, Guangdong, Tibet, Hainan, Guangxi, Sichuan, Sichuan, Hebei, Guizhou, Shanxi, Yunnan, Yunnan, Liaoning, Shaanxi, Shaanxi, Shaanxi, Jilin
Format: &3N:val val fatigue time in minutes For example: &3N:20
Format: &5B:val For example: &5B:1; eg: 3: High sensitivity; 2: Medium sensitivity; 1: Low sensitivity; 0: Off
Format: &5C:val For example: &5C:1; eg: 3: High sensitivity; 2: Medium sensitivity; 1: Low sensitivity; 0: Off
Format: &5D:val For example: &5D:1; eg: 3: High sensitivity; 2: Medium sensitivity; 1: Low sensitivity; 0: Off
Format: &5E:val For example: &5E:1; eg:3: High sensitivity; 2: Medium sensitivity; 1: Low sensitivity; 0: Off
Format: &5F:val For example: &5E:0; eg:1. The system supplements 0200 data from 1 second before and after the three urgent triggers. The default value is 0, with a maximum support setting of 10 seconds, and the default is 0.
Format: &5S: For example, &5S:140 indicates a fuel consumption coefficient of 1.4; the default is 100, which equals 1.0.
Format: &5T: For example, &5T:140 indicates a mileage coefficient of 1.4; the default is 100, which equals 1.0.

Format: &5P

For example: &5P:0

0: Turn off all logs;

1: Open only system logs

2: Open only the GSM section logs

4: Open only the diagnostic section logs

8: OBD Interactive Data Flow Log

10: GPS data logging: Send TOGPS lenHlenLdata1..dataN to transmit len-length data to the GPS module.

The mask corresponding to the hexadecimal number: bit0: System, bit1: GSM, bit2: Diagnosis (set to 1 for enabled, 0 for disabled).

Parameter	Explain
<HL&P:HOLLOO	Characteristic
&V:HBD200_V402631	Software version number
&A:CMMTM	APN
&B:58.61.154.237:7018	IP and port
&C:019170535373	Equipment ID
&D:0000,16	Motorcycle type ID
&1A:5	Set the data packet retransmission interval
&1B:115	Low threshold voltage (accuracy 0.1V)
&1C:132	Ignition threshold (precision 0.1V)
&1D:240	Fatigue Driving Threshold (min)
&1E:120	Hyperglycemic threshold (kmol/L)
&1F:3	Duration of overspeeding S
&1H:40,14400	Heartbeat data interval
&1L:8274	Mileage (M)
&1Y:3242	Fuel consumption (ml)
&1J:190,6,6,2	Rapid acceleration parameter
&1K:240,6,8,2,18	Rapid deceleration parameters
&1M:240,20,80,6	Sharp turn parameter
&1N:1,15,20	Trailer alarm parameters
&1O:1,300,240,1500	Collision alarm parameter
&3A:44	Provincial ID
&3B:303	Administrative region of a city ID
&3C:66688	Manufacturer ID
&3D:HB-D200	Terminal model
&3F:1	Vehicle color
&3G:17B88888	License plate
&3H:0	Reporting Strategy
&3J:5	Schedule report settings
&3K:300	Fixed Interval Reporting Settings
&3L:240	Fatigue Driving Settings
&3M:0	Pre-drive alert setting
&3N:20	Minimum rest period
&3P:120	Hyperglycemic threshold (kmol/L)
&3Q:10	Pre-excess speed threshold
&3V:190	TTS playback volume
&3S:540000000000	Police ID
&3W:0	Location type
&3O:0	Register, Log Out, and Settings
&3X:30	Stalling return transmission interval
&3Z:30	OBD data transmission interval
&5A:1	Switch OBD
&5B:2	High-speed acceleration level
&5C:2	Grade of rapid deceleration
&5D:2	Sharp turn rating
&5E:2	Collision grade
&5F:5	Level 3 catch-up supplementation timing
&5P:8	Print log enable disable command, default is disabled
&5R:70	OBD data stream transmission interval
&5S:10	Fuel consumption coefficient
&5T:10	Mileage coefficient
&5X:500>	Collision alarm data XYZ axis acquisition frequency