



An Introduction to Kconfig / prj.conf

- `prj.conf` sets Kconfig symbols that shape features, drivers, and build options.
- Kconfig enforces dependencies and provides defaults for each board and module.
- Overlay configs (e.g., `boards/\*.conf`) fine-tune per-board tweaks.

```
zephyr-esp32s3-course > apps > blinky > ⚙ prj.conf
1  # esp32s3_demo/prj.conf
2  CONFIG_GPIO=y
3  CONFIG_LOG=y
4  CONFIG_LOG_DEFAULT_LEVEL=3
5  CONFIG_MAIN_STACK_SIZE=4096
6
7  # Comms
8
9  CONFIG_CONSOLE=y
10 CONFIG_UART_CONSOLE=y
11 CONFIG_SERIAL=y
12 CONFIG_STDOUT_CONSOLE=y
13
14 # For debug
15 CONFIG_DEBUG=y
16 CONFIG_DEBUG_THREAD_INFO=y
17 CONFIG_ASSERT=y
18
19
```

Key idea: Kconfig is Zephyr's feature control system for your app.