

Microwave: Amana 1000/1100

Card No. MC097

Perform Maintenance Check

Frequency

Weekly

Models

Amana 1000/1100

Estimated Time to Complete

10 Minutes

Health & Safety Hazards

Food Safety



Wash and dry hands **after** performing this task



Ensure nuts, bolts & screws are tight



Inspect equipment. Do not use if damaged

Check for the Following

- 1 Electrical plug for loose screws and loose/damaged wires
- 2 Power cable for kinks/nicks/splits of other damage
- 3 Power cable entry to appliance, ensure is secure and wires not damaged
- 4 All 4 Rubber feet are present and secure
- 5 Timer membrane is not damaged or severely worn
- 6 All locking nuts are present at the back of the Microwave and are tightened (These secure the side and top panels to the Microwave)
- 7 Front door handle is secure, opens and latches close ensuring a tight seal
- 8 Inside front door all screws are present and tightened
- 9 **NB Unplug the unit at the main socket.** Unclip Splatter Shield. Check the condition (no cracks or damage)
- 10 Locate the fan on the underside of the microwave. Check the fan is free to rotate and there is no damage to the fins
- 11 Clip the Splatter Shield back into position **NB** Reconnect the power supply to the microwave

