

MerryChef Ovens

Card No: MC098

Perform Maintenance Check

Frequency	Weekly
Models	All
Estimated Time to Complete	10 Minutes

Health and Safety Hazards

-  Sharp objects / surfaces
-  Hot Surfaces

Food Safety

-  Wash and dry hands **before and after** performing this task
-  Ensure nuts, bolts & screws are tight
-  Inspect equipment. Do not use if damaged



Check for the following:

1. Check impinger plate inside oven cavity to ensure there are at least 2 fixing bolts/screws present, tight and free from corrosion*
2. Check all other bolts/screws are present and secure*
3. Check door gasket/seal and ensure intact, not hanging loose or has any sections broken away or cracked*
4. Check power cord and plug for damage*

*Place a Next Visit call out with your approved Catering Company to replace any loose, missing or corroded bolts/screws, and/or damaged door seal, power cord/plug

