this corner → scanner's arrow corner

✂ Cut out along the dashed line.

The card goes here, face down, edges roughly on the little ticks.

SHEET 1 · FRAME

Grade Check scan guide

Reusable. Puts every card in the same spot, on black.

1. Cut out the window on the dashed line.
2. Lay this sheet on the glass, **this side up**, blue corner in the scanner's arrow corner. Leave it there.
3. Drop the card into the window, **face down**.
4. Lay **sheet 2** on top, **black side down**.
5. Close the lid gently. First time: press **Find my card** in Grade Check.

Back of the card: flip it inside the window. 180° scans: turn it upside down in place. Sheet 2 just lifts off and goes back on.

Why black?

The scanner looks up through the glass. With black behind the card and around it, the card's edges stand out sharply, so whitening, nicks and soft corners show up. Keep both black sides clean: dust or scuffs on the black can look like defects.



Scale check: this ruler should measure exactly 3 inches.

Back of sheet 1. This black block surrounds the window on the glass side, so the scanner sees black right up to the card.

