

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Piaggio - mp3_250_ie

PIAGGIO WOULD LIKE TO THANK YOU

for choosing one of its products. We have prepared this manual to help you to get the very best from your scooter.
Please read it carefully before riding
the scooter for the first time. It contains information, tips and precautions for using your scooter. It also describes features, details and devices to assure
you that you have made the right choice. We believe that if you follow our suggestions, you will soon get to know your new vehicle and it will serve you well for a long time to come. This booklet forms an integral part of the scooter; should the scooter be sold, it must be transferred to the new owner.

MP3 250 i.e.

The instructions given in this manual are intended to provide a clear, simple guide to using your scooter; this booklet also details routine maintenance procedures and regular checks that should be carried out on the vehicle at an authorised Dealer or Service Centre . The booklet also contains instructions for simple repairs. Any operations not specifically described in this manual require the use of special tools and/or particular technical knowledge: to carry out these operations refer to any authorised Dealer of Service Centres .

Personal safety

Failure to completely observe these instructions will result in serious risk of personal injury.

Safeguarding the environment

Sections marked with this symbol indicate the correct use of the vehicle to prevent damaging the environment.

Vehicle intactness

The incomplete or non-observance of these regulations leads to the risk of serious damage to the vehicle and sometimes even the invalidity of the guarantee.

The signs that you see on this page are very important. They are used to highlight those parts of the booklet that should be read with particular care. As you can see, each sign consists of a different graphic symbol, making it quick and easy to locate the various topics.

INDEX

VEHICLE	7
Dashboard	9
Analogue instrument panel	10
Clock	12
Digital lcd display	13
Maintenance icons	13
MODE button	14
Key switch	14

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Locking the steering wheel	14
Releasing the steering wheel	14
Switch direction indicators	15
Horn button	15
Light switch	16
Emergency flashing light button	16
Start-up button	17
Engine stop button	17
Front suspension unlock-lock switch	18
The immobilizer system	18
Keys	18
Immobilizerdevice enabled indicator led	20
Operation	20
Programming the immobilizer system	21
Saddle opening remote control	22
Remote control programming	22
Accessing the fuel tank	24
The saddle	25
Opening the saddle to access the helmet compartment by remote control	26
Opening the saddle to access the helmet compartment in an emergency	27
Opening of top box	28
Identification	28
USE.....	29Checks
.....	30
Refuelling	31
Tyre pressure	33
Shock absorbers adjustment	34
Running in	35
Starting up the engine	36
Precautions	39
Difficult start up	39
Stopping the engine	40
Stand	40
Automatic transmission	41
Safe driving	41
Front suspension locking system	44
MAINTENANCE	49
Engine oil level	50
Engine oil level check	50
Engine oil top-up	50
Warning light (insufficient oil pressure)	50
Engine oil change	51
Hub oil level	52

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Tyres	54
Spark plug dismantlement	55
Removing the air filter	56
Air filter cleaning	56
Cooling fluid level	57
Checking the brake oil level	58
Braking system fluid top up	58
Battery	60
Use of a new battery	60
Long periods of inactivity	61
Fuses	61
Front light group	66
Headlight adjustment	66
Front direction indicators	70
Rear optical unit	70
Number plate light	72
Helmet compartment lighting bulb	72
Rear-view mirrors	73
Front and rear disc brake	73
Puncture	74
Periods of inactivity	75
Cleaning the vehicle	75
TECHNICAL DATA	81
Kit equipment	85
SPARE PARTS AND ACCESSORIES	87
Warnings	88
PROGRAMMED MAINTENANCE	91
Scheduled maintenance table	92

MP3 250 i.e.

Chap. 01

Vehicle

Dashboard (01_01, 01_02)

A = Ignition key-switch

B = Starter button

C = Throttle control

D = Front brake lever

E = Turn indicator switch

F = Headlight switch

G = Rear brake lever

H = Horn button

I = Engine cut-off switch

L = Mode switch

M = Emergency turn indicator switch

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

N = Analogue instrument panel

O = Indicator unit

P = Bag hook