

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Benelli - montaggio_manutenzione_nuovo_english

Tornado Naked Tre 899 - Tornado Naked Tre 899 S

Owner's Manual

Tornado Naked Tre 899

1 General information	1
1.1 Symbols	2
.....	3
2 Safety information	5
2.1 Safety	5
2.1.1 Personalization	5
2.1.2 General safety regulations	6
2.1.3 Vehicle load	8
2.1.4 Use of the vehicle in competitions.....	9
2.1.5 Advices for safe riding	9
2.1.6 Protective clothing	12
2.1.7 Suggestions against theft	13
2.2 Safety - Visual and acoustic signals	14
3 Controls and instruments	15
3.1 Location of controls and instruments.....	15
3.2 Side stand	16
3.3 Handlebar controls, left side	17
3.4 Handlebar controls, right side	19
3.5 Ignition switch and steering lock.....	21
3.6 Gear lever	23
3.7 Instruments and warning lights.....	24
3.7.1 Multifunction display	25
4 Operation	28
4.1 Using the motorcycle	28
4.2 Preriding checks	29
4.3 Running-in	31
4.6 Parking the motorcycle	32
4.7 Saddle disassembly driver.....	33
4.8 Saddle disassembly passenger.....	33
4.9 Refuelling	34
4.10 Starting the engine	36
4.11 Improve our riding skills	37
5 Adjustments	38
5.1 List of adjustments	39
5.2 Recapitulatory table of adjustments.....	40
5.3 Adjustments that can be done by user...41	
5.3.1 Front brake lever adjustment	41
5.3.2 Adjusting the rearview mirrors	41

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

5.3.3 Front projector regulation	42
5.3.4 Adjustment of minimum engine rpm.....	42
5.3.5 Front projector lamps replacement	43
5.4 Adjustments that has to be done by a Benelli Q.J. Authorized Workshop	44
5.4.1 Clutch lever play	44
Tornado Naked Tre 899	
5.5 Adjusting the rear suspension	45
5.5.1 Adjusting rear suspension spring preload	47
5.5.2 Adjusting rear suspension rebound damper hydraulic device	47
6 Maintenance	49
6.1 Tables of scheduled maintenance and checks	49
6.3 Table of lubricants	59
6.4 Checking the engine oil level	60
6.4.1 Topping up the engine oil level	61
6.5 Checking the coolant level	63
6.5.1 Topping up the coolant level.....	64
6.6 Checking the wear of the brake pads....	66
6.7 Checking the brake	67
6.8 Checking the tires and rims	69
6.8.1 Checking of the rims and the wheel rims....	71
6.9 Cleaning checking and lubricating the drive chain	72
6.9.1 Cleaning	73
.....	73
6.10 Checking the idle speed	74
6.11 Replacing the fuses	75
6.12 Battery	77
6.13 Cleaning the motorcycle	78
6.14 Prolonged inactivity	80
7 Technical information	81
.....	82

Tornado Naked Tre 899

11 General information

Dear Customer,

We invite you to read this Owners Manual before using your new TORNADO NAKED TRE 899.

It contains important information for a safe use of the vehicle and to keep it in perfect working order.

Keep it by putting it in the special papers-case compartment.

We remind you, however, that TORNADO NAKED TRE 899 is a high performance vehicle that needs to be ride with attention and skill.

You better refrain from driving the vehicle out of bounds, if you are not sure of your ability in managing it; however, when you ride on public street or open to the public, you have to scrupulously observe the Highway Code.

Always remember to use a homologated helmet, of your size, and always correctly laced up. We recommend you, besides, always to wear an appropriate protective wear.

Tornado Naked Tre 899

1.1 Symbols

In order to make more simple and readily the most important information, we have used the following symbols:

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Danger Warns you that there is a serious intrinsic danger that could cause personal injuries and deadly accidents in case you dont follow the supplied directions.

Warning Warns you that there is a danger that could cause personal injuries and deadly accidents in case you dont follow the supplied directions.

Caution Reminds you a safety practice you better follow or an unsafety activity you better avoid if you dont want to risk under go personal injuries or to damage your vehicle.

Benelli Q.J. reserves the right to make any changes, whenever deemed, to its products and to this manual. Wherever vehicle, dont hesitate to download from the web site www.benelli.com the update version of the Owners Manual, or contact the Customer Service Benelli Q.J. calling +39 0721.418740, which will arrange to send to you the new update version.

2

1. Frame serial number
2. Engine serial number
3. Homologation data

Tornado Naked Tre 899

We recommend writing down the main numbers in the spaces provided below.

FRAME No. ZBN _____

ENGINE No. _____

COLOR CODE _____

KEY No. _____

xxxxxxxxxxxxxxxxxxxxxx

xxxxxxxxxxxxxxxxxxxxxxxxx

Labels

Color code

Key identification number

Tornado Naked Tre 899

number.

The key, supplied in four copies, can be used both for starting the motorcycle and for operating all the locks.

Keep the key copies in a safe place.

you need to ask for a duplicate of the key.

The color code must be mentioned when ordering body spares. This code can be read on the labels placed under the saddle.

Spare parts order

If you need to order spare parts, beside the matriculation frame number, it can be necessary to mention the engine number.

4

Tornado Naked Tre 899

2 Safety information

2.1 Safety

2.1.1

WARNING It is strictly forbidden to intervene on the vehicle by modifying the mechanical components or by replacing

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

them with non genuine spare parts. All this activities make the vehicle homologation forfeit rendering it unusable for public street use, and can also cause serious damages for the user and for the vehicle itself. Benelli Q.J. is not responsible for any

It is possible to personalize the suspension trim by working on the special adjustments this trim adjustment can compromise the motorcycle safe use and, therefore, it has to be done only by expert persons. Wherever you want to personalize the motorcycle trim in relation to your personal requirements, we suggest you to apply to a Benelli Q.J. Authorized Workshop. You

www.benelli.com or calling the Benelli Q.J. Customer Service dialling +39 0721.418740.

5

Tornado Naked Tre 899

2.1.2 General safety regulations

Before you start riding make sure you keep in mind the controls, characteristics, working and limits of the motorcycle. workshop does all the maintenance operations written on the Maintenance section of this Owners Manual, following carefully all the directions and suggestions.

We advise you against having the maintenance operations and the repairs done by persons or workshop that dont belong to the Benelli Q.J. Authorized Workshop net. Especially we advise you against doing on your own the maintenance operations and the repairs on your TORNADO NAKED TRE 899!

For any necessity or further information dont hesitate to apply to your Benelli Q.J. Distributor or to the nearest Benelli the web site www.benelli.com or calling the Benelli Q.J. Customer Service dialling +39 0721.418740.

The full control of this motorcycle is basic for a safe riding. Therefore it is necessary to start riding with a good concentration and in perfect physical conditions, apart from always assessing the street and atmospheric conditions.

In order to avoid compromising handling and stability of your motorcycle, you should obey the following warnings:

- do not attach any object to the vehicle;
- do not hook a sidecar, a tow or any other accessory to the motorcycle;
- do not remove any part and/or component;
- do not modify the vehicle in any way;

6

Tornado Naked Tre 899

Do not ride this motorcycle if you do not possess a regular driving licence. Failure to heed this warning constitutes a breach of the Highway Code, besides posing a serious hazard to the drivers and other peoples safety.

Always wear a helmet, even on short rides.

Do not start the engine in closed places. Exhaust gases are toxic and can quickly saturate the air and cause fainting or even death.

While riding, always keep both hands on the handlebars.

Park the vehicle where it is unlikely to be bumped into or damaged. Even slight or involuntary bumps can cause the vehicle to topple over, with subsequent risk of serious harm to people or children.

To prevent the vehicle from tipping over, never park it on soft or uneven ground, nor on