

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Hyosung - te_100_r

1 This manual should be considered a permanent part of the vehicle and should remain with the vehicle when resold or otherwise transferred to a new owner or operator. The manual contains important safety information and instructions which should be read carefully before operating the vehicle.

Downloaded from www.Manualslib.com manuals search engine

2 IMPORTANT

WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information the words WARNING, CAUTION and NOTE have special meanings. Information following these signal words should be carefully reviewed.

FOREWORD

This manual is an essential part of your vehicle. Please read it carefully. It contains important information on safety, operation and maintenance. It is especially important that this manual remain with the vehicle at the time of resale. The next owner will need this information also.

Your HYOSUNG TE100R is built for use by children, but this owner's manual is written for the adults who will be supervising the children. HYOSUNG strongly recommends, therefore, that you review this entire manual with your child and carefully explain the instructions, requirements, and warnings it contains so that your child can understand them.

NOTE

This provides special information to make maintenance easier or important instructions clearer. These instructions point out special service procedures or precautions that must be followed to avoid damaging the machine.

CAUTION

The personal safety of the rider or bystanders may be involved. Disregarding this information could result in personal injury.

WARNING

HYOSUNG MOTORS & MACHINERY INC.

COPYRIGHT HYOSUNG MOTORS & MACHINERY INC.

Downloaded from www.Manualslib.com manuals search engine

3

Even though the TE100R has four wheels, it can tip over in any direction. Improper turning techniques, traversing hills, accelerating on hills, and turning on hills can all lead to vehicle tip over.

Learn proper riding techniques and avoid riding situations which can lead to tip over accidents.

The TE100R and other all terrain vehicles (ATVs) have unique handling characteristics. ATVs handle differently than motorcycles. Although ATVs have four(or three) wheels, they handle differently than automobiles, too.

ATVs require special riding techniques suited to their handling characteristics, so be sure that all riders of the TE100R practice and master the riding techniques described in this owner's manual (Starting on page 21).

WARNING

Proper parental supervision and instruction are necessary for safe and proper operation of this TE100R by young riders.

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

WARNING

WARNING

IMPORTANT NOTICE TO PARENTS

Read this owner's manual carefully and review its contents fully with your child. It is YOUR RESPONSIBILITY to make sure that your TE100R is properly and safely ridden and maintained.

It is important that both you and your child understand and observe the restrictions listed on the fender label of the TE100R

You must take special precautions to reduce the chance of accidents and injuries resulting from operation of this vehicle. Some of the important safety precautions you should take are :

Supervise operation of the TE100R AT ALL TIMES. Constant supervision is necessary so you can observe that the operator is riding safely.

Never permit children under age 12 to operate the TE100R These children, as well as some children age 12 and older, may not be able to operate this vehicle safely due to physical or mental limitations. Parents should carefully observe their child's first use of the vehicle. Further use should be permitted only if the parent can determine that the child has the physical and mental capabilities necessary to operate the vehicle safely.

Before first use of the TE100R read this owner's manual carefully to become familiar with the TE100R's features, and safety and maintenance requirements. Review all instructions, requirements and warnings with the riders. Keep the owner's manual in the storage compartment located under the seat.

Downloaded from www.Manualslib.com manuals search engine

4

Before the rider's first use of the TE100R make sure that he/she is familiar with the location and operation of all controls, and has been instructed in the proper operation of the vehicle.

For first use of the TE100R find a level, open area for the rider to use to become familiar with the operation of controls and the operating and handling characteristics of the TE100R

Before each use, perform daily inspections with the rider. Specific items to check are listed in the INSPECTION BEFORE RIDING section on page 21 of this owner's manual.

Make sure the rider wears a helmet, eye protection, and protective clothing (gloves, leather or heavy cloth pants, long sleeved shirt or jacket, boots).

Beware of hazardous situations. Instruct the rider to do likewise.

Do not permit the TE100R to be used on public roads AT ANY TIME.

This vehicle is designed and manufactured for use ONLY off public roads. It is not subject to Federal Motor Vehicle Safety Standards as it is not equipped or approved for operation on public streets, roads, or highways at any time.

Do not permit the TE100R to be operated on any paved surfaces. The vehicle can be more difficult to control when it is operated on pavement.

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Permit use only by a single rider. This vehicle is designed for use only by a single rider. Extra seat space is provided so the rider can change his/her body position to maneuver the vehicle. This space should never be used to carry a passenger.

Do not permit anyone to operate the TE100R while under the influence of alcohol or other drugs.

Make sure the combined weight of the rider, protective gear and any accessories or cargo does not exceed the 68kg (150lbs) weight limit. Exceeding this weight limit may result in injury caused by damage to the vehicle or altered handling characteristics.

Observe periodic maintenance requirements your authorized HYOSUNG dealer is trained and equipped to perform this service.

Never permit vehicle refueling by anyone other than an adult.

Drain gasoline from the fuel tank and carburetor prior to transporting the TE100R

Caution the rider and others near the TE100R not to get close to or touch any moving parts or any heated areas such as the engine and exhaust system.

Do not make any modifications to the TE100R Modifications may make the vehicle unsafe or illegal unsafe or illegal in your state.

TE100R always come on the head lamp and tail lamp when starting engine.

TE100R has a reverse gear lever. The reverse gear indicator lamp will come on when the
Downloaded from www.Manualslib.com manuals search engine

5

transmission is in reverse gear.

To shift into reverse gear, completely stop the vehicle and wait 3 seconds. Shifting into reverse gear when the vehicle is moving can be hazardous and damage the vehicle. If you shift the vehicle into reverse gear when the vehicle is moving it could stop suddenly, throwing you from the vehicle. Always come to a complete stop before shifting into reverse gear. Check the area behind the vehicle if you are about to reverse. After the vehicle reverse, completely stop it and wait 3 seconds. Turn the reverse gear lever at the original situation.

Before the vehicle started, confirm that the reverse gear lever is released. If you started the vehicle that reverse gear is shifted into, it could be hazardous and damage the vehicle.

Downloaded from www.Manualslib.com manuals search engine

6

1. SERIAL NUMBER LOCATION 8
 2. FUEL AND OIL RECOMMENDATION 8
- FUEL

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

ENGINE OIL	
TRANSMISSION OIL	
3. LOCATION OF PARTS	9
4. CONTROLS	12
IGNITION SWITCH	
IGNITION KEY INDICATOR LAMP	
LEFT HANDLEBAR	
RIGHT HANDLEBAR	
REVERSE GEAR LEVER	
FUEL COCK	
KICK START LEVER	
5. EQUIPMENT AND ADJUSTMENTS	17
FUEL TANK CAP	
REMOTE ENGINE STOP SWITCH	
6. BREAK-IN (RUNNING-IN)	20
7. INSPECTION BEFORE RIDING	21
8. RIDING TIPS	21
9. INSTRUCTING THE YOUNG RIDER	28
10. INSPECTION AND MAINTENANCE	31
MAINTENANCE SCHEDULE	
PERIODIC MAINTENANCE CHART	
TABLE OF CONTENTS	

Downloaded from www.Manualslib.com manuals search engine

7	
SEAT REMOVAL	
TOOLS	
INSPECTION OF FUEL	
INSPECTION OF ENGINE OIL	
AIR CLEANER	
SPARK PLUG	
SHIFT PLAY	
IDLE SPEED ADJUSTMENT	
THROTTLE CABLE ADJUSTMENT	
FUEL HOSE	
TRANSMISSION OIL	
ENGINE OIL LEVEL	
BRAKE	
TIRES	
DRIVE CHAIN	
FRONT AND REAR WHEEL REMOVAL	
REPLACEMENT OF THE LAMP	
GENERAL LUBRICATION	
11. TROUBLE SHOOTING	48
12. TRANSPORTING	49

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

13. CLEANING PROCEDURE 51

14. STORAGE PROCEDURE 52

15. LOCATION OF LABELS 54

16. SPECIFICATIONS 56

Downloaded from www.Manualslib.com manuals search engine

8

FUEL

ENGINE OIL

TRANSMISSION OIL

Frame No. :

Engine No. :

The frame number is stamped on the front frame member as shown in the illustration.

The engine serial number is stamped on the right side of the crankcase assembly.

Please write down the serial numbers here for your future reference. The frame and/or engine serial numbers are used to title the vehicle. They are also used to assist your dealer when ordering parts or referring to special service information.

Gasoline used should be graded 91 octane or higher. An unleaded type gasoline is recommended. If engine pinging is experienced, substitute another brand as there are differences between brands.

Use HYOSUNG HYPOL OIL HS. If they are not available, use a good quality TWO-STROKE engine oil.

Use a good quality SAE 10W/30 or 10W/40 multi-grade motor oil.

SERIAL NUMBER LOCATION

FUEL AND OIL RECOMMENDATION

Downloaded from www.Manualslib.com manuals search engine

9

LOCATION OF PARTS

Rear brake lever (Parking brake lever)

Parking brake knob

Front brake lever

Throttle lever

Reverse gear lever

Fuel tank cap

Indicator lamp

Starter switch

Engine stop switch

Downloaded from www.Manualslib.com manuals search engine

10

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Fuel cock
Head lamp
Battery & fuse
Muffler
Drive chain
Gear shift shaft

NOTE

means the invisible parts.

Downloaded from www.Manualslib.com manuals search engine