



SIM CARD USER MANUAL

Easy setup for your EvairSIM card

A complete setup guide for phones, tablets, MiFi devices, and supported cameras.

www.evairdigital.com

service@evairdigital.com

You are in. Welcome to EvairSIM.

Scan the QR code to visit www.evairdigital.com and start your global connectivity experience.



Check plan details instantly.

View your plan validity and remaining data so you stay informed and in control.

Order new plans effortlessly.

Browse plans, renew, or switch with just a tap wherever you are.

Get quick support.

Report issues and connect with our support team for fast, helpful assistance.

First things first

Please check these items before using your SIM card.

1. Check whether your phone is unlocked

Before using your SIM card, check if your phone is network-locked. If it is locked, contact the customer service team of the device retailer or carrier to unlock it.

2. Confirm third-party SIM support

Make sure your phone or device supports third-party SIM cards and has data roaming enabled.

Manual APN reminder

If automatic setup does not work, use APN plus. Leave username and password blank.

CONTENTS	04
Top up or check balance	05
Switch carriers on iOS	06
Configure APN on iOS	07
Switch carriers on Android	08
Configure APN on Android	09
Set up APN on MiFi	10
Set up APN on Reolink devices	12
APN quick reference	14
Q&A	15

Easy ways to top up or check your balance

Use EvairSIM online to view your SIM plan, remaining data, validity, and available renewal options.

1

Open EvairSIM

Visit www.evairdigital.com or scan the QR code in this manual.

2

Check your plan

Review your plan validity and remaining data before changing settings.

3

Order new plans

Browse plans and choose the option that fits your device and data needs.

4

Contact support

If you need help, use the app or email service@evairdigital.com.

How to switch carriers on iOS devices

Use this if your iPhone or iPad does not automatically connect to a good network.

1

Insert SIM card

Insert the EvairSIM card and wait for the device to detect it.

2

Open Settings

Tap Cellular, then tap the SIM card that uses EvairSIM.

3

Enable Data Roaming

Turn on Data Roaming and tap Network Selection.

4

Select carrier manually

Disable Automatic, wait 1-2 minutes, then manually select the carrier with the strongest signal.

How to configure APN for iOS devices

Most iOS devices connect automatically. If not, set APN manually.

1

Insert SIM card

Install the SIM and wait for the phone to recognize it.

2

Open Cellular

Open Settings, tap Cellular, then select the EvairSIM SIM card.

3

Open data network

Enable Data Roaming, then tap Cellular Data Network.

4

Set APN

Enter APN plus. Leave Username and Password blank, then save.

How to switch carriers on Android devices

Android menu names vary by brand, but the network selection flow is similar.

1

Insert SIM card

Insert the EvairSIM card and power on your device.

2

Open Settings

Tap Mobile Network, then tap SIM Card.

3

Enable roaming

Turn on Data Roaming and tap Carrier or Network Operator.

4

Select manually

Disable Automatic Selection, wait 1-2 minutes, then manually choose a carrier.

How to configure APN for Android devices

Use this if your device has no internet after data roaming is enabled.

1

Open APN settings

Go to Settings, Network or Mobile Network, then APN or Access Point Names.

2

Add a new APN

Tap +, Add New APN, or Manual Configuration.

3

Enter APN details

Set APN to plus. Leave Username and Password blank.

4

Save and select

Save the APN, select it as active, and wait for the connection.

How to set up APN on MiFi

For mobile Wi-Fi, hotspots, and routers, enter the APN from the admin panel.

1

Insert SIM card

Insert the SIM card into the MiFi, hotspot, or router.

2

Access admin panel

Open Chrome, Safari, or another browser. Enter the Wi-Fi hotspot or router IP address.

3

Common IP addresses

The IP is often 192.168.0.1 or 192.168.1.1. Some devices print it on the rear label.

4

Log in

Use your admin username and password. Check your device manual if needed.

Finish MiFi APN setup

After logging in, find the network APN menu and enter the values below.

5

Find APN settings

Go to Settings, Network, then APN.
Enable roaming if the device provides this option.

6

Add configuration

Select Add New APN or Manual Configuration.

7

Enter APN

Set APN to plus. Leave Username and Password blank.

8

Save and reconnect

Save the profile, select it, then restart the MiFi if it does not connect.

What if a Reolink camera fails to connect automatically?

Based on Reolink camera settings. Some cameras require APN import by Micro SD card.

1

Create a configuration file

On a computer, create a TXT file named `my_custom_apn`.

2

Add APN information

Enter `apn=plus`, `username=`, and `password=`. Leave username and password empty.

3

Transfer to SD card

Save `my_custom_apn.txt` to the root directory of a FAT32 Micro SD card.

4

Import to camera

Turn off the camera, then install the SIM card and Micro SD card.

Reboot and verify

Finish the camera import process after installing the SIM and SD card.

Trigger the update

Power on the camera and press the reset button for a few seconds to trigger the APN update.

Wait for import

The camera will reboot and automatically import the APN settings.

Success indicator

A blue LED light or voice prompt usually indicates successful configuration.

APN quick reference

Use these values when any phone, MiFi, router, or camera asks for APN settings.

Preferred APN	plus
Other accepted APNs	globaldata or internet
Username	Leave blank
Password	Leave blank
Data roaming	Enable it

After changing APN, save it, select it, wait about 2 minutes, then restart the device if it still does not connect.

1. Why is there no network connection after inserting the SIM card?

Please enable Data Roaming on your phone and wait about 2 minutes for the SIM card to activate and connect automatically. Alternatively, restart your phone after enabling roaming to restore the network connection.

2. Why is there still no network connection after enabling roaming?

Your device may not support automatic APN configuration. Please manually set the APN to one of the following: globaldata, plus, or internet.

3. Why does my SIM card show as expired even though I have not used all the data?

EvairSIM SIM cards support automatic APN configuration. Some brands of mobile Wi-Fi and other IoT devices have roaming enabled by default, which triggers automatic activation once the SIM card is inserted. The plan will show as expired once the package duration ends.

4. Why does my device display Invalid SIM, SIM Locked, No Service, or SIM Network Unlock PIN?

This indicates that your device is carrier-locked and does not support SIM cards from other providers. Contact your device provider to unlock it. EvairSIM IoT cards are compatible with unlocked devices.

5. Why is there still no internet after I enabled data roaming and configured APN on my mobile Wi-Fi?

Please check if your device supports US network bands. Our SIM cards support these 4G/LTE bands: B2, B4, B12, B13, B14, B30, B66, and B71.

For 5G, supported bands include n5, n41, n71, n77, n258, n260, and n261.

If your device supports these bands

Take screenshots of your Data Roaming and APN configuration pages and send them to EvairSIM support if it still cannot connect.

6. How can I contact you?

You can reach us via the app or by emailing service@evairdigital.com.

7. Why is my network speed only 50 Mbps?

Your current network speed depends on the carrier your device selects and the signal strength in your area. Try manually switching network providers and choosing the strongest signal among AT&T, Verizon, or T-Mobile.

8. Why did my internet stop working after I had been using it for a while?

Log in to the EvairSIM app or website and wait 15 minutes to check if your data package has been exhausted.

Before changing APN again

First check your remaining data and signal. If you still have data, try manually switching carriers before creating a new APN profile.

What if I still have data but cannot connect?

If you still have data but cannot connect, we recommend manually switching to a different carrier.

9. Do I need to buy a new SIM card once my data is used up?

No. Download the EvairSIM app or visit the top-up page to subscribe to a new plan. You can continue using the same SIM card.

10. Why is my security camera unable to connect after inserting the SIM card?

Your device may not support automatic APN configuration. Contact the camera support team to ask how to manually configure APN. The EvairSIM APN is globaldata, plus, or internet.

For cameras

If the camera brand has no visible APN menu, use the camera maker's support instructions or the SD-card import method shown earlier in this booklet.

11. Can the US SIM card I purchased be used in Mexico or Europe?

No. If you need to use our SIM card in multiple regions, such as the US and Europe, or the US, Mexico, and Canada, you will need to purchase our Multi-Region SIM card.

12. Does the SIM card provide a static US IP address?

Not exactly. The EvairSIM IoT card provides a local US IP, which supports US-based apps and streaming services. Because the card supports all three major US carriers, the IP address may change during network fluctuations or when switching between carriers.

13. Can I use the SIM card in American Samoa?

No. The EvairSIM card is supported in the Mainland US, Alaska, and Hawaii. It is currently not supported in other US overseas territories or islands.

Coverage reminder

This physical SIM manual is for the US SIM card. For multi-region use, choose the correct Multi-Region SIM before traveling.

Quick APN reminder

Use APN plus first. If needed, try globaldata or internet. Leave username and password blank.

If your device does not connect

Try these checks before contacting support.

Confirm the device is unlocked

Carrier-locked phones and devices may show Invalid SIM, SIM Locked, No Service, or SIM Network Unlock PIN.

Enable data roaming

Wait about 2 minutes after turning on roaming. If needed, restart the device.

Set APN manually

Use plus first. If needed, try globaldata or internet. Leave username and password blank.

When contacting support

Please include enough information so our team can help quickly.

Send your device details

Include the device model, SIM ICCID, and the city or area where you are using the SIM.

Send screenshots

Include screenshots of Data Roaming, APN settings, and any error message shown by your device.

Email

service@evairdigital.com



Manage your SIM online

Check data, top up, and contact support at www.evairdigital.com.

www.evairdigital.com

service@evairdigital.com