



SIM CARD USER MANUAL

Easy setup for your EvairSIM card

Simple steps for phones, tablets, MiFi devices, and supported cameras.

www.evairdigital.com

service@evairdigital.com

Welcome to EvairSIM

Scan the QR code to visit www.evairdigital.com.



Check your plan.

View validity and remaining data.

Top up easily.

Choose a new plan when you need more data.

Get support.

Contact us from the website or by email.

Keep this booklet with your SIM card. It has the APN values and troubleshooting steps you may need later.

Before you begin

Check these two items first. They solve many setup problems.

1. Make sure your device is unlocked

If your phone or device is carrier-locked, contact the original carrier or device seller to unlock it.

2. Turn on data roaming

EvairSIM needs data roaming enabled on most phones, tablets, MiFi devices, and cameras.

Manual APN, if needed

APN: plus. Username and password: leave blank.

CONTENTS	04
Top up or check balance	05
Switch carriers on iOS	06
Configure APN on iOS	08
Switch carriers on Android	10
Configure APN on Android	12
Set up APN on MiFi	14
Set up APN on Reolink	16
APN reference	18
Q&A	19

Top up or check your balance

Use the EvairSIM website to check your plan, add more data, or contact support.

1

Open EvairSIM

Visit www.evairdigital.com or scan the QR code in this booklet.

2

Check or top up

View your plan details, remaining data, and available top-up plans.

If data stops working after normal use, check your remaining data before changing device settings.

Switch carriers on iOS

Use these steps if your iPhone or iPad does not connect automatically.

1

Insert SIM card

Insert the EvairSIM card and power on your device.

2

Open SIM settings

Open Settings. Tap Cellular, then tap the SIM card that uses EvairSIM.

Switch carriers on iOS

3

Enable roaming

Turn on Data Roaming, then open Network Selection.

4

Select manually

Disable Automatic, wait 1-2 minutes, then manually select a carrier.

Configure APN on iOS

Most devices connect automatically. If not, enter the APN manually.

1

Open Settings

Tap Cellular, then tap the SIM card that uses EvairSIM.

2

Open data settings

Enable Data Roaming, then tap Cellular Data Network.

Enter APN details

3

Set APN

Enter plus as the APN.

4

Leave blank

Leave Username and Password blank. Save the settings.

Switch carriers on Android

Menu names vary by Android brand, but the flow is similar.

1

Insert SIM card

Install the EvairSIM card and power on your device.

2

Open SIM settings

Open Settings. Tap Mobile Network, then tap SIM Card.

Switch carriers on Android

3

Enable roaming

Turn on Data Roaming and tap Carrier or Network Operator.

4

Select manually

Disable Automatic Selection, wait 1-2 minutes, then manually select a carrier.

Configure APN on Android

Use this if the device has no internet after roaming is enabled.

1

Open APN settings

Go to Settings, Mobile Network, SIM Card, then Access Point Names or APN.

2

Add a new APN

Tap + or Add New APN.

Enter APN details

3

Set APN

Enter plus as the APN.

4

Save and select

Leave Username and Password blank. Save the APN and select it.

Set up APN on MiFi

Use the device admin panel to enter APN manually.

1

Insert SIM card

Insert the SIM card into the MiFi, hotspot, or router.

2

Access admin panel

Open a browser and enter the device IP address, often 192.168.0.1 or 192.168.1.1.

Set up APN on MiFi

3

Log in

Use the admin username and password from your device manual.

4

Enter APN

Go to Settings, Network, then APN. Set APN to plus and leave username/password blank.

Reolink camera APN setup

Some cameras require APN import by SD card.

1

Create a TXT file

On a computer, create a text file named my_custom_apn.

2

Add APN information

Enter apn=plus, username=, and password=. Leave username and password empty.

Reolink camera APN setup

3

Transfer to SD card

Save my_custom_apn.txt to the root directory of a FAT32 Micro SD card.

4

Import to camera

Turn off the camera. Install the SIM and SD card. Power on, then press reset for a few seconds.

Manual APN quick reference

Preferred APN	plus
Other APNs	globaldata or internet
Username	Leave blank
Password	Leave blank
Roaming	Enable data roaming

After changing APN, save it, select it, wait about 2 minutes, then restart the device if it still does not connect.

1. Why is there no network connection after inserting the SIM card?

Enable Data Roaming and wait about 2 minutes for the SIM card to activate and connect automatically. You can also restart your phone after enabling roaming.

2. Why is there still no network connection after enabling roaming?

Your device may not support automatic APN configuration. Manually set the APN to globaldata, plus, or internet.

3. Why does my SIM show as expired even though I have not used all the data?

Some MiFi and IoT devices have roaming enabled by default. This can activate the SIM when it is inserted. The plan shows expired once the package duration ends.

4. Why does my device display Invalid SIM, SIM Locked, No Service, or SIM Network Unlock PIN?

Your device is likely carrier-locked. Contact your device provider to unlock it. EvairSIM IoT cards work with unlocked devices.

5. Why is there still no internet after roaming and APN setup on my mobile Wi-Fi?

Please check if your device supports US network bands. Our SIM cards support B2, B4, B12, B13, B14, B30, B66, B71 for 4G/LTE and n5, n41, n71, n77, n258, n260, n261 for 5G.

If your device supports these bands but still cannot connect, send screenshots of your roaming and APN pages to EvairSIM support.

6. How can I contact you?

You can reach us via the app or by emailing service@evairdigital.com.

7. Why is my network speed only 50 Mbps?

Speed depends on the selected carrier and local signal strength. Try manually switching between AT&T, Verizon, or T-Mobile and choose the strongest signal.

8. Why did my internet stop working after I had been using it for a while?

Log in to the EvairSIM app or website and wait 15 minutes to check if your data package has been exhausted. If you still have data, manually switch to a different carrier.

9. Do I need to buy a new SIM card once my data is used up?

No. Use the EvairSIM app or top-up page to subscribe to a new plan. You can continue using the same SIM card.

10. Why is my security camera unable to connect after inserting the SIM card?

Your device may not support automatic APN configuration. Contact the camera support team to ask how to manually configure APN. The EvairSIM APN is globaldata, plus, or internet.

11. Can the US SIM card be used in Mexico or Europe?

No. For multiple regions, such as the US and Europe or the US, Mexico, and Canada, purchase our Multi-Region SIM card.

12. Does the SIM card provide a static US IP address?

Not exactly. The EvairSIM IoT card provides a local US IP, which supports US-based apps and streaming services.

Because the card supports all three major US carriers, the IP address may change during network fluctuations or carrier switching.

13. Can I use the SIM card in American Samoa?

No. The EvairSIM card is supported in the Mainland US, Alaska, and Hawaii. It is not currently supported in other US overseas territories or islands.

Need help?

Email service@evairdigital.com and include screenshots of your roaming and APN settings.

Still not connected?

Please send us your device model, SIM ICCID, and screenshots of your data roaming and APN pages.

Support email

service@evairdigital.com

For most devices, the key settings are: data roaming on, APN plus, username blank, password blank.



Manage your SIM online

Check data, top up, and contact support.

www.evairdigital.com

service@evairdigital.com