
TERMINALS OF ECU

DI18O-04



No.	Symbol	Terminal Name
А	-	Electrical Connector Check Mechanism
В	-	Electrical Connector Check Mechanism
C20 – 6	PR+	Squib (Seat belt pretensioner, RH)
C20 – 7	PR-	Squib (Seat belt pretensioner, RH)
C21 – 3	LA	SRS Warning Light
C21 – 5	IG2	Power Source
C21 – 6	IG1	Power Source
C21 – 9	SR+	Front Airbag Sensor (RH)
C21 – 10	P+	Squib (Passenger)
C21 – 11	P-	Squib (Passenger)
C21 – 12	SIL	Diagnosis
C21 – 13	D	Squib (Driver)
C21 – 14	D+	Squib (Driver)
C21 – 15	SL+	Front Airbag Sensor (LH)
C21 – 19	Тс	Diagnosis
C21 – 20	SR-	Front Airbag Sensor (RH)
C21 – 26	SL-	Front Airbag Sensor (LH)
C21 – 27	E1	Ground
C21 – 28	E2	Ground
C22 – 1	PL-	Squib (Seat belt pretensioner, LH)
C22 – 2	PL+	Squib (Seat belt pretensioner, LH)

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 859