DI0SO-24

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the page given.

DTC No. (See Page)	Detection Item	Trouble Condition	MIL *1	Memory
P0500 3RZ-FE: (DI-167) 5VZ-FE (DI-378)	Vehicle Speed Sensor "A"	Open or short in No. 1 vehicle speed sensor circuit No. 1 vehicle speed sensor Combination meter ECM	•	0
P0705 (DI-482)	Transmission Range Sensor Circuit Malfunction (PRNDL Input)	Short in park/neutral position switch circuit Park/neutral position switch ECM	•	0
P0710 (DI–487)	Transmission Fluid Temperature Sensor "A" Circuit	Open or short in ATF temperature sensor circuit ATF temperature sensor ECM	•	0
P0712*3 (DI-487)	Transmission Fluid Temperature Sensor "A" Circuit Low Input		•	0
P0713* ³ (DI-487)	Transmission Fluid Temperature Sensor "A" Circuit High Input		•	0
P0722 (DI-489)	Output Speed Sensor	Open or short in No. 2 vehicle speed sensor circuit No. 2 vehicle speed sensor ECM	•	0
P0724 3RZ-FE: (DI-182) 5VZ-FE (DI-397)	Brake Switch "B" Circuit High	Short in stop light switch circuit Stop light switch ECM	•	0
P0741 (DI-494)	Torque Converter Clutch Sole- noid Performance (Shift Solenoid Valve SL)	Shift solenoid valve SL is stuck open or closed Valve body is blocked up or stuck Lock-up clutch	•	0
P0743 (DI-496)	Torque Converter Clutch Circuit Electrical	Open or short in shift solenoid valve SL circuit Shift solenoid valve SL ECM	•	0
P0751 (DI-500)	Shift Solenoid "A" Performance (Sfiht Solenoid Valve S1)	Shift solenoid valve No. 1 is stuck open or closed Valve body is blocked up or stuck Open or short in shift solenoid valve No.1 circuit Shift solenoid valve No. 1 ECM	•	0
P0753*2 (DI-502)	Shift Solenoid "A" Electrical	Open or short in shift solenoid valve No.1 circuit Shift solenoid valve No.1 ECM	•	0
P0756 (DI-500)	Shift Solenoid "B" Performance (Sfiht Solenoid Valve S2)	Shift solenoid valve No. 2 is stuck open or closed Valve body is blocked up or stuck Open or short in shift solenoid valve No. 2 circuit Shift solenoid valve No. 2 ECM	•	0
P0758 ^{*2} (DI-502)	Shift Solenoid "B" Electrical	Open or short in shift solenoid valve No.2 circuit Shift solenoid valve No.2 ECM	•	0

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 731

DIAGNOSTICS – AUTOMATIC TRANSMISSION (A340E, A340F)

DTC No. (See Page)	Detection Item	Trouble Condition	MIL *1	Memory
P0818 *4 (DI-507)	Driveline Disconnect Switch Input Circuit	Short in transfer neutral position switch circuit Transfer neutral position switch ECM	•	0
P0850 (DI–482)	Park/Neutral Switch Input Circuit	Short in park/neutral position switch circuit Park/neutral position switch ECM	•	0
P0973 *3 (DI-509)	Shift Solenoid "A" Control Circuit Low	Open or short in shift solenoid valve No. 1 circuit Shift solenoid valve No. 1 ECM	•	0
P0974 *3 (DI–509)	Shift Solenoid "A" Control Circuit High		•	0
P0976 *3 (DI–509)	Shift Solenoid "B" Control Circuit Low	Open or short in shift solenoid valve No. 2 circuit Shift solenoid valve No. 2 ECM	•	0
P0977 *3 (DI-509)	Shift Solenoid "B" Control Circuit High		•	0
P1782 *4 (DI-512)	Transfer L4 Switch Circuit	Short in transfer L4 position switch circuit Transfer L4 position switch ECM	•	0
P2716 *3 (DI–516)	Pressure Contorl Solenoid "D" Electrical	Open or short in shift solenoid valve SLT circuit Shift solenoid valve SLT ECM	•	0

^{*1 : •...}MIL light up

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 732

^{*2 : 3}RZ–FE only

^{*3 : 5}VZ–FE only *4 : 4WD only