

SAFE OPERATING PROCEDURE

Disc Brake Lathe

LOCATION:

TOI-OHOMAI
Institute of Technology

PERSONAL PROTECTIVE EQUIPMENT



Version: 1	Key Contact: George Fisher
Effective Date: 18/09/2020	Speciality/Position: Technician
Review Date: Sept 2022	Contact number: 021 190 4236
Permits required	Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS Remove as necessary	List	Control Method	Lock out Yes or No
Moving vehicles	Secured on hoist	Manufactures specs	No
Falling objects	Disc-calipers	Secured under body	No
Moving Machinery	Turning disc		No
Moving materials	Steel chips. Eye protection		
Hot surfaces	Hot chips. Eye protection		

PURPOSE/PROCESS

Machining brake disc

PROCEDURES:

DO NOT use this machine unless you have proven to your trainer that you are competent in its safe use and operation

Pre Start Check

1. Make sure the vehicle being worked on is in neutral.
2. Check the area is clear of clutter.
3. Raise the vehicle until the wheel hub is at waist level.
4. Check for excessive bearing play and correct any hub irregularities.
5. Remove wheels and callipers.
6. Clean all mating surfaces between the rotor, hub and wheel.
7. Check cutting bits.

Operation

1. Have the lathe in the right side up position.
2. Select the correct adapter and mount with hand wrench.
3. Mount the lathe to the adaptor.
4. Centre and secure the cutting head making sure the back edge is securely in the dovetail.
5. Set the automatic shut-off cam so it will engage when the cutting head clears the rotor.

6. Double green light means it is okay to make the cut. If the lathe shows a red light, rotate the adapter 180 degrees and try again.
7. Make a scratch cut to establish the baseline for depth of cut.
8. Advance the cutting head to the inside edge of the rotor being careful that the cutting arms do not hit the lathe.
9. Set cut depth so all run out can be taken out of the rotor in one pass.
10. Remember the lathe can take up to 0.03" per pass.

Close Down

1. If set, automatic will stop machine
2. Remove grinding machine
3. Remove adaptor plate

Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Technician		
Reviewed by	Marie Denis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan			

Document Control

Date	Revision number	Modifications	Revised by	Approved by
10.03.20	Version 1			