

SAFE OPERATING PROCEDURE

Launch 2 post hoist

LOCATION: Automotive Workshop

TOI-OHOMAI
Institute of Technology

PERSONAL PROTECTIVE EQUIPMENT



Version: 1	Key Contact: George Fisher
Effective Date: 18/09/2020	Speciality/Position: Automotive Technician
Review Date: September 2022	Contact number: 07 346 8968
Permits required	Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS <i>Remove as necessary</i>	List	Control Method <i>Eliminate, isolate, minimise.</i>	Lock out <i>Yes or no.</i>
Moving Machinery	Locking mechanism gears Wire ropes Hoist moving up or down Hydraulic Rams	Check daily for wear and tear Check area is free of obstacles before operating hoist Check oil level Check frayed cables	Lock out and tags No
Falling objects	Foreign material can fall from vehicle when hoisted is raised	Safety glasses to be worn when operating or working under hoist	No
Falling from height	Standing on hoist, overloading or hoisting unsuitable vehicle	Do not stand on hoist when raising or lowering. Check rating capacity on hoist name plate. Check car manufacturer handbook for hoist suitability. Ensure car is secure before raising hoist	No
Slips and trips	Hoist arms in raised position. Spilt oil and water on floor.	Do not leave hoist arms raised without a vehicle on. People can walk into them, Clean up spills.	No
Hazardous materials	Exhaust fumes	Ventilation and extraction fan.	No

PURPOSE/PROCESS

To provide access to the underside of a motor vehicle

PROCEDURE:

DO NOT use this machine unless you have proven to your trainer that you are competent in its safe use and operation

Pre Start Check

1. Lower the hoist to floor level. Check oil level.
2. Check lifting pads for damage, cuts, oils or grease on them.
3. Check hoist for any loose bolts, tighten them and report any bent or loose guards.
4. Check controls and safety locks that they are working (you will hear the safety paw clicking).

Machine start

1. Check the hoist arms are clear of the vehicle before driving on.
2. Park the vehicle centrally on the hoist but far enough forward to clear the driver's door on the hoist post. Put vehicle in neutral and the park brake off. Exit vehicle.
3. Position the lifting pads under the vehicle at pick-up points approved by the vehicle manufacturer (you can move the vehicle back and forward as necessary).
4. Adjust the lifting pads heights to ensure they all lift evenly.
5. Check the lifting arms and pads will clear the vehicle body and exhaust pipe.

Machine Operation

1. Turn the isolating switch to the up position and raise the vehicle approximately 500 mm allowing the hoist to take full weight.
2. Check that the pads are in the correct positions and the vehicle is evenly loading the pads (touching all pads). If not, lower the hoist and readjust as necessary.
3. Shake the vehicle to check that it is stable.
4. Raise the hoist to the desired height for you to work on it. As you are raising the hoist, watch that the vehicle doesn't collide with anything and that it is staying level and stable.
5. Lower the vehicle until it contacts the safety locks.
6. Before working on the vehicle, do another check that the lifting pads are correctly positioned and the lifting arms are locked.
7. Before lowering the hoist, check the floor beneath the hoist and the vehicle is clear of people, parts, tools and equipment. Raise the hoist off the safety locks. Pull safety lock release to disengage the safety lock and operate the lowering handle to lower the vehicle.
8. Watch the vehicle while lowering to make sure it does not collide with anything and is staying level.
9. Move the arms clear of the vehicle before the vehicle is moved off the hoist.
10. Use stands if removing heavy components.

Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Automotive Technician		
Reviewed by	Marie Dennis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan	Programme Manager		

Document Control

Date	Revision number	Modifications	Revised by	Approved by
11/08/2020	1		G Fisher	M Dennis