

# SAFE OPERATING PROCEDURE

Tecalemit 2 post hoist LOCATION: Automotive Workshop



## PERSONAL PROTECTIVE EQUIPMENT



|                             |                                                                                                                        |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------|
| Version: 1                  | Key Contact: George Fisher                                                                                             |
| Effective Date: 18/09/2020  | Speciality/Position: Automotive Technician                                                                             |
| Review Date: September 2022 | Contact number: 07 346 8968                                                                                            |
| Permits required            | Confined space <input type="checkbox"/> Hot Works <input type="checkbox"/> Working at Heights <input type="checkbox"/> |

## HAZARDS ASSOCIATED WITH THIS EQUIPMENT

| PERMANENT HAZARDS<br><i>Remove as necessary</i> | List                                                          | Control Method<br><i>Eliminate, isolate, minimise.</i>                                                                                                                                      | Lock out<br><i>Yes or no.</i>                |
|-------------------------------------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|
| Moving Machinery                                | Locking mechanism gears<br><br>Hoist moving up or down        | Check daily for wear and tear<br><br>Check area is free of obstacles before operating hoist                                                                                                 | Lock out and tag if gears are worn<br><br>No |
| Falling objects                                 | Foreign material can fall from vehicle when hoisted is raised | Safety glasses to be worn when operating or working under hoist                                                                                                                             | No                                           |
| Falling from height                             | Standing on hoist, overloading or hoisting unsuitable vehicle | Do not stand on hoist when raising or lowering. Check rating capacity on hoist name plate. Check car manufacturer handbook for hoist suitability. Ensure car is secure before raising hoist | No                                           |
| Slips and trips                                 | Hoist arms in raised position. Spilt oil and water on floor.  | Do not leave hoist arms raised without a vehicle on. People can walk into them, Clean up spills.                                                                                            | No                                           |
| Hazardous materials                             | Exhaust fumes                                                 | Ventilation and extraction fan.                                                                                                                                                             | No                                           |

## PURPOSE/PROCESS

To provide access to the underside of a motor vehicle

## PROCEDURE:

**DO NOT** use this machine unless you have proven to your trainer that you are competent in its safe use and operation

### Pre Start Check

1. Lower the hoist to floor level. Check that a gap exists between lift and safety nuts on both columns.
2. Check lifting pads for damage, cuts, oils or grease on them. Raise the hoist 500 mm and put a dip stick through the hole in the column into the reservoir. The oil reservoir must be kept half full
3. Check hoist for any loose bolts, tighten them and report any bent or loose guards. Check controls and safety locks that they are working.

### Machine start

1. Check the hoist arms are clear of the vehicle before driving on
2. Park the vehicle centrally on the hoist but far enough forward to clear the driver's door on the hoist post. Put vehicle in neutral and the park brake off. Exit vehicle
3. Position the lifting pads under the vehicle at pick-up points approved by the vehicle manufacturer (you can move the vehicle back and forward as necessary).
4. Adjust the lifting pads heights to ensure they all lift evenly
5. Check the lifting arms and pads will clear the vehicle body and exhaust pipe

### Machine Operation

1. Turn the isolating switch to the up position and raise the vehicle approximately 500 mm allowing the hoist to take full weight.
2. Check that the pads are in the correct positions and the vehicle is evenly loading the pads (touching all pads). If not, lower the hoist and readjust as necessary.
3. Shake the vehicle to check that it is stable
4. Raise the hoist to the desired height for you to work on it. As you are raising the hoist, watch that the vehicle doesn't collide with anything and that it is staying level and stable.
5. Before working on the vehicle, do another check that the lifting pads are correctly positioned and the lifting arms are locked
6. Before lowering the hoist, check the floor beneath the hoist and the vehicle is clear of people, parts, tools and equipment.
7. Lower the hoist fully by turning the isolating switch to the lower side. Watch the vehicle while lowering to make sure it does not collide with anything and is staying level.
8. Move the arms clear of the vehicle before the vehicle is moved off the hoist
9. Use stands if removing heavy components.

### Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

|                    | Name            | Title/Position        | Signature | Date |
|--------------------|-----------------|-----------------------|-----------|------|
| <b>Author</b>      | George Fisher   | Automotive Technician |           |      |
| <b>Reviewed by</b> | Marie Dennis    | HSW Manager           |           |      |
| <b>Reviewed by</b> | Tony Middlemiss | Health and safety rep |           |      |
| <b>Manager</b>     | Joe Nathan      | Programme Manager     |           |      |

### Document Control

| Date       | Revision number | Modifications | Revised by | Approved by |
|------------|-----------------|---------------|------------|-------------|
| 11/08/2020 | 1               | New format    | G Fisher   | M Dennis    |
|            |                 |               |            |             |
|            |                 |               |            |             |
|            |                 |               |            |             |
|            |                 |               |            |             |