

SAFE OPERATING PROCEDURE

CEMB Wheel Balancer LOCATION: Automotive Workshop

PERSONAL PROTECTIVE EQUIPMENT



Version: 2	Key Contact: George Fisher
Effective Date: 18/09/2020	Speciality/Position: Technician
Review Date: December 2022	Contact number: 021 190 4236
Permits required	Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS Remove as necessary	List	Control Method	Lock out Yes or No
Electric shock	Power cord	Test and tag, RCD if using outside or in damp conditions	Yes
Flying objects	Loose stones	Remove stones	
Moving Machinery	Rotating parts could cause entanglement.	Keep hands away from moving parts, do not wear loose clothing that could get caught.	
Manual handling	Wheels are heavy and have to be lifted onto balancer.	Use correct manual handling techniques, ask for help if needed.	
Noise			
Moving materials	Objects can fly off wheel – mud, stones.	Eye protection.	
Hit by objects	Fitting of weights – hammering close to fingers/hands	Training	

PURPOSE/PROCESS

PROCEDURES:

DO NOT use this machine unless you have proven to your trainer that you are competent in its safe use and operation

Pre Start Check

1. Check the area is uncluttered and free from slips, trips and falls
2. Check power leads and switches for damage.
3. Check the electrical test tag is current.
4. Make sure the wheel is the right size for the balancer.

5. Ensure the wheel is clean – free of mud and stones.
6. Select the correct adapter to mount the wheel.

Operation

1. Select the correct cones for the rim you are balancing.
2. Fit the wheel and tighten the lock. Check that the rim is not loose on the cones.
3. Remove the wheel weights.
4. Set the balancer (Diameter, off set, width)
5. Close the guard and press start. When the machine stops it will tell you the weight size that needs to fitted for the inner and outer rim.
6. Lift guard and turn by hand to the correct setting.
7. Fit the correct weight at this setting and turn the wheel by hand for the setting for the outside and then fit the correct weight.
8. Close the guard and check again.

Close Down

1. Remove wheel and clean area.

Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Technician		17/08/20
Reviewed by	Marie Dennis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan			

Document Control

Date	Revision number	Modifications	Revised by	Approved by
18/09/2020	1	New format	George	Marie