TCP/IP Configuration description


Open "RFIDDemo.exe" in Document of "RFIDDemo";

Connect to the LAN port of Computer or Router;


To power up the reader, then you can configuration the TCP/IP of reader;

Running NET Config Software diagram


1. Open "RFIDDemo.exe":




2. Choice "Net Interface", click "BROADCAST" of the menu;




3. Broadcast the TCP/IP Address of Reader:




4. Get the TCP/IP Parameters of reader:



5. Set the TCP/IP Parameters of reader:



6. Wait about 5~15sec, click "Broadcast", Broadcast the TCP/IP Address of Reader to confirm;



7. At the step, the configuration is complete;