BATOCERA MOVIE PLAYER APP VERSION 1

START-TO-FINISH EASY INSTALLATION GUIDE

What This Installs

A simple fullscreen movie player for Batocera 42. Play movies with a controller or Zaparoo NFC card without using Kodi.

YOU NEED	WHERE IT GOES
Batocera 42 Zaparoo Core installed Keyboard USB drive Batocera Movie App Version 1 ZIP	Movies: \\BATOCERA\share\roms\movies Posters: beside the movie or in the images folder

Before You Begin

The installer preserves your existing movies, posters, viewing progress, working Zaparoo cards, and phone settings. You do not need to remove an older Movie Player version first.

Allow about 5-10 minutes. Keep the Batocera machine powered on until the Installation Successful window appears.

PART 1 - PREPARE THE FILES

COPY THE INSTALLER TO A USB DRIVE

1	**Find the application ZIP** Open the **Application** folder in this Release Kit. Locate **Batocera-Movie-App-Version-1.zip**.
2	**Extract the ZIP** Right-click the ZIP and choose **Extract All**. You must see **install.sh**, **VERSION**, and the **files** folder inside the extracted folder. Do not run install.sh on Windows.
3	**Copy the extracted folder to USB** Copy the entire extracted folder to a USB drive. Safely eject the drive and connect it to the Batocera machine.

CORRECT USB LAYOUT

```
Batocera-Movie-App-Version-1/
    install.sh
    VERSION
    files/
```

[NEXT]

PART 2 - RUN THE INSTALLER

USE BATOCERA'S F1 FILE MANAGER

4	**Open the Batocera file manager** From the Batocera main menu, connect a keyboard and press **F1**. The desktop file manager opens.
5	**Open the USB drive** Choose your USB drive in the left column. Open the extracted Batocera Movie Player folder.
6	**Execute install.sh** Double-click **install.sh**. When asked what to do, choose **Execute**. Wait while the installer checks MPV, Zaparoo, the Movies theme, and the session manager.

RUN OR DISPLAY?

You are opening install.sh.

Choose the option that runs or executes the file.

[EXECUTE]

PART 3 - FINISH AND REBOOT

WAIT FOR A CLEAR SUCCESS MESSAGE

7	**Wait for Installation Successful** Do not close anything while files are being installed. A large **INSTALLATION SUCCESSFUL** window will appear when Version 1 is completely installed.
8	**Close the installer window** Click the **CLOSE INSTALLER** button at the bottom of the success window. If needed, click the window's **X** in its upper-right corner. You will return to Batocera's F1 file manager.
9	**Close F1 and reboot Batocera** Close the file manager window to return to Batocera. Open the Batocera main menu and choose **QUIT > RESTART SYSTEM**. Wait for Batocera to finish rebooting before testing Movies.

If the success window never appears: stop and open Ports > Collect Movie Player Logs. Do not repeatedly reinstall without reading the result.

INSTALLATION SUCCESSFUL

BATOCERA MOVIE PLAYER APP VERSION 1
THEME CHECK: PASSED
Movies found: your movie count
Phone access: PRESERVED - NOT CHANGED
Batocera will not reboot automatically.

[CLOSE INSTALLER]

PART 4 - VERIFY THE INSTALL

CONFIRM VERSION 1 BEFORE ADDING MOVIES

10	**Check the installed version** After Batocera restarts, open **Ports > Movie Player Version**. Confirm that it reports **Batocera Movie Player App Version 1**.

11	**Confirm the Movies section** Return to the main Batocera screen. Confirm that the Movies section, theater background, Movies logo, and two-panel movie list appear normally.

VERSION CHECK

Batocera Movie Player App
Version 1
Created by Joshua R. Taylor
JRT3D.com - 2026

[CLOSE]

PART 5 - ADD MOVIES AND POSTERS

ONE MOVIE LIBRARY - NO DUPLICATES

12	**Copy movies into the Movies folder** From another computer, open **\\BATOCERA\share\roms\movies**. Copy MP4, MKV, AVI, MOV, M4V, WEBM, MPEG, MPG, TS, M2TS, WMV, VOB or other supported movie files there.
13	**Add an optional poster** Give the poster the same base filename as the movie. Example: **The Goonies.mp4** and **The Goonies-poster.jpg**. JPG, JPEG, PNG, WEBP and BMP are supported.
14	**Update the Batocera list** In Batocera choose **GAME SETTINGS > UPDATE GAME LISTS**. Open Movies and confirm that the title and poster appear.

EXAMPLE MOVIE FOLDER

The Goonies.mp4
The Goonies-poster.jpg
Cooties.mkv
images/Cooties.webp

[UPDATE GAME LISTS]

PART 6 - CONNECT ZAPAROO

BUILD THE PHONE'S LOCAL MOVIE LIST

15	**Refresh the phone database** Open the Zaparoo phone app. Go to **Settings > Manage Media > All systems > Update media database**. If background optimisation is running, allow it to finish.
16	**Find the Movie system** After the update finishes, open **Search Media** and select the **Movie** system. Choose a movie from search and write that result to its NFC tag.
17	**Test the complete flow** Scan the movie tag. The movie should open fullscreen without exposing Batocera's left-side menu. Scan a second movie tag to switch immediately.

WRITE MOVIE TAGS THE SAFE WAY

Use Search Media > Movie.
Select the exact movie result.
Write that result to the tag.
Do not hand-type Path or ZapScript for normal movie cards.

[WRITE TAG]

HOW TO SCAN A CARD

PLACE - PAUSE - REMOVE

For a fast, reliable read, place the card over the reader instead of swiping it past the reader.

1	**Place it flat** Place the card flat over the reader antenna. Keep the NFC tag side closest to the reader.
2	**Hold it still** Hold the card still for about half a second, until the reader reacts. Then remove it.
3	**Mark the sweet spot** Find the area where cards read most reliably. Mark that spot clearly on the reader enclosure.
4	**Keep the area clear** Keep the reader away from metal, magnets, hard drives, power supplies, and other electronics.
5	**Use one card** Do not scan a stack of cards. Thick holders can reduce range, so place the NFC side nearest the reader.
6	**Check the USB connection** If reads are inconsistent through a USB hub, connect the reader directly to Batocera and test again.

PART 7 - DAILY USE

SIMPLE CONTROLLER AND CARD OPERATION

The Release Kit includes a full-size controller guide, quick-controls sheet, printable duplex control cards, and individual front/back JPGs.

A / START Play or Pause	**B** Stop and return
X / Y Fit-Fill / Zoom	**D-PAD** Seek and volume
L1 / R1 Seek 60 seconds	**SELECT** Start Over prompt

DAILY USE REMINDER
Scan a movie card to play it. Scan a second movie to switch immediately. Press B once to stop and return to Movies. **[READY]**

HELP AND MAINTENANCE

THE THREE PLACES TO CHECK

Open Ports in Batocera for these tools:

A	**Movie Player Version** Shows the installed version. Confirm **Batocera Movie Player App Version 1**.
B	**Movie Player Diagnostics** Displays clear success/failure checks for the player, theme, Zaparoo and library.
C	**Collect Movie Player Logs** Creates a diagnostics text file and, when available, a ZIP in the main SHARE folder.

Useful log locations

/userdata/system/logs/movie-player-install.log
/userdata/system/logs/movie-player-diagnostics.log
/userdata/system/logs/batocera-movie-player.log

READY FOR V1 TESTING

Movies open manually and from NFC cards.
B returns safely to Movies.
Fit, Fill and Zoom work.
Movie-to-game and game-to-movie handoff work.

[V1 READY]