EVERYDAY MOVIE CONTROLS

SPACE OR A	**PLAY / PAUSE** Pause the movie. Press again to keep playing.
LEFT OR L1	**REWIND** Move backward through the movie.
RIGHT OR R1	**FAST FORWARD** Move forward through the movie.
L2	**BACK 60 SECONDS** Jump back one minute.
R2	**FORWARD 60 SECONDS** Jump forward one minute.
SELECT / BACK	**RESTART MOVIE** Start the current movie again from the beginning.
B, ESC, OR Q	**STOP AND RETURN** Close the movie and return to the Movies section.

Some features require a movie file with matching subtitle, audio, or chapter tracks.

JRT3D.com - Joshua R. Taylor 2026

PICTURE, SOUND & SUBTITLES

X	**FIT / FILL** Switch between fitting the whole picture and filling the screen.
Y	**ZOOM** Cycle through 115%, 130%, 150%, and Off.
UP	**VOLUME UP** Make the movie louder.
DOWN	**VOLUME DOWN** Make the movie quieter.
M	**MUTE** Turn sound off or back on.
S	**SUBTITLES ON / OFF** Show or hide subtitles when the movie includes them.
N	**NEXT SUBTITLE** Choose the next available subtitle track.

Some features require a movie file with matching subtitle, audio, or chapter tracks.

JRT3D.com - Joshua R. Taylor 2026

TRACKS, CHAPTERS & INFORMATION

AUDIO CARD

NEXT AUDIO TRACK

Change language or audio track when another is available.

CHAPTER + CARD

NEXT CHAPTER

Move to the next chapter.

CHAPTER - CARD

PREVIOUS CHAPTER

Return to the previous chapter.

INFO CARD

MOVIE INFORMATION

Show information about the movie currently playing.

PROGRESS CARD

PLAYBACK PROGRESS

Show the current position and remaining playback time.

ZAPAROO CARD TIP

Place the card flat over the reader and hold it still for about half a second. Do not swipe it.

Some features require a movie file with matching subtitle, audio, or chapter tracks.

JRT3D.com - Joshua R. Taylor 2026

WHAT THE MOVIE APP CAN DO

MOVIES TAB

DEDICATED MOVIES LIBRARY

Browse movie titles from their own section in Batocera.

SCAN CARD

PLAY WITH A MOVIE CARD

Scan a written Zaparoo movie card to start that movie full screen.

SCAN NEW MOVIE

SWITCH BETWEEN MOVIES

A new movie card stops the current movie and starts the new one.

SCAN MEDIA

SWITCH BETWEEN MOVIES AND GAMES

Move between a playing movie and a game without restarting Batocera.

MATCH FILE NAME

ADD YOUR OWN POSTERS

Use matching JPG, PNG, BMP, or WebP artwork for each movie.

CURRENT MEDIA

WRITE THE PLAYING MOVIE

Use Zaparoo Current Media to write the movie that is playing to a tag.

BUILT-IN TOOLS

REFRESH AND TROUBLESHOOT

Refresh movie listings and collect diagnostics when help is needed.

Some features require a movie file with matching subtitle, audio, or chapter tracks.