




For 24FCV0026-0027









37FCT-24150


B-Pillar Wiring Harness (Long Axle)










37FCV-24010-Z03 Instrument harness







37FCW-24221-A09 Harness(USB)
















>200~500	+20,-10	+20,-10
>500~1000	+30,-15	+30, -15
>1000~3000	+40,-20	+40,-20
>3000~5000	+50, -25	+50,-25
more than 5000	+1.5%, -0.5%	+2.0%,-0.5%
Clamping piece	+5,-5	+5,-5
grommet	+5,-5	+5,-5




NO.	MUDI	= NO	WIRE	WIRE	WIRE	CONNECTED FROM.		CONNECTED TO.		NOTE
NO.	VVIPCE	INO.	DIA.	TYPE	COL.	FUNCTION	Con NO.	FUNCTION	Con NO.	INOIE
1	30#	30#	1.25	AVSST	Lg	To front wall light harness (7)	1	To right speaker (1)	3	
2	31#	31#	1.25	AV551	L	To fornt light harness(6)	1	To right speaker (2)	3	
3	201	201	1.25	AVSS	L	TO front wall light harness C(1)	2	To right electic window switch(5)	5	
4	207	207	1.25	AVSS	R/L	To front wall light harness C(1)	2	To right electric window switch (3)	5	
5	208	208	1.25	AVSS	G/R	To front wall light harness C(3)	2	To right electic window switch (5)	5	
6	222	202	1.25	AVSS	L/W	To RF door motor (2)	4	Right door electric window switch(1) 5	
7	223	206	1.25	AVSS	L/R	To RF door motor(1)	4	Right electric window switch (4)	5	
8	212	212	1.25	AVSS	L/Y	To Front light harness C(4)	1	To RF door lock(1)	6	
9	213	213	1.25	AVSS	L/B	To font wall lilght harness C(8)	-1	To right front door lock(4)	6	
	H-5A	H-5A	0.5	AVSS	L/R	To font wall light harness D (3)	2	To electic rear view mirror	7	
	H-8	H-8	0.5	AVSS	R/G	To font wall light harness D(3)	2	To electric rear view mirror (1)	7	
	H-9	H-9	0.5	AVSS	R/W	To front wall light haness D(2)	2	To electic rear view mirror	7	
	0bD	0bD	0.85	AVSS	W/B	TO Electric Rear View Mirror (6)	7	TO front wall harness D (5)	2	
	49A	49A	0.85	AVSS	L/B	TO Electric Rear View Mirror (4)	7	To front wall harness (6)	2	





RF door harness




NO.	Ι,	WIRE NO	WIR	E WIR	E WIR	CONNECTED F	ROM.	CONNECTED T	0.	NOTE
NO.	i '	WIKE NO	DIA.	TYP	E COL	FUNCTION	ConNO.	FUNCTION	Con NO.	NOTE
1	0с		2. 0	AVS	s W/B	TO ceiling harness (1)	1	J0cA、0cB	Λ	
2		0cA	1. 2	5 AVS	s W/B	J0c	<u>l</u>	To rear wiper (3)	3	
3		0сВ	0.8	5 AVS	s W/B	J0c	Λ	To upper brake light(1)	4	
4		0cC	2. 0	AVS	s W/B	Ј0с	ſ	To rear defroster (2)	5	
5	21	21	0.8	5 AVS	S G/W	TO ceiling harness (3)	1	To upper brake light (2)	4	
6	216	216	2. 0	AVS	S B	To ceilling harness (4	1	To rear defroster (1)	2	
7	RW-	2 RW-:	2 1.2	5 AVS	S L/R	To ceilling harness (2)	1	To rear wiper (1)	3	
8	36al	36al	3 1.2	5 AVS	S L/R	To ceilling harness (8)	1	To rear wiper (2)	3	
9	RW-	RW-	1 1.2	5 AVS	S L/W	To ceilling harness (7)	1	To rear wiper (4)	3	


Autodesk


37Z15-24090

LR door harness


Autodesk








37Z15-24140-C Ceiling transit harness(long axle)



NO.	WIDI	E NO.	WIRE	WIRE	WIRE	CONNECTED FROM.		CONNECTED TO.		NOTE	
NO.	WIRI	E INO.	DIA.	TYPE	COL.	FUNCTION	Con NO.	FUNCTION	Con NO.	NOTE	
1	Α	А	20	HEB	B/R	Battery positive pole	4	engine	1		
2	В	В	20	EB	B/Gr	Battery negative terminal	5	Engine ground	2		
3	75	75	3.0	AVS	В	starter	6	engine compart ment harnes	ss 3		


Length	Allowable tolerance(mm)
distinguishing	main line
0~200	+10,-0
>200~1000	+20,-0
>1000~2000	+30,-0
>2000	+2%,-0%
Refer To the diagram	if there is special guidance tolerance



A view C view D view


37Z15-24180 Battery harness Asy


Autodesk SDJ622-F2. 2U (0. 3-0. 5) (2) 090G (0. 3-0. 5) (2) SDJ622-F2. 2A (0. 85-1. 25) (2) DJ90112 (B) (0. 85-1. 25) (2) DJ70613Y-2.2-21(Gr) TO engine compartment harness SDJ621-F3*0. 6A(0. 5-0. 85)(2) SDJ611-F2. 2B (0. 85-1. 25) (2) DJ70616Y-2. 2-11 (W) TO sliding door limiter 37Z15-24210 Step harness Autodesk








Harness License plate lamp














Technical requirement

- 1. Remove lint and zinc plating.
- 2. Detailed dimensions are based on 3D data








Technical requirement


- 1. Remove lint and zinc plating.
- 2. Detailed dimensions are based on 3D data


37Z15-24320



front fog lamp harness


	NO. WIRE NO.		WIRE	WIRE	WIRE	CONNECTED FROM.		CONNECTED TO.		
NO.	WIRE N	0.	DIA.	TYPE	COL.	FUNCTION	Con NO.	FUNCTION	Con NO.	NOTE
1	0n	0n	0.5	AVSS	W/B	TO Fuel Sensor Harness (3)	1	TO frame wiring harness (2)	2	
2	0na	0na	2.0	AVSS	W/B	TO Fuel Sensor Harness (4)	1	TO frame wiring harness (3)	2	
3	144	144	2.0	AVSS	R	TO Fuel Sensor Harness (1)	1	TO frame wiring harness (9)	2	
4	58	58	0.5	AVSS	Y/L	TO Fuel Sensor Harness (2)	1	TO frame harness(7)	2	





Fuel sensor harness

	NO. WIRE NO.		WIRE	WIRE	WIRE	CONNECTED FROM.		CONNECTED TO.		Nome
NO.	WIKE N	0.	DIA.	TYPE	COL.	FUNCTION	Con NO.	FUNCTION	Con NO.	NOTE
1	0d	0d	0. 5	AVSS	W/B	To engine compartment harness	1	TO driver safety mortise lock (2)	2	
2			TO engine compartment harness (1)	1	TO driver lock harness(1)	2				



safty belt alarm harness on driver's side

DJ7021-2.3-21 TO driver safety mortise lock

M	O. W	TDE A	īO.	WIRE	WIRE	WIRE	CONNECTED FROM.		CONNECTED TO.		NOTE
IN	U. W.	TKE I	iU.	DIA.	TYPE		FUNCTION C	Con NO.	FUNCTION	Con NO.	NOTE
	1 0	2	C	25	QVR	В	1	1	TO ground(2)	2	
	·				•			•			

 $\begin{bmatrix} C \\ 25 \\ B \end{bmatrix}$

FD435-D8-(25.0)(1)

RPTL0036S

To battery cathode

37Z15-24190

FD435-D8(25)(1) To body ground

Battery negative ground wire harness

Functions and colors

Groups	0	1	2	3	4	5	6	7	8	9	Н
Meanings	Ground	Power	Lamp	Accessory	Spare	A/C	Engine	ABS	Retarder	Instrument	Hybrid
		And		device		Heater	Electric	ECAS	AT	And	Power
		start		and		Fuel	control			signal	
				audio		heater					
Wire	В	R	G	V	Gr	L	W	Y	Р	Br	0
color											

Wire number and explanation

Wire number	Function	Color	Wire number	Function	Color
		0-Grou	nd (B-bla	ck)	
0035	Ground	В		* 0035A, 0035B, 0035C etc.	
	1-F	ower an	d start (R-red)	
1011	Switch power *	R	1134	CAN module 3 switch power 2	R
*	0011A, 0011B, 0011C etc.		1201	Front electric box ACC power	R
1023	Ignition lock start position	R	1202	Front electric box ON power	R
1031	ON control	R	1203	Front electric box permanent power	R
1032	Battery permanent power *	R	1241	Neutral relay input	R
*	0032A, 0032B, 0032C etc.		1242	Rear flap opening indication	R
1037	ACC control	R	1243	Shift relay control	R
1038	Ignition lock start position	R	1301	Rear start button output	R
1047	Start relay input	R	1302	Rear start power	R
1050	Engine stop power	R	1341	Water fountain power	R
1059	Chief power switch control	R	1342	Refrigerator power	R
1159	Emergency switch	R	1343	Preheating power	R
1060	Start relay output	R	1421	ACC fuse box power 1	R
1184	Alternator N or W signal	R	1422	ACC fuse box power 2	R
1111	CAN module1 permanent power1	R	1423	ACC fuse box power 3	R
1112	CAN module1 permanent power2	R	1424	ACC fuse box power 4	R
1113	CAN module1 switch power1	R	1431	ON relay power input	R
1114	CAN module1 switch power2	R	1432	ON relay power output	R
1121	CAN module2permanent power1	R	1433	Rear electric box ON relay control	R
1122	CAN module2 permanent power2	R	1434	Front electric box ON relay control	R
1123	CAN module2 switch power1	R	1501	Wakeup power 1	R
1124	CAN module2 switch power2	R	1502	Wakeup power 2	R
1131	CAN module3 permanent power1	R	1510	CAN switch group power 1	R
1132	CAN module3 permanent power2	R	1511	CAN switch group power 2	R
1133	CAN module3 switch power1	R	1512	Diagnostic switch and OBD power	R
		2-1amj	o (G-gree	n)	
2002	Flasher input	G	2100	Daylight driving lamp	G
2003	Alarm switch permanent power	G	2101	Daylight driving lamp control	G
2004	Right directional lamp	G	2104	Right directional lamp switch	G

2005	Left directional lamp	G	2105	Left directional lamp switch	G
2006	Alarm lamp ON power	G	2116	Aisle lamp switch	G
2007	Flasher output	G	2117	Aisle lamp	G
2008	Brake lamp power	G	2118	Fluorescent lamp switch 2 power	G
2012	Dimmer switch	G	2122	Luggage chamber lamp	G
2014	Low beam control	G	2123	Fluorescent lamp switch 3 power	G
2015	Right high beam lamp	G	2123	Luggage chamber lamp control	G
2016	Lamp switch power	G	2136	Left reading lamp	G
2017	Contour lamp	G	2137	Right reading lamp	G
2018	Reverse lamp switch power	G	2138	Reading lamp relay control	G
2024	Fluorescent lampswitch power1	G	2139	Reading lamp switch power	G
2025	Front fog lamp	G	2144	Brake lamp	G
2026	High beam control	G	2171	Contour lamp control	G
2027	Front fog lamp control	G	2182	Rear fog lamp control	G
2028	Left high beam	G	2413	Switch illumination lamp	G
2066	Fluorescent lamp 2	G	2240	Engine chamber lamp	G
2067	Left low beam	G	2315	Fog lamp switch power	G
2069	Reverse lamp	G	2321	Brake lamp failure alarm	G
2075	Fluorescent lamp 3	G	2322	Left brake lamp	G
2076	Right low beam	G	2323	Right brake lamp	G
2078	Fluorescent lamp 1	G	2413	Switch illumination lamp	G
2080	Fluorescent lamp 4	G	2600	Driver lamp	G
2082	Rear fog lamp	G	2601	Driver lamp switch	G
2083	Rear fog lamp forgetting shut-off relay input	G	2800	Right reading lamp relay input	G
2084	Rear fog lamp forgetting shut-off buzzer	G			
	3-Acce	ssory a	nd audio	(V-violet)	
3001	Door power	V	3149	Left powered sunshade lifting	V
3019	Audio switch power	V	3150	Left powered sunshade lowering	V
3013	Electric horn	V	3151	Right powered sunshade lifting	V
3020	Wiper washer power	V	3152	Right powered sunshade lowering	V
3021	Coin box machine power	V	3160	Toilet occupation	V
3030	Guideboard switch power	V	3161	Toilet help	V
3033	Front door control	V	3162	Toilet dirty water level alarm	V
3036	Middle door control	V	3172	Signal arm control signal	V
3039	Wiper reposition	V	3174	Guideboard control	V
3040	Wiper switch reposition	V	3175	Rear view mirrorswitch control power	V
3041	Wiper switch intermittent	V	3179	Signal arm power	V
3042	Windscreen washer	V	3178	School bus lamp power	V
3044	Rear passenger door opening indication	V	3188	Inside display device switch power	V
3045	Low wiper speed	V	3189	Driver fan switch power	V
3046	Low wiper speed	V	3191	Yellow ready parking lamp	V


1

3049A	Checking Left child controller/closing door	V	3192	Red ready parking lamp	V
3049	output Front door closing control	V	3193	Parking ring power-fuse to switch	V
3049	LF speaker +	V	3194	Parking ring power-switch to ring	V
3052		V	3194	School bus lamp	V
	LF speaker -	V		Window Glass breaker +	V
3053	LR speaker +	V	3197		V
3054	LR speaker -	V	3198	Window glass braker -	V
3055	RF speaker +	·	3216	Air cleaner	
3052	RF speaker -	V	3233	Front door opening switch	V
3053	RR speaker+	V	3236	Middle door opening switch	V
3054	RRspeaker-	V	3242	Windshield washer switch	V
3068	Horn button	V	3249	Front door closing switch	V
3072	Brake condensing separator	V	3255	Signalarm opening output	V
3074	Exhaust brake switch	V	3293	Middle door closing switch	V
3077	exhaust brake solenoid valve	V	3300	Safety window switch output	V
3079	Accelerator pedal switch	V	3301	Safety door switch output	V
3080	Guideboard	V	3302	Looking-around button switchoutput	V
3081	Front door opening indication signal	V	3303	Air releasing valve alarm	V
3085	Station broadcasting inside speaker	V	3311	Centralized lubrication control power	V
3086	Speaker connecting wire 1	V	3317	TV switch power	V
3087	Station broadcasting outside speaker	V	3318	Getting-off monitor power	V
3088	Speaker connection wire 2	V	3324	Audio permanent power	V
3089	Driver fan	V	3330	Front TV display	V
3093	Middle door closing control	V	3331	Middle display device	V
3094	Passenger service button	V	3380	Preparing parking lamp switch output	V
3095	Asking getting-off button	V	3389	Safety belt switch	V
3096	Coin machine lamp	V	3501	TV switch power	V
3097	Coin machine switch output	V	3504	audio12Vswitchpowerinput+	V
3115	Display device switch power	V	3505	Audio 12V power input-	V
3116	Electronic clock	V	3506	Audio 12V permanent power input+	V
3121	Luggage chamber hatch opening indication	V	3510	Ventilation fan +	V
3124	Front door step lamp	V	3513	Ventilation fan -	V
3125	Middle door step lamp	V	3520	Middle door emergency valve alarm	V
3130	Electric horn	V	3521	Front dooremergency valve alarm	V
3131	Pneumatic horn	V	3602	Engine extinguisher power -	V
3132	Toilet vent fan power	V	3603	Engine extinguisher power +	V
3133	Wiper low speed control	V	3604	Engine extinguisher feedback -	V
3134	Wiper high speed control	V	3605	Engine extinguisher feedback +	V
		V			V
3142	Wiper relay connection	V	3631	Side mirror defrosting	V

21/2	Powered sunshade/	V	3701	high temp.alarmoutput	V					
3143	cigar lighter									
3147	Toilet clean water level alarm	V								
4-spare (Gr)										
5-A/Cheater/fuel pipe heating (L)										
5010	A/Ccontrolpower	L	5181	Defroster low speed	L					
5011	A/Ccapacitorpower	L	5182	Defroster high speed	L					
5091	Preheating power	L	5281	Defrosterlow speed switch	L					
5092	Floor heater power	L	5282	Defrosterhigh speed switch	L					
5093	Middle door closing Control A/Cpower control	L	5312	No-battery capacitor sample	L					
5094	A/C alternator exciting	L	5313	No-batterycapacitor output	L					
5097	Preheating control	L	5509	No-batterycapacitor ground	L					
5098	Preheating plug	L	5552	Driver A/C power1	L					
5119	Defroster power	L	5553	Driver A/C power2	L					
5167	Engine idle-up solenoid valve	L								
6-engineelectrical control (W)										
6129	Exhaust brake valve	W	6240	Engine chamber lamp	W					
6232	Engine electrical control ON power	W	6640	NG content sensor ground	W					
6233	engineelectrical control permanent power	W	6641	NG content sensor power (12V)	W					
6303	Rear stop button output	W		ne content beneat penal (121)						
7-ABS, ECAS (Y)										
		7-ABS	S ECAS ()	7)						
7128	ARS working state control		ı		V					
7128 7140	ABS working state control	Y	7146	ABS indication	Y					
7140	ECAS ON power	Y Y	7146 7314	ABS indication ABS control power	Y					
		Ү Ү Ү	7146 7314 7316	ABS indication ABS control power ABS power						
7140 7141	ECAS ON power ECAS permanent power	Y Y Y 8-reta	7146 7314 7316 rder, AT	ABS indication ABS control power ABS power (P)	Y					
7140 7141 8008	ECAS ON power ECAS permanent power Retarder ON power	Y Y Y 8-reta	7146 7314 7316 rder、AT 8127	ABS indication ABS control power ABS power (P) Retarder control power	Y Y					
7140 7141	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch	Y Y Y 8-reta P	7146 7314 7316 rder, AT 8127 8205	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication	Y					
7140 7141 8008 8010	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr	Y Y Y 8-reta P P rument	7146 7314 7316 rder、AT 8127 8205 cluster/s	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br)	Y Y P P					
7140 7141 8008	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm	Y Y Y 8-reta P	7146 7314 7316 rder, AT 8127 8205	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication	Y Y					
7140 7141 8008 8010 9009 9029	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch	Y Y Y 8-reta P P rument Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9108 9109	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm	Y Y P P Br					
7140 7141 8008 8010 9009 9029 9034	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1	Y Y Y 8-reta P P rument Br Br	7146 7314 7316 rder, AT 8127 8205 cluster/s 9108 9109 9110	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm	Y Y P P Br Br					
7140 7141 8008 8010 9009 9029 9034 9043	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator	Y Y Y 8-reta P P rument Br Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9108 9109 9110 9145	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator	Y Y P P Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output	Y Y Y 8-reta P P rument Br Br Br Br	7146 7314 7316 rder, AT 8127 8205 cluster/s 9108 9109 9110 9145 9148	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator	P P Br Br Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048 9061	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output air pressure I too low alarm	Y Y Y 8-reta P P rument Br Br Br Br Br	7146 7314 7316 rder, AT 8127 8205 cluster/s 9108 9109 9110 9145 9148 9156	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator air pressure II too low alarm	P P Br Br Br Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048 9061	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output air pressure I too low alarm Engine coolant temp.	Y Y Y 8-reta P P rument Br Br Br Br Br Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9108 9109 9110 9145 9148 9156 9200	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator air pressure II too low alarm Brake pad alarm output	P P Br Br Br Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048 9061 9062	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output air pressure I too low alarm Engine coolant temp. Fuel gauge	Y Y Y 8-reta P P rument Br Br Br Br Br Br Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9108 9109 9110 9145 9148 9156 9200 9218	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator air pressure II too low alarm Brake pad alarm output Neutral position signal	P P Br Br Br Br Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048 9061 9062 9063	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output air pressure I too low alarm Engine coolant temp. Fuel gauge Odometer sensor power	Y Y Y 8-reta P P rument Br Br Br Br Br Br Br Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9108 9109 9110 9145 9148 9156 9200 9218 9324	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator air pressure II too low alarm Brake pad alarm output Neutral position signal Instrument permanent power	P P Br Br Br Br Br Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048 9061 9062 9063 9064	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output air pressure I too low alarm Engine coolant temp. Fuel gauge Odometer sensor power odometersensoroutputsignal	Y Y Y 8-reta P P rument Br Br Br Br Br Br Br Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9109 9110 9145 9148 9156 9200 9218 9324 9401	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator air pressure II too low alarm Brake pad alarm output Neutral position signal Instrument permanent power air pressure II sensor (spare)	P P P Br Br Br Br Br Br Br Br Br					
7140 7141 8008 8010 9009 9029 9034 9043 9048 9061 9062 9063 9064	ECAS ON power ECAS permanent power Retarder ON power Retarder SHUTOFF switch 9-instr Instrument cluster ON power coolant temp. too high alarm switch Charging indicator1 Parking braking indicator Brake lamp switch output air pressure I too low alarm Engine coolant temp. Fuel gauge Odometer sensor power	Y Y Y 8-reta P P rument Br Br Br Br Br Br Br Br Br	7146 7314 7316 rder、AT 8127 8205 cluster/s 9108 9109 9110 9145 9148 9156 9200 9218 9324	ABS indication ABS control power ABS power (P) Retarder control power Retarder indication ignal (Br) RM brake pad wearing alarm LR brake pad wearing alarm RR brake pad wearing alarm Centralized lubrication indicator Fuel leveltoo low indicator air pressure II too low alarm Brake pad alarm output Neutral position signal Instrument permanent power	P P Br Br Br Br Br Br Br Br					

9083	Air filter blocked alarm	Br	9511	coolant temp./level alarm buzzer	Br					
9089	Too low coolant level alarm	Br	9651	vehicle speed signal1	Br					
9090	Oil pressure indication	Br	9652	vehicle speed signal2	Br					
9101	Engine chamber	Br	9653		Br					
9101	high temp.alarm1		9000	vehicle speedsignal3						
9102	Engine chamber high	Br	9654		Br					
9102	temp.alarm2		3034	vehicle speedsignal4						
9103	Retarder high temp.alarm	Br	9655	vehicle speed signal5	Br					
9104	Luggage chamber high	Br	9656		Br					
3104	temp.alarm		9030	vehicle speed signal6						
9105	LF brake pad wearing alarm	Br	9657	vehicle speedsignal7	Br					
9106	RF brake pad wearing alarm	Br	9658	vehicle speedsignal8	Br					
9107	LM brakepad wearing alarm	Br	9834	Charging indicator2	Br					
	H-hybrid									

3.3 wire code meanings



3