

MANUAL

CAPCOM

SETTING EXPLANATION


OPCB CONNECTOR

JAMMA STANDARD

OCRT MONITOR

VERTICAL SCREEN

OCONTROL PANEL




08-WAY LEVER: MOVES PLAYER IN 8 DIRECTIONS

OSHOT BUTTON: NORMAL SHOT

○BOMB BUTTON: BOMB

 $\circ \text{DIP SW}$

(THERE ARE TWO TYPES OF PCB.)



JAMMA STANDARD

SOLDER SIDE			COMPONENTS SIDE
GND	A	1	GND
GND	В	2	GND
+5V	С	3	+5V
+5V	D	4	+5V
N.C.	Е	5	N.C.
+12V	F	6	+12V
	Н	7	
N.C.	J	8	COIN COUNTER 1
(COIN LOCK OUT 2)	K	9	(COIN LOCK OUT 1)
SP (-)	L	10	SP (+)
N.C.	M	11	N.C.
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	Р	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
N.C.	S	15	TEST SW
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P SHOT 1 (2P SHOT)	Z	22	1P SHOT 1 (1P SHOT)
2P SHOT 2 (2P BOMB)	a	23	1P SHOT 2 (1P BOMB)
N.C.	b	24	N.C.
N.C.	c	25	N.C.
N.C.	d	26	N.C.
GND	e	27	GND
GND	f	28	GND

• PARTS NAME

CR7E-56DA-3.96E: (HIROSE)

OR

1168-056-009 :(KEL)

●DIP SW(A)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
	1 COIN 1 CREDIT	OFF	OFF	OFF					
	1 COIN 2 CREDITS	ON	OFF	OFF					
	1 COIN 3 CREDITS	OFF	ON	OFF					
COIN 1	1 COIN 4 CREDITS	ON	ON	OFF					
SETTINGS	1 COIN 6 CREDITS	OFF	OFF	ON					
	2 COINS 1 CREDIT	ON	OFF	ON					
	3 COINS 1 CREDIT	OFF	ON	ON					
	4 COINS 1 CREDIT	ON	ON	ON					
	1 COIN 1 CREDIT				OFF	OFF	OFF		
	1 COIN 2 CREDITS				ON	OFF	OFF		
	1 COIN 3 CREDITS]			OFF	ON	OFF		
COIN 2	1 COIN 4 CREDITS]			ON	ON	OFF		
SETTINGS	1 COIN 6 CREDITS				OFF	OFF	ON		
	2 COINS 1 CREDIT	1			ON	OFF	ON		
	3 COINS 1 CREDIT]			OFF	ON	ON		
	4 COINS 1 CREDIT]			ON	ON	ON		
CONTINUE	NORMAL							OFF	
COIN	CONTINUE COIN							ON	
NOT USED						-			OFF

^{\$} IF CONTINUE COIN MODE IS "ON", GAME STARTS WITH 2-COIN 1-CREDIT AND CONTINUES WITH 1-COIN 1-CREDIT.

●DIP SW(B)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
	EASY	OFF	OFF	OFF					
	•	ON	OFF	OFF					
		OFF	ON	OFF					
DIFFICULTY	NORMAL	ON	ON	OFF					
LEVEL		OFF	OFF	ON					
		ON	OFF	ON					
		OFF	ON	ON					
	HARD	ON	ON	ON					
	1ST 600000Pts.				OFF	OFF			
	EVERY 1400000Pts.				OFF	OFF			
	1ST 600000Pts.]							
EXTENDED	2ND 2000000Pts.				ON	OFF			
PLAY	3RD 4500000Pts.								
	1ST 1200000Pts.				OFF	ON			
	2ND 3500000Pts.				OFF	ON			4
	ONLY 2000000Pts.]			ON	ON			
NOT USED					_		OFF	OFF	OFF

●DIP SW(C)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
THE MIMDED	3 PLAYERS	OFF	OFF						
THE NUMBER -	1 PLAYER	ON	OFF						
	2 PLAYERS	OFF	ON						
PLAYER	4 PLAYERS	ON	ON						
FREE PLAY	NORMAL			OFF					
FREE PLAY	FREE PLAY			ON					
SCREEN	NO				OFF				
PAUSE	YES				ON				
SCREEN	NO					OFF			
FLIP	YES					ON			
DEMON- STRATION	NO						OFF		
SOUND	YES						ON		
CONTINUE	NO							OFF	
CONTINUE	YES							ON	
TEST MODE -	GAME MODE		-						OFF
	TEST MODE								ON

**HIGHLIGHTED CHARACTER INDICATES FACTORY SETTING.

**MAKE SURE THE POWER IS OFF BEFORE CHANGING DIP SWITCHES.

No. 2-8, TSURIGANECHO 2-CHOME, CHUO-KU, OSAKA 540, JAPAN TEL (06) 946-2058 FAX NO. (06) 946-6657