

Quick Info on Sympodium Monitor ID 350

- To start the Sympodium Monitor ID 350
 - 1. Ensure the computer is switched "on"
 - 2. Turn the monitor switch on
 - 3. Press any keyboard button

After starting the computer there are two kinds of function controls;

Pen-Tool Buttons (located at the top)	
R	The Arrow button changes pen to mouse mode (pointer mode)
	The Digital ink color buttons (black, blue & red). • Works well with PowerPoint, websites, and software such as excel • Write on the screen The Eraser button to manually erase digital ink.

Tips:

• Use these tools in presentations and instruction; Use the digital ink to draw on the screen. To quickly erase all drawings, press the arrow button & touch the screen



You can double click your way though a link while still in pen mode

Last updated July 17, 2008

Function Buttons (located near the bottom)	
C	Launch Notebook software This can be used to make quick notes without having to wait to open a word document.
•	Change next pen contact to a right-click Press button once to use stylus pen for right clicking.
6	 Useful in taking quick pictures of websites or students work and instantly saving it as a picture. Opens onto the notebook software function
USB Connection (located on the outside edge of the monitor	

Tips:

- -The podium computer is now equipped with a mouse as an alternative input device.
- -The options which display when one right clicks an object change with each object. Ex: right click a picture online and you can copy the picture, right click on the desktop background and the properties menu is made available.

FAQ:

• My monitor is still blank, or is saying no signal.

Press any keyboard button, or Touch the screen with the stylus pen, or Press the monitors power on/off (be sure monitor and computer are on).

- I have a faded boxed outline on the screen that won't go away Restart the computer to reset the screen
- My stylus pen won't line up with the arrow, what do I do? Or, I am having Problems using the stylus with detailed objects, such as checkboxes.

The best solution is to restart the computer, however for a quick fix, locate the position of the tip of the pointer to the stylus tip. Use that distance as your new location of the arrow.

Last updated July 17, 2008

Add your own! To hold in building this manual feel free to write down any questions or time you may have		
To help in building this manual feel free to write down any questions or tips you may have. We're trying to make this as useful and thorough as possible so don't hesitate to ask anything about workstation.		



http://infodome.sdsu.edu

Last updated July 17, 2008 3