


1. REFER TO P&ID LEAD SHEETS FOR SYMBOLS AND ABBREVIATIONS.
2. ALL AUTOMATED VALVES ARE TO BE FAIL-CLOSE UNLESS OTHERWISE 3. CONNECTION POINTS TO EQUIPMENT ARE SHOWN FOR REFERENCE

1. SUPPLY AIR: VAV-XXXX (XXXX IS EQUAL TO ROOM NUMBER SERVED)
2. RETURN AIR: RAV-XXXX (XXXX IS EQUAL TO ROOM NUMBER SERVED) 3. EXHAUST AIR: EAV-XXXX (XXXX IS EQUAL TO ROOM NUMBER SERVED) 4. ALL RETURN AIR AND EXHAUST AIR ROOM GRILLES HAVE A 2" MERV 8 5. ALL RETURN AIR AND EXHAUST AIR VALVES HAVE A MERV 13 FILTER BOX BEFORE THE VALVE 6. SPACE TEMPERATURE TRANSMITTERS ARE TO BE LOCATED IN THE RETURN AIR DUCT JUST BEYOND THE MERV 8 FILTER 7. HALF TONE PIDS REPRESENT PHASE TWO SPACE.







PROJECT KEYSTONE - PHASE 1

Date 05/25/22 LIC NO 50819 CONFIDENTIAL - THIS DRAWING IS THE PROPERTY OF UPSHER-SMITH. THE

MANNER WITHOUT THE WRITTEN PERMISSION OF THE OWNER. CHECKED BY: Checker

SPACE AIR DISTRIBUTION P&ID