

LEMKEN QR Guide for Karat 10/Karat 12

Level the front beam and back beam with the front hydraulic ram - can be adjusted to LEVEL the machine with the remote when the machine is stopped, can't adjust while moving in the ground. If the machine is not level the wings on the front will "butterfly up" and cause damage to the hydraulic cylinders. **Always raise and lower the machine as you turn**, the shanks and rollers are not designed to be in the ground while turning.



Depth Control

This is a **GAUGE** only 1 = shallow, 5 = deep, maximum depth is between 14"-15"

Adjust the turn buckles on the front gauge wheels so they carry weight and keep the machine level side to side. These should be the same length (about 8 threads above the top jam nut).

Best operating speed is dependent on field conditions, preferably minimum speed 4-5mph, best 6mph+.



Closing disc

The main function of the closing discs are to LEVEL the soil so that you have a smooth and level finish behind the rollers. For the outside left and right wings these are fully adjustable. Adjust so that you have a smooth pass to pass finish.

For the main closing disc, usually have three to four holes showing to start off. Adjust accordingly for a level finish. Once these are set you will not need to adjust them again. Note: adjust the center disc with the wings folded up, it is easier to do.



Shanks and Quick-Change Points

Shanks are protected by a 1300lb trip spring and secondary by shear bolts. When replacing shear bolts make sure they are in the same position as all other shanks as you have several options for adjustments. Maximum Depth (14"-15") NEW HARD CARBIDE METAL

POINTS, K6H – 33710023, K8H – 33710031, K12H – 33710030. NEW HARD CARBIDE METAL WINGS, KF30HL – 33710019, KF30HR - 33710018. For taking out alfalfa use the K12H or K8H on the front row with 30 cm wings, 2nd & 3rd row use the 40cm hard surface wings, KF40P RE – 33710004, KF40P LI – 33710005

Operations & Maintenance: grease all axle fittings **DAILY!** Grease all other hinge or folding points every other day. Always raise and lower on the ends, the rollers and shanks are not designed to be operated while in the ground!