

LEMKEN QR Guide for Rubin 10/ Rubin 12



LEVEL THE MACHINE – (arrows DO NOT need to line up to each other)

Silver or Blue Arrow = Level, Calibrate the Pitch = Extend the front ram (Silver or Blue Arrow) all the way out, pull the silver or blue rod all the way to the top of the number gauge (1). Place the end of the rod in the best hole of honeycomb plate to secure the position. Start with the silver or blue arrow in the 3-4 position then adjust as conditions change. Adjust the silver or blue arrow as needed when changing tractors and various drawbar heights to match field conditions.

Main Frame below the gauge needs to be level, DO NOT drop the front gang down deeper.

Red Arrow is the working depth – 1 = shallow, 9 = deep. DO NOT use wheels for depth control, they must always be up in working position. DO NOT TURN with the disc in the ground! The **Rubin 10** gauge allows for wear, new disc's #5 max depth, as they wear go up to #9 to achieve maximum depth with worn discs.



Rebound Harrows

The purpose of the Rebound Harrow is to shatter and mix the soil and residue. Low residue = lower the harrows, high residue = raise the harrows. These are not designed to drag on the soil surface.

Rear leveling harrows

Adjust these to level the soil before the rollers. Usually you need these a few inches in the ground.



Lateral Limiter Plate (side shields)

These are adjustable for various soil conditions. Up/down, forward/backwards. These are designed to keep the soil in the working width so there are no ridges.

Rear outside disc adjustment

These outside rear discs can be adjusted so that there is not any pass to pass ridges or valleys. To adjust raise the disc, put a large block of wood under the blade then lower the disc. This will compress the spring so that the adjustments can be made. By having the disc higher there will be less of a valley created pass to pass.

Rubin 10 front stabilizer wheels are self-adjusting.

When to replace worn disc blades: Rubin 12 -29" blades – maximum wear 4" (25"), Rubin 10 – 25" blades – maximum wear 4" – (21"). After the blades have worn the effective tillage depth, mixing, and finish job are not effective.

Operations & Maintenance: Grease the axle assembly DAILY and all other beams and folding points every other day. DO NOT TURN WITH the machine in the ground! Always raise and lower as you turn, the machine and rollers are not designed to be turned in the ground!

Rubin 10/1000 – Exception – the rollers are on the ground when turning to provide stability.