

Standard measured values	Deflection of the angle sensor	Fault
4.5 V	max. deflection	Overvoltage > 4.6 V

Inductive sensors/Capacitive sensors

Standard measured values	Signal from the operating system	Fault
0 V	Display of error code	Yes
12 V	in operation	No

LEMKEN item number	Function	Applied sensors
573_4375	Fan speed Tramline-distributor monitoring	Inductive sensor
57311284	Lifting compact discs	Angle sensor 70° 0.5V-4.5V with pre-mounted lever (57311161)
47310107	Level	Probe sensor M12 3P NO (double hopper)
57310742	Speed	Radar sensor 27.45 Hz type Pa
57310743	Speed	Radar sensor 27.45 Hz UK
67310532	Seed pipe monitoring	Seed monitoring D30x1370, incl. flexible hose
67310568	Seed pipe monitoring	Seed monitoring D30x1020, incl. flexible hose

2 Malfunctions

Job computer and Powerbox

No.	Fault description	Cause	Remedy
L5000	 NO power supply LSC-1 (master ECU)  Voltage to supply master ECU CANNOT be measured	Sensor on master ECU defective Cable form of master ECU defective Master ECU defective	- Check cable forms of the master ECU for damage. - Check plug-in connections on all the sensors of the master ECU. - Loosen all plug-in connections and check during which insert-remove procedure the message appears.

No.	Fault description	Cause	Remedy
L5000	 NO power supply LSC-1 (master ECU)  Voltage to supply master ECU CANNOT be measured	Sensor on master ECU defective Cable form of master ECU defective Master ECU defective	■ Replace defective components in the following order: – sensors ⇒ Function test – Cable forms ⇒ Function test – Master ECU
L5001	 NO power supply LSC-1 (slave ECU)  Voltage to supply slave ECU CANNOT be measured	Sensor on slave ECU defective Cable form of slave ECU defective Slave ECU defective	■ Check cable forms of the slave ECU for damage. ■ Check plug-in connections on all the sensors of the slave ECU. ■ Loosen all plug-in connections and check during which insert-remove procedure the message appears. ■ Replace defective components in the following order: – sensors ⇒ Function test – Cable forms ⇒ Function test – Slave ECU
L5002	 NO power supply ISOBUS  ISOBUS power supply CANNOT be measured on the ISOBUS gateway	Faulty wiring of ISOBUS connecting cable in Powerbox 60A ISOBUS power fuse in the tractor/mounting set defective ISO PWR fuse in Powerbox defective Cable form between Powerbox and ISOBUS gateway defective ISOBUS gateway defective	■ Check fuse in the tractor and mounting set. ■ Check fuses in the Powerbox. ■ Check plug-in connections/cable form between the Powerbox and the ISOBUS gateway. ■ Use a measuring device to check up to which point the ISOBUS voltage can be measured, see pin assignment of the cable form between the Powerbox and the ISOBUS gateway. ■ Replace defective components.
L5005	 No CAN communication to first Powerbox  No CAN communication between master ECU and first Powerbox.	1. Powerbox not connected Faulty wiring of ISOBUS connecting cable in first Powerbox 15A ECU power fuse in tractor/mounting set defective Cable form between first Powerbox and master ECU defective First Powerbox defective Job computer defective	■ Check whether the first Powerbox is supplied with voltage (visual inspection of the LEDs). ■ Cable form between first Powerbox and master ECU for damage.

No.	Fault description	Cause	Remedy
L5005	 No CAN communication to first Powerbox  No CAN communication between master ECU and first Powerbox.	1. Powerbox not connected Faulty wiring of ISOBUS connecting cable in first Powerbox 15A ECU power fuse in tractor/mounting set defective Cable form between first Powerbox and master ECU defective First Powerbox defective Job computer defective	■ Replace defective components in the following order: – Cable form between first Powerbox and master ECU ⇒ Function test – 1. Powerbox ⇒ Function test – Master ECU
L5008	 Member fuse in first Powerbox defective  At least one fuse (M1-M5) in the first Powerbox is defective.	Fuse defective No fuse connected First Powerbox defective	■ Check fuses (M1-M5) in the first Powerbox. If necessary, replace the fuses. ■ 1. Replace Powerbox.
L5009	 Voltage measurement/Non-ISOBUS terminal fuse in first Powerbox tripped  Fuse for the ISOBUS power measurement/power supply of the non-ISOBUS operation terminal has tripped.	Cable form between first Powerbox and ISOBUS gateway/Non-ISOBUS terminal defective First Powerbox defective ISOBUS gateway/Non-ISOBUS operation terminal defective	■ Cable form between first Powerbox and ISOBUS gateway/non-ISOBUS terminal for damage. ■ Replace defective components in the following order: – Cable form between first Powerbox and ISOBUS gateway/non-ISOBUS terminal ⇒ Function test – 1. Powerbox ⇒ Function test – ISOBUS gateway/non-ISOBUS terminal
L5010	 No CAN communication to second Powerbox  No CAN communication between master ECU and second Powerbox.	2. Powerbox not connected Faulty wiring of cable form between first or second Powerbox Cable form between first or second Powerbox defective First or second Powerbox defective	■ Check whether the second Powerbox is supplied with voltage (visual inspection of the LEDs). ■ Check the cable form between the first and second Powerbox for damage. ■ Replace defective components in the following order: – Check the cable form between the first and second Powerbox ⇒ Function test – 2. Powerbox ⇒ Function test – 1. Powerbox
L5013	 Member fuse in second Powerbox defective	Fuse defective No fuse connected Second Powerbox defective	■ Check fuses (M1-M5) in the second Powerbox. If necessary, replace the fuses. ■ 2. Replace Powerbox.

No.	Fault description	Cause	Remedy
L5013	 At least one fuse (M1-M5) in the second Powerbox is defective.	Fuse defective No fuse connected Second Powerbox defective	
L5015	 No CAN communication to third Powerbox  No CAN communication between master ECU and third Powerbox.	3. Powerbox not connected Faulty wiring of cable form between second or third Powerbox Cable form between second or third Powerbox defective Second or third Powerbox defective	■ Check whether the third Powerbox is supplied with voltage (visual inspection of the LEDs). ■ Check the cable form between the second and third Powerbox for damage. ■ Replace defective components in the following order: – Check the cable form between the second and third Powerbox ⇒ Function test – 3. Powerbox ⇒ Function test – 2. Powerbox
L5018	 Member fuse in third Powerbox defective  At least one fuse (M1-M5) inside the third Powerbox is defective.	Fuse defective No fuse connected Third Powerbox defective	■ Check fuses in the third Powerbox. If necessary, replace the fuses. ■ 3. Replace Powerbox.
L5020	 No CAN communication to slave ECU  NO CAN communication between master ECU and slave ECU.	Slave ECU not connected Cable form between first Powerbox and slave ECU defective First Powerbox defective Slave ECU defective	■ Check whether the slave ECU is supplied with voltage (visual inspection of the LEDs). ■ Cable form between first Powerbox and slave ECU for damage. ■ Replace defective components in the following order: – Cable form between first Powerbox and slave ECU ⇒ Function test – 1. Powerbox ⇒ Function test – Slave ECU
L5021	 No CAN communication to MultiHub ECU	MultiHub ECU not connected Cable form between last Powerbox and MultiHub ECU defective Last Powerbox defective MultiHub ECU defective	■ Check whether the MultiHub ECU is supplied with voltage (visual inspection of the LEDs). ■ Check the cable form between the last Powerbox and MultiHub ECU for damage.

No.	Fault description	Cause	Remedy
L5021	 No CAN communication to MultiHub ECU	MultiHub ECU not connected Cable form between last Powerbox and MultiHub ECU defective Last Powerbox defective MultiHub ECU defective	■ Replace defective components in the following order: – Cable form between last Powerbox and MultiHub ECU ⇒ Function test – Last Powerbox ⇒ Function test – MultiHub ECU

Metering motors

No.	Fault description	Cause	Remedy
L5030	 No CAN communication to metering motor  No CAN communication between master ECU and respective metering motor.	Metering motor not connected Incorrect ID of metering motor Cable form between metering motor and associated Powerbox defective Associated Powerbox defective Metering motor defective	■ Assigning metering motor ID ■ Check cable form between the metering motor and the associated Powerbox for damage. ■ Check line flows with a measuring device, see pin assignment of the motor cable form. ■ Replace defective components in the following order: – Metering motor ⇒ Function test – Cable form between metering motor and associated Powerbox ⇒ Function test – Associated Powerbox
L5031	 Malfunction in the electronics of the metering motor  General malfunction in the motor electronics	Metering motor defective, malfunction in the electronics of the metering motor Input current too high due to blockage	■ Visually inspect metering chamber. If necessary, remove foreign objects. ■ Clean metering unit. ■ Replace metering motor.
L5032	 Undervoltage at metering motor  Supply voltage of respective metering motor is below 9 V.	Voltage source too weak Cable form between metering motor and associated Powerbox defective Associated Powerbox defective Metering motor defective	■ Start the tractor. ■ Check voltage in the control unit (Information > Metering motors menu): Voltage > 11 V ■ Check cable form between the associated Powerbox and the metering motor for damage. ■ Check voltages with a measuring device inside the associated Powerbox and on the cable form, see pin assignment of the motor cable form. ■ Replace metering motor.

No.	Fault description	Cause	Remedy
L5033	 Overvoltage at metering motor  Supply voltage of respective metering motor is above 35 V.	Incorrect voltage source Cable form between metering motor and associated Powerbox defective Associated Powerbox defective Metering motor defective	■ Connect machine to another 12 V power source (tractor, power supply unit, etc.). ■ Check voltages of the associated Powerbox and the metering motor in the control unit (Information > Voltage > Metering motors menu). ■ Check cable form between the associated Powerbox and the metering motor for damage. ■ Check voltages with a measuring device inside the associated Powerbox and on the cable form, see pin assignment of the motor cable form. ■ Replace metering motor.

Angle sensor

No.	Fault description	Cause	Remedy
L5040	 Undervoltage angle sensor soil cultivation  Supply voltage of angle motor is below 400 mV	Angle sensor soil cultivation not connected Angle sensor soil cultivation defective Sensor cable form between master ECU and angle sensor soil cultivation defective Master ECU defective	■ Check cable form between master ECU and angle sensor soil cultivation for damage. ■ Replace defective components in the following order: – Angle sensor soil cultivation ⇒ Function test – Cable form between master ECU and angle sensor soil cultivation ⇒ Function test – Master ECU
L5041	 Overvoltage angle sensor soil cultivation  Supply voltage of respective metering motor is above 4600 mV.	Angle sensor soil sensor soil cultivation defective Sensor cable form between master ECU and angle sensor soil cultivation defective Master ECU defective	■ Check cable form between master ECU and angle sensor soil cultivation for damage. ■ Replace defective components in the following order: – Angle sensor soil cultivation ⇒ Function test – Cable form between master ECU and angle sensor soil cultivation ⇒ Function test – Master ECU

Pressure differential sensor

No.	Fault description	Cause	Remedy
L5042	 Undervoltage at pressure differential sensor  Supply voltage of respective metering motor is below 400 mV.	Pressure differential sensor not connected Pressure differential sensor defective Sensor cable form between master ECU and pressure differential sensor defective Master ECU defective	■ Check cable form between master ECU and pressure differential sensor for damage. ■ Replace defective components in the following order: – Pressure differential sensor ⇒ Function test – Cable form between master ECU and pressure differential sensor ⇒ Function test – Master ECU
L5043	 Overvoltage at pressure differential sensor  Supply voltage of respective metering motor is above 4600 mV.	Pressure differential sensor defective Sensor cable form between master ECU and pressure differential sensor defective Master ECU defective	■ Check cable form between master ECU and pressure differential sensor for damage. ■ Replace defective components in the following order: – Pressure differential sensor ⇒ Function test – Cable form between master ECU and pressure differential sensor ⇒ Function test – Master ECU

3 Warnings

Depending on the software version, messages start with **L0**, **L4** or **L5**.

Starting and performing sowing

No.	Fault description	Cause	Remedy
L0304, L4304 or L5304	 Minimum operating speed not reached  The minimum operating speed calculated by the calibration test is not reached.	Driving speed too low Calibration test not performed correctly	■ Drive faster. ■ Perform new calibration test at a lower desired driving speed. ■ Check the speed signal. ■ If necessary, perform 100 m calibration.

No.	Fault description	Cause	Remedy
L0305, L4305 or L5305	 Maximum operating speed exceeded  The maximum operating speed calculated by the calibration test is exceeded.	Driving speed too high Calibration test not performed correct	- Drive more slowly. - Perform new calibration test at a higher desired driving speed. - Check speed signal. - If necessary, perform 100m calibration.
L0309, L4309 or L5303	 Tramline rhythm not available  Tramlines cannot be created in the currently calculated rhythm	The currently entered working width of the cultivating machine cannot be implemented with the equipment of the machine. Machine settings incorrect	- Adjust the working width of the cultivating machine. - Check machine settings.
L5300	 Software versions of master ECU and ISOBUS gateway incompatible  Machine functions are blocked for safety reasons.	Master ECU NOT updated Update of master ECU faulty	Perform update of master ECU in the service menu.
L5302	 Calibration test incomplete  Metering units are not (fully) adapted to current seeds. Incorrect distribution is possible.	Calibration test not completed correctly	- Perform new calibration test completely. - Load saved calibration test.

Calibration terminal

No.	Fault description	Cause	Remedy
L5320	 NO CAN communication to calibration terminal  No CAN communication between master ECU and calibration terminal	Calibration terminal not connected Cable form between first Powerbox and calibration terminal defective First Powerbox defective Calibration terminal defective	- Check whether the calibration terminal is supplied with voltage (visual inspection of the LED). - Cable form between first Powerbox and the calibration terminal for damage. - Replace defective components in the following order: - Cable form between first Powerbox and calibration terminal ⇒ Functional test 1. Powerbox ⇒ Functional test - Calibration terminal

Metering motor

No.	Fault description	Cause	Remedy
L0314, L4314 or L5332	 Deviation set and actual speed of the metering motor  Deviation between the set and actual speed of the metering motor (> 500 rpm)	Excessive tightening torque (≥ 12 Nm) at metering motor Metering motor defective	■ Clean metering unit and check again. ■ Remove metering motor and check again in idle mode. ■ Replace faulty metering motor.
L0330, L4330 or L5331	 Tightening torque critical  The tightening torque of the corresponding metering unit is permanently (at least for 5 seconds) above the permitted threshold value (> 9 Nm).	Foreign objects in the metering unit Impairment of the rotary movement due to abrasive components inside the metering unit Metering motor defective	■ Check metering unit for foreign objects or abrasive components. ■ Remove metering unit. Check metering unit for soiling and damage. ■ Remove metering motor. Test metering motor again in idle mode. ■ Replace faulty metering motor.
L5330	 Overtemperature metering motor  The temperature of the respective metering motor is above 80 °C.	Excessive tightening torque at the metering motor over a longer period of time Metering motor defective	■ Clean metering unit. ■ Remove metering motor. Test metering motor again in idle mode. ■ Drive more slowly. ■ Replace faulty metering motor.

TramlineControl

No.	Fault description	Cause	Remedy
L5342	 Failure GPS for TramlineControl  The GPS signal has failed for use of TramlineControl.	No connection to the GPS receiver GPS receiver not set up / parametrised correctly GPS receiver defective	■ Check the connections on the GPS receiver. ■ Check GPS settings. ■  Have the error rectified by service personnel.
L5343	 No position data for TramlineControl  GPS receiver data is received. The position data is invalid.	No guiding line created Driving direction not parallel to guiding line	■ Create guiding line. ■ Align driving direction parallel to the guiding line. ■  Have the error rectified by service personnel.

Fan

No.	Fault description	Cause	Remedy
L0308, L4308 or L5351	 Fan speed exceeded  The set maximum speed threshold of the fan is exceeded.	Maximum speed limit too low	- Adjust maximum speed in the settings. - Reduce oil quantity via the flow control valve (tractor, machine).
L5350	 Fan speed not reached  The set minimum speed threshold of the fan is not reached.	Lower speed limit too high Sensor sensing distance not observed (< 3 mm) Sensor defective Cable form defective Master ECU defective	- Switch on the fan. - Adjust minimum speed in the settings. - Increase oil flow rate via flow control valve (tractor, machine). - Check sensor position and sensing distance. - Check cable form for damage. - Replace defective components in the following order: - Sensor ⇒ Functional test - Cable form ⇒ Functional test - Master ECU defective

Tramline distributor

No.	Fault description	Cause	Remedy
L0311, L4311 or L5356	 Nominal pressure for switching the tramline distributors too low  Due to the excessively low fan speed (< 2000 rpm) the nominal pressure at the tramline cylinders is insufficient. Incorrect switching operation is possible.	Fan switched off or fan speed too low Sensor sensing distance not observed (< 3 mm) Inductive sensor defective Cable form defective Master ECU defective	- Switch on the fan. - Increase oil flow rate via flow control valve (tractor, machine). - Check sensor position and sensing distance. - Check cable form for damage. - Replace defective components in the following order: - Inductive sensor ⇒ Functional test - Cable form ⇒ Functional test - Master ECU
L5355	 Tramline distributor travel incomplete  The corresponding tramline distributor does not move correctly to its end positions.	Distributor insert jammed Dirt accumulation below the distributor insert Sensor position or sensing distance (< 3 mm) incorrect Cable form defective Slave ECU defective	- Check travel of tramline distributors. - Remove distributor insert. Clean distributor. - Check sensor position and sensing distance. Mount sensors correctly.

No.	Fault description	Cause	Remedy
L5355	 Tramline distributor travel incomplete  The corresponding tramline distributor does not move correctly to its end positions.	Distributor insert jammed Dirt accumulation below the distributor insert Sensor position or sensing distance (< 3 mm) incorrect Cable form defective Slave ECU defective	■ Check cable form for damage. ■ Check and replace defective components in the following order, if required: – Sensor ⇒ Functional test – Cable form ⇒ Functional test – Slave ECU

Folding

No.	Fault description	Cause	Remedy
L5360	 Centre coulter bar segment dropped down  The centre coulter bar segment of the folded-in machine has dropped down. The sequence control automatically shows the status for lifting the centre coulter bar segment.	Centre coulter bar segment has dropped down due to oil loss	To lift the coulter bar segment back up: ■ Follow the instructions of the sequence control.
L5361	 Left lateral section folded out  The left lateral section of the folded-in machine has dropped down. The sequence control automatically displays the status for folding in the left lateral section.	Left lateral section has dropped down due to oil loss	To lift the left lateral section back up: ■ Follow the instructions of the sequence control.
L5362	 Right lateral section folded out  The right lateral section of the folded-in machine has dropped down. The sequence control automatically displays the status for folding in the right lateral section.	Right lateral section has dropped down due to oil loss	To lift the right lateral section back up: ■ Follow the instructions of the sequence control.

Pressure tank monitoring

No.	Fault description	Cause	Remedy
L5370	 Pressure difference between seed hopper and metering unit  Excessive pressure difference between seed hopper and metering units	Seed hopper not leak tight Metering unit housing not leak tight Differential pressure sensor defective Cable form defective Master ECU defective	■ Check seed hopper for leak tightness. ■ Check metering unit housing for leak tightness. ■ Check cable form for damage. ■ Replace defective components in the following order: – Pressure differential sensor ⇒ Functional test – Cable form ⇒ Functional test – Master ECU

Seed pipe monitoring (KFÜ)

No.	Fault description	Cause	Remedy
L5500	 Seed pipe monitoring (KFÜ): CAN error  No communication to the seed pipe monitoring module	Seed pipe monitoring module (LJR-115) not connected Cable form defective Seed pipe monitoring module defective Slave ECU defective	■ Re-install the seed pipe monitoring module in the menu. ■ Check whether the seed pipe monitoring module is supplied with voltage (visual inspection of the LEDs). ■ Check cable form for damage. ■ Replace defective components in the following order: – Connecting cable form ⇒ Functional test – Seed pipe monitoring module ⇒ Functional test – Slave ECU
L5501	 Seed pipe monitoring (KFÜ): Supply voltage too low  The seed pipe monitoring module reports insufficient supply voltage (< 9 V)	Supply voltage at the seed pipe monitoring module too low Connecting cable form defective	■ Start the tractor and make sure the generator is running. ■ Check the voltage in the control (Information > Voltage menu). ■ Check plug-in connections. ■ Check cable form for damage. ■ Replace defective components in the following order: – Connecting cable form ⇒ Functional test – Seed pipe monitoring module

No.	Fault description	Cause	Remedy
L5502	 Seed pipe monitoring (KFÜ): LIN error  Communication interrupted: at least one sensor	Cable forms defective Sensor defective Seed pipe monitoring module defective	■ Determine the faulty sensor in the control (Information > Seed pipe monitoring menu) ■ Check the sensor cable form and connecting cable form for damage. ■ Replace defective components in the following order: – Sensor ⇒ Functional test – Sensor cable form ⇒ Functional test – Connecting cable form ⇒ Functional test – Seed pipe monitoring module
L5503	 Seed pipe monitoring (KFÜ): Insufficient sensors  Insufficient sensors detected on at least one distributor based on the current machine configuration.	Tramline settings incorrect Sensors/Sensor cable form connected incorrectly	■ Check number of sensors on the distributor. ■ Check cabling on the distributor.
L5504	 Seed pipe monitoring (KFÜ): Sensor values invalid  At least one sensor sends incorrect measured values.	General sensor communication error Sensor defective	■ Restart seed pipe monitoring module. ■ Replace sensor.
L5505	 Seed pipe monitoring (KFÜ): Excessive quantity  At least one sensor reports an excessive flow of seeds.	Incorrect seeds Sensor defective	■ Perform new calibration test with the correct seeds. ■ Adapt limit parameters in the service menu. ■ Determine the faulty sensor in the control (Information > Seed pipe monitoring menu); ■ Replace sensor.
L5506	 Seed pipe monitoring: Seed pipe blocked  At least one sensor reports a blockage within the measuring range.	Seed pipe blocked Sensor defective	■ Determine the faulty sensor in the control (Information > Seed pipe monitoring menu). ■ Replace sensor.
L5507	 Seed pipe monitoring (KFÜ): Insufficient amount	Incorrect seeds Seed pipe upstream of sensor blocked or broken off Tramline settings incorrect Seed pipe	■ Perform calibration test with the correct seeds. ■ Determine the faulty sensor in the control (Information > Seed pipe monitoring menu).

No.	Fault description	Cause	Remedy
L5507	 At least one sensor reports an insufficient/unavailable flow of seeds.	monitoring parameter incorrect Seed pipe monitoring cabling incorrect	- Check relevant seed pipe. - Check tramline insert: Parameters must correspond to tramline insert. - Check connected sequence of the sensors. - Determine the faulty sensor in the control (Information > Seed pipe monitoring menu); - Replace sensor.
L5508	 Seed pipe monitoring: Seed pipe soiled  At least one sensor reports heavy soiling within the measuring range.	Seed pipe heavily soiled Sensor defective	- Check the sensor for soiling and clean it, if necessary. - Replace sensor.

Lighting equipment

No.	Fault description	Cause	Remedy
L5525	 LIN bus abort to lighting module  No communication between master ECU and lighting module	Lighting module not connected Connecting cable form defective Lighting module defective Master ECU defective	- Check whether the lighting module is supplied with voltage (visual inspection of the LEDs). - Check cable form for damage. - Replace defective components in the following order: - Connecting cable form ⇒ Functional test - Lighting module ⇒ Functional test - Master ECU
L5526	 Lighting module: Error at output  Short circuit or cable break at the corresponding output of the lighting module	Consumer not connected correctly Lighting cable form defective Lighting module defective	- Check connection of the cable form in the lighting module. - Check cable form for damage. - Replace defective components in the following order: - Lighting cable form ⇒ Functional test - Lighting equipment ⇒ Functional test - Lighting module

4 Notices

No.	Fault description	Cause	Remedy
L5600	 Start with half the working width required for tramlines 	The tramline mechanism settings require starting with half the working width on the first pass-over.	Switch-off of the singling units on the displayed side of the machine.
L5601	 One half of the machine switched off manually 	All singling units on one half of the machine are switched off.	- Check whether the switch-off is necessary. - If required, correct.
L5602	 Initial calibration of the radar sensor 	The radar sensor has not yet been calibrated.	Perform 100 m calibration.
L5603	 Speed source backup active 	GPS failure Connection to TECU interrupted	- Check GPS input. - Check connection to TECU.
L5650	 Hopper empty  When the hopper is empty: Distribution not possible	Hopper empty Level sensor not calibrated Level sensor defective Motor cable form Metering motor defective	- Refill spreading material. - Check sensors in the hopper: - Green LED at sensor lights up if power supply is connected. - Yellow LED at sensor lights up when seeds are in the hopper. - Readjust level sensor, see operating instructions for the machine. - Check cable form for damage.  If necessary, have the cable form or the sensor replaced by service personnel. - Refill spreading material. - Check sensors in the hopper: - Green LED at sensor lights up if power supply is connected. - Yellow LED at sensor lights up when seeds are in the hopper. - Readjust level sensor, see operating instructions for the machine. - Check cable form for damage. - Replace defective components in the following order: - Level sensor ⇒ Functional test - Cable form ⇒ Functional test - Metering motor