



Channel Configuration Instructions:

GND

GND

R20

JP23

Q10A

DMN61D8L-I

DMN61D8L-LM

JP27

MOS_A7

Each channel or pair has several configurable output modes.
All channels can do the -500mA range.
Only channel A can do the +16A with optional soft start range.
Only channels B and C can do the ±1.5A range
For Bank A:
For the -500mA and +16A ranges:
Populate the dual MOSFET
The two channels in the pair may be configured independently
For the -500mA range: Jump the 2 position jumper for that channel
For the +16A range:
Populate the P-FET, the 10K resistor, and a 1k gate resistor
Jump the 3 position jumper to select the voltage (if available)
To add soft start: Use a 680k gate resistor and populate the capacitor

Never populate the dual MOSFET and the MOSFET driver on the same channel pair For the -500mA range: Populate the dual MOSFET only For the ±1.5A range: Populate the dual MOSFET driver only Both channels in the pair mmust be configured identically

Mode	Dual Driver	Dual MOSFET	P MOSFET	2pad Jumper	Rgate	С
-500mA		Yes		Jumped		
+16A		Yes	Yes	Open	1k	
+16A W/ Soft Start		Yes	Yes	Open	680k	Yes
±1.5A	Yes					

Do not populate any component not specified in the table

Title:
Rev:

Contributors: \${CONTRIBUTOR} | Sheet: /power_switching/ | Id: 2/2