When looking up the LaunchPad and BoosterPack pinout, TI provides a handy **BoosterPack Checker** website (also linked from Pages → Datasheets):

- https://dev.ti.com/bpchecker
  - Select the LaunchPad and BoosterPack (they are in separate tabs on the left)
  - Click **Toggle Connector** such that the BoosterPack is on **Connector #2**.
  - Hover the mouse over the Connector #1 and #2 pins to receive information on the pin function, GPIO port and pin number, and peripheral signal name.