Sequence of Operations: AHU-1 Supply Air Temperature Setpoint

Sample document written for Mechanical Muse to exercise "bring your own sequence". It is not taken from any standard or project.

1. GENERAL

AHU-1 serves an open-plan office floor. The building automation system calculates the discharge air temperature setpoint described here and sends it to the AHU's cooling coil loop once a minute.

2. INPUTS

- AHU enable (on/off).
- Outdoor air temperature, °F.
- Return air relative humidity, %.

3. SETPOINT CALCULATION

3.1 While the AHU is off, the setpoint is 55 °F.

3.2 When the AHU starts, hold the setpoint at 55 °F for the first 10 minutes so the space is pulled down quickly. The 10 minutes start again every time the AHU starts.

3.3 After that, reset the setpoint from outdoor air temperature: 55 °F when it is 70 °F or warmer outside, 65 °F when it is 60 °F or colder, and in a straight line between those points.

3.4 Dehumidification: if return air humidity has stayed above 60 % for 5 minutes, use 55 °F regardless of outdoor air temperature, until humidity drops below 55 %.

4. OUTPUTS

- Discharge air temperature setpoint, °F.
- Dehumidification active (on/off), for the operator's graphics.