Model GW-50 50-Gallon Gas Water Heater: Owner's Manual

Safety

Keep flammable products such as gasoline, paint thinner and adhesives away from the burner compartment. Never store anything against the flue collar.

Maintenance

Flush the tank every six months to remove sediment: close the cold supply, attach a hose to the drain valve and run it until the water is clear.

Inspect the magnesium anode rod every 3 years and replace it when more than six inches of core wire are exposed. Replacement anode part number AR-5521. A depleted rod lets the steel tank corrode from the inside.

Test the temperature and pressure relief valve once a year by lifting the lever for a few seconds.

Troubleshooting

A rotten egg smell in hot water usually means bacteria reacting with the anode; an aluminium-zinc anode fixes it.

If the pilot will not stay lit, the thermocouple is the most likely cause.