

Rivertek RT-2050 Pressure Transmitter -- Quick Start Guide

QUICK START GUIDE FOR RIVERTEK RT-2050 PRESSURE TRANSMITTER

INSTALLATION STEPS

- Site Preparation**: Ensure the installation site is clean and free from obstructions. Verify that the ambient temperature and humidity levels are within specified limits (e.g., -10°C to +60°C and 0-90% RH).
- Mounting**: Use the included mounting bracket to secure the RT-2050 transmitter to a stable surface. Position the unit vertically for optimal performance, ensuring that the pressure port is aligned with the fluid flow.
- Connection to Pressure Source**: Connect the transmitter's pressure port to the process line. Use appropriate fittings to prevent leaks and ensure a secure connection.

WIRING DIAGRAM DESCRIPTION

The RT-2050 has a four-wire configuration: two wires for power supply and two for the output signal. The power supply wires are color-coded as follows: red for positive (+24V DC) and black for negative (GND). The output signal wires are blue (4-20 mA signal) and green (signal return). Ensure that the power supply is disconnected during wiring. After wiring, connect the red wire to the power supply positive terminal, the black wire to the negative terminal, the blue wire to the signal input of your control system, and the green wire to the signal return.

BASIC STARTUP CHECK

- Power On**: Once wiring is complete, apply power to the RT-2050. The LED indicator should light up, confirming the unit is powered.
- Signal Verification**: Use a multimeter to check the output signal. For zero pressure, the output should be approximately 4 mA. Gradually apply pressure to verify that the output scales correctly to 20 mA at full scale.
- Calibration Check**: Perform a quick calibration check using known pressure sources. Adjust settings as necessary according to the calibration procedure outlined in the full manual.

Ensure all connections are secure and the environment is free from contamination before proceeding with regular operation.