

Instruction list

Note: English symbols must be used, and a # symbol must be included at the end. Incorrect command will result in no response or an incorrect response format.			
NO.	Functional items	Instruction format	Remark
1	Address lookup	123 or DW	
2	Status query	STATUS#	
3	Version query	VERSION#	
4	Locate immediately	LJDW#	Sleep mode will wake up the device for location tracking The location status will report the location packet.
5	Query parameter settings PARAM#		
6	Latitude and longitude location query command WHERE#		
9	Backend server parameter settings (main IP)	1. Configure the domain name: SERVER,1,domain,port,0# 2. Configure IP: SERVER,0,IP,port,0# The last digit 0 represents: TCP	
10. Query	backend server parameters SERVER#		
11	Restart command	RESET#	
12	Add SOS number	SOS, A, Number 1, Number 2, Number 3#	
13	Delete SOS number;	SOS, D, Number 1, Number 2, Number 3#	
14	query SOS number	SOS#	
15	Heartbeat interval settings	HBT,T1,T2# T1 = 1-5 minutes, ACC ON heartbeat packet upload interval T2 = 1-5 minutes, ACC OFF heartbeat packet upload interval	
16. Query	heartbeat interval (HBT#)		
17	GPS data timed transmission interval	TIMER,T1,T2# T1 = 5-60 seconds; upload interval when ACC ON. T2 = 5-60 seconds; upload interval in ACC OFF state.	
18	Query GPS data scheduled transmission time Interval	TIMER#	
19	Delayed Arming Settings	DEFENSE,A# A: 1-60 minutes, defense delay time	
20	Query the delay arming time DEFENSE#		
21. Query	SENSOR controls GPS time	SENDS, A# A = 0-300 minutes 0 indicates GPS is always on.	
22. Query	SENSOR to control GPS time. SENDS#		
23. Query	Hydraulic and electric control	RELAY, A# A=0/1; 0 connects the fuel system, 1 disconnects the fuel system.	Only 4/8-line devices support this.
24. Query	Query the status of the electric control system (RELAY#)		
25	Enable vibration alarm settings	SENALM,A,M# A=ON	Only devices with GSENSOR are supported.

		M = 0 ~ 2 Alarm reporting methods 0 GPRS only , 1 SMS+GPRS, 2 GPRS+SMS+CALL;	
26	Turn off vibration alarm	SENALM, OFF#	
27	Query vibration alarm settings parameters	SENALM#	Only devices with GSENSOR are supported.
28	Enable power failure alarm settings	POWERALM,A,M,T1,T2,# A=ON M = 0 ~ 2 ; 0 GPRS only , 1 SMS+GPRS , 2 GPRS+SMS+CALL T1 = 2-60 seconds; power outage detection time T2 = 1-300 seconds; minimum charging time	
29	OFF# Power failure alarm	POWERALM	
30	Query power outage alarm status	POWERALM#	
31	Enable low battery alarm settings	BATALM,A,M# A=ON M=0~1 0 represents: GPRS only, 1 represents: SMS+GPRS.	
32	Turn off the low battery alarm setting	BATALM, OFF#	
33	Query low battery alarm status	BATALM#	
34	Enable displacement alarm settings	MOVING,A,R,M# A=ON R = 100~1000; displacement radius M=0~2; 0 GPRS only, 1 SMS+GPRS; 2 GPRS+SMS+CALL	
35	Turn off displacement alarm	MOVING, OFF#	
36	Query displacement setting status	MOVING#	
37	Activate overspeed alarm	SPEED,A,B,C,M# A=ON B = 5-600 seconds; time range C = 1~255km/h; Overspeed threshold range M = 0 ~ 1 Alarm reporting method: 0 GPRS only , 1 SMS+GPRS;	
38	Turn off the overspeed warning	(SPEED, OFF)#	
39	Check the speed limit setting status	SPEED#	
40	SOS alarm	KEYALM, OFF# Turn off SOS alarm KEYALM, ON, M# M = 0 to 3; Alarm reporting methods 0: GPRS only 1: SMS+GPRS 2: GPRS + SMS + CALL 3: SMS + CALL;	This function is only supported by eight-line devices.
41	APN parameter settings	APN, <Network Name># APN, <network name>[,username][,password]# Using custom APN parameters will disable APN adaptation.	

		APN# Query the parameters of the currently used APN ASETAPN,A# A=ON/OFF; ON indicates that APN adaptive mode is enabled. OFF indicates that APN adaptive mode is disabled.	
42	WIFISW switch	WIFISW,A# A=ON/OFF; ON WIFI location is turned on OFF to turn off default WIFISW,ON#	No Wi-Fi available.
43	ACCALM	ACCALM,A,B,C# A = ON/OFF; ON means on/off; OFF means off/closed. A = 1:0:0 represents: GPRS only, 1 represents: SMS+GPRS, 2 represents: SMS+GPRS, 3 represents: SMS+GPRS, 4 represents: SMS+GPRS, 5 represents: SMS+GPRS, 6 represents: SMS+GPRS, 7 represents: SMS+GPRS, 8 represents: SMS+GPRS, 9 represents: SMS+GPRS, 1... GPRS+SMS+CALL 3. GPRS+CALL C=0y3 0 and 3 both indicate ACCON and ACCOFF alarms; 1 indicates ACCON alarm, ACCOFF alarm not; 2 indicates ACCOFF alarm, ACCON alarm not.	Some versions do not support the C function, meaning they only have the ACCON alarm function or ACCOFF alarm function
44	Vibration-related ACC	CXCS#ACCLINE SZCS#ACCLINE=A A=0 Vibration Correlation A=1 Vibration is not associated (default)	Some versions may not support sending commands that fail. This instruction for the EG915 series
	Vibration-related ACC	SENACC# query SENACC,1# Open SENACC,0# Close	This instruction is used in the 4G17H series.
45	SENSOR, 10, 60, 1#	SENSOR,<A>[,B][,C]# A = 10~300 seconds, detection time, default value: 10 seconds. Second B = 10~300 seconds, alarm delay in automatic arming mode, default value: 60 seconds. C = 1-300 minutes, vibration alarm interval, default 1 minute. bell SENSOR# Query the set parameters	
46	SENSORSET	SENSORSET,<A>,,<C>,<D># A = 10-300 seconds; SENSOR detection time range; Default Value recognition: 10 seconds B = 1-20 times; Vibration activation GPS trigger threshold; Default: 2 times C = 1-20 times; Vibration alarm trigger threshold; Default	

		Value recognition: 3 times D=1-3; SENSOR interval (C seconds), default value: 1 Constraints: AÿC*DÿB*D SENSORSET# Query the set vibration-triggered GPS operating conditions. Default parameters: sensorset: 10,2,3,1	
47	LBS#	LBSOFF# Disable base station information upload LBSON# Enable base station information upload LBS# Query Base Station Information Upload Switch	The 808 protocol base station extension package will no longer report base station extension packages. The base station information in the data reported by the GT02/GT06 protocol is all set 0
48	SERVER2SW#	Dual IP switch query	Dual IP software is required.
49	SERVER2SW#	SERVER2SW,A# A = ON/OFF; ON OFF	Dual IP software is required.
50	Backend server parameter settings (sub IP)	1. Configure the domain name: SERVER2,1,domain name,port,0# 2. Configure the IP address: SERVER2,0,IP address,port,0# The last digit 0 represents TCP.	Dual IP software is required.
53	COLLIDEALM[,S][,M][,V]#	COLLIDEALM[,S][,M][,V]# S is the alarm switch, 0: off, 1: on (default) Thinking 0 M represents the reporting method: 0: GPRS only; 1: ... GPRS+SMS defaults to 0 V is the collision threshold, ranging from 10 to 1024, with a default value of 720.	Not all projects support this.
52	Flip alarm	OVERTURNALM[,S][,M][,V][,T1][,T2][,T3]# S is the alarm switch, 0: off, 1: on (default) Thinking 0 M represents the reporting method: 0: GPRS only; 1: ... GPRS+SMS defaults to 0 V is the toggle threshold, ranging from 1 to 20, in units of... 0.1g (default is 7) T1 represents the time range for collecting calibration values. 3-300 is in seconds, the default is 30. T2 is used to determine the range of trigger duration. 3-300 is in seconds, default is 5.	Not all projects support this.

		T3 indicates an alarm interval range of 1-60 minutes, with a default value of 10.	
53	sudden speed change alarm	SPEEDCHGALM[S][M][V1][V2][T]# S is the alarm switch, 0: off, 1: on (default) Thinking 0 M represents the reporting method: 0: GPRS only; 1: ... GPRS+SMS defaults to 0 V1 is the threshold for rapid acceleration, ranging from 10 to 300 km/h. The default value is 30. V2 is the rapid deceleration threshold, ranging from 10 to 300 km/h, with a default value of 50. T represents the detection time range of 1-30 units. The value is in seconds, with a default value of 3.	Not all projects support this.
54	sharp turn alarm	RASHTURNALM[S][M][V1][V2][T]# S is the alarm switch, 0: off, 1: on (default) Thinking 0 M represents the reporting method: 0: GPRS only; 1: ... GPRS+SMS defaults to 0 V1 is the angle change threshold, ranging from 10 to 180 degrees, with a default value of 20 degrees. V2 is the speed threshold, ranging from 10 to 200. The position is KM/H, and the default value is 50. T represents the detection time range of 1-30 units. The value is in seconds, with a default value of 3.	Not all projects support this.
55	ANGLEREP,ON,2,10#	ANGLEREP,<A>[B][C]# A=ON/OFF (Default: ON) B=2 // 2~5 seconds (detection time) Default 2 C=10 // 10~180 degrees (upload value above 10 degrees) Default 10	
56	STA_SENDGPS,3#	STA_SENDGPS,<A># A = 0~3 0: No static reporting 1: GPSON stationary reporting 2: GPS OFF - Scheduled reporting; 3: Compatible with both 1 and 2 - Default reporting is 3.	Not all projects support this.
57	DORMANCY, 300#	DORMANCY,<A># A = 5~65535# Unit: seconds (default 300)	Not all projects support this.

58	MILEAGE#	MILEAGE,<A># A=ON/OFF# A=ON (If it is a GT02 protocol, the data length will be increased by 4).	Not all projects support this.
----	----------	---	--------------------------------