

Sangoma提供的语音板卡支持RJ46接口,我们也配置一根RJ45-BNC (75欧姆-120欧姆) 的转接线。 具体如何做RJ46线,请参考网站链接。http://wkik.sangoma.com/Cablepinouts<sup>©</sup> 确认运营商验定的线路端口順序,必须和此卡端口一一对应,否则可能出现呼叫问题

#### 检测服务器类型

Sangoma板卡支持2U以上机箱,和PCI或PCI接口的主板插插。建议使用PCI-E插槽的主板。因为目前主流服务器都仅支持PCI-E 插槽。

## 检查Asterisk以及相关版本

到文档写作时,建议使用asterisk主流版本是asterisk-1.8和以上版本,支持dahdi-2.0以上版本,wanpipe-7.0 以上。 不建议使用更低的asterisk版本, zaptel或者asterisk更低版本不建议使用,除非用户经过完整的功能测试。 强烈建议用户安装前咨询我们技术人员 asterisk, dahdi chan \_ss7 版本,遵忠出现不必要的问题。 另外,此文档适应于所有的sangoma E1城卡,具体端口数量可能不同,所以请安装时注意。

#### 检查功能需求

如果客户安装了chan\_ss7,然后需要安装界面管理系统,建议仅使用freepbx支持,通过自定义界面配置呼入和呼出的路由规则。 另外,请用户注意,文档中使用的所有软件版本不是最终版本,涉及到命令和安装路径可能不同,请选择最新的安装版本,或者咨询相关 技术人员。

最后,强烈建议用户使用文档中默认的安装路径和源代码保存路径,方便支持人员安装调试

# 第1章:下载Asterisk/dahdi/chan\_ss7

#### 为asterisk/dahdi安装必要的支持包

安装asterisk/dahdi 之前。必须确认完全安装以下支持包,否则编译报错

 $\label{prop:condition} \begin{tabular}{ll} yum-y install kernel-devel-$\{(uname-r) libtool* make gcc patch perl bison gcc-c++ ncurses-devel flex libtermcap-devel autoconf* automake* autoconf* \end{tabular}$ 

## 从asterisk 官方网站下载asterisk 和dahdi 源代码

下载稳定版本,减压压缩文件到 /usr/src 目录,以下是安装时的举例版本,客户根据自己的实际环境做调整

DAHDI dahdi-linux-2.1.0.4.tar.gz, dahdi-tools-2.1.0.1.tar.gz ASTERISK asterisk-1.4.24.1.tar.gz 注意,这里用户可以下载dahdi-linux-complete 版本,这个版本已经包括了dahdi-linux和dahdi-tool。

#### 做链接

In -s /usr/src/dahdi-linux-2.1.0.4 /usr/src/dahdi In -s /usr/src/asterisk-1.4.24.1 /usr/src/asterisk

## 下载SS7的支持包chan ss7

从官方网站下载chan\_ss7的支持包:www.dicea.dk/company/downloads 此次下载的版本是chan\_ss7-1.1.tar.gz,用户可以根据实际的环境进行版本的调整。 1) 解压压缩文件到 /usr/src 目录。

#### 2) 使用VI 编辑器修改Makefile

vi /usr/src/chan\_ss7-1.1/Makefile

#### 3) 修改源代码包含路径分别到asterisk/dahdi的减压目录

```
INCLUDE+=-I../dahdi/include // 指到 dahdi 源代码路径
INCLUDE+=-I../asterisk/include // 指到 asterisk 源代码路径
```

保存文件,退出。

# 第2章:编译Asterisk/dahdi/chan ss7

## 编译dahdi-linux 和dahdi-tools

执行命令到相应的dahdi-linux,dahdi-tools 目录 执行命令:make,make install 完成dahdi内核和用户部分的安装

## 编译asterisk

执行命令 cd asterisk 源代码目录下:

```
./configure
make
make install
make samples // 生成配置文件,将覆盖原来的文件!
```

#### 编译chan\_ss7

执行命令 cd chan\_ss7 源代码目录下,执行命令

```
make
make install
cp chan_ss7.so /usr/lib/asterisk/modules/
```

# 第3章:配置驱动/dahdi模块/SS7模块

## 安装Sangoma驱动

1) 下载sangoma wanpipe 驱动,以下版本可能是旧的版本,用户建议用户下载最新驱动

```
wget ftp://ftp.sangoma.com/linux/current_wanpipe/wanpipe-3.4.4.tgz
```

#### 2) 减压tar 文件到 /usr/src

#### 3) 安装wanpipe支持包

```
yum install perl-devel
yum install awk
yum install flex
yum install flex
yum install libtermcap-devel
```

#### 4) 安装wanpipe驱动

#### 执行setup安装过程时的选项:

```
[root@localhost wanpipe-7.0.5]# ./Setup install

WANPIPE v7.0.5 Installation Script
Copyright (c) 1995-2013, Sangoma Technologies Inc.

WANPIPE INSTALLATION
You are about to install WANPIPE Multi-Protocol
TDM Voice & WAN Router into your system.
```

This script will examine your system, then install, create and/or modify necessary files and directories. You must have Linux Kernel Headers along with full development tools (i.e. GNU C compiler and utilities) installed in order to be able to install this product. This script will automatically compile all WANPIPE kernel drivers and install them in their appropriate directory. If you are installing Wanpipe for ASTERISK/ZAPTEL this script will will prompt you for zaptel source location. If you have previoulsy installed WANPIPE, this release will overrite/upgrade full release without the need to uninstall first! IMPORTANT: It is always recommended to say YES to all options prompted during the install! Please visit: http://wiki.sangoma.com for more info. Would you like to install WANPIPE now? [y] (y/n) y // 选择y WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. Fixing file permissions... Verifying files and fixing permissions ...Done Warning: Wanpipe Modules are currently running! Its recommended to unload Wanpipe Modules before proceeding with installation. Would you like to proceed? (y/n) y Checking for C developement tools ... (gcc) OK Checking for C++ developement tools ... OK Checking for Make utility ... OK Checking for nourses library ... OK Checking for Perl developement tools ... OK Checking for AWK ... OK Checking for FLEX ...OK Checking for Patch ...OK Checking for libtermcap-devel...OK Press [Enter] to continue... // 确认以上支持包成功安装。输入 Enter 键 WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. Installing WANPIPE Device Drivers: Linux KERNEL To integrate WANPIPE Multi-Protocol Voice & WAN Router modules into the Linux kernel, the kernel has to be updated with latest wanpipe sources. Install will only modify existing wanpipe source that is already in the It is always recommended to say YES to all options prompted during the install! WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. Please specify absolute path name of your linux headers/source directory Press Enter for Default: /lib/modules/2.6.32-358.23.2.el6.x86 64/build Setting linux directory to /lib/modules/2.6.32-358.23.2.el6.x86 64/build Upgrading WANPIPE kernel documentation ... Done. Installing WANPIPE include headers ...Done. WANPIPE device drivers upgraded successfully! Press [Enter] to continue... // 输入Enter 键 WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. WANPIPE KERNEL DRIVER COMPILATION The next step in WANPIPE installation involves compiling WANPIPE kernel modules. This script will compile and install WANPIPE modules into the currently running linux kernel. For greater customization you will be prompted to select which Protocol/Drivers you would like to build into the WANPIPE kernel modules. Wanpipe for Asterisk/Dahdi/Zaptel Default for Asterisk/Dahdi/Zaptel Wanpipe for Wan Routing/API Default for Wan/IP Routing and Data API Wanpipe for Asterisk SMG/SS7 Default for Asterisk SS7 Wanpipe for TDM API

Default for FreeSwitch and Voice API Custom Compilation: Customise WANPIPE driver compilation to add only the protocols that you need. This way one can reduce the size of the WANPIPE kernel drivers. Refer to http://wiki.sangoma.com for more info grep: /lib/modules/2.6.32-358.23.2.el6.x86\_64/build/include/include/autoconf.h: No such file or directory grep: /lib/modules/2.6.32-358.23.2.el6.x86-64/build/include/include/autoconf.h: No such file or directory WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. Please Select Compilation Mode WAN Protocols Support Protocols: Frame Relay, CHDLC, PPP, ATM, X25, ADSL, TDM API Default for: Wan Routing, Data & Voice API devel. Asterisk/Dahdi Support
 Asterisk protocols: libpri (PRI,BRI), Analog (FXO/FXS), libss7 (SS7)
 Default for: Asterisk 3. Asterisk/Dahdi + WAN Protocol Support 4. TDM API (libsangoma)
Protocols: TDM API (libsangoma) on AFT adapters: Default for: FreeSWITCH, Yate, Sunrise
Custom voice development 5. Custom Compilation Mode
Specify protocols to be added into the WANPIPE kernel drivers. 6. Deprecated: SMG (BRI) (Asterisk SMG/BRI [Use Asterisk/Dahdi option 2 instead]) 7. Deprecated: SMG (BRI) + Asterisk/Dahdi [Use Asterisk/Dahdi option 2 instead] Please select (1-7) [Default: 1]: 2 // 现在2在asterisk环境下安装E1 卡 Looking for zaptel/dahdi directory in /usr/src ... 1 : /usr/src/dahdi-linux-complete-2.7.0.1+2.7.0.1 m : Enter zaptel path manually (ctrl-c to Exit) Please select working zaptel directory [1-1][m]: 1 // 输入 1 选择 dahdi 源代码安装路径,如果dahdi 没有安装在默认的路径下,需要手动添加路径 Enabling the TDM Voice Asterisk Support Dahdi HW HDLC Support Detected: Enabling DCHAN Feature Native Dahdi HW HDLC Support Detected - No patch required Dahdi source unmodified Checking for UDEV Zaptel compatibility... Dahdi installed, no need to add UDEV rules Enabling the AFT TEl Support Checking for SMP support ... Enabled. Checking current processor type ...x86 64 Wan Update Flags: -DAF WANPIPE\_2612\_FORCE\_UPDATE -DWANPIPE\_MOD\_266\_FORCE\_UPDATE Checking fo regparm: Disabled CFLAGS: gcc -Wp,-MD, wanpipe.o.d -nostdinc -iwithprefix include -D LINUX -Dlinux -D KERNEL -I/usr/include/wanpipe -I/lib/modules/2.6.32-358.23.2.el6.x86 64/build/include -DMODULE -DAF WANPIPE 2612 FORCE UPDATE Compiling General WANPIPE Driver for 2.6.X Kernel .....Done. WAN HWEC module enabled and compiled! Linking Wanpipe Driver and protocols ...Done. Updating Kernel Modules ...Done. Compilation Successful. WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. WANPIPE META CONFIGURATION There are two configuration files associated with WANPIPE. 1) /usr/src/wanpipe-7.0.5/wanrouter.rc: - defines locations of important files such as lock and configuration files as well as start/stop order of multiple WANPIPE devices. 2) /usr/src/wanpipe-7.0.5/wanpipel.conf:
- main configuration file for each WANPIPE device. - defines interfaces, hardware and protocol information.

- this file can be created using the 'wancfg' GUI utility or manually based on sample files located in /etc/wanpipe/samples. Please read the WanpipeInstallation. (pdf/txt) manual for further Press [Enter] to continue... // 输入 Enter Wanpipe META config file found in /etc/wanpipe directory Wanpipe startup sequence: wanpipel Would you like to keep the original wanpipe startup sequence? (y/n) y // 选择 y

Please specify a desired location for WANPIPE configuration files. (Press Enter for Default: /etc/wanpipe) <specify path:> Please specify a desired location for WANPIPE interface files. (Press Enter for Default: /etc/wanpipe/interfaces) <specify path:> // 摁Enter 键, 板卡配置文件路径 Please specify a location for WANPIPE binary, firmware files. (Press Enter for Default: /etc/wanpipe/firmware) <specify path:> //摁 Enter 键。 WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. WANPIPE UTILITIES SETUP WANPIPE utilities are used to:
1) create configuration files: for Zaptel and Asterisk /usr/sbin/wancfg dandi#Dahdi and Asterisk /usr/sbin/wancfg\_zaptel#Zaptel and Asterisk /usr/sbin/wancfg\_zaptel#Zaptel and Asterisk /usr/sbin/wancfg-tdmapi#TDM APT
2) create WANPIPE WANVIP configuration files. (/usr/sbin/wancfg)

3) start, stop, restart individual/all devices and interfaces. (/usr/sbin/wanrouter)
4) debug line, protocol and driver problems. (/usr/sbin/wanpipemon)
5) aid in WANPIPE API development (/etc/wanpipe/api) Refer to the WanpipeInstallation.(pdf/txt) for more information. Press [Enter] to continue... // 提 Enter Compiling WANPIPE LibSangoma API library ...Done. Compiling WANPIPE LibStelephony API library ...Done. Compiling WANPIPE Utilities ...Done. Compiling WANPIPE WanCfg Utility ... Done. Compiling WANPIPE LibStelephony API Library ... skipped, not required. Compiling WANPIPE API Development Utilities ... skipped, not required. Compiling WANPIPE HWEC Utilities ... Done. WANPIPE Environment Setup Complete !!! Press [Enter] to continue... // 摁 Enter 键 Installing WANPIPE Files ...! Installing WANPIPE Utilities in /usr/sbin Installing wanrouter.rc in /etc/wanpipe Installing wanpipe libraries in /etc/wanpipe
Installing firmware in /etc/wanpipe/firmware Installing firmware in /etc/wanpipe/firmware
Installing documentation in /usr/share/doc/wanpipe
cp: omitting directory 'doc/man'
Installing sample api code in /etc/wanpipe/api
Installing Afr Firmware update utility in /etc/wanpipe/util
Installing driver headers in /etc/wanpipe/api/include/linux
Installing Hardware Echo Cancel Utilites
Press [Enter the Continue... // 想 Enter 键 WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc. WANPIPE BOOTSTRAP CONFIGURATION Your system uses System V -style initialization scripts. You have an option to add router start-up script to those scripts so that the router will start automatically when system enters multi-user mode and shut down when it enters single-user mode or when it is halted. i.e. By selecting this option WANPIPE will startup on system bootup and stop on system shutdown. Would you like to install WANPIPE start-up scripts? (y/n) y //  $\$\lambda$  y Sangoma Wanpipe Dahdi/Zaptel/SMG/TDMAPI/BOOT Configuration Script v2.39 Sangoma Technologies Inc. # Copyright(c) 2013. # Current boot level is 3 Wanrouter boot scripts configuration... Removing existing wanrouter boot scripts...OK Verifying Zaptel boot scripts... Enabling wanrouter boot scripts ...(level:8)
Enabling wanrouter shutdown scripts ...(level:91) WANPIPE v7.0.5 Installation Script Copyright (c) 1995-2013, Sangoma Technologies Inc.

```
WANPIPE INSTALLATON: COMPLETE
 WANPIPE installation is now complete. WANPIPE kernel drivers and configuration/debug utilities have been compiled and installed.
 1) Proceed to configure the WANPIPE drivers:
Asterisk/Dahdi : /usr/sbin/wancfg_dahdi
Asterisk/Zaptel : /usr/sbin/wancfg_zaptel
                              : /usr/sbin/wancfg tdmapi
  TDM API : /usr/sbin/wancfg_tdma
SMG SS7/BRI/PRI : /usr/sbin/wancfg_smg
WAN Routing/API : /usr/sbin/wancfg
 2) Use the /usr/sbin/wanrouter startup script to start and stop
the router. (eg: wanrouter start)
3) To uninstall WANPIEF package run ./Setup remove
  Please read http://wiki.sangoma.com for further instructions.
  Wanpipe / Zaptel Configuration
 wancfg zaptel configurator can create all wanpipe config files for ZAPTEL including /etc/zaptel.conf file. Optionally: the configurator can also create Asterisk zapata.conf
  Would you like to configure wanpipe devices for DAHDI? (y/n) y // {rak m}{\lambda} y
   # Sangoma Wanpipe # Dahdi/Zaptel/SMG/TDMAPI/BOOT Configuration Script # $2.39 # $ Sangoma Technologies Inc. # Copyright(c) 2013. #
 Would you like to generate /etc/asterisk/chan_dahdi.conf 1. YES 2. NO
  2. NO
[1-2]:1 // 输入1 , 创建默认chan dahdi.conf 文件
  Configuring T1/E1 cards [A101/A102/A104/A108/A116/T116]
  A101 detected on slot:4 bus:4
  Configuring port 1 on A101 slot:4 bus:4.
  Select media type for AFT-A101 on port 1 [slot:4 bus:4 span:1]
 1. T1
2. E1
3. Unused
4. Exit
[1-4]:2 // 选择 2, 配置为E1 类型
 Configuring port 1 on AFT-A101 as E1, line coding:HDB3, framing:CRC4
1. YES - Keep these settings
2. NO - Configure line coding and framing
[1-2, ENTER='YES']:2 // 是否安装HDB3, CRC4 方式创建文件;如果不带CRC4, 选择2, 修改配置文件
  Select line coding for port 1 on 101
  1. HDB3
2. AMI
[1-2, ENTER='HDB3']:1 // 选择 1
  Select framing for port 1 on 101
   1. CRC4
2. NCRC4
3. UNFRAMED
   [1-3, ENTER='CRC4']:2 // 选择不支持CRC4
 Select clock for AFT-101 on port 1 [slot:4 bus:4 span:1]
1. NORMAL
2. MASTER
   [1-2]:1 // 选择 1
Select Signalling type for AFT-101 on port 1 [slot:4 bus:4 span:1]
1. Zaptel/Dahdi - PRI CPE
2. Zaptel/Dahdi - PRI NET
3. Zaptel/Dahdi - E & M
4. Zaptel/Dahdi - E & M Wink
5. Zaptel/Dahdi - FXS - Ground Start
6. Zaptel/Dahdi - FXS - Ground Start
7. Zaptel/Dahdi - FXS - Ground Start
7. Zaptel/Dahdi - FXS - Ground Start
9. Zaptel/Dahdi - FXO - Loop Start
10. Zaptel/Dahdi - FXO - Loop Start
11. Sangoma SMG/Sangoma prid- PRI CPE
12. Sangoma SMG/Sangoma prid- PRI CPE
12. Sangoma SMG/Sangoma prid- PRI NET
[1-12]:1 // 选择CPE 用户侧。运营商是网络侧
  Select switchtype for AFT-101 on port 1 1. National ISDN 2
    2. Nortel DMS100
   2. Nortel DMS100
3. AT&T 4ESS
4. Lucent 5ESS
5. EuroISDN
6. Old National ISDN 1
  7. Q.SIG
[1-7]:5 // 选择5
  Would you like to enable hardware DTMF detection?
   1. YES
2. NO
   [1-2, ENTER='YES']:1 // 选择 1
 Would you like to enable hardware fax detection?
1. YES
2. NO
   [1-2, ENTER='NO']:1 // 选择 1
  Configuring port 1 on AFT-101 as a full E1
   1. YES - Use all channels
2. NO - Configure for fractional
[1-2, ENTER='YES']:1 // 使用所有通道
```

```
Select dialplan context for AFT-101 on port 1
  1. from-pstn
2. from-internal
3. Custom
[1-3]:1 // 选择1
Port 1 on AFT-A101 configuration complete...
Press any key to continue: // 揌Enter 继续检测安装
T1/E1 card configuration complete.
Press any key to continue: // 揌 Enter 键,进行其他板卡检测
Configuring ISDN BRI cards [A500/B500/B700]
No Sangoma ISDN BRI cards detected
Press any key to continue: // 摁 enter
Configuring GSM cards [W400]
No Sangoma GSM cards detected
Press any key to continue: // 摁Enter
Configuring analog cards [A200/A400/B600/B610/B700/B800]
Configuring USB devices [U100]
 # SUMMARY #
   1 T1/E1 port(s) detected, 1 configured
0 ISDN BRI port(s) detected, 0 configured
0 analog card(s) detected, 0 configured
0 GSM card(s) detected, 0 configured
   0 usb device(s) detected, 0 configured
Configurator will create the following files:
1. Wanpipe config files in /etc/wanpipe
2. Dahdi config file /etc/dahdi/system.conf
3. chan dahdi config file /etc/asterisk/chan_dahdi.conf
Your original configuration files will be saved to:
1. /etc/dahdi/system.conf.bak
2. /etc/asterisk/chan_dahdi.conf.bak
Your configuration has been saved in /etc/wanpipe/debug-2013-11-21.tgz. When requesting support, email this file to techdesk@sangoma.com
Configuration Complete! Please select following:
1. YES - Continue
2. NO - Exit
[1-2]:1 // 选择 1, 继续配置
 Dahdi and Wanpipe configuration complete: choose action
 1. Save cfg: Restart Asterisk & Wanpipe now
2. Save cfg: Restart Asterisk & Wanpipe when convenient
3. Save cfg: Stop Asterisk & Wanpipe when convenient
4. Save cfg: Stop Asterisk & Wanpipe when convenient
5. Save cfg: Save cfg only (Not Recommended!!!)
6. Do not save cfg: Exit
[1-6]:2 // 选择 2 或者 3。
Stopping Asterisk...
Waiting for inactivity to perform halt
Stopping Wanpipe...
Shutting down wanpipel interface: wlgl
Shutting down device: wanpipel
No devices running, Unloading Modules
Unloading Dahdi modules...
FATAL: Module dahdi is in use.
Error executing command:
modprobe -r dahdi // 忽略这些错误
Would you like to continue?
1. No - exit
2. YES
 [1-2, ENTER='No']:1 2 // 选择2
Removing old configuration files...
Copying new Wanpipe configuration files...
Copying new Dahdi configuration file (/etc/dahdi/system.conf)...
Copying new chan dahdi configuration files (/etc/asterisk/chan dahdi.conf)...
Starting Wanpipe...
Starting WAN Router...
Loading WAN drivers: wanpipe done.
Starting up device: wanpipe1
--> Loading ec image OCT6116-64S.ima...
Configuring interfaces: wlg1
Loading Dahdi...
DAHDI Tools Version - 2.7.0.1
```

```
DAHDI Version: 2.7.0.1
 Echo Canceller(s): HWEC
 Configuration
 SPAN 1: CCS/HDB3 Build-out: 0 db (CSU)/0-133 feet (DSX-1)
 31 channels to configure.
Setting echocan for channel 1 to mg2
Setting echocan for channel 2 to mg2
Setting echocan for channel 3 to mg2
 Setting echocan for channel
Setting echocan for channel 5 to mg2
Setting echocan for channel 6 to mg2
Setting echocan for channel 7 to mg2
Setting echocan for channel 8 to mg2
Setting echocan for channel 9 to mg2
 Setting echocan for channel 10 to mg2
Setting echocan for channel 11 to mg2
Setting echocan for channel 12 to mg2
Setting echocan for channel 13 to mg2
Setting echocan for channel 14 to mg2
Setting echocan for channel 15 to mg2
Setting echocan for channel 16 to none
Setting echocan for channel 17 to mg2
Setting echocan for channel 18 to mg2
Setting echocan for channel 19 to mg2
Setting echocan for channel 20 to mg2
Setting echocan for channel 21 to mg2
Setting echocan for channel 22 to mg2
Setting echocan for channel 23 to mg2
Setting echocan for channel 23 to mg2
Setting echocan for channel 25 to mg2
Setting echocan for channel 26 to mg2
 Setting echocan for channel 27 to mg2
Setting echocan for channel 28 to mg2
Setting echocan for channel 28 to mg2
Setting echocan for channel 29 to mg2
Setting echocan for channel 30 to mg2
 Setting echocan for channel 31 to mg2
Starting Asterisk... Unable to connect to remote asterisk (does /var/run/asterisk/asterisk.ctl exist?)
Listing Asterisk channels...
     Chan Extension Context
                                                      Language MOH Interpret default
                                                                                                        Blocked
                                                                                                                         State
                                                                                                                                          Description
                                                                                                                          In Service
  pseudo
                              default
                              from-pstn
from-pstn
                                                                        default
default
                                                                                                                         In Service
In Service
                              from-pstn
from-pstn
                                                                        default
                                                                                                                         In Service
                                                                         default
                                                                                                                          In Service
                              from-pstn
from-pstn
from-pstn
                                                                        default
                                                                                                                          In Service
                                                                        default
default
                                                                                                                         In Service
In Service
                              from-pstn
from-pstn
from-pstn
                                                                        default
                                                                                                                         In Service
                                                                                                                          In Service
                                                                                                                          In Service
         10
11
12
13
14
15
17
18
19
20
21
22
23
24
25
                                                                        default
                              from-pstn
from-pstn
                                                                        default
default
                                                                                                                          In Service
                                                                                                                          In Service
                              from-pstn
from-pstn
                                                                        default
default
                                                                                                                          In Service
                                                                                                                          In Service
                              from-pstn
                                                                        default
                                                                                                                          In Service
                                                                         default
                                                                                                                          In Service
                               from-pstn
                                                                        default
                                                                                                                          In Service
                              from-pstn
from-pstn
                                                                         default
                                                                                                                          In Service
                              from-pstn
from-pstn
from-pstn
                                                                        default
                                                                                                                         In Service
                                                                                                                         In Service
In Service
                                                                        default
                              from-pstn
from-pstn
                                                                        default
default
                                                                                                                         In Service
In Service
         26
27
28
                              from-pstn
from-pstn
                                                                        default
                                                                                                                          In Service
                              from-pstn
                                                                        default
                                                                                                                         In Service
         29
                              from-pstn
                                                                         default
                                                                                                                          In Service
                              from-pstn
                                                                                                                          In Service
                              from-pstn
                                                                                                                         In Service
Type "asterisk -r" to connect to Asterisk console
Wanrouter start complete ...
Current boot level is 3
 Wanrouter boot scripts configuration...
Removing existing wanrouter boot scripts...OK Would you like wanrouter to start on system boot? 1. YES 2. NO
 [1-2]:1 // 选择 1
Verifying Dahdi boot scripts...
Verifying Dahdi boot scripts...Enabled (level:13)
Verifying Dahdi shutdown scripts...Enabled (level:87)
Enabling wanrouter boot scripts ...(level:12)
Enabling wanrouter shutdown scripts ...(level:86)
Would you like to execute 'dahdi_cfg' each time wanrouter starts? 1. YES 2. NO ....
 [1-2]:1 // 选择 1
Removing old smg_ctrl boot....OK
Removing old smg_ctrl_safe boot....OK
Sangoma cards configuration complete, exiting...
 You have new mail in /var/spool/mail/roc
                                                     。
『到此,板卡配置完成。如果是2,4,8,或者16E1板卡,脚本在安装过程中会自动检测
 第2口,第3口,依此类推。重复执行相应的次数。
```

以下信息星驱动安装时的提示一些特别说明信息,请选择正确的选项。如果选择错误,可以重新执行Setup-sangoma 来重新配置。 以下信息星安装过程中对中国用户的选项,如果成功安装,可以跳过 步骤 4.

5) 注意,在sangoma+asterisk+Dahdi+chan\_ss7 环境下,系统仅仅需要3个核心的配置文件:

- 1) /etc/wanpipe 目录下的 Sangoma 板卡的驱动每个端口的配置文件(wanpipe1.conf wanpipe2.conf wanpipeX.conf),板卡 CRC4,主时钟,硬件板卡的 回声DSP, HDB3配置
- 2) /etc/dahdi/system.conf 控制 bchan mtp2 语音通道配置文件
- 3) /etc/asterisk/ss7.conf 控制asterisk 环境下的应用层(ISPUP,CIC,OPC,DPC 等等)文件,不需要chan\_dahdi.conf 文件

用户需要在/etc/asterisk/ modules.conf 文件中,禁止chan dahdi.so 启动加载。

## 修改wanpipe.conf 文件

注意,如果用户修改了wanpipeX.conf 文件或者 system.conf, 要求用户重新启动wanpipe 驱动(建议重新启动服务器环境)。 具体wanpipe.conf 参数配置的具体信息,请参考:http://wiki.sangoma.com/Wanpipe-Asterisk-Configuration-File @

```
[devices]
wanpipel = WAN_AFT, Comment

[interfaces]
wigl = wanpipel, , TDM_VOICE, Comment

[wanpipel]
CARD TYPE = AFT
SSI4CPU = A
CommPort = PRI
AUTO PCISLOT = NO
PCISIOT = 9
PCIBUS = 2
PF MEDIA = E1
PF LCODE = HDB3
PFF PRAME = NCRC4
PFF LINE = 1
TF CLOCK = NORMAL
TT ERE CLOCK = NORMAL
TT EN HORMIPDEDANCE = NO
PF TXTRISTATE = NO
WIDEPERST 9000
TIPLE 25
LONGE FRONT END = NO
TDMY SFAN = I
TDMY DCHAN = 0 / fløy30, 则代表关闭了dchan, 默认设置为16。
//这里的配置要和/etc/dahdi/system.confy 大部分dchan设置是必须关闭的。如果使用dchan是这里设置为16。
//如果在system.conf 文件中设置了MTP2=16而不使用dchan, 那么这里设置为0。

[wigl]
ACTIVE CH = ALL
TDMW_ECHO_OFF = NO
```

#### 修改system.conf 文件配置

#### 注意,以下配置是以A104D举例,支持4个span.

```
#autogenerated by /usr/sbin/wancfg_dahdi do not hand edit
#autogenrated on 2012-8-09
#Dahdi Channels Configurations
#For detailed Dahdi options, view /etc/dahdi/system.conf.bak
loadzone-cn
defaultzone-cn
defaultzone-cn
span=1,1,0,ccs,hdb3
bchan=1-31
#TDU使用 bchan=1-15,17-31和 MTP2=16 来对接SS7
#hardhdlc=16 // 注释hardhdlc 或者 dchan
#Sangoma Al04 port 2 [slot:4 bus:22 span:2] <wanpipe2>
span=2,2,0,ccs,hdb3
bchan=3-2-62
#Bechocanceller=mg2,32-46,48-62
#bardhdlc=47 // 注释hardhdlc 或者 dchan
#Sangoma Al04 port 3 [slot:4 bus:22 span:3] <wanpipe3>
span=3,3,0,ccs,hdb3
bchan=63-67
#Sangoma Al04 port 3 [slot:4 bus:22 span:3] <wanpipe3>
span=3,3,0,ccs,hdb3
bchan=63-81
#Sangoma Al04 port 4 [slot:4 bus:22 span:4] <wanpipe3>
span=4,0,ccs,hdb3
bchan=63-94-124
#Sangoma Al04 port 4 [slot:4 bus:22 span:4] <wanpipe4>
span=4,0,ccs,hdb3
bchan=94-124
#Schocanceller=mg2,94-108,110-124
#Sandodlc=109 // 注释hardhdlc 或者 dchan
```

### 检查ss7.conf 文件配置

```
[linkset-ls1]
enabled => yes
enable_st => yes
```

```
hunting_policy => even_mru // 支持_even_mru或_odd_lru。CIC呼叫策略,正确选择呼叫策略,可以避免CIC电路双抢的问题,减少呼出语音不同的情况。context => ss7_call // 对应_extensions.conf 文件的标签
context => ss7 call // 対版 extensions.conf 文件的标签 language => en subservice => auto // 主叫地址属性,支持国内有效,国际有限。如果是用户属性local,需要打补丁。查看文档最后的代码。variant => CHINA //设置为中国变种-SS7 ISUP link=ll linkset => ls1 channels => l-15,17-31 schannel => l6 firstcic => 1
 enabled => yes
 echocancel => no
echocan train => 350
echocan taps => 128
  [link-12]
linkset => 1s1
channels => 1-31
schannel =>
firstcic => 33
enabled => yes
  [link-13]
[link-13]
linkset => ls1
channels => 1-31
schannel =>
firstcic => 65
 enabled => yes
 [link-14]
linkset => ls1
 channels => 1-31
schannel =>
firstcic => 97
enabled => yes
                              // host 名称必须是本地服务器的主机名称,请修改到相应的主机名称。否则, asterisk 启动后会显示主机名称不符报错信息。
  [host-sangoma]
[ROSt-Sanguma]
enabled => yes
opc => 0xXXXXXXX; / 和运营商获取源点吗
dpc => ls:10xXXXXXXX; // 和运营商获取目的地点码
links => l1:1,12:2,13:3,14:4 // 对应link数量
```

## 配置呼叫测试的拨号规则

打开呼叫配置文件 vi /etc/extensions.conf,添加以下拨号规则,然后使用分机拨100呼出测试

```
[ss7_call] // 对应 ss7.conf 文件里面的context
exten => 100,1,Dial(ss7/XXXXXXXXXX) // 呼出到XXXXXXXX你的呼出号码
exten => 100,2,Hangup
```

# 第4章:检查SS7状态

## 启动sangoma语音板卡的顺序

Sangoma 的驱动的卸载,加载顺序特别特别,需要用户特别留意。 卸载的流程:

```
asterisk -r 进入后台,执行 core stop now
amportal stop // 如果是elastix 或者 tribox 执行此命令停止asterisk 服务
wanrouter stop
service dahdi stop
```

### 加载的流程:

```
wanrouter start
dahdi cfg -vvvv
safe āsterisk
asterisk -r // 进入Asterisk 后台
```

具体参看资料: http://wiki.sangoma.com/wanpipe-asterisk-operation#wan-ast-zap-stop-start 🗗 10

#### 确认链路连接正常

#### 执行asterisk -r 进入到asterisk CLI

```
CLI> ss7 link status // 如果显示 INSERVICE, 说明链路成功连接, 否则检查线路配置。
linkset sluc, link ll, schannel l6, sls 0, INSERVICE, rx: 0, tx: 3/3, sentseq/lastack: 85/85, total 80657912), 806579216
CLI> ss7 status
linkset idle busy initiating resetting total incoming total outgoing
lsl 300 0 0 0
gwl*CLI> ss7 linestat // 无呼叫,显示 IDLE 闲置状态
Linkset: lsl
CCC 1 Idle
CCC 2 Idle
CCC 2 Idle
CCC 3 Idle
CCC 4 Idle
CCC 4 Idle
CCC 6 Idle
CCC 7 Idle
CCC 7 Idle
CCC 9 Idle
CCC 9 Idle
CCC 9 Idle
CCC 10 Idle
CCC 11 Idle
CCC 11 Idle
CCC 11 Idle
CCC 12 Idle
CCC 13 Idle
CCC 13 Idle
CCC 13 Idle
CCC 15 Idle
CCC 17 Idle
```

以上命令检查无错误,就可以开始测试呼叫。

第5章:呼叫测试语音线路

添加拨号规则以后,重新reload asterisk 模块,使用分机拨打100就可以测试呼出。

## 第6章:7号信令常见问题排查

```
1)如果链路正常,呼叫有振令,但是互相听不到语音,检查CIC配置。默认是0,询问运营商此项配置的具体值
3) BNC长头,短头用法:短头-Rx-12,长头-Tx-45。
4) 通常使用的E1线包括:直通线(连接运营商),交叉线(两张板卡对测),回环测试线(板卡端口之间对接测试)。
5) 直通线/交叉线/回环测试线的做法: E1线的做法和线序 @。
6) SS7 开源的协议栈包括chan ss7 和libss7。
7) chan_ss7 支持中国SS7 ISUP。TUP模块不建议使用。
8) 原号码透传在asterisk-1.6 版本可以支持,发送到对端。asterisk-1.8 不支持。
建议使用比较旧的版本,然后修改运营商设置的用户属性,重新设置rdnis
9) chan_ss7 可以在elastix 上重新配置,但是应用层的模块可能出现错误,例如CDR,FOP。
10) 目前ss7 除了支持sangoma, digium 以外还可以支持openvox, Atcom, 三汇语音板卡。
11) 除了Sangoma语音板卡可以实现SS7进入方案,可以选择sangoma ss7设备进入的方式:
7号信令设备 🗗
12) chan ss7 如何提高修改代码支持用户属性:
关于主叫地址性质的修改,参见l4isup.c
 /* Calling party's category Q.763 (3.11). */
- param[0] = 0x0a; /* Ordinary calling subscriber */
+ param[0] = 0x0c; /* Local User */
 isup_msg_add_fixed(msg, sizeof(msg), &current, param, 1);
13) 解决原呼叫号码诱传问题,建议使用asterisk-1.4, 1.6版本,修改用户属性,然后重新设置rdnis。
```

13)解决原呼叫号码透传问题,建议使用asterisk-1.4,1.6版本,修改用户属性,然后重新设置rdnis。14)如何通过不同的链路组或者指定的CICIP出

语法:

```
Dial(SS7/Linkset1:33/number)
Dial(SS7/Linkset1/number)
```

#### patch:

```
--- 14isup.c.orig 2010-04-14 13:32:30.000000000 +0200
+++ 14isup.c 2010-04-14 13:31:39.000000000 +0200
@@ -525,7 +525,7 @@
@@ -537,6 +537,10 @@
           if(!cur->reset_done || (cur->blocked & (BL_LH|BL_RM|BL_RH|BL_UNEQUIPPED|BL_LINKDOWN))) {
  continue;
           /* is this cic within the selected range? */
if(cur->cic < first_cic || cur->cic > last_cic) {
   continue;
           if((cur->cic % 2) == odd) {
best = cur;
best_prev = prev;
00 -558,7 +562,7 00
  /* This implements the policy: Primary hunting group even CICs, secondary
/* This implements the policy: Frimary nunting group even CLCs, secondary hunting group odd CTCs. Choose most recently used CTC. */
-static struct ss7 chan *cic hunt even mru(struct linkset* linkset) {
+static struct ss7 chan *cic hunt even mru(struct linkset* linkset, int first_cic, int last_cic) {
    struct ss7_chan *cur, *prev, *Dest, *best_prev;
best = NULL;
@@ -569,6 +573,10 @@
if(!cur->reset_done || (cur->blocked & (BL_LH|BL_RM|BL_RH|BL_UNEQUIPPED|BL_LINKDOWN))) {
       /* is this cic within the selected range? */
if(cur->cic < first_cic || cur->cic > last_cic) {
  continue;
        // if((cur->cic % 2) == 0) {
  /* Choose the first idle even circuit, if any. */
  best = cur;
 00 -597,7 +605,7 00
 /* This implements the policy: Sequential low to high CICs */
-static struct ss7 chan *cic hunt seq lth htl(struct linkset* linkset, int lth)
+static struct ss7-chan *cic_hunt_seq_lth_htl(struct linkset* linkset, int lth, int first_cic, int last_cic)
     struct ss7 chan *cur, *prev, *best = NULL, *best prev = NULL;
@@ -606,6 +614,10 @@
if(!cur->reset_done || (cur->blocked & (BL_LH|BL_RH|BL_RH|BL_UNEQUIPPED|BL_LINKDOWN))) {
           continue;
         /* is this cic within the selected range? */
       if(cur->cic < first_cic || cur->cic > last_cic) {
        if (!best) {
           best = cur;
           continue:
@@ -815,21 +827,30 @@
```

```
/^ nunt free CLC //
-static struct ss7 chan* cic hunt(struct linkset* linkset)
+static struct ss7 chan* cic hunt(struct linkset* linkset, int first cic, int last cic)
     if(first_cic > last_cic) {
   ast_log(LOG_ERROR, "first CIC: %d greater than last CIC: %d\n", first_cic, last_cic);
   return NULL;
    if(first_cic < linkset->first_cic || first_cic > linkset->last_cic || last_cic > linkset->last_cic) {
   ast_log(LOG_ERROR, "CICs not in valid range, first: %d last: %d\n", first_cic, last_cic);
   return NULL;
      struct ss7 chan* pvt;
switch(linkset->hunt_policy) {
case HUNT_ODD_LRU:
        במפב אטאו טטט גאט:

pvt = clc hunt odd lru(linkset);

pvt = cic hunt_odd_lru(linkset, first_cic, last_cic);

break;
     case HUNT EVEN MRU:
    case HUNT_EVEN MRU:
   pvt = cic hunt_even_mru(linkset);
   pvt = cic_hunt_even_mru(linkset, first_cic, last_cic);
   break;
case HUNT_SEQ_LTH:
        pvt = cic hunt_seq_lth_htl(linkset, 1);
pvt = cic_hunt_seq_lth_htl(linkset, 1, first_cic, last_cic);
break;
     case HUNT SEQ HTL:
        case now1_Sew_Hill:
pvt = cic hunt seq_lth_htl(linkset, 0);
pvt = cic_hunt_seq_lth_htl(linkset, 0, first_cic, last_cic);
break;
break;
default;
pvt = NULL;
pvt = NULL;
ee -847,6 +868,7 ee
struct ss7 cham *pvt;
struct linkset linkset = this host->default_linkset;
char *sep = strchr(arg, '/');
+ char *cic_sep = strchr(arg, ':');
      ast log(LOG DEBUG, "SS7 request (%s/%s) format = 0x%X.\n", type, arg, format);
 @@ -857,16 +879,58 @@
      if (sep) {
  char name buf[100];
         strncpy(name_buf, arg, sep-arg);
name_buf[sep-arg] = 0;
         // linkset:cics -> link1:10-21
if(cic sep != NULL) {
   strncpy(name_buf, arg, cic_sep-arg);
   name_buf[cic_sep-arg] = 0;
          else {
                strncpy(name_buf, arg, sep-arg);
name_buf[sep-arg] = 0;
         linkset = lookup linkset(name buf);
         if (llinkset) { ast log(LOG ERROR, "SS7 requester: No such linkset: '%s', using default\n", name_buf); linkset = this_host->default_linkset;
     lock_global();
pvt = cic hunt(linkset);
      // CIC selection via dial parameter // TODO check if cics extracted are numeric before calling atoi()
      if(cic_sep != NULL) {
// use specific cics
            char cics[100];
char first cic[10], last cic[10];
             // copy xxx:xxx part
            strncpy(cics, cic_sep + 1, sep-cic_sep-1);
cics[sep-cic_sep] = '\0';
            char *cics sep = strchr(cics, '-');
             if(cics sep != NULL) {
             // copy eic parts
// copy eic parts
strncpy(first cic, cics, cics sep-cics);
strncpy(last cic, cics sep + 1, strlen(cics) - (cics_sep-cics) - 2);
 + first_cic[cics_sep-cics] = '\0';
+ last_cic[strlen(cics) - (cics_sep-cics) - 2] = '\0';
                pvt = cic hunt(linkset, atoi(first cic), atoi(last cic));
             else {
       // single CIC
int cic = atoi(cics);
                   pvt = cic_hunt(linkset, cic, cic);
     else {
            pvt = cic hunt(linkset, linkset->first cic, linkset->last cic);
     if(pvt == NULL) {
 unlock_global();
@@ -2789,7 +2853,9 @@
    ! -2789,7 +2853,9 @@
t7_clear(pyt);
pvT->owner = NULL;
chan->tech pvt = NULL;
newpvt = clc hunt(pvt->link->linkset);
ast log(LOG WARNING, "Reattempt call: hunting on all cics\n");
// Todo: use cics specified in dial parameters
newpvt = clc hunt(pvt->link->linkset, pvt->link->linkset->first_cic, pvt->link->linkset->last_cic);
      if (newpyt)
         ast mutex lock(&newpvt->lock);
ast loc(LOG DEBUG, "Reattempt call: Got cic %d\n", newpvt->cic);
```

15) 如何查看E1线路物理连接状态是否正常,请参考 http://wiki.voip88.com/index.php/Sangoma @

16) Sangoma wanpipe 命令使用手册,请参考 http://wiki.voip88.com/index.php/Sangoma @ 17) 打包Sangoma 系统日志,请参考 http://wiki.voip88.com/index.php/Sangoma @ 本页面最后修订于2014年7月4日 (星期五) 14:26. 此页面已被浏览过5.624次. 隐私权政策 关于VoIP88 Wiki 免责声明