

PRECHG is powered via a teensy when the teensy receives the shutdown signal from the rest of the car. Once the TS is precharged, PRECHG turns off, opening the Precharge relay.

